

<b>Item Code</b>	<b>Item Description</b>	<b>Brand</b>
01100341	CIRCLIP OIL SEAL LOCK	Bajaj spare parts
01100342	BEARING BALL	Bajaj spare parts
01100355	SEAL OIL MAGN SIDE	Bajaj spare parts
01100610	KEY WOODRUFF MAGNETO	Bajaj spare parts
01100611	KEY WOODRUFF CLUTCH	Bajaj spare parts
01100612	WASHER FAN DISC	Bajaj spare parts
01100614	RING LOCK FOR NUT	Bajaj spare parts
01100711	RING SHOULDER 1 TO 5	Bajaj spare parts
01100712	SHOULDER RING	Bajaj spare parts
01100713	RING SHOULDER NO. 3	Bajaj spare parts
01100714	RING SHOULDER NO. 4	Bajaj spare parts
01100804	SPRING CLUTCH	Bajaj spare parts
01100817	RING LOCK	Bajaj spare parts
01100818	WASHER BRASS	Bajaj spare parts
01100905	RING O	Bajaj spare parts
01101008	ROLLER	Bajaj spare parts
01101009	BEARING	Bajaj spare parts
01101205	SPRING RETURN	Bajaj spare parts
01110609	WASHER PLAIN	Bajaj spare parts
01160508	WASHER - LOCK	Bajaj spare parts
01160717	CLIP LOCK	Bajaj spare parts
01170110	BEARING BALL	Bajaj spare parts
01170111	BEARING BALL	Bajaj spare parts
01170119	NUT FOR AXLE	Bajaj spare parts
01170122	RING - O	Bajaj spare parts
01180123	BALL STEEL	Bajaj spare parts
01190205	WASHER SPRING	Bajaj spare parts
01200213	WASHER CUP	Bajaj spare parts
03100335	BEARING NEEDLE	Bajaj spare parts
03100338	BEARING +STEEL CAGE	Bajaj spare parts
03100619	BEARING ROLLER SMALL	Bajaj spare parts
03100620	BEARING ROLLER SMALL	Bajaj spare parts
03100621	BEARING ROLLER SMALL	Bajaj spare parts
03100718	BOLT FOR RR WHEEL	Bajaj spare parts
03100802	BOX CLUTCH	Bajaj spare parts
03100826	PLATE INNER WITH BUSH	Bajaj spare parts
03150207	RING O	Bajaj spare parts
03170109	PIN	Bajaj spare parts
03170127	CIRCLIP	Bajaj spare parts
03180116	RING O	Bajaj spare parts
03190204	WASHER PLAIN	Bajaj spare parts
03190206	WASHER PLAIN	Bajaj spare parts
04101027	KIT PLATE CLUTCH	Bajaj spare parts
05101018	BEARING NEEDLE	Bajaj spare parts

05101051	BREATHER ASSEMBLY	Bajaj spare parts
05101071	KIT PLATE CLUSTER GEAR	Bajaj spare parts
05101072	PLATE THRUST	Bajaj spare parts
05101083	ADJUSTER WITH NUT	Bajaj spare parts
05151012	ADJUSTER WITH NUT	Bajaj spare parts
05161256	NUT - CLIP :- M6	Bajaj spare parts
05181011	BALL STEEL+NYLONCAGE	Bajaj spare parts
05190301	DRIVE COMP SPEEDOMETER	Bajaj spare parts
05190302	GEAR ASSY NYLON	Bajaj spare parts
05191005	SUPPORT	Bajaj spare parts
05201146	REGULATOR	Bajaj spare parts
06100702	STEM SUPER / CHETAK / M80	Bajaj spare parts
06101007	GEAR STARTER	Bajaj spare parts
06101009	BEARING BALL	Bajaj spare parts
06101049	GEAR SHIFTER ASSY	Bajaj spare parts
06101056	CROSS	Bajaj spare parts
06101111	SCREW FOR BRACKET	Bajaj spare parts
06101112	SPRING	Bajaj spare parts
06101196	PIN-GUDGEON M/S SAMKRG piston	Bajaj spare parts
06101213	SPACER CLASSIC	Bajaj spare parts
06101218	ROD CONNECTING SCOOTER	Bajaj spare parts
06111350	CAP SPARK PLUG	Bajaj spare parts
06141010	PIPE FUEL	Bajaj spare parts
06160713	SPRING FOR LOCK	Bajaj spare parts
06180303	SPRING	Bajaj spare parts
06191023	CABLE ACC SCOOTER	Bajaj spare parts
06191061	LUBRICATOR ASSY	Bajaj spare parts
06191089	GRIP HAND CLASSIC	Bajaj spare parts
06191116	TUBE GEAR CONTROL + SLEEV	Bajaj spare parts
06201083	LAMP 12V 10W	Bajaj spare parts
06221028	PAD SHOCK	Bajaj spare parts
07181009	BALL STEEL+NYLON CAGE	Bajaj spare parts
08111018	COIL CHARGING	Bajaj spare parts
13101024	SHAFT ROCKER ARM	Bajaj spare parts
13101031	CAP	Bajaj spare parts
13101165	GASKET	Bajaj spare parts
14151021	SEAL OIL 30 X 17 X 6	Bajaj spare parts
14151033	BEARING BALL	Bajaj spare parts
15101011	BEARING BALL	Bajaj spare parts
15101122	GASKET	Bajaj spare parts
15101146	GEAR CORONA	Bajaj spare parts
15101171	RING SPACER	Bajaj spare parts
15151066	BEARING BALL	Bajaj spare parts
15161069	CAP RUBBER	Bajaj spare parts
15181032	PLATE COVER	Bajaj spare parts

15181033	SPRING WASHER	Bajaj spare parts
16101022	KIT GASKET M80	Bajaj spare parts
16111115	COIL PICKUP	Bajaj spare parts
16111125	PLUG SPARK WR4AC	Bajaj spare parts
16121138	NEEDLE ASSEMBLY	Bajaj spare parts
16151008	LINK CONNECTING SPRING FA	Bajaj spare parts
16151066	NIPPLE SPOKE	Bajaj spare parts
16201055	SPRING STOP SWITCH	Bajaj spare parts
18141041	CAP ASSY	Bajaj spare parts
18201044	LAMP :- 12V - 10W - R 10W	Bajaj spare parts
19101003	GASKET HEAD CYLINDER	Bajaj spare parts
19101016	RING SHOULDER	Bajaj spare parts
19101017	RING SHOULDER NO. 2	Bajaj spare parts
19101018	RING SHOULDER NO. 3	Bajaj spare parts
19101019	RING SHOULDER NO. 4	Bajaj spare parts
19101020	RING SHOULDER NO. 5	Bajaj spare parts
19151008	BEARING NEEDLE	Bajaj spare parts
19161151	RIVET PUSH (BLACK COLOUR)	Bajaj spare parts
20101020	GASKET ALUMINIUM	Bajaj spare parts
20201029	"LAMP 12V 21/5W, P 21/5W"	Bajaj spare parts
21100324	CIRCLIP	Bajaj spare parts
21100711	CIRCLIP main shaft	Bajaj spare parts
21101427	SPRING	Bajaj spare parts
21101429	CLIP SPRING	Bajaj spare parts
21150307	TYRE FOR 3 WHEELER	Bajaj spare parts
21150420	PIN FORK	Bajaj spare parts
21150422	PACKING WASHER COPPER	Bajaj spare parts
21160417	PLATE REINFORCEMENT	Bajaj spare parts
21170419	CIRCLIP	Bajaj spare parts
21180307	KNOB	Bajaj spare parts
21180308	SPRING	Bajaj spare parts
22101115	GRIP - STARTING HANDLE	Bajaj spare parts
22101423	PLUG	Bajaj spare parts
22131014	SPACER	Bajaj spare parts
22131018	GEAR SATELLITE	Bajaj spare parts
22150240	SPRING RETURN	Bajaj spare parts
22150241	WASHER PLAIN	Bajaj spare parts
22150435	BOLT	Bajaj spare parts
22150451	SCREW CYLINDER SECURING	Bajaj spare parts
22150507	RATCHET	Bajaj spare parts
22151067	PIN FOR HAND BRAKE CO	Bajaj spare parts
22151081	DISC COMPLETE LEFT	Bajaj spare parts
22151097	BOTTLE BRAKE FLUID	Bajaj spare parts
22151106	DRUM BRAKE C.I.4S PETR /	Bajaj spare parts
22161193	STRIP - FOAM	Bajaj spare parts

22161221	NUMBER PLATE DIMENS	Bajaj spare parts
22161238	BRACKET FR NUMBR PL	Bajaj spare parts
22170115	SEAL OIL	Bajaj spare parts
22170117	SPACER	Bajaj spare parts
22170118	SPACER	Bajaj spare parts
22170434	BOLT FOR AXLE	Bajaj spare parts
22171007	SEAL OIL	Bajaj spare parts
22180219	PLATE LOCK STEERING	Bajaj spare parts
22181058	ST LOCK PLATE ASSY	Bajaj spare parts
22191096	SPEEDO CABL1095 445	Bajaj spare parts
22191097	SPEEDO CABL1094 145	Bajaj spare parts
22230635	WIPER ASSEMBLY	Bajaj spare parts
22231142	BEADING RUBBER + KEY	Bajaj spare parts
22231258	GLASS CENTRAL LAPPLE WIND	Bajaj spare parts
22250132	ELECT CABLE ASSY	Bajaj spare parts
23161305	NIPPLE GREASE	Bajaj spare parts
24100305	BUSH	Bajaj spare parts
24100308	BEARING BALL	Bajaj spare parts
24100703	GEAR SPEED 4	Bajaj spare parts
24100808	PLATE THRUST	Bajaj spare parts
24100907	LEVER INTERNAL	Bajaj spare parts
24100908	PLUNGER	Bajaj spare parts
24101050	GEAR SHIFTER ASSY RE 2S	Bajaj spare parts
24101054	GEAR MULTIPLE	Bajaj spare parts
24101055	GEAR MULTIPLE	Bajaj spare parts
24101056	PIN GEAR MULTIPLE	Bajaj spare parts
24101064	LEVER INTERNAL	Bajaj spare parts
24101069	BREATHER ASSEMBLY	Bajaj spare parts
24101077	GEAR SHIFTER ASSY RE 2S	Bajaj spare parts
24101087	TUBE STARTING	Bajaj spare parts
24101100	SHAFT MAIN	Bajaj spare parts
24101114	KIT PLATE CLUSTER GEAR	Bajaj spare parts
24101155	COWLING .RE 2S	Bajaj spare parts
24101177	HANDLE STARTING WITH GRIP	Bajaj spare parts
24101201	GEAR ASSY SECTOR	Bajaj spare parts
24101203	DOG DRIVEN	Bajaj spare parts
24101206	CRANKSHAFT ASSY	Bajaj spare parts
24101409	PIN LEVER SUPPORT	Bajaj spare parts
24101414	WASHER	Bajaj spare parts
24101419	NUT HEX L H THREAD	Bajaj spare parts
24101421	PIN	Bajaj spare parts
24101422	PIN	Bajaj spare parts
24101545	PIVOT CLUTCH	Bajaj spare parts
24101546	ROD-CONNECTING FOR `3WH-2S-RE'	Bajaj spare parts
24101557	GEAR ASSY MULTIPLE	Bajaj spare parts

24101590	CRANKSHAFT	Bajaj spare parts
24101614	PLUNGER	Bajaj spare parts
24101615	TUBE CONNECTING ASSY	Bajaj spare parts
24101616	CONNECTOR TUBE CONN. AS	Bajaj spare parts
24101621	BASE PLATE ASSLY	Bajaj spare parts
24101629	CYL BL PIST ASSY	Bajaj spare parts
24101674	CLUTCH COVER	Bajaj spare parts
24101676	CLUTCH LEVER ASSy	Bajaj spare parts
24101702	COLLAR	Bajaj spare parts
24101711	NUT M14X1	Bajaj spare parts
24101712	LOCK WASHER	Bajaj spare parts
24101714	WASHER MG PIN	Bajaj spare parts
24101720	BUSH FOR EYE PIN	Bajaj spare parts
24101723	GASKET HEAD CYLINDER	Bajaj spare parts
24101746	WHEEL CLUTCH	Bajaj spare parts
24101751	PLATE CLUTCH	Bajaj spare parts
24101764	CRANKCASE MAGNETO SIDE-FACELIFT	Bajaj spare parts
24101766	COVER SPARKPLUG FACELIFT	Bajaj spare parts
24101771	GROMMET COVER FAN FACELIFT	Bajaj spare parts
24101774	CYLINDER PISTON ASSY	Bajaj spare parts
24101779	ASSLY MANIFOLD AIR INTAKE	Bajaj spare parts
24101781	CLUTCH COMPLETE	Bajaj spare parts
24101782	GEAR ENGINE	Bajaj spare parts
24101784	ENGINE ASSLY COMPLETE	Bajaj spare parts
24101791	GEAR CORONA	Bajaj spare parts
24101792	GEAR MULTIPLE ASSY COMP	Bajaj spare parts
24101793	ASSLY LEVER AND SECTOR	Bajaj spare parts
24101803	GEAR 4TH SPEED	Bajaj spare parts
24101804	GEAR 3RD SPEED	Bajaj spare parts
24101805	GEAR 2ND SPEED	Bajaj spare parts
24101806	GEAR 1ST SPEED	Bajaj spare parts
24101817	CRANKCASE MAGNETO SIDE FL NES	Bajaj spare parts
24101825	ENGINE ASSLY COMPLETE	Bajaj spare parts
24101829	ASSLY SHAFT PROPELLER	Bajaj spare parts
24101830	ASSLY SHAFT PROPELLER COMP	Bajaj spare parts
24101870	ASSEY CRANKSHAFT COMP	Bajaj spare parts
24101871	DRIVE SHAFT	Bajaj spare parts
24101875	ASSLY SILENCER WITH SAI	Bajaj spare parts
24101879	CLIP CABLE	Bajaj spare parts
24101880	ASSLY STARTING TUBE COMP. FL	Bajaj spare parts
24101881	ASSLY STARTING TUBE FL	Bajaj spare parts
24101888	ASSLY SILENCER	Bajaj spare parts
24101899	PIN MULTIPLE GEAR	Bajaj spare parts
24101900	CRANKCASE CLUTCH SIDE FL	Bajaj spare parts
24101901	COVER CLUTCH	Bajaj spare parts

24101925	ASSLY PISTON SAMKRG RE145FL	Bajaj spare parts
24101929	SPRING TORSION CLUTCH RETURN	Bajaj spare parts
24101935	ASSLY SILENCER BASF CAT-SAI	Bajaj spare parts
24101937	GEAR MULTIPLE ASSY COMP RE	Bajaj spare parts
24101938	GEAR MULTIPLE RE145FL	Bajaj spare parts
24101939	GEAR 2ND SPEED RE145FL	Bajaj spare parts
24101941	COVER GEAR SHIFTER	Bajaj spare parts
24101944	GROMMET SPARK PLUG-FL	Bajaj spare parts
24101945	ASSLY COVER GEAR SHIFTER	Bajaj spare parts
24101946	ASSLY GEAR SHIFTER	Bajaj spare parts
24101948	ASSLY GEAR SHIFTER (NES)	Bajaj spare parts
24101954	BRACKET CABLE GUIDE	Bajaj spare parts
24101962	SLEEVE MAIN SHAFT	Bajaj spare parts
24101963	SHAFT MAIN	Bajaj spare parts
24101964	ASSLY CRANKSHAFT	Bajaj spare parts
24101971	ASSLY SHROUD LH	Bajaj spare parts
24101974	ASSLY SILENCER WITH SAI BSIV	Bajaj spare parts
24101977	ASSLY ENGINE COMPACT 2S BSIV	Bajaj spare parts
24101978	ASSLY CYL. BLOCK PISTON	Bajaj spare parts
24102002	ASSLY PROPELLER SHAFT COMP	Bajaj spare parts
24102003	ASSLY PROPELLER SHAFT	Bajaj spare parts
24102007	GROMMET SPARK PLUG	Bajaj spare parts
24102017	ASSLY MAIN SHAFT COMP	Bajaj spare parts
24102023	GRILL AIR INTAKE	Bajaj spare parts
24102028	SILENCER ASSLY	Bajaj spare parts
24102046	BREATHER	Bajaj spare parts
24102062	ENGINE ASSEMBLY	Bajaj spare parts
24111024	COIL CHARGING	Bajaj spare parts
24111062	COIL L.T.NO.1FOR12V	Bajaj spare parts
24111065	COIL L.T.NO.2FOR12V	Bajaj spare parts
24111099	CHARGING COIL	Bajaj spare parts
24111109	GROMMET (H.T.CABLE/CAP)	Bajaj spare parts
24111113	RUBBER GROMMET (H.T. CABLE)	Bajaj spare parts
24111121	COIL H T RED FO	Bajaj spare parts
24111124	STATOR ASSYHI POWER	Bajaj spare parts
24111128	CDI WITH DAMPER(NEW)	Bajaj spare parts
24111132	CDI GAS PETR SOLEN	Bajaj spare parts
24111155	ROTOR ASSEMBLY(25DEG)	Bajaj spare parts
24111188	CDI DC FOR RE 145CNG/LPG	Bajaj spare parts
24111189	CDI DC FOR RE145 D PETROL	Bajaj spare parts
24111200	COIL ASY PICK UP	Bajaj spare parts
24111202	ROTOR ASSY.COMPLETE	Bajaj spare parts
24111205	STATOR ASSLY	Bajaj spare parts
24111207	H.T.COIL WITH CABLE -LH	Bajaj spare parts
24111210	ROTOR ASSY. (15 DEG.)	Bajaj spare parts

24111218	MAGNETO ASSLY.	Bajaj spare parts
24111219	ASSLY ROTOR 1 PHASE KS	Bajaj spare parts
24116148	WASHER -IGLIDUR	Bajaj spare parts
24116149	PLUG SPARK (RL82C)	Bajaj spare parts
24116157	COIL HT ASSY WITH CAP	Bajaj spare parts
24116169	STATOR ASSLY RE COMPACT ES	Bajaj spare parts
24121053	PLUNGER ASSY	Bajaj spare parts
24121060	CAP ASSY TOP	Bajaj spare parts
24121065	SCREW AIR	Bajaj spare parts
24121066	VALVE PISTON	Bajaj spare parts
24121067	RING O	Bajaj spare parts
24121069	PIN FLOAT	Bajaj spare parts
24121070	SEAT VALVE VS	Bajaj spare parts
24121072	JET PILOT	Bajaj spare parts
24121073	GASKET	Bajaj spare parts
24121074	JET NEEDLE	Bajaj spare parts
24121075	NEEDLE JET	Bajaj spare parts
24121076	PACKING	Bajaj spare parts
24121077	JET MAIN	Bajaj spare parts
24121079	FLOAT ASSY	Bajaj spare parts
24121080	SCREW IDLING	Bajaj spare parts
24121087	SPRING	Bajaj spare parts
24121118	CARBURETTOR 3WH2SRE RE 2S	Bajaj spare parts
24121127	NEEDLE JET	Bajaj spare parts
24121128	JET NEEDLE	Bajaj spare parts
24121145	ELEMENT AIR FILTER	Bajaj spare parts
24121244	WASHER FOR FLEX HOSE	Bajaj spare parts
24121245	INSERT BELLOW	Bajaj spare parts
24121249	CASE UPP SEAL BOX VA	Bajaj spare parts
24121250	RING O TOP FOR SEAL	Bajaj spare parts
24121262	CONNECTOR-M/S.VANAZ LPG KIT	Bajaj spare parts
24121266	RETAINER MFVM/S. VA	Bajaj spare parts
24121267	KNOB MFV M/S.VANAZ	Bajaj spare parts
24121268	FILTER MFV VANAZ LPG	Bajaj spare parts
24121275	SCREW GRUB M4X6 L MFV-M/S. VANAZ LPG KIT	Bajaj spare parts
24121283	WASHER SEALING MFV V	Bajaj spare parts
24121289	SPRING GUIDE MFV - M/S. VANAZ LPG KIT	Bajaj spare parts
24121294	WASHER BRASS MFV - M/S. VANAZ LPG KIT	Bajaj spare parts
24121298	LEVER VANAZ LPG	Bajaj spare parts
24121299	PIN LEVER VANAZ LPG	Bajaj spare parts
24121303	GUIDE SPRING VANAZ	Bajaj spare parts
24121304	SPRING M/S LPG KIT	Bajaj spare parts
24121306	WASHER RUBBER	Bajaj spare parts
24121312	LEVER SUB ASSY 1ST S	Bajaj spare parts
24121313	SEAT 1ST STAGE VANA	Bajaj spare parts

24121314	RUBBER WASHER 1ST SA	Bajaj spare parts
24121315	WASHER COPPER LPG KIT	Bajaj spare parts
24121316	CONNECTOR INLET VAN	Bajaj spare parts
24121317	SPRING VACUUM - M/S.	Bajaj spare parts
24121318	DIAPHRAGM ASSY.VACU	Bajaj spare parts
24121321	RING O FL CON	Bajaj spare parts
24121327	PLUG PR CHECK	Bajaj spare parts
24121333	CLIP VACUUM HOSE VA	Bajaj spare parts
24121337	CONNECTOR FILLER VA	Bajaj spare parts
24121354	CLIP LOW PR CNG HOS	Bajaj spare parts
24121356	MIXER TUBE (NYLON)	Bajaj spare parts
24121361	SEALCARBURETTOR	Bajaj spare parts
24121365	FLOAT ASSEMBLY	Bajaj spare parts
24121367	JET MAIN	Bajaj spare parts
24121371	JET NEEDLE	Bajaj spare parts
24121393	KNOB	Bajaj spare parts
24121394	CAP	Bajaj spare parts
24121398	RING O LPG FILTE	Bajaj spare parts
24121400	FILTER ELEMENT LPG	Bajaj spare parts
24121407	BRACKET FILLING VALV	Bajaj spare parts
24121413	ASSEMBLY 1ST STAGE RED. U	Bajaj spare parts
24121418	SEAL BOX ZERO DEG	Bajaj spare parts
24121427	REGULATOR LPG 2 STAG	Bajaj spare parts
24121432	FILLER CONNECTOR WIT	Bajaj spare parts
24121434	HOSE MFV TO LPR	Bajaj spare parts
24121437	PUMP OIL ASSY	Bajaj spare parts
24121449	IDLING ADJUSTER KIT	Bajaj spare parts
24121456	CONNECTOR SS FOR CNG	Bajaj spare parts
24121457	CARBURETOR ASSEMBLY	Bajaj spare parts
24121458	ASSEMBLY SAI	Bajaj spare parts
24121460	TUBE SAI INLET	Bajaj spare parts
24121462	SILENCER FOR SAI	Bajaj spare parts
24121467	TUBE OIL INLET OIL PUMP	Bajaj spare parts
24121472	INTEGRAL DUCT	Bajaj spare parts
24121474	INSERT FOR BELLOW	Bajaj spare parts
24121476	SPRING BAND(DIA16.8) HOSE	Bajaj spare parts
24121477	CLAMP HOSE	Bajaj spare parts
24121485	SCREW AIR KIT	Bajaj spare parts
24121486	JET KIT	Bajaj spare parts
24121487	PISTON VALUE ASSLY KIT	Bajaj spare parts
24121488	MIXING CAP ASSLY. KIT	Bajaj spare parts
24121494	JET KIT	Bajaj spare parts
24121498	HOSE SOLENOID TO LPR	Bajaj spare parts
24121500	HOSE HPR TO SOLENOID	Bajaj spare parts
24121504	SPRING	Bajaj spare parts



24121505	CONNECTER INLET	Bajaj spare parts
24121506	SCREW FLOW ADJUSTING	Bajaj spare parts
24121507	BODY -FLOW CONTROL	Bajaj spare parts
24121508	TUBE OVERFLOW CARB.	Bajaj spare parts
24121642	FILTER AIR SAI TYPE	Bajaj spare parts
24121645	DUCT INLET AIR FILTER	Bajaj spare parts
24121646	HOOK FOR SAI TUBE	Bajaj spare parts
24121648	BREATHER RESTRICTOR	Bajaj spare parts
24121649	HOSE BREATHER	Bajaj spare parts
24121652	FILTER FUEL	Bajaj spare parts
24121655	KIT LPG V RE2S 3W UG	Bajaj spare parts
24121656	PETR SOLENOID	Bajaj spare parts
24121664	ASSLY COMP.INTEGRAL DUCT	Bajaj spare parts
24121669	TUBE OIL CYL.BLOCK	Bajaj spare parts
24121670	TUBE OIL MANIFOLD	Bajaj spare parts
24121674	HOSE OIL OUT	Bajaj spare parts
24121676	CARBURETOR ASSY	Bajaj spare parts
24121682	ASSLY FUEL TANK WELD FL	Bajaj spare parts
24121695	ASSLY FUEL COCK FL	Bajaj spare parts
24121698	SEAL FUEL TAP FL 24121698	Bajaj spare parts
24121703	ASSLY BRACKET SAI. 145FL	Bajaj spare parts
24121704	TUBE SAI OUTLET 145FL	Bajaj spare parts
24121709	SLEEVE CARBURETTOR FL	Bajaj spare parts
24121716	TUBE S.A.I. INLET	Bajaj spare parts
24121721	BELLOW-ACC.CABLE	Bajaj spare parts
24121722	CLIP SPRING BAND	Bajaj spare parts
24121729	CLAMP	Bajaj spare parts
24121738	ASSLY CARBURETTOR BS-4	Bajaj spare parts
24121749	CLAMP	Bajaj spare parts
24130105	BEARING BALL	Bajaj spare parts
24130106	SHAFT SPLINED	Bajaj spare parts
24130111	BUSH HSG BEVEL GEAR	Bajaj spare parts
24130113	PIN	Bajaj spare parts
24130118	GEAR IDLER	Bajaj spare parts
24130209	GEAR FARE METER	Bajaj spare parts
24131002	PINION FARE METER	Bajaj spare parts
24131003	WIRE	Bajaj spare parts
24131007	BUSH	Bajaj spare parts
24131008	PLUG	Bajaj spare parts
24131009	GEAR BEVEL	Bajaj spare parts
24131016	GEAR REVERSE CON.	Bajaj spare parts
24131017	HSG SATELLITE GEAR	Bajaj spare parts
24131032	PIN GEAR BEVEL	Bajaj spare parts
24131046	LEVER AND SECTOR COM.	Bajaj spare parts
24131069	BEVEL GEAR SAT GEAR HSG S	Bajaj spare parts

24131070	BEVEL GEAR DIFF GEAR SIDE	Bajaj spare parts
24131072	SHAFT ASSY PROPELLER	Bajaj spare parts
24131074	BELLOW PROPELLER SHAFT	Bajaj spare parts
24131078	COVER DIFFERENTIAL	Bajaj spare parts
24131088	COMP. REV. LEVER <(>	Bajaj spare parts
24131098	NIPPLE GREASE	Bajaj spare parts
24131101	BOLT FLANGE M7X1 80L	Bajaj spare parts
24131116	BRACKET REVERSE CABLE	Bajaj spare parts
24140115	RING O	Bajaj spare parts
24141090	TANK FUEL RE 2S	Bajaj spare parts
24141091	CLIP SPRING	Bajaj spare parts
24141094	TANK FUEL 3 LITRE	Bajaj spare parts
24141132	PULLEY TAP SIDE	Bajaj spare parts
24141133	PULLEY KNOB SIDE	Bajaj spare parts
24141134	INSERT KNOB MOUNTING	Bajaj spare parts
24141135	SPACER FOR KNOB MOUNTING	Bajaj spare parts
24141136	BRACKET FUEL KNOB MTG	Bajaj spare parts
24141137	KNOB FUEL TAP OPERATION	Bajaj spare parts
24141139	PIPE TANK FUEL TO COCK (GREY)	Bajaj spare parts
24141140	TUBE FUEL COCK FILTER	Bajaj spare parts
24141141	TUBE FUEL FILTER TO CAR	Bajaj spare parts
24141148	FUEL COCK WITH CABL	Bajaj spare parts
24141149	TANK ASSEMBLY COMP	Bajaj spare parts
24141152	ASSY PIPE FUEL WITH FILTER	Bajaj spare parts
24141153	CLAMP	Bajaj spare parts
24141164	KNOB FUEL TAP OPERATION	Bajaj spare parts
24141165	ASSLY FUEL TAP	Bajaj spare parts
24141166	BRACKET FUEL KNOB MOUNTING	Bajaj spare parts
24141175	ASSLY FUEL TANK WELD FL	Bajaj spare parts
24141183	PLUG SEAT FUEL COCK BKT	Bajaj spare parts
24141184	ASSEMBLY FUEL COCK FL	Bajaj spare parts
24141187	PIPE ROV TO CANISTER	Bajaj spare parts
24141188	PIPE CANISTER - PURGE CONT VALVE	Bajaj spare parts
24141190	PIPE TANK TO ROV	Bajaj spare parts
24141191	PIPE PURGE CTR VALVE TO ENG	Bajaj spare parts
24141194	ASSEMBLY CAP	Bajaj spare parts
24141197	ASSEMBLY FUEL TAP	Bajaj spare parts
24141210	GASKET 4 HOLE	Bajaj spare parts
24141214	ASSLY PIPE TANK TO CARB-EVAP	Bajaj spare parts
24141218	ASSLY WELDED FUEL TANK-EVAP	Bajaj spare parts
24150501	CABLE HAND BRAKE 4S PET /	Bajaj spare parts
24151058	BRAKE CABL1216 445	Bajaj spare parts
24151059	BRAKE CABL1246 FL AS	Bajaj spare parts
24151060	BRAKE CABL1183 FL AS	Bajaj spare parts
24151061	LEVER ASSY HAND BRAKE	Bajaj spare parts

24151067	BRACKET RR CABLE	Bajaj spare parts
24151068	PIN REAR CABLE GUI	Bajaj spare parts
24151079	RING LOCK BOOT	Bajaj spare parts
24151087	ROD PUSH	Bajaj spare parts
24151090	FORK PUSH ROD	Bajaj spare parts
24151092	SEAL OIL SUPPLY PORT	Bajaj spare parts
24151093	SCREW RESERVOIR MTG.	Bajaj spare parts
24151094	NUT HEX ( M 8 )	Bajaj spare parts
24151097	KIT MAJOR TMC	Bajaj spare parts
24151098	KIT MINOR TMC	Bajaj spare parts
24151107	MAJOR WHEEL CYLINDER	Bajaj spare parts
24151108	MINOR WHEEL CYLINDER	Bajaj spare parts
24151113	MAJOR WHEEL CYL R	Bajaj spare parts
24151114	MINOR WHEEL CYLINDER REAR	Bajaj spare parts
24151138	SPRING SHOE CLAMPING	Bajaj spare parts
24151146	PIN PIVOT PARK LEVER	Bajaj spare parts
24151148	WASHERPLAINN PARK	Bajaj spare parts
24151163	CYL ASSY WHEEL COMP F	Bajaj spare parts
24151164	CYL ASSY WHEEL COMP R	Bajaj spare parts
24151167	PLATE BACK FR	Bajaj spare parts
24151168	AUTO ADJUSTER FR.	Bajaj spare parts
24151170	KIT RATCHET FR <&<	Bajaj spare parts
24151171	KIT SHOE BRAKE	Bajaj spare parts
24151172	KIT SHOE CLAMP SPRIN	Bajaj spare parts
24151173	KIT SPRING FR LH	Bajaj spare parts
24151174	PLATE BACK REAR LH	Bajaj spare parts
24151175	AUTO ADJUSTER LH ASS	Bajaj spare parts
24151177	KIT PARKING LEVER LH	Bajaj spare parts
24151178	PLATE BACK REAR RH	Bajaj spare parts
24151179	AUTO ADJUSTER RH ASS	Bajaj spare parts
24151181	KIT RATCHET RH	Bajaj spare parts
24151182	KIT SPRING RH	Bajaj spare parts
24151183	LEVER RH PARKI ASSLY	Bajaj spare parts
24151221	ASSLY BK PIP RR RE145 PTRL FL	Bajaj spare parts
24151232	PAD BRAKE PEDAL REFL	Bajaj spare parts
24151234	HOSE REAR CIRCUIT-1 FL	Bajaj spare parts
24151238	NUT SPECIAL M6 X 1 FOR HB CABLE	Bajaj spare parts
24151239	BOLT WHEEL FL	Bajaj spare parts
24151243	ASSLY FRONT BRAKE PANEL FL	Bajaj spare parts
24151247	ASSLY BRACKET GUIDE HOSE FL	Bajaj spare parts
24151248	HOSE FLEXIBLE BRAKE FRONT	Bajaj spare parts
24151255	SPRING TORSION BRAKE PDL FL	Bajaj spare parts
24151256	ASSLY BRAKE PEDAL WITH PAD FL	Bajaj spare parts
24151258	CYLINDER COMP TANDEM MSTR FL	Bajaj spare parts
24151266	ASSLY AXLE FRONT WHEEL	Bajaj spare parts

24151268	BRAKE SHOE KIT (FL)	Bajaj spare parts
24151274	HANDLE BAR	Bajaj spare parts
24151275	CYLINDER COMP TANDUM MASTER FL	Bajaj spare parts
24151279	TYRE 4X8- E MARK	Bajaj spare parts
24151283	BRAKE TANDEM MASTER ASSY	Bajaj spare parts
24151285	WHEEL 3.00X8	Bajaj spare parts
24151289	CAP ASSY RESERVOIR WO LIS	Bajaj spare parts
24151290	ASSLY BRAKE RESERVOIR	Bajaj spare parts
24151291	CYLINDER COMP TANDEM MASTER	Bajaj spare parts
24151296	TUBE	Bajaj spare parts
24151297	WASHER	Bajaj spare parts
24151299	RESERVOIR OIL BRAKE	Bajaj spare parts
24160913	BLOCK ENGINE	Bajaj spare parts
24160916	PLATE UPPER LEVER	Bajaj spare parts
24160924	PLUG RUBBER	Bajaj spare parts
24161003	BOLT HEX	Bajaj spare parts
24161149	BUSH SINTERED BRONZE	Bajaj spare parts
24161176	STRIP FLAP MUD FR	Bajaj spare parts
24161256	RUBBER BUFFER	Bajaj spare parts
24161297	CLIP NUT (M8X1.25)	Bajaj spare parts
24161352	PLUG RUBBER	Bajaj spare parts
24161355	LABEL TYRE ROTATION	Bajaj spare parts
24161358	LABEL INSTRUCTION FOR GAS VEL	Bajaj spare parts
24161368	TOOLBOX RIGHT SIDE (PLAST	Bajaj spare parts
24161369	TOOLBOX SIDE LH	Bajaj spare parts
24161370	TOOLBOX LID RIGHT SI	Bajaj spare parts
24161371	COVER MIDDLE PORTI	Bajaj spare parts
24161373	COVER SWITCHES	Bajaj spare parts
24161409	LOCK TOOL BOX WITH K	Bajaj spare parts
24161422	BRACKET LPR MTG VANA	Bajaj spare parts
24161423	GUARD LPR BREATHER V	Bajaj spare parts
24161435	CLAMP ASSY WITH ROD	Bajaj spare parts
24161436	ROD TIE BATTERY I	Bajaj spare parts
24161443	COVER DUST TOP	Bajaj spare parts
24161446	HOLDER WATER BOTTLE	Bajaj spare parts
24161468	LEVER ASSLY REVERSE	Bajaj spare parts
24161492	COVER FOR SWITCHES	Bajaj spare parts
24161504	TOOLBOX WITH IGN SWT	Bajaj spare parts
24161505	ASSEMBLY TOOLBOX	Bajaj spare parts
24165116	COVER STEERING	Bajaj spare parts
24165132	BRACKET MTG FR NUMBER PLATE	Bajaj spare parts
24165169	GROMMET UPPER PART	Bajaj spare parts
24165214	GROMMET STEERING COVER	Bajaj spare parts
24165215	MAT FLOOR FRONT	Bajaj spare parts
24165230	GROMMET UPPER PART	Bajaj spare parts

24165234	ASSLY STEERING COVER FL	Bajaj spare parts
24165255	CLIP PLASTIC FL	Bajaj spare parts
24165260	ASSLY PLATE ELEC MTG FL	Bajaj spare parts
24165270	BRACKET OIL TANK MTG FL	Bajaj spare parts
24165273	SLEEVE BUMPER MTG MID FL	Bajaj spare parts
24165274	SLEEVE BUMPER MTG SIDE FL	Bajaj spare parts
24165284	ASSLY CROSS MBR WITH DAMP	Bajaj spare parts
24165285	ASSLY CROSS MBR COMP FL	Bajaj spare parts
24165302	BEADING STEERING COVER FL	Bajaj spare parts
24165303	TOOL BOX	Bajaj spare parts
24165309	ASSLY TRAY BATTERY 32 AH	Bajaj spare parts
24165328	ASSLY TRAY BATTERY 7 AH	Bajaj spare parts
24170205	SPRING FR SUSP 4S PETR /	Bajaj spare parts
24170425	PIN SHAFT PROPELLER	Bajaj spare parts
24170431	CLIP - HOSE	Bajaj spare parts
24170505	CUP WASHER TOP SIDE	Bajaj spare parts
24170507	BOLT FOR SHOCK ABSORBER	Bajaj spare parts
24170508	SPRING REAR SUSPENSION	Bajaj spare parts
24171014	WASHER ASSEMBLY LOCK	Bajaj spare parts
24171024	SEAL OIL 48 DIA.	Bajaj spare parts
24171049	RUBBER MOUNTING	Bajaj spare parts
24171055	BUSH RUBBER SHOCK	Bajaj spare parts
24171063	SHOCK ABS RR 4S PETR / CN	Bajaj spare parts
24171066	CLIP SPRING	Bajaj spare parts
24171068	SLIDER BLOCK	Bajaj spare parts
24171075	NIPPLE GREASE	Bajaj spare parts
24171076	BELLOW PROPELLER	Bajaj spare parts
24171094	SHOCK ABSORBER RR RE 2S	Bajaj spare parts
24171117	BOLT HEXAGON (FLANGE)	Bajaj spare parts
24171118	AXLE ASSLY REAR WHEE	Bajaj spare parts
24171129	PIN PIVOT	Bajaj spare parts
24171131	HUB ASSEMBLY FR WH	Bajaj spare parts
24171133	PANEL ASSY FR WITH SHOE	Bajaj spare parts
24171136	HUB FRONT WHEEL	Bajaj spare parts
24171137	SHOCKABSORBER ASSY FR	Bajaj spare parts
24171179	ASSEMBLY TRAILING ARM LH FL	Bajaj spare parts
24171180	ASSLY TRAILING ARM RH FL	Bajaj spare parts
24171197	BUSH BONDED	Bajaj spare parts
24171198	PIN PIVOT	Bajaj spare parts
24171200	SEAL PIVOT	Bajaj spare parts
24171201	BEARING NEEDLE	Bajaj spare parts
24181032	LOCK STEERING WITH KEY	Bajaj spare parts
24181033	COVER DUST TOP	Bajaj spare parts
24181034	COVER DUST BOTTOM	Bajaj spare parts
24181039	COVER HANDLE BAR	Bajaj spare parts

24181043	COLUMN STEERING	Bajaj spare parts
24181045	COLUMN STEERING	Bajaj spare parts
24181046	RACE UPPER BEARING	Bajaj spare parts
24181047	NUT LOCK RING	Bajaj spare parts
24181050	LOCK SET	Bajaj spare parts
24181053	LOCK SET	Bajaj spare parts
24181059	LOCK SET RE2S UPGR NES	Bajaj spare parts
24181067	GUIDE FOR CLUTCH CABLE	Bajaj spare parts
24181074	ASSLY GEAR CONTROL TUBE	Bajaj spare parts
24181147	ASSLY STEERING COLUMN	Bajaj spare parts
24181153	LOCK SET	Bajaj spare parts
24181155	LOCK SET RE 145 FL	Bajaj spare parts
24181156	LOCK SET RE145 ES FL	Bajaj spare parts
24181160	ASSLY STEERING COLUMN REFL	Bajaj spare parts
24181161	SPACER DAMPENING PLATE	Bajaj spare parts
24181163	COVER HANDLE BAR-ppc	Bajaj spare parts
24190227	CABLE INNER GEAR RE 2S	Bajaj spare parts
24191024	CABLE CLUTCH RE 2S	Bajaj spare parts
24191075	CABLE GEAR GREY RE 2S	Bajaj spare parts
24191078	CABLE INNER CL.RE2S	Bajaj spare parts
24191086	CHOKE CABL2541 2S 4S	Bajaj spare parts
24191089	INSTRUMENT CLUSTER 4S PET	Bajaj spare parts
24191092	CLUTCH CABL2710 COM2	Bajaj spare parts
24191096	TUBE GEAR CONTROL	Bajaj spare parts
24191098	TUBE GAS CONTR W H.BA	Bajaj spare parts
24191099	RING GEAR INDICATOR	Bajaj spare parts
24191100	PULLEY GEAR CONTROL	Bajaj spare parts
24191101	PULLEY GAS CONTROL	Bajaj spare parts
24191105	SCREW SPECIAL NEW HANDLE	Bajaj spare parts
24191108	INSTRUMENT CLUSTER RE 2S	Bajaj spare parts
24191113	CLUTCH CABL2668 COM2	Bajaj spare parts
24191120	GUIDE CABLE	Bajaj spare parts
24191129	CHOKE CABL2574 145PE	Bajaj spare parts
24191131	CLUTCH CABL2750 ASSE	Bajaj spare parts
24191132	CABLE ACCELERATOR	Bajaj spare parts
24191133	CABLE ACCELERATER	Bajaj spare parts
24191134	GEAR CABL2390 145 WH	Bajaj spare parts
24191135	GEAR CABL2405 145 BL	Bajaj spare parts
24191136	CABLE FUEL COCK GREAY	Bajaj spare parts
24191137	CABLE FUEL COCK BLACK	Bajaj spare parts
24191138	ACC CABL1876 ASSEMBL	Bajaj spare parts
24191139	REVERS CABL1131 COM2	Bajaj spare parts
24191144	SPRING TENSION	Bajaj spare parts
24191174	ACC CABL2850 COM 2S	Bajaj spare parts
24191175	CABLE ASSY COMP CLUT	Bajaj spare parts

24191176	GEAR CABL2405 COM 2S	Bajaj spare parts
24191177	GEAR CABL2412 COM 2S	Bajaj spare parts
24191178	SPEEDO CABL1200 COM2	Bajaj spare parts
24191179	SPEEDO CABL1200 COM2	Bajaj spare parts
24191180	SLEEVE FOR CABLES	Bajaj spare parts
24191182	CHOKE CABL2778 COM2S	Bajaj spare parts
24191184	PULLEY GEAR CONTROL	Bajaj spare parts
24191185	SPRING CLIP	Bajaj spare parts
24191187	TUBE GAS CNTRL WITH GRIP	Bajaj spare parts
24191195	CABLE SPEEDOMETER COMPLETE	Bajaj spare parts
24191196	CABLE INNER SPEEDOMETER	Bajaj spare parts
24191197	BOOT RUBBER FOR CABLE	Bajaj spare parts
24191200	CHOKE CABL2620 COM2S	Bajaj spare parts
24191201	CABLE GEAR WHITE COMPLETE	Bajaj spare parts
24191202	CABLE GEAR BLACK COMPLETE	Bajaj spare parts
24191207	CLAMP CABLE	Bajaj spare parts
24191216	CABLE SPEEDOMETER COMPLETE	Bajaj spare parts
24191217	CABLE INNER SPEEDOMETER	Bajaj spare parts
24191219	INDICATOR ASSLY RH	Bajaj spare parts
24191220	SPEEDOMETER ASSLY	Bajaj spare parts
24201277	REGULATOR WITH CAPAC	Bajaj spare parts
24201303	BLINKER RE 2S CNG / LPG	Bajaj spare parts
24201304	BLINKER RE 2S CNG / LPG	Bajaj spare parts
24201326	HARNESS WIRING FR. RE 2S	Bajaj spare parts
24201333	GAUGE PRESSURE CNG	Bajaj spare parts
24201336	GAUGE PRESSURE(CNG) VANAZ	Bajaj spare parts
24201337	GAUGE CONTENT LPG	Bajaj spare parts
24201360	CABLE ASSY RELAY	Bajaj spare parts
24201361	CABLE ASSY/LPG TL	Bajaj spare parts
24201363	CABLE FLASHER HAZARD	Bajaj spare parts
24201365	FUSE BOX ASSY(COMBINE HAR	Bajaj spare parts
24201368	HEAD LIGHT WITH LAMP(HS1)	Bajaj spare parts
24201378	RIM - HEAD LIGHT(NEW)	Bajaj spare parts
24201380	CABLE ASSLY(HEAD LIGHT HS1)	Bajaj spare parts
24201388	FUSE BOX ASSY	Bajaj spare parts
24201407	FUSE BOX ASSEMBLY	Bajaj spare parts
24201408	WIPER MOTOR PIGTAIL	Bajaj spare parts
24201411	FUSE BOX ASSLY(LPG)	Bajaj spare parts
24201415	CABIN LIGHT ASSY/LAMP	Bajaj spare parts
24201416	CABLE ASSLY (CABIN LIGHT)	Bajaj spare parts
24201420	CABLE ASSLY(REVERSE SWITCH)	Bajaj spare parts
24201421	REVERSE SWITCH	Bajaj spare parts
24201431	STARTER RELAY(WITHOUT	Bajaj spare parts
24201442	INDICATOR ASSLY_CNG	Bajaj spare parts
24201443	INDICATOR ASSLY LPG	Bajaj spare parts

24201451	COMBINED HARNESS(RE2S)	Bajaj spare parts
24201452	INDICATOR ASSY 6P COUP(KS EXPORT	Bajaj spare parts
24201456	FILTER SOLENIOD VALVE	Bajaj spare parts
24201472	ASSLY TAIL LIGHT LH REFL	Bajaj spare parts
24201473	ASSLY TAIL LIGHT RH REFL	Bajaj spare parts
24201476	GASKET TAIL LIGHT ASSLY REFL	Bajaj spare parts
24201477	LENS TAIL LIGHT LH REFL	Bajaj spare parts
24201484	GASKET FRONT SIDE INDICATOR REFL	Bajaj spare parts
24201485	COVER SIDE INDICATOR FRONT LH	Bajaj spare parts
24201486	COVER SIDE INDICATOR FRONT RH	Bajaj spare parts
24201487	SIDE INDICATOR FRONT LH	Bajaj spare parts
24201488	SIDE INDICATOR FRONT RH	Bajaj spare parts
24201493	CABLE BATTERY RE 145D FL	Bajaj spare parts
24201499	LENS TAIL LIGHT RH REFL	Bajaj spare parts
24201500	CABLE TAILLAMP WITH HOLDER LH FL	Bajaj spare parts
24201501	CABLE TAILLAMP WITH HOLDER RH FL	Bajaj spare parts
24201502	CABLE FR INDI WITH HOLDER LH FL	Bajaj spare parts
24201503	CABLE FR INDI WITH HOLDER RH FL	Bajaj spare parts
24201504	LENS & RFLTR FR IND FL	Bajaj spare parts
24201508	REGULATOR DC 1 PHASE	Bajaj spare parts
24201509	REGULATOR DC 1 PHASE	Bajaj spare parts
24201514	ASSLY INDICATOR FL	Bajaj spare parts
24201515	BULB 12V,10W,CAPLESS	Bajaj spare parts
24201523	HOLDER FRONT INDICATOR ASSY FL	Bajaj spare parts
24201524	GROMMET WIPER MOTOR SMALL FL	Bajaj spare parts
24201525	GROMMET WIPER MOTOR BIG FL	Bajaj spare parts
24201526	ASSLY WIPER MOTOR SMALL FL	Bajaj spare parts
24201527	HARNESS FRONT PETROL	Bajaj spare parts
24201528	HARNESS REAR PETROL	Bajaj spare parts
24201529	HARNESS FRONT RE145 ES P	Bajaj spare parts
24201530	HARNESS REAR RE145 ES P	Bajaj spare parts
24201535	ASSLY INDICATOR FL	Bajaj spare parts
24201536	ASSEMBLY INDICATOR FL	Bajaj spare parts
24201538	ASSLY CDI DAMPER DELLORTO FL	Bajaj spare parts
24201540	ASSLY CDI DAMPER DELLORT ESFL	Bajaj spare parts
24201549	HARNESS FRONT RE145 FL NES	Bajaj spare parts
24201550	HARNESS REAR RE145 FL NES	Bajaj spare parts
24201551	BULB 12V 2W T5 TYPE	Bajaj spare parts
24201559	SPEEDOMETER ASSY WITH 0.77	Bajaj spare parts
24201564	PACKING RUBBER - BATTERY 32 AH	Bajaj spare parts
24201568	HARNESS FRONT NES	Bajaj spare parts
24201569	HARNESS REAR NES	Bajaj spare parts
24201571	HARNESS FRONT ES	Bajaj spare parts
24201572	HARNESS REAR ES	Bajaj spare parts
24201573	CABLE BATTERY ES	Bajaj spare parts



24201575	HARNESS BODY RE COMPACT	Bajaj spare parts
24201581	ASSLY BRAIDED CABLE	Bajaj spare parts
24201582	HARNESS REAR ES	Bajaj spare parts
24201583	HARNESS REAR NES	Bajaj spare parts
24201585	ASSY CDI WITH DAMP PET ES-BSIV	Bajaj spare parts
24201586	ASSY CDI WITH DAMP PET NES-BSIV	Bajaj spare parts
24201591	CABLE TIE	Bajaj spare parts
24201595	HARNESS FRONT RE 2S PETROL	Bajaj spare parts
24201596	CABLE BATTERY RE COMPACT 2S ES	Bajaj spare parts
24201597	TELL TALE INDICATOR ASSY PET NES	Bajaj spare parts
24201598	TELL TALE INDICATOR ASSY PET ES	Bajaj spare parts
24201599	ASSLY INDICATOR PETROL	Bajaj spare parts
24201606	HARNESS FRONT-ES	Bajaj spare parts
24201616	CABLE EARTH-ENGINE TO CHASSIS	Bajaj spare parts
24201617	HARNESS FRONT-ES-PETROL	Bajaj spare parts
24201618	HARNESS REAR-ES-PETROL	Bajaj spare parts
24201621	HARNESS HARNESSWIRING-FRONT	Bajaj spare parts
24201622	HARNESS WIRING REAR	Bajaj spare parts
24201645	INDICATOR ASSLY	Bajaj spare parts
24211009	PASSENGER BACKREST	Bajaj spare parts
24211026	BOLT COMBINATION	Bajaj spare parts
24211028	ASSLY FRAME DRIVER SEAT	Bajaj spare parts
24211029	ASSLY SEAT DRIVER	Bajaj spare parts
24211035	HOOK DRIVER SEAT	Bajaj spare parts
24211037	ENCLOSURE - DRIVER SEAT	Bajaj spare parts
24211048	ASSLY DRIVER SEAT	Bajaj spare parts
24211050	ASSLY DRIVER BACKREST	Bajaj spare parts
24211056	ASSLY PASSENGER SEAT	Bajaj spare parts
24211058	ASSLY PASSENGER BACKREST	Bajaj spare parts
24221027	TOOLKIT COMPLETE RE2	Bajaj spare parts
24221031	TOOLKIT COMPLETE	Bajaj spare parts
24221032	EMBLEM COMPACT	Bajaj spare parts
24221033	EMBLEM PETROL	Bajaj spare parts
24221034	EMBLEM BAJAJ RE LOGO	Bajaj spare parts
24221047	JACK ASSLY COMPLETE	Bajaj spare parts
24221049	LABEL COMPACT WHITE	Bajaj spare parts
24221050	LABEL COMPACT BLACK	Bajaj spare parts
24230176	KNOB COMP	Bajaj spare parts
24230185	FLAP MUD	Bajaj spare parts
24230198	PAD RUBBER	Bajaj spare parts
24230401	FRAME ASSY HOOD	Bajaj spare parts
24231090	ANGLE RH RR MUD FLAP	Bajaj spare parts
24231091	ANGLE LH RR MUD FLAP	Bajaj spare parts
24231146	CLIP	Bajaj spare parts
24231157	STRIP FLAP REAR MUDGUARD	Bajaj spare parts

24231239	PIPE HOOD	Bajaj spare parts
24231245	KNOB DOOR REAR	Bajaj spare parts
24231336	PACKING FOR BODY	Bajaj spare parts
24231421	SPACER BEHIND PASS BACKRE	Bajaj spare parts
24231422	PLAIN WASHER	Bajaj spare parts
24231473	MATTING REAR	Bajaj spare parts
24231475	NUT DOME CAP-M5	Bajaj spare parts
24231499	PANEL SIDE COVER	Bajaj spare parts
24231504	BOLT FLANGED M8X1.25	Bajaj spare parts
24231522	LOCK - I	Bajaj spare parts
24231523	LOCK - II	Bajaj spare parts
24231564	ASSLY FRAME DRIVER SEAT	Bajaj spare parts
24231565	SEAT DRIVER	Bajaj spare parts
24231615	JOINT PLATE LH REFL	Bajaj spare parts
24231616	JOINT PLATE RH REFL	Bajaj spare parts
24231620	ASSLY BACKREST SUPPORT TOP	Bajaj spare parts
24231625	BRACKET MTG WIPER MOTOR	Bajaj spare parts
24231630	SCREW SELF DRILL BH	Bajaj spare parts
24231641	PACKING SHIELD & WINDSHIELD REFL	Bajaj spare parts
24231661	BEADING PERIPHERAL FL	Bajaj spare parts
24231662	SUPPORT WINDSHIELD GLASS FL	Bajaj spare parts
24231666	BOLT COMBINATION	Bajaj spare parts
24231699	ASSLY UTILITY HEADBOX FL	Bajaj spare parts
24231705	BRACKET SEAT MOUNT PASSENGER	Bajaj spare parts
24231713	ASSLY KNOB FOR REAR DOOR	Bajaj spare parts
24231722	PACKING FOR BODY	Bajaj spare parts
24231726	PACKING BODY MOUNTING	Bajaj spare parts
24231748	ASSLY HOOD FRAME COMP FL	Bajaj spare parts
24231750	HOOD FRAME REAR	Bajaj spare parts
24231772	ASSLY STICK HOOD I FL	Bajaj spare parts
24231775	ASSLY STICK HOOD II FL	Bajaj spare parts
24231780	GLASS GREEN WINDSHLD MIDDLE	Bajaj spare parts
24231795	GLASS GREEN WINDSHLD MID TOUGH	Bajaj spare parts
24231806	BRACKET ENCLOSURE SIDE MTG	Bajaj spare parts
24231812	WASHER RUBBER MIRROR	Bajaj spare parts
24231834	GLASS GREEN WINDSHLD SIDE LH FL	Bajaj spare parts
24231835	GLASS GREEN WINDSHLD SIDE RH FL	Bajaj spare parts
24231837	PLASTIC STRIP HOOD FIXING	Bajaj spare parts
24231866	STRIP HOOD PET-LONG	Bajaj spare parts
24231867	STRIP HOOD PET-SHORT	Bajaj spare parts
24231871	STRIP HOOD FIXING	Bajaj spare parts
24231876	LABEL BS4 -COMPACT	Bajaj spare parts
24231877	BACKREST DRIVER BLACK	Bajaj spare parts
24251010	LABEL TWIN SPARK	Bajaj spare parts
25191054	LAMP 12V 2W	Bajaj spare parts

25201009	LAMP 12V 35 / 35W	Bajaj spare parts
25231064	BEADING MUDGUARD	Bajaj spare parts
28101022	CAP STRAINER	Bajaj spare parts
28101038	SPRING	Bajaj spare parts
28101057	STOPPER CAM SHAFT	Bajaj spare parts
28101080	BUSH RUBBER	Bajaj spare parts
28101107	KEY - PARALLEL	Bajaj spare parts
28101110	DAMPER SPRING	Bajaj spare parts
28101118	BUSH	Bajaj spare parts
28101125	GUIDE VALVE	Bajaj spare parts
28101129	SPRING SEAT	Bajaj spare parts
28101141	PLUG OIL	Bajaj spare parts
28101167	SPROCKET CAMSHAFT	Bajaj spare parts
28101174	CLIP SPRING	Bajaj spare parts
28101195	HOLDER	Bajaj spare parts
28101214	SPRING	Bajaj spare parts
28141015	TAP COCK FUEL	Bajaj spare parts
29121118	NEEDLE VALVE ASSY	Bajaj spare parts
29191062	LEVER CONTROL LH	Bajaj spare parts
30101014	SEAL OIL	Bajaj spare parts
30101053	RING SNAP (CIRCLIP)	Bajaj spare parts
30101061	RING O	Bajaj spare parts
30101096	PLATE CLUTCH	Bajaj spare parts
30101121	RELEASE CLUTCH OUTER	Bajaj spare parts
30101129	SPRING	Bajaj spare parts
30101142	SEAL OIL	Bajaj spare parts
30101154	BUSH	Bajaj spare parts
30101185	RING O	Bajaj spare parts
30101192	BEARING BALL	Bajaj spare parts
30101195	RING O	Bajaj spare parts
30101236	BALL STEEL	Bajaj spare parts
30121004	RING SNAP	Bajaj spare parts
30141028	GASKET	Bajaj spare parts
30141031	RING O	Bajaj spare parts
30141032	BOLT	Bajaj spare parts
30141039	PACKING	Bajaj spare parts
30141052	PACKING	Bajaj spare parts
30151004	CAM BR ASLY FRONT	Bajaj spare parts
30151005	INDICATOR	Bajaj spare parts
30151008	PANEL BRAKE REAR	Bajaj spare parts
30151009	INDICATOR	Bajaj spare parts
30151011	CAM ASSEMBLY BRAKE	Bajaj spare parts
30151032	COLLAR BEARING	Bajaj spare parts
30151033	SEAL OIL	Bajaj spare parts
30151035	SEAL OIL 48 X 62 X 7	Bajaj spare parts

30151038	RING O	Bajaj spare parts
30151039	BAJAJ BRG 6302 C3	Bajaj spare parts
30151041	GEAR METER SCREW	Bajaj spare parts
30151042	WASHER A	Bajaj spare parts
30151059	BEARING BALL	Bajaj spare parts
30151063	DRUM BRAKE RR CAL115 / DT	Bajaj spare parts
30151065	BEARING BALL	Bajaj spare parts
30151069	SPRING	Bajaj spare parts
30151073	COLLAR	Bajaj spare parts
30151075	COLLAR BEARING	Bajaj spare parts
30151076	DAMPER	Bajaj spare parts
30151078	COUPLING	Bajaj spare parts
30151079	SLEEVE	Bajaj spare parts
30151080	COLLAR	Bajaj spare parts
30151082	SEAL OIL	Bajaj spare parts
30151095	BOLT HEX	Bajaj spare parts
30151096	BOLT HEX	Bajaj spare parts
30151105	SHOE BRAKE CAL 115 / PULS	Bajaj spare parts
30151116	GEAR SPEEDOMETER	Bajaj spare parts
30151118	STOPPER BUSHING	Bajaj spare parts
30151119	BUSHING	Bajaj spare parts
30161157	SHAFT STAND	Bajaj spare parts
30161158	SPRING	Bajaj spare parts
30161169	GROMMET	Bajaj spare parts
30171018	BUSHING RUBBER	Bajaj spare parts
30171022	PIN	Bajaj spare parts
30171023	ADJUSTER CHAIN LH	Bajaj spare parts
30171024	ADJUSTER CHAIN RH	Bajaj spare parts
30171030	BUSH RUBBER	Bajaj spare parts
30181011	NUT	Bajaj spare parts
30181020	RING FOR FAN	Bajaj spare parts
30181023	RING - SNAP	Bajaj spare parts
30181025	Bolt	Bajaj spare parts
30181026	GASKET	Bajaj spare parts
30181029	RING O	Bajaj spare parts
30181045	CUSHION - FORK COVER	Bajaj spare parts
30181053	CYLINDER FORK	Bajaj spare parts
30191017	NUT	Bajaj spare parts
30191030	BOOT	Bajaj spare parts
30191031	SPRING	Bajaj spare parts
30191035	SPRING	Bajaj spare parts
30191036	NUT BRAKE ADJUSTER	Bajaj spare parts
30191037	PIN	Bajaj spare parts
30191038	PIN	Bajaj spare parts
30191048	BAND	Bajaj spare parts

30191067	SEAL OIL	Bajaj spare parts
30191070	SPRING	Bajaj spare parts
30191071	ROD END	Bajaj spare parts
30191072	NUT ADJUSTING	Bajaj spare parts
30201057	RELAY	Bajaj spare parts
30201064	BAND	Bajaj spare parts
30201069	REFLECTOR REFLEX	Bajaj spare parts
30201074	SPRING SWITCH BRAKE	Bajaj spare parts
30201084	LAMP 12V 2W	Bajaj spare parts
30201085	FUSE 15 AMPS	Bajaj spare parts
30201104	BOX FUSE WITH DAMP	Bajaj spare parts
30211005	COLLAR	Bajaj spare parts
31101006	CAP	Bajaj spare parts
31101008	GUIDE VALVE	Bajaj spare parts
31101014	GASKET	Bajaj spare parts
31101018	SPRING RETAINER VALVE	Bajaj spare parts
31101019	COLLET	Bajaj spare parts
31101020	ARM ROCKER 4S CHAMP	Bajaj spare parts
31101024	SPROCKET	Bajaj spare parts
31101033	CHAIN BOXER AR/CAL 115 /	Bajaj spare parts
31101038	RATCHET	Bajaj spare parts
31101039	COIL SPRING	Bajaj spare parts
31101040	GUIDE	Bajaj spare parts
31101041	SPRING	Bajaj spare parts
31101051	ROD SHIFT	Bajaj spare parts
31101055	SPRING	Bajaj spare parts
31101056	GUIDE	Bajaj spare parts
31101060	PLUG	Bajaj spare parts
31101061	PLUG	Bajaj spare parts
31101062	BOLT	Bajaj spare parts
31101064	PLUG	Bajaj spare parts
31101067	GAUGE	Bajaj spare parts
31101104	STOPPER	Bajaj spare parts
31101106	GASKET (STOPPER ROC.ARM)	Bajaj spare parts
31101108	DAMPER	Bajaj spare parts
31101109	COLLAR	Bajaj spare parts
31101110	SPRING	Bajaj spare parts
31101113	GASKET	Bajaj spare parts
31101124	SHAFT KICK	Bajaj spare parts
31101135	WHEEL CLUTCH BYK	Bajaj spare parts
31101136	HUB CLUTCH	Bajaj spare parts
31101137	HOLDER	Bajaj spare parts
31101141	SPRING	Bajaj spare parts
31101148	ROD PUSH	Bajaj spare parts
31101172	FITTING	Bajaj spare parts

31101173	KEY WOODRUFF	Bajaj spare parts
31101175	INSULATOR	Bajaj spare parts
31101191	FORK SHIFT	Bajaj spare parts
31101192	FORK SHIFT	Bajaj spare parts
31101288	RING SET PISTON STD 4S	Bajaj spare parts
31101295	COVER GENERATOR	Bajaj spare parts
31101314	CYL BLOCK ASSY BOXER 4S	Bajaj spare parts
31111055	STATOR ASSYBOXER AR	Bajaj spare parts
31111056	COIL EXCITOR	Bajaj spare parts
31111058	COIL PULSAR	Bajaj spare parts
31121006	GASKET	Bajaj spare parts
31121008	HOLDER CARBURETTOR	Bajaj spare parts
31121029	ELEMENT - AIR FILTER	Bajaj spare parts
31121041	CLAMP	Bajaj spare parts
31121070	JET SLOW 4S CHAPM	Bajaj spare parts
31121166	CARBURETTOR 4S CHAMP	Bajaj spare parts
31151004	COLLAR	Bajaj spare parts
31151011	CAM BRAKE	Bajaj spare parts
31151014	SEAL OIL	Bajaj spare parts
31151018	COLLAR BEARING	Bajaj spare parts
31151021	DAMPER SHOCK	Bajaj spare parts
31151024	PANEL BRAKE REAR	Bajaj spare parts
31151026	COLLAR	Bajaj spare parts
31151027	COUPLING	Bajaj spare parts
31151028	SLEEVE	Bajaj spare parts
31151029	WASHER	Bajaj spare parts
31151030	COLLAR	Bajaj spare parts
31151037	LEVER BRAKE	Bajaj spare parts
31151060	SHOE BRAKE BOXER AR / CT	Bajaj spare parts
31151064	GEAR SPEEDOMETER	Bajaj spare parts
31161018	DAMPER	Bajaj spare parts
31161078	WASHER	Bajaj spare parts
31171006	SHAFT ARM SWING	Bajaj spare parts
31171012	DAMPER SWING ARM	Bajaj spare parts
31181019	CAP OIL LOCK	Bajaj spare parts
31181054	HANDLE BOXER AR / BYK	Bajaj spare parts
31181098	PIPE INNER FORK 4S CHAMP	Bajaj spare parts
31181099	SPRING FRONT FORK 4S CHA	Bajaj spare parts
31181108	RING SNAP	Bajaj spare parts
31191002	CLAMP	Bajaj spare parts
31191003	CABLE SPEEDOMETER BOXER A	Bajaj spare parts
31191012	Mter Assly 4S CHA	Bajaj spare parts
31191027	CABLE ACCELERATOR 4S	Bajaj spare parts
31191028	CABLE CLUTCH 4S CHAMP	Bajaj spare parts
31191032	BOOT FOR ACC CABLE	Bajaj spare parts

31201001	COLLAR	Bajaj spare parts
31201003	RELAY	Bajaj spare parts
31201009	BAND	Bajaj spare parts
31201021	CLAMP	Bajaj spare parts
31201028	LAMP 12V 10/5W	Bajaj spare parts
31201045	REGULATOR RECTIFIER UNIT	Bajaj spare parts
31201079	SWITCH RR BR	Bajaj spare parts
31201081	SWITCH NEUTRAL BOXER	Bajaj spare parts
33141007	CLAMP HYPALON PIPES	Bajaj spare parts
33141008	CLAMP PCOK OUT	Bajaj spare parts
35101059	CROSS	Bajaj spare parts
35101060	PLUG - OIL	Bajaj spare parts
35101064	CRANKSHAFT ASSY CLASIC	Bajaj spare parts
35101167	PLATE OTR CI.5 p	Bajaj spare parts
35101170	BOX CLUTCH 5 PORT	Bajaj spare parts
35101173	PLATE DRIVING 5 PORT	Bajaj spare parts
35101176	RING LOCK	Bajaj spare parts
35101178	BUSH CLUTCH	Bajaj spare parts
35101208	SPRING CLUTCH BIGGER	Bajaj spare parts
35121035	VALVE REED	Bajaj spare parts
35161060	NUT CLIP	Bajaj spare parts
35171033	NIPPLE GREASE BM6	Bajaj spare parts
36001002	ACCESSORY VISIOR	Bajaj spare parts
36001051	Liquid Gasket Loctite 10 gm	Bajaj spare parts
36001055	LUBRICANT CHAIN 1 KG	Bajaj spare parts
36001056	ACCESSORY SPRAY-CARB. CLEANING	Bajaj spare parts
36001058	ACCESSORY COOLANT FOR RADIATOR	Bajaj spare parts
36001061	ENGINE OIL SYNTHETIC 10W50	Bajaj spare parts
36001062	LOCTITE LIQUID SEALANT L5910	Bajaj spare parts
36011001	KIT M G PIN ROLLER SCOOT	Bajaj spare parts
36061001	KIT ROLLER BRACKET SCOOT	Bajaj spare parts
36061002	KIT CLUTCH LEVER OPN	Bajaj spare parts
36061003	KIT CLUTCH LEVER	Bajaj spare parts
36061009	KIT OIL SEAL CHETAK 5PORT	Bajaj spare parts
36102401	KIT OIL SEAL RE 2S	Bajaj spare parts
36151001	KIT OIL SEAL & O RING M80	Bajaj spare parts
36152203	KIT LINER / RIVET 3WH	Bajaj spare parts
36170101	KIT BEARING FR WHEL	Bajaj spare parts
36172201	KIT BEARING FR WHEEL RE/	Bajaj spare parts
36222207	KIT DRIVEN PLATE SCOOTER	Bajaj spare parts
36222237	KIT STEEL BALL SCOOTER	Bajaj spare parts
36222240	KIT OIL SEAL SCOOTER	Bajaj spare parts
36222246	KIT SPRING PLATE SC	Bajaj spare parts
36222256	KIT PLATE SPRING	Bajaj spare parts
36224004	KIT BUSH INNER RACE NEW	Bajaj spare parts

36224005	LOCK TOOL BOX PLASTIC WITH KEY	Bajaj spare parts
36224006	PISTON RING SET 2S (22101211-2)	Bajaj spare parts
36241001	KIT DRIVE PLATES RE 2S	Bajaj spare parts
36241002	KIT ROLLER BRACKET 3WH	Bajaj spare parts
36241010	KIT OIL SEAL MOD. RE 2S	Bajaj spare parts
36244004	KIT MFV FLOAT VALVE KIT	Bajaj spare parts
36244005	KIT SPINDLE WITH PAD	Bajaj spare parts
36244016	KIT PIVOT PIN WITH B	Bajaj spare parts
36244023	IGNITION PARKING SWITCH	Bajaj spare parts
36244024	LOCK FOR DOOR WITH KEY	Bajaj spare parts
36244025	KIT PLATE FRCITION RE 145	Bajaj spare parts
36244039	KIT ST CONE FORK SMALL & MEDIUM	Bajaj spare parts
36244040	KIT-JET KIT ( CARB-24121676)	Bajaj spare parts
36244041	KIT ST CONE FORK FACE LIFT MAX	Bajaj spare parts
36244042	LOCK STG WITH KEY SMALL	Bajaj spare parts
36244043	SWITCH IGNITION WITH KEY	Bajaj spare parts
36244044	LOCK DOOR FUEL FILLING	Bajaj spare parts
36244045	SWITCH IGNITION WITH KEY	Bajaj spare parts
36244047	KIT FLOAT BODY KIT CARB	Bajaj spare parts
36244049	KIT O RING & GASKET KIT CARB	Bajaj spare parts
36244050	KIT_OIL SEAL KIT RE COMPACT 2S	Bajaj spare parts
36244057	PACKING SET FOR 2S & RE145 MODEL	Bajaj spare parts
36244058	KIT_PACKING SET FOR RE145 D	Bajaj spare parts
36244059	KIT PACKING SET FOR COMPACT 2S ES	Bajaj spare parts
36244060	KIT PACKING SET	Bajaj spare parts
36244061	KIT_PILOT SCREW 2S PET	Bajaj spare parts
36244062	KIT_MIXING CAP ASSLY	Bajaj spare parts
36244063	KIT_FRONT HUB PIN-ALL COMPACT FL	Bajaj spare parts
36244069	KIT RE WHEEL BEARING	Bajaj spare parts
36244070	KIT_OIL SEAL KIT- 2/3 PORT 2ST ENGINE	Bajaj spare parts
36244071	KIT_SPRING PLATE 2ST COMPACT	Bajaj spare parts
36244072	KIT_OIL SEAL KIT- 5 PORT 2ST ENGINE	Bajaj spare parts
36244075	KIT_ASSLY REFLECTOR WITH HOLDER	Bajaj spare parts
36244083	KIT PISTON PIN GUDGEON FL 2S	Bajaj spare parts
36244094	KIT_COMPACT RUBBER BUFFER	Bajaj spare parts
36244097	JET KIT (24121738)	Bajaj spare parts
36244098	PISTON VALVE ASSLY KIT(24121738)	Bajaj spare parts
36281008	KIT VALVE LEGEND	Bajaj spare parts
36301509	KIT SCREW GEAR METER KB1	Bajaj spare parts
36311006	KIT CHAIN GUIDE	Bajaj spare parts
36311008	KIT REPAIR VALVE	Bajaj spare parts
36311009	KIT OIL SEAL 4S CHAMP	Bajaj spare parts
36311014	KIT OIL SEAL 4S CHAMP	Bajaj spare parts
36311016	KIT O RING 4S CHAMP	Bajaj spare parts
36311020	KIT SHAFT KICK BOXER AR/C	Bajaj spare parts



36311027	KIT REPAIR KICK LEVER	Bajaj spare parts
36311028	KIT VALVE CAL/BOXR	Bajaj spare parts
36311508	KIT CHAIN SPROCKET 4S CHA	Bajaj spare parts
36314002	KIT BALL STEEL STEER	Bajaj spare parts
36314004	OIL FORK (160 ml)	Bajaj spare parts
36314005	KIT ST.CONE (31MM)GR	Bajaj spare parts
36314006	GASKET KIT 4S	Bajaj spare parts
36AA1003	KIT GASKET RE 4S	Bajaj spare parts
36AA1004	KIT OILSEAL RE 4S	Bajaj spare parts
36AA4007	KIT SPRING DAMPER CL	Bajaj spare parts
36AA4012	KIT PISTON VALVE ASSLY	Bajaj spare parts
36AA4013	KIT JET KIT	Bajaj spare parts
36AA4014	IGNITION PARKING SWITCH	Bajaj spare parts
36AA4015	LOCK FUEL WITH KEY	Bajaj spare parts
36AA4016	KIT PLATE FRICTION RE 205	Bajaj spare parts
36AA4017	KIT PLATE FRICTION RE 2S	Bajaj spare parts
36AA4018	KIT ST MOTOR SPRING	Bajaj spare parts
36AA4019	KIT CH TENS RAT TYPE	Bajaj spare parts
36AA4020	KIT CHA TENS SPR TYPE	Bajaj spare parts
36AA4021	KIT CHA TENS SPR TYPE	Bajaj spare parts
36AA4025	KIT FRICTION PLATE KIT	Bajaj spare parts
36AA4028	SWITCH IGNITION WITH KEY	Bajaj spare parts
36AA4029	KIT_GEAR DRIVE ASSLY	Bajaj spare parts
36AA4032	KIT ROD CONNECTING 4S FL	Bajaj spare parts
36AA4033	KIT_VALVE KIT 4S FL	Bajaj spare parts
36AA4036	KIT GASKET_4S ENGINE	Bajaj spare parts
36AA4039	KIT KIT OIL SEAL 4S	Bajaj spare parts
36AA4040	"KIT OIL SEAL 205, 205D & M"	Bajaj spare parts
36AA4041	KIT OIL SEAL COMPACT OPTIMA 4S	Bajaj spare parts
36AA4042	KIT PACKING SET FOR	Bajaj spare parts
36AA4044	KIT_PISTON VALVE ASSLY	Bajaj spare parts
36AA4045	KIT_IDLING ADJUSTER_4S	Bajaj spare parts
36AA4046	KIT_JET KIT CARB_AA121199	Bajaj spare parts
36AA4047	KIT_PILOT SCREW COMPACT 4S	Bajaj spare parts
36AA4050	KIT PACKING SET-COMPACT	Bajaj spare parts
36AA4051	KIT FR WHEEL BEARING	Bajaj spare parts
36AA4067	KIT PISTON PIN GUDGEON FL 4S	Bajaj spare parts
36AA4070	KIT 3W DRIVER SEAT ENCLOSURE	Bajaj spare parts
36AA4071	JET KIT	Bajaj spare parts
36AA4072	PILOT SCREW KIT	Bajaj spare parts
36AA4073	PISTON VALVE ASSY KIT	Bajaj spare parts
36AA4074	FLOAT BODY ASSY KIT	Bajaj spare parts
36AA4075	O-RING AND GASKET KIT	Bajaj spare parts
36AA4080	KIT CYL.BLK.PISTION ( F )	Bajaj spare parts
36AA4100	STARTER CABLE GUIDE ASSY KIT-4S RL	Bajaj spare parts

36AA4102	KIT_VALAVE KIT 4S RL	Bajaj spare parts
36AA4103	LOOSE AUTORIKSHAW COVER -COMPACT	Bajaj spare parts
36AA4104	KIT_VALVE KIT 205 MODELS	Bajaj spare parts
36AA4105	CYL BLOCK PISTON ASSLY-LPG	Bajaj spare parts
36AA4106	KIT VALAVE 4S BSIV	Bajaj spare parts
36AA4110	JET KIT(AA121280) COMPACT 4S PET	Bajaj spare parts
36AA4111	PILOT SCR KIT AA121280 C 4S PET	Bajaj spare parts
36AA4112	PISTON VALVE KIT AA121280 4S PET	Bajaj spare parts
36AA4114	FLANGE S.G. HSG. WITH OIL SEAL	Bajaj spare parts
36AA4115	FLANGE DIFF. GEAR WITH OIL SEAL	Bajaj spare parts
36AA4116	ASSLY CYL. HEAD_VALVE 4S-205	Bajaj spare parts
36AA4117	ASSLY CYL. HEAD_VALVE 4S- 175	Bajaj spare parts
36AA4118	ASSLY CYL. HEAD_VALVE FL REFRESH	Bajaj spare parts
36AA4119	ASSLY CYL. HEAD_VALVE 4S 205 BS4	Bajaj spare parts
36AA4124	KIT P RING OS(0.25) 205 PET/LPG	Bajaj spare parts
36AA4125	KIT P RING OS(0.50) 205 PET/LPG	Bajaj spare parts
36AA4142	WHEEL CYLINDER ASSLY FRONT-RE	Bajaj spare parts
36AA4143	WHEEL CYLINDER MAJOR KIT- RE & Z	Bajaj spare parts
36AA4144	BRAKE SHOE SPRING KIT- RE FR	Bajaj spare parts
36AA4145	BRAKE SHOE CLAMP SPRING KIT- RE	Bajaj spare parts
36AA4146	BACK PLATE FRONT- RE	Bajaj spare parts
36AA4147	AUTO ADJUSTER ASSLY FRONT-RE	Bajaj spare parts
36AB4001	KIT BUSH PIVOT PIN 3WH	Bajaj spare parts
36AB4003	KIT Brg Race Lower RE	Bajaj spare parts
36AE0001	KIT CLUTCH PLATE KIT RE 2S	Bajaj spare parts
36AF0008	KIT IDILING ADJUSTER	Bajaj spare parts
36AF0009	KIT AIR SCREW	Bajaj spare parts
36AF0010	KIT JET	Bajaj spare parts
36AF0011	KIT TOP CAP ASSLY.	Bajaj spare parts
36AF0012	KIT PISTON VALVE KIT ASSL	Bajaj spare parts
36AF0013	KIT STARTER CABLE GUIDE A	Bajaj spare parts
36AF0014	KIT O RING	Bajaj spare parts
36AF0015	KIT FLOAT BODY ASSY	Bajaj spare parts
36AF0016	KIT JET	Bajaj spare parts
36AF0017	KIT PISTON VALVE ASSLY	Bajaj spare parts
36AF0018	IGNITION PARKING SWITCH	Bajaj spare parts
36AF0019	LOCK-CNG WITH KEY	Bajaj spare parts
36AF0022	SWITCH IGNITION WITH KEY	Bajaj spare parts
36AF0023	KIT_JET CARB(AG121077)	Bajaj spare parts
36AF0024	KIT_PISTON VALVE ASSLY	Bajaj spare parts
36AF0026	KIT_JET KIT CARB_	Bajaj spare parts
36AF0027	KIT_PISTON VALVE ASSLY_AF121522	Bajaj spare parts
36AF0028	KIT_PILOT SCREW 2S GASKIT_PILOT SCREW 2S	Bajaj spare parts
36AF0029	KIT_COIL ASSLY	Bajaj spare parts
36AF0030	KIT_PAPER FILTER	Bajaj spare parts

36AF0031	KIT_PISTON SUB ASSLY & SPRING	Bajaj spare parts
36AF0032	KIT_NRV SUB ASSLY & SPRING	Bajaj spare parts
36AF0033	KIT_DUST PLUG	Bajaj spare parts
36AF0034	KIT_PRESSURE GAUGE	Bajaj spare parts
36AF0035	KIT_FILTER (SB)	Bajaj spare parts
36AF0036	KIT_MICRO SWITCH	Bajaj spare parts
36AF0037	KIT_PRIMARY LPR	Bajaj spare parts
36AF0038	KIT_SECONDERY LPR	Bajaj spare parts
36AF0039	"KIT_""O"" RING"	Bajaj spare parts
36AF0040	KIT_FILLER VALVE	Bajaj spare parts
36AF0041	KIT_MFV MANUAL SERVICE VALVE	Bajaj spare parts
36AF0042	KIT_MFV 80% ASSLY.	Bajaj spare parts
36AF0043	KIT_RELIF VALVE SPRING KIT	Bajaj spare parts
36AF0044	CYL PISTON-CNG 4S ASSLY	Bajaj spare parts
36AF0045	KIT_PILOT SCREW - AZ581217	Bajaj spare parts
36AF0047	JET KIT-COMPACT CNG 4S RL-AF121527	Bajaj spare parts
36AF0048	PISTON VALVE ASSY KIT	Bajaj spare parts
36AF0049	JET KIT (AF121534) COMP. 4S CNG	Bajaj spare parts
36AF0050	PISTON VALVE KIT AF121534 4S CNG	Bajaj spare parts
36AF0051	KIT P RING OS(0.25) 205 CNG	Bajaj spare parts
36AF0052	KIT P RING OS(0.50) 205 CNG	Bajaj spare parts
36AF0057	DIAPHRAGM ASSLY KIT- BS6	Bajaj spare parts
36AF0058	KIT_VALVE BI FUEL- BS6	Bajaj spare parts
36AF0062	KIT OIL COOLER PIPE SUPORT BKT	Bajaj spare parts
36AF0063	KIT CAM CHAIN SPROCKET-AF101772	Bajaj spare parts
36AF0064	KIT CAM CHAIN SPROCKET-AM101170	Bajaj spare parts
36AF0065	ASSLY CYL. HEAD VALVE BS6 BF	Bajaj spare parts
36AF0066	IACV CABLE KIT 4S	Bajaj spare parts
36AG0001	JET KIT (AG121099) 2S LPG	Bajaj spare parts
36AG0002	PISTON VALVE ASSY KIT AG121099	Bajaj spare parts
36AH0003	SPRING KIT FR/LH- Z	Bajaj spare parts
36AH0004	SPRING KIT RR RH Z BS6	Bajaj spare parts
36AH0010	WHEEL CYLINDER MOUNTING KIT FRONT Z BS6	Bajaj spare parts
36AH0011	WHEEL CYLINDER MINOR KIT RE & Z BS6	Bajaj spare parts
36AL0002	KIT SHAFT DECOMP GC 1000	Bajaj spare parts
36AL0005	KIT Brg Race Lower GC	Bajaj spare parts
36AL0014	LOCK-FUEL TANK CAP WITH KEY	Bajaj spare parts
36AL0015	LOCK-GLOVE BOX LID WITH KEY	Bajaj spare parts
36AL0016	LOCK-STERO LID WITH KE	Bajaj spare parts
36AL0017	LOCK-BATTERY WITHKEY	Bajaj spare parts
36AL0022	"Upper St. Cone GC,Mega"	Bajaj spare parts
36AL0024	DOOR LOCK DOOR.WITH KEY LH	Bajaj spare parts
36AL0025	DOOR LOCK DOOR.WITH KEY RH	Bajaj spare parts
36AL0026	HAND STARTING MECH.W/O ROPE	Bajaj spare parts
36AL0029	WHEEL CYLINDER MINOR KIT CARGO	Bajaj spare parts

36AL0030	WHEEL CYLINDER MIAJOR KIT CARGO	Bajaj spare parts
36AL0033	BACK PLATE ASSLY FR CARGO	Bajaj spare parts
36AL0035	BENJO BOLT KIT CARGO	Bajaj spare parts
36AL0038	BACK PLATE ASSLY LH FINISHED CARGO	Bajaj spare parts
36AL0040	BACK PLATE ASSLY LH FINISHED CARGO	Bajaj spare parts
36AL0041	KIT_ WHEEL CYLINDER MTG KIT CARGO	Bajaj spare parts
36AL0042	KIT BARSHAFT LH AL133005-MAXIMA CARGO D	Bajaj spare parts
36AL0043	KIT BARSHAFT RH AL133006-MAXIMA CARGO D	Bajaj spare parts
36AL0044	LH LOCK (AL181042) LH FOR DOOR WITH KEY	Bajaj spare parts
36AL0045	LOCK (AL181043) RH FOR DOOR WITH KEY	Bajaj spare parts
36AL0050	FRONT BRAKE SHOE KIT MAXIMA C	Bajaj spare parts
36AL0051	REAR RH BRAKE SHOE KIT MAXIMA C	Bajaj spare parts
36AL0052	REAR LH BRAKE SHOE KIT MAXIMA C	Bajaj spare parts
36AL0053	LOOSE AUTORIKSHAW COVER -CARGO	Bajaj spare parts
36AL0057	KIT LOWER ST. CONE BIG MODEL	Bajaj spare parts
36AL0058	KIT UPPER ST. CONE BIG MODEL	Bajaj spare parts
36AL0059	KIT-FR WHEEL BEARING KIT	Bajaj spare parts
36AM0003	KIT_ JET KIT CARB_	Bajaj spare parts
36AM0004	JET KIT-COMPACT LPG 4S RL-AM121178	Bajaj spare parts
36AM0005	PISTON VALVE ASSY KIT	Bajaj spare parts
36AM0006	JET KIT (AM121187) COM 4S LPG	Bajaj spare parts
36AM0007	PISTON VALVE KIT AM121187 4S LPG	Bajaj spare parts
36AM0011	SOLENOID FILTER ELEMNT- O RING	Bajaj spare parts
36AN0010	CYL PISTON-LPG,PET 4S ASSLY	Bajaj spare parts
36AN0013	VALVE KIT CNG	Bajaj spare parts
36AN0015	KIT Piston Ring Set RE 205 UG	Bajaj spare parts
36AN0016	KIT RING PISTON RE4S	Bajaj spare parts
36AN0028	KIT BARSHAFT AN101419-CARGO CNG	Bajaj spare parts
36AN0030	JET KIT-CARGO CNG 4S RL-AN121217	Bajaj spare parts
36AN0031	PISTON VALVE ASSY KIT	Bajaj spare parts
36AN0032	CYL BLOCK PISTON ASSLY-CNG 4S BSIV	Bajaj spare parts
36AN0033	KIT RING PISTON RE4S BSIV CNG	Bajaj spare parts
36AN0034	KIT PISTON RING CARGO PETROL	Bajaj spare parts
36AN0039	KIT P RING OS(0.25) 236 PET/LPG	Bajaj spare parts
36AN0040	KIT P RING OS(0.50) 236 PET/LPG	Bajaj spare parts
36AN0043	ASSLY A/F W/O ELEMENT - C CNG	Bajaj spare parts
36AP0002	KIT CG PLATE NEW	Bajaj spare parts
36AS0002	PILOT SCREW KIT(AS121021)	Bajaj spare parts
36AS0003	PISTON VALVE ASSY KIT AS121021	Bajaj spare parts
36AT0001	KIT IGNITION LOCK WITH KEY	Bajaj spare parts
36AT0003	HPR FILTER 17MM-AT172117	Bajaj spare parts
36AT0004	KIT FIELD FIX DUEL HPR	Bajaj spare parts
36AU0001	KIT CYL BLOCK PISTON ASSLY	Bajaj spare parts
36AU0002	KIT LOWER ST.CONE SMALL TUB	Bajaj spare parts
36AU0003	KIT UPPER ST.CONE SMALL&MED A/R	Bajaj spare parts

36AU0004	KIT LOW ST.CONE SM- BIG TUBE	Bajaj spare parts
36AU0005	KIT_REAR WHEEL BEARING -COMPACT	Bajaj spare parts
36AU0006	KIT-FR WHEEL BEARING KIT	Bajaj spare parts
36AZ0003	KIT PISTON VALVE KIT ASSLY_AZ	Bajaj spare parts
36AZ0015	KIT_JET -AZ581214	Bajaj spare parts
36AZ0017	KIT_PISTON VALVE ASSLY_AZ581214	Bajaj spare parts
36AZ0020	KIT_PILOT SCREW OPTIMA 4S	Bajaj spare parts
36AZ0023	KIT_BARSHAFT BF551803 RE COMPACT+ 4S	Bajaj spare parts
36AZ0024	JET KIT-COMPACT + CNG 4S RL- AZ581219	Bajaj spare parts
36AZ0025	JET KIT-COMPACT + LPG 4S RL- RA581207	Bajaj spare parts
36AZ0026	LOOSE AUTORIKSHAW COVER -COMP PLUS/MA	Bajaj spare parts
36AZ0046	KIT PISTON RING	Bajaj spare parts
36AZ0048	BLOCK PISTON ASSLY CNG-236	Bajaj spare parts
36AZ0049	KIT_CONNECTING ROD 4S -236	Bajaj spare parts
36AZ0052	ASSLY CYL. HEAD_VALVE 4S 236 BS4	Bajaj spare parts
36AZ0054	KIT P RING OS(0.25) 236 CNG	Bajaj spare parts
36AZ0055	KIT P RING OS(0.50) 236 CNG	Bajaj spare parts
36AZ0058	SEAT ENCLOSURE KIT- MAXIMA Z GAS	Bajaj spare parts
36AZ0059	KIT CLUTCH COVER (AZ541202)	Bajaj spare parts
36AZ0060	ASSLY A/F W/O ELEMENT- RE AF	Bajaj spare parts
36AZ0075	CYL BLOCK PISTON ASSLY-CNG	Bajaj spare parts
36AZ0076	BRAKE SHOE WITH HBL LH KIT-Z	Bajaj spare parts
36AZ0077	BACK PLATE ASSLY LH FINISHED-Z	Bajaj spare parts
36AZ0078	BRAKE SHOE WITH HBL RH KIT-Z	Bajaj spare parts
36AZ0079	BACK PLATE ASSLY RH FINISHED-Z	Bajaj spare parts
36AZ0080	BRAKE SHOE WITH HBL FR KIT-Z BS6	Bajaj spare parts
36AZ0084	KIT CLUTCH COVER (AZ541217)	Bajaj spare parts
36AZ0089	DOOR FUEL FILLING WITH KEY Z	Bajaj spare parts
36BA4001	KIT LINER PISTON RE DIE	Bajaj spare parts
36BA4002	KIT STEERING CONE RE DIE	Bajaj spare parts
36BA4004	CYL.BLOCK PISTON RE DIESE	Bajaj spare parts
36BA4005	LOCK-FUEL FILL DOOR WITH KEY	Bajaj spare parts
36BA4008	KIT	Bajaj spare parts
36BA4013	IGNITION SWITCH-BA201173	Bajaj spare parts
36BA4014	WHEEL CYLINDER MOUNTING KIT REAR Z BS6	Bajaj spare parts
36BA4015	KIT_WHEEL CYLINDER MOUNTING COMPACT DSL	Bajaj spare parts
36BA4021	KIT_VALVE DIESEL FL	Bajaj spare parts
36BA4027	KIT PISTON PIN GUDGEON FL DIESEL	Bajaj spare parts
36BA4029	KIT_OIL FL DIESEL	Bajaj spare parts
36BA4031	"KIT_VALVES, SEAT FL DIESEL"	Bajaj spare parts
36BA4032	KIT_ENGINE OVERHAULING DIESEL BS-II	Bajaj spare parts
36BA4034	KIT ENGINE OVERHAULING DIESEL	Bajaj spare parts
36BA4035	KIT-RUBBER BUFFER(DURA BLOCK)	Bajaj spare parts
36BA4036	RR3 GREASE PACK 50 GMS	Bajaj spare parts
36BA4037	BSIV DSL OIL FILTER COVER-INSERT	Bajaj spare parts

36BA4039	KIT PIVOT PIN SPARES	Bajaj spare parts
36BA4042	KIT SLIDER BLOCK	Bajaj spare parts
36BA4043	KIT SLIDER BLOCK WITH PIN	Bajaj spare parts
36BA4044	KIT CYLINDER LINER PIST ASSLY	Bajaj spare parts
36BA4045	KIT_ BALL STEEL WITH CAGE LOWER & UPPER	Bajaj spare parts
36BA4048	GREASE LIMAPLEX HTX3- 50 GM.	Bajaj spare parts
36BB0006	KIT CYLINDER LINER	Bajaj spare parts
36BB0007	KIT CYL.BLOCK PISTON ASLY	Bajaj spare parts
36BB0012	KIT Piston ring kit std	Bajaj spare parts
36BB0029	ST LOCK WITH KEY GC	Bajaj spare parts
36BB0030	CAP TANK FUEL WITH KEY	Bajaj spare parts
36BB0033	Battery Lock	Bajaj spare parts
36BB0035	PROTECTION PLUG FR.MAXIMA DSL	Bajaj spare parts
36BB0037	KIT_ MAXIMA MATTS	Bajaj spare parts
36BB0039	KIT_ FR WHEEL BEARING KIT	Bajaj spare parts
36BB0040	KIT_ REAR WHEEL BEARING max	Bajaj spare parts
36BB0042	KIT CRANKCASE PISTON ASSLY- COMP.	Bajaj spare parts
36BB0043	KIT CRANKCASE PISTON ASSLY- OPTIMA	Bajaj spare parts
36BB0047	KIT BARSHAFT LH BB133078-MAXIMA DSL	Bajaj spare parts
36BB0048	KIT BARSHAFT RH BB133079-MAXIMA DSL	Bajaj spare parts
36BB0052	FRONT BRAKE SHOE KIT MAXIMA	Bajaj spare parts
36BB0053	REAR RH BRAKE SHOE KIT MAXIMA	Bajaj spare parts
36BB0054	REAR LH BRAKE SHOE KIT MAXIMA	Bajaj spare parts
36BB0055	BS4 KIT_ C'CASE PISTON COMP MAXI	Bajaj spare parts
36BB0056	BS4 KIT_ C'CASE PISTON COMP	Bajaj spare parts
36BB0061	KIT_ BALL STEEL WITH CAGE LOWER & UPPE	Bajaj spare parts
36BB0067	KIT CRANKCASE PISTON ASSLY- RE & MAXIMA	Bajaj spare parts
36BB0068	KIT CRANKCASE PISTON ASSLY- Z	Bajaj spare parts
36BB0069	KIT VALVE DIESEL BS6	Bajaj spare parts
36BB0070	VALVE KIT - NEW EX. VALVE DSL	Bajaj spare parts
36BF0001	BR SHOE SET REAR	Bajaj spare parts
36BF0002	BR SHOE SET FRONT	Bajaj spare parts
36BF0003	KIT_ BACK PLATE COMPLETE- RH-REAR	Bajaj spare parts
36BF0009	MECHANICAL PART SET FRONT	Bajaj spare parts
36BF0010	Mechanical Part Set Rear	Bajaj spare parts
36BF0011	KIT-COMPLETE SET OF SPRINGS ALL	Bajaj spare parts
36BF0012	KIT-SIDE FASTENING SPRING SET ALL	Bajaj spare parts
36BF0023	KIT SET LOCK RHD	Bajaj spare parts
36BF0025	KIT LOCK FUEL FILTER LID	Bajaj spare parts
36BF0026	KIT LOCK GLOW BOX	Bajaj spare parts
36BF0027	KIT IGNITION SWITCH ST. LOCK	Bajaj spare parts
36BF0028	KIT LOCK EAC- QUTE	Bajaj spare parts
36BF0029	KIT LOCK HOOD- QUTE	Bajaj spare parts
36BF0030	KIT DOOR LOCK MECHANISM RH	Bajaj spare parts
36BF0031	REMOTE FOR FM RADIO QUTE DOM	Bajaj spare parts

36BF0040	KIT FRICTION PLATE - QUTE	Bajaj spare parts
36BF0044	KIT DRAG LINK NUT M12- NEW	Bajaj spare parts
36BG0004	KIT IGNITION PARKING SWITCH	Bajaj spare parts
36BH0008	KIT OBJ MAX	Bajaj spare parts
36BH0009	KIT OBJ MEGA	Bajaj spare parts
36BH0010	KIT OBJ & TRIPOD MAX	Bajaj spare parts
36BH0011	KIT OBJ & TRIPOD-MEGA	Bajaj spare parts
36BH0019	KIT ROLLER	Bajaj spare parts
36BH0029	SPARE WHEEL LOCK	Bajaj spare parts
36BH0030	KIT-KIT IBJ-DOUBLE CHAMFER	Bajaj spare parts
36BH0031	KIT_IBJ & TRIPOD DOUBLE CHAMFER	Bajaj spare parts
36BH0034	KIT_OPTIMA MATTS	Bajaj spare parts
36BH0035	KIT_REAR WHEEL BEARING OPT	Bajaj spare parts
36BH0036	KIT_BOOT WITH NEW BOOT	Bajaj spare parts
36BH0037	KIT_BOOT & RETAILNER (K TEC BOOT)	Bajaj spare parts
36BH0039	KIT BARSHAFT LH BH551418 -RE COMP	Bajaj spare parts
36BH0040	KIT BARSHAFT RH BH55141 -RE COMP	Bajaj spare parts
36BH0052	BEARING RACE KIT UPPER-COMP & Z	Bajaj spare parts
36BH0053	BEARING RACE KIT LOWER- COMP & Z	Bajaj spare parts
36BH0054	FUEL COCK FILTER FOR AY171812	Bajaj spare parts
36CS0001	KIT VALVE WAVE	Bajaj spare parts
36DD1502	KIT CHAIN SPROCKET CALIB	Bajaj spare parts
36DD1503	KIT CHAIN SPROKET CAL	Bajaj spare parts
36DD1504	KIT CHAIN SPROCKET CAL 11	Bajaj spare parts
36DD1505	KIT CHAIN SPROCKET WIND12	Bajaj spare parts
36DD4001	KIT PISTON RING SET CT100	Bajaj spare parts
36DD4002	KIT GASKET CT 100	Bajaj spare parts
36DD4006	KIT PLATE FRICTION BOXER	Bajaj spare parts
36DD4007	KIT PLATE CLUTCH BOXER C	Bajaj spare parts
36DD4008	KIT PLATE CLUTCH	Bajaj spare parts
36DD4009	GASKET KIT PLATINA / CT 100	Bajaj spare parts
36DD4010	GASKET KIT PLATINA	Bajaj spare parts
36DD4011	KIT ENGINE OIL FILTER+CVR O RING	Bajaj spare parts
36DF1701	KIT BUSH SHOCKER	Bajaj spare parts
36DH1003	KIT CHAIN GUIDE PULSAR	Bajaj spare parts
36DH1008	KIT BOSS KICK	Bajaj spare parts
36DH1501	KIT CHAIN SPROCKET PULSAR	Bajaj spare parts
36DH1601	KIT GROMMET SIDECOVER	Bajaj spare parts
36DH1902	O Ring Kit Master Cyl.Pulsar DTS-I	Bajaj spare parts
36DH4001	KIT CHAIN CASE PLS OLD	Bajaj spare parts
36DH4004	KIT 10K KM PUL150 DT	Bajaj spare parts
36DH4006	KIT PRI PULSAR150/18	Bajaj spare parts
36DH4007	KIT STARTER CLUTCH	Bajaj spare parts
36DH4008	KIT BODY COMP STARTER CLUTCH	Bajaj spare parts
36DH4009	KIT PRIMARY DRIVE PUL 150	Bajaj spare parts

36DH4011	HARDWARE SHIELD PUL	Bajaj spare parts
36DH4012	LEVER BRAKE PUL-150 UG4	Bajaj spare parts
36DH4013	KIT CHAIN SPROCKET UG4	Bajaj spare parts
36DH4014	HDWARE ROD BR PUL15	Bajaj spare parts
36DH4015	HARDWARE ROD PUL150	Bajaj spare parts
36DH4018	HARDWARE LEGGUARD	Bajaj spare parts
36DH4019	KIT Centrifugal oil	Bajaj spare parts
36DH4020	KITHARDWR FAIRING MO	Bajaj spare parts
36DH4025	KIT CLUTCH FRIC DIS125	Bajaj spare parts
36DH4026	KIT PLATE CLUTCH	Bajaj spare parts
36DH4027	KIT PLATE CLUTCH P150UG3	Bajaj spare parts
36DH4028	KIT PLATE FRIC PUL 180	Bajaj spare parts
36DH4029	SPRAY CHAIN LUB 100 ML	Bajaj spare parts
36DH4030	KIT CHAIN GUIDE PULS	Bajaj spare parts
36DH4031	KIT ASSLY CL COVER K1 FLOWER TYPE	Bajaj spare parts
36DH4032	KIT Starter Clutch Assly	Bajaj spare parts
36DH4033	ENGINE GASKET pul 150	Bajaj spare parts
36DH4034	KIT DECAL TANK PUL BL	Bajaj spare parts
36DH4035	KIT DECAL FAIRING PUL BL	Bajaj spare parts
36DH4036	KIT DECAL COWL 220SF BL	Bajaj spare parts
36DH4037	KIT DECAL TANK PUL RD	Bajaj spare parts
36DH4038	KIT DECAL FAIRING PUL RD	Bajaj spare parts
36DH4039	KIT DECAL COWL 220SF RD	Bajaj spare parts
36DH4040	KIT PLATE FRICTION DISC125	Bajaj spare parts
36DH4041	KIT PLATE FRICTION DISC135	Bajaj spare parts
36DH4042	KIT SEATCOWL DCL BLUE150	Bajaj spare parts
36DH4043	KIT SEATCOWL DCL RED 150	Bajaj spare parts
36DH4044	KIT COVER CLUTCH SLV P150	Bajaj spare parts
36DH4047	KIT SCB SENSOR+MAG PLSR 150	Bajaj spare parts
36DH4048	KIT BB-KIT MJR MST	Bajaj spare parts
36DH4049	KIT BB- KIT MIN CAL & GR	Bajaj spare parts
36DH4050	KIT CYL HEAD+COVER	Bajaj spare parts
36DH4052	GREASE BRAKE SYS	Bajaj spare parts
36DH4057	KIT BODY BALNCER+GEAR BAL IDL	Bajaj spare parts
36DH4061	OIL BRAKE DOT 4	Bajaj spare parts
36DH4062	KIT TANK SPOILER DCL S BLUE-K1	Bajaj spare parts
36DH4063	KIT TANK SPOILER DCL W RED-K1	Bajaj spare parts
36DH4064	KIT TANK SPOILER DCL PL SILVER-K1	Bajaj spare parts
36DH4065	KIT S COWL DCL S BLUE-K1	Bajaj spare parts
36DH4066	KIT S COWL DCL W RED-K1	Bajaj spare parts
36DH4067	KIT S COWL DCL PL SILVER-K1	Bajaj spare parts
36DH4068	KIT FAIRING DCL PL SILVER K1	Bajaj spare parts
36DH4069	KIT TANK DCL PL SILVER-K1	Bajaj spare parts
36DH4070	KIT S COVER DCL PL SILVER-K1	Bajaj spare parts
36DH4071	SPRAY CHAIN LUB 100	Bajaj spare parts



36DH4072	SPRAY RUST REMOVER WONDER FILL EASIN	Bajaj spare parts
36DH4073	KIT DCL FAIRING E BL-K1 & K2	Bajaj spare parts
36DH4074	KIT DCL T SPOILER E BL-K1	Bajaj spare parts
36DH4075	KIT DCL S COWL E BL-K1	Bajaj spare parts
36DH4077	KIT DCL T SPOILER M WHITE-K1	Bajaj spare parts
36DH4079	KIT DCL S COWL M WHITE-K1	Bajaj spare parts
36DH4080	KIT SUSPENSION BUSH KIT PULSAR	Bajaj spare parts
36DH4081	KIT GASKET ENGINE (HALF)	Bajaj spare parts
36DH4082	KIT OIL SEAL PULSAR 150	Bajaj spare parts
36DH4085	KIT DCL TANK E BLACK-K1&K2	Bajaj spare parts
36DH4089	FR AXLE KIT PULSAR 150 UG4	Bajaj spare parts
36DH4090	REAR AXLE KIT : PULSAR 150 UG4	Bajaj spare parts
36DH4091	HALF AXLE KIT PULSAR 150 UG4	Bajaj spare parts
36DH4094	CLUTCH PLATE	Bajaj spare parts
36DH4095	FRICTION PLATE	Bajaj spare parts
36DH4096	KIT FR.NUM PLATE AVENGER 220	Bajaj spare parts
36DH4099	KIT ASSLY C'CASE LH	Bajaj spare parts
36DH4101	KIT PISTON RINGS	Bajaj spare parts
36DH4102	PISTON RING SET	Bajaj spare parts
36DH4103	CYL BLOCK+PISTON K1 BSIV	Bajaj spare parts
36DH4104	KIT SEAT COWL DCL BLACK	Bajaj spare parts
36DH4105	KIT SEAT COWL DCL BLUE	Bajaj spare parts
36DH4106	KIT DCL FAIRING FL RED	Bajaj spare parts
36DH4109	KIT DCL S COVER LH F RED	Bajaj spare parts
36DH4110	KIT DCL S COVER RH F RED	Bajaj spare parts
36DH4111	KIT DCL SEAT COVER F RED	Bajaj spare parts
36DH4112	KIT DCL TANK F RED	Bajaj spare parts
36DH4115	KIT CYL COMPLE FORK K1 BSIV	Bajaj spare parts
36DH4116	KIT PRIMARY DRIVE & DRIVEN K1	Bajaj spare parts
36DH4117	KIT FRICTION PLATE K1 BSIV	Bajaj spare parts
36DH4118	KIT CARB JET BSIV-K1	Bajaj spare parts
36DH4119	KIT CARB V PISTON BSIV-K1	Bajaj spare parts
36DH4120	KIT STEEL CLUTCH PLATE K1 BSIV	Bajaj spare parts
36DH4121	KIT ASSLY CRANKCASE RH K1BSIV	Bajaj spare parts
36DH4122	KIT S COWL DCL E BL	Bajaj spare parts
36DH4123	KIT S COWL DCL R BLUE	Bajaj spare parts
36DH4124	KIT ASLY CL CVR MAT SLATE GRAY	Bajaj spare parts
36DH4125	KIT DECAL FAIRING PASSION RED	Bajaj spare parts
36DH4126	KIT DECAL TANK PASSION RED	Bajaj spare parts
36DH4127	KIT DECAL SEAT COWL PASSION RED	Bajaj spare parts
36DH4128	KIT DECAL SIDE COVER LH PASSION RED	Bajaj spare parts
36DH4129	KIT DECAL SIDE COVER RH PASSION RED	Bajaj spare parts
36DH4131	KIT FAIRING DECAL SAFFIRE BLUE	Bajaj spare parts
36DH4132	KIT TANK DECAL S BLUE	Bajaj spare parts
36DH4133	KIT SIDE COVER LH S BLUE	Bajaj spare parts

36DH4134	KIT SIDE COVER RH S BLUE	Bajaj spare parts
36DH4135	KIT FAIRING DECAL C W RED	Bajaj spare parts
36DH4136	PILOT SCREW KIT	Bajaj spare parts
36DH4137	KIT SIDE COVER LH WINE RED	Bajaj spare parts
36DH4138	KIT SIDE COVER RH WINE RED	Bajaj spare parts
36DH4139	KIT SEAT COWL DECL S BLUE-K1	Bajaj spare parts
36DH4140	KIT SEAT COWL DECL WINE RED-K1	Bajaj spare parts
36DH4141	KIT TANK DECAL WINE RED	Bajaj spare parts
36DH4143	KIT FAIRING DECAL	Bajaj spare parts
36DH4144	KIT TANK DECAL	Bajaj spare parts
36DH4145	KIT SEAT COWL DECAL	Bajaj spare parts
36DH4146	KIT FAIRING DECAL ROYAL BLUE	Bajaj spare parts
36DH4147	KIT TANK DECAL ROYAL BLUE	Bajaj spare parts
36DH4148	KIT SIDE CVR DCL LH ROYAL BLUE	Bajaj spare parts
36DH4149	KIT SIDE CVR DCL RH ROYAL BLUE	Bajaj spare parts
36DH4150	KIT SEAT COWL DCL RH ROYAL BLUE	Bajaj spare parts
36DH4151	ASSLY CRANKCASE LH K1 R	Bajaj spare parts
36DH4152	ASSLY CRANKCASE RH K1 R	Bajaj spare parts
36DH4154	KIT CHAIN SPROCKET	Bajaj spare parts
36DH4155	KIT TANK DECAL	Bajaj spare parts
36DH4156	KIT TANK FLAP DECAL	Bajaj spare parts
36DH4157	KIT SIDE COVER LH DECAL	Bajaj spare parts
36DH4158	KIT SIDE COVER RH DECAL	Bajaj spare parts
36DH4159	KIT SEAT COWL DECAL	Bajaj spare parts
36DH4160	KIT FENDER DECAL	Bajaj spare parts
36DH4161	KIT WHEEL RIM DECAL	Bajaj spare parts
36DH4163	KIT TANK DECAL BL-RED	Bajaj spare parts
36DH4164	KIT TANK FLAP DECAL BL-RED	Bajaj spare parts
36DH4165	KIT SIDE COVER LH DECAL BL-RED	Bajaj spare parts
36DH4166	KIT SIDE COVER RH DECAL BL-RED	Bajaj spare parts
36DH4167	KIT SEAT COWL DECAL BL-RED	Bajaj spare parts
36DH4168	KIT FENDER DECAL BL-RED	Bajaj spare parts
36DH4169	KIT WHEEL RIM DECAL BL-RED	Bajaj spare parts
36DH4170	PUSH ROD FRONT MASTER CYLINDER	Bajaj spare parts
36DH4171	GROMMET PUSH ROD FR MASTER CYL	Bajaj spare parts
36DH4172	MAJOR KIT REAR MST CYLINDER ENDU	Bajaj spare parts
36DH4173	MINOR KIT REAR MST CYLINDER ENDU	Bajaj spare parts
36DH4174	DISC PAD SET REAR CALIPER ENDU	Bajaj spare parts
36DH4175	MAJOR KIT REAR CALIPER ENDU	Bajaj spare parts
36DH4176	KIT PISTON SEAL REAR CALIPER ENDU	Bajaj spare parts
36DH4177	KIT MINOR REAR CALIPER ENDU	Bajaj spare parts
36DH4178	KIT BLEEDER SCREW ENDU	Bajaj spare parts
36DH4179	KIT CALIPER HARDWARES ENDU	Bajaj spare parts
36DH4180	KIT HOLDER BRACKET CALIPER ENDU	Bajaj spare parts
36DH4181	KIT FILLER & PROTECTION CAP	Bajaj spare parts

36DH4182	KIT RESERVOIR TUBE	Bajaj spare parts
36DH4183	KIT RESERVOIR	Bajaj spare parts
36DH4184	KIT BRAKE HOSE ENDU	Bajaj spare parts
36DH4188	KIT PRIMARY DRIVE & DRIVEN GEAR	Bajaj spare parts
36DH4189	KIT AIR FIL ELEMENT & CVR O RING	Bajaj spare parts
36DH4191	KIT SEAT COWL DECAL-EBLACK	Bajaj spare parts
36DH4192	KIT SEAT COWL DECAL-V RED	Bajaj spare parts
36DH4193	KIT BENJO BOLT	Bajaj spare parts
36DH4196	FASTNING CAP KIT	Bajaj spare parts
36DH4201	RR MASTER CYLINDER PUSH ROD KIT	Bajaj spare parts
36DH4205	KIT HOSE UNIT ABS-CALIPER	Bajaj spare parts
36DH4206	KIT HOSE CYL MASTER FR-UNIT ABS	Bajaj spare parts
36DH4214	KIT FENDER DCL V RED	Bajaj spare parts
36DH4215	KIT FENDER DCL EBL BLUE	Bajaj spare parts
36DH4216	KIT FENDER DCL EBL RED	Bajaj spare parts
36DH4217	KIT SEAT COWL DCL V RED	Bajaj spare parts
36DH4218	KIT SEAT COWL DCL EBL RED	Bajaj spare parts
36DH4219	KIT SEAT COWL DCL EBL BLUE	Bajaj spare parts
36DH4220	KIT BELLY PAN DCL V RED	Bajaj spare parts
36DH4221	KIT BELLY PAN DCL BL RED	Bajaj spare parts
36DH4222	KIT BELLY PAN DCL BL BLUE	Bajaj spare parts
36DH4224	KIT CYL BLOCK+PISTON P125	Bajaj spare parts
36DH4225	VALVE KIT	Bajaj spare parts
36DH4227	BOSS KICK SET	Bajaj spare parts
36DH4231	KIT LEG GUARD LH/RH + HARDWARE	Bajaj spare parts
36DH4232	KIT CHAIN SPROCKETS	Bajaj spare parts
36DH4233	VACUUM PISTON KIT-BK-PV-486	Bajaj spare parts
36DH4234	PILOT SCREW KIT-BK-PS-382	Bajaj spare parts
36DH4235	JET KIT -BK-JET-488	Bajaj spare parts
36DH4236	FLOAT BODY KIT-BK-FCB-489	Bajaj spare parts
36DH4237	TOP CAP KIT-BK-TC-453	Bajaj spare parts
36DH4238	STARTER LEVER+PLUNGER-BK-ST-490	Bajaj spare parts
36DH4239	O-RING & GASKET KIT-BK-OG-487	Bajaj spare parts
36DH4242	KIT ST. CLUTCH-ROLLER & SPRING	Bajaj spare parts
36DH4243	BRAKE SHOE KIT JH131809	Bajaj spare parts
36DH4244	VALVE REPAIR KIT	Bajaj spare parts
36DH4245	KIT CAM CHAIN GUIDE	Bajaj spare parts
36DH4246	KIT CYL BLOCK+PISTON	Bajaj spare parts
36DH4247	KIT ASSEMBLY C'CASE LH	Bajaj spare parts
36DH4248	KIT ASSEMBLY C'CASE RH	Bajaj spare parts
36DH4252	KIT BELLY PAN DCL EBLACK	Bajaj spare parts
36DH4253	KIT BELLY PAN DCL E BLACK CROME	Bajaj spare parts
36DH4254	KIT DECAL BELLY PAN SAFFIRE BLUE	Bajaj spare parts
36DH4255	KIT DECAL BELLY PAN C WINE RED	Bajaj spare parts
36DH4256	KIT DCL BELLY PAN EBONY BLACK	Bajaj spare parts

36DH4257	KIT DCL BELLY PAN E BLACK BLUE	Bajaj spare parts
36DH4258	KIT DCL BELLY PAN MATTE V RED	Bajaj spare parts
36DH4259	BLOCK PISTON ASSLY	Bajaj spare parts
36DH4260	BELLY PAN DCL KIT LIME GREEN	Bajaj spare parts
36DH4262	KIT BLOCK-PISTON	Bajaj spare parts
36DH4264	KIT CLUTCH COVER SUB ASSLY	Bajaj spare parts
36DH4266	KIT FAIRING DECAL PEARL WHITE	Bajaj spare parts
36DH4267	KIT TANK DECAL PEARL WHITE	Bajaj spare parts
36DH4268	KIT SEAT COWL DECAL P WHITE	Bajaj spare parts
36DH4269	KIT TANK DECAL SATIN S BLUE	Bajaj spare parts
36DH4270	KIT FAIRING DECAL SATIN S BLUE	Bajaj spare parts
36DH4271	KIT SEAT COWL DECAL SATIN S BLUE	Bajaj spare parts
36DH4272	KIT FAIRING DECAL VOLCANIC RED	Bajaj spare parts
36DH4273	KIT TANK DECAL LH VOLCANIC RED	Bajaj spare parts
36DH4274	KIT SEAT COWL DCL VOLCANIC RED	Bajaj spare parts
36DH4275	KIT FAIRING DECAL SATIN S BLACK	Bajaj spare parts
36DH4276	KIT TANK DECAL SATIN S BLACK	Bajaj spare parts
36DH4277	KIT SEAT COWL DCL SATIN S BLACK	Bajaj spare parts
36DH4280	KIT WHEEL DCL RED	Bajaj spare parts
36DH4282	KIT WHEEL DCL PEARL WHITE	Bajaj spare parts
36DH4283	KIT SEAT COWL DCL SATIN S BLACK	Bajaj spare parts
36DH4284	KIT SEAT COWL DCL VOLCANIC RED	Bajaj spare parts
36DH4285	KIT SEAT COWL DCL SATIN S BLUE	Bajaj spare parts
36DH4286	KIT SEAT COWL DCL PEARL WHITE	Bajaj spare parts
36DH4287	KIT FENDER DECAL RED	Bajaj spare parts
36DH4288	KIT FENDER DECAL PEARL WHITE	Bajaj spare parts
36DH4289	KIT WHEEL DCL RED	Bajaj spare parts
36DH4290	KIT WHEEL DCL PEARL WHITE	Bajaj spare parts
36DH4292	KIT SEAT COWL DCL M WHITE	Bajaj spare parts
36DH4293	KIT SEAT COWL DCL BLUE	Bajaj spare parts
36DH4294	KIT SEAT COWL DCL RED	Bajaj spare parts
36DH4295	KIT SEAT COWL DCL SPARK BLACK	Bajaj spare parts
36DH4296	KIT DECAL FAIRING SILVER	Bajaj spare parts
36DH4297	KIT DECAL WHEEL SILVER	Bajaj spare parts
36DH4298	KIT DECAL COWL SEAT SILVER	Bajaj spare parts
36DH4301	KIT DECAL WHEEL LIME GREEN	Bajaj spare parts
36DH4302	KIT DECAL COWL SEAT LIME GREEN	Bajaj spare parts
36DH4303	KIT DECAL FAIRING LIME GREEN	Bajaj spare parts
36DH4304	KIT DECAL FAIRING P RED	Bajaj spare parts
36DH4306	KIT DECAL COWL SEAT P RED	Bajaj spare parts
36DH4307	KIT DECAL WHEEL P RED	Bajaj spare parts
36DH4308	KIT DECAL FAIRING SOLAR RED	Bajaj spare parts
36DH4309	KIT DECAL TANK SOLAR RED	Bajaj spare parts
36DH4310	KIT DECAL SEAT COWL RED	Bajaj spare parts
36DH4311	KIT DECAL WHEEL SOLAR RED	Bajaj spare parts

36DH4312	KIT DECAL FAIRING GREEN	Bajaj spare parts
36DH4313	KIT DECAL TANK GREEN	Bajaj spare parts
36DH4314	KIT DECAL COWL SEAT GREEN	Bajaj spare parts
36DH4315	KIT DECAL WHEEL TREE FROG GREEN	Bajaj spare parts
36DH4322	COVER CLUTCH ASSLY SLICK BLACK	Bajaj spare parts
36DH4323	COVER CLUTCH ASSLY SLICK BLACK	Bajaj spare parts
36DH4324	TANK DECAL KIT PASSION RED	Bajaj spare parts
36DH4325	TANK DECAL KIT PL SILVER	Bajaj spare parts
36DH4327	TANK DECAL KIT GREEN	Bajaj spare parts
36DH4328	KIT DECAL COWL SEAT SILVER	Bajaj spare parts
36DH4329	KIT DECAL TANK SOLAR RED	Bajaj spare parts
36DH4330	KIT DECAL TANK GREEN	Bajaj spare parts
36DH4332	KIT DCL FAIRING S BLACK SILVER	Bajaj spare parts
36DH4333	KIT DCL FAIRING S BLUE WHITE	Bajaj spare parts
36DH4334	KIT DCL FAIRING S BLACK BLUE	Bajaj spare parts
36DH4335	KIT DCL FAIRING S BLACK RED	Bajaj spare parts
36DH4336	KIT DCL TANK S BLACK SILVER	Bajaj spare parts
36DH4337	KIT DCL TANK S BLUE WHITE	Bajaj spare parts
36DH4338	KIT DCL TANK S BLACK BLUE	Bajaj spare parts
36DH4339	KIT DCL TANK S BLACK RED	Bajaj spare parts
36DH4340	KIT DCL COWL SEAT S BLK SVR	Bajaj spare parts
36DH4341	KIT DCL COWL SEAT S BL WH	Bajaj spare parts
36DH4342	KIT DCL COWL SEAT S BLK BL	Bajaj spare parts
36DH4343	KIT DCL COWL SEAT S BLK RED	Bajaj spare parts
36DH4344	KIT DCL FENDER S BLACK SILVER	Bajaj spare parts
36DH4345	KIT DCL FENDER S BLUE WHITE	Bajaj spare parts
36DH4346	KIT DCL FENDER S BLACK BLUE	Bajaj spare parts
36DH4347	KIT DCL FENDER S BLACK RED	Bajaj spare parts
36DH4356	KIT FRICATION PLATE ETL	Bajaj spare parts
36DH4357	KIT CLUTCH PLATE PLANISH ETL	Bajaj spare parts
36DH4358	CARBURETTOR HEATER KIT-K19	Bajaj spare parts
36DH4359	CARBURETTOR HEATER KIT-K1 BS4	Bajaj spare parts
36DH4360	KIT DECAL SEAT COWL SILVR-P125	Bajaj spare parts
36DH4362	KIT DCL SEAT COWL SOLAR RED-P125	Bajaj spare parts
36DH4363	KIT DCL SEAT COWL TF GREEN-P125	Bajaj spare parts
36DH4364	KIT FAIRING DCL RED	Bajaj spare parts
36DH4365	KIT FAIRING DCL SILVER	Bajaj spare parts
36DH4369	KIT FAIRING DCL TF GREEN	Bajaj spare parts
36DH4370	KIT TANK DCL RED	Bajaj spare parts
36DH4371	KIT TANK DCL SILVER	Bajaj spare parts
36DH4372	KIT TANK DCL TF GREEN	Bajaj spare parts
36DH4387	Accessory kit Pulsar 150	Bajaj spare parts
36DH4389	KIT SEAT COWL DECAL SILVER	Bajaj spare parts
36DH4391	KIT SEAT COWL DECAL BLUE	Bajaj spare parts
36DH4392	KIT SEAT COWL DECAL RED	Bajaj spare parts

36DJ1004	KIT VALVE PULSAR DTSI 180	Bajaj spare parts
36DJ1406	KIT DECAL PULSER 180	Bajaj spare parts
36DJ1501	KIT CHAIN SPROCKET PUL 15	Bajaj spare parts
36DJ1502	KIT CHAIN SPROCKET PULSAR	Bajaj spare parts
36DJ4005	KIT CHAIN SPROCKET MOD.PU	Bajaj spare parts
36DJ4008	KIT RING SET PSTN UG	Bajaj spare parts
36DJ4011	KIT DECAL PULSAR UGI	Bajaj spare parts
36DJ4016	KIT OIL SEAL PUL 180	Bajaj spare parts
36DJ4017	KIT ASSLY CL COVER	Bajaj spare parts
36DJ4021	KIT WHEEL 2.5X17 (4 LUG SILVER)	Bajaj spare parts
36DJ4022	KIT ENGINE GASKET PLR 180	Bajaj spare parts
36DJ4023	KIT SEATCOWL DCL BLUE180	Bajaj spare parts
36DJ4024	KIT SEATCOWL DCL RED180	Bajaj spare parts
36DJ4026	KIT COVER CLUTCH SLV P180	Bajaj spare parts
36DJ4029	KIT SILENCER ASLY W/O SHIELD	Bajaj spare parts
36DJ4030	KIT SCB SENSOR+MAG -K2/K3 S	Bajaj spare parts
36DJ4031	KIT END MJR MAST CYL	Bajaj spare parts
36DJ4032	KIT MIN CAL END	Bajaj spare parts
36DJ4033	KIT END -KIT MJR CAL & GR	Bajaj spare parts
36DJ4034	KIT CYL HEAD+COV-P180	Bajaj spare parts
36DJ4037	KIT FAIRING DCL W RED-K1/K2	Bajaj spare parts
36DJ4038	KIT FAIRING DCL M WHITE K2	Bajaj spare parts
36DJ4039	KIT FAIRING DCL S BLUE K1/K2	Bajaj spare parts
36DJ4040	KIT S COWL DCL W RED-K2	Bajaj spare parts
36DJ4041	KIT S COWL DCL M WHITE-K2	Bajaj spare parts
36DJ4042	KIT S COWL DCL S BLUE-K2	Bajaj spare parts
36DJ4043	KIT S COVER DCL W RED-K1/K2/K3	Bajaj spare parts
36DJ4044	KIT S COVER DCL M WHITE-K2/K3	Bajaj spare parts
36DJ4045	KIT S COVER DCL S BLUE-K1/K2/K3	Bajaj spare parts
36DJ4046	KIT TANK DCL S BLUE-K1/K2	Bajaj spare parts
36DJ4047	KIT TANK DCL M METALLIC-K2	Bajaj spare parts
36DJ4048	KIT TANK DCL S BLUE-K1/K2	Bajaj spare parts
36DJ4049	KIT TANK SPOILER DCL W RED-K2	Bajaj spare parts
36DJ4050	KIT TANK SPOILER DCL M WHITE-K2	Bajaj spare parts
36DJ4051	KIT TANK SPOILER DCL S BLUE-K1/K2	Bajaj spare parts
36DJ4052	KIT DCL S COWL E BL-K2	Bajaj spare parts
36DJ4054	KIT GASKET ENGINE (HALF)	Bajaj spare parts
36DJ4057	GRAB HANDLE KIT BLACK / SILVER :	Bajaj spare parts
36DJ4061	KIT VALVE + VALVE OIL SEAL	Bajaj spare parts
36DJ4063	KIT FAIRING DCL RED	Bajaj spare parts
36DJ4064	KIT TANK DCL RED	Bajaj spare parts
36DJ4065	KIT DCLLH SIDE COVER RED	Bajaj spare parts
36DJ4066	KIT DCL RH SIDE COVER RED	Bajaj spare parts
36DJ4067	KIT S COWL DCL RED	Bajaj spare parts
36DJ4068	KIT TANK DCL R BLUE K2	Bajaj spare parts

36DJ4069	KIT FAIRING DCL R BLUE K2	Bajaj spare parts
36DJ4072	KIT S COWL R BLUE K2	Bajaj spare parts
36DJ4075	KIT FAIRING DCL E BLACK	Bajaj spare parts
36DJ4076	KIT TANK DCL E BLACK	Bajaj spare parts
36DJ4077	KIT S COWL E BLACK	Bajaj spare parts
36DJ4078	KIT FAIRING DCL R BLUE	Bajaj spare parts
36DJ4079	KIT TANK DCL R BLUE	Bajaj spare parts
36DJ4081	KIT S COWL R BLUE K2	Bajaj spare parts
36DJ4082	KIT ASSLY CL CVR SLATE GRAY-K2	Bajaj spare parts
36DJ4083	KIT DECAL SEAT COWL PASSION RED	Bajaj spare parts
36DJ4084	KIT SEAT COWL DECAL S BLUE-K2	Bajaj spare parts
36DJ4085	KIT SEAT COWL DECAL W RED-K2	Bajaj spare parts
36DJ4086	KIT SEAT COWL DECAL	Bajaj spare parts
36DJ4087	KIT SEAT COWL DECAL K2	Bajaj spare parts
36DJ4089	ASSEMBLY HEAD MACH. WITH COVER	Bajaj spare parts
36DJ4090	KIT SEAT COWL DECAL-EBLACK	Bajaj spare parts
36DJ4091	KIT SEAT COWL DECAL-V RED	Bajaj spare parts
36DJ4092	KIT SPOILER DECAL-EBLACK	Bajaj spare parts
36DJ4093	KIT TANK DECAL-EBLACK	Bajaj spare parts
36DJ4094	KIT SPOILER DECAL-V RED	Bajaj spare parts
36DJ4095	KIT TANK DECAL-V RED	Bajaj spare parts
36DJ4096	KIT CYLINDER HEAD	Bajaj spare parts
36DJ4098	KIT BLACK CYL HEAD WITH COVER	Bajaj spare parts
36DJ4101	KIT FAIRING DECALS ORANGE	Bajaj spare parts
36DJ4102	KIT FAIRING DECALS PM SILVER	Bajaj spare parts
36DJ4103	KIT FAIRING DECALS P RED	Bajaj spare parts
36DJ4105	VALVE KIT	Bajaj spare parts
36DJ4106	BLOCK PISTON ASSLY	Bajaj spare parts
36DJ4107	PISTON RING SET	Bajaj spare parts
36DJ4108	BELLY PAN DCL KIT EB BLK P.RED	Bajaj spare parts
36DJ4110	BELLY PAN DCL KIT EB PLT SILVER	Bajaj spare parts
36DJ4120	KIT DCL TANK S BLACK SILVER	Bajaj spare parts
36DJ4121	KIT DCL TANK SAFIRE BLUE WHITE	Bajaj spare parts
36DJ4122	KIT DCL TANK S BLACK BLUE	Bajaj spare parts
36DJ4123	KIT DCL TANK S BLACK RED	Bajaj spare parts
36DJ4124	KIT DCL COWL SEAT S BLK SILVER	Bajaj spare parts
36DJ4125	KIT DCL COWL SEAT S BLUE WHITE	Bajaj spare parts
36DJ4126	KIT DCL COWL SEAT S BLK BLUE	Bajaj spare parts
36DJ4127	KIT DCL COWL SEAT S BLK RED	Bajaj spare parts
36DJ4128	KIT DCL COWL SEAT S BLK SILVER	Bajaj spare parts
36DJ4129	KIT DCL COWL SEAT S BLUE WHITE	Bajaj spare parts
36DJ4130	KIT DCL COWL SEAT S BLK BLUE	Bajaj spare parts
36DJ4131	KIT DCL COWL SEAT S BLK RED	Bajaj spare parts
36DK0005	KIT VALVE REPAIR PUL	Bajaj spare parts
36DK0006	KIT DECAL SET PULSAR	Bajaj spare parts

36DK0007	KIT CENTRIFUIGAL OIL	Bajaj spare parts
36DK0008	KIT HARDWARE AIR CLE	Bajaj spare parts
36DK0009	KIT HARDWARE SILENCE	Bajaj spare parts
36DK0011	KIT HARD ENG.MOUNT	Bajaj spare parts
36DK0012	KIT BUSH RE.SHOCK	Bajaj spare parts
36DK0013	KIT HARDWARE	Bajaj spare parts
36DK0014	KIT LEVER BRAKE	Bajaj spare parts
36DK0015	KIT ELEMENT AIR FILT	Bajaj spare parts
36DK0016	KIT HARD.BRAKE PEDAL	Bajaj spare parts
36DK0017	KIT HWARE ROD BRA	Bajaj spare parts
36DK0018	KIT H.WARE ROD TORQ	Bajaj spare parts
36DK0019	KIT HARDWARE HOLD LH	Bajaj spare parts
36DK0020	KIT OUTER TUBE	Bajaj spare parts
36DK0021	KIT HARDWARE BRKT	Bajaj spare parts
36DK0024	KIT CHAIN SPROCKET	Bajaj spare parts
36DK0026	KIT TANK DECAL PULR	Bajaj spare parts
36DK0029	KIT PRIMARY PULSAR	Bajaj spare parts
36DK0031	KIT HARDWARE RODBRAK	Bajaj spare parts
36DK0032	KIT 10 K KM PULSAR U	Bajaj spare parts
36DK0033	KIT P200 LG GUARD KI	Bajaj spare parts
36DK0034	KIT BRAKE PEDAL KIT	Bajaj spare parts
36DK0036	KIT CHAIN SPROCKET UG4	Bajaj spare parts
36DK0037	KIT MIRROR HOLDER PU	Bajaj spare parts
36DK0038	KIT SET PRIMARY DRIV	Bajaj spare parts
36DK0040	KIT CHAIN SPROCKET	Bajaj spare parts
36DK0044	KIT DECAL FAIRING M BLCK	Bajaj spare parts
36DK0045	GREASE MOLYKOTE200G	Bajaj spare parts
36DK0050	KIT STARTER MOTOR	Bajaj spare parts
36DK0058	KIT PISTON VALVE 220F	Bajaj spare parts
36DK0059	KIT MAIN JET	Bajaj spare parts
36DK0060	KIT FLOAT CHAMBER BODY 22	Bajaj spare parts
36DK0061	KIT TAP CAP ASSLY 220F	Bajaj spare parts
36DK0062	KIT SOLENOID ASSLY 220F	Bajaj spare parts
36DK0064	KIT COVER RH FLOWER TYPE	Bajaj spare parts
36DK0065	MINOR KIT CALIPER WITH GREASE	Bajaj spare parts
36DK0066	MAJOR KIT CALIPER WITH GREASE	Bajaj spare parts
36DK0067	KIT CALIPER MAJOR/GREASE	Bajaj spare parts
36DK0068	KIT CALIPER MAJOR/GREASE	Bajaj spare parts
36DK0069	MAJOR KIT M CYL WTH GREASE	Bajaj spare parts
36DK0070	MINOR KIT MASTER CYL	Bajaj spare parts
36DK0071	PUSH ROD WITH GREASE	Bajaj spare parts
36DK0072	KIT PLATE FRICT PULSR	Bajaj spare parts
36DK0073	KIT PLATE FRIC PUL	Bajaj spare parts
36DK0074	KIT PLATE FRICTION	Bajaj spare parts
36DK0075	KIT PLATE FRICTION PULSAR	Bajaj spare parts



36DK0076	KIT Starter Clutch Assembly	Bajaj spare parts
36DK0077	KIT For Starter Clutch	Bajaj spare parts
36DK0078	KIT ENGINE GASKET PULSAR 220	Bajaj spare parts
36DK0082	KIT DECAL TANK 220F BL	Bajaj spare parts
36DK0083	KIT DECAL FAIRING 220F BL	Bajaj spare parts
36DK0084	KIT DECAL SD COVER BLUE	Bajaj spare parts
36DK0085	KIT DECAL COWL 220F BLUE	Bajaj spare parts
36DK0086	KIT DECAL TANK 220F RD	Bajaj spare parts
36DK0087	KIT DECAL FAIRING 220F RD	Bajaj spare parts
36DK0088	KIT DECAL SD COVER RED	Bajaj spare parts
36DK0089	KIT DECAL COWL 220F RED	Bajaj spare parts
36DK0090	HEAD CYLINDER	Bajaj spare parts
36DK0096	KIT FAIRING DCL S BLUE K3	Bajaj spare parts
36DK0097	KIT TAN DCL S BLUE-K3	Bajaj spare parts
36DK0098	KIT S COWL DCL S BLUE	Bajaj spare parts
36DK0099	KIT FAIRING DCL W RED K3	Bajaj spare parts
36DK0100	KIT TAN DCL W RED-K3	Bajaj spare parts
36DK0101	KIT S COWL DCL W RED-K3	Bajaj spare parts
36DK0102	KIT FAIRING DCL M WHITE K3	Bajaj spare parts
36DK0103	KIT TAN DCL M WHITE-K3	Bajaj spare parts
36DK0104	KIT S COWL DCL M WHITE-K3	Bajaj spare parts
36DK0105	KIT PULSAR DCL SATIN CROME-LH	Bajaj spare parts
36DK0106	KIT PULSAR DCL SATIN CROME-RH	Bajaj spare parts
36DK0107	KIT DCL FAIRING E BL-K3	Bajaj spare parts
36DK0108	KIT DCL S COWL E BL-K3	Bajaj spare parts
36DK0111	KIT DCL S COWL S BLUE-K3S	Bajaj spare parts
36DK0112	KIT DCL S COWL W RED-K3S	Bajaj spare parts
36DK0113	KIT DCL S COWL M WHITE-K3S	Bajaj spare parts
36DK0114	KIT DCL S COWL E BLACK-K3S	Bajaj spare parts
36DK0115	KIT DCL TANK E BLACK-K3	Bajaj spare parts
36DK0119	KIT CYL HEAD WITH COVER SAI-K3	Bajaj spare parts
36DK0120	SEAT COWL DCL-220	Bajaj spare parts
36DK0121	TANK DCL-P220	Bajaj spare parts
36DK0122	KIT FAIRING DCL-P220	Bajaj spare parts
36DK0123	KIT FAIRING DCL ROYAL BLUE	Bajaj spare parts
36DK0124	KIT TANK DCL ROYAL BLUE	Bajaj spare parts
36DK0125	KIT S COVER LH ROYAL BLUE	Bajaj spare parts
36DK0126	KIT S COVER RH ROYAL BLUE	Bajaj spare parts
36DK0127	KIT S COWL ROYAL BLUE	Bajaj spare parts
36DK0128	KIT DCL SEAT CVR F RED	Bajaj spare parts
36DK0129	KIT FAIRING DCL F RED	Bajaj spare parts
36DK0130	KIT TANK DCL F RED	Bajaj spare parts
36DK0131	KIT FAIRING DCL EB BL	Bajaj spare parts
36DK0132	KIT TANK DCL EB BL	Bajaj spare parts
36DK0133	KIT SEAT COWL DCL EB BL	Bajaj spare parts

36DK0134	KIT FAIRING DCL R BLUE	Bajaj spare parts
36DK0135	KIT TANK DCL R BLUE	Bajaj spare parts
36DK0136	KIT SEAT COWL DCL R BLUE	Bajaj spare parts
36DK0137	KIT DCL S COVER LH E BL	Bajaj spare parts
36DK0138	KIT DCL S COVER RH E BL	Bajaj spare parts
36DK0139	KIT DCL S COVER LH E R BLUE	Bajaj spare parts
36DK0140	KIT DCL S COVER RH R BLUE	Bajaj spare parts
36DK0141	KIT ASSLY CL CVR SLATE GRAY-K3	Bajaj spare parts
36DK0142	KIT DECAL FAIRING PASSION RED	Bajaj spare parts
36DK0143	KIT DECAL TANK PASSION RED	Bajaj spare parts
36DK0144	KIT DECAL SEAT COWL PASSION RED	Bajaj spare parts
36DK0145	KIT FAIRING DCL S BLUE	Bajaj spare parts
36DK0146	KIT TANK DECAL S BLUE	Bajaj spare parts
36DK0147	KIT SEAT COWL DCL S BLUE	Bajaj spare parts
36DK0148	KIT FAIRING DCL WINE RED	Bajaj spare parts
36DK0149	KIT FAIRING DECAL WINE RED	Bajaj spare parts
36DK0150	KIT SEAT COWL DCL W RED	Bajaj spare parts
36DK0151	KIT FAIRING DECAL	Bajaj spare parts
36DK0152	KIT SIDE COVER DCL LH	Bajaj spare parts
36DK0153	KIT SIDE COVER DCL RH	Bajaj spare parts
36DK0154	KIT SEAT COWL DCL	Bajaj spare parts
36DK0155	KIT FENDER DECAL	Bajaj spare parts
36DK0156	KIT ASSLY CARB PLUNGER K3 BS4	Bajaj spare parts
36DK0159	KIT ST. CONE WITH GREASE	Bajaj spare parts
36DK0160	KIT AIR FIL ELEMENT & CVR O RING	Bajaj spare parts
36DK0162	KIT FAIRING DECAL EBONY BLACK	Bajaj spare parts
36DK0163	KIT SEAT COWL DECAL EBLACK	Bajaj spare parts
36DK0164	KIT FENDER DECAL EBLACK	Bajaj spare parts
36DK0165	KIT BELLY PAN DECAL EBLACK	Bajaj spare parts
36DK0166	KIT FAIRING DECAL V RED	Bajaj spare parts
36DK0167	KIT SEAT COWL DECAL V RED	Bajaj spare parts
36DK0168	KIT FENDER DECAL V RED	Bajaj spare parts
36DK0169	KIT BELLY PAN DECAL V RED	Bajaj spare parts
36DK0173	KIT HEAD+COVER-K3 UG BLACK IM	Bajaj spare parts
36DK0174	KIT HEAD+COVER-K3UG BLACK IM-FRD	Bajaj spare parts
36DK0176	KIT SEAT COWL DECAL BLUE	Bajaj spare parts
36DK0177	KIT FAIRING DECAL BLUE	Bajaj spare parts
36DK0178	KIT FENDER DECAL BLUE	Bajaj spare parts
36DK0179	KIT BELLY PAN DECAL BLUE	Bajaj spare parts
36DK0180	KIT SEAT COWL DECAL BLUE	Bajaj spare parts
36DK0181	KIT SPOILER DECAL BLUE	Bajaj spare parts
36DK0182	KIT TANK DECAL BLUE	Bajaj spare parts
36DK0183	KIT SEAT COWL DECAL BLUE	Bajaj spare parts
36DK0186	FR M/CYL TO ABS HOSE KIT	Bajaj spare parts
36DK0187	FR CALIPER TO ABS HOSE KIT	Bajaj spare parts

36DK0188	KIT BLOCK-PISTON ASSLY	Bajaj spare parts
36DK0189	KIT TIMING CHAIN GUIDE	Bajaj spare parts
36DK0190	KIT VALVE INLET-OUTLET	Bajaj spare parts
36DK0191	KIT VALVE REPAIR CYL HEAD	Bajaj spare parts
36DK0192	KIT PISTON RINGS	Bajaj spare parts
36DK0193	KIT ASSLY CRANKCASE LH	Bajaj spare parts
36DK0194	KIT ASSLY CRANKCASE RH	Bajaj spare parts
36DK0197	KIT FAIRING DECAL SATIN WHITE	Bajaj spare parts
36DK0198	KIT FAIRING DECAL V RED	Bajaj spare parts
36DK0199	KIT FAIRING DECAL SATIN S BLUE	Bajaj spare parts
36DK0200	KIT FAIRING DCL S METALIC BLACK	Bajaj spare parts
36DK0201	KIT TANK DECAL SATIN WHITE	Bajaj spare parts
36DK0202	KIT TANK DECAL SATIN S BLUE	Bajaj spare parts
36DK0203	KIT TANK DECAL VOLCANIC RED	Bajaj spare parts
36DK0204	KIT TANK DECAL SATIN S BLACK	Bajaj spare parts
36DK0205	KIT SEAT COWL DCL SATIN P WH	Bajaj spare parts
36DK0206	KIT SEAT COWL DCL SATIN BLUE	Bajaj spare parts
36DK0207	KIT SEAT COWL DCL VOLCANIC RED	Bajaj spare parts
36DK0208	KIT SEAT COWL DCL SATIN S BLACK	Bajaj spare parts
36DK0209	KIT CRANKCASE LH DK101385	Bajaj spare parts
36DK0210	COVER CLUTCH 220 SLICK BLACK	Bajaj spare parts
36DK0211	KIT DCL COWL SEAT S BL WHITE	Bajaj spare parts
36DK0212	KIT DCL COWL SEAT S BLK RED	Bajaj spare parts
36DK0213	KIT DCL COWL SEAT S BLK BLUE	Bajaj spare parts
36DK0214	KIT DCL COWL SEAT S BLK SILVER	Bajaj spare parts
36DK0215	KIT DCL FAIRING S BLK RED	Bajaj spare parts
36DK0216	KIT DCL FAIRING S BLACK SILVER	Bajaj spare parts
36DK0217	KIT DCL FAIRING S BLK BLUE	Bajaj spare parts
36DK0218	KIT DCL FAIRING S BLUE WHITE	Bajaj spare parts
36DK0219	KIT DCL FENDER S BLACK BLUE	Bajaj spare parts
36DK0220	KIT DCL FENDER S BLACK RED	Bajaj spare parts
36DK0221	KIT DCL FENDER S BLACK SILVER	Bajaj spare parts
36DK0222	KIT DCL FENDER S BLUE WHITE	Bajaj spare parts
36DK0223	KIT DCL TANK S BLACK BLUE	Bajaj spare parts
36DK0224	KIT DCL TANK S BLACK RED	Bajaj spare parts
36DK0225	KIT DCL TANK S BLACK SILVER	Bajaj spare parts
36DK0226	KIT DCL TANK S BLUE WHITE	Bajaj spare parts
36DK0227	KIT DCL WHEEL S BLACK BLUE	Bajaj spare parts
36DK0228	KIT DCL WHEEL S BLACK RED	Bajaj spare parts
36DK0229	KIT DCL WHEEL S BLACK SILVER	Bajaj spare parts
36DK0230	KIT DCL WHEEL S BLUE WHITE	Bajaj spare parts
36DK0232	ACCESSORY KIT PULSAR 220 F	Bajaj spare parts
36DS1001	KIT O RING HEAD CYL DISCO	Bajaj spare parts
36DS1002	KIT VALVE DISCOVER	Bajaj spare parts
36DS1004	KIT CHAIN GUIDE DISCOVER	Bajaj spare parts

36DS1201	KIT CARB VACCUM PISTON DI	Bajaj spare parts
36DS1202	KIT HOLDER JET DISCOVER	Bajaj spare parts
36DS1401	KIT GROMMET FUEL TANK	Bajaj spare parts
36DS1502	KIT GEAR SPEEDOMETER	Bajaj spare parts
36DS1504	KIT CHAIN SPROCKET DIS	Bajaj spare parts
36DS1801	HOLDER HANDLE SET	Bajaj spare parts
36DS1802	KIT STEERING CONE	Bajaj spare parts
36DS2101	KIT DAMPER SEAT	Bajaj spare parts
36DS4010	KIT CHAIN CASE DISCOVER	Bajaj spare parts
36DS4011	KIT CHAIN SPROCKET DISCOV	Bajaj spare parts
36DS4012	KIT CH SPR DISCOV	Bajaj spare parts
36DS4020	KITCHAIN CASE DIS 12	Bajaj spare parts
36DS4032	KIT OIL SEAL DIS 125	Bajaj spare parts
36DS4033	KIT DISCOVER 100/125/150 : O RING KIT	Bajaj spare parts
36DS4034	KIT VALVE + VALVE OIL SEAL	Bajaj spare parts
36DS4035	KIT ST. CONE (30MM) WITH GREASE	Bajaj spare parts
36DT0001	KIT HARDWARE FAIRING+R COWL	Bajaj spare parts
36DT0002	KIT HARDWARE S COWL+SIDE	Bajaj spare parts
36DT0003	KIT HARDWARE P TANK COVER	Bajaj spare parts
36DT0004	KIT TIE BAND-W HARNESS	Bajaj spare parts
36DT0007	KIT CHAIN SPROCKET	Bajaj spare parts
36DT0010	KIT DCL FAIRING-P YELLOW	Bajaj spare parts
36DT0011	KIT DCL FAIRING-PA RED	Bajaj spare parts
36DT0013	KIT DCL S COWL-P YELLOW	Bajaj spare parts
36DT0014	KIT DCL S COWL-PA RED	Bajaj spare parts
36DT0016	KIT DCL SPOILER LH-P YELLOW	Bajaj spare parts
36DT0017	KIT DCL SPOILER LH-PA RED	Bajaj spare parts
36DT0019	KIT DCL SPOILER RH-P YELLOW	Bajaj spare parts
36DT0020	KIT DCL SPOILER RH-PA RED	Bajaj spare parts
36DT0028	KIT DCL FENDER ABS-P RED	Bajaj spare parts
36DT0029	KIT DCL FENDER ABS- BR YELLOW	Bajaj spare parts
36DT0030	KIT DCL FENDER -P RED	Bajaj spare parts
36DT0031	KIT DCL FENDER - BR YELLOW	Bajaj spare parts
36DT0034	MJR KIT FR MASTER CYL	Bajaj spare parts
36DT0035	MINOR KIT - FR MASTER	Bajaj spare parts
36DT0036	SWITCH KIT - FR MASTER	Bajaj spare parts
36DT0039	MJR KIT - REAR M/ CYL-(Ø14)	Bajaj spare parts
36DT0040	MINOR KIT - REAR M/ CYL-(Ø14)	Bajaj spare parts
36DT0042	KIT HOSE DISC BRAKE REAR	Bajaj spare parts
36DT0043	KIT BRK HOSE MASTER CYL	Bajaj spare parts
36DT0044	Kit brake hose caliper to ABS unit	Bajaj spare parts
36DT0045	KIT DECAL FAIRING EBONY BLACK	Bajaj spare parts
36DT0046	DECAL F LH E-BLACK	Bajaj spare parts
36DT0047	DECAL F LOWER RH E-BLACK	Bajaj spare parts
36DT0048	KIT DECAL SEAT COWL EBONY BLACK	Bajaj spare parts

36DT0049	KIT DECAL FRONT FENDER EBONY BLACK	Bajaj spare parts
36DT0052	KIT BRACKET CALIPER REAR	Bajaj spare parts
36DT0053	KIT FR.NUM.PLATE PUL	Bajaj spare parts
36DT0054	KIT RR.NUMBER PLATE PULSAR RS 200	Bajaj spare parts
36DT0055	KIT CL HOUSING & PRIMARY GEAR	Bajaj spare parts
36DT0057	KIT FAIRING DCL P RED	Bajaj spare parts
36DT0058	KIT SIDE FAIRING DCL LH P RED	Bajaj spare parts
36DT0059	KIT SIDE FAIRING DCL RH P RED	Bajaj spare parts
36DT0060	KIT TANK TOP COVER P RED	Bajaj spare parts
36DT0061	KIT S COWL DCL 2D P RED	Bajaj spare parts
36DT0062	KIT FAIRING DCL S BLUE	Bajaj spare parts
36DT0063	KIT SIDE FAIRING DCL LH S BLUE	Bajaj spare parts
36DT0064	KIT SIDE FAIRING DCL RH S BLUE	Bajaj spare parts
36DT0065	KIT T TOP COVER S BLUE	Bajaj spare parts
36DT0066	KIT S COWL DCL 2D S BLUE	Bajaj spare parts
36DT0067	KIT SIDE FAIRING DCL LH B GRAY	Bajaj spare parts
36DT0068	KIT FAIRING DCL B GRAY	Bajaj spare parts
36DT0069	KIT SIDE FAIRING DCL RH B GRAY	Bajaj spare parts
36DT0070	KIT T TOP COVER B GRAY	Bajaj spare parts
36DT0071	KIT S COWL DCL 2D B GRAY	Bajaj spare parts
36DT0072	KIT F FENDER DCL P RED-ABS	Bajaj spare parts
36DT0073	KIT F FENDER DCL S BLUE-ABS	Bajaj spare parts
36DT0074	KIT F FENDER DCL M BLACK-ABS	Bajaj spare parts
36DT0075	KIT FENDER DCL RED-N ABS	Bajaj spare parts
36DT0076	KIT FENDER DCL S BLUE-N ABS	Bajaj spare parts
36DT0077	KIT FENDER DCL BLACK-N ABS	Bajaj spare parts
36DT0079	KIT CRANKCASE RH BSIV	Bajaj spare parts
36DT0080	KIT CRANKCASE LH BSIV	Bajaj spare parts
36DT0081	K8 BSIV CYL HEAD(NEW CASTING)	Bajaj spare parts
36DT0085	KIT CRANKCASE LH	Bajaj spare parts
36DT0086	KIT HOSE M CYL REAR TO ABS	Bajaj spare parts
36DT0087	KIT HOSE CALIPER RR TO ABS	Bajaj spare parts
36DT0088	KIT HOSE M CYL RR TO ABS	Bajaj spare parts
36DT0089	KIT HOSE CALIPER REAR TO ABS	Bajaj spare parts
36DT0090	KIT HOSE MASTER CYL FRONT TO ABS	Bajaj spare parts
36DT0092	KIT HOSE CALIPER FRONT TO ABS	Bajaj spare parts
36DT0098	KIT DCL FAIRING BLUE	Bajaj spare parts
36DT0100	KIT DCL COWL SEAT RED	Bajaj spare parts
36DT0101	KIT DCL COWL SEAT BLACK	Bajaj spare parts
36DT0102	KIT DCL COWL SEAT BLUE	Bajaj spare parts
36DT0103	KIT DCL FRONT WHEEL YELLOW	Bajaj spare parts
36DT0104	KIT DCL FRONT WHEEL RED	Bajaj spare parts
36DT0105	KIT DCL FRONT WHEEL BLUE	Bajaj spare parts
36DT0109	KIT ENGINE GASKET	Bajaj spare parts
36DT0110	KIT DCL FAIRING	Bajaj spare parts

36DT0111	KIT DCL FAIRING GRAY	Bajaj spare parts
36DT0112	ASSLY MAG COVER SATIN BLACK	Bajaj spare parts
36DU1001	KIT O RING CT 100	Bajaj spare parts
36DU1004	GEAR LEVER SPRING KIT CT	Bajaj spare parts
36DU1007	KIT BOSS KICK CT100	Bajaj spare parts
36DU1202	KIT IDLING SCREW CT 100	Bajaj spare parts
36DU1203	KIT AIR CONTROL SCREW	Bajaj spare parts
36DU1204	KIT GASKET O RING CARB.	Bajaj spare parts
36DU1205	KIT FLOAT PIN CT-100	Bajaj spare parts
36DU1206	KIT CARBU HOLDER JET CT 1	Bajaj spare parts
36DU1503	KIT GEAR METER	Bajaj spare parts
36DU1504	KIT BUSHING FR HUB	Bajaj spare parts
36DU1505	KIT CHAIN SPROCKET CT100	Bajaj spare parts
36DU1506	KIT BEARING RR WH CT 100	Bajaj spare parts
36DU1901	KIT CABLE ADJ CT 100	Bajaj spare parts
36DU4003	KIT CHAIN SPROCKET CT 100	Bajaj spare parts
36DU4004	KIT CHAIN CASE 17 INCH CT	Bajaj spare parts
36DU4017	KIT CHAIN SPROCKET CT 100	Bajaj spare parts
36DU4033	DCL COWLING BL-RED	Bajaj spare parts
36DU4034	DCL COWLING FL-RED	Bajaj spare parts
36DU4036	DCL COWLING EL-BLUE	Bajaj spare parts
36DU4037	DCL COWLING BL-BLUE	Bajaj spare parts
36DU4038	DCL TANK BL-RED	Bajaj spare parts
36DU4039	DCL TANK FL RED	Bajaj spare parts
36DU4040	DCL TANK EL BLUE	Bajaj spare parts
36DU4041	DCL TANK BL-BLUE	Bajaj spare parts
36DU4042	DCL S COVER-BL RED	Bajaj spare parts
36DU4043	DCL S COVER-FL RED	Bajaj spare parts
36DU4044	DCL S COVER-EL BLUE	Bajaj spare parts
36DU4045	DCL S COVER-BL BLUE	Bajaj spare parts
36DU4046	DCL SEAT COWL-BL RED	Bajaj spare parts
36DU4047	DCL SEAT COWL-FL RED	Bajaj spare parts
36DU4048	DCL SEAT COWL EL BLUE	Bajaj spare parts
36DU4049	DCL SEAT COWL-BL BLUE	Bajaj spare parts
36DU4051	VALVE REPAIR	Bajaj spare parts
36DU4055	PRIMARY DRIVE+DRIVEN	Bajaj spare parts
36DU4056	KIT GASKET-CT100	Bajaj spare parts
36DU4057	KIT DCL P TANK BL-RED	Bajaj spare parts
36DU4058	KIT DCL P TANK FL-RED	Bajaj spare parts
36DU4059	KIT DCL P TANK EL-BLUE	Bajaj spare parts
36DU4060	KIT DCL P TANK BL-BLUE	Bajaj spare parts
36DU4061	KIT DCL S CVR BL RED	Bajaj spare parts
36DU4062	KIT DCL S CVR FL RED	Bajaj spare parts
36DU4063	KIT DCL S CVR EL BLUE	Bajaj spare parts
36DU4064	KIT DCL S CVR BL BLUE	Bajaj spare parts

36DU4074	KIT VALVE + VALVE OIL SEAL	Bajaj spare parts
36DU4075	KIT CHAIN SPROCKET CT100ES	Bajaj spare parts
36DU4076	KIT VALVE INTAKE+EXHAUST	Bajaj spare parts
36DU4078	KIT ASSLY CRANKCASE LH	Bajaj spare parts
36DU4079	KIT ASSLY CLUTCH COVER	Bajaj spare parts
36DU4081	KIT THROTTLE VALVE-B105B	Bajaj spare parts
36DU4082	TOP SET - B105B	Bajaj spare parts
36DU4083	IDLING SCREW SET-B105B	Bajaj spare parts
36DU4084	KIT JET- B105B	Bajaj spare parts
36DU4085	KIT CHAIN SPROCKET CT100ES	Bajaj spare parts
36DU4086	KIT DECAL FAIRING BL-RED	Bajaj spare parts
36DU4087	KIT DECAL TANK BL-RED	Bajaj spare parts
36DU4088	KIT DECAL SEAT COWL BL-RED	Bajaj spare parts
36DU4089	KIT DECAL FAIRING FL RED	Bajaj spare parts
36DU4090	KIT DECAL TANK FL RED	Bajaj spare parts
36DU4091	KIT DECAL SEAT COWL FL RED	Bajaj spare parts
36DU4095	KIT DECAL FAIRING BL BLUE	Bajaj spare parts
36DU4096	KIT DECAL TANK BL BLUE	Bajaj spare parts
36DU4097	KIT DECAL SEAT COWL BL BLUE	Bajaj spare parts
36DU4109	KIT AIR FIL ELEMENT & CVR O RING	Bajaj spare parts
36DU4112	"KIT LEG GUARD,SAREE GUARD+BOLTS"	Bajaj spare parts
36DU4119	KIT COWLING DECALS BL-RED	Bajaj spare parts
36DU4120	KIT COWLING DECALS FLAME RED	Bajaj spare parts
36DU4121	KIT COWLING DECALS EL BLUE	Bajaj spare parts
36DU4122	KIT COWLING DECALS BL BLUE	Bajaj spare parts
36DU4123	KIT SEAT COWL DECALS BL RED	Bajaj spare parts
36DU4124	KIT SEAT COWL DECALS FL RED	Bajaj spare parts
36DU4125	KIT SEAT COWL DECALS EL BLUE	Bajaj spare parts
36DU4126	KIT SEAT COWL DECALS BL BLUE	Bajaj spare parts
36DU4128	KIT TANK DECAL BLACK-BLUE	Bajaj spare parts
36DU4129	KIT SEAT COWL DECAL BLACK-BLUE	Bajaj spare parts
36DU4130	KIT FAIRING DECAL BLACK-BLUE	Bajaj spare parts
36DU4132	KIT TANK DECAL RED-RED	Bajaj spare parts
36DU4133	KIT SEAT COWL DECAL RED-RED	Bajaj spare parts
36DU4134	KIT FAIRING DECAL RED-RED	Bajaj spare parts
36DU4135	KIT WHEEL DECAL RED-RED	Bajaj spare parts
36DU4136	KIT TANK DECAL MATTE G YELLOW	Bajaj spare parts
36DU4137	KIT SEAT COWL DECAL YELLOW	Bajaj spare parts
36DU4138	KIT FAIRING DECAL YELLOW	Bajaj spare parts
36DU4139	KIT WHEEL DECAL YELLOW	Bajaj spare parts
36DU4140	KIT WHEEL DECAL BLUE	Bajaj spare parts
36DU4141	KIT CHAIN SPROCKET	Bajaj spare parts
36DU4143	REAR WHEEL BRG KIT - CT 100	Bajaj spare parts
36DU4144	KIT CHAIN SPROCKET	Bajaj spare parts
36DU4145	KIT FAIRING DCL BLACK-BLUE	Bajaj spare parts

36DU4146	KIT FAIRING DCL FLAME RED	Bajaj spare parts
36DU4147	KIT FAIRING DCL MATTE GREEN	Bajaj spare parts
36DU4148	KIT LEG GURAD & SARI GUARD	Bajaj spare parts
36DU4149	KIT SEAT COWL DCL BLUE	Bajaj spare parts
36DU4150	KIT SEAT COWL DCL FL RED	Bajaj spare parts
36DU4151	KIT SEAT COWL DCL MATT GREEN	Bajaj spare parts
36DU4152	KIT CLUTCH COVER ASSLY	Bajaj spare parts
36DU4154	PISTON VALVE ASSY KIT-BK-PV-506	Bajaj spare parts
36DU4155	PILOT SCREW KIT-BK-PS-507	Bajaj spare parts
36DU4157	JET KIT -BK-JET-508	Bajaj spare parts
36DU4158	FLOAT BODY ASSY KIT-BK-FCB-509	Bajaj spare parts
36DU4159	TOP CAP ASSY KIT-BK-TC-510	Bajaj spare parts
36DU4160	O-RING & GASKET KIT-BK-OG-511	Bajaj spare parts
36DU4161	STARTER KIT-BK-ST-512	Bajaj spare parts
36DU4170	KIT FAIRING DCL RED	Bajaj spare parts
36DU4171	KIT TANK DCL RED	Bajaj spare parts
36DU4172	KIT SIDE COVER DCL RED	Bajaj spare parts
36DU4173	KIT SEAT COWL DCL RED	Bajaj spare parts
36DU4181	KIT DECAL SEAT COWL CT110 BL-RED	Bajaj spare parts
36DU4182	KIT DECAL FAIRING BLACK-RED	Bajaj spare parts
36DU4185	KIT FAIRING BLACK BLUE DECALS	Bajaj spare parts
36DU4186	KIT FAIRING BRIGHT RED DECALS	Bajaj spare parts
36DU4187	KIT FAIRING YELLOW DECALS	Bajaj spare parts
36DU4188	KIT FAIRING RED DECAL	Bajaj spare parts
36DU4189	KIT TANK BLUE DECALS	Bajaj spare parts
36DU4190	KIT TANK RED DECALS	Bajaj spare parts
36DU4191	KIT TANK GREEN DECALS	Bajaj spare parts
36DU4192	KIT TANK RED DECAL	Bajaj spare parts
36DU4207	REAR WHEEL BRG KIT - CT 100	Bajaj spare parts
36DV0004	KIT CHAIN SPROCKET AVENGE	Bajaj spare parts
36DV0006	KIT CHAIN SPROCKET MOD.AV	Bajaj spare parts
36DV0007	KIT STEERING CONE	Bajaj spare parts
36DV0011	KIT ST. CONE (37MM) WITH GREASE	Bajaj spare parts
36DX0001	KIT CHAIN SPR DIS	Bajaj spare parts
36DY0004	KIT THROTTLE VALVE-B105A	Bajaj spare parts
36DY0005	AIR CONTROL SCREW KIT-B105A	Bajaj spare parts
36DY0006	KIT JET- C101B	Bajaj spare parts
36DY0008	KIT DCL SEAT COWL BL RED	Bajaj spare parts
36DY0010	KIT DCL SEAT COWL FL RED	Bajaj spare parts
36DY0012	KIT SEAT COWL DCL EL BLUE	Bajaj spare parts
36DY0014	KIT SEAT COWL DCL BL BLUE	Bajaj spare parts
36DY0020	KIT CHAIN SPROCKET	Bajaj spare parts
36DY0021	PISTON VALVE ASSY KIT	Bajaj spare parts
36DY0022	IDLING ADJUSTER KIT	Bajaj spare parts
36DY0023	JET KIT	Bajaj spare parts



36DY0024	AIR SOLENOID BRACKET KIT	Bajaj spare parts
36DY0025	HANDLE BAR KIT	Bajaj spare parts
36DY0026	GRIP FRAME KIT	Bajaj spare parts
36DY0027	LOCKSET WITH PT CAP CT110X	Bajaj spare parts
36DY0028	KIT CLUTCH PLATE MAKINO	Bajaj spare parts
36DY0029	KIT FAIRING DECAL SILVER	Bajaj spare parts
36DY0030	KIT TANK DECAL SILVER	Bajaj spare parts
36DY0031	KIT BRAKE HOSE FRONT	Bajaj spare parts
36DY0032	KIT BLOCK PISTON	Bajaj spare parts
36DY0033	KIT TANK DECAL E BLACK BLUE	Bajaj spare parts
36DY0034	KIT TANK DECAL EBONY BLACK RED	Bajaj spare parts
36DY0035	KIT TANK DECAL E BLACK GREEN	Bajaj spare parts
36DY0036	KIT FAIRING DECAL E BLACK BLUE	Bajaj spare parts
36DY0037	KIT FAIRING DECAL E BLACK RED	Bajaj spare parts
36DY0038	KIT FAIRING DCL E BLACK GREEN	Bajaj spare parts
36DY0040	KIT DRIVE CHAIN SPROCKET	Bajaj spare parts
36DY0041	PISTON VALVE ASSEMBLY KIT	Bajaj spare parts
36DY0042	JET KIT	Bajaj spare parts
36DY0043	HANDLE BAR WITH TRIM	Bajaj spare parts
36DY0044	KIT CL HOUSING+PRI DRIVE GEAR	Bajaj spare parts
36DZ0001	KIT CHAIN CASE PLATINA	Bajaj spare parts
36DZ0002	KIT CHAIN SPROCKET PLATIN	Bajaj spare parts
36DZ0005	KIT LEG / SARI GUARD PLA	Bajaj spare parts
36DZ0008	KIT GEAR METER SCREW	Bajaj spare parts
36DZ0009	KIT CASE CHAIN PLATINA	Bajaj spare parts
36DZ0020	KIT FRONT K SEAL	Bajaj spare parts
36DZ0021	KIT GEAR MTR SCREW	Bajaj spare parts
36DZ0022	KIT CABLE INNER SPEEDO	Bajaj spare parts
36DZ0036	KIT TANK DECAL LB BLUE-NON	Bajaj spare parts
36DZ0039	KIT TANK DECAL MAROON-NON CR PLATINA	Bajaj spare parts
36DZ0040	KIT TANK DECAL FL RED NON CR PLATINA0	Bajaj spare parts
36DZ0042	KIT TANK DECAL SILV CR PLATINA	Bajaj spare parts
36DZ0043	KIT TANK JET BL PLAT	Bajaj spare parts
36DZ0045	KIT TANK DECAL MAROONPLATINA	Bajaj spare parts
36DZ0047	KIT FAIRING DECAL CW	Bajaj spare parts
36DZ0048	KIT FAIRING DECAL JBL NON CR PLATINA	Bajaj spare parts
36DZ0049	KIT FAIRING DECAL	Bajaj spare parts
36DZ0050	KIT FAIRING DECAL RED	Bajaj spare parts
36DZ0051	KIT FAIRING DECAL	Bajaj spare parts
36DZ0052	KIT FAIRING DECAL SILVER CR PLATINA00	Bajaj spare parts
36DZ0053	KIT FAIRING DECAL JET BL-CR PLATINA00	Bajaj spare parts
36DZ0055	KIT FAIRING DECALM	Bajaj spare parts
36DZ0056	KIT SEAT COWL DECAL	Bajaj spare parts
36DZ0058	KIT SEAT COWL DECAL	Bajaj spare parts
36DZ0059	KIT SEAT COWL DECAL	Bajaj spare parts

36DZ0060	KIT SEAT COWL DECAL	Bajaj spare parts
36DZ0061	KIT SEAT COWL DECAL BLUE	Bajaj spare parts
36DZ0062	KIT SEAT COWL DECAL	Bajaj spare parts
36DZ0063	KIT SEAT CWL DCL BLK	Bajaj spare parts
36DZ0065	KIT SEAT COWL DECAL MAROONPLATINA 100	Bajaj spare parts
36DZ0066	KIT ENGINE GASKET PLATINA	Bajaj spare parts
36DZ0068	KIT FR.NUMBER PLATE PLATINA	Bajaj spare parts
36DZ0070	KIT OIL SEAL 4S	Bajaj spare parts
36DZ2008	KIT ST. CONE (31MM) WITH GREASE	Bajaj spare parts
36FA1501	KIT CHAIN SPROCKET BYK	Bajaj spare parts
36GL0010	H105-CALIPER MAJOR KIT	Bajaj spare parts
36GL0011	H105-CALIPER MINOR KIT	Bajaj spare parts
36GL0013	H105-CALIPER MINI KIT	Bajaj spare parts
36GL0017	PAIRED SCU & FOB KIT	Bajaj spare parts
36GL0020	AC CHARGING CABLE FUSE CAP KIT	Bajaj spare parts
36GL0025	GLOVE BOX HOOK SLEEVE PIN KIT	Bajaj spare parts
36JA0002	KIT VALVE KIT XCD	Bajaj spare parts
36JA0003	KIT VALVE REPAIR KIT	Bajaj spare parts
36JA0004	KIT CHAIN GUIDE KIT	Bajaj spare parts
36JA0005	KIT CHAIN SPROCKET	Bajaj spare parts
36JA0006	KIT CHAIN CASE KIT X	Bajaj spare parts
36JA0007	DECAL SET JET BLACK	Bajaj spare parts
36JA0010	KIT SET DRIVE /XCD	Bajaj spare parts
36JA0017	Kit Carbu. Holder	Bajaj spare parts
36JA0020	KIT PLATE FRCI XCD/125	Bajaj spare parts
36JA0022	KIT GASKETS PULSAR 135	Bajaj spare parts
36JA0023	KIT GASKETS DISCOVER 100	Bajaj spare parts
36JB0003	KIT CHAIN SPROCKET P	Bajaj spare parts
36JB0005	KIT DECL SET CWRED	Bajaj spare parts
36JB0021	KIT JET (MOD) DISCO M	Bajaj spare parts
36JB0022	KIT AIR SCREW ( MOD ) DISCO M	Bajaj spare parts
36JB0025	KIT ASLY C CASE RH D100 UG	Bajaj spare parts
36JB4032	KIT ASSLY CLUTCH COVER - DIS 110	Bajaj spare parts
36JC0002	KIT CHAIN SPROC PUL	Bajaj spare parts
36JC0003	KIT HARDWARE ROD BRA	Bajaj spare parts
36JC0006	KIT H ROD BRAKE PULSAR	Bajaj spare parts
36JC0007	KIT KIT LEVER BRAKE PULSA	Bajaj spare parts
36JC0008	KIT PUL DEC BLACK L	Bajaj spare parts
36JC0009	KIT PULSAR DECAL BLA	Bajaj spare parts
36JC0010	KIT PULSAR DECAL GREY	Bajaj spare parts
36JC0011	KIT PUL DEC GREY CRO RH	Bajaj spare parts
36JC0020	KIT JC OLD BLACK CYL HEAD+COVER	Bajaj spare parts
36JD0001	KIT JET PULSAR 135 LS	Bajaj spare parts
36JD0002	KIT VC SCREW PUL 135 LS	Bajaj spare parts
36JD0003	KIT IDLING SCREW PULSAR 1	Bajaj spare parts

36JD0004	KIT VACCUM PISTON	Bajaj spare parts
36JD0005	KIT CARB.GASKET O RING	Bajaj spare parts
36JD0006	KIT JET NEEDLE HARDWARE P	Bajaj spare parts
36JD0007	KIT ADJ RSA ( FIELD FIX )	Bajaj spare parts
36JD0009	KIT MAG CVR MLS-P135	Bajaj spare parts
36JD0010	COVER CLUTCH PUL-135 LS	Bajaj spare parts
36JD0011	KIT FAIRING DCL RED-P135	Bajaj spare parts
36JD0012	KIT SPOILER DCL RED-P135	Bajaj spare parts
36JD0013	KIT SIDE COVER DCL RED-P135	Bajaj spare parts
36JD0014	KIT SEATCOWL DCL RED	Bajaj spare parts
36JD0015	KIT TANK DCL RED-P135	Bajaj spare parts
36JD0016	KIT FAIRING DCL BLUE-P135	Bajaj spare parts
36JD0017	KIT SPOILER DCL BLUE-P135	Bajaj spare parts
36JD0018	KIT SEAT COWL DCL BLUE	Bajaj spare parts
36JD0019	KIT SIDE CVR DCL-BLUE P135	Bajaj spare parts
36JD0020	KIT TANK DCL BLUE-P135	Bajaj spare parts
36JD0021	CYL Block Assy XCD125	Bajaj spare parts
36JD0026	KIT ENGINE GASKET PULSAR 135 LS	Bajaj spare parts
36JD0044	CYL HEAD BSIV FOR SPARES	Bajaj spare parts
36JD0045	KIT TANK DCL BL RED	Bajaj spare parts
36JD0046	KIT FAIRING DCL BL RED	Bajaj spare parts
36JD0047	KIT SPOILER DCL BL RED	Bajaj spare parts
36JD0048	KIT S COWL DCL BL RED	Bajaj spare parts
36JD0049	KIT TANK DCL R BLUE	Bajaj spare parts
36JD0050	KIT FAIRING DCL R BLUE	Bajaj spare parts
36JD0051	KIT SPOILER DCL R BLUE	Bajaj spare parts
36JD0052	KIT S COWL DCL R BLUE	Bajaj spare parts
36JD0057	KIT FAIRING DCL F RED BS IV	Bajaj spare parts
36JD0058	KIT SPOILER DCL F RED BS IV	Bajaj spare parts
36JD0060	KIT TANK DCL F RED BS IV	Bajaj spare parts
36JD0061	KIT SEAT COWL DCL F RED BS IV	Bajaj spare parts
36JD0067	KIT TANK DCL E BL CROME	Bajaj spare parts
36JD0068	KIT FAIRING DCL E BL CROME	Bajaj spare parts
36JD0069	KIT SPOILER DCL E BL CROME	Bajaj spare parts
36JD0070	KIT S COWL DCL E BL CROME	Bajaj spare parts
36JD0071	KIT TANK DCL R BLUE CROME	Bajaj spare parts
36JD0072	KIT FAIRING DCL R BLUE CROME	Bajaj spare parts
36JD0073	KIT SPOILER DCL R BLUE CROME	Bajaj spare parts
36JD0074	KIT S COWL DCL R BLUE CROME	Bajaj spare parts
36JD0075	KIT ASSLY CL COVER SLATE GRAY	Bajaj spare parts
36JD0076	KIT DECAL TANK PASSION RED	Bajaj spare parts
36JD0077	KIT DECAL FAIRING PASSION RED	Bajaj spare parts
36JD0078	KIT DECAL SPOILER PASSION RED	Bajaj spare parts
36JD0079	KIT DECAL SEAT COWL PASSION RED	Bajaj spare parts
36JD0082	KIT TANK DECAL S BLUE	Bajaj spare parts

36JD0083	KIT FAIRING DECAL S BLUE	Bajaj spare parts
36JD0084	KIT SPOILER DECAL S BLUE	Bajaj spare parts
36JD0085	KIT SEAT COWL DECAL S BLUE	Bajaj spare parts
36JD0086	KIT TANK DECAL CW RED	Bajaj spare parts
36JD0087	KIT FAIRING DECAL CW RED	Bajaj spare parts
36JD0088	KIT SPOILER DECAL CW RED	Bajaj spare parts
36JD0089	KIT SEAT COWL DECAL CW RED	Bajaj spare parts
36JD0091	CBS LEVER SPRING KIT	Bajaj spare parts
36JD0092	CBS LINK KIT	Bajaj spare parts
36JD0093	CBS FASTENING CAP KIT	Bajaj spare parts
36JD0104	KIT ASSLY CRANKCASE -RH	Bajaj spare parts
36JD0110	KIT AIR FIL ELEMENT & CVR O RING	Bajaj spare parts
36JE0001	KIT VALVE REPAIR SPRINT	Bajaj spare parts
36JE0002	KIT PISTON RING SET SPRINT	Bajaj spare parts
36JE0003	KIT CHAIN GUIDE SPRINT	Bajaj spare parts
36JE0004	Set Drive and Driven	Bajaj spare parts
36JE0005	KIT CLUTCH PLATE SPRINT	Bajaj spare parts
36JE0007	KIT CHAIN SPROCKET SPRINT	Bajaj spare parts
36JE0009	SIDE COVER GROMMET KIT	Bajaj spare parts
36JE0012	CYL BLK PST ASLY SPRIT	Bajaj spare parts
36JE0013	HEAD CYLINDER	Bajaj spare parts
36JE0014	KIT CHAIN SPROCKET O RING TYPE	Bajaj spare parts
36JE0016	KIT PISTON VALVE ASSLY	Bajaj spare parts
36JE0017	KIT PILOT SCREW	Bajaj spare parts
36JE0018	KIT JET	Bajaj spare parts
36JE0019	KIT FLOAT CHAMBER BODY	Bajaj spare parts
36JE0020	KIT TOP CAP	Bajaj spare parts
36JE0021	KIT PLUNGER ASSLY	Bajaj spare parts
36JE0022	KIT O-RING & GASKET	Bajaj spare parts
36JE0023	KIT CARB JET D125T	Bajaj spare parts
36JE0024	KIT FRICTION - D102B&C	Bajaj spare parts
36JE0027	KIT VALVE KIT FOR PULSAR K11	Bajaj spare parts
36JE0029	KIT CLUTCH CVR K11UG SLATE GREY	Bajaj spare parts
36JE0036	KIT ASSLY CL COVER SATIN BLACK	Bajaj spare parts
36JE0038	ASSLY MAG COVER SATIN BLACK	Bajaj spare parts
36JE0039	PISTON VALVE ASSY KIT	Bajaj spare parts
36JE0040	PILOT SCREW KIT	Bajaj spare parts
36JE0041	IDLING ADJUSTER KIT	Bajaj spare parts
36JE0042	JET KIT	Bajaj spare parts
36JE0043	FLOAT BODY ASSY KIT	Bajaj spare parts
36JE0044	O-RING & GASKET KIT	Bajaj spare parts
36JE0046	FRICTION PLATE KIT	Bajaj spare parts
36JE0047	CLUTCH PLATE (STEEL PLATE) KIT	Bajaj spare parts
36JE0048	KIT CL HOUSING + PRIMARY GEAR	Bajaj spare parts
36JE0049	KIT CYLINDER HEAD NS 125	Bajaj spare parts

36JE0050	KIT ASSLY CLUTCH COVER	Bajaj spare parts
36JF0001	KIT ASSLY CYL HEAD	Bajaj spare parts
36JF0002	KIT ASSLY BLOCK-PISTON	Bajaj spare parts
36JF0004	KIT ASSLY CL COVER	Bajaj spare parts
36JF0005	KIT CHAIN GUIDE	Bajaj spare parts
36JF0006	KIT Chain Sprocket	Bajaj spare parts
36JF0007	KIT BOSS KICK	Bajaj spare parts
36JF0008	KIT S COWL DCL P RED	Bajaj spare parts
36JF0009	KIT S COWL DCL M WHITE	Bajaj spare parts
36JF0010	KIT S COWL DCL S BLUE	Bajaj spare parts
36JF0011	KIT FENDER DCL S BLUE	Bajaj spare parts
36JF0012	KIT FENDER DCL P RED	Bajaj spare parts
36JF0013	KIT FENDER DCL E BLACK	Bajaj spare parts
36JF0014	KIT FENDER DCL M WHITE	Bajaj spare parts
36JF0015	KIT END-CAL MJR WITH GREASE	Bajaj spare parts
36JF0016	KIT END-CAL MINOR WITH GREASE	Bajaj spare parts
36JF0017	KIT END-CAL MINI WITH GREASE	Bajaj spare parts
36JF0018	KIT END-MAST CYL MJR WITH GREASE	Bajaj spare parts
36JF0019	KIT MAST CYL	Bajaj spare parts
36JF0020	KIT END-MAST CYL SEAL WITH GREASE	Bajaj spare parts
36JF0021	KIT JET K11	Bajaj spare parts
36JF0022	KIT PILOT SCREW K11	Bajaj spare parts
36JF0023	KIT PISTON VALVE ASSY K11	Bajaj spare parts
36JF0024	KIT IDLE ADJUSTER K11	Bajaj spare parts
36JF0025	KIT VALVE REPAIR	Bajaj spare parts
36JF0026	KIT PISTON RING	Bajaj spare parts
36JF0027	KIT ASSLY CRANKCASE LH K11	Bajaj spare parts
36JF0028	KIT FENDER DCL RED-K16B	Bajaj spare parts
36JF0029	KIT ASSLY CRANKCASE RH K11	Bajaj spare parts
36JF0030	KIT FENDER DCL S BLUE-K16B	Bajaj spare parts
36JF0031	KIT CYL COMP FORK-K11	Bajaj spare parts
36JF0038	KIT GASKET-AS150	Bajaj spare parts
36JF0042	KIT PISTON RINGS	Bajaj spare parts
36JF0045	MASTER CYL MINOR KIT W/O GREASE	Bajaj spare parts
36JF0050	KIT ASSLY CYL HEAD	Bajaj spare parts
36JF0051	KIT ASSLY CRANKCASE LH	Bajaj spare parts
36JF0052	KIT ASSLY CRANKCASE RH	Bajaj spare parts
36JF0054	KIT PRIMARY DRIVE & DRIVEN	Bajaj spare parts
36JF0055	KIT CHAIN GUIDE	Bajaj spare parts
36JF0056	KIT CHAIN SPROCKET	Bajaj spare parts
36JF0057	KIT ENGINE GASKET	Bajaj spare parts
36JF0058	KIT VALVE REPAIR	Bajaj spare parts
36JF0059	KIT BLOCK PISTON	Bajaj spare parts
36JF0060	KIT PISTON RING SET	Bajaj spare parts
36JF0062	KIT CYLINDER COMP FORK	Bajaj spare parts

36JF0063	KIT FORK OIL SEALS	Bajaj spare parts
36JF0064	KIT HOSE ABS TO FR M CYL	Bajaj spare parts
36JF0065	KIT HOSE ABS TO FR CAL	Bajaj spare parts
36JF0066	KIT HOSE ABS TO RR M CYL	Bajaj spare parts
36JF0067	KIT DCL F FENDER PLUM RED	Bajaj spare parts
36JF0068	KIT DCL S COWL PLUM RED	Bajaj spare parts
36JF0069	KIT DCL F FENDER T BLUE	Bajaj spare parts
36JF0070	KIT DCL S COWL T BLUE	Bajaj spare parts
36JF0071	KIT DCL F FENDER P WHITE	Bajaj spare parts
36JF0072	KIT DCL S COWL P WHITE	Bajaj spare parts
36JF0074	KIT DCL F FENDER PLUM RED-NON ABS	Bajaj spare parts
36JF0075	KIT DCL F FENDER T BLUE-NON ABS	Bajaj spare parts
36JF0076	KIT DCL F FENDER P WHITE-NON ABS	Bajaj spare parts
36JF0078	KIT HOSE ABS TO RR CALIPER - K10	Bajaj spare parts
36JF0079	KIT HOSE REAR - K10 NONABS	Bajaj spare parts
36JF0080	KIT HOSE FR CALIPER NON ABS - K10	Bajaj spare parts
36JF0081	KIT CLAMP KIT MAST CYL	Bajaj spare parts
36JF0082	PUSHROD ASSLY KIT	Bajaj spare parts
36JF0083	KIT BRACKET SUB ASSLY	Bajaj spare parts
36JF0084	KIT PRIMARY PIN	Bajaj spare parts
36JF0085	KIT PUSHROD ASSLY	Bajaj spare parts
36JF0086	KIT REAR RESERVOIR	Bajaj spare parts
36JF0087	KIT RESERVOIR TUBE	Bajaj spare parts
36JF0088	BRACKET SUB ASSLY KIT	Bajaj spare parts
36JF0089	KIT SHIM 2.70 MM	Bajaj spare parts
36JF0090	KIT SHIM 2.74 MM	Bajaj spare parts
36JF0091	KIT SHIM 2.78 MM	Bajaj spare parts
36JF0092	KIT SHIM 2.82 MM	Bajaj spare parts
36JF0093	KIT SHIM 2.86 MM	Bajaj spare parts
36JF0094	KIT SHIM 2.90 MM	Bajaj spare parts
36JF0095	KIT SHIM 2.94 MM	Bajaj spare parts
36JF0096	KIT SHIM 2.98 MM	Bajaj spare parts
36JF0097	KIT SHIM 3.02 MM	Bajaj spare parts
36JF0098	KIT SHIM 3.06 MM	Bajaj spare parts
36JF0099	KIT SHIM 3.08 MM	Bajaj spare parts
36JF0100	KIT SHIM 3.10 MM	Bajaj spare parts
36JF0101	KIT SHIM 3.12 MM	Bajaj spare parts
36JF0102	KIT SHIM 3.14 MM	Bajaj spare parts
36JF0103	KIT SHIM 3.16 MM	Bajaj spare parts
36JF0104	KIT SHIM 3.18 MM	Bajaj spare parts
36JF0105	KIT SHIM 3.20 MM	Bajaj spare parts
36JF0113	KIT DCL FENDER RED-GRY NS160	Bajaj spare parts
36JF0115	KIT DCL FENDER WHT-GRY NS160	Bajaj spare parts
36JF0116	PISTON RING SET- KT03	Bajaj spare parts
36JF0117	KIT CYL BLOCK PIST ASSLY NS160	Bajaj spare parts

36JF0119	KIT DCL TANK CVR RED-BLK NS160	Bajaj spare parts
36JF0120	KIT DCL SEAT COWL RED-BLCK NS160	Bajaj spare parts
36JF0121	KIT DCL TANK CVR WHT-BLK NS160	Bajaj spare parts
36JF0122	KIT DCL SEAT COWL WHT-BLCK NS160	Bajaj spare parts
36JF0123	KIT DCL FENDER BLUE-BLK NS160	Bajaj spare parts
36JF0124	KIT DCL FAIRING BLUE-BLK NS160	Bajaj spare parts
36JF0125	KIT DCL TANK CVR BLUE-BLK NS160	Bajaj spare parts
36JF0126	KIT DCL SIDE CVR BLUE-BLK NS160	Bajaj spare parts
36JF0127	KIT DCL SEAT COWL BLUE-BLK NS160	Bajaj spare parts
36JF0128	KIT TANK CVR DCL NS160	Bajaj spare parts
36JF0130	KIT CRANKCASE RH BSIV NS160	Bajaj spare parts
36JF0132	KIT CRANKCASE LH BSIV NS160	Bajaj spare parts
36JF0133	KIT PRIMARY DRIVE AND DRIVEN	Bajaj spare parts
36JF0134	KIT CYL HEAD ASSLY	Bajaj spare parts
36JF0135	KIT CLUTCH COVER ASSLY	Bajaj spare parts
36JF0136	KIT DCL FR FENDER MATT BLACK	Bajaj spare parts
36JF0137	KIT DCL S COWL MATT BLACK	Bajaj spare parts
36JF0138	KIT CYL COMPL FORK	Bajaj spare parts
36JF0139	VACUUM PISTON ASSY KIT	Bajaj spare parts
36JF0140	PILOT SCREW KIT	Bajaj spare parts
36JF0141	IDLING ADJUSTER KIT	Bajaj spare parts
36JF0142	JET KIT	Bajaj spare parts
36JF0146	KIT DCL FENDER GRAY BLACK	Bajaj spare parts
36JF0147	KIT DCL FAIRING GRAY BLACK	Bajaj spare parts
36JF0149	KIT DCL TANK CVR GRAY BLACK	Bajaj spare parts
36JF0150	KIT DCL SEAT COWL GRAY BLACK	Bajaj spare parts
36JF0152	KIT VACUUM PISTON ASSLY	Bajaj spare parts
36JF0153	KIT JET	Bajaj spare parts
36JF0156	KIT DCL FR FENDER GM BLACK	Bajaj spare parts
36JF0157	KIT DCL FR FENDER R RED	Bajaj spare parts
36JF0158	KIT DCL FR FENDER C BLUE	Bajaj spare parts
36JF0159	KIT DCL FR FENDER G GREEN	Bajaj spare parts
36JF0160	KIT DCL FR FENDER GM BLACK ABS	Bajaj spare parts
36JF0161	KIT DCL FR FENDER R RED ABS	Bajaj spare parts
36JF0162	KIT DCL FR FENDER C BLUE ABS	Bajaj spare parts
36JF0164	KIT DCL SEAT COWL	Bajaj spare parts
36JF0165	CLUTCH COVER SILK MATTE BLACK	Bajaj spare parts
36JF0167	KIT CHAIN SPROCKET	Bajaj spare parts
36JF0172	KIT ASSLY CRANKCASE LH	Bajaj spare parts
36JF0179	KIT HOSE CYL MASTER FR-UNIT ABS	Bajaj spare parts
36JF0180	KIT HOSE UNIT ABS-CALIPER FRONT	Bajaj spare parts
36JF0181	KIT HOSE CYL MASTER RR-UNIT ABS	Bajaj spare parts
36JF0182	KIT HOSE UNIT ABS-CALIPER REAR	Bajaj spare parts
36JF0184	REAR RESERVIOR KIT	Bajaj spare parts
36JF0185	FR CLAMP KIT	Bajaj spare parts

36JF0186	REAR RESERIOR TUBE KIT	Bajaj spare parts
36JF0195	KIT FRICTION PLATE	Bajaj spare parts
36JF0196	KIT BLOCK PISTON K10UG	Bajaj spare parts
36JF0197	KIT CAM CHAIN GUIDE	Bajaj spare parts
36JF0198	KIT VALVE REPAIR	Bajaj spare parts
36JF0199	KIT HOSE CYL MASTER FR-UNIT ABS	Bajaj spare parts
36JF0200	KIT HOSE UNIT ABS-CALIPER FRONT	Bajaj spare parts
36JF0202	KIT CLUTCH COVER DOMINAR UG	Bajaj spare parts
36JF0208	ASSLY BLOCK PISTON	Bajaj spare parts
36JF0209	CHAIN SPROCKET KIT	Bajaj spare parts
36JF0211	KIT CRANKCASE ASSLY LH	Bajaj spare parts
36JF0212	BLOCK PISTON ASSLY	Bajaj spare parts
36JF0213	KIT VALVE REPAIR	Bajaj spare parts
36JF0215	KIT DCL BELLY PAN YELLOW	Bajaj spare parts
36JF0216	KIT DCL BELLY PAN RED	Bajaj spare parts
36JF0217	KIT DCL BELLY PAN BLUE	Bajaj spare parts
36JF0218	KIT DCL SEAT COWL YELLOW	Bajaj spare parts
36JF0219	KIT DCL SEAT COWL RED	Bajaj spare parts
36JF0220	KIT DCL SEAT COWL BLUE	Bajaj spare parts
36JF0221	KIT DCL BELLY PAN GRAY	Bajaj spare parts
36JF0222	KIT DCL SEAT COWL PEARL WHITE	Bajaj spare parts
36JF0223	KIT DCL SEAT COWL	Bajaj spare parts
36JF0224	KIT SEAT COWL DCL GRAY	Bajaj spare parts
36JF0225	KIT FRICTION PLATE	Bajaj spare parts
36JF0226	KIT BLOCK PISTON	Bajaj spare parts
36JF0228	KIT DRIVE CHAIN + SPROCKETS	Bajaj spare parts
36JF0229	KIT VALVE REPAIR	Bajaj spare parts
36JF0230	KIT FAIRING DECAL ORANGE	Bajaj spare parts
36JF0231	KIT FAIRING DECAL BLUE	Bajaj spare parts
36JF0232	KIT DECAL SEAT COWL ORANGE	Bajaj spare parts
36JF0233	KIT DECAL SEAT COWL RED	Bajaj spare parts
36JF0234	KIT DECAL SEAT COWL GREY	Bajaj spare parts
36JF0235	KIT DECAL SEAT COWL BLUE	Bajaj spare parts
36JF0238	KIT WHEEL DECAL RED	Bajaj spare parts
36JF0239	KIT WHEEL DECAL ORANGE	Bajaj spare parts
36JF0240	KIT WHEEL DECAL GRAY	Bajaj spare parts
36JF0241	KIT WHEEL DECAL BLUE	Bajaj spare parts
36JF0251	KIT DCL SEAT COWL BLACK	Bajaj spare parts
36JF0252	KIT DCL COVER TANK BLACK	Bajaj spare parts
36JF0253	KIT DCAL WHEEL BLACK	Bajaj spare parts
36JF0254	KIT BRACKET LOWER LH+HARDWARES	Bajaj spare parts
36JF0255	KIT BRACKET LOWER RH+HARDWARES	Bajaj spare parts
36JF0258	Accessory kit Dominar 400	Bajaj spare parts
36JF0259	Accessory kit Dominar 250	Bajaj spare parts
36JF0260	IT SAREE+LEG GUARD-PUL NS125	Bajaj spare parts



36JF0265	KIT DECAL TANK FLAP LH WHITE	Bajaj spare parts
36JF0266	KIT DECAL TANK FLAP RH WHITE	Bajaj spare parts
36JF0267	KIT DECAL TANK FLAP LH BLACK	Bajaj spare parts
36JF0268	KIT DECAL TANK FLAP RH BLACK	Bajaj spare parts
36JF0269	KIT DECAL SEAT COWL WHITE	Bajaj spare parts
36JF0270	KIT DECAL SEAT COWL BLACK	Bajaj spare parts
36JF0271	KIT DECAL BELLY PAN WHITE	Bajaj spare parts
36JF0272	KIT DECAL BELLY PAN BLACK	Bajaj spare parts
36JF0273	KIT DECAL SEAT COWL WHITE	Bajaj spare parts
36JF0274	KIT DECAL SEAT COWL BLACK	Bajaj spare parts
36JG0004	SHAFT OIL PUMP ASSLY KTM125 EXP	Bajaj spare parts
36JG0006	WHEEL ASSLY FR K-125	Bajaj spare parts
36JG0010	KIT TRIPLE CLAMP ASLY	Bajaj spare parts
36JG0011	KIT STEERING HEAD BEARING	Bajaj spare parts
36JG0014	KIT DAMPING RUBBER	Bajaj spare parts
36JG0016	KIT PIST.RING KTM125 EXP.	Bajaj spare parts
36JG0017	KIT BRAKE PAD FRONT KTM	Bajaj spare parts
36JG0046	TOPCASE 37 REAR BAG-KTM-60012027500	Bajaj spare parts
36JG0083	KIT BRAKE FLUID RESERVOIR CPL.	Bajaj spare parts
36JG0087	KTM FORK OIL	Bajaj spare parts
36JG0091	KIT WATER PUMP SEALS W/GRASE	Bajaj spare parts
36JG0092	KIT CAP FUEL TANK EVAP E10 MY16	Bajaj spare parts
36JG0096	KIT BRAKE HOSE FRONT 200	Bajaj spare parts
36JG0097	KIT BRAKE HOSE REAR 200	Bajaj spare parts
36JG0098	KIT SAREE GUARD RH	Bajaj spare parts
36JG0101	ADV FRAME FR	Bajaj spare parts
36JG0105	BR HOSE KIT ABS TO MAST CYL. FR	Bajaj spare parts
36JG0106	BR HOSE KIT FR ABS TO CALIPER	Bajaj spare parts
36JG0107	BR HOSE REAR MC TO ABS	Bajaj spare parts
36JG0108	BR HOSE REAR CALIPER TO ABS	Bajaj spare parts
36JG0109	KTI FRONT WHEEL	Bajaj spare parts
36JG0110	KTI REAR WHEEL	Bajaj spare parts
36JG0111	KIT HAND GUARD ELEC ORG D390	Bajaj spare parts
36JG0112	KIT CR' CASE ASY LH 390 CC MY20	Bajaj spare parts
36JG0113	KIT CR' CASE ASSY RH 390 CC MY20	Bajaj spare parts
36JG0115	CYL HEAD-CAM HOLD JP511062 BLK	Bajaj spare parts
36JG0124	ADV FUEL TANK BLK WITH DAMPER	Bajaj spare parts
36JG0127	KIT FRONT WHEEL BLACK GLOSS	Bajaj spare parts
36JG0138	ADV FUEL TANK ORANGE WITH DAMPER	Bajaj spare parts
36JG0139	ADV FUEL TANK BLUE WITH DAMPER	Bajaj spare parts
36JG0140	ADV FUEL TANK BLACK WITH DAMPER	Bajaj spare parts
36JH0001	KIT PISTON RINGS	Bajaj spare parts
36JH0002	KIT CHAIN CASE UPPER+LOWER	Bajaj spare parts
36JH0003	KIT BLOCK <(>&<)> PISTON	Bajaj spare parts
36JH0004	KIT FRICTION PLATE	Bajaj spare parts

36JH0006	KIT CHAIN SPROCKET	Bajaj spare parts
36JH0008	KIT VALVE REPAIR	Bajaj spare parts
36JH0009	KIT BOSS KICK SET	Bajaj spare parts
36JH0011	KIT FORK CYLINDER COMP	Bajaj spare parts
36JH0012	KIT CARB O RINGS&GASKET	Bajaj spare parts
36JH0013	KIT CARB JETS	Bajaj spare parts
36JH0014	KIT CARB THROTTLE VALVE	Bajaj spare parts
36JH0015	KIT CARB FLOAT CHAMBER BODY	Bajaj spare parts
36JH0016	KIT CARB IDLING SCREW	Bajaj spare parts
36JH0017	KIT CARB TOP CAP	Bajaj spare parts
36JH0018	KIT CARB PLUNGER ASSLY	Bajaj spare parts
36JH0019	KIT VALVE INTAKE & EXHAUST	Bajaj spare parts
36JH0021	KIT ASSLY C'CASE LH	Bajaj spare parts
36JH0022	KIT ASSLY C'CASE RH	Bajaj spare parts
36JH0023	KIT CYL HEAD COVER WITH NIPPLE	Bajaj spare parts
36JH0027	KIT CYL HEAD + COVER V12	Bajaj spare parts
36JH0028	KIT VALVE V12	Bajaj spare parts
36JH0029	KIT VALVE REPAIR V12	Bajaj spare parts
36JH0030	KIT BLOCK PISTON V12	Bajaj spare parts
36JH0031	KIT CYL FORK	Bajaj spare parts
36JH0032	KIT PISTON RINGS	Bajaj spare parts
36JH0033	KIT FRICTION PLATE	Bajaj spare parts
36JH0039	KIT CARB V12-JETS	Bajaj spare parts
36JH0040	KIT CARB V12-AIR SCREW	Bajaj spare parts
36JH0042	KIT CARB V12-TOP COMP	Bajaj spare parts
36JH0043	KIT CARB 12-THROTTLE VALVE	Bajaj spare parts
36JH0044	KIT CARB V15-FLOAT CHAMBER BODY	Bajaj spare parts
36JH0045	KIT CARB V12 IDLING SCREW	Bajaj spare parts
36JH0046	KIT FR DISC COVER & HARDWARE	Bajaj spare parts
36JH0050	KIT CYL BLOCK & PISTON	Bajaj spare parts
36JH0052	KIT ASSLY CLUTCH COVER-V12	Bajaj spare parts
36JH0053	KIT ASSLY CLUTCH COVER-V15	Bajaj spare parts
36JH0057	KIT FRICTION PLATE	Bajaj spare parts
36JH0069	KIT CHAIN SPROCKET	Bajaj spare parts
36JH0070	KIT TANK DECALS V15	Bajaj spare parts
36JH0072	PISTON VALVE ASSY KIT	Bajaj spare parts
36JH0073	PILOT SCREW KIT	Bajaj spare parts
36JH0074	VACUUM ADJUSTER KIT	Bajaj spare parts
36JH0075	JET KIT	Bajaj spare parts
36JH0076	TOP CAP ASSY KIT	Bajaj spare parts
36JH0077	PLUNGER ASSY KIT	Bajaj spare parts
36JH0078	KIT TANK DECAL CW RED	Bajaj spare parts
36JH0079	KIT TANK DECAL M BLUE	Bajaj spare parts
36JH0080	ENGINE GASKET KIT- V15	Bajaj spare parts
36JK0003	KIT AIR SCREW	Bajaj spare parts

36JK0005	KIT JET PLATINA UG	Bajaj spare parts
36JK0011	KIT VALVE PLATINA BM 125	Bajaj spare parts
36JK0012	CHAIN GUIDE KIT	Bajaj spare parts
36JK0019	SCREW AIR KIT	Bajaj spare parts
36JK0020	IDLING SCREW KIT	Bajaj spare parts
36JK0021	JET KIT	Bajaj spare parts
36JK0022	PISTON VALVE KIT	Bajaj spare parts
36JK0026	CARBURETOR ORING KIT	Bajaj spare parts
36JK0027	CHOKE PLUNGER KIT	Bajaj spare parts
36JK0030	KIT CRANKCASE CL.	Bajaj spare parts
36JK0031	CYL BLOCK ASSLY BM125	Bajaj spare parts
36JK0036	KIT LEG / SAREE GUARD BLA	Bajaj spare parts
36JK0044	KIT TANK DECAL BL BLUE	Bajaj spare parts
36JK0045	KIT TANK DECAL BL RED PLATINA 125	Bajaj spare parts
36JK0047	KIT TANK DECAL BL	Bajaj spare parts
36JK0049	KIT COV SIDE DECAL BL/RED	Bajaj spare parts
36JK0050	KIT CVR S.DCL BL GREN	Bajaj spare parts
36JK0051	KIT COVER SIDE DEC BL FL	Bajaj spare parts
36JK0052	KIT FAI DECAL BL BLUE P.125	Bajaj spare parts
36JK0053	KIT FAIR BL RED PLATINA 125	Bajaj spare parts
36JK0055	KIT FAIRING DECAL	Bajaj spare parts
36JK0056	KIT DECAL SEAT COWL BL BLUE PLATINA 125	Bajaj spare parts
36JK0057	KIT DECAL SEAT COWL BL RED PLATINA 125	Bajaj spare parts
36JK0058	KIT DECAL SEAT COWL BL	Bajaj spare parts
36JK0059	KIT DECAL SEAT COWLBL FLAME RED PLATINA	Bajaj spare parts
36JK0060	KIT ENGINE GASKET PLATINA 125	Bajaj spare parts
36JK0061	KIT ENGINE GASKET PLATINA 125	Bajaj spare parts
36JK0064	KIT CYL BLOCK & PISTON	Bajaj spare parts
36JK0065	KIT PISTON RINGS	Bajaj spare parts
36JK0066	KIT LOCK SET	Bajaj spare parts
36JK0071	KIT FAIRING DCL BL-BLUE	Bajaj spare parts
36JK0072	KIT TANK DCL BL-BLUE	Bajaj spare parts
36JK0073	KIT SEAT COWL DCL-BL-BLUE	Bajaj spare parts
36JK0074	KIT FAIRING DCL BL-GRAY	Bajaj spare parts
36JK0075	KIT TANK DCL BL-GRAY	Bajaj spare parts
36JK0076	KIT SEAT COWL DECL BL-GRAY	Bajaj spare parts
36JK0077	KIT FAIRING DCL E BLUE	Bajaj spare parts
36JK0078	KIT TANK DCL E BLUE	Bajaj spare parts
36JK0079	KIT SEAT COWL DCL E BLUE	Bajaj spare parts
36JK0080	KIT FAIRING DCL W RED	Bajaj spare parts
36JK0081	KIT TANK DCL W RED	Bajaj spare parts
36JK0082	KIT SEAT COWL DCL W RED	Bajaj spare parts
36JK0083	KIT CHAIN SPROCKET	Bajaj spare parts
36JK0084	LOCK SET WITH PT CAP	Bajaj spare parts
36JK0089	KIT FAIRING DCL BLUE	Bajaj spare parts

36JK0090	KIT FAIRING DCL RED	Bajaj spare parts
36JK0091	KIT FAIRING DCL CW RED	Bajaj spare parts
36JK0092	KIT TANK DCL BLUE	Bajaj spare parts
36JK0093	KIT TANK DCL RED	Bajaj spare parts
36JK0094	KIT TANK DCL CW RED	Bajaj spare parts
36JK0095	KIT SEAT COWL DCL BLUE	Bajaj spare parts
36JK0097	KIT SEAT COWL DCL C W RED	Bajaj spare parts
36JK0098	KIT FENDER DCL BLUE	Bajaj spare parts
36JK0099	KIT FENDER DCL RED	Bajaj spare parts
36JK0100	KIT FENDER DCL CW RED	Bajaj spare parts
36JK0101	KIT SEAT COWL DCL RED	Bajaj spare parts
36JK0102	KIT BRAKE HOSE	Bajaj spare parts
36JK0103	CARB PISTON VALVE KIT-BK-PV-482	Bajaj spare parts
36JK0104	PILOT SCREW KIT-BK-PS-480	Bajaj spare parts
36JK0105	CARB JET KIT- BK-JET-477	Bajaj spare parts
36JK0106	FLOAT BODY KIT-BK-FCB-478	Bajaj spare parts
36JK0107	TOP CAP ASSY KIT-BK-TC-481	Bajaj spare parts
36JK0108	O-RING & GASKET KIT-BK-OG-483	Bajaj spare parts
36JK0109	KIT CLUTCH COVER	Bajaj spare parts
36JK0110	KIT DCL FAIRING E BLACK-BLUE	Bajaj spare parts
36JK0111	KIT DCL FAIRING E BLACK-RED	Bajaj spare parts
36JK0112	KIT DECAL FAIRING CW RED	Bajaj spare parts
36JK0114	HOSE UNIT ABS-CALIPER FRONT	Bajaj spare parts
36JK0115	KIT BLOCK PISTON BS6	Bajaj spare parts
36JK0116	HOSE CYL MASTER FR-UNIT ABS	Bajaj spare parts
36JK0118	KIT TANK DECAL BLUE	Bajaj spare parts
36JK0119	KIT SEAT COWL DCL BLUE	Bajaj spare parts
36JK0121	KIT TANK DECAL RED	Bajaj spare parts
36JK0122	KIT SEAT COWL DCL RED	Bajaj spare parts
36JK0123	KIT TANK DCL CW RED	Bajaj spare parts
36JK0124	KIT SEAT COWL DCL CW RED	Bajaj spare parts
36JK0128	KIT FAIRING DCL CHARCOAL BLACK	Bajaj spare parts
36JK0130	KIT SEAT COWL DCL CHARCOAL BLACK	Bajaj spare parts
36JK0131	KIT FENDER DCL CHARCOAL BLACK	Bajaj spare parts
36JK0140	KIT FAIRING DCL BEACH BLUE	Bajaj spare parts
36JK0142	KIT SEAT COWL DCL BEACH BLUE	Bajaj spare parts
36JK0143	KIT FENDER DCL BEACH BLUE	Bajaj spare parts
36JK0144	KIT FAIRING DCL MATTE RED	Bajaj spare parts
36JK0146	KIT SEAT COWL DCL MATTE RED	Bajaj spare parts
36JK0147	KIT FENDER DCL MATTE RED	Bajaj spare parts
36JK0148	KIT TANK DCL MATTE RED	Bajaj spare parts
36JK0149	KIT TANK DCL CHARCOAL BLACK	Bajaj spare parts
36JK0150	KIT TANK DCL BEACH BLUE	Bajaj spare parts
36JK0151	KIT DECAL COWL SEAT BLUE	Bajaj spare parts
36JK0152	KIT DCL COWL SEAT BURGUNDY RED	Bajaj spare parts

36JK0153	KIT DECAL COWL SEAT WINE RED	Bajaj spare parts
36JK0154	KIT DCL COWL SEAT BEACH BLUE	Bajaj spare parts
36JK0155	KIT DCL COWL SEAT C BLACK	Bajaj spare parts
36JK0156	KIT DCL COWL SEAT V MATTE RED	Bajaj spare parts
36JK0161	KIT DECAL FAIRING GRAY	Bajaj spare parts
36JK0162	KIT DECAL TANK GRAY	Bajaj spare parts
36JK0163	KIT DECAL SEAT COWL GRAY	Bajaj spare parts
36JK0164	KIT DECAL FENDER GRAY	Bajaj spare parts
36JK0165	KIT DCL COWL SEAT COCKTAIL W RED	Bajaj spare parts
36JK0166	KIT DCL COWL SEAT EBONY BLACK	Bajaj spare parts
36JK0167	KIT DCL COWL SEAT GLOSS P GRAY	Bajaj spare parts
36JK0168	KIT DCL COWL SEAT SAFFIRE BLUE	Bajaj spare parts
36JK0169	KIT DCL FAIRING COCKTAIL RED	Bajaj spare parts
36JK0170	KIT DCL FAIRING EBONY BLACK	Bajaj spare parts
36JK0171	KIT DCL FAIRING PEWTER GRAY	Bajaj spare parts
36JK0172	KIT DCL FAIRING SAFFIRE BLUE	Bajaj spare parts
36JK0173	KIT DCL FENDER FRONT C W RED	Bajaj spare parts
36JK0174	KIT DCL FENDER FRONT EBONY BLK	Bajaj spare parts
36JK0175	KIT DCL FENDER FRONT P GRAY	Bajaj spare parts
36JK0176	KIT DCL FENDER FRONT S BLUE	Bajaj spare parts
36JK0177	KIT DCL TANK COCKTAIL W RED	Bajaj spare parts
36JK0178	KIT DCL TANK EBONY BLACK	Bajaj spare parts
36JK0179	KIT DCL TANK GLOSS P GRAY	Bajaj spare parts
36JK0180	KIT DCL TANK SAFFIRE BLUE	Bajaj spare parts
36JK0181	KIT BLOCK PISTON ASSLY	Bajaj spare parts
36JL0001	KIT CHAIN GUIDE-P200	Bajaj spare parts
36JL0002	KIT ASLY CL COVER-P200	Bajaj spare parts
36JL0007	CYL BLOCK ASSY PULSR200	Bajaj spare parts
36JL0009	KIT CHAIN SPROCKET-P200	Bajaj spare parts
36JL0010	KIT ASLY CYL HEAD-P200	Bajaj spare parts
36JL0011	KIT VALVE REPAIRE-P200	Bajaj spare parts
36JL0012	KIT TANK DAMPER-P200	Bajaj spare parts
36JL0015	KIT PILLION HARDWARE-P200	Bajaj spare parts
36JL0016	KIT S COWL GROMMET-P200	Bajaj spare parts
36JL0017	KIT WIND SHIELD MTG-P200	Bajaj spare parts
36JL0019	KIT JET PULSAR 200	Bajaj spare parts
36JL0020	KIT VC SCREW P200	Bajaj spare parts
36JL0021	KIT IDLING SCREW P200	Bajaj spare parts
36JL0022	KIT PISTON VALVE P200	Bajaj spare parts
36JL0023	KIT GASKET/O-RING-P200	Bajaj spare parts
36JL0024	KIT JET NEEDLE HARWARE-P200	Bajaj spare parts
36JL0025	KIT CENTER STAND-P200 NS	Bajaj spare parts
36JL0026	KIT FAIRING DCL-BLACK	Bajaj spare parts
36JL0027	KIT FENDER DCL-RED	Bajaj spare parts
36JL0028	KIT FENDER DCL-BLUE	Bajaj spare parts

36JL0029	KIT FENDER DCL-BLACK	Bajaj spare parts
36JL0030	KIT FENDER DCL-YELLOW	Bajaj spare parts
36JL0031	KIT TANK COVER MTG HARDWARE	Bajaj spare parts
36JL0032	VALVE KIT	Bajaj spare parts
36JL0035	FR WHEEL BRG KIT	Bajaj spare parts
36JL0036	WINDSHIELD SCREW KIT	Bajaj spare parts
36JL0037	FAIRING SCREW KIT	Bajaj spare parts
36JL0039	KIT WATER PUMP ROTOR & SEAL	Bajaj spare parts
36JL0041	KIT MAIN STEP HARDWARE-P200	Bajaj spare parts
36JL0046	KIT ASLY CL COVER-P200NS	Bajaj spare parts
36JL0048	KIT DCL FAIRING-S BLUE	Bajaj spare parts
36JL0049	KIT DCL FAIRING JL- PA RED	Bajaj spare parts
36JL0052	KIT DCL TANK JL-BL	Bajaj spare parts
36JL0053	KIT DCL TANK JL- PA RED	Bajaj spare parts
36JL0054	KIT DCL SPOILER-RED	Bajaj spare parts
36JL0055	KIT DCL SPOILER-BL	Bajaj spare parts
36JL0057	KIT DCL SEAT COWL-BL	Bajaj spare parts
36JL0058	KIT DCL SEAT COWL-RED	Bajaj spare parts
36JL0060	KIT DCL FENDER-BL	Bajaj spare parts
36JL0061	KIT DCL FENDER-RED	Bajaj spare parts
36JL0063	KIT DCL FAIRING-M WHITE	Bajaj spare parts
36JL0064	KIT DCL FENDER-E BLACK	Bajaj spare parts
36JL0065	KIT DCL FENDER-M WHITE	Bajaj spare parts
36JL0066	KIT DCL S COWL-M WHITE	Bajaj spare parts
36JL0067	KIT DCL SPOILER-M WHITE	Bajaj spare parts
36JL0088	KIT FR.NUMBER PLATE PULSAR AS 200	Bajaj spare parts
36JL0089	KIT RR.NUMBER PLATE PULSAR AS 150-200	Bajaj spare parts
36JL0091	KIT ANTI JUDDER	Bajaj spare parts
36JL0092	KIT NEW DECAL SPOILER PM WHITE IRAN	Bajaj spare parts
36JL0108	KIT DCL SIDE COVER RED-BLK BS IV	Bajaj spare parts
36JL0110	KIT DCL SIDE COVR WHT-BLK BS IV	Bajaj spare parts
36JL0114	KIT FAIRING DCL R-BL	Bajaj spare parts
36JL0115	KIT COVER TANK DCL R-BL	Bajaj spare parts
36JL0116	KIT SEAT COWL DCL R-BL	Bajaj spare parts
36JL0117	KIT FENDER FRONT DCL R-BL	Bajaj spare parts
36JL0118	KIT FAIRING DCL W-GRAY	Bajaj spare parts
36JL0119	KIT COVER TANK DCL W-GRAY	Bajaj spare parts
36JL0120	KIT SEAT COWL DCL W-GRAY	Bajaj spare parts
36JL0121	KIT FENDER FRONT DCL W-GRAY	Bajaj spare parts
36JL0122	KIT FAIRING DCL BL-GRAY	Bajaj spare parts
36JL0123	KIT COVER TANK DCL BL-GRAY	Bajaj spare parts
36JL0124	KIT SEAT COWL DCL BL-GRAY	Bajaj spare parts
36JL0125	KIT FENDER FRONT DCL BL-GRAY	Bajaj spare parts
36JL0127	KIT DCL SIDE CVR BLK-GRY BS IV	Bajaj spare parts
36JL0130	KIT FENDER FR DCL YL-GRY BSIV	Bajaj spare parts

36JL0131	KIT FAIRING DCL YL-GRAY BSIV	Bajaj spare parts
36JL0132	KIT CVR TANK DCL YL-GRAY BSIV	Bajaj spare parts
36JL0133	KIT DCL SIDE CVR YL-GRY BSIV	Bajaj spare parts
36JL0134	KIT DCL SEAT COWL YL-GRY BSIV	Bajaj spare parts
36JL0135	KIT TANK CVR DCL NS200	Bajaj spare parts
36JL0140	KIT ASSLY CL CVR 200NS	Bajaj spare parts
36JL0141	BRAKE HOSE ASSLY KIT FRONT	Bajaj spare parts
36JL0142	BRAKE HOSE ASSLY KIT FRONT	Bajaj spare parts
36JL0144	JL BSIII CYL HEAD(NEW CASTING)	Bajaj spare parts
36JL0145	JL BSIV CYL HEAD(NEW CASTING)	Bajaj spare parts
36JL0181	LIMAPLEX GREASE 10 GM POUCH	Bajaj spare parts
36JL0182	KIT FRONT BRAKE HOSE	Bajaj spare parts
36JL0184	KIT CHAIN SPROCKET EUIV	Bajaj spare parts
36JL0187	KIT ENGINE OIL FILTER+CVR O RING	Bajaj spare parts
36JL0189	KIT CYL HEAD	Bajaj spare parts
36JL0190	HOSE KIT-FR MASTER CYL TO ABS	Bajaj spare parts
36JL0191	HOSE KIT -FR CALIPER TO ABS HOSE	Bajaj spare parts
36JL0193	KIT ASSLY CYL HEAD +OIL NOZZLE	Bajaj spare parts
36JL0194	KIT CHAIN SPROCKET	Bajaj spare parts
36JL0197	KIT FAIRING DCL YELLOW	Bajaj spare parts
36JL0198	KIT FAIRING DCL RED	Bajaj spare parts
36JL0199	KIT FAIRING DCL NIGHTY SKY	Bajaj spare parts
36JL0200	KIT FAIRING DCL PLASMA BLUE	Bajaj spare parts
36JL0201	KIT TANK UPPER DCL YELLOW	Bajaj spare parts
36JL0202	KIT TANK UPPER DCL RED	Bajaj spare parts
36JL0203	KIT TANK DCL NIGHTY SKY	Bajaj spare parts
36JL0204	KIT TANK DCL PLASMA BLUE	Bajaj spare parts
36JL0208	KIT DCL BELLY PAN YELLOW	Bajaj spare parts
36JL0209	KIT DCL BELLY PAN RED	Bajaj spare parts
36JL0210	KIT DCL BELLY PAN PLASMA BLUE	Bajaj spare parts
36JL0211	KIT DCL WHEEL FRONT YELLOW	Bajaj spare parts
36JL0212	KIT DCL WHEEL FRONT RED	Bajaj spare parts
36JL0213	KIT DCL WHEEL FRONT BLUE	Bajaj spare parts
36JL0217	KIT ENGINE GASKET	Bajaj spare parts
36JL0218	KIT DCL TANK SIDE COVER P WHITE	Bajaj spare parts
36JL0219	KIT DCL TANK SIDE COVER SATIN	Bajaj spare parts
36JL0220	KIT DCL TANK SIDE COVER GRAY	Bajaj spare parts
36JL0221	KIT WHEEL DCL GRAY	Bajaj spare parts
36JL0222	KIT DCL BELLY PAN GRAY	Bajaj spare parts
36JL0223	KIT DCL SEAT COWL PEARL WHITE	Bajaj spare parts
36JL0224	KIT SEAT COWL DCL RED	Bajaj spare parts
36JL0225	KIT SEAT COWL DCL GRAY	Bajaj spare parts
36JL0226	KIT SEAT COWL DCL BLUE	Bajaj spare parts
36JL0227	KIT ASSLY CL COVER SATIN BLACK	Bajaj spare parts
36JL0230	ASSLY MAG COVER SATIN BLACK	Bajaj spare parts

36JL0233	KIT HARDWARE BRAKE HOSE	Bajaj spare parts
36JL0237	Accessory kit Pulsar NS160	Bajaj spare parts
36JL0238	Accessory kit Pulsar NS200	Bajaj spare parts
36JL0240	KIT PILLION HARDWARE-P200	Bajaj spare parts
36JL0242	KIT HOSE CYL MASTER FR-UNIT ABS	Bajaj spare parts
36JL0243	KIT HOSE UNIT ABS-CALIPER FRONT	Bajaj spare parts
36JL0244	KIT HOSE CYL MASTER RR-UNIT ABS	Bajaj spare parts
36JL0245	KIT HOSE UNIT ABS-CALIPER REAR	Bajaj spare parts
36JL0246	KIT HOSE UNIT ABS-CALIPER REAR	Bajaj spare parts
36JL0247	KIT FAIRING DECAL	Bajaj spare parts
36JL0248	KIT TANK COVER TOP DECAL	Bajaj spare parts
36JL0249	KIT TANK LH SIDE DECAL WHITE	Bajaj spare parts
36JL0250	KIT TANK LH SIDE DECAL BLACK	Bajaj spare parts
36JL0251	KIT TANK RH SIDE DECAL WHITE	Bajaj spare parts
36JL0252	KIT TANK RH SIDE DECAL BLACK	Bajaj spare parts
36JL0253	KIT SEAT COWL DCL-WHITE	Bajaj spare parts
36JL0255	KIT BELLY PAN DCL-WHITE	Bajaj spare parts
36JL0256	KIT BELLY PAN DCL-BLACK	Bajaj spare parts
36JL0257	KIT FENDER DECAL	Bajaj spare parts
36JL0258	KIT SEAT COWL DCL-BLACK	Bajaj spare parts
36JL0259	MASTER CYL PUSH ROD-FORK KIT	Bajaj spare parts
36JL0260	RESERVOIR ASSEMBLY KIT	Bajaj spare parts
36JL0261	KIT SEAT COWL DCL-WHITE	Bajaj spare parts
36JL0262	KIT SEAT COWL DCL-BLACK	Bajaj spare parts
36JM0003	KIT CHAIN SPROCKET	Bajaj spare parts
36JM0004	KIT STARTER RELAY	Bajaj spare parts
36JM0005	KIT FRAME WINDSHIELD AVENGER	Bajaj spare parts
36JN0007	KIT CH.SPR DIS 135	Bajaj spare parts
36JN0015	CHAIN/SPROKT DIS 135	Bajaj spare parts
36JN0016	KIT ENGINE GASKET DIS 135	Bajaj spare parts
36JN0017	KIT STARTER RLY- FF ( JN351604 )	Bajaj spare parts
36JP0011	BR HOSE ASY KIT(ABS TO FR M CY)	Bajaj spare parts
36JP0012	BR HOSE ASY KIT(ABS TO FRCLIPER)	Bajaj spare parts
36JP0013	BR HOSE ASY KIT(ABS- R MST CY)	Bajaj spare parts
36JP0014	BR HOSE ASY KIT(ABS-RE CALIPER)	Bajaj spare parts
36JP0015	BR HOSE ASY FR - NON ABS	Bajaj spare parts
36JP0016	KIT FR.M/CYL ASY W/O CLAMP-JY13	Bajaj spare parts
36JP0017	KIT FR.M/CYL ASSLY W/O CLAMP-22	Bajaj spare parts
36JP0018	KIT HAND GUARD ELEC ORG D390	Bajaj spare parts
36JP0022	KIT FR WHEEL BLACK MY17	Bajaj spare parts
36JP0023	KIT RR WHEEL BLACK MY17	Bajaj spare parts
36JP0026	IGNITION SWITCH WITH KEY MY17	Bajaj spare parts
36JP0035	IGN LOCK WITH SHEAR BOLTS MY17	Bajaj spare parts
36JP0036	LOCK SET EVAP SHEAR BOLTS MY17	Bajaj spare parts
36JP0037	FR FRAME ASY BLK DUKE MY18	Bajaj spare parts



36JP0038	FR FRAME ASLY ORG DUKE MY18	Bajaj spare parts
36JP0039	KIT OUTPUT SPROCKET DUKE 250	Bajaj spare parts
36JP0042	KIT ECU BRACKET COVER	Bajaj spare parts
36JP0043	KIT LED HEADLAMP BUSH	Bajaj spare parts
36JP0044	CYL HEAD & GASKET 250DUKE (JP22)	Bajaj spare parts
36JP0054	SPLIT BRG BUSH GREEN-JG531034	Bajaj spare parts
36JP0055	SPLIT BRG BUSH BLUE-JG531034	Bajaj spare parts
36JP0056	SPLIT BRG BUSH NEUTRAL-JG531034	Bajaj spare parts
36JP0057	KIT CR' CASE ASY RH 200 MY20	Bajaj spare parts
36JP0058	KIT CR' CASE ASY LH 200 MY20	Bajaj spare parts
36JP0066	BR HOSE KIT ABS TO MAST CYL. FR	Bajaj spare parts
36JP0067	BR HOSE KIT ABS TO FR CALIPER	Bajaj spare parts
36JP0068	BR HOSE KIT REAR MC TO ABS	Bajaj spare parts
36JP0069	BR HOSE KIT REAR CALIPER TO ABS	Bajaj spare parts
36JP0079	COLOUR SIL.PRIMER(5 QTY)BOTTLE	Bajaj spare parts
36JP0089	KIT VALVE SEAT & SPRING	Bajaj spare parts
36JR0013	KIT DCL TANK TOP M T GREY	Bajaj spare parts
36JR0015	KIT DCL TANK TOP M V RED	Bajaj spare parts
36JR0016	KIT DCL TANK TOP M YELLOW	Bajaj spare parts
36JR0017	KIT DCL SEAT COWL M T GREY	Bajaj spare parts
36JR0019	KIT DCL SEAT COWL M V RED	Bajaj spare parts
36JR0020	KIT DCL SEAT COWL M YELLOW	Bajaj spare parts
36JR0021	KIT DCL FAIRING FRONT GREY	Bajaj spare parts
36JR0022	KIT DCL FAIRING FRONT M V RED	Bajaj spare parts
36JR0023	KIT DCL FAIRING FRONT M YELLOW	Bajaj spare parts
36JR0033	KIT CHAIN SPROCKET	Bajaj spare parts
36JR0034	KIT HOSE UNIT ABS-CALIPER	Bajaj spare parts
36JR0035	KIT HOSE CYL MASTER-UNIT ABS	Bajaj spare parts
36JR0036	KIT HOSE BRAKE REAR	Bajaj spare parts
36JR0037	KIT CHAIN GUIDE	Bajaj spare parts
36JR0038	KIT PRIMARY DRIVE & CL HOUSING	Bajaj spare parts
36JR0039	KIT PISTON RINGS	Bajaj spare parts
36JR0040	KIT VALVE	Bajaj spare parts
36JR0041	KIT INLET VALVE HARDWARE	Bajaj spare parts
36JR0042	KIT EXHAUST VALVE HARDWARE	Bajaj spare parts
36JR0043	KIT AIR FILTER ELEMENT+SEAL	Bajaj spare parts
36JR0045	KIT FRICTION PLATE	Bajaj spare parts
36JR0046	CALIPER MAJOR KIT	Bajaj spare parts
36JR0047	CALIPER MINI KIT	Bajaj spare parts
36JR0048	FASTENING CAP KIT	Bajaj spare parts
36JR0049	RR MASTER CYL MAJOR KIT-K17B/D/F	Bajaj spare parts
36JR0050	MASTER CYL PUSH ROD-FORK KIT	Bajaj spare parts
36JR0051	MASTER CYL SEAL KIT	Bajaj spare parts
36JR0052	RESERVOIR ASSEMBLY KIT	Bajaj spare parts
36JR0053	FILLER UNION , O-RING KIT	Bajaj spare parts

36JR0054	HOSE TUBE -CLAMP KIT	Bajaj spare parts
36JR0055	KIT CRANKCASE ASSEMBLY LH	Bajaj spare parts
36JR0056	KIT CRANKCASE ASSEMBLY RH	Bajaj spare parts
36JR0057	KIT SEAT COWL DCL BLACK	Bajaj spare parts
36JR0058	KIT SEAT COWL DCL RED	Bajaj spare parts
36JR0060	KIT FAIRING DCL G T BLACK	Bajaj spare parts
36JR0061	KIT FAIRING DCL RED	Bajaj spare parts
36JR0063	KIT DECAL TANK G T BLACK	Bajaj spare parts
36JR0064	KIT TANK DCL RACING RED	Bajaj spare parts
36JR0065	KIT TANK DECAL YELLOW	Bajaj spare parts
36JR0066	KIT DCL TANK FLAP RED LH	Bajaj spare parts
36JR0067	KIT DCL TANK FLAP RED RH	Bajaj spare parts
36JR0068	KIT DCL TANK FLAP YELLOW RH	Bajaj spare parts
36JR0069	KIT DCL TANK FLAP YELLOW LH	Bajaj spare parts
36JR0070	KIT DCL TANK FLAP GRAY LH	Bajaj spare parts
36JR0071	KIT DCL TANK FLAP GRAY RH	Bajaj spare parts
36JR0072	KIT BLOCK PISTON	Bajaj spare parts
36JR0073	KIT ASSLY CL COVER DEEP COPPER	Bajaj spare parts
36JR0076	KIT SEAT COWL DECAL N250 BLUE	Bajaj spare parts
36JR0077	KIT FAIRING DECAL BLUE F250	Bajaj spare parts
36JR0078	KIT TANK DECAL BLUE F250	Bajaj spare parts
36JR0080	KIT SEAT COWL DECAL F250 BLUE	Bajaj spare parts
36JR0081	KIT DECAL TANK FLAP RH	Bajaj spare parts
36JR0082	KIT DECAL TANK FLAP LH	Bajaj spare parts
36JR0083	KIT TANK DECAL BLUE	Bajaj spare parts
36JR0084	KIT FAIRING DECAL BLUE	Bajaj spare parts
36JR0085	ABS UNIT TO FR CALIPER HOSE KIT	Bajaj spare parts
36JR0086	RE MASTER CYL TO ABS UNIT HOSE	Bajaj spare parts
36JR0087	ABS UNIT TO RE CALIPER HOSE KIT	Bajaj spare parts
36JR0088	REAR MASTER PUSH ROD KIT	Bajaj spare parts
36JR0089	REAR RESERVOIR ASSEMBLY KIT	Bajaj spare parts
36JR0090	KIT FENDER DCL BLACK GLOSSY	Bajaj spare parts
36JR0091	KIT TANK DCL BLACK GLOSSY	Bajaj spare parts
36JR0092	KIT DCL FLAP LH BLACK GLOSSY	Bajaj spare parts
36JR0093	KIT DCL FLAP RH BLACK GLOSSY	Bajaj spare parts
36JR0094	KIT TANK DCL BLACK GLOSSY F	Bajaj spare parts
36JR0095	KIT CLUTCH COVER BACK COLOUR	Bajaj spare parts
36JR0096	KIT HOSE M/C TO ABS UNIT	Bajaj spare parts
36JR0097	KIT HOSE M/C TO ABS UNIT	Bajaj spare parts
36JR0098	CHAIN GUIDE KIT	Bajaj spare parts
36JR0099	KIT BLOCK PISTON ASSLY	Bajaj spare parts
36JR0100	KIT PRIMARY GEAR+ CL HSG	Bajaj spare parts
36JR0101	KIT VALVE INTAKE+EXHAUST	Bajaj spare parts
36JR0102	KIT ASSLY CYL HEAD	Bajaj spare parts
36JR0103	KIT ASSLY CRANKCASE RH	Bajaj spare parts

36JR0104	KIT ASSLY CRANKCASE LH	Bajaj spare parts
36JR0105	KIT DCL N160 C BLUE	Bajaj spare parts
36JR0106	KIT DCL N160 TECHNO BLACK	Bajaj spare parts
36JR0107	KIT DCL N160 RACING RED	Bajaj spare parts
36JR0109	KIT CHAIN SPROCKET	Bajaj spare parts
36JR0110	KIT VALVE REPAIR	Bajaj spare parts
36JR0112	KIT FRICTION PLATE	Bajaj spare parts
36JR0113	KIT CLUTCH PLATE STEEL	Bajaj spare parts
36JR0114	KIT CLUTCH COVER MATTE COPPER	Bajaj spare parts
36JR0115	KIT FAIRING DECAL B BLACK	Bajaj spare parts
36JR0116	KIT TANK DECAL BROOKLYN BLACK	Bajaj spare parts
36JR0117	KIT TANK FLAP DCL BROOKLYN BLACK	Bajaj spare parts
36JR0118	KIT TANK FLAP RH DCL BLACK	Bajaj spare parts
36JR0119	Accessory kit Pulsar F/N 250	Bajaj spare parts
36JR0120	Accessory kit Pulsar N160	Bajaj spare parts
36JR0123	KIT CLUTCH COVER SLICK BLACK	Bajaj spare parts
36JR0124	LOCK SET SATIN SILVER	Bajaj spare parts
36JR0125	LOCK SET SATIN BLACK	Bajaj spare parts
36JR0126	LOCK SET SATIN SILVER	Bajaj spare parts
36JR0127	LOCK SET SATIN BLACK	Bajaj spare parts
36JR0128	KIT BLOCK PISTON ASSLY	Bajaj spare parts
36JR0129	KIT VALVE INTAKE+EXHAUST	Bajaj spare parts
36JR0130	KIT CHAIN SPROCKET	Bajaj spare parts
36JR0131	KIT VALVE REPAIR	Bajaj spare parts
36JR0132	KIT HOSE UNIT ABS-CALIPER FRONT	Bajaj spare parts
36JR0133	KIT HOSE CYL MASTER FR-UNIT ABS	Bajaj spare parts
36JR0134	KIT DECAL FENDER RACING RED	Bajaj spare parts
36JR0135	KIT DECAL FENDER C BLUE	Bajaj spare parts
36JR0136	KIT DCL FENDER CHARCOAL BLACK	Bajaj spare parts
36JR0137	KIT DECAL FAIRING RACING RED	Bajaj spare parts
36JR0138	KIT DECAL FAIRING C BLUE	Bajaj spare parts
36JR0139	KIT DCL FAIRING CHARCOAL BLACK	Bajaj spare parts
36JR0140	KIT DECAL TANK RACING RED	Bajaj spare parts
36JR0141	KIT DECAL TANK BLUE	Bajaj spare parts
36JR0142	KIT DECAL TANK C BLACK	Bajaj spare parts
36JR0143	KIT DECAL TANK FLAP LH RED	Bajaj spare parts
36JR0144	KIT DECAL TANK FLAP LH BLUE	Bajaj spare parts
36JR0145	KIT DECAL TANK FLAP LH C BLACK	Bajaj spare parts
36JR0146	KIT DECAL TANK FLAP RH RED	Bajaj spare parts
36JR0147	KIT DECAL TANK FLAP RH BLUE	Bajaj spare parts
36JR0148	KIT DECAL TANK FLAP RH C BLACK	Bajaj spare parts
36JR0149	KIT LOCK SET SLATE GREY PT CAP	Bajaj spare parts
36JR0150	ACCESSORY KIT PULSAR 150 NEW	Bajaj spare parts
36JR0153	KIT DECAL TANK FLAP LH WHITE	Bajaj spare parts
36JR0154	KIT DECAL TANK FLAP RH WHITE	Bajaj spare parts

36JR0155	KIT DECAL TANK FLAP LH BLUE	Bajaj spare parts
36JR0156	KIT DECAL TANK FLAP RH BLUE	Bajaj spare parts
36JR0157	KIT DECAL FAIRING WHITE	Bajaj spare parts
36JR0158	KIT DECAL FAIRING BLUE	Bajaj spare parts
36JR0161	KIT TANK DCL BLACK GLOSSY	Bajaj spare parts
36JT0005	GRAPHICS KIT RACE RC -KTM-90208999000	Bajaj spare parts
36JT0006	TANK PROTECTION STIKER	Bajaj spare parts
36JT0007	TANKPAD -KTM-90107011000	Bajaj spare parts
36JT0008	CRASH PAD FRONT-KTM-90109945000	Bajaj spare parts
36JT0014	WINDSHIELD-KTM-90108965000	Bajaj spare parts
36JT0015	GRAPHICS KIT RACE Duke	Bajaj spare parts
36JT0017	CRASH PAD REAR - KTM - 90110945000	Bajaj spare parts
36JT0022	RACING FOOTPEGS	Bajaj spare parts
36JT0029	BRAKE LEVER LOCK - KTM - 61012016000	Bajaj spare parts
36JT0034	TANK CAP STICKER -KTM-90107909000	Bajaj spare parts
36JT0036	CAP ORANGE	Bajaj spare parts
36JT0040	KTM T-SHIRT ROUND NECK - EXTRA LARGE	Bajaj spare parts
36JT0041	KTM T-SHIRT ROUND NECK - LARGE	Bajaj spare parts
36JT0042	KTM T-SHIRT ROUND NECK - MEDIUM	Bajaj spare parts
36JT0043	KTM T-SHIRT ROUND NECK - SMALL	Bajaj spare parts
36JT0044	KTM T-Shirt - Polo - Extra Large	Bajaj spare parts
36JT0045	KTM T-Shirt - Polo - Large	Bajaj spare parts
36JT0046	KTM T-Shirt - Polo - Medium	Bajaj spare parts
36JT0047	KTM T-Shirt - Polo - Small	Bajaj spare parts
36JT0054	BIKE COVER (KTM)	Bajaj spare parts
36JT0055	CHROME STICKER SET KTM:90608999200	Bajaj spare parts
36JT0061	GRAPHICS KIT-STYLE - 93008999100	Bajaj spare parts
36JT0062	GRAPHIC KIT NEON	Bajaj spare parts
36JT0063	TANK PAD - 93007911000	Bajaj spare parts
36JT0065	LEVER SET - 00010000233	Bajaj spare parts
36JT0066	WINDSHIELD - 90508908044	Bajaj spare parts
36JT0068	WINDSHIELD	Bajaj spare parts
36JT0069	HANDLEBAR END MIRROR	Bajaj spare parts
36JT0070	CRASH PADS REAR	Bajaj spare parts
36JT0071	CRASH PADS FRONT	Bajaj spare parts
36JT0072	ERGO TANK PAD 790 DUKE	Bajaj spare parts
36JT0074	KTM MY RIDE CONTROL UNIT.	Bajaj spare parts
36JT0075	BIKE COVER (KTM) 790	Bajaj spare parts
36JT0076	TPMS FOR 790 DUKE	Bajaj spare parts
36JT0082	HELMET LOCK(60012015000)	Bajaj spare parts
36JT0083	REAR SPROCKET(9051095104204)	Bajaj spare parts
36JT0084	RADITR PROTE GRILE(95835940044)	Bajaj spare parts
36JT0087	HANDLEBAR PAD(79002901050)	Bajaj spare parts
36JT0088	GPS BRACKET(63512992044)	Bajaj spare parts
36JT0090	H. LIGHT PROTECTN(63514999033)	Bajaj spare parts

36JU0001	KIT RING SET KTM 200	Bajaj spare parts
36JU0002	KIT FRIC PLATES KTM 200	Bajaj spare parts
36JU0004	KIT SPLIT BUSH GREEN COLOUR	Bajaj spare parts
36JU0005	KIT SPLIT BUSH BLUE COLOUR	Bajaj spare parts
36JU0006	KIT SPLIT BUSH NONE COLOUR	Bajaj spare parts
36JU0007	KIT CYLINDER BLOCK	Bajaj spare parts
36JU0011	ENG.CON.UNIT KTM 200	Bajaj spare parts
36JU0014	FUEL TANK ASSLY COMP 125-200 EXP	Bajaj spare parts
36JU0016	KIT BELLY PAN ASSLY DUKE 200	Bajaj spare parts
36JU0018	KIT CHAIN SPROCKETS KTM 200	Bajaj spare parts
36JU0019	Kit Fork Oil seal	Bajaj spare parts
36JU0028	KIT SENSOR FUEL LEVEL JG/JU	Bajaj spare parts
36JU0036	KIT CRANK SHAFT ASSLY	Bajaj spare parts
36JU0040	KIT SHIM 2MM JG511268AA	Bajaj spare parts
36JU0041	KIT SHIM 2.04MM JG511268AB	Bajaj spare parts
36JU0042	KIT SHIM 2.08MM JG511268AC	Bajaj spare parts
36JU0043	KIT SHIM 2.12MM JG511268AD	Bajaj spare parts
36JU0044	KIT SHIM 2.16MM JG511268AE	Bajaj spare parts
36JU0045	KIT SHIM 2.20MM JG511268AF	Bajaj spare parts
36JU0046	KIT SHIM 2.24MM JG511268AG	Bajaj spare parts
36JU0047	KIT SHIM 2.28MM JG511268AH	Bajaj spare parts
36JU0048	KIT SHIM 2.32MM JG511268AI	Bajaj spare parts
36JU0049	KIT SHIM 2.36MM JG511268AJ	Bajaj spare parts
36JU0050	KIT SHIM 2.40MM JG511268AK	Bajaj spare parts
36JU0051	KIT SHIM 2.44 MM JG511268AL	Bajaj spare parts
36JU0052	KIT SHIM 2.48 MM JG511268AM	Bajaj spare parts
36JU0053	KIT SHIM 2.52 MM JG511268AN	Bajaj spare parts
36JU0054	KIT SHIM 2.56 MM JG511268AO	Bajaj spare parts
36JU0055	KIT SHIM 2.60 MM JG511268AP	Bajaj spare parts
36JU0056	KIT SHIM 2.64 MM JG511268AQ	Bajaj spare parts
36JU0057	KIT SHIM 2.68 MM JG511268AR	Bajaj spare parts
36JU0058	KIT SHIM 2.72 MM JG511268AS	Bajaj spare parts
36JU0059	KIT SHIM 2.76 MM JG511268AT	Bajaj spare parts
36JU0060	KIT SHIM 2.80 MM JG511268AU	Bajaj spare parts
36JU0061	KIT SHIM 2.84 MM JG511268AV	Bajaj spare parts
36JU0062	KIT SHIM 2.88 MM JG511268AW	Bajaj spare parts
36JU0063	KIT SHIM 2.92 MM JG511268AX	Bajaj spare parts
36JU0064	KIT SHIM 2.96 MM JG511268AY	Bajaj spare parts
36JU0065	KIT SHIM 3 MM JG511268AZ	Bajaj spare parts
36JU0066	KIT SHIM 3.04 MM JG511268BA	Bajaj spare parts
36JU0067	KTM PERIODIC SERVICE KIT	Bajaj spare parts
36JU0068	KTM 200 REAR AXLE KIT	Bajaj spare parts
36JU0070	KIT REAR WHEEL ASSLY DUKE 200	Bajaj spare parts
36JU0071	KIT CHAIN SPROCKET DUKE 200	Bajaj spare parts
36JU0073	KIT VALVE CVR GSKT-DUKE 200	Bajaj spare parts

36JU0074	KIT STEERING RACE UPPER JU/JY	Bajaj spare parts
36JU0077	KTM P/T COVR WITH DEL-ORNG	Bajaj spare parts
36JU0079	KTM P/T COVER WITH DEL-WHITE	Bajaj spare parts
36JU0080	KIT FR.WHEEL ASY KTM200	Bajaj spare parts
36JU0081	KIT RR. WEEL ASY KTM200-DOM BLK	Bajaj spare parts
36JU0085	SHIM 2.02 MM	Bajaj spare parts
36JU0086	SHIM 2.06 MM	Bajaj spare parts
36JU0087	SHIM 2.10 MM	Bajaj spare parts
36JU0088	SHIM 2.14 MM	Bajaj spare parts
36JU0089	SHIM 2.18 MM	Bajaj spare parts
36JU0091	SHIM 2.26 MM	Bajaj spare parts
36JU0092	SHIM 2.30 MM	Bajaj spare parts
36JU0101	SHIM 2.66 MM	Bajaj spare parts
36JU0108	SHIM 2.94 MM	Bajaj spare parts
36JU0109	SHIM 2.98 MM	Bajaj spare parts
36JU0110	SHIM 3.02 MM	Bajaj spare parts
36JU0114	KIT FRONT BRAKE PAD WITH SHIM	Bajaj spare parts
36JU0116	KIT CRANK CASE ASSY LH 200 CC	Bajaj spare parts
36JU0117	KIT KIT CRANK CASE ASSY RH 200 CC	Bajaj spare parts
36JU0123	KIT CR' CASE ASY RH 200 CC MY17	Bajaj spare parts
36JU0124	KIT D VALVE COVER GASKET 200	Bajaj spare parts
36JU0129	DECAL SET D200 MY17 WHITE	Bajaj spare parts
36JU0135	KIT OUTPUT SPROCKET DUKE 200	Bajaj spare parts
36JU0136	CLUTCH HOUSING ASSLY KIT	Bajaj spare parts
36JU0137	KITGRAB HAND&S GUARD RH DUKE200	Bajaj spare parts
36JU0139	KIT CRANKSHAFT ASSEMBLY COMP	Bajaj spare parts
36JU0140	KIT FRICTION PLATE FOR KTM 125	Bajaj spare parts
36JU0141	HOUSING CLUTCH ASSLY WITH BUSH	Bajaj spare parts
36JU0142	KIT BRAKE HOSE FR ABS TO CALIPER	Bajaj spare parts
36JU0143	KIT BRAKE HOSE FR ABS TO MC	Bajaj spare parts
36JU0144	KIT FRONT WHEEL	Bajaj spare parts
36JU0145	KIT REAR WHEEL	Bajaj spare parts
36JU0146	KIT FRONT WHEEL	Bajaj spare parts
36JU0147	KIT REAR WHEEL	Bajaj spare parts
36JU0148	BR HOSE KIT ABS TO M CYL. FR	Bajaj spare parts
36JU0149	BR HOSE KIT FR ABS TO CALIPER	Bajaj spare parts
36JU0150	BR HOSE REAR MC TO ABS	Bajaj spare parts
36JU0151	BR HOSE KIT ABS TO M CYL. FRONT	Bajaj spare parts
36JU0152	KIT CR' CASE ASY LH - HR BLACK	Bajaj spare parts
36JU0153	KIT CR' CASE ASSY RH - HR BLACK	Bajaj spare parts
36JU0159	BR HOSE REAR CALIPER TO ABS	Bajaj spare parts
36JU0160	REAR MASTER CYL RES TUBE KIT	Bajaj spare parts
36JU0161	REAR MASTER CYL RES TUBE KIT	Bajaj spare parts
36JV0006	VALVE REPAIR KIT BM125	Bajaj spare parts
36JV0007	KIT CHAIN GUIDE BM125	Bajaj spare parts

36JW0007	KIT VALVE XCD135	Bajaj spare parts
36JW0009	KIT CHAIN GUIDE XCD	Bajaj spare parts
36JW0010	KIT SET PISTON RING XCD 1	Bajaj spare parts
36JW0011	KIT CHAIN SPROCKET X	Bajaj spare parts
36JW0012	KIT CHAIN CASE XCD 135 CC	Bajaj spare parts
36JW0013	KIT HWARE LG SCD 135	Bajaj spare parts
36JW0014	KIT STARTER CL XCD 135	Bajaj spare parts
36JX0002	FILTER KIT	Bajaj spare parts
36JX0003	FORK SEALING KIT 43MM DUKE790	Bajaj spare parts
36JX0004	CLUTCH COVER COMPLETE	Bajaj spare parts
36JX0005	DECAL SET 790 DUKE ORANGE	Bajaj spare parts
36JX0006	BRAKE LEVER	Bajaj spare parts
36JX0007	CLUTCH LEVER CPL.	Bajaj spare parts
36JX0008	GUIDE BUSHING SET	Bajaj spare parts
36JX0009	FRONT WHEEL REPAIR KIT	Bajaj spare parts
36JX0010	REAR WHEEL REPAIR KIT	Bajaj spare parts
36JX0011	BRAKE PAD SET FRONT	Bajaj spare parts
36JX0012	BRAKE PAD SET	Bajaj spare parts
36JX0013	STEARING HEAD REP. KIT	Bajaj spare parts
36JX0014	PISTON ASSEMBLY	Bajaj spare parts
36JX0015	PISTON ASSEMBLY	Bajaj spare parts
36JX0016	KIT DRIVE CHAIN 16/41	Bajaj spare parts
36JX0019	REP. KIT BEAR./SEAL UP. 07	Bajaj spare parts
36JX0021	SWING ARM REPAIR KIT SX-F	Bajaj spare parts
36JX0028	LEVER BOLT CPL.	Bajaj spare parts
36JX0029	RESERVOIR ASSEMBLY	Bajaj spare parts
36JX0031	CLAMP	Bajaj spare parts
36JX0040	ENGINE GASKET KIT	Bajaj spare parts
36JX0042	ENGINE SPROCKET 17 T DAMPED	Bajaj spare parts
36JX0043	VALVE SPRING KIT	Bajaj spare parts
36JY0002	Kit Frict. Plate	Bajaj spare parts
36JY0003	KIT Piston Ring KTM 390	Bajaj spare parts
36JY0004	KIT Split Bearing Bush Green KTM 390	Bajaj spare parts
36JY0005	KIT Split Bearing Bush Blue KTM 390	Bajaj spare parts
36JY0006	KIT Split Bearing Bush None KTM 390	Bajaj spare parts
36JY0007	Kit Cyl. Blk. Pist.	Bajaj spare parts
36JY0014	KIT HAND GUARD KTM 390	Bajaj spare parts
36JY0026	KIT COUPLING WITH BRG	Bajaj spare parts
36JY0029	KIT SHIM 2 MM	Bajaj spare parts
36JY0030	KIT SHIM 2.04 MM	Bajaj spare parts
36JY0031	KIT SHIM 2.08 MM	Bajaj spare parts
36JY0032	KIT SHIM 2.12 MM	Bajaj spare parts
36JY0033	KIT SHIM 2.16 MM	Bajaj spare parts
36JY0034	KIT SHIM 2.20 MM	Bajaj spare parts
36JY0035	KIT SHIM 2.24 MM	Bajaj spare parts

36JY0036	KIT SHIM 2.28 MM	Bajaj spare parts
36JY0037	KIT SHIM 2.32 MM	Bajaj spare parts
36JY0038	KIT SHIM 2.36 MM	Bajaj spare parts
36JY0039	KIT SHIM 2.40 MM	Bajaj spare parts
36JY0040	KIT SHIM 2.44 MM	Bajaj spare parts
36JY0041	KIT 2.48 MM	Bajaj spare parts
36JY0042	KIT SHIM 2.52 MM	Bajaj spare parts
36JY0043	KIT SHIM 2.56 MM	Bajaj spare parts
36JY0044	KIT SHIM 2.60 MM	Bajaj spare parts
36JY0045	KIT 2.64 MM	Bajaj spare parts
36JY0046	KIT SHIM 2.68 MM	Bajaj spare parts
36JY0047	KIT 2.72 MM	Bajaj spare parts
36JY0048	KIT SHIM 2.76 MM	Bajaj spare parts
36JY0049	KIT SHIM 2.80 MM	Bajaj spare parts
36JY0050	KIT SHIM 2.84 MM	Bajaj spare parts
36JY0051	KIT SHIM 2.88 MM	Bajaj spare parts
36JY0052	KIT SHIM 2.92 MM	Bajaj spare parts
36JY0053	KIT SHIM 2.96 MM	Bajaj spare parts
36JY0054	KIT SHIM 3 MM	Bajaj spare parts
36JY0055	KIT SHIM 3.04 MM	Bajaj spare parts
36JY0056	KIT SHIM 2.30 MM JY511231AP	Bajaj spare parts
36JY0057	KIT SHIM 2.34 MM JY511231AR	Bajaj spare parts
36JY0058	KIT SHIM 2.38 MM JY511231AT	Bajaj spare parts
36JY0059	KIT SHIM 2.42 MM JY511231AV	Bajaj spare parts
36JY0060	KIT SHIM 2.46 MM JY511231AX	Bajaj spare parts
36JY0061	KIT SHIM 2.50 MM JY511231AZ	Bajaj spare parts
36JY0062	KIT SHIM 2.54 MM JY511231BB	Bajaj spare parts
36JY0063	KIT SHIM 2.58 MM JY511231BD	Bajaj spare parts
36JY0064	KIT SHIM 2.62 MM JY511231BF	Bajaj spare parts
36JY0065	KIT VALVE SPRING KTM	Bajaj spare parts
36JY0068	KIT FRONT FENDER WITH HOLES	Bajaj spare parts
36JY0069	KIT VALVE CVR GSKT- DUKE 390	Bajaj spare parts
36JY0070	KTM 390 P T COVER	Bajaj spare parts
36JY0071	KIT DRIVE SPROCKET	Bajaj spare parts
36JY0073	KIT CHAIN SPROCKETS KTM 390 MY	Bajaj spare parts
36JY0075	PRESSURE SWITCH KIT	Bajaj spare parts
36JY0076	BANJO BOLT KIT	Bajaj spare parts
36JY0077	BRAKE HOSE ASY KIT	Bajaj spare parts
36JY0078	BRAKE HOSE ASY KIT	Bajaj spare parts
36JY0079	BRAKE HOSE ASY KIT	Bajaj spare parts
36JY0080	BRAKE HOSE ASSY KIT	Bajaj spare parts
36JY0081	KIT FR.WHEEL ASSY KTM390-DOM ORG	Bajaj spare parts
36JY0082	KIT RR.WHEEL ASSY KTM390 -DOM ORG	Bajaj spare parts
36JY0084	KIT SIDE FAIRING LH WITH DECAL RC200	Bajaj spare parts
36JY0085	KIT SIDE FAIRING RH WITH DECAL RC200	Bajaj spare parts



36JY0086	KIT FUEL TANK COVER WITH DECALS RC200	Bajaj spare parts
36JY0087	KIT BELLY PAN RH WITH DECAL RC200	Bajaj spare parts
36JY0088	KIT BELLY PAN LH WITH DECAL RC200	Bajaj spare parts
36JY0089	KIT SIDE FAIRING LH WITH DECAL RC390	Bajaj spare parts
36JY0090	KIT SIDE FAIRING RH WITH DECAL RC390	Bajaj spare parts
36JY0092	KIT BELLY PAN LH WITH DECAL RC390	Bajaj spare parts
36JY0093	KIT BELLY PAN RH WITH DECAL RC390	Bajaj spare parts
36JY0100	KIT CHAIN SPROCKET KTM 200 MY15	Bajaj spare parts
36JY0101	KIT CHAIN SPROCKET KTM 390 MY15	Bajaj spare parts
36JY0102	KIT OUT PUT SHAFT	Bajaj spare parts
36JY0103	KIT FRIC PLATE KTM 390 A/S	Bajaj spare parts
36JY0106	KIT ROTOR SCREW CPL	Bajaj spare parts
36JY0153	RING PISTON KT10	Bajaj spare parts
36JY0156	KIT BUSH BIG END GREEN COLOUR	Bajaj spare parts
36JY0157	KIT BUSH BIG END NONE COLOUR	Bajaj spare parts
36JY0158	KIT BUSH BIG END BLACK COLOUR	Bajaj spare parts
36JY0168	RC200 LH HANDLE BAR	Bajaj spare parts
36JY0169	RC 200 RH HANDLE BAR	Bajaj spare parts
36JY0170	RC 390 LH HANDLE BAR	Bajaj spare parts
36JY0171	RC 390 RH HANDLE BAR	Bajaj spare parts
36JY0175	KIT CRANK CASE ASSY RH 390 CC	Bajaj spare parts
36JY0177	KIT BRAKE HOSE ASSY	Bajaj spare parts
36JY0178	BRAKE HOSE ASSY KIT	Bajaj spare parts
36JY0179	MAJOR KIT REAR CALIPER	Bajaj spare parts
36JY0180	MINOR KIT REAR CALIPER	Bajaj spare parts
36JY0181	PRIMARY PIN KIT REAR CALIPER	Bajaj spare parts
36JY0182	PUSH ROD ASSY KIT REAR MASTER CY	Bajaj spare parts
36JY0183	FRONT MASTER CYLINDER MAJOR KIT	Bajaj spare parts
36JY0184	FRONT MASTER CYLINDER MINOR KIT	Bajaj spare parts
36JY0185	FR M/CYL CLAMP KIT	Bajaj spare parts
36JY0186	FR M/CYL BRAKE LEVER KIT	Bajaj spare parts
36JY0187	FR M/CYL BOOT SPD KIT	Bajaj spare parts
36JY0188	FR CALIPER BRAKE PAD KIT-SINTERED	Bajaj spare parts
36JY0192	KIT BALANCER SHAFT KTM 390	Bajaj spare parts
36JY0197	KIT CR' CASE ASY LH 390 CC MY17	Bajaj spare parts
36JY0198	KIT CR' CASE ASSY RH 390 CC MY17	Bajaj spare parts
36JY0199	KIT VALVE COVER GASKET 390	Bajaj spare parts
36JY0200	PACKING KIT ENGINE CRANKCASE 390	Bajaj spare parts
36JY0205	KIT FR WHEEL ELEC ORANGE MY17	Bajaj spare parts
36JY0206	KIT REAR WHEEL ORANGE	Bajaj spare parts
36JY0220	BRAKE LEVER KIT 10W02622	Bajaj spare parts
36JY0221	"CLAMP KIT - KT19,20, 22 10W05270"	Bajaj spare parts
36JY0222	CLAMP KIT - KT22 10W05251	Bajaj spare parts
36JY0223	MAJOR KIT RE MAST CYL 10W02822	Bajaj spare parts
36JY0224	MINOR KIT RE MAST CYL 10W05712	Bajaj spare parts

36JY0225	RE RESERVOIR TUBE KIT 06W12414	Bajaj spare parts
36JY0226	PUSH ROD ASY KIT 10W02931	Bajaj spare parts
36JY0227	FRAME ORANGE (52JY0635)RC	Bajaj spare parts
36JY0228	FRAME EL ORANGE (52JY0797)MY17	Bajaj spare parts
36JY0229	FRAME EL ORANGE (52JY0796) RC	Bajaj spare parts
36JY0233	FRAME ORANGE(52JY0635)W VINPLAT	Bajaj spare parts
36JY0234	FRAME ELORANGE(52JY0797)W VIN PL	Bajaj spare parts
36JY0235	FRAMEEL ORANGE(52JY0796)W VIN PL	Bajaj spare parts
36JY0238	KIT OUTPUT SPROCKET	Bajaj spare parts
36JY0239	KIT BRAKE HOSE FRONT 200	Bajaj spare parts
36JY0240	KIT BRAKE HOSE REAR 200	Bajaj spare parts
36JY0242	FRAME ASSLY RC 390 MY18	Bajaj spare parts
36JY0251	KIT BLOCK PISTON ASY KTM 390	Bajaj spare parts
36JY0262	BR HOSE KIT REAR MC TO ABS	Bajaj spare parts
36JY0263	BR HOSE KIT REAR CALIPER TO ABS	Bajaj spare parts
36JY0265	KIT DECAL TANK	Bajaj spare parts
36JY0266	KIT DECAL FENDOR FR MY20 RC390	Bajaj spare parts
36JY0267	KIT DECAL FRG LH MY20 RC390 GREY	Bajaj spare parts
36JY0268	KIT DECAL FRG RH MY20 RC390 GREY	Bajaj spare parts
36JY0269	KIT DCL SEAT CWL MY20 RC390 GRY	Bajaj spare parts
36JY0270	KIT DECAL TANK MY20 RC200 ORG	Bajaj spare parts
36JY0271	KIT DCL FENDER FR MY20 RC200 ORG	Bajaj spare parts
36JY0272	KIT DECAL FRG LH MY20 RC200 ORG	Bajaj spare parts
36JY0273	KIT DECAL FRG RH MY20 RC200 ORG	Bajaj spare parts
36JY0274	KIT DCL SEAT CWL MY20 RC200 ORG	Bajaj spare parts
36JY0275	FRAME ASY MY20 RC ORG	Bajaj spare parts
36JY0276	KIT DECAL TANK MY20 RC125 BLK	Bajaj spare parts
36JY0277	KIT DCL FENDER FR MY20 RC125 BLK	Bajaj spare parts
36JY0278	KIT DECAL FRG LH MY20 RC125 BLK	Bajaj spare parts
36JY0279	KIT DECAL FRG RH MY20 RC125 BLK	Bajaj spare parts
36JY0280	KIT DECAL SEAT COWL MY20 RC125	Bajaj spare parts
36JY0281	FRAME ASY MY20 RC BLK	Bajaj spare parts
36JY0290	KIT DECAL STRUCTURE FAIRING	Bajaj spare parts
36JY0291	KIT DECAL IN FAIR LH CER WHT	Bajaj spare parts
36JY0292	KIT DECAL IN FAIR RH CER WHT	Bajaj spare parts
36JY0293	KIT DECAL COVER TANK CER WHT	Bajaj spare parts
36JY0294	KIT DECAL SEAT COWL WHT	Bajaj spare parts
36JY0295	KIT DECAL IN FAIR LH BLK	Bajaj spare parts
36JY0296	KIT DECAL IN FAIR RH BLK	Bajaj spare parts
36JY0297	KIT DECAL COVER TANK BLK	Bajaj spare parts
36JY0298	KIT DECAL SEAT COWL BLK	Bajaj spare parts
36JY0299	KIT DECAL TANK ORG	Bajaj spare parts
36JY0300	KIT DECAL TANK BLK	Bajaj spare parts
36JY0301	KIT DECAL IN FAIR LH SLVR	Bajaj spare parts
36JY0302	KIT DECAL IN FAIR RH SLVR	Bajaj spare parts

36JY0303	KIT DECAL COVER TANK SLVR	Bajaj spare parts
36JY0304	KIT DECAL SEAT COWL SLVR	Bajaj spare parts
36JY0305	KIT DECAL IN FAIR LH BLK	Bajaj spare parts
36JY0306	KIT DECAL IN FAIR RH BLK	Bajaj spare parts
36JY0307	KIT DECAL COVER TANK BLK	Bajaj spare parts
36JY0310	RC FR FRAME ASSY BLK GLS	Bajaj spare parts
36JY0311	RC FR FRAME ASSY EB ORG GLS	Bajaj spare parts
36JY0313	HOSE CYLINDER MASTER FR-UNIT ABS	Bajaj spare parts
36JY0314	HOSE UNIT ABS-CALIPER FRONT	Bajaj spare parts
36JY0315	HOSE BRAKE REAR	Bajaj spare parts
36JY0316	HOSE CYLINDER MASTER RR-UNIT ABS	Bajaj spare parts
36JY0318	HOSE UNIT ABS-CALIPER REAR	Bajaj spare parts
36JY0319	HOSE CYLINDER MASTER RR-UNIT ABS	Bajaj spare parts
36JY0320	HOSE UNIT ABS-CALIPER REAR	Bajaj spare parts
36JY0321	WHEEL FR EB ORG	Bajaj spare parts
36JY0322	WHEEL RR EB ORG	Bajaj spare parts
36JY0323	WHEEL FR BLACK GLS	Bajaj spare parts
36JY0324	WHEEL RR BLACK GLS	Bajaj spare parts
36JY0330	KIT GROMMET	Bajaj spare parts
36JY0342	LOCK 3 IN 1 WITH CAP EVAP	Bajaj spare parts
36JY0346	KIT DECAL STRUCTURE FAIRING	Bajaj spare parts
36JY0350	RC200 KIT DECAL FENDER	Bajaj spare parts
36JY0351	RC200 KIT DECAL INNER FAIRING LH	Bajaj spare parts
36JY0352	RC200 KIT DECAL INNER FAIRING RH	Bajaj spare parts
36JY0353	RC200 KIT DECAL COVER TANK	Bajaj spare parts
36JY0354	RC200 KIT DECAL SEAT COWL	Bajaj spare parts
36JY0359	FUEL PUMP REPAIR KIT	Bajaj spare parts
36JY0360	DIAGNOSTIC TOOL	Bajaj spare parts
36JZ0001	KIT VALVE DISCO H	Bajaj spare parts
36JZ0002	CYL BLOCK ASLY DISCO H	Bajaj spare parts
36JZ0003	KIT DRIVE & DRIVEN DISCO H	Bajaj spare parts
36JZ0004	VALVE REPAIR KIT	Bajaj spare parts
36JZ0005	KIT PISTON RING	Bajaj spare parts
36JZ0007	KIT CHAIN SPROCKET	Bajaj spare parts
36JZ0008	KIT STARTER CLUTCH RE	Bajaj spare parts
36JZ0009	KIT CLUTCH BRG & BUS	Bajaj spare parts
36JZ0010	HEAD CYLINDER	Bajaj spare parts
36JZ0011	KIT CRANK CASE	Bajaj spare parts
36JZ0014	KIT PRIMARY DRIVE&DRI	Bajaj spare parts
36JZ0015	KIT COVER MAGNETO DIS	Bajaj spare parts
36JZ0016	IDLING SCREW KIT DISCO H	Bajaj spare parts
36JZ0017	JET KIT DISCO H	Bajaj spare parts
36JZ0019	THROTTLE VALVE KIT DISCO	Bajaj spare parts
36JZ0020	CABLE ADJUSTER KIT DISCO	Bajaj spare parts
36JZ0021	KIT CARB.GASKET O RING D	Bajaj spare parts

36JZ0022	KIT FUEL COCK SEAL ADVIK	Bajaj spare parts
36JZ0023	KIT PRIMARY DRIVE & DRIVE	Bajaj spare parts
36JZ0024	CYL BLOCK ASSY Disco125	Bajaj spare parts
36JZ0025	COVER CLUTCH ASSY DIS 125	Bajaj spare parts
36JZ0026	KIT CHAIN SPROCKET DIS 12	Bajaj spare parts
36JZ0028	CRANK CASE MAG SIDE DIS12	Bajaj spare parts
36JZ0030	SILENCER W/O SHIELD DIS1	Bajaj spare parts
36JZ0031	KIT JET KIT DISCO 125	Bajaj spare parts
36JZ0032	KIT THROTTLE VALVE KIT DI	Bajaj spare parts
36JZ0037	KIT FRICTION PLATE DISCO 125	Bajaj spare parts
36JZ0038	KIT FUEL GAUGE	Bajaj spare parts
36JZ0039	KIT SPEEDOMETER MACHINE	Bajaj spare parts
36JZ0040	KIT CYLINDER FORK DIS 125	Bajaj spare parts
36JZ0041	KIT DECAL COVER SIDE BL BLUE DIS 150	Bajaj spare parts
36JZ0042	KIT DECAL COVER SIDE BL RED DIS 150	Bajaj spare parts
36JZ0047	KIT DECAL COVER SIDE	Bajaj spare parts
36JZ0048	KIT DECAL COVER SIDE BL BLUE DIS 125	Bajaj spare parts
36JZ0049	KIT DECAL COVER SIDE	Bajaj spare parts
36JZ0050	KIT DECAL COVER SIDE	Bajaj spare parts
36JZ0051	KIT DECAL FAIRING BL BLUE DIS 150	Bajaj spare parts
36JZ0052	KIT DECAL FAIRING BL RED DIS 150	Bajaj spare parts
36JZ0057	KIT DECAL FAIRING BL RED DIS 125	Bajaj spare parts
36JZ0059	KIT DECAL FAIRING BL	Bajaj spare parts
36JZ0060	KIT DECAL FAIRING BL GOLD DIS 125	Bajaj spare parts
36JZ0061	KIT DECAL FAIRING 125	Bajaj spare parts
36JZ0062	KIT DEC COWL BL BLUE	Bajaj spare parts
36JZ0063	KIT DECAL SEAT COWL BL RED DIS 150	Bajaj spare parts
36JZ0064	KIT DECAL SEAT COWLBL BLUE DIS 150	Bajaj spare parts
36JZ0065	KIT DECAL SEAT COWL	Bajaj spare parts
36JZ0066	KIT DECAL SEAT COWL BL GOLD DIS 150	Bajaj spare parts
36JZ0067	KIT DECAL SEAT COWLBL MAG REDDIS 150	Bajaj spare parts
36JZ0068	KIT DECAL SEAT COWL	Bajaj spare parts
36JZ0069	KIT DECAL SEAT COWLBL BLUE DIS 125	Bajaj spare parts
36JZ0070	KIT DECAL SEAT COWLBL GOLD DIS 125	Bajaj spare parts
36JZ0071	KIT DECAL SEAT COWLBL MAG REDDIS 125	Bajaj spare parts
36JZ0072	KIT ENGINE GASKET PULSAR 135 LS	Bajaj spare parts
36JZ0074	CYL BLOCK ASSY-D125 MX	Bajaj spare parts
36JZ0075	KIT ASLY CL COVER-D125 MX	Bajaj spare parts
36JZ0078	KIT ASLY C CASE RH-D125 MX	Bajaj spare parts
36JZ0079	KIT ASLY CYL HEAD-D125 MX	Bajaj spare parts
36JZ0080	KIT CHAIN SPROCKET-D125 MX	Bajaj spare parts
36JZ0081	KIT CHAIN GUIDE-D125 MX	Bajaj spare parts
36JZ0084	KIT TANK DCL-F RED DIS H/125	Bajaj spare parts
36JZ0085	KIT SIDE CVR DCL-F RED DIS H/125	Bajaj spare parts
36JZ0086	KIT FAIRING DCL-F RED DIS H/125	Bajaj spare parts

36JZ0087	KIT S COWL DCL-F RED DIS 125	Bajaj spare parts
36JZ0088	KIT S COWL DCL-F RED DIS H	Bajaj spare parts
36JZ0089	KIT FARING DCL D102 BLK-BLUE	Bajaj spare parts
36JZ0090	KIT S COWL DCL D102 BLK-BLUE	Bajaj spare parts
36JZ0091	KIT FARING DCL D102 BLK-RED	Bajaj spare parts
36JZ0092	KIT S COWL DCL D102 BLK-RED	Bajaj spare parts
36JZ0093	KIT FARING DCL D102 BLUE	Bajaj spare parts
36JZ0094	KIT S COWL DCL D102 BLUE	Bajaj spare parts
36JZ0095	KIT FARING DCL D102 RED	Bajaj spare parts
36JZ0096	KIT S COWL DCL D102 RED	Bajaj spare parts
36JZ0097	KIT CHAIN GUIDE-D102C	Bajaj spare parts
36JZ0098	KIT BOSS KICK SET-D102C	Bajaj spare parts
36JZ0101	KIT Fairing Assly H.Ware d125st	Bajaj spare parts
36JZ0102	VALVE KIT	Bajaj spare parts
36JZ0103	CLUTCH PLATE KIT	Bajaj spare parts
36JZ0104	FR WHEEL BRG KIT	Bajaj spare parts
36JZ0106	FAIRING SCREW KIT	Bajaj spare parts
36JZ0107	KIT SEAT PIPE FR FORK-D125ST	Bajaj spare parts
36JZ0110	KIT CHAIN CASE	Bajaj spare parts
36JZ0111	KIT ASSLY CYLINDER HEAD	Bajaj spare parts
36JZ0113	KIT PISTON RING SET	Bajaj spare parts
36JZ0114	KIT BLOCK PISTON	Bajaj spare parts
36JZ0115	KIT CARB PISTON VALVE	Bajaj spare parts
36JZ0116	KIT CARB VC SCREW	Bajaj spare parts
36JZ0117	KIT CARB IDLING SCREW	Bajaj spare parts
36JZ0118	KIT CARB JET	Bajaj spare parts
36JZ0119	KIT CARB PLUNGER ASSLY	Bajaj spare parts
36JZ0120	KIT CARB O RING & GASKET	Bajaj spare parts
36JZ0121	KIT FRICTION PLATE	Bajaj spare parts
36JZ0122	KIT GUIDE CAM CHAIN-D106A	Bajaj spare parts
36JZ0123	KIT FAIRING DCL BL-RED	Bajaj spare parts
36JZ0125	KIT FAIRING DCL BLUE-BLUE	Bajaj spare parts
36JZ0126	KIT S COWL DCL-BLUE-BLUE	Bajaj spare parts
36JZ0127	KIT FAIRING DCL GR-GREEN	Bajaj spare parts
36JZ0128	KIT S COWL DCL-GR-GREEN	Bajaj spare parts
36JZ0129	KIT FAIRING DCL-RED-RED	Bajaj spare parts
36JZ0130	KIT COWL DCL-RED-RED	Bajaj spare parts
36JZ0131	KIT CHAIN SPROCKET	Bajaj spare parts
36JZ0132	KIT STARTER CLUTCH REPAIR	Bajaj spare parts
36JZ0133	COVER CLUTCH	Bajaj spare parts
36JZ0134	KIT DECAL SEAT COWL UPPER CROME	Bajaj spare parts
36JZ0135	FAIRING DCL BLACK-RED-F	Bajaj spare parts
36JZ0136	FAIRING DCL BLUE-BLUE-F	Bajaj spare parts
36JZ0137	FAIRING DCL GR-GREEN-F	Bajaj spare parts
36JZ0138	FAIRING DCL W RED-RED-F	Bajaj spare parts

36JZ0139	S COWL UPPER CROME-F	Bajaj spare parts
36JZ0140	SHOE BRAKE	Bajaj spare parts
36JZ0141	KIT SEAT COWL DECAL	Bajaj spare parts
36JZ0142	KIT FAIRING/COWLING DECAL	Bajaj spare parts
36JZ0143	KIT DCL FAIRING GOLD-FKIT DCL FAIRING GO	Bajaj spare parts
36JZ0147	KIT DCL T BL BLUE-2D	Bajaj spare parts
36JZ0148	KIT DCL T BL RED-2D	Bajaj spare parts
36JZ0149	KIT DCL T E BLU BLUE-2D	Bajaj spare parts
36JZ0150	KIT DCL T F RED RED-2D	Bajaj spare parts
36JZ0151	KIT DCL TANK -3D	Bajaj spare parts
36JZ0154	KIT DCL FAIRING BLUE BLUE-2D	Bajaj spare parts
36JZ0155	KIT DCL FAIRING RED RED-2D	Bajaj spare parts
36JZ0156	KIT DCL S COWL BL BLUE-2D	Bajaj spare parts
36JZ0157	KIT DCL S COWL BL RED-2D	Bajaj spare parts
36JZ0158	KIT DCL S COWL BLUE BLUE-2D	Bajaj spare parts
36JZ0159	KIT DCL S COWL RED RED-2D	Bajaj spare parts
36JZ0160	KIT DCL S CVR BL BLUE-2D	Bajaj spare parts
36JZ0161	KIT DCL S CVR BL RED-2D	Bajaj spare parts
36JZ0162	KIT DCL S CVR BLUE BLUE-2D	Bajaj spare parts
36JZ0163	KIT DCL S CVR RED RED-2D	Bajaj spare parts
36JZ0165	KIT CYL HEAD-D125 SIL	Bajaj spare parts
36JZ0166	KIT CYL BL-PISTON-125 SIL	Bajaj spare parts
36JZ0167	KIT ASSLY C'CASE LH	Bajaj spare parts
36JZ0168	KIT ASSLY C'CASE RH	Bajaj spare parts
36JZ0171	KIT GASKET-D125 2V	Bajaj spare parts
36JZ0172	KIT GASKET-D150SF	Bajaj spare parts
36JZ0182	CYLINDER HEAD WITH STUDS	Bajaj spare parts
36JZ0183	BLOCK PISTON KIT	Bajaj spare parts
36JZ0184	PRIMARY DRIVE GEAR & CL HOUSING	Bajaj spare parts
36JZ0185	FRICATON PLATE KIT	Bajaj spare parts
36JZ0187	PISTON VALVE ASSY KIT	Bajaj spare parts
36JZ0188	PILOT SCREW KIT	Bajaj spare parts
36JZ0189	JET KIT D101D	Bajaj spare parts
36JZ0190	FLOAT BODY ASSY KIT	Bajaj spare parts
36JZ0191	O-RING & GASKET KIT	Bajaj spare parts
36JZ0192	MIXING CAP ASSY KIT	Bajaj spare parts
36JZ0193	KIT SEAT COWL DECAL E BLACK	Bajaj spare parts
36JZ0194	KIT SEAT COWL DECAL F RED	Bajaj spare parts
36JZ0196	PLUNGER ASSLY WITH LEVER	Bajaj spare parts
36JZ0197	KIT CHAIN SPROCKET	Bajaj spare parts
36JZ0198	KIT FRICTION PLATE	Bajaj spare parts
36JZ0199	KIT CLUTCH PLATE	Bajaj spare parts
36JZ0205	KIT FRICTION PLATE+CLUTCH PLATE	Bajaj spare parts
36JZ0206	KIT ASSLY CLUTCH COVER-DIS125UG	Bajaj spare parts
36JZ0207	KIT ST. CONE-D125 M WITH GREASE	Bajaj spare parts

36JZ0218	KIT TANK DECAL EB BLK W BLUE	Bajaj spare parts
36JZ0220	KIT FAIRING DCL EB BLK W RED	Bajaj spare parts
36JZ0227	KIT SEAT COWL DCL FLAME RED	Bajaj spare parts
36PA0002	KIT GUIDE CAMCHAIN	Bajaj spare parts
36PA0003	KIT PISTON RING SET	Bajaj spare parts
36PA0004	KIT VALVE	Bajaj spare parts
36PA0006	KIT GEAR SET PRIMARY	Bajaj spare parts
36PA0011	KIT JET DISCO M	Bajaj spare parts
36PA0012	KIT AIR SCREW DISCO M	Bajaj spare parts
36PA0013	KIT IDLING SCREW DIS M	Bajaj spare parts
36PA0014	KIT THROTTLE VALVE	Bajaj spare parts
36PA0015	KIT CARB O RING DISCO M	Bajaj spare parts
36PA0042	KIT CHAIN SPROCKET DISCO	Bajaj spare parts
36PA0043	KIT CHAIN SPROCKET DISCO	Bajaj spare parts
36PA0044	KIT COV SIDE DCL GOLD	Bajaj spare parts
36PA0045	KIT COVER SIDE DECAL MAG REDDIS 100	Bajaj spare parts
36PA0046	KIT COVER SIDE DECAL BL BLUE DIS 100	Bajaj spare parts
36PA0047	KIT COVER SIDE DECAL BL RED DIS 100	Bajaj spare parts
36PA0048	KIT COV SIDE DECL BLu	Bajaj spare parts
36PA0049	KIT COVER SIDE DECAL	Bajaj spare parts
36PA0060	KIT FAIRING DECAL	Bajaj spare parts
36PA0061	KIT FAIRING DECAL MAG REDDIS 100	Bajaj spare parts
36PA0062	KIT FAIRING DECAL BL BLUE DIS 100	Bajaj spare parts
36PA0063	KIT FAIRING DECAL BL RED DIS 100	Bajaj spare parts
36PA0064	KIT FAIRING DECAL BLUE BLUE DIS 100	Bajaj spare parts
36PA0065	KIT FAIRING DECAL RED RED DIS 100	Bajaj spare parts
36PA0076	KIT SEAT COWL DECAL GOLD GREENDIS 100	Bajaj spare parts
36PA0077	KIT SEAT COWL DECAL MAG REDDIS 100	Bajaj spare parts
36PA0078	KIT SEAT COWL D.BLUE	Bajaj spare parts
36PA0079	KIT SEAT COWL DECAL BLUE	Bajaj spare parts
36PA0080	KIT SEAT COWL DECL BLU	Bajaj spare parts
36PA0081	KIT SEAT COWL DECAL RED RED DIS 100	Bajaj spare parts
36PA0092	KIT ENGINE GASKET DISCOVER 100	Bajaj spare parts
36PA0093	KIT CYL BLOCK&PISTON-D100	Bajaj spare parts
36PA0095	KIT CHAIN SPROCKET-D100 4V	Bajaj spare parts
36PA0096	KIT ASSLY CYL HEAD -D100 4V	Bajaj spare parts
36PA0098	KIT CHAIN CASE KIT-D100 4V	Bajaj spare parts
36PA0106	KIT CARB IDLING SCREW D100T	Bajaj spare parts
36PA0108	KIT CARB GASKET & O RING D100T	Bajaj spare parts
36PA0109	KIT DCL S COWL RED-D 125 T	Bajaj spare parts
36PA0110	KIT DCL S COWL BLUE-D 125 T	Bajaj spare parts
36PA0111	KIT DCL S COWL BL RED-D 125 T	Bajaj spare parts
36PA0112	KIT DCL S COWL BL BLUE-D 125 T	Bajaj spare parts
36PA0113	KIT CHAIN SPROCKET - D125 T	Bajaj spare parts
36PA0114	KIT CHAIN CASE- D125 T	Bajaj spare parts

36PA0115	KIT GUIDE CAM CHAIN-D125T	Bajaj spare parts
36PA0117	KIT DCL FAIRING-125 T BL-BLUE	Bajaj spare parts
36PA0118	KIT DCL FAIRING-125 T BL-RED	Bajaj spare parts
36PA0119	KIT DCL FAIRING-125 T BLUE	Bajaj spare parts
36PA0120	KIT DCL FAIRING-125 T RED	Bajaj spare parts
36PA0121	KIT CYL COMP FORK-D105A	Bajaj spare parts
36PA0122	KIT CHAIN CASE UPPER+LOWER	Bajaj spare parts
36PA0123	KIT CHAIN SPROCKET-D105A	Bajaj spare parts
36PA0125	KIT CARB.JET D100 M	Bajaj spare parts
36PA0126	KIT CARB SLOW JET D100 M	Bajaj spare parts
36PA0127	KIT CARB THROTTLE VALVE D100T	Bajaj spare parts
36PA0128	KIT FAIRING DCL OLIVE YELLOW	Bajaj spare parts
36PA0129	KIT FAIRING DCL BLACK CER.BLUE	Bajaj spare parts
36PA0130	KIT FAIRING DCL BLACK RED	Bajaj spare parts
36PA0132	KIT FAIRING DCL RED	Bajaj spare parts
36PA0133	KIT SIDE CVR DCL OLIVE YELLOW	Bajaj spare parts
36PA0134	KIT SIDE CVR DCL BLACK CER.BLUE	Bajaj spare parts
36PA0135	KIT SIDE CVR DCL BLACK RED	Bajaj spare parts
36PA0136	KIT SIDE COVER DCL BLUE	Bajaj spare parts
36PA0137	KIT SIDE COVER DCL RED	Bajaj spare parts
36PA0138	KIT S COWL DCL OLIVE YELLOW	Bajaj spare parts
36PA0139	KIT S COWL DCL BLACK CER.BLUE	Bajaj spare parts
36PA0140	KIT S COWL DCL BLACK RED	Bajaj spare parts
36PA0141	KIT S COWL DCL BLUE	Bajaj spare parts
36PA0142	KIT S COWL DCL RED	Bajaj spare parts
36PA0145	KIT C'CASE RH-D100 M	Bajaj spare parts
36PA0146	KIT ASLY C'CASE LH-D105A	Bajaj spare parts
36PA0152	KIT CHAIN SPROCKET - D100M	Bajaj spare parts
36PA0154	KIT PISTON VALV -D125M	Bajaj spare parts
36PA0155	KIT PILOT SCREW-D125M	Bajaj spare parts
36PA0156	KIT JET - D125M	Bajaj spare parts
36PA0157	KIT CHAIN CASE ASSL -D125M	Bajaj spare parts
36PA0159	KIT CENTRE STAND REPAIR	Bajaj spare parts
36PA0160	KIT FAIRING DCL-BLUE	Bajaj spare parts
36PA0161	KIT SIDE COVER DCL-BLUE	Bajaj spare parts
36PA0162	KIT S COWL DCL-BLUE	Bajaj spare parts
36PA0163	KIT FAIRING DCL-RED	Bajaj spare parts
36PA0164	KIT SIDE COVER DCL-RED	Bajaj spare parts
36PA0165	KIT S COWL DCL-RED	Bajaj spare parts
36PA0166	KIT FAIRING DCL-MAGENTA	Bajaj spare parts
36PA0167	KIT	Bajaj spare parts
36PA0168	KIT S COWL DCL-MAGENTA	Bajaj spare parts
36PA0169	KIT FAIRING DCL-GREEN	Bajaj spare parts
36PA0170	KIT SIDE COVER DCL-GREEN	Bajaj spare parts
36PA0171	KIT S COWL DCL-GREEN	Bajaj spare parts



36PA0172	KIT FAIRING DCL-P SIL-ICE BLUE	Bajaj spare parts
36PA0173	KIT S COVER DCL-P SIL-ICE BLUE	Bajaj spare parts
36PA0174	KIT S COWL DCL-P SIL-ICE BLUE	Bajaj spare parts
36PA0175	KIT FAIRING DCL-P SIL-GOLD BLACK	Bajaj spare parts
36PA0176	KIT S COVER DCL-P SIL-GOLD BLACK	Bajaj spare parts
36PA0177	KIT S COWL DCL-P SIL-GOLD BLACK	Bajaj spare parts
36PA0180	KIT VALVE KIT FOR DISCOVER D102B(M) -	Bajaj spare parts
36PA0184	KIT VALVE + VALVE OIL SEAL DIS 100M/ T	Bajaj spare parts
36PA0185	KIT VALVE + VALVE OIL SEAL	Bajaj spare parts
36PA0186	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
36PA0187	KIT CHAIN SPROCKET	Bajaj spare parts
36PA0188	KIT FORK CYL COMP.	Bajaj spare parts
36PA0189	KIT THROTTLE VALVE-D104A DOM	Bajaj spare parts
36PA0190	AIR CONTROL SCREW KIT D104A	Bajaj spare parts
36PA0191	GASKET O RING KIT	Bajaj spare parts
36PA0192	KIT JET- D104A	Bajaj spare parts
36PA0193	FLOAT CHAMBER SET	Bajaj spare parts
36PA0194	PLUNGER ASSY WITH LEVER KIT	Bajaj spare parts
36PA0198	KIT FAIRING DECAL EBONY BLACK	Bajaj spare parts
36PA0199	KIT FAIRING DECAL FLAME RED	Bajaj spare parts
36PA0201	KIT SEAT COWL DECAL E BLACK	Bajaj spare parts
36PA0202	KIT SEAT COWL DECAL F RED	Bajaj spare parts
36PA0204	KIT TANK DECAL EBONY BLACK	Bajaj spare parts
36PA0205	KIT TANK DECAL FLAME RED	Bajaj spare parts
36PA0206	KIT TANK DECAL BLUE	Bajaj spare parts
36PA0207	KIT FAIRING DECAL BLUE	Bajaj spare parts
36PA0208	KIT SEAT COWL DECAL BLUE	Bajaj spare parts
36PA0209	KIT SEAT COWL DECAL BLUE	Bajaj spare parts
36PA0210	KIT ASSLY CRANKCASE RH	Bajaj spare parts
36PA0211	KIT ASSLY CRANKCASE RH	Bajaj spare parts
36PA0212	KIT TANK DECAL EB GRAY	Bajaj spare parts
36PA0214	KIT SEAT COWL DCL EB GRAY	Bajaj spare parts
36PA0216	KIT ST. CONE WITH GREASE	Bajaj spare parts
36PD0001	KIT HEAD CYL WITH COVER A	Bajaj spare parts
36PD0003	KIT CHAIN SPROCKET AV 220	Bajaj spare parts
36PD0006	KIT COVER RH FLOWER	Bajaj spare parts
36PD0007	KIT ENGINE GASKET AVENGER 220	Bajaj spare parts
36PD0008	HEAD ASLY(10MM) AV220 SIL	Bajaj spare parts
36PD0009	KIT CHAIN SPROCKET-A102	Bajaj spare parts
36PD0012	KIT ASSLY CL COVER-A102	Bajaj spare parts
36PD0013	KIT ASSLY C'CASE LH-A102&102B	Bajaj spare parts
36PD0014	KIT ASSLY C'CASE RH-A102	Bajaj spare parts
36PD0015	KIT T DCL-DARK BLUE-A101	Bajaj spare parts
36PD0016	KIT T DCL-BL METALLIC-A101	Bajaj spare parts
36PD0017	KITS COVER DCL DARK BLUE-A101	Bajaj spare parts

36PD0018	KIT S CVR DCL BL METALIC-A101	Bajaj spare parts
36PD0021	KIT CHAIN SPROCKET-A101	Bajaj spare parts
36PD0022	KIT ASSLY C'CASE RH-A101	Bajaj spare parts
36PD0023	KIT ASSLY C'CASE LH-A101	Bajaj spare parts
36PD0024	KIT TANK DCL E BLACK-A102	Bajaj spare parts
36PD0027	KIT S CVR DCL E BLACK-A102	Bajaj spare parts
36PD0030	FRICITION PLATE-A101	Bajaj spare parts
36PD0031	JET-A101	Bajaj spare parts
36PD0032	VACUUM PISTON ASSLY-A101	Bajaj spare parts
36PD0033	JET-A102	Bajaj spare parts
36PD0034	VACUUM PISTON ASSLY-A102	Bajaj spare parts
36PD0035	BRAKE HOSE	Bajaj spare parts
36PD0036	BANJO BOLT	Bajaj spare parts
36PD0037	FR M/CYL ASSLY- MAJOR	Bajaj spare parts
36PD0038	FR M/CYL ASSLY- MINOR	Bajaj spare parts
36PD0040	FR M/CYL ASSLY-SWITCH	Bajaj spare parts
36PD0041	FR M/CYL ASSLY-BRAKE LEVER	Bajaj spare parts
36PD0043	CAL ASSLY (Ø28X2)-PAD SPRING	Bajaj spare parts
36PD0044	CAL ASSLY (Ø28X2)-PAD PIN	Bajaj spare parts
36PD0045	CAL BRACKET	Bajaj spare parts
36PD0046	CAL ASSLY (Ø28X2)-WEAR PAD	Bajaj spare parts
36PD0048	KIT CALIPER MINI	Bajaj spare parts
36PD0049	KIT ANCHOR PIN	Bajaj spare parts
36PD0050	KIT MASTER CYL MAJOR	Bajaj spare parts
36PD0051	KIT MASTER CYL MINOR	Bajaj spare parts
36PD0052	KIT FASTENING CAP	Bajaj spare parts
36PD0053	KIT MASTER CYL SEAL	Bajaj spare parts
36PD0054	KIT BANJO BOLT	Bajaj spare parts
36PD0055	KIT FRICTION PLATE-A102	Bajaj spare parts
36PD0056	KIT RR.NUMBER PLATE AVENGER 220 CRU	Bajaj spare parts
36PD0057	KIT ENGINE GASKET-AV 150 STREET	Bajaj spare parts
36PD0058	KIT TANK DCL GOLDEN BEIGE	Bajaj spare parts
36PD0060	KIT H/WARE HOLDER STEP-FR	Bajaj spare parts
36PD0061	KIT A101 HEAD COVER + COVER	Bajaj spare parts
36PD0062	KIT A102 HEAD COVER + COVER	Bajaj spare parts
36PD0063	KIT TANK DCL V RED	Bajaj spare parts
36PD0064	KIT TANK DCL M GREENKIT TANK DCL M GREEN	Bajaj spare parts
36PD0065	KIT TANK DECAL MATTE BLACK	Bajaj spare parts
36PD0067	KIT TANK DECAL 2D CL WHITE	Bajaj spare parts
36PD0068	KIT TANK DECAL TROPICAL NIGHT	Bajaj spare parts
36PD0069	KIT TANK DECAL C WHITE	Bajaj spare parts
36PD0070	KIT TANK DECAL SPICY RED	Bajaj spare parts
36PD0071	KIT TANK DECAL E BLACK	Bajaj spare parts
36PD0072	KIT FR BR SYSTEM HOSE	Bajaj spare parts
36PD0073	KIT FR BR SYSTEM HOSE	Bajaj spare parts

36PD0074	VACUUM PISTON ASSY KIT	Bajaj spare parts
36PD0075	JET KIT	Bajaj spare parts
36PD0079	FRAME ASSLY	Bajaj spare parts
36PD0081	KIT AIR FIL ELEMENT & CVR O RING	Bajaj spare parts
36PD0083	KIT CYL HEAD A101 PD511018	Bajaj spare parts
36PD0084	KIT CYL HEAD A101 PD511021	Bajaj spare parts
36PD0087	FASTENING CAP KIT	Bajaj spare parts
36PD0089	HOSE ASSLY-MC TO ABS UNIT	Bajaj spare parts
36PD0090	HOSE ASSLY-ABS UNIT TO CALIPER	Bajaj spare parts
36PD0094	HOSE ASSLY-MC TO ABS UNIT	Bajaj spare parts
36PD0096	KIT PISTON RINGS	Bajaj spare parts
36PD0098	KIT CHAIN SPROCKET	Bajaj spare parts
36PD0099	KIT BLOCK PISTON	Bajaj spare parts
36PD0100	VACCUM PISTON ASSL BKPV475	Bajaj spare parts
36PD0101	CARBURETOR JET KIT BKJET476	Bajaj spare parts
36PD0102	KIT HEAD CYLINDER-COVER	Bajaj spare parts
36PD0104	KIT BLOCK PISTON	Bajaj spare parts
36PD0105	KIT PISTON RING SET	Bajaj spare parts
36PD0109	KIT BRAKE HOSE - ETL ABS	Bajaj spare parts
36PD0110	KT HOSE M/C TO ABS UNIT ETL ABS	Bajaj spare parts
36PD0111	KIT HOSE CALIPER TO ABS UNIT ETL	Bajaj spare parts
36PD0112	3 IN 1 SENSOR KIT	Bajaj spare parts
36PD0113	ACCESSORY KIT AVENGER STREET	Bajaj spare parts
36PD0114	Accessory kit Avenger 220	Bajaj spare parts
36PF0001	HAED CYL BM150	Bajaj spare parts
36PF0002	CYL BLOCK ASSLY BM150	Bajaj spare parts
36PF0004	CRANKCASE LH BM150	Bajaj spare parts
36PF0005	CRANKCASE RH BM150	Bajaj spare parts
36PF0007	COVER NAGNETO BM150	Bajaj spare parts
36PF0008	COVER CLUTCH BM150	Bajaj spare parts
36PF0009	KIT FRICTION PLATE BM150	Bajaj spare parts
36PF0010	KIT CHAIN SPROCKET BM150	Bajaj spare parts
36PF0011	KIT CHAIN CASE	Bajaj spare parts
36PF0017	KIT TANK DCL BLACK BM 150	Bajaj spare parts
36PF0021	KIT JET BM150	Bajaj spare parts
36PF0022	KIT PISTON VALUE BM150	Bajaj spare parts
36PF0023	KIT CHOKE PLUNGER BM150	Bajaj spare parts
36PF0024	KIT CARBURETTOR GASKET / O RING	Bajaj spare parts
36PF0025	KIT SILENCER W/O SHIELD-B150	Bajaj spare parts
36PF0037	KIT ASSLY CYL HEAD BM100	Bajaj spare parts
36PF0038	KIT ASSLY CRANKCASE LH (ES)	Bajaj spare parts
36PF0042	CARB JET PL-B104DCARB JET PL-B104D	Bajaj spare parts
36PF0043	KIT CHAIN CASE - PL B104D	Bajaj spare parts
36PF0044	ASLY CYL HEAD-PL B104DASLY CYL HEAD-PL B	Bajaj spare parts
36PF0045	BLOCK PISTON-B104DBLOCK PISTON-B104D	Bajaj spare parts

36PF0046	ASSLY CL COVER-B104DASSLY CL COVER-B104D	Bajaj spare parts
36PF0047	VALVE REPAIR-B104DVALVE REPAIR-B104D	Bajaj spare parts
36PF0048	VALVE IN + EX-B104DVALVE IN + EX-B104D	Bajaj spare parts
36PF0049	KIT FAIRING DCL-C RED	Bajaj spare parts
36PF0050	KIT FAIRING DCL-EL BLUE	Bajaj spare parts
36PF0051	KIT FAIRING DCL-E BLACK	Bajaj spare parts
36PF0052	KIT TANK DCL-C RED	Bajaj spare parts
36PF0053	KIT TANK DCL-EL BLUE	Bajaj spare parts
36PF0054	KIT TANK DCL-E BLACK	Bajaj spare parts
36PF0055	KIT S COVER DCL-C RED	Bajaj spare parts
36PF0056	KIT S COVER DCL-EL BLUE	Bajaj spare parts
36PF0057	KIT S COVER DCL-E BLACK	Bajaj spare parts
36PF0058	KIT S COWL DCL-C RED	Bajaj spare parts
36PF0059	KIT S COWL DCL-EL BLUE	Bajaj spare parts
36PF0060	KIT COWL DCL-E BLACK	Bajaj spare parts
36PF0061	KIT CAM CHAIN GUIDE	Bajaj spare parts
36PF0062	KIT PISTON RING SET	Bajaj spare parts
36PF0063	S COWL DCL-C RED KS	Bajaj spare parts
36PF0064	S COWL DCL-EL BLUE KS	Bajaj spare parts
36PF0065	S COWL DCL-E BLACK KS	Bajaj spare parts
36PF0066	KIT DCL FAIRING-S GRAY	Bajaj spare parts
36PF0067	KIT DCL S COVER-S GRAY	Bajaj spare parts
36PF0068	KIT DCL S COWL-S GRAY (ES)	Bajaj spare parts
36PF0069	KIT DCL S COWL-S GRAY (KS)	Bajaj spare parts
36PF0070	KIT DCL TANK-S GRAY	Bajaj spare parts
36PF0071	KIT FAIRING DCL A WHITE	Bajaj spare parts
36PF0072	KIT TANK DCL A WHITE	Bajaj spare parts
36PF0073	KIT SIDE CVR DCL A WHITE	Bajaj spare parts
36PF0074	KIT S COWL DCL A WHITE	Bajaj spare parts
36PF0075	KIT GASKET-PL 100ES	Bajaj spare parts
36PF0086	KIT FRICTION PLATE MAKINO	Bajaj spare parts
36PF0087	KIT CLUTCH PLATE MAKINO	Bajaj spare parts
36PF0088	KIT PRIMARY DRIVE	Bajaj spare parts
36PF0089	KIT FAIRING DCL EL BLUE	Bajaj spare parts
36PF0090	KIT FAIRING DCL E BL	Bajaj spare parts
36PF0091	KIT FAIRING DCL FL RED	Bajaj spare parts
36PF0092	KIT TANK DCL EL BLUE	Bajaj spare parts
36PF0093	KIT TANK DCL E BL	Bajaj spare parts
36PF0094	KIT TANK DCL FL RED	Bajaj spare parts
36PF0095	KIT S COVER DCL EL BLUE	Bajaj spare parts
36PF0096	KIT S COVER DCL E BL	Bajaj spare parts
36PF0097	KIT S COVER DCL FL RED	Bajaj spare parts
36PF0098	KIT SEAT C DCL EL BLUE-KS	Bajaj spare parts
36PF0099	KIT SEAT C DCL E BLACK-KS	Bajaj spare parts
36PF0100	KIT SEAT C DCL FL RED-KS	Bajaj spare parts

36PF0101	KIT SEAT C DCL EL BLUE-KS	Bajaj spare parts
36PF0102	KIT SEAT C DCL E BLACK-KS	Bajaj spare parts
36PF0103	KIT SEAT C DCL FL RED-KS	Bajaj spare parts
36PF0110	KIT CARB TOP COMP-B104D BS-IV	Bajaj spare parts
36PF0112	ASSLY CYL HEAD WITH STUD-PF	Bajaj spare parts
36PF0113	FORK CYL COMPLETE	Bajaj spare parts
36PF0118	KIT PISTON RINGS MAKE-SAMKRG	Bajaj spare parts
36PF0119	KIT FAIRING DECAL BLUE	Bajaj spare parts
36PF0120	KIT FAIRING DECAL BLACK	Bajaj spare parts
36PF0121	KIT FAIRING DECAL RED	Bajaj spare parts
36PF0122	KIT TANK DECAL BLUE	Bajaj spare parts
36PF0123	KIT TANK DECAL BLACK	Bajaj spare parts
36PF0124	KIT TANK DECAL RED	Bajaj spare parts
36PF0125	KIT SEAT COWL DECAL BLUE	Bajaj spare parts
36PF0126	KIT SEAT COWL DECAL BLACK	Bajaj spare parts
36PF0127	KIT SEAT COWL DECAL RED	Bajaj spare parts
36PF0128	KIT ASSLY CRANKCASE LH	Bajaj spare parts
36PF0130	KIT GASKET- PL 100ES	Bajaj spare parts
36PF0132	KIT ASSLY CYLINDER HEAD	Bajaj spare parts
36PF0133	KIT THROTTLE VALVE-B106C	Bajaj spare parts
36PF0134	AIR CONTROL SCREW KIT-B106C	Bajaj spare parts
36PF0135	KIT JET- B106C	Bajaj spare parts
36PF0138	KIT L G +S G+HW PL 100KS	Bajaj spare parts
36PF0143	PISTON VALVE ASSY KIT	Bajaj spare parts
36PF0144	AIR SCREW KIT	Bajaj spare parts
36PF0145	IDLING ADJUSTER KIT	Bajaj spare parts
36PF0146	JET KIT	Bajaj spare parts
36PF0147	FLOAT BODY ASSY KIT	Bajaj spare parts
36PF0148	O-RING & GASKET KIT	Bajaj spare parts
36PF0149	MIXING CAP ASSY KIT	Bajaj spare parts
36PF0150	KIT SEAT COWL DCL ELECTRON BLUE	Bajaj spare parts
36PF0151	KIT SEAT COWL DCL EB RED	Bajaj spare parts
36PF0152	KIT SEAT COWL DCL CW RED	Bajaj spare parts
36PF0157	JET KIT-BK-JET-484	Bajaj spare parts
36PF0158	KIT CLUTCH COVER CT110	Bajaj spare parts
36PF0161	KIT CL COVER PL SILVER	Bajaj spare parts
36PF0165	PISTON VALVE ASSY KIT-BK-PV-496	Bajaj spare parts
36PF0166	PILOT SCREW KIT-BK-PS-497	Bajaj spare parts
36PF0167	IDLING ADJUSTER KIT-BK-SRA-498	Bajaj spare parts
36PF0168	JET KIT -BK-JET-499	Bajaj spare parts
36PF0169	FLOAT BODY ASSY KIT-BK-FCB-500	Bajaj spare parts
36PF0170	TOP CAP ASSY KIT-BK-TC-481	Bajaj spare parts
36PF0171	O-RING & GASKET KIT-BK-OG-501	Bajaj spare parts
36PF0172	STARTER KIT-BK-ST-502	Bajaj spare parts
36PF0173	PISTON VALVE ASSY KIT-BK-PV-503	Bajaj spare parts

36PF0174	JET KIT -BK-JET-504	Bajaj spare parts
36PF0175	KIT FAIRNG DCL ELECTRON BLUE	Bajaj spare parts
36PF0176	KIT FAIRING DECAL BLACK	Bajaj spare parts
36PF0177	KIT FAIRING DECAL RED	Bajaj spare parts
36PF0178	AIR SOLENOID ASSLY KIT-BK-TC-481	Bajaj spare parts
36PF0179	KIT TANK DCL BLACK GREY	Bajaj spare parts
36PF0180	KIT COWLING DCL BLACK GREY	Bajaj spare parts
36PF0181	KIT TANK DCL BLACK RED	Bajaj spare parts
36PF0182	KIT COWLING DCL BLACK RED	Bajaj spare parts
36PF0183	STARTER PLUNGER KIT BKST474	Bajaj spare parts
36PF0184	KIT BLOCK-PISTON BS6	Bajaj spare parts
36PF0202	KIT DECAL FAIRING E BLK M RED	Bajaj spare parts
36PF0203	KIT DECAL FAIRING E BLACK BRASS	Bajaj spare parts
36PF0204	KIT DECAL FAIRING E BLACK BLUE	Bajaj spare parts
36PF0205	KIT DCL TANK E BLACK BLUE	Bajaj spare parts
36PF0206	KIT DCL TANK E BLACK B	Bajaj spare parts
36PF0207	KIT DCL TANK E BLK M RED	Bajaj spare parts
36PF0208	KIT DCL COWL SEAT BLACK M RED	Bajaj spare parts
36PF0209	KIT DCL COWL SEAT BLACK BLUE	Bajaj spare parts
36PF0210	KIT DCL COWL SEAT BRASS	Bajaj spare parts
36PF0216	KIT FRICTION PLATE	Bajaj spare parts
36RA0001	BLOCK PISTON ASSLY LPG - 236	Bajaj spare parts
36RA0002	FRICTION PLATE KIT- 236	Bajaj spare parts
36RA0003	VALVE KIT 4S - 236	Bajaj spare parts
36RA0004	KIT PISTON VALVE ASSLY MAX Z 4S	Bajaj spare parts
36RA0006	JET KIT- MAXIMA Z 4S	Bajaj spare parts
36RA0007	KIT FLOT CHAMBER BODY-MAX Z 4S	Bajaj spare parts
36RA0011	KIT LOCK LID COVER WITH KEY	Bajaj spare parts
36RA0012	MATRIX FILTER ELEMENT-O RING	Bajaj spare parts
36RA0013	CYL BLOCK PISTON ASSLY- PL,LPG	Bajaj spare parts
36RA0014	ASSLY CYL. HEAD _ VALVE BS6	Bajaj spare parts
36RA0015	KIT VALVE 4S 236 BS6	Bajaj spare parts
37004375	TOOL XC_2 DIAGNOSTIC TOOL	Bajaj spare parts
37204046	Pigtail - stator to harness connection f	Bajaj spare parts
39004401	SCREW	Bajaj spare parts
39007104	BOLT HEXAGON HEAD :- M5	Bajaj spare parts
39008004	BOLT HEX HEAD M10 X 25L	Bajaj spare parts
39008904	BOLT 'D' M7 M7 X 49L	Bajaj spare parts
39011904	BOLT HEX HEAD M8 X 16L	Bajaj spare parts
39013205	STUD M7	Bajaj spare parts
39016109	RIVET - COUNTERSUNK HEAD	Bajaj spare parts
39019711	WASHER PLAIN	Bajaj spare parts
39019811	WASHER PLAIN	Bajaj spare parts
39019911	WASHER PLAIN	Bajaj spare parts
39020011	WASHER - PLAIN sil mtg	Bajaj spare parts

39020111	WASHER PLAIN	Bajaj spare parts
39020811	WASHER PLAIN	Bajaj spare parts
39020911	WASHER - PLAIN	Bajaj spare parts
39021111	WASHER PLAIN	Bajaj spare parts
39021311	WASHER PLAIN	Bajaj spare parts
39021911	WASHER PLAIN	Bajaj spare parts
39023011	WASHER PLAIN	Bajaj spare parts
39023911	WASHER PLAIN	Bajaj spare parts
39024011	WASHER PLAIN	Bajaj spare parts
39024211	WASHER PLAIN	Bajaj spare parts
39024811	PLAIN WASHER	Bajaj spare parts
39025111	WASHER PLAIN	Bajaj spare parts
39025411	WASHER PLAIN	Bajaj spare parts
39025811	WASHER PLAIN	Bajaj spare parts
39026312	WASHER SPRING 6.1X11.8X1.	Bajaj spare parts
39026512	WASHER SPRING	Bajaj spare parts
39026612	WASHER SPRING	Bajaj spare parts
39026712	WASHER SPRING	Bajaj spare parts
39026912	WASHER SPRING	Bajaj spare parts
39028715	NUT HEXAGON M4 X 0.7	Bajaj spare parts
39028915	HEXAGON NUT-M8 X 1.25	Bajaj spare parts
39029115	NUT HEXAGON M5 X 0.8	Bajaj spare parts
39029215	NUT HEXAGON M6 X 1	Bajaj spare parts
39029515	NUT HEXAGON M9 X 1.25	Bajaj spare parts
39029615	NUT HEXAGON M10	Bajaj spare parts
39030215	HEXAGON NUT-M10X1.5	Bajaj spare parts
39030315	NUT HEXAGON M14 X 1.5	Bajaj spare parts
39031215	NUT - HEXAGON :- M10 X 1.5 SIL	Bajaj spare parts
39032615	NUT NYLOC M5 X 0.8	Bajaj spare parts
39033717	CIRCLIP EXTERNAL	Bajaj spare parts
39034017	CIRCLIP INTERNAL	Bajaj spare parts
39034217	CIRCLIP INTERNAL	Bajaj spare parts
39037511	WASHER PLAIN	Bajaj spare parts
39039004	SCREW HEX M8 X 25L	Bajaj spare parts
39042215	NUT NYLOC M10	Bajaj spare parts
39042606	PIN SPRING	Bajaj spare parts
39042706	PIN SPRING	Bajaj spare parts
39042817	CIRCLIP INTERNAL	Bajaj spare parts
39043501	SCREW HEX HEAD M8 X 20L	Bajaj spare parts
39044706	SPRING TYPE STRT.PIN	Bajaj spare parts
39045104	BOLT	Bajaj spare parts
39045411	WASHER PLAIN	Bajaj spare parts
39045506	PIN - SPRING TYPE STRAIGHT	Bajaj spare parts
39046204	BOLT HEX M8 X 1.25 M8 X	Bajaj spare parts
39046715	NUT HEXAGON M12 X 1.5	Bajaj spare parts

39050809	RIVET COUNTERSUNK HEAD	Bajaj spare parts
39052611	WASHER	Bajaj spare parts
39054311	WASHER PLAIN	Bajaj spare parts
39055302	SCREW SELF TAPPING MAB6	Bajaj spare parts
39058915	NUT HEXAGON WELD M	Bajaj spare parts
39059015	NUT HEX WELD M5X.8	Bajaj spare parts
39059417	CIRCLIP INTERNAL	Bajaj spare parts
39064517	CIRCLIP :- E-TYPE	Bajaj spare parts
39066301	SCREW SLOTTED CH HEAD M5	Bajaj spare parts
39068205	STUD M6 FOR CYLINDER BLOC	Bajaj spare parts
39068405	STUD M7 FOR CYLINDER HEAD	Bajaj spare parts
39069015	NUT NYLOC M8	Bajaj spare parts
39069415	NUT HEXAGON LOCK M8 X 1.	Bajaj spare parts
39070201	SCREW PAN CROSS M6 M6 X	Bajaj spare parts
39070311	WASHER PLAIN	Bajaj spare parts
39070501	SCREW M5 M5 X 10L	Bajaj spare parts
39070815	NUT HEXAGON M10 X1.25	Bajaj spare parts
39071111	WASHER PLAIN	Bajaj spare parts
39071215	NUT DOMED CAP M12	Bajaj spare parts
39071411	WASHER PLAIN	Bajaj spare parts
39071601	SCREW PAN CROSS M5 M5 X	Bajaj spare parts
39072211	WASHER	Bajaj spare parts
39073001	SCREW PAN CROSS M6 M6 X 3	Bajaj spare parts
39073212	WASHER - SPRING	Bajaj spare parts
39073712	WASHER SPRING	Bajaj spare parts
39073817	CIRCLIP EXTERNAL	Bajaj spare parts
39074011	WASHER NONMETALLIC	Bajaj spare parts
39074301	SCREW CSK M6 M6 X 20L	Bajaj spare parts
39074501	SCREW PAN CROSS M6 M6 X	Bajaj spare parts
39074601	SCREW PAN CROSS	Bajaj spare parts
39074701	SCREW PAN CROSS M6 M6 X	Bajaj spare parts
39074801	SCREW PAN CROSS M6 M6 X	Bajaj spare parts
39075201	SCREW CSK M6 M6 X 16L	Bajaj spare parts
39075301	SCREW PAN CROSS M6 M6 X	Bajaj spare parts
39075601	SCREW PAN CROSS M6 M6 X	Bajaj spare parts
39075801	SCREW PAN CROSS	Bajaj spare parts
39076101	SCREW PAN CROSS M5 M5 X	Bajaj spare parts
39077504	BOLT - HEXAGON :- M6 X 1	Bajaj spare parts
39078211	WASHER PLAIN	Bajaj spare parts
39078708	PIN COTTER	Bajaj spare parts
39078912	WASHER SPRING	Bajaj spare parts
39079415	NUT HEXAGON FINE M10 X 1	Bajaj spare parts
39079708	PIN COTTER	Bajaj spare parts
39079815	NUT HEXAGON FLANGE M6	Bajaj spare parts
39079908	PIN COTTER	Bajaj spare parts



39080115	NUT HEXAGON M20 X 1	Bajaj spare parts
39080204	BOLT SQUARE M8 X 36L	Bajaj spare parts
39080411	WASHER PLAIN	Bajaj spare parts
39080511	PLAIN WASHER	Bajaj spare parts
39080708	PIN SNAP	Bajaj spare parts
39080808	PIN SPLIT	Bajaj spare parts
39081302	SCREW	Bajaj spare parts
39081411	WASHER PLAIN	Bajaj spare parts
39081715	NUT HEXAGON FLANGE M6	Bajaj spare parts
39083001	SCREW PAN CROSS	Bajaj spare parts
39083415	NUT HEXAGON M6 X 1	Bajaj spare parts
39084001	SCREW PAN CROSS M4 M4 X	Bajaj spare parts
39084914	WASHER LOCK TOOTHED	Bajaj spare parts
39085517	CIRCLIP ETYPE	Bajaj spare parts
39086411	WASHER PLAIN	Bajaj spare parts
39089704	BOLT HEX HEAD M6 X 10L	Bajaj spare parts
39091715	NUT HEXAGON M7 X 1	Bajaj spare parts
39092101	SCREW PAN CROSS M4	Bajaj spare parts
39093915	NUT HEX. NYLOC	Bajaj spare parts
39094111	PLAIN WASHER	Bajaj spare parts
39095615	NUT HEXAGON M8 X 1.25	Bajaj spare parts
39096315	NUT DOMED CAP M6	Bajaj spare parts
39097204	BOLT SOCKET M6	Bajaj spare parts
39097315	NUT HEXAGON M5 X 0.5	Bajaj spare parts
39097804	BOLT 'D' M10 M10 X 36L	Bajaj spare parts
39098004	BOLT - HEXAGON HEAD-clutch assly	Bajaj spare parts
39098308	PIN SNAP	Bajaj spare parts
39098717	RING SNAP	Bajaj spare parts
39099206	DOWEL	Bajaj spare parts
39099311	WASHER PLAIN	Bajaj spare parts
39099511	WASHER PLAIN	Bajaj spare parts
39099906	PIN HOLLOW DOWEL	Bajaj spare parts
39100006	PIN HOLLOW DOWEL	Bajaj spare parts
39100120	BEARING BALL	Bajaj spare parts
39100320	BEARING BALL 17X 35X10	Bajaj spare parts
39100420	BEARING BALL 10X30 X9	Bajaj spare parts
39100820	BEARING NEEDLE	Bajaj spare parts
39101004	BOLT	Bajaj spare parts
39101101	SCREW M6 M6 X 10L	Bajaj spare parts
39101321	RING O	Bajaj spare parts
39101421	RING O	Bajaj spare parts
39101621	RING O	Bajaj spare parts
39101721	RING O	Bajaj spare parts
39101921	RING O	Bajaj spare parts
39102021	RING O	Bajaj spare parts

39102121	RING O	Bajaj spare parts
39102304	BOLT	Bajaj spare parts
39102702	SCREW CROSS CHEESE MAB6	Bajaj spare parts
39102821	RING O	Bajaj spare parts
39103309	RIVET	Bajaj spare parts
39103519	SEAL OIL	Bajaj spare parts
39104011	WASHER PLAIN	Bajaj spare parts
39104119	SEAL OIL	Bajaj spare parts
39104219	SEAL OIL	Bajaj spare parts
39104319	SEAL OIL	Bajaj spare parts
39104619	SEAL OIL	Bajaj spare parts
39105006	PIN HOLLOW DOWEL	Bajaj spare parts
39105315	NUT HEXAGON FLANGE M14	Bajaj spare parts
39105411	WASHER PLAIN	Bajaj spare parts
39105515	NUT HEXAGON FLANGE M10	Bajaj spare parts
39105711	WASHER PLAIN	Bajaj spare parts
39106504	BOLT FLANGED SMALL M6 X 4	Bajaj spare parts
39106901	SCREW HEX HEAD M6 X 25L	Bajaj spare parts
39107001	SCREW - HEXAGON HEAD EX. Tube	Bajaj spare parts
39107404	BOLT FLANGED SMALL M6 X 3	Bajaj spare parts
39107504	BOLT FLANGED SMALL M6 X 3	Bajaj spare parts
39107801	SCREW PAN CROSS - M6	Bajaj spare parts
39107901	SCREW HEX HEAD	Bajaj spare parts
39108019	SEAL OIL	Bajaj spare parts
39118011	WASHER PLAIN	Bajaj spare parts
39118215	NUT	Bajaj spare parts
39118415	NUT NYLOC M5 X 0.8	Bajaj spare parts
39119704	BOLT SOCKET M6 M6 X 20L	Bajaj spare parts
39121111	WASHER PLAIN	Bajaj spare parts
39121420	BEARING BALL 20X42X12	Bajaj spare parts
39122411	WASHER PLAIN	Bajaj spare parts
39122515	NUT HEXAGON FLANGE M10	Bajaj spare parts
39126321	RING O	Bajaj spare parts
39126421	RING O	Bajaj spare parts
39127121	RING O	Bajaj spare parts
39128321	RING O	Bajaj spare parts
39129004	BOLT - HEXAGON :- M6 X 1	Bajaj spare parts
39129804	SCREW HEX SOCKET HEAD M8	Bajaj spare parts
39130911	WASHER PLAIN	Bajaj spare parts
39132420	BEARING BALL 25 X62X17	Bajaj spare parts
39133615	NUT HEGON M10 X 1.25	Bajaj spare parts
39134620	BEARING ROLER BIG EN	Bajaj spare parts
39135315	NUT - NYLOC :hl hsg check plte	Bajaj spare parts
39135519	SEAL OIL CLUTCH SIDE	Bajaj spare parts
39135815	NUT HEXAGON FLANGE M12	Bajaj spare parts

39136420	BEARING BALL 12X 32X10	Bajaj spare parts
39137704	BOLT HEX + COLLAR	Bajaj spare parts
39138904	BOLT HEX M8 X 1.25 M8 X	Bajaj spare parts
39139604	BOLT HEX M10 X 1.5 M10 X	Bajaj spare parts
39142305	STUD M8	Bajaj spare parts
39143020	BEARING BALL 6	Bajaj spare parts
39143104	BOLT 'D' M8 M8 X 50L	Bajaj spare parts
39143520	BEARING NEEDLE	Bajaj spare parts
39143620	BEARING NEEDLE	Bajaj spare parts
39144525	RING SEALING	Bajaj spare parts
39145220	BEARING NEEDLE	Bajaj spare parts
39147817	CIRCLIP WIRE	Bajaj spare parts
39148720	BEARING BALL 30 X55 X9	Bajaj spare parts
39149315	NUT HEXAGON M12 X 1.25	Bajaj spare parts
39149721	RING O	Bajaj spare parts
39149819	SEAL OIL	Bajaj spare parts
39149919	SEAL OIL	Bajaj spare parts
39150611	WASHER PLAIN	Bajaj spare parts
39150711	Washer (Oil cooler mtg.)	Bajaj spare parts
39150811	PLAIN WASHER	Bajaj spare parts
39151011	WASHER PLAIN	Bajaj spare parts
39152301	SCREW PAN CROSS M5	Bajaj spare parts
39152401	SCREW PAN CROSS M5 M5 X	Bajaj spare parts
39153419	SEAL OIL 25 X 45 X 7	Bajaj spare parts
39153519	SEAL OIL 20 X 35 X 7	Bajaj spare parts
39153721	RING O	Bajaj spare parts
39154704	BOLT HEXAGON HEAD :- M8	Bajaj spare parts
39154905	STUD M8	Bajaj spare parts
39155104	BOLT FLANGE	Bajaj spare parts
39155304	BOLT FLANGE M6 M6 X 25L	Bajaj spare parts
39155504	BOLT FLANGE M6 X 60L	Bajaj spare parts
39155604	BOLT FLANGE M8 X 16L	Bajaj spare parts
39156015	NUT - HEXAGON WITH FLANGE :- M4	Bajaj spare parts
39156121	RING O	Bajaj spare parts
39156221	RING O	Bajaj spare parts
39156421	RING O	Bajaj spare parts
39156706	SLEEVE SPRING DOWEL	Bajaj spare parts
39156806	SLEEVE - SPRING DOWEL	Bajaj spare parts
39156906	SLEEVE - SPRING DOWEL	Bajaj spare parts
39157006	SLEEVE SPRING DOWEL	Bajaj spare parts
39157217	CIRCLIP EXTERNAL	Bajaj spare parts
39157311	WASHER PLAIN	Bajaj spare parts
39157704	SCREW HEXAGON HEAD	Bajaj spare parts
39157915	NUT - HEXAGON :- M8 X 1.25	Bajaj spare parts
39158015	NUT - HEXAGON :- M6 X 1	Bajaj spare parts

39158211	WASHER PLAIN	Bajaj spare parts
39158511	WASHER PLAIN	Bajaj spare parts
39158721	RING O	Bajaj spare parts
39158821	RING O	Bajaj spare parts
39160804	BOLT HEX SOCKET M10X1.5 M	Bajaj spare parts
39161211	WASHER PLAIN	Bajaj spare parts
39162011	WASHER PLAIN 10 X 20	Bajaj spare parts
39163015	NUT HEXAGON FLANGE M6	Bajaj spare parts
39163505	STUD M8	Bajaj spare parts
39165305	STUD - M7	Bajaj spare parts
39165721	RING O	Bajaj spare parts
39165805	STUD - M7	Bajaj spare parts
39165911	WASHER PLAIN	Bajaj spare parts
39166005	STUD M8	Bajaj spare parts
39166404	HEXAGON BOLT	Bajaj spare parts
39166511	WASHER-SEAL 6	Bajaj spare parts
39167121	RING O	Bajaj spare parts
39167204	BOLT FLANGE M6 X 16 M6 X	Bajaj spare parts
39167304	BOLT FLANGE M6 M6 X 20L	Bajaj spare parts
39167404	BOLT FLANGE M6 X 25 M6 X	Bajaj spare parts
39167504	BOLT FLANGE M6	Bajaj spare parts
39167604	BOLT FLANGE M6 X 50 M6 X	Bajaj spare parts
39167704	BOLT M6 X 45 M6 X 45L	Bajaj spare parts
39168004	BOLT FLANGE M6 M6 X 12L	Bajaj spare parts
39168304	BOLT FLANGE M8 X 40L	Bajaj spare parts
39168606	PIN - HOLLOW DOWEL	Bajaj spare parts
39168904	BOLT - FLANGE	Bajaj spare parts
39169801	SCREW PAN M5 M5 X 12L	Bajaj spare parts
39169901	SCREW CSK M6 M6 X 12L	Bajaj spare parts
39170207	PIN CLEVIS WITH HEAD	Bajaj spare parts
39170415	NUT CUP M6	Bajaj spare parts
39170704	BOLT HEX M10 X 1.5 M10 X	Bajaj spare parts
39171404	BOLT FLANGED	Bajaj spare parts
39171519	SEAL OIL	Bajaj spare parts
39171619	SEAL OIL	Bajaj spare parts
39171905	STUD	Bajaj spare parts
39172104	BOLT FLANGED M6 X 88L	Bajaj spare parts
39172420	BEARING BALL 15 X	Bajaj spare parts
39172711	GASKET	Bajaj spare parts
39173719	SEAL OIL 26 X 42 X 8	Bajaj spare parts
39173821	RING O	Bajaj spare parts
39174004	BOLT SH. 6 X 85	Bajaj spare parts
39174419	SEAL OIL	Bajaj spare parts
39175904	BOLT SH 6 X 55 M6 X 55L	Bajaj spare parts
39176511	WASHER PLAIN	Bajaj spare parts

39176601	SCREW PAN CROSS M5 M5 X	Bajaj spare parts
39176904	BOLT FLANGED M8 M8 X 30L	Bajaj spare parts
39177102	SCREW TAPPING 5 X 16	Bajaj spare parts
39177304	BOLT HEX + FLANGE M5 M5 X	Bajaj spare parts
39177802	SCREW TAPPING	Bajaj spare parts
39177902	SCREW TAPPING 4 X 10	Bajaj spare parts
39178001	SCREW PAN M5 M5 X 8L	Bajaj spare parts
39178101	SCREW TRUSS M6	Bajaj spare parts
39178301	SCREW TRUSS M5	Bajaj spare parts
39178924	WASHER NYLON	Bajaj spare parts
39179021	RING O	Bajaj spare parts
39179104	BOLT - M6	Bajaj spare parts
39179211	WASHER - PLAIN	Bajaj spare parts
39179611	WASHER PLAIN	Bajaj spare parts
39180204	BOLT - HEXAGON SOCKET HEAD :- M6	Bajaj spare parts
39181304	BOLT -HEX. : M	Bajaj spare parts
39181404	BOLT FLANGED M8 X 40L	Bajaj spare parts
39182512	WASHER SPRING	Bajaj spare parts
39182612	WASHER - SPRING	Bajaj spare parts
39182712	WASHER - SPRING	Bajaj spare parts
39182812	WASHER SPRING	Bajaj spare parts
39182912	WASHER SPRING	Bajaj spare parts
39183012	WASHER SPRING	Bajaj spare parts
39183911	WASHER PLAIN	Bajaj spare parts
39184401	SCREW PAN CROSS M5	Bajaj spare parts
39184504	HEX.BOLT WITH FLANGE	Bajaj spare parts
39184904	BOLT HEX HEAD+FLA M10 M10	Bajaj spare parts
39185004	BOLT HEX + FLANGE M10 X 50L	Bajaj spare parts
39186101	SCREWCROS COUNTERSUNK M4 M4 X 30L	Bajaj spare parts
39186420	BEARING BALL 20X52 X15	Bajaj spare parts
39186919	SEAL OIL 15 X 24 X 5	Bajaj spare parts
39187019	SEAL OIL 33 X 50 X 6.5	Bajaj spare parts
39187105	STUD M6	Bajaj spare parts
39187411	PLAIN WASHER	Bajaj spare parts
39188020	BEARING BALL15 X 32X9	Bajaj spare parts
39188515	NUT HEXAGON FLANGE M16	Bajaj spare parts
39190204	BOLT FLANGED M6	Bajaj spare parts
39190701	SCREW TRUSS CROSS	Bajaj spare parts
39191204	BOLT FLANGED	Bajaj spare parts
39191719	SEAL OIL	Bajaj spare parts
39192707	PIN ROLLER	Bajaj spare parts
39193120	BEARING BALL 28	Bajaj spare parts
39193717	CIRCLIP	Bajaj spare parts
39193815	NUT HEXAGON FLANGE M16	Bajaj spare parts
39194004	BOLT FLANGED M8 M8 X 14L	Bajaj spare parts

39194304	BOLT FLANGE M6 1 14 MM	Bajaj spare parts
39194404	BOLT FLANGED	Bajaj spare parts
39194604	BOLT FLANHGGE M8	Bajaj spare parts
39195404	BOLT FLANGE M6*10	Bajaj spare parts
39195604	BOLT FLANGED SMALL M8 X 2	Bajaj spare parts
39195804	BOLT FLANGED SMALL M6 X 1	Bajaj spare parts
39196304	BOLT FLANGED	Bajaj spare parts
39196704	BOLT	Bajaj spare parts
39197015	NUT HEXAGON FLANGE M8	Bajaj spare parts
39197215	NUT HEX. WITH FLANGEM	Bajaj spare parts
39198104	BOLT HEX SOCKET M5 M5 X 1	Bajaj spare parts
39198820	BEARING - BALL- 12 X 28 X 8	Bajaj spare parts
39199020	BEARING NEEDLE	Bajaj spare parts
39199404	BOLT UPSET M6	Bajaj spare parts
39199819	SEAL OIL	Bajaj spare parts
39200511	WASHER	Bajaj spare parts
39200811	WASHER PLAIN	Bajaj spare parts
39201619	SEAL OIL	Bajaj spare parts
39201719	SEAL OIL	Bajaj spare parts
39202904	BOLT-FLANGED	Bajaj spare parts
39204021	RING O	Bajaj spare parts
39206004	BOLT FLANGED M5 X 16L	Bajaj spare parts
39212415	NUT HEXAGON FLANGE M6 X	Bajaj spare parts
39213217	RING SNAP	Bajaj spare parts
39213319	SEAL OIL	Bajaj spare parts
39213421	RING O	Bajaj spare parts
39214124	"WASHER, NYLON, 5.3X11.5X1.5 "	Bajaj spare parts
39214704	BOLT HEX HEAD+FLA M6 M6 X	Bajaj spare parts
39215220	BEARING NEEDLE	Bajaj spare parts
39215320	BEARING NDL RL3X38X1	Bajaj spare parts
39215704	BOLT HEX +FLANGE M8 M8 X	Bajaj spare parts
39215811	WASHER PLAIN	Bajaj spare parts
39215911	WASHER PLAIN	Bajaj spare parts
39216011	WASHER PLAIN	Bajaj spare parts
39216511	WASHER PLAIN	Bajaj spare parts
39216611	WASHER PLAIN	Bajaj spare parts
39216812	WASHER CONICAL	Bajaj spare parts
39217924	WASHER 5.1X10X1.0	Bajaj spare parts
39218006	PIN HOLLOW DOWEL 12 X 20	Bajaj spare parts
39218106	PIN HOLLOW DOWEL 14 X 20	Bajaj spare parts
39218520	BEARING DEEP GROOVE	Bajaj spare parts
39218819	SEAL OIL	Bajaj spare parts
39218919	SEAL OIL	Bajaj spare parts
39219019	SEAL OIL	Bajaj spare parts
39219421	RING O	Bajaj spare parts

39219908	PIN SNAP JOINT B OIL DELIVERY	Bajaj spare parts
39220011	WASHER PLAIN PRI DRIVE G	Bajaj spare parts
39220207	PARALLEL PIN	Bajaj spare parts
39220307	PIN PARALLEL	Bajaj spare parts
39220404	BOLT - HEXAGON HEAD WITH FLANGE :- M6	Bajaj spare parts
39220504	BOLT HEX HEAD+FLA M8 M8 X 14L	Bajaj spare parts
39222204	BOLT FLANGED M8 M8 X 16L	Bajaj spare parts
39222815	NUT DOMED CAP M	Bajaj spare parts
39223704	BOLT HEXAGON HEAD	Bajaj spare parts
39223801	SCREW PAN HEAD	Bajaj spare parts
39224020	BEARING BALL	Bajaj spare parts
39224120	BEARING BALL	Bajaj spare parts
39224915	NUT - NYLOC :- M10	Bajaj spare parts
39226405	STUD M8	Bajaj spare parts
39227611	WASHER - PLAIN	Bajaj spare parts
39228501	SCREW SLOTTED & CROSS REC	Bajaj spare parts
39229515	NUT FLANGE M8	Bajaj spare parts
39230404	HEX HD BOLT/FLANG-M6	Bajaj spare parts
39231204	BOLT HEX HEAD+FLA M8 M8 X	Bajaj spare parts
39231704	BOLT - HEXAGON HEAD	Bajaj spare parts
39234411	WASHER PLAIN	Bajaj spare parts
39234911	WASHER PLAIN	Bajaj spare parts
39235404	BOLT HEX FLANGE M6	Bajaj spare parts
39235717	CIRCLIP INTERNAL	Bajaj spare parts
39236220	BEARING BALL 12	Bajaj spare parts
39236615	NUT DOMED CAP	Bajaj spare parts
39236915	NUT - FLANGE :- M7	Bajaj spare parts
39237423	GROMMET FOR UPPER PART	Bajaj spare parts
39237523	GROMMET FOR MUDGUARD	Bajaj spare parts
39238104	BOLT HEX SOCKET M5	Bajaj spare parts
39238315	NUTHEXAGON FLANGE	Bajaj spare parts
39239121	RING O	Bajaj spare parts
39239620	BEARING BALL12 X32 X10	Bajaj spare parts
39240011	WASHER	Bajaj spare parts
39240320	BEARING DEEP GROOVE	Bajaj spare parts
39240701	SCREW - TRUSS :- M6	Bajaj spare parts
39240817	CIRCLIP	Bajaj spare parts
39241204	BOLT HEX HEAD+FLA M8 M8 X	Bajaj spare parts
39241304	BOLT HEX HEAD+FLA M8 M8 X	Bajaj spare parts
39241404	BOLT HEX SOCKET M8	Bajaj spare parts
39242311	WASHER PLAIN	Bajaj spare parts
39242411	WASHER PLAIN	Bajaj spare parts
39242511	WASHER PLAIN	Bajaj spare parts
39242704	BOLT HEX SOCKET M6	Bajaj spare parts
39244011	WASHER SPRING STEEL	Bajaj spare parts

39244311	WASHER PLAIN	Bajaj spare parts
39244704	BOLT - HEXAGON HEAD	Bajaj spare parts
39244811	WASHER PLAIN	Bajaj spare parts
39245111	WASHER PLAIN 4.5X8X1	Bajaj spare parts
39245504	HEX.HD BOLT/FLANG-M8	Bajaj spare parts
39246417	CIRCLIP	Bajaj spare parts
39246520	BEARING BALL	Bajaj spare parts
39246904	BOLT HEX HEAD+FLA M8 M8 X	Bajaj spare parts
39247304	BOLT HEX HEAD+FLA M6 M6 X	Bajaj spare parts
39247404	BOLT HEX HEAD+FLA M6 M6 X	Bajaj spare parts
39247504	BOLT HEX HEAD+FLA M6 M6 X	Bajaj spare parts
39247604	BOLT HEXAGON HEAD	Bajaj spare parts
39247915	NUT FLANGE M8X1.	Bajaj spare parts
39248304	BOLT-HEXAGON HEAD W	Bajaj spare parts
39248415	NUT FLANGE M5	Bajaj spare parts
39249211	WASHER PLAIN	Bajaj spare parts
39249504	BOLT SOC. HEAD	Bajaj spare parts
39249804	BOLT HEX HEAD+FLANGEM8	Bajaj spare parts
39251604	BOLT SHOULDER M10	Bajaj spare parts
39251704	BOLT HEX HEAD M8	Bajaj spare parts
39252820	BEARING NDL RL14X20X	Bajaj spare parts
39253105	STUD M10	Bajaj spare parts
39253204	BOLT HEX HEAD+FLA M6	Bajaj spare parts
39253515	NUT DOMED CAP M8	Bajaj spare parts
39253815	NUT HEXAGON M12	Bajaj spare parts
39253921	RING O	Bajaj spare parts
39254104	BOLT HEX HEAD+FLA M7	Bajaj spare parts
39254220	BEARING BALL15X42X13	Bajaj spare parts
39254717	CIRCLIP - INTERNAL PRV	Bajaj spare parts
39255020	BEARING BALL20X47X14	Bajaj spare parts
39255717	CIRCLIP	Bajaj spare parts
39256120	BEARING BALL 6305	Bajaj spare parts
39256220	BEARING NEEDLE	Bajaj spare parts
39256611	WASHER PLAIN	Bajaj spare parts
39256711	WASHER PLAIN	Bajaj spare parts
39258204	BOLT HEX HEAD+FLANGE	Bajaj spare parts
39258320	BEARING BALL 6004	Bajaj spare parts
39258501	SCREW M6	Bajaj spare parts
39258811	WASHER PLAIN	Bajaj spare parts
39259201	SCREW PAN CROSS M4	Bajaj spare parts
39260011	WASHER PLAIN	Bajaj spare parts
39260120	BEARING BALL 25 X 42 X 9	Bajaj spare parts
39260220	BEARING BALL 6202	Bajaj spare parts
39260320	BEARING BALL 6202	Bajaj spare parts
39260607	PIN PARALLEL	Bajaj spare parts



39260715	NUT - NYLOC (M12 X 1.5)	Bajaj spare parts
39260801	SCREW GRUB M5 X 0.8 X 7	Bajaj spare parts
39261515	NUT FLANGE M12 X 1	Bajaj spare parts
39262921	RING O	Bajaj spare parts
39264715	DOMED CAP NUT	Bajaj spare parts
39265912	WASHER SPRING	Bajaj spare parts
39266921	RING O	Bajaj spare parts
39267104	BOLT FLANGED M8	Bajaj spare parts
39268020	BEARING BALL 10X35X11	Bajaj spare parts
39268120	BEARING-BALL C3	Bajaj spare parts
39268320	BEARING BALL 17X35X1	Bajaj spare parts
39268620	BEARING BALL 6202 C3	Bajaj spare parts
39268820	BEARING BALL 6301 C3	Bajaj spare parts
39269920	O-RING FOR TEMP.SENSOR	Bajaj spare parts
39270004	HEXAGON BOLT FLAN-M8	Bajaj spare parts
39270204	FLANGE BOLT	Bajaj spare parts
39270411	WASHER (SPRING STEEL)	Bajaj spare parts
39270704	BOLT HEX+ FLANGE	Bajaj spare parts
39271115	NUT FLANGE M6 X 1P	Bajaj spare parts
39271217	CIRCLIP INTERNAL	Bajaj spare parts
39272204	BOLT SOCKET HEAD M8	Bajaj spare parts
39272315	NUT FLANGE M10 OL GR PASS	Bajaj spare parts
39272711	WASHER PLAIN	Bajaj spare parts
39273104	BOLT FLANGE M8 X 1.25	Bajaj spare parts
39275404	BOLT HEX HEAD + FLANGE	Bajaj spare parts
39275701	SCREW PAN CROSS M5X30L	Bajaj spare parts
39276501	SCREW TRUSS M6	Bajaj spare parts
43010035	VERTICAL RUBB.STRIP.	Bajaj spare parts
52210040	MUDGUARD REAR	Bajaj spare parts
52210043	DOOR TOOL BOX ED COATEDDOOR TOOL BOX ED	Bajaj spare parts
52240483	BUMPER ASSLY 242310	Bajaj spare parts
52240485	DOOR ENCLOSURE ASSLY RH FOR SRILANKA	Bajaj spare parts
52240512	BEARING RACE UPP	Bajaj spare parts
52240583	CHASSIS BARE RE 145	Bajaj spare parts
52240590	BODY ASSLY RE 5P ANT	Bajaj spare parts
52240591	BODY ASSLY RE 4S	Bajaj spare parts
52240595	BODY ASSLY RE 2S ANT	Bajaj spare parts
52240596	BODY ASSLY RE 145	Bajaj spare parts
52240597	CHASSIS BARE RE 2S CMVR	Bajaj spare parts
52240601	WINDSHIELD ASSLY	Bajaj spare parts
52240604	CHAISSIS BARE	Bajaj spare parts
52240637	CRANKCASE MAG SIDE ASSLY	Bajaj spare parts
52240645	WIND SHIELD ED COATED	Bajaj spare parts
52240656	CRANKCASE MAGNETO SIDE ES	Bajaj spare parts
52240667	ASSLY FRAME ( BB161084 )	Bajaj spare parts

52240668	BODY ASSLY ( BB231351 )	Bajaj spare parts
52240669	DOOR ENGINE FOR TRAY (BB231215)	Bajaj spare parts
52240670	DOOR ASSLY REAR (BB231216)	Bajaj spare parts
52240674	BARE CHASSIS (BA161160)	Bajaj spare parts
52240675	BODY COMPT ED CO BA23112	Bajaj spare parts
52240678	BARE CHSSIS ED COATED AF161114	Bajaj spare parts
52240681	ASSLY BARE CHASSIS COMP	Bajaj spare parts
52240712	ASSLY CYL.HEAD DAMPER	Bajaj spare parts
52240717	ASSLY-CRANKCASE CLUTCH SIDE	Bajaj spare parts
52240743	ASSLY CHASS ED COATED	Bajaj spare parts
52240746	ASSLY CHASSIS REFL ED COATED	Bajaj spare parts
52240748	ASSLY DOOR REAR LOWER	Bajaj spare parts
52240760	ED COATED BUMPER 24165137	Bajaj spare parts
52240765	ASSLY WHEEL RIM 22151090	Bajaj spare parts
52240912	ED BODY COM(AA231294) COMP 2S REFRESH	Bajaj spare parts
52240916	ED COATED CHASSIS (24165345) COMP 2S REF	Bajaj spare parts
52241742	ED COATED CHASSIS THL (AG161032)	Bajaj spare parts
52244040	ED COATED FR MUDGUARD	Bajaj spare parts
52244058	ED COATED ASSLY CHASSIS BARE COMP RE	Bajaj spare parts
52244063	ED COATED MUDGURAD	Bajaj spare parts
52244064	ED COATED CHASSIS	Bajaj spare parts
52244065	ED COATED BODY AA231249	Bajaj spare parts
52244066	ED COATED BODY AF231177	Bajaj spare parts
52248006	CROSS MEMBER RE 2S	Bajaj spare parts
52AA0310	BODY ASSLY ED COATED ( AA231190)	Bajaj spare parts
52AA0315	CHAISSIS BARE	Bajaj spare parts
52AA0323	ASSLY SF ED COAT-ASY	Bajaj spare parts
52AA0457	FAREMETER ASSEMBLY WITH RUBBER SEAL	Bajaj spare parts
52AA0464	ASSLY COMP REVERSE LEVER WITH CABLE	Bajaj spare parts
52AA0501	ASSLY REAR DOOR ED	Bajaj spare parts
52AA0748	ED COATED BARE CHASSIS COMP AA161292	Bajaj spare parts
52AA0749	ED COATED CHASSIS COMP-F161120	Bajaj spare parts
52AA0876	ED COATED BODY AA231333 - BSIV 2S/4S PET	Bajaj spare parts
52AA0972	ASSLY MUDGUARD ED COATED A161289	Bajaj spare parts
52AA0973	ASSLY BODY COMP COATED AA231349	Bajaj spare parts
52AA0974	ASSLY CHASSIS BARE FI AA161356	Bajaj spare parts
52AA1527	CRANKCASE 4S MAG SIDE WITH DRAIN BOLT	Bajaj spare parts
52AA4035	ASSLY-FAREMETER 205FL	Bajaj spare parts
52AB0098	MUDGUARD FRONT	Bajaj spare parts
52AF0082	CHAISSIS BARE	Bajaj spare parts
52AF0084	BODY ASSY	Bajaj spare parts
52AF0118	ASSLY DOOR GAS FILLING	Bajaj spare parts
52AF0218	ED COATED BODY-AF231231	Bajaj spare parts
52AF0543	ASSEMBLY CHASSIS BARE (AF161279)	Bajaj spare parts
52AF0546	ASSEMBLY DOOR RH RE (AF231689)	Bajaj spare parts

52AF0547	ASSEMBLY	Bajaj spare parts
52AF0555	ASSEMBLY BODY WITHOUT DOOR(52AF0487)ED C	Bajaj spare parts
52AF0559	CRANKCASE 4S MAG SIDE WITH DRAIN BOLT	Bajaj spare parts
52AF0580	ED COATED DOOR ASSEMBLY REAR_AF231569_RE	Bajaj spare parts
52AF0608	BODY ASSLY ED COATED RE CNG\LPG BI FUEL	Bajaj spare parts
52AF0609	ASSLY CHASSIS BARE ED COATED PART RE LP	Bajaj spare parts
52AF0621	DOOR ASSEMBLY REAR ED COATED	Bajaj spare parts
52AF0639	CRANK CASE 4S MAGNETO SIDE WITH DRAIN BO	Bajaj spare parts
52AF0803	ASSLY BUMPER REAR P.COATED YELLOW FOR RE	Bajaj spare parts
52AF0826	ED COATED ASSEMBLY CHASSIS_AF161120	Bajaj spare parts
52AF0888	ASY CNG CYLINDER WITH VALVE ASSLY FOR RE	Bajaj spare parts
52AG0070	ED COATED CHASSIS THL (24165373)	Bajaj spare parts
52AH0296	ED COATED BUMPER REAR_AH113812	Bajaj spare parts
52AH0349	SIDE DOOR RH RE_ED COATED.	Bajaj spare parts
52AH0351	SIDE DOOR LH RE_ED COATED.	Bajaj spare parts
52AH0598	ASSEMBLY DRIVER SEAT COMPLETE COOL GRAY	Bajaj spare parts
52AH0608	ASSEMBLY DRIVER SEAT COMPLETE BLACK	Bajaj spare parts
52AH0725	ASSEMBLY HOOD BLACK RE EV	Bajaj spare parts
52AH0741	ASSEMBLY HOOD NEPTUNE BLACK RE EV	Bajaj spare parts
52AL0218	DOOR ASSLY RH AL24	Bajaj spare parts
52AL0278	WINDSHIELD ASSLY	Bajaj spare parts
52AL0317	ASSLY LOCK SET RE CARGO	Bajaj spare parts
52AL0389	ED COATED CHASSIS RE CARGO AL161650	Bajaj spare parts
52AL0390	ED COATEDT RE CR-AL241633	Bajaj spare parts
52AL0391	ED COATED ASSY ENG ACCESS COVER CARGO AL	Bajaj spare parts
52AL0392	ED COATED ASSLY DOOR RH AL241596	Bajaj spare parts
52AL0393	ED COATED CA CARGO AL241419	Bajaj spare parts
52AL0395	ED COATED ASSLY DOOR LH AL241597	Bajaj spare parts
52AL0396	ED COATED ASSLY PANEL REAR DOOR AL24163	Bajaj spare parts
52AL0871	ED COATED ASSLY CHASSIS BARE-CARGO DSL	Bajaj spare parts
52AM0017	CHAISSIS BARE	Bajaj spare parts
52AM0019	CHAISSIS BARE	Bajaj spare parts
52AM0236	ASSEMBLY	Bajaj spare parts
52AM0262	ASSLY CHASSIS BARE ED COATED PART RE L	Bajaj spare parts
52AN0111	LOCKSET ASSLY RE CARGO CNG	Bajaj spare parts
52AN0118	ASSEMBLY CNG CYLINDER - CARGO CNG	Bajaj spare parts
52AN0204	BARE CHASSIS CARGO CNG PAINTED AN161226	Bajaj spare parts
52AN0230	ASSLY CHASSIS (AN161226)CNG ED -COATED	Bajaj spare parts
52AN0262	ED COATED CABIN ASSLY AL241419	Bajaj spare parts
52AN0459	ED COATED ASSLY CHASSIS BARE-CARGO CNG	Bajaj spare parts
52AN0498	ED COATED ASSLY CHASSIS CARGO CNG - BI	Bajaj spare parts
52AS0003	BODY ASSY	Bajaj spare parts
52AS0020	ED BODY COMP (AF231207) COMP 2S GAS REFR	Bajaj spare parts
52AS0021	ED COATED CHASSIS (AS160034) COMP 2S GAS	Bajaj spare parts
52AT0085	COVER FASCIA FRONT BOTTOM LH YELLOW	Bajaj spare parts

52AT0086	COVER FASCIA FRONT BOTTOM RH YELLOW	Bajaj spare parts
52AT0087	COVER FASCIA FRONT BOTTOM LH BLACK	Bajaj spare parts
52AT0088	COVER FASCIA FRONT BOTTOM RH BLACK	Bajaj spare parts
52AT0089	COVER FASCIA FRONT BOTTOM LH WHITE	Bajaj spare parts
52AT0090	COVER FASCIA FRONT BOTTOM RH WHITE	Bajaj spare parts
52AT0091	COVER FASCIA FRONT BOTTOM LH GREEN	Bajaj spare parts
52AT0092	COVER FASCIA FRONT BOTTOM RH GREEN	Bajaj spare parts
52AT0093	COVER FASCIA FRONT BOTTOM LH BLUE	Bajaj spare parts
52AT0094	COVER FASCIA FRONT BOTTOM RH BLUE	Bajaj spare parts
52AT0095	COVER FASCIA FRONT BOTTOM LH RED	Bajaj spare parts
52AT0096	COVER FASCIA FRONT BOTTOM RH RED	Bajaj spare parts
52AT0111	ASSLY BARE CHASSIS WB MAXIMA LPG	Bajaj spare parts
52AT0112	CHASSIS WB MAXIMA CNG	Bajaj spare parts
52AT0135	COVER PANEL BOLTABLE BODY FR LH	Bajaj spare parts
52AT0136	COVER PANEL BOLTABLE BODY FR RH	Bajaj spare parts
52AT0137	COVER LOWER FRONT LH	Bajaj spare parts
52AT0138	COVER LOWER FRONT RH	Bajaj spare parts
52AT0139	COVER REAR LH FL	Bajaj spare parts
52AT0140	COVER REAR RH FL	Bajaj spare parts
52AT0167	COVER ASSLY - ECO GREEN	Bajaj spare parts
52AT0168	COVER ASSLY - GOLDEN YELLOW	Bajaj spare parts
52AT0169	COVER ASSLY - JET BLACK	Bajaj spare parts
52AT0193	COVER ASSEMBLY WHITE	Bajaj spare parts
52AT0194	ASSEMBLY	Bajaj spare parts
52AT0195	COVER ASSEMBLY BLUE	Bajaj spare parts
52AT0291	ED COATED ASSLY CHASSIS BARE MAXIMA CNG	Bajaj spare parts
52AT0292	ED COATED ASSLY CHASSIS BARE MAXIMA LPG	Bajaj spare parts
52AT0293	ED COATED BODY ASSLY MAXIMA DSL	Bajaj spare parts
52AT0295	ED COATED DOOR ASSLY RH MAXIMA	Bajaj spare parts
52AT0296	ED COATED DOOR ASSLY LH MAXIMA	Bajaj spare parts
52AT0311	ED COATED ASSLY CHASSIS X WIDE CNG - BI	Bajaj spare parts
52AT0312	ED COATED ASSLY CHASSIS X WIDE LPG - BI	Bajaj spare parts
52AU0119	ASSEMBLY HOOD YELLOW RE PETROL BSVI	Bajaj spare parts
52AU0129	ASSEMBLY CHASSIS BARE ((161424)	Bajaj spare parts
52AU0133	ASSEMBLY BODY WITHOUT DOOR(52AU0133) ED	Bajaj spare parts
52AZ0021	FRAME ASSLY	Bajaj spare parts
52AZ0053	COVER ASSLY GAS FILLING	Bajaj spare parts
52AZ0112	AZ111056-ASSLY FRAME COMPACT	Bajaj spare parts
52AZ0135	ASSEMBLY LOCKSET COMPACT + CNG/LPG UPG	Bajaj spare parts
52AZ0147	ASSLY HOOD FRAME REAR WITOUHT PIPES REG	Bajaj spare parts
52AZ0149	ASSLY SIDE PIPE & HARDWERE HOOD REGULAR	Bajaj spare parts
52AZ0150	ED COATED BODY AZ211028 BSIV OPTIMA GAS	Bajaj spare parts
52AZ0174	ED COATED COVER BATTERY ACCESS UG	Bajaj spare parts
52AZ0176	ED COATED ASSLY SIDE DOOR LH UG	Bajaj spare parts
52AZ0177	ED COATED ASSLY SIDE DOOR RH UG	Bajaj spare parts

52AZ0178	ED COATED ASSLY DOOR FUEL FILLING UG	Bajaj spare parts
52AZ0180	ED COATED ASSLY DOOR REAR UPPER UG	Bajaj spare parts
52AZ0190	ASSLY CHASSIS BARE MAXIMA Z LPG -AZ11106	Bajaj spare parts
52AZ0364	ASSEMBLY CNG CYLINDER AND VALVE MAXIMA Z	Bajaj spare parts
52AZ0416	ASSLY CHASSIS BARE	Bajaj spare parts
52AZ0432	ED COATED BODY ASSLY Z CNG,LPG	Bajaj spare parts
52AZ0477	ED COATED ASSBLY CHASSIS Z CNG- BI FUEL	Bajaj spare parts
52BA0147	PISTON ASSY RE DIESEL	Bajaj spare parts
52BA0242	BODY ASSY	Bajaj spare parts
52BA0244	CHAISSIS BARE	Bajaj spare parts
52BA0283	DOOR ASSLY SIDE FILLING	Bajaj spare parts
52BA0308	ASSLY BARE CHASSIS COMPACT DSL HC	Bajaj spare parts
52BA0386	ED BODY COMP(BA231161) 445 DSL REFRES	Bajaj spare parts
52BA0388	ED COATED CHAS-BA161196	Bajaj spare parts
52BA0874	HOOD ASSLY BLACK RE DSL BSVI	Bajaj spare parts
52BA0891	ASSEMBLY CHASSIS BARE (BA161213	Bajaj spare parts
52BA0892	ASSEMBLY BODY WITHOUT DOOR(52BA0852)ED C	Bajaj spare parts
52BB0075	MUDGUARD FRONT (BB161090 )	Bajaj spare parts
52BB0148	ASSLY BARE CHASSIS MAXIMA HC	Bajaj spare parts
52BB0285	REAR DOOR ASLY MAXIMA ED COATED	Bajaj spare parts
52BB0359	ASSLY CHASSIS WB MAXIMA DSL	Bajaj spare parts
52BB0360	BODY ASSLY –WB MAXIMA DSL/CNG/LPG	Bajaj spare parts
52BB0361	DOOR ASSLY UPPER REAR –WB MAXIMA DSL	Bajaj spare parts
52BB0362	COVER ASSLY ENGINE ACCESS –WB MAXIMA	Bajaj spare parts
52BB0367	COVER PILLAR B LH	Bajaj spare parts
52BB0373	COVER PILLAR B RH	Bajaj spare parts
52BB0666	ED COATED ASSLY CHASSIS BARE MAXIMA DSL	Bajaj spare parts
52BB0694	ED COATED COVER PILLER B LH FOR SPARES	Bajaj spare parts
52BB0695	ED COATED COVER PILLER B RH FOR SPARES	Bajaj spare parts
52BF0079	ASSLY FRONT DOOR COMP LH	Bajaj spare parts
52BF0085	ASSLY FRONT DOOR COMP RH	Bajaj spare parts
52BF0086	ASSLY FRONT DOOR COMP RH	Bajaj spare parts
52BF0089	ASSLY FRONT DOOR COMP RH	Bajaj spare parts
52BF0091	ASSLY REAR DOOR COMP LH	Bajaj spare parts
52BF0092	ASSLY REAR DOOR COMP LH	Bajaj spare parts
52BF0093	ASSLY REAR DOOR COMP LH	Bajaj spare parts
52BF0094	ASSLY REAR DOOR COMP LH	Bajaj spare parts
52BF0095	ASSLY REAR DOOR COMP LH	Bajaj spare parts
52BF0096	ASSLY RAR DOOR COMP LH	Bajaj spare parts
52BF0097	ASSLY REAR DOOR COMP RH	Bajaj spare parts
52BF0098	ASSLY REAR DOOR COMP RH	Bajaj spare parts
52BF0099	ASSLY REAR DOOR COMP RH	Bajaj spare parts
52BF0100	ASSLY REAR DOOR COMP RH	Bajaj spare parts
52BF0101	ASSLY REAR DOOR COMP RH	Bajaj spare parts
52BF0102	ASSLY REAR DOOR COMP RH	Bajaj spare parts

52BF0103	ASSLY HOOD	Bajaj spare parts
52BF0104	ASSLY HOOD	Bajaj spare parts
52BF0105	ASSLY HOOD	Bajaj spare parts
52BF0106	ASSLY HOOD	Bajaj spare parts
52BF0107	ASSLY HOOD	Bajaj spare parts
52BF0108	ASSLY HOOD	Bajaj spare parts
52BF0109	CAP TR ARM MTG LH	Bajaj spare parts
52BF0110	CAP TR ARM MTG LH	Bajaj spare parts
52BF0111	CAP TR ARM MTG LH	Bajaj spare parts
52BF0112	CAP TR ARM MTG LH	Bajaj spare parts
52BF0113	CAP TR ARM MTG LH	Bajaj spare parts
52BF0114	CAP TR ARM MTG LH	Bajaj spare parts
52BF0115	CAP TR ARM MTG RH	Bajaj spare parts
52BF0116	CAP TR ARM MTG RH	Bajaj spare parts
52BF0117	CAP TR ARM MTG RH	Bajaj spare parts
52BF0118	CAP TR ARM MTG RH	Bajaj spare parts
52BF0119	CAP TR ARM MTG RH	Bajaj spare parts
52BF0120	CAP TR ARM MTG RH	Bajaj spare parts
52BF0127	ASSLY PLENUM CHAMBER	Bajaj spare parts
52BF0327	ASSLY FRONT DOOR COMP LH RED	Bajaj spare parts
52BF0328	ASSLY FRONT DOOR COMP LH YELLOW	Bajaj spare parts
52BF0329	ASSEMBLY FRONT DOOR COMP LH BLUE	Bajaj spare parts
52BF0330	ASSEY FRONT DOOR COMP LH W	Bajaj spare parts
52BF0331	ASSLY FRONT DOOR COMP LH BLACK	Bajaj spare parts
52BF0332	ASSLY FRONT DOOR COMP LH GREEN	Bajaj spare parts
52BF0345	ASSLY FRONT DOOR COMP LOCKABLE RH RED	Bajaj spare parts
52BF0346	ASSLY FRONT DOOR COMP LOCKABLE RH YELLOW	Bajaj spare parts
52BF0347	ASSLY FRONT DOOR COMP LOCKABLE RH BLUE	Bajaj spare parts
52BF0348	ASSLY FRONT DOOR COMP LOCKABLE RH WHITE	Bajaj spare parts
52BF0349	ASSLY FRONT DOOR COMP LOCKABLE RH BLACK	Bajaj spare parts
52BF0350	ASSLY FRONT DOOR COMP LOCKABLE RH GREEN	Bajaj spare parts
52BF0533	FUEL LID ED COATED	Bajaj spare parts
52BF0630	FOR BJ551007 INPUT SHAFT ASSLY FOR 2	Bajaj spare parts
52BF0631	FOR BJ551008 FOR OUT PUT SHAFT ASSLY	Bajaj spare parts
52BF0689	ED COATED DOOR FRAME-FRT LH-BF243085	Bajaj spare parts
52BF0690	ED COATED DOOR FRAME-FRT RH-BF243086	Bajaj spare parts
52BF0708	ASSEMBLY ROOF CARRIER BOX	Bajaj spare parts
52BF0710	FM RADIO & SPEAKER BOX	Bajaj spare parts
52BF0711	QUTE DOMESTIC ACCESSORY TRIMS BOX	Bajaj spare parts
52BF0804	ASSLY BIW RHD WITH SM ROOF ED COATED	Bajaj spare parts
52BF0854	ASSEMBLY BIW CNG RHD WITH SM ROOF ED COA	Bajaj spare parts
52BF0917	ASSEMBLY ROOF CARRIER BOX (NEW)	Bajaj spare parts
52BF0935	ASSEMBLY RAIN CHANNEL WITH TAPE LH	Bajaj spare parts
52BF0936	ASSEMBLY RAIN CHANNEL WITH TAPE RH	Bajaj spare parts
52BF0980	ED COATED PANEL ROOF INNER LH	Bajaj spare parts

52BF0982	ED COATED PANEL PILLAR A OUTER UPPER LH	Bajaj spare parts
52BF0984	ED COATED PANEL PILLAR C OUTER LH	Bajaj spare parts
52BF0985	ED COATED PANEL PILLAR C OUTER RH	Bajaj spare parts
52BF0986	ED COATED PANEL DASHBOARD	Bajaj spare parts
52BF0987	ED COATED BRACKET STG RACK MTG LH HXM	Bajaj spare parts
52BF0988	ED COATED BRACKET STG RACK MTG RH HXM	Bajaj spare parts
52BF0992	ED COATED PANEL RAIL ROOF OUTER LH	Bajaj spare parts
52BF0994	ED COATED ASSEMBLY BACK PANEL INNER UPR	Bajaj spare parts
52BF0995	ED COATED PANEL WINDSHIELD INNER	Bajaj spare parts
52BF0996	ED COATED PANEL BACK OUTER	Bajaj spare parts
52BF0997	ED COATED PANEL WINDSHIELD OUTER LOWER	Bajaj spare parts
52BF0998	ED COATED PANEL PILLAR A OUTER LOWER LH	Bajaj spare parts
52BF1000	ED COATED PANEL BUMPER FRONT OUTER	Bajaj spare parts
52BF1001	ED COATED PANEL BUMPER FRONT INNER	Bajaj spare parts
52BF1002	ED COATED PANEL HEAD LAMP MTG TOP LH	Bajaj spare parts
52BF1003	ED COATED PANEL HEAD LAMP MTG TOP RH	Bajaj spare parts
52BF1004	ED COATED BRACKET LAMP HEAD REAR LH	Bajaj spare parts
52BF1005	ED COATED BRACKET LAMP HEAD RH	Bajaj spare parts
52BF1006	ED COATED MEMBER PARTITION LOWER-MIDDLE	Bajaj spare parts
52BF1007	ED COATED PANEL REAR QUARTER OUTER LH	Bajaj spare parts
52BF1008	ED COATED PANEL REAR QUARTER OUTER RH	Bajaj spare parts
52BF1009	ED COATED PANEL SIDE SILL OUTER LH	Bajaj spare parts
52BF1010	ED COATED PILLAR ASSEMBLY B UPPER LH	Bajaj spare parts
52BF1011	ED COATED PILLAR ASSEMBLY B UPPER RH	Bajaj spare parts
52BF1012	ED COATED PANEL ROOF INNER CROSS	Bajaj spare parts
52BF1013	ED COATED PANEL SIDE SILL OUTER RH	Bajaj spare parts
52BF1014	ED COATED BRACKET BUMPER MTG 1	Bajaj spare parts
52BF1205	QUTE STEERING RACK GUIDE BUSH SUB ASSLY	Bajaj spare parts
52BH0029	ASSLY BODY COMP.-ED COATED	Bajaj spare parts
52BH0055	FRAME ASSLY (BH111050)	Bajaj spare parts
52BH0056	DOOR FUEL FILLING (BH211012)	Bajaj spare parts
52BH0057	DOOR ENGINE ACCESS (BH211014)	Bajaj spare parts
52BH0058	DOOR REAR UPPER (BH211016 )	Bajaj spare parts
52BH0059	DOOR REAR LOWER (BH211093 )	Bajaj spare parts
52BH0060	ASSLY BODY COMP (BH211120 )	Bajaj spare parts
52BH0098	ASSLY BARE CHASSIS OPTIMA DSL HC	Bajaj spare parts
52BH0164	ACCESSORY COMPACT CLOSED HOOD SP	Bajaj spare parts
52BH0174	ASSEMBLY LOCKSET COMPACT + DSL UPGRADE	Bajaj spare parts
52BH0207	ED COATED ASSLY BARE CHASSIS COMP UG	Bajaj spare parts
52BH0209	ASSEMBLY DOOR RR ENG ACCESS (AZ244002 )E	Bajaj spare parts
52BH0210	ASSEMBLY DOOR ENG ACCESS (AZ211329 )ED C	Bajaj spare parts
52BH0417	ED COATED ASSLY CHASSIS BARE- Z DIESEL	Bajaj spare parts
52BH0418	ED COATED BODY ASSLY Z DIESEL	Bajaj spare parts
52BH0419	ED COATED FRAME ASSLY WINDSHIELD	Bajaj spare parts
52BH0443	ASSLY HOOD BLACK MAXIMA Z	Bajaj spare parts

52BH0444	ASSLY HOOD WHITE MAXIMA Z	Bajaj spare parts
52BH0445	ASSLY HOOD YELLOW MAXIMA Z	Bajaj spare parts
52BH0446	ASSLY HOOD MUSHROOM MAXIMA Z	Bajaj spare parts
52DD0286	FENDER FRONT	Bajaj spare parts
52DG0191	SEMIFINISH COVER	Bajaj spare parts
52DG0192	COVER SIDE RH PRIM	Bajaj spare parts
52DG0268	SF FENDER REAR	Bajaj spare parts
52DG0288	SEMIFINISH FOR FENDER FRO	Bajaj spare parts
52DG0289	NUMBER PLATE FRONT	Bajaj spare parts
52DH0080	COVER SIDE RH MASKED	Bajaj spare parts
52DH0117	LEVER GEAR SHIFT PULSAR	Bajaj spare parts
52DH0153	COVER STARTER MOTOR	Bajaj spare parts
52DH0169	PUMP OIL PULSAR DTS-I	Bajaj spare parts
52DH0177	HOLDER BALANCER IDLER WI	Bajaj spare parts
52DH0278	FENDER FR UNPAINT PUL	Bajaj spare parts
52DH0295	INSTRUMENT CLUSTER	Bajaj spare parts
52DH0309	CASE CHAIN ASSY SILVER P	Bajaj spare parts
52DH0528	COVER SIDE LH M.P. B	Bajaj spare parts
52DH0529	COVER SIDE RH M.P.BL	Bajaj spare parts
52DH0530	COVER SIDE LH WINE R	Bajaj spare parts
52DH0531	COVER SIDE RH	Bajaj spare parts
52DH0534	COVER SIDE LH M.N.BL	Bajaj spare parts
52DH0535	COV.SIDE RH M/NIGHT	Bajaj spare parts
52DH0541	FLAP TANK ASSY LH WINE RE	Bajaj spare parts
52DH0542	FLAP TANK RH C W/RED	Bajaj spare parts
52DH0543	FLAP TANK ASSY LH PL BLUE	Bajaj spare parts
52DH0544	FLAP TANK RH PLSMA BLUE	Bajaj spare parts
52DH0547	TANKFLAP LH MIDNIT B	Bajaj spare parts
52DH0548	FLAP TANK ASSY RH MID BL	Bajaj spare parts
52DH0624	COVER LH BLK PULSAR	Bajaj spare parts
52DH0673	SIDE CVR LH BLACK PAINT. RED DECL	Bajaj spare parts
52DH0674	SIDE COVR RH BLACK	Bajaj spare parts
52DH0675	SIDE COVR LH BLACK	Bajaj spare parts
52DH0676	SIDE CVR RH BLACK PAINT.BLUE DEC	Bajaj spare parts
52DH0682	FAIRING C W RED - W- RED DECAL	Bajaj spare parts
52DH0683	FAIRING PL BLUE W BLUE DECAL	Bajaj spare parts
52DH0686	COVER LH AST COMP	Bajaj spare parts
52DH0695	COVER LHRR MOONLIGHT K1	Bajaj spare parts
52DH0767	KIT LEG GUARD (PULSAR 150)	Bajaj spare parts
52DH0811	K1 FLAP LH BLACK+S BLUE DCL	Bajaj spare parts
52DH0812	K1 FLAP RH BLACK+S BLUE DCL	Bajaj spare parts
52DH0813	K1 FLAP LH BLACK+PL SILVER DCL	Bajaj spare parts
52DH0815	K1 FLAP LH BLACK+W RED DCL	Bajaj spare parts
52DH0816	K1 FLAP RH BLACK+W RED DCL	Bajaj spare parts
52DH0820	FRONT FENDER ASSLY SAFFIRE BLUE	Bajaj spare parts



52DH0821	FRONT FENDER PLA SILVER	Bajaj spare parts
52DH0822	FRONT FENDER ASSLY WINE RED	Bajaj spare parts
52DH0823	S COVER LH+DCL PL SILVER-K1	Bajaj spare parts
52DH0824	S COVER RH+DCL PL SILVER-K1	Bajaj spare parts
52DH0846	FRONT FENDER ASSLY E BLACK	Bajaj spare parts
52DH0850	FAIRING PLATINIUM SILVR DECL	Bajaj spare parts
52DH0877	TANK FLAP ASSLY LH K1 PL. SILVER DECAL	Bajaj spare parts
52DH0878	TANK FLAP ASSLY RH K1 PL SILVER DECAL	Bajaj spare parts
52DH0879	TANK F ASSLY LH BLACK DECAL	Bajaj spare parts
52DH0880	TANK ASSLY RH B DEC	Bajaj spare parts
52DH0885	FRONT FENDER ASSLY M WHITE	Bajaj spare parts
52DH0887	FLAP RH BLACK M WHITE DEC	Bajaj spare parts
52DH0928	K1 GRAB HANDLE WITH TPT WASHER N BOLT	Bajaj spare parts
52DH1317	SF FOR ASSLY MAGNETO COVR	Bajaj spare parts
52DH1318	COVER CLUTCH ASSLY - MATT SLATE GRAY PUL	Bajaj spare parts
52DH1322	TANK FLAP LH KHI EB BL WH DECL	Bajaj spare parts
52DH1323	TANK FLAP LH WH RO BLUE DECL	Bajaj spare parts
52DH1324	TANK FLAP RH WH EB BLCK DECL	Bajaj spare parts
52DH1325	TANK FLAP RH WH RO BLUE DECL	Bajaj spare parts
52DH1335	FAIRING WITH KHI EB BLK DECAL	Bajaj spare parts
52DH1336	FAIRING WITH ROYAL BLUE DECAL	Bajaj spare parts
52DH1355	FUEL TANK WITH DECAL KHI EB BLK	Bajaj spare parts
52DH1357	SEAT CWL W DKL KHI EB BLK	Bajaj spare parts
52DH1358	SEAT CWL W DKL RYL BLUE	Bajaj spare parts
52DH1361	FUEL TANK WITH DECAL ROYAL BLUE	Bajaj spare parts
52DH1363	FUEL TANK WH DKL FL RED P150 UG	Bajaj spare parts
52DH1364	TNK FLP LH ASY W DKL FL RED P150 UG	Bajaj spare parts
52DH1365	TNK FLP RH ASY W DKL FL RED P150 UG	Bajaj spare parts
52DH1366	SEAT COWL WH DKL FL. RED P150 UG	Bajaj spare parts
52DH1368	SDE CVR LH ASY W DKL FL RED P150 UG	Bajaj spare parts
52DH1369	SDE CVR RH ASY W DKL FL RED P150 UG	Bajaj spare parts
52DH1370	FAIRING WH FL. RED DKL P150 UG+BSIV	Bajaj spare parts
52DH1375	FUEL TANK WITH DECAL FLAME RED	Bajaj spare parts
52DH1412	COVER RR LH SLATE MATTE GRAY P150 UG	Bajaj spare parts
52DH1521	FUEL TANK WH DCL KHI EBY.BLK P150 UG	Bajaj spare parts
52DH1523	TANK FLAP LH ASLY DL KH.EB. BLKP150UG	Bajaj spare parts
52DH1524	TANK.FLAP.LH.ASLY DCL.RY.BL.P150UG	Bajaj spare parts
52DH1525	TANK.FLAP.RH ASLY.DCL KH.EB.BLP150UG	Bajaj spare parts
52DH1527	SI.CVR LH ASLY DCL KH.EB.BL P150 UG	Bajaj spare parts
52DH1528	SI.CVR LH ASLY DCLROYAL BLUE P150 UG	Bajaj spare parts
52DH1529	SI.CVR RH WH DCL KHI EB.BLK P150 UG	Bajaj spare parts
52DH1530	SI.CVR RH WH DCL ROYAL BLUE P150 UG	Bajaj spare parts
52DH1531	FAIRING WITH KHI EB.BLK DCL P-150 UG	Bajaj spare parts
52DH1532	FAIRING WITH RYL BLUE DCL (P 150 UG)	Bajaj spare parts
52DH1535	SEAT COWL WITH DCL KHI EB.BLK P150UG	Bajaj spare parts

52DH1536	SEAT COWL WITH DCL RYL BLUE P150 UG	Bajaj spare parts
52DH1596	FUEL TANK W DKL KHI PASS RED P150 UG	Bajaj spare parts
52DH1597	TNK FLP LH W DKL KHI PASS RED P150 UG	Bajaj spare parts
52DH1598	TNK FLP RH W DKL KHI PASS RED P150 UG	Bajaj spare parts
52DH1599	SD CVR LH ASY DKL KHI PAS RD P150 UG	Bajaj spare parts
52DH1600	SD CVR RH ASY DKL KHI PAS RD P150 UG	Bajaj spare parts
52DH1601	FAIRING WH KHI PASS RED DKL P150 UG	Bajaj spare parts
52DH1603	SEAT COWL W DKL KHI PASS RED P150 UG	Bajaj spare parts
52DH1628	FUEL TANK WITH DECAL KHI EB.BLACK (P150	Bajaj spare parts
52DH1650	SD CVR LH ASY WH DKL SAFFIRE BLU P150	Bajaj spare parts
52DH1651	SD CVR RH ASY WH DKL SAFFIRE BLU P150	Bajaj spare parts
52DH1652	FAIRING WITH SAFFIRE BLUE DECAL(P150 BS4	Bajaj spare parts
52DH1654	SEAT COWL WITH DECALSAFFIRE BLUE (P150UG	Bajaj spare parts
52DH1657	TANK FLAP LH ASY WH DKL SAFFIRE BLU P150	Bajaj spare parts
52DH1658	TANK FLAP RH ASY WH DKL SAFFIRE BLU P150	Bajaj spare parts
52DH1660	SD CVR LH ASY WH DKL C.WINE RED P150	Bajaj spare parts
52DH1661	SD CVR RH ASY WH DKL C.WINE RED P150	Bajaj spare parts
52DH1662	FAIRING WITH C.WINE RED DECAL(P150 BS41	Bajaj spare parts
52DH1664	SEAT COWL WITH DECALC.WINE RED (P 150 UG	Bajaj spare parts
52DH1667	TANK FLAP LH ASY WH DKL C.WINE RED P150	Bajaj spare parts
52DH1668	TANK FLAP RH ASY WH DKL C.WINE RED P150	Bajaj spare parts
52DH1715	SD CVR LH ASY WH DKL MATTE PWTR GRY	Bajaj spare parts
52DH1716	SD CVR RH ASY WH DKL MATTE PWTR GRY	Bajaj spare parts
52DH1717	FAIRING WITH KHI EBONY BLACK DECAL	Bajaj spare parts
52DH1719	SEAT COWL WH DECAL KHI EBONY BLACK	Bajaj spare parts
52DH1721	FR. FENDER WH DKL KHI EBONY BLACK	Bajaj spare parts
52DH1723	TANK FLAP LH ASLY WH DKL KHI EB.BLK P150	Bajaj spare parts
52DH1724	TANK FLAP RH ASLY WH DKL KHI EB.BLK P150	Bajaj spare parts
52DH1786	SIDE COVER LH ASLY WH DKL ROYL BLU P150	Bajaj spare parts
52DH1787	SIDE COVER RH ASLY WH DKL ROYL BLU P150	Bajaj spare parts
52DH1788	FAIRING WITH ROYAL BLUE DECAL (P-150 BS4	Bajaj spare parts
52DH1790	SEAT COWL WH DKL ROYAL BLUE (P150 UG+BS4	Bajaj spare parts
52DH1792	TANK FLAP LH ASLY WH DKL ROYAL BLU (P150	Bajaj spare parts
52DH1876	TANK FLAP LH ASSLY WH DKL KHI EB BLK K1R	Bajaj spare parts
52DH1877	TANK FLAP RH ASSLY WH DKL KHI EB BLK K1R	Bajaj spare parts
52DH1883	SEAT COWL WH DECAL KHI EB. BLK K1R	Bajaj spare parts
52DH1887	FR. FENDER ASLY WH BRACE KHI EB. BLK K1R	Bajaj spare parts
52DH2001	FRONT FENDER ASSLY KHI EB.BLK CHROM K1R	Bajaj spare parts
52DH2009	FRONT FENDER ASSLY KHI EB.BLACK RED (K1R	Bajaj spare parts
52DH2010	TANK FLAP LH ASY DCL KHI EB.BLK RED K1R	Bajaj spare parts
52DH2011	TANK FLAP RH ASY DCL KHI EB.BLK RED K1R	Bajaj spare parts
52DH2014	SEAT COWL WH DCL KHI EBONY BLACK RED(K1R	Bajaj spare parts
52DH2016	SIDE COVER LH ASLY WH DCL C.WINE RED K1R	Bajaj spare parts
52DH2017	SIDE COVER RH ASLY WH DCL C.WINE RED K1R	Bajaj spare parts
52DH2136	FUEL TANK KHI EBY BLK K1R + 3D DCAL	Bajaj spare parts

52DH2137	FUEL TANK KHI EB BLK K1R + 3D DCAL BLUE	Bajaj spare parts
52DH2141	SIDE COVER LH ASSLY (PULSAR 150)	Bajaj spare parts
52DH2142	SIDE COVER RH ASSLY (PULSAR 150)	Bajaj spare parts
52DH2145	SEAT COWL DECAL KHI EBONY BLACK (P150	Bajaj spare parts
52DH2148	FUEL TANK W.DKL KHI EB.BLACK (PULSAR 150	Bajaj spare parts
52DH2389	SIDE COVER LH ASY PASION RED(P150 CLASIC	Bajaj spare parts
52DH2390	SIDE COVER RH ASY PASION RED(P150 CLASIC	Bajaj spare parts
52DH2392	SEAT COWL WH DKL PASION RED(P_150 CLASIC	Bajaj spare parts
52DH2396	GRAB HANDLE ASSLY SATIN RED(P_150 CLASIC	Bajaj spare parts
52DH2397	SEAT ASSLY PASSION RED (P_150 CLASSIC)	Bajaj spare parts
52DH2398	SIDE COVER LH ASY LIME GREEN(P150 CLASIC	Bajaj spare parts
52DH2399	SIDE COVER RH ASY LIME GREEN(P150 CLASIC	Bajaj spare parts
52DH2401	SEAT COWL WH DKL LIME GREEN(P_150 CLASIC	Bajaj spare parts
52DH2405	GRAB HANDLE ASY SATIN LIME GREEN(P_150	Bajaj spare parts
52DH2406	SEAT ASSLY LIME GREEN (P_150 CLASSIC)	Bajaj spare parts
52DH2447	SIDE COVER LH ASY PLA.SILVER(P150 CLASIC	Bajaj spare parts
52DH2448	SIDE COVER RH ASY PLA.SILVER(P150 CLASIC	Bajaj spare parts
52DH2450	SEAT COWL WH DKL PLA.SILVER(P_150 CLASIC	Bajaj spare parts
52DH2454	GRAB HANDLE ASY PLA.SILVER SATINN(P_150	Bajaj spare parts
52DH2455	SEAT ASSLY PLA. SILVER(P_150 CLASSIC)	Bajaj spare parts
52DH2498	K1R SEAT CWL - MATT VOLCANIC RED+DECAL	Bajaj spare parts
52DH2499	SEAT COWL K1R EBONY BLK CLIP NUT + DCL	Bajaj spare parts
52DH2548	SD CVR LH ASY C.BLK SPRTY ORNG(K1 CLASIC	Bajaj spare parts
52DH2549	SD CVR RH ASY C.BLK SPRTY ORNG(K1 CLASIC	Bajaj spare parts
52DH2556	GRAB HANDLE ASLY SPORTY ORANGE(K1 CLASIC	Bajaj spare parts
52DH2557	SEAT ASSLY SPORTY ORANGE(K1 CLASSIC	Bajaj spare parts
52DH2586	SEAT COWL K1R ABS EB BLACK + BLUE DECAL	Bajaj spare parts
52DH2616	K1 BELLY PAN LH E. BLACK + RED DECAL	Bajaj spare parts
52DH2617	K1 BELLY PAN RH E. BLACK + RED DECAL	Bajaj spare parts
52DH2620	K1 BELLY PAN LH E. BLACK + CHROME DECAL	Bajaj spare parts
52DH2621	K1 BELLY PAN RH E. BLACK + CHROME DECAL	Bajaj spare parts
52DH2624	K1 BELLY PAN LH SAFFIRE BLUE + CHROME DE	Bajaj spare parts
52DH2625	K1 BELLY PAN RH SAFFIRE BLUE + CHROME DE	Bajaj spare parts
52DH2628	K1 BELLY PAN LH CC WINE RED + CHROME DEC	Bajaj spare parts
52DH2629	K1 BELLY PAN RH CC WINE RED + CHROME DEC	Bajaj spare parts
52DH2651	K1 TANK CHARCOAL BLK+3D LIMEGREEN DECAL	Bajaj spare parts
52DH2704	K1 TANK EB.BLACK + 3D PASSION RED DECAL	Bajaj spare parts
52DH2705	K1 TANK EB.BLACK+3D PLAT. SILVER DECAL	Bajaj spare parts
52DH2706	K1 TANK CHARCOAL BLK+3DSPORTY ORAN DECAL	Bajaj spare parts
52DH2765	FINISH PART OF CRANKCASE RH DH102165	Bajaj spare parts
52DH2766	FINISH PART OF CRANKCASE LH DH102339	Bajaj spare parts
52DH2771	K1/K2 ABS TANK EB.BLK+3D PASS.RED DCAL	Bajaj spare parts
52DH2772	K1/K2 ABS TANK EB.BLK+3D PLAT. SLVR DCAL	Bajaj spare parts
52DH2773	K1/K2 ABS TANK CHAR.BLK+3D SP. ORAN DCAL	Bajaj spare parts
52DH2783	K2 FUEL TANK BS IV EB BLK + NEW DCAL	Bajaj spare parts

52DH2784	K2 FUEL TANK BS IV EB BLK + 3D DCAL	Bajaj spare parts
52DH2786	FUEL TANK BSIV EBONY BLACK WITH 3DDECAL	Bajaj spare parts
52DH2787	K2 FUEL TANK BS IV SAFFIRE BLUE+DECAL	Bajaj spare parts
52DH2788	K2 FUEL TANK BS IV SAFFIRE BLUE+3D DECAL	Bajaj spare parts
52DH2790	K2 FUEL TANK BS4 WINE RED+ 3D DECAL	Bajaj spare parts
52DH2913	FRAME ASSLY K1 PULSAR CKD (NEPAL)	Bajaj spare parts
52DH2937	K1/K1R BS6 TANK SAFFIRE BLUE +3D DECAL	Bajaj spare parts
52DH2939	K1/K1R BS6 FUEL TANK WINE RED + 3D DECAL	Bajaj spare parts
52DH2941	K1/K1R BS6 TANK EB.BLACK+ CHR.DEC+3D DEC	Bajaj spare parts
52DH2943	K1/K1R BS6 TANK EB.BLACK+ RED DEC+3D DEC	Bajaj spare parts
52DH2944	K1 COVER RR LH ASSLY SLT MATT GRAY BS6	Bajaj spare parts
52DH2966	K1R BS6 TANK EBONY BLACK + 3D DECAL	Bajaj spare parts
52DH2983	FUEL TANK EB BLK SUP SILVER DKL P125 CBS	Bajaj spare parts
52DH2994	GRAB HANDLE ASY NEON BLUE PULSAR-125 CBS	Bajaj spare parts
52DH2995	SEAT COWL WH DECAL EB BLK SOLAR RED(P125	Bajaj spare parts
52DH2997	SEAT COWL WH DECAL EB BLK PL SILVER(P125	Bajaj spare parts
52DH2999	SEAT COWL WH DECL CHAR BLK NEON BLU(P125	Bajaj spare parts
52DH3006	SEAT ASSLY SOLAR RED (P125 CBS )	Bajaj spare parts
52DH3010	K1 BELLY PAN RH E. BLACK + RED DECAL	Bajaj spare parts
52DH3011	K1 BELLY PAN LH E. BLACK + RED DECAL	Bajaj spare parts
52DH3016	K1 BELLY PAN RH E. BLACK + BLUE DECAL	Bajaj spare parts
52DH3017	K1 BELLY PAN LH E. BLACK + BLUE DECAL	Bajaj spare parts
52DH3019	SEAT COWL EBONY BLK CLIP NUT + RED DCL	Bajaj spare parts
52DH3023	SEAT COWL EBONY BLK CLIP NUT + BLUE DCL	Bajaj spare parts
52DH3025	FR FENDER WITH K19-B EBONY BLK RED	Bajaj spare parts
52DH3029	FR FENDER WITH K19-B EBONY BLK BLUE DKL	Bajaj spare parts
52DH3031	TANK FLAP RH EB BL WH RED DECL P125	Bajaj spare parts
52DH3033	TANK FLAP LH EB BL WH RED DECL P125	Bajaj spare parts
52DH3039	TANK FLAP RH EB BL WH BLU DECL P125	Bajaj spare parts
52DH3041	TANK FLAP LH EB BL WH BLU DECL P125	Bajaj spare parts
52DH3055	SIDE COVER LH ASY EB BLK SOLAR RED(P-125	Bajaj spare parts
52DH3056	SIDE COVER LH ASY CHAR BLK NEON BLU(P125	Bajaj spare parts
52DH3057	SIDE COVER RH ASY CHAR BLK NEON BLU(P125	Bajaj spare parts
52DH3058	SIDE COVER RH ASY EB BLK SOLAR RED(P-125	Bajaj spare parts
52DH3061	SEAT ASSLY NEON BLUE (P_125 CBS)	Bajaj spare parts
52DH3112	FUEL TANK EB BLK WITH SOLAR RED P125 CBS	Bajaj spare parts
52DH3114	FUEL TANK CHR BLK NEON BLU DKL P125 CBS	Bajaj spare parts
52DH3118	TANK ASSLY WITH DECAL EB BLK RED	Bajaj spare parts
52DH3120	TANK ASLY WH DCL VOLCANIC RED(P125 K19B	Bajaj spare parts
52DH3126	GRAB HANDLE ASSLY SOLAR RED(PUL-125 CBS)	Bajaj spare parts
52DH3189	K1 TANK DH141080CHAR BLACK+P.RED 3D DECA	Bajaj spare parts
52DH3237	TANKDH141080 CHAR.BLACK+LIME GREEN 3DDEC	Bajaj spare parts
52DH3355	K1 BS6 BELLY PAN LH EBONY BLACK+RED DECA	Bajaj spare parts
52DH3356	K1 BS6 BELLY PAN RH EBONY BLACK+RED DECA	Bajaj spare parts
52DH3357	K1 BS6 BELLY PAN LH EB. BLACK+CHROME DEC	Bajaj spare parts

52DH3358	K1 BS6 BELLY PAN RH EB. BLACK+CHROME DEC	Bajaj spare parts
52DH3359	K1 BS6 BELLY PAN LH CC WINE RED+DECAL	Bajaj spare parts
52DH3360	K1 BS6 BELLY PAN RH CC WINE RED+DECAL	Bajaj spare parts
52DH3361	K1 BS6 BELLY PAN LH SAFFIRE BLUE+DECAL	Bajaj spare parts
52DH3362	K1 BS6 BELLY PAN RH SAFFIRE BLUE+DECAL	Bajaj spare parts
52DH3452	K1 P150 CBS BELLYPAN LH EB.BLK+P.RED DEC	Bajaj spare parts
52DH3453	K1 P150 CBS BELLYPAN RH EB.BLK+P.RED DEC	Bajaj spare parts
52DH3455	K1 P150 CBS BELLYPAN RH EB.BLK+PLAT.SILV	Bajaj spare parts
52DH3456	K1 P150 CBS BELLYPAN LH EB.BLK+PLAT.SILV	Bajaj spare parts
52DH3461	BELLY PAN LH CHARCOAL BLACK+L GRN DECAL	Bajaj spare parts
52DH3462	BELLY PAN RH CHARCOAL BLACK+L GRN DECAL	Bajaj spare parts
52DH3568	K1R BS6 TANK EBONY BLK BLUE+ 3D DECAL	Bajaj spare parts
52DH3615	K1F BS6 TANK MATTE VOLCANIC RED+3D DECAL	Bajaj spare parts
52DH3623	K1 NEON BS6 TANKFLAP LH EB.BLK.+P.RED DE	Bajaj spare parts
52DH3625	K1 NEON BS6 TANKFLAP RH EB.BLK.+P.RED DE	Bajaj spare parts
52DH3627	K1 NEON BS6 TANK FLAP LH EB.BLK+S.SILV D	Bajaj spare parts
52DH3629	K1 NEON BS6 TANK FLAP RH EB.BLK+S.SILV D	Bajaj spare parts
52DH3631	K1 NEON BS6 TANKFLAP LH CHAR.BLK+L.GREEN	Bajaj spare parts
52DH3633	K1 NEON BS6 TANKFLAP RH CHAR.BLK+L.GREEN	Bajaj spare parts
52DH3635	K1 NEON BS6 TANK EB.BLK + P.RED 3D	Bajaj spare parts
52DH3636	K1 NEON BS6 TANK EB.BLK + PLAT.SILVER 3D	Bajaj spare parts
52DH3637	K1 NEON BS6 TANK CHAR.BLK+LIME GREEN 3D	Bajaj spare parts
52DH3688	TANK FLAP LH EB BLK W SO RED DKL K19 BS6	Bajaj spare parts
52DH3689	TANK FLAP LH EB BLK W PL SIL DKL K19 BS6	Bajaj spare parts
52DH3690	TANK FLAP LH CH BLK W NE BLU DKL K19 BS6	Bajaj spare parts
52DH3691	TANK FLAP RH EB BLK W SO RED DKL K19 BS6	Bajaj spare parts
52DH3692	TANK FLAP RH EB BLK W PL SIL DKL K19 BS6	Bajaj spare parts
52DH3693	TANK FLAP RH CH BLK W NE BLU DKL K19 BS6	Bajaj spare parts
52DH3694	TANK KHI EB BLK W SO RED DKL K19 BS6	Bajaj spare parts
52DH3696	TANK KHI EB BLK W PL SIL DKL K19 BS6	Bajaj spare parts
52DH3698	TANK CH BLK W NE BLU DKL K19 BS6	Bajaj spare parts
52DH3707	K1 NEON BS6 BELLY PAN LH CHR BLK+LIM GRN	Bajaj spare parts
52DH3708	K1 NEON BS6 BELLY PAN RH CHR BLK+LIM GRN	Bajaj spare parts
52DH3710	K1 NEON BS6 BELLY PAN LH EB BLK+P.RED	Bajaj spare parts
52DH3711	K1 NEON BS6 BELLY PAN RH EB BLK+P.RED	Bajaj spare parts
52DH3713	K1 NEON BS6 BELLY PAN LH EB BLK+SR.SILVR	Bajaj spare parts
52DH3714	K1 NEON BS6 BELLY PAN RH EB BLK+SR.SILVR	Bajaj spare parts
52DH3754	BELLY PAN LH EB BLK-SL RED K19C BS6	Bajaj spare parts
52DH3755	BELLY PAN RH EB BLK-SL RED K19C BS6	Bajaj spare parts
52DH3793	TANK FLAP LH ASY CH BLK K19C BS6	Bajaj spare parts
52DH3795	TANK FLAP RH ASY CH BLK K19C BS6	Bajaj spare parts
52DH3796	TANK CH BLK W TF GRN DKL K19C BS6	Bajaj spare parts
52DH3798	SEAT COWL W DKL CH BLK-TF GREEN K19C BS6	Bajaj spare parts
52DH3800	SIDE COVER LH ASY CH BLK-TF GRN K19C BS6	Bajaj spare parts
52DH3821	SIDE COVER RH ASY CH BLK-TF GRN K19C BS6	Bajaj spare parts

52DH3823	BELLY PAN LH CH BLK W TF GRN K19C BS6	Bajaj spare parts
52DH3824	BELLY PAN RH CH BLK W TF GRN K19C BS6	Bajaj spare parts
52DH3898	TANK FLAP LH ASY CH BLK W TF GRN K19C	Bajaj spare parts
52DH3899	TANK FLAP RH ASY CH BLK W TF GRN K19C	Bajaj spare parts
52DH3992	K1 BELLY PAN LH IN KHI EB BLK+BLUE DECAL	Bajaj spare parts
52DH3993	K1 BELLY PAN LH IN KHI EB BLK+RED DECAL	Bajaj spare parts
52DH3994	BELLY PAN LH(DH161620) VOLC RED+DECAL	Bajaj spare parts
52DH3995	K1 BELLY PAN RH IN KHI EB BLK+BLUE DECAL	Bajaj spare parts
52DH3996	K1 BELLY PAN RH IN KHI EB BLK+RED DECAL	Bajaj spare parts
52DH3997	BELLY PAN RH(DH161621) VOLC RED+DECAL	Bajaj spare parts
52DH4165	FAIRING K1 EB BLK+PEARL MET WHT DECL	Bajaj spare parts
52DH4166	FAIRING K1 EB BLK+SATIN SAF BLUE DECL	Bajaj spare parts
52DH4167	FAIRING K1 EB BLK+VOLCANIC RED DECL	Bajaj spare parts
52DH4168	FAIRING K1 EB BLK+SAT SPARK MAT BLK DECL	Bajaj spare parts
52DH4173	K1 TANK FLAP LH ASLY SATIN P.WHT W DECL	Bajaj spare parts
52DH4174	K1 TANK FLAP LH ASLY SATIN S.BLUE DECL	Bajaj spare parts
52DH4175	K1 TANK FLAP LH ASLY VOLCANIC RED DECL	Bajaj spare parts
52DH4176	K1 TANK FLAP LH ASLY SATIN S MET BLK DEC	Bajaj spare parts
52DH4177	K1 TANK FLAP RH ASLY SATIN S.BLUE DECL	Bajaj spare parts
52DH4178	K1 TANK FLAP RH ASLY VOLCANIC RED DECL	Bajaj spare parts
52DH4179	K1 TANK FLAP RH ASLY SATIN S MET BLK DEC	Bajaj spare parts
52DH4180	K1 TANK FLAP RH ASLY SATIN P.WHT DECL	Bajaj spare parts
52DH4181	K1 SIDE COVER LH ASSLY SATIN BLACK W DCL	Bajaj spare parts
52DH4182	K1 SIDE COVER RH ASSLY SATIN BLACK W DEC	Bajaj spare parts
52DH4184	K1 SEAT COWL WITH DCL PEARL M WHITE	Bajaj spare parts
52DH4187	K1 ABS FR FENDER EB.BLK+SAT.P.WHT DECAL	Bajaj spare parts
52DH4188	K1 ABS FR FENDER EB.BLK+RED DECAL	Bajaj spare parts
52DH4190	K1 SEAT COWL WITH DCL SATIN SAF BLUE	Bajaj spare parts
52DH4192	K1 SEAT COWL VOLCANIC RED WITH DCL	Bajaj spare parts
52DH4194	K1 SEAT COWL SATIN SP. BLK WITH DECAL	Bajaj spare parts
52DH4196	K1 BELLY PAN LH E. BLACK+P.MET WHT DECAL	Bajaj spare parts
52DH4197	K1 BELLY PAN RH E. BLACK+P.MET WHT DECAL	Bajaj spare parts
52DH4199	K1 BELLY PAN LH E. BLACK+SATIN BLUE DCL	Bajaj spare parts
52DH4200	K1 BELLY PAN RH E. BLACK+SATIN BLUE DCL	Bajaj spare parts
52DH4202	K1 BELLY PAN LH E. BLACK+VOL RED DCL	Bajaj spare parts
52DH4203	K1 BELLY PAN RH E. BLACK+VOL RED DCL	Bajaj spare parts
52DH4205	K1 BELLY PAN LH E. BLACK+SATIN S.BLK DCL	Bajaj spare parts
52DH4206	K1 BELLY PAN RH E. BLACK+SATIN S.BLK DCL	Bajaj spare parts
52DH4210	K1 BS6 TANK SATIN P.WHT+WHT DECAL+3D DEC	Bajaj spare parts
52DH4212	K1 BS6 TANK SATIN S.BLUE+BLUE DCL+3D DEC	Bajaj spare parts
52DH4214	K1 BS6 TANK VOL RED+RED DCL+3D DEC	Bajaj spare parts
52DH4216	K1 BS6 TANK SATIN SP.BLK+BLK DCL+3D DEC	Bajaj spare parts
52DH4231	K1R/K2 FLAP LH SATIN PEARL WHITE+DECAL	Bajaj spare parts
52DH4233	K1R/K2 FLAP RH SATIN PEARL WHITE+DECAL	Bajaj spare parts
52DH4235	K1R/K2 TANK FLAP LH SATIN S.BLUE+DECAL	Bajaj spare parts

52DH4237	K1R/K2 TANK FLAP RH SATIN S.BLUE+DECAL	Bajaj spare parts
52DH4239	K1R/K2 TANK FLAP LH VOL RED+DECAL	Bajaj spare parts
52DH4241	K1R/K2 TANK FLAP RH VOL RED+DECAL	Bajaj spare parts
52DH4243	K1R/K2 TANK FLAP LH SATIN S MET BLK+DEC	Bajaj spare parts
52DH4245	K1R/K2 TANK FLAP RH SATIN S MET BLK+DEC	Bajaj spare parts
52DH4246	SIDE CVR LH ASLY K1R CUBIC PRINT W GLOSS	Bajaj spare parts
52DH4247	SIDE CVR RH ASLY K1R CUBIC PRINT W GLOSS	Bajaj spare parts
52DH4249	K1R/K2/K3 FRNT FENDR EB BLACK + WHT DECL	Bajaj spare parts
52DH4251	K1R/K2/K3 FRNT FENDR EB BLACK + RED DECL	Bajaj spare parts
52DH4293	FRONT FENDER ASSLY KHI E.BLACK RED DECAL	Bajaj spare parts
52DH4294	FRONT FENDER ASSLY KHI E.BLACK WHITE DEC	Bajaj spare parts
52DH4354	SEAT COWL W DKL K EB BLK-SL RED K19A/C	Bajaj spare parts
52DH4356	SEAT COWL W DKL K EB BLK-PL SIL K19A/C	Bajaj spare parts
52DH4358	SEAT COWL W DKL CH BLK TF GRN K19C	Bajaj spare parts
52DH4367	TANK FLAP LH K EB BL-SL RED DKL K19A/C	Bajaj spare parts
52DH4368	TANK FLAP RH K EB BL-SL RED DKL K19A/C	Bajaj spare parts
52DH4369	TANK FLAP LH K EB BL-PL SIL DKL K19A/C	Bajaj spare parts
52DH4370	TANK FLAP RH K EB BL-PL SIL DKL K19A/C	Bajaj spare parts
52DH4371	TANK FLAP LH CH BLK-TF GRN DKL K19C	Bajaj spare parts
52DH4372	TANK FLAP RH CH BLK-TF GRN DKL K19C	Bajaj spare parts
52DH4373	TANK KHI EB BLK W SL RED DKL K19A/C BS6	Bajaj spare parts
52DH4374	TANK KHI EB BLK W PL SIL DKL K19A/C BS6	Bajaj spare parts
52DH4375	TANK CH BLK W TF GRN DKL K19C BS6	Bajaj spare parts
52DH4381	BELLY PAN LH KHI EB BLK-SL RED DKL K19C	Bajaj spare parts
52DH4382	BELLY PAN RH KHI EB BLK-SL RED DKL K19C	Bajaj spare parts
52DH4383	BELLY PAN LH KHI EB BLK-PL SIL DKL K19C	Bajaj spare parts
52DH4384	BELLY PAN RH KHI EB BLK-PL SIL DKL K19C	Bajaj spare parts
52DH4385	BELLY PAN LH CH BLK-TF GRN DKL K19C	Bajaj spare parts
52DH4386	BELLY PAN RH CH BLK-TF GRN DKL K19C	Bajaj spare parts
52DH4402	GRAB HANDLE ASSLY BLK SPR MAT K19A DI/DR	Bajaj spare parts
52DH4403	FAIRING K1 EBONY BLACK+P SILVER DECAL	Bajaj spare parts
52DH4404	FAIRING K1 NEON CHARCOAL BLK+L GREEN DEC	Bajaj spare parts
52DH4405	FAIRING K1 NEON EBONY BLACK+P RED DECAL	Bajaj spare parts
52DH4406	K1 NEON SEAT COWL CHAR BLACK+L GREEN DEC	Bajaj spare parts
52DH4407	K1 NEON SEAT COWL EBONY BLACK+PA RED DEC	Bajaj spare parts
52DH4408	K1 NEON SEAT COWL EBONY BLACK+SILVER DEC	Bajaj spare parts
52DH4409	FLAP LH K1 NEON EBONY BLACK+PA RED DECAL	Bajaj spare parts
52DH4410	FLAP RH K1 NEON EBONY BLACK+PA RED DECAL	Bajaj spare parts
52DH4411	FLAP LH K1 NEON EBONY BLACK+L GREEN DEC	Bajaj spare parts
52DH4412	FLAP RH K1 NEON CHARCOAL BLK+L GREEN DEC	Bajaj spare parts
52DH4413	FLAP LH K1 NEON EBONY BLACK+SILVER DECAL	Bajaj spare parts
52DH4414	FLAP RH K1 NEON EBONY BLACK+SILVER DECAL	Bajaj spare parts
52DH4415	TANK DH141089 E BLK+SILVER DECAL K1 NEON	Bajaj spare parts
52DH4416	TANK DH141089 CHAR BLK+L GRN DEC K1 NEON	Bajaj spare parts
52DH4417	TANK DH141089 E BLK+P RED DECAL K1 NEON	Bajaj spare parts

52DH4418	BELLY PAN LH C BLACK+L GREEN DEC K1 NEON	Bajaj spare parts
52DH4419	BELLY PAN RH C BLACK+L GREEN DEC K1 NEON	Bajaj spare parts
52DH4420	BELLY PAN LH EB BLK+SILVER DECAL K1 NEON	Bajaj spare parts
52DH4421	BELLY PAN RH EB BLK+SILVER DECAL K1 NEON	Bajaj spare parts
52DH4422	BELLY PAN LH EB BLK+P RED DECAL K1 NEON	Bajaj spare parts
52DH4423	BELLY PAN RH EB BLK+P RED DECAL K1 NEON	Bajaj spare parts
52DH4427	SD CVR LH KHI EB BLK- E BLK MESH K19A/C	Bajaj spare parts
52DH4428	SD CVR RH KHI EB BLK- E BLK MESH K19A/C	Bajaj spare parts
52DH4430	SD CVR LH CHARCOAL BLK K19C DISC/DRUM	Bajaj spare parts
52DH4431	SD CVR RH CHARCOAL BLK K19C DISC/DRUM	Bajaj spare parts
52DH4461	K1 NEON SIDE COVER LH ASSLY SATIN BLK	Bajaj spare parts
52DH4462	K1 NEON SIDE COVER RH ASSLY SATIN BLK	Bajaj spare parts
52DH4526	FAIRING K EB BL-SL RED DKL K19A/C DI/DR	Bajaj spare parts
52DH4527	FAIRING K EB BL-PL SIL DKL K19A/C DI/DR	Bajaj spare parts
52DH4528	FAIRING CH BLK-TF GRN DKL K19C DI/DR	Bajaj spare parts
52DH4617	K1ABS FR FENDER EB.BLK+SMB SILVER DCL	Bajaj spare parts
52DH4619	FAIRING K1 EB BLK+SMB SILVER DCL K1 BS6	Bajaj spare parts
52DH4620	K1 TANK FLAP LH ASLY SPRK MAT BLK+SL DCL	Bajaj spare parts
52DH4621	K1 TANK FLAP RH ASLY SPRK MAT BLK+SL DCL	Bajaj spare parts
52DH4623	K1 SEAT COWL WITH SPARK MAT BLK+SL DCL	Bajaj spare parts
52DH4625	K1BELLY PAN LH E.BLK+SPRK MAT BLK+SL DCL	Bajaj spare parts
52DH4626	K1BELLY PAN RH E.BLK+SPRK MAT BLK+SL DCL	Bajaj spare parts
52DH4627	K1BS6 TANK SPR MAT BLK+SILVER DCL+3D DEC	Bajaj spare parts
52DH4632	K1 ABS FR FENDER EB.BLK+SF BLU WHT DCL	Bajaj spare parts
52DH4634	K1BS6FAIRING EB BLK+SF BLU-WHITE DCL	Bajaj spare parts
52DH4635	K1 TANK FLAP LH ASLY SAFIR BLU+WHT DCL	Bajaj spare parts
52DH4636	K1 TANK FLAP RH ASLY SAFIR BLU+WHT DCL	Bajaj spare parts
52DH4638	K1 SEAT COWL WITH SAFIR BLUE+WHITE DCL	Bajaj spare parts
52DH4640	K1 BELLY PAN LH E.BLK+SAF BLUE-WHITE DCL	Bajaj spare parts
52DH4641	K1 BELLY PAN RH E.BLK+SAF BLUE-WHITE DCL	Bajaj spare parts
52DH4642	K1 BS6 TANK SAF BLUE + WHITE DCL+3D DEC	Bajaj spare parts
52DH4647	K1 ABS FR FENDER EB.BLK+SMB BLUE DCL	Bajaj spare parts
52DH4649	FAIRING EB BLK+SPAK M BLK+BLUE DCL K1BS6	Bajaj spare parts
52DH4650	K1TANK FLAP LH ASLY SPR MAT BLK+BLUE DCL	Bajaj spare parts
52DH4651	K1TANK FLAP RH ASLY SPR MAT BLK+BLUE DCL	Bajaj spare parts
52DH4653	K1SEAT COWL WITH SPRK MAT BLK+BLU DCL	Bajaj spare parts
52DH4655	K1BELLY PAN LH E.BLK+SPRK MAT BLK+BLU DCL	Bajaj spare parts
52DH4656	K1BELLY PAN RH E.BLK+SPRK MAT BLK+BLU DCL	Bajaj spare parts
52DH4657	K1BS6 TANK SPR MAT BLK+BLU DCL+3D DEC	Bajaj spare parts
52DH4662	K1 ABS FR FENDER EB.BLK+SMB RED DCL	Bajaj spare parts
52DH4664	K1BS6FAIRING EB BLK+SPR M BLK-RED DCL	Bajaj spare parts
52DH4665	K1TANK FLAP LH ASLY SPARK MAT BLK+RED DC	Bajaj spare parts
52DH4666	K1TANK FLAP RH ASLY SPRK MAT BLK+RED DCL	Bajaj spare parts
52DH4668	K1SEAT COWL WITH SPRK MAT BLK+RED DCL	Bajaj spare parts
52DH4670	K1BELLY PAN LH E.BLK+SPRK MAT BLK+RED DCL	Bajaj spare parts



52DH4671	K1BELY PAN RH E.BLK+SPRK MAT BLK+RED DCL	Bajaj spare parts
52DH4672	K1BS6 TANK SPR MAT BLK+RED DCL+3D DEC	Bajaj spare parts
52DH4682	K1R/K2 TANK FLAP LH SPR MAT BLK+SLV DCL	Bajaj spare parts
52DH4684	K1R/K2 TANK FLAP RH SPR MAT BLK+SLV DCL	Bajaj spare parts
52DH4691	K1R/K2 TANK FLAP LH SAFIR BLU+WHT DCL	Bajaj spare parts
52DH4693	K1R/K2 TANK FLAP RH SAFIR BLU+WHT DCL	Bajaj spare parts
52DH4700	K1R/K2 TANK FLAP LH SPR MAT BLK+BLU DCL	Bajaj spare parts
52DH4702	K1R/K2 TANK FLAP RH SPR MAT BLK+BLU DCL	Bajaj spare parts
52DH4709	K1R/K2 TANK FLAP LH SPR MAT BLK+RED DCL	Bajaj spare parts
52DH4711	K1R/K2 TANK FLAP RH SPR MAT BLK+RED DCL	Bajaj spare parts
52DH4768	K1R TANK SPR MAT BLK+SILVER DCL+3D DEC	Bajaj spare parts
52DH4770	K1R TANK SAF BLUE + WHITE DCL+3D DEC	Bajaj spare parts
52DH4772	K1R TANK SPR MAT BLK+BLU DCL+3D DEC	Bajaj spare parts
52DH4774	K1R TANK SPR MAT BLK+RED DCL+3D DEC	Bajaj spare parts
52DH5061	SEAT COWL W DKL K EB BLK-SL RED K19A/C	Bajaj spare parts
52DH5063	SEAT COWL W DKL K EB BLK-PL SIL K19A/C	Bajaj spare parts
52DH5065	SEAT COWL W DKL CH BLK TF GRN K19A/C	Bajaj spare parts
52DH5067	FAIRING K EB BL-SL RED DKL K19A/C DI/DR	Bajaj spare parts
52DH5068	FAIRING K EB BL-PL SIL DKL K19A/C DI/DR	Bajaj spare parts
52DH5069	FAIRING CH BLK-TF GRN DKL K19A/CC DI/DR	Bajaj spare parts
52DH5077	TANK FLAP LH K EB BL-SL RED DKL K19A/C	Bajaj spare parts
52DH5078	TANK FLAP RH K EB BL-SL RED DKL K19A/C	Bajaj spare parts
52DH5079	TANK FLAP LH K EB BL-PL SIL DKL K19A/C	Bajaj spare parts
52DH5080	TANK FLAP RH K EB BL-PL SIL DKL K19A/C	Bajaj spare parts
52DH5081	TANK FLAP LH CH BLK-TF GRN DKL K19A/C	Bajaj spare parts
52DH5083	TANK FLAP RH CH BLK-TF GRN DKL K19A/C	Bajaj spare parts
52DH5084	TANK KHI EB BLK W SL RED DKL K19A/C BS6	Bajaj spare parts
52DH5085	TANK KHI EB BLK W PL SIL DKL K19A/C BS6	Bajaj spare parts
52DH5086	TANK CH BLK W TF GRN DKL K19A/C BS6	Bajaj spare parts
52DH5314	K1NEON BS6 TANK CLASSIC WHT+3D WHITE DEC	Bajaj spare parts
52DH5512	FAIRING K EB BLK W SIL DKL K19A/C DI/DR	Bajaj spare parts
52DH5513	FAIRING K EB BLK W BLU DKL K19A/C DI/DR	Bajaj spare parts
52DH5514	FAIRING K EB BLK W RED DKL K19A/C DI/DR	Bajaj spare parts
52DH5515	FAIRING K EB BLK W WHT DKL K19A/C DI/DR	Bajaj spare parts
52DH5524	TANK SP M BLK W SIL DKL K19A/C DI/DR BS6	Bajaj spare parts
52DH5525	TANK SP M BLK W BLU DKL K19A/C DI/DR BS6	Bajaj spare parts
52DH5526	TANK SP M BLK W RED DKL K19A/C DI/DR BS6	Bajaj spare parts
52DH5536	SEAT COWL SP M BLK W SIL DK K19A/C DI/DR	Bajaj spare parts
52DH5537	SEAT COWL SP M BLK W BLU DK K19A/C DI/DR	Bajaj spare parts
52DH5538	SEAT COWL SP M BLK W RED DK K19A/C DI/DR	Bajaj spare parts
52DH5539	SEAT COWL SF BLUE W WHT DKL K19A/C DI/DR	Bajaj spare parts
52DJ0166	CASE CHAIN ASSY BLACK PUL	Bajaj spare parts
52DJ0357	FLAP TANK ASSY LH WINE RE	Bajaj spare parts
52DJ0358	FLAP TANK RH C WINE RED	Bajaj spare parts
52DJ0359	FLAP TANK ASSY LH PL BLUE	Bajaj spare parts

52DJ0360	FLAP TANK ASSY RH PL BLUE	Bajaj spare parts
52DJ0363	FLAP TANK ASSY LH MID BLA	Bajaj spare parts
52DJ0364	FLAP TANK ASSY RH MID BLA	Bajaj spare parts
52DJ0373	TANK FLAP LH UNPAINTED	Bajaj spare parts
52DJ0374	TANK FLAP ASSY RH K2 UG4 UNPAINTED	Bajaj spare parts
52DJ0390	CLUTCH COVER WITH TA	Bajaj spare parts
52DJ0416	STEP HOLDER RH (JC) SHEEN	Bajaj spare parts
52DJ0517	FAIRING BLACK+SAF BLUE DCL	Bajaj spare parts
52DJ0518	FAIRING BLACK+M WHITE DCL	Bajaj spare parts
52DJ0519	FAIRING BLACK+W RED DCL	Bajaj spare parts
52DJ0520	FRONT FENDER ASSLY SAFFIRE BLUE	Bajaj spare parts
52DJ0521	FRONT FENDER ASSLY METTALIC WHITE	Bajaj spare parts
52DJ0522	FRONT FENDER ASSLY WINE RED	Bajaj spare parts
52DJ0523	K2 FLAP LH BLACK+S BLUE DCL	Bajaj spare parts
52DJ0524	K2 FLAP RH BLACK+S BLUE DCL	Bajaj spare parts
52DJ0526	K2 FLAP RH BLACK+M WHITE DCL	Bajaj spare parts
52DJ0527	K2 FLAP LH BLACK+W RED DCL	Bajaj spare parts
52DJ0531	SEAT COWL ASLY WITH T LAMP WINE RED	Bajaj spare parts
52DJ0532	COVER SIDE LH SAFFIRE BLUE	Bajaj spare parts
52DJ0533	COVER SIDE RH SAFFIRE BLUE	Bajaj spare parts
52DJ0534	COVER SIDE LH MET WHITE	Bajaj spare parts
52DJ0535	COVER SIDE RH METTALIC WHITE	Bajaj spare parts
52DJ0536	COVER SIDE LH WINE RED	Bajaj spare parts
52DJ0537	COVER SIDE RH WINE RED	Bajaj spare parts
52DJ0545	P TANK K1/K2 M BLACK+W RED DCL	Bajaj spare parts
52DJ0546	P TANK K1/K2 M BLACK+S BLUE DCL	Bajaj spare parts
52DJ0547	P TANK K2 M BLACK+M WHITE DCL	Bajaj spare parts
52DJ0555	TANK FUAL K1/K2 EBONY BLACK+CW RED DCL	Bajaj spare parts
52DJ0556	TANK FUAL K1/K2 EBONY BLACK	Bajaj spare parts
52DJ0557	TANK FUAL M WHITE DCL	Bajaj spare parts
52DJ0562	COVER SIDE LH WITH E BLACK	Bajaj spare parts
52DJ0563	COVER SIDE RH WITH E BLACK	Bajaj spare parts
52DJ0565	FRONT FENDER ASSLY E BLACK	Bajaj spare parts
52DJ0566	FAIRING WITH CHROME DECAL	Bajaj spare parts
52DJ0568	K2 FLAP RH PAINTED BLACK WITH DECAL	Bajaj spare parts
52DJ0577	FAIRING WITH DECAL W RED	Bajaj spare parts
52DJ0578	FAIRING WITH M WHITE DECAL	Bajaj spare parts
52DJ0625	TANK FUEL K1/K2 EB BLK + CHROME DECAL	Bajaj spare parts
52DJ0640	TANK FLAP ASSLY LH K2 EBONY BLACK DECAL	Bajaj spare parts
52DJ0641	TANK FLAP ASSLY RH K2 EBONY BLACK DECAL	Bajaj spare parts
52DJ0838	TANK FUAL K2 BS IV EBONY BLACK WITH CLEA	Bajaj spare parts
52DJ0904	FAIRING K2 EBONY BLACK WITH DECAL	Bajaj spare parts
52DJ0905	FLAP LH K2 EBONY BLACK WITH DECAL	Bajaj spare parts
52DJ0906	FLAP RH K2 EBONY BLACK WITH DECAL	Bajaj spare parts
52DJ0909	SEAT COWL K2 BSIV EBONY BLACK WITH DEC	Bajaj spare parts

52DJ0943	FLAP LH K2 ROYAL BLUE + DECAL	Bajaj spare parts
52DJ0944	FLAP RH K2 ROYAL BLUE + DECAL	Bajaj spare parts
52DJ0945	SEAT COWL K2 ROYAL BLUE + DECAL	Bajaj spare parts
52DJ0946	K2 FUEL TANK BSIV ROYAL BLUE + DCAL	Bajaj spare parts
52DJ0951	ASSLY COVER SIDE LH K2/K3 EB BLK	Bajaj spare parts
52DJ0952	ASSLY COVER SIDE RH K2/K3 EB BLK	Bajaj spare parts
52DJ0956	ASSLY COVER SIDE LH K2/K3 RO BLUE	Bajaj spare parts
52DJ0957	ASSLY COVER SIDE RH K2/K3 RO BLUE	Bajaj spare parts
52DJ0999	FLAP LH K2 FLAME RED WITH DECAL	Bajaj spare parts
52DJ1000	FLAP RH K2 FLAME RED WITH DECAL	Bajaj spare parts
52DJ1001	SEAT COWL K2 FLAME RED WITH DECAL	Bajaj spare parts
52DJ1002	K2 FUEL TANK BSIV FL RED WITH DECAL	Bajaj spare parts
52DJ1013	"FRONT FENDER ASSLY K2 K3 FLAME RED	Bajaj spare parts
52DJ1041	K2 UG BS3 FUEL TANK EBONY BLK + 3D DCAL	Bajaj spare parts
52DJ1042	K2 BS3 FUEL TANK ROYAL BLUE	Bajaj spare parts
52DJ1045	K2 UG FUEL TANK BS3 FLAME RED	Bajaj spare parts
52DJ1072	SEAT COWL K2 ROYAL BLUE + NEW DECAL	Bajaj spare parts
52DJ1074	SEAT COWL K2 EBONY BLACK + NEW DCAL	Bajaj spare parts
52DJ1085	FLAP LH K2 EBONY BLACK + NEW DCAL	Bajaj spare parts
52DJ1087	FLAP RH K2 EBONY BLACK + NEW DCAL	Bajaj spare parts
52DJ1089	FLAP LH K2 ROYAL BLUE + NEW DCAL	Bajaj spare parts
52DJ1091	FLAP RH K2 ROYAL BLUE + NEW DCAL	Bajaj spare parts
52DJ1096	K2 FUEL TANK BS4 ROYAL BLUE + NEWDCAL	Bajaj spare parts
52DJ1115	SEAT COWL K2 PASSION RED+DECAL	Bajaj spare parts
52DJ1117	FLAP LH K2 PASSION RED+DECAL	Bajaj spare parts
52DJ1118	FLAP RH K2 PASSION RED+DECAL	Bajaj spare parts
52DJ1119	K2 FUEL TANK BS IV PASSION RED+DECAL	Bajaj spare parts
52DJ1171	K2 SEAT COWL SAFFIRE BLUE DECAL	Bajaj spare parts
52DJ1173	K2 SEAT COWL COCKTAIL WINE RED DECAL	Bajaj spare parts
52DJ1179	K2 FLAP LH SAFFIRE BLUE DECAL	Bajaj spare parts
52DJ1181	K2 FLAP RH SAFFIRE BLUE DECAL	Bajaj spare parts
52DJ1183	K2 FLAP LH COCKTAIL WINE RED DECAL	Bajaj spare parts
52DJ1185	K2 FLAP RH COCKTAIL WINE RED DECAL	Bajaj spare parts
52DJ1188	K2 FUEL TANK BS4 COCKTAIL WINE REDDECAL	Bajaj spare parts
52DJ1208	FRONT FENDOR EB BLACK K2/K3 WITH DECAL	Bajaj spare parts
52DJ1213	FLAP LH K2 EBONY BLACK WITH DECAL	Bajaj spare parts
52DJ1214	FLAP RH K2 EBONY BLACK WITH DECAL	Bajaj spare parts
52DJ1235	SEAT COWL K2 ROYAL BLUE + DCAL	Bajaj spare parts
52DJ1237	K2 FUEL TANK BSIV ROYAL BLUE + DCAL + LQ	Bajaj spare parts
52DJ1241	P 180 BS3 TANK WINE RED +2D + 3D DCAL	Bajaj spare parts
52DJ1298	K2 FUEL TANK BS IV EB BLK + 3D DCAL	Bajaj spare parts
52DJ1299	K2 FUEL TANK BS IV SAFFIRE BLUE+3D DECAL	Bajaj spare parts
52DJ1300	K2 FUEL TANK BS4 WINE RED+ 3D DECAL	Bajaj spare parts
52DJ1301	K2 FUEL TANK BS IV EBONY BLACK + 3D DECA	Bajaj spare parts
52DJ1327	K2 FUEL TANK EB BLK + CROME DCL+3D DCL	Bajaj spare parts

52DJ1437	ASSEMBLY	Bajaj spare parts
52DJ1438	ASSEMBLY	Bajaj spare parts
52DJ1439	K1R/K2/K3 BELY PAN LH VLCNIC RED+DCL	Bajaj spare parts
52DJ1440	ASSEMBLY	Bajaj spare parts
52DJ1441	K2 SEAT COWL - MATT VOLCANIC RED + DECAL	Bajaj spare parts
52DJ1442	K1R/K2/K3 FRNT FNDR MAT VOLCANIC RED+DCL	Bajaj spare parts
52DJ1444	K1R/K2 FLAP LH EBONY BLACK + DECAL	Bajaj spare parts
52DJ1445	K1R/K2 FLAP RH EBONY BLACK + DECAL	Bajaj spare parts
52DJ1446	K1R/K2/K3- BELLY PAN LH -KHI EB BLK+DCL	Bajaj spare parts
52DJ1447	K1R/K2/K3- BELLY PAN RH -KHI EB BLK+DCL	Bajaj spare parts
52DJ1448	SEAT COWL K2 EBONY BLACK CLIP NUT + DCL	Bajaj spare parts
52DJ1449	K1R/K2/K3 FRNT FENDR EB BLACK + DECAL	Bajaj spare parts
52DJ1454	ASLY CUBIC PRINTED SIDE CVR LH K1R/K2/K3	Bajaj spare parts
52DJ1455	ASLY CUBIC PRINTED SD CVR RH K1R/K2/K3	Bajaj spare parts
52DJ1483	K1R/K2 BS4 TANK IN KHI EB BLK	Bajaj spare parts
52DJ1497	K1/K2/K1R ABS EB BLACK / BLUE DCL+3D DCL	Bajaj spare parts
52DJ1498	FLAP LH K1R/K2 EBONY BLACK +BLUE DECAL	Bajaj spare parts
52DJ1499	FLAP RH K1R/K2 EBONY BLACK + BLUE DECAL	Bajaj spare parts
52DJ1500	K1R/K2/K3 BELY PAN LH KHI EB BLK+BLU DCL	Bajaj spare parts
52DJ1501	K1R/K2/K3 ABS BELY PAN RH EB BK+BLU DCL	Bajaj spare parts
52DJ1502	K1R/K2/K3 ABS FR FENDER EB BLK+BLU DCL	Bajaj spare parts
52DJ1513	SEAT COWL K2 EB BLACK + BLU DCL	Bajaj spare parts
52DJ1518	K1R/K2 NON ABS TNK KHI EB BK+BLU DCL+3D	Bajaj spare parts
52DJ1551	TANK K1 K2 K1R ABS EB BLK /RED DCL+3D DC	Bajaj spare parts
52DJ1552	TANK K1 K2 K1R ABS VOLCANIC RED+3D DCL	Bajaj spare parts
52DJ1617	K2 BS3 EBONY BLACK TANK +3 D DECAL	Bajaj spare parts
52DJ1618	K2 HF FRT. FAIRING E.BLACK+ P. RED DECAL	Bajaj spare parts
52DJ1621	K2 HF SEAT COWL E. BLACK+PAS RED DECAL	Bajaj spare parts
52DJ1633	K2 FRONT FENDER IN CHARCOAL BLACK	Bajaj spare parts
52DJ1634	K2 HF FRT FRNG EBLK+ SILVER DCAL	Bajaj spare parts
52DJ1636	K2 HF FRT. FRNG CHAR BLK+SP. ORNG	Bajaj spare parts
52DJ1639	K2 HF SEAT COWL E. BLACK+ SILVER DECAL	Bajaj spare parts
52DJ1641	K2 HF SEAT COWL CHAR.BLACK+ SP.ORG. DECA	Bajaj spare parts
52DJ1778	K2HF BS6 TANK EB.BLK+3D PASS.RED DCL ABS	Bajaj spare parts
52DJ1779	K2HF BS6 TANK EB.BLK+3D PLAT.SILVER DCL	Bajaj spare parts
52DJ1788	K2HF BS4 TANK-EBONY BLACK+P.RED 3D DEC	Bajaj spare parts
52DJ1789	K2HF BS4 TANK-EBONY BLACK+SILVER 3D DEC	Bajaj spare parts
52DJ1790	K2HF ABS TANK-EBONY BLACK+ P.RED 3D DEC	Bajaj spare parts
52DJ1791	K2HF ABS TANK-EBONY BLACK+ SILVER 3D DEC	Bajaj spare parts
52DJ1801	K2 BELLY PAN LH EBONY BLACK+RED DECAL	Bajaj spare parts
52DJ1802	K2 BELLY PAN RH EBONY BLACK+RED DECAL	Bajaj spare parts
52DJ1805	K2 ABS FUEL TANK EB. BLACK+P.RED 3D DECA	Bajaj spare parts
52DJ1806	K2 SEAT COWL EB BLACK+P.SILVER 3D DECAL	Bajaj spare parts
52DJ1807	K2 BELLY PAN LH EB BLACK+P. SILVER DECAL	Bajaj spare parts
52DJ1808	K2 BELLY PAN RH EB BLACK+P. SILVER DECAL	Bajaj spare parts

52DJ1811	K2 ABS FUEL TANK EB. BLACK+P.SIL 3D DECA	Bajaj spare parts
52DJ1845	K2HF BELLY PAN LH EB. BLK + PASS.RED DEC	Bajaj spare parts
52DJ1846	K2HF BELLY PAN RH EB. BLK + PASS.RED DEC	Bajaj spare parts
52DJ1848	K2HF BELLY PAN RH EB.BLK + PLAT.SILV DEC	Bajaj spare parts
52DJ1849	K2HF BELLY PAN LH EB.BLK + PLAT.SILV DEC	Bajaj spare parts
52DJ1851	K2HF BELLY PAN LH CHAR.BLK+SP.ORANGE DEC	Bajaj spare parts
52DJ1852	K2HF BELLY PAN RH CHAR.BLK+SP.ORANGE	Bajaj spare parts
52DJ2048	K2HFBELLYPANLHDH161620EBLKPASSREDDECAL	Bajaj spare parts
52DJ2049	K2HF BELLYPANRHDH161621 EBLK +PASS RED D	Bajaj spare parts
52DJ2050	K2HFBELLYPANLH DH161620EBLK+P.SILVER DEC	Bajaj spare parts
52DJ2051	K2H(DH161621 BELLY PAN RH EBLK+P.SILDEC	Bajaj spare parts
52DJ2052	K2LH BELLYPANL DH161620 CHABLK+S.ORGDECA	Bajaj spare parts
52DJ2053	K2HF BELLYPANRHDH161621CHABLK+S.ORGDECAL	Bajaj spare parts
52DJ2080	K2 SEAT COWL WITH DCL PEARL M WHITE	Bajaj spare parts
52DJ2082	K2 SEAT COWL WITH DCL SATIN SAF BLUE	Bajaj spare parts
52DJ2084	K2 SEAT COWL VOLCANIC RED WITH DCL	Bajaj spare parts
52DJ2086	K2 SEAT COWL SATIN SP. BLK WITH DECAL	Bajaj spare parts
52DJ2126	PIPE VALVE PURGE(DH102461)WITH CLAMP ASL	Bajaj spare parts
52DJ2186	SIDE COVER LH ASSLY CHAR.BLK NEW C&G	Bajaj spare parts
52DJ2187	SIDE COVER RH ASSLY CHAR .BLK NEW C&G	Bajaj spare parts
52DJ2233	K2 SEAT COWL WITH SPARK MAT BLK+SL DCL	Bajaj spare parts
52DJ2235	K2 SEAT COWL WITH SAFIR BLUE+WHITE DCL	Bajaj spare parts
52DJ2237	K2 SEAT COWL WITH SPRK MAT BLK+BLU DCL	Bajaj spare parts
52DJ2239	K2 SEAT COWL WITH SPRK MAT BLK+RED DCL	Bajaj spare parts
52DK0013	FENDER FR W/T MASKING	Bajaj spare parts
52DK0027	SEAT COWL WITH GROMM	Bajaj spare parts
52DK0078	BRACKET SET STAY LH RH K3	Bajaj spare parts
52DK0144	FRAME FAIRING & OIL COOLE	Bajaj spare parts
52DK0167	STEP HOLDER LH (K3) SHEEN	Bajaj spare parts
52DK0168	STEP HOLDER RH	Bajaj spare parts
52DK0200	FAIRING (DK75042V)W/ RED DECAL	Bajaj spare parts
52DK0201	FAIRING (DK75044K)W/BLU DECAL	Bajaj spare parts
52DK0203	MAGNETO LH COVER ASSLY	Bajaj spare parts
52DK0204	COVER RH ASSLY MOONLIGHT	Bajaj spare parts
52DK0207	STEP HOLDER ASSY LH K2/K3	Bajaj spare parts
52DK0260	SEAT COWL ASLY WITH T LAMP SAFFIRE BLUE	Bajaj spare parts
52DK0261	SEAT COWL ASLY WITH T LAMP METTALIC WHIT	Bajaj spare parts
52DK0263	FAIRING P220 C W RED WITH DECAL	Bajaj spare parts
52DK0264	FAIRING P220 SAFFIRE BLUE WITH DECAL	Bajaj spare parts
52DK0265	FAIRING P220 METALLIC WHITE WITH DECAL	Bajaj spare parts
52DK0267	P TANK K3 SF M BLK+W RED DCL	Bajaj spare parts
52DK0268	P TANK K3 SF M BLK+W RED DCL	Bajaj spare parts
52DK0269	P TANK K3 SF M BLK + SAF BLUE DCL	Bajaj spare parts
52DK0271	PETROL TANK 220 SF EBONY BLK + CW RED DC	Bajaj spare parts
52DK0272	PETROL TANK 220 SF EBONY BLK + SAF BLUE	Bajaj spare parts

52DK0273	SEAT COWL ASLY WITH T LAMP EBONY BLACK	Bajaj spare parts
52DK0274	P220 FAIRING WITH DECAL	Bajaj spare parts
52DK0277	FAIRING E BLACK WITH SAFFIRE BLUE DECAL	Bajaj spare parts
52DK0278	FAIRING E BLACK WITH WINE RED DECAL	Bajaj spare parts
52DK0295	TANK FUEL K3 EB BLK + Chrome Decal	Bajaj spare parts
52DK0334	ROTOR ASSEMBLY WITH STARTER CLUTCH AND S	Bajaj spare parts
52DK0631	FAIRING K3 EBONY BLACK WITH DECAL	Bajaj spare parts
52DK0632	SEAT COWL K3 EBONY BLACK WITH DECAL	Bajaj spare parts
52DK0662	FAIRING K3 ROYAL BLUE + DECAL	Bajaj spare parts
52DK0663	SEAT COWL K3 ROYAL BLUE + DECAL	Bajaj spare parts
52DK0687	SF FOR ASSLY MAGNETO COVER DK101766_BS4	Bajaj spare parts
52DK0688	SF FOR ASSLY CLUTCH COVER DK101765_BS4	Bajaj spare parts
52DK0691	SF FOR ASSLY MAGNETO COVER DK101766_BS4	Bajaj spare parts
52DK0721	K3 FUEL TANK BSIV EB BLK 3D DECAL	Bajaj spare parts
52DK0722	K3 FUEL TANK BSIV ROYAL BLUE DECAL	Bajaj spare parts
52DK0726	SEAT COWL K3 FLAME RED DECAL	Bajaj spare parts
52DK0728	K3 FUEL TANK BSIV FLAME RED	Bajaj spare parts
52DK0821	SEAT COWL EBONY BLACK K3 BS4 NEW DCAL	Bajaj spare parts
52DK0823	SEAT COWL ROYAL BLUE K3 BS4 NEW DCAL	Bajaj spare parts
52DK0825	FAIRING K3 EB BLK BS4 NEW DCAL	Bajaj spare parts
52DK0827	FAIRING K3 ROYAL BLUE BS4 NEW DCAL	Bajaj spare parts
52DK0832	K3 FUEL TANK BS4 ROYAL BLUE + NEW DCAL	Bajaj spare parts
52DK0857	K3 FUEL TANK BS IV PASSION RED+DECAL	Bajaj spare parts
52DK0902	K3 SEAT COWL SAFFIRE BLUE DECAL	Bajaj spare parts
52DK0906	K3 FAIRING SAFFIRE BLUE DECAL	Bajaj spare parts
52DK0908	K3 FAIRING COCKTAIL WINE RED DECAL	Bajaj spare parts
52DK0911	K3 FUEL TANK BS4 COCKTAIL WINE REDDECAL	Bajaj spare parts
52DK0953	K3 SEAT COWL EBONY BLACK WITH DECAL	Bajaj spare parts
52DK0954	K3 FAIRING EBONY BLACK	Bajaj spare parts
52DK1007	K3 FUEL TANK BS4 EB BLK + 3D DCAL	Bajaj spare parts
52DK1009	K3 FUEL TANK BS4 SAFFIRE BLUE+ 3D DECAL	Bajaj spare parts
52DK1164	K3 SEAT COWL - MATT VOLCANIC RED + DECAL	Bajaj spare parts
52DK1165	SEAT COWL K3 EBONY BLACK CLIP NUT + DCL	Bajaj spare parts
52DK1170	K3 FRT FAIRING MATT VOLCANIC RED + DECAL	Bajaj spare parts
52DK1171	K3 FAIRING EBONY BLACK + DECAL	Bajaj spare parts
52DK1188	K3 BS4 TANK IN KHI EB BLK+3D DCL	Bajaj spare parts
52DK1194	K3 ABS BS4 TANK EB BLK+ 3D DCL	Bajaj spare parts
52DK1198	FAIRING K3 EBONY BLACK + BLUE DECAL	Bajaj spare parts
52DK1202	SEAT COWL K3 ABS EB BLK +BLUE DCL K3 ABS	Bajaj spare parts
52DK1228	K3 NON ABS VOLCANIC RED TANK + 3 D DECAL	Bajaj spare parts
52DK1230	K3 ABS BS4 VOLCANIC RED TANK + 3 D DECAL	Bajaj spare parts
52DK1292	K3 BS6 FUEL TANK CHARCOAL BLK + 3D DECAL	Bajaj spare parts
52DK1293	K3 BS6 FUEL TANK EBONY BLACK + 3D DECAL	Bajaj spare parts
52DK1294	K3 BS6 FUEL TANK MATT VOLCNC RED+3D DCAL	Bajaj spare parts
52DK1295	K3 COVER LH RR SUB ASSLY MATT SLATE GRAY	Bajaj spare parts

52DK1302	PUL220 SEAT COWL BR. YELLOW+P.RED 3D DECA	Bajaj spare parts
52DK1366	BELLY PAN LH EBONY BLACK+PASSION RED DEC	Bajaj spare parts
52DK1367	BELLY PAN LH EBONY BLACK+P. SILVER DEC	Bajaj spare parts
52DK1368	BELLY PAN RH EBONY BLACK+PASSION RED DEC	Bajaj spare parts
52DK1369	BELLY PAN RH EBONY BLACK+P. SILVER DEC	Bajaj spare parts
52DK1370	BELLY PAN LH CHARCOAL BLACK+S.ORANGE DEC	Bajaj spare parts
52DK1371	BELLY PAN RH CHARCOAL BLACK+S.ORANGE DEC	Bajaj spare parts
52DK1373	BELLY PAN LH EBONY BLACK+RED DECAL	Bajaj spare parts
52DK1374	BELLY PAN RH EBONY BLACK+RED DECAL	Bajaj spare parts
52DK1375	BELLY PAN LH EBONY BLACK+BLUE DECAL	Bajaj spare parts
52DK1376	BELLY PAN RH EBONY BLACK+BLUE DECAL	Bajaj spare parts
52DK1386	BELLY PAN LH VOLCANIC RED+DECAL	Bajaj spare parts
52DK1387	BELLY PAN RH VOLCANIC RED+DECAL	Bajaj spare parts
52DK1447	CYL. HEAD WITH COVER DK102000	Bajaj spare parts
52DK1488	K3 BS6 FAIRING ASSLY WHITE DECAL N.C&G	Bajaj spare parts
52DK1489	K3 FRONT FAIRING EB BLK + WHITE DECAL	Bajaj spare parts
52DK1490	K3 FRONT FAIRING EB BLK + BLUE DECAL	Bajaj spare parts
52DK1493	K3 FRONT FAIRING EB BLK + VOL RED DECL	Bajaj spare parts
52DK1495	K3 FRONT FAIRING EB BLK + S BLK DECAL	Bajaj spare parts
52DK1497	K3 SEAT COWL -EB BLK + WHITE DECAL	Bajaj spare parts
52DK1499	K3 SEAT COWL SATIN S BLUE WITH DECAL	Bajaj spare parts
52DK1501	K3 SEAT COWL VOL RED WITH DECAL	Bajaj spare parts
52DK1503	K3 SEAT COWL SP MAT BLK WITH DECAL	Bajaj spare parts
52DK1505	K3 BELLY PAN LH E. BLACK+P.MET WHT DECAL	Bajaj spare parts
52DK1506	K3 BELLY PAN RH E. BLACK+P.MET WHT DECAL	Bajaj spare parts
52DK1508	K3 BELLY PAN LH E. BLACK+S. BLUE DECAL	Bajaj spare parts
52DK1509	K3 BELLY PAN RH E. BLACK+S. BLUE DECAL	Bajaj spare parts
52DK1511	K3 BELLY PAN LH E. BLACK+VOL RED DECAL	Bajaj spare parts
52DK1512	K3 BELLY PAN RH E. BLACK+VOL RED DECAL	Bajaj spare parts
52DK1514	K3 BELLY PAN LH E. BLACK+S BLACK DECAL	Bajaj spare parts
52DK1515	K3 BELLY PAN RH E. BLACK+S BLACK DECAL	Bajaj spare parts
52DK1516	K3 BS6 TANK SATIN P.WHT+WHT DECAL+3D DEC	Bajaj spare parts
52DK1519	K3 BS6 TANK SATIN S.BLUE+BLUE DCL+3D DEC	Bajaj spare parts
52DK1522	K3 BS6 TANK VOL RED+RED DCL+3D DEC	Bajaj spare parts
52DK1525	K3 BS6 TANK SATIN SP.BLK+BLK DCL+3D DEC	Bajaj spare parts
52DK1579	K3 FRONT FENDER EB BLACK+SILVER DCL	Bajaj spare parts
52DK1583	K3 FRONT FAIRING EB BLK + SILVER DEC	Bajaj spare parts
52DK1585	K3 SEAT COWL SPAR MAT BLK-SILVER DEC	Bajaj spare parts
52DK1587	K3 BELLY PAN LH E.BLK+ SMB-SILVER DCL	Bajaj spare parts
52DK1588	K3 BELLY PAN RH E.BLK+ SMB-SILVER DCL	Bajaj spare parts
52DK1589	K3 BS6 TANK SPARK MATTALIC BLK+3D DEC	Bajaj spare parts
52DK1592	K3 FRONT FENDER EB BLACK+BLUE DCL	Bajaj spare parts
52DK1596	K3 FRONT FAIRING EB BLK + BLUE DEC	Bajaj spare parts
52DK1598	K3 SEAT COWL SPAR MAT BLK-BLUE DEC	Bajaj spare parts
52DK1600	K3BELLY PAN LH E.BLK+SPR MAT BLK-BLU DCL	Bajaj spare parts

52DK1601	K3BELLY PAN RH E.BLK+SPR MAT BLK-BLU DCL	Bajaj spare parts
52DK1602	K3 BS6 TANK SPR MET BLK+3D DCL+BLUE DCL	Bajaj spare parts
52DK1605	K3 FRONT FENDER EB BLACK+RED DCL	Bajaj spare parts
52DK1609	K3 FRONT FAIRING EB BLK + RED DCL	Bajaj spare parts
52DK1611	K3 SEAT COWL SPAR MAT BLK-RED DCL	Bajaj spare parts
52DK1613	K3BELLY PAN LH E.BLK+ SPR MAT BL-RED DCL	Bajaj spare parts
52DK1614	K3BELLY PAN RH E.BLK+ SPR MAT BL-RED DCL	Bajaj spare parts
52DK1615	K3 BS6 TANK SPR MET BLK+3D DCL+RED DCL	Bajaj spare parts
52DK1618	K3FRONT FENDER EB BLACK+SF BLU WHT DCL	Bajaj spare parts
52DK1622	K3 FAIRING EB BLK + SF BLUE-WHITE DCL	Bajaj spare parts
52DK1624	K3 SEAT COWL SAFFIRE BLUE- WHITE DCL	Bajaj spare parts
52DK1626	K3 BELLY PAN LH E.BLK+SF BLU-WHT DCL	Bajaj spare parts
52DK1627	K3 BELLY PAN RH E.BLK+SF BLU-WHT DCL	Bajaj spare parts
52DK1628	K3 BS6 TANK SAFFIRE BLUE+3D DCL+WHT DCL	Bajaj spare parts
52DK5506	COVER SIDE LH WITH MASKIN	Bajaj spare parts
52DK5507	COVER SIDE RH WITH MASKIN	Bajaj spare parts
52DM0086	COVER CHAIN	Bajaj spare parts
52DM0159	CHAIN CASE U/L	Bajaj spare parts
52DM0323	SID CVR LH ENY BLK	Bajaj spare parts
52DM0325	SD CVR RH EBNY BLK	Bajaj spare parts
52DM0326	TANK ENY BLK WH BLUE DKL CT100 B DO	Bajaj spare parts
52DM0327	TANK ENY BLK RED WH RED DKL CT100B DO	Bajaj spare parts
52DM0329	SD CVR RH FL RED WH	Bajaj spare parts
52DM0330	TANK FLAME RED WH RED DCL CT100 B DOM	Bajaj spare parts
52DM0331	SD CVR LH EL. BLUE WH	Bajaj spare parts
52DM0332	SD CVR RH EL. BLUE WH	Bajaj spare parts
52DM0333	TANK EL. BLUE WH BLUE DCL CT100B DOM	Bajaj spare parts
52DM0348	BRAKE PEDAL WITH BRAKE ROD S/A	Bajaj spare parts
52DM0368	ASSLY GEAR SHIFT LEVER CT100B	Bajaj spare parts
52DM0387	TANK EB BLK WH BLK RED DKL CT100B BSIV	Bajaj spare parts
52DM0388	TANK EB BLK WH BLK BLUE DKL CT100B BSIV	Bajaj spare parts
52DM0389	TANK FLAME RED WH RED DKL CT100B BSIV	Bajaj spare parts
52DM0390	TANK ELEC BLUE WH BLUE DKL CT100B BSIV	Bajaj spare parts
52DP0120	SF FOR COVER SEAT S/A USE	Bajaj spare parts
52DS0092	SIDE COVER LH WITH M	Bajaj spare parts
52DS0093	SIDE COVER RH	Bajaj spare parts
52DS0094	FENDER FR	Bajaj spare parts
52DT0153	SILENCER END CHAMBER ASSLY K8	Bajaj spare parts
52DT0173	FRONT FAIRING WITH DECAL P RED	Bajaj spare parts
52DT0174	FRONT FAIRING WITH DECAL BRI YELLOW	Bajaj spare parts
52DT0195	K8 Front fairing with decal BLACK	Bajaj spare parts
52DT0265	K8 TANK COVER WITH DECAL PASSION RED	Bajaj spare parts
52DT0266	TANK COVER WITH DECAL BRIGHT YELLOW	Bajaj spare parts
52DT0268	FRONT FENDER ABS DECAL RED	Bajaj spare parts
52DT0269	FRONT FENDER DECAL BRIGHT YELL	Bajaj spare parts



52DT0270	K8 FRONT FENDER ABS WITH DECAL EBONY B	Bajaj spare parts
52DT0271	FRONT FENDER NON ABS WITH DECAL PASSION	Bajaj spare parts
52DT0272	FRONT FENDER NON ABS WITH DECAL BRIGHT Y	Bajaj spare parts
52DT0274	SIDE FAIRING RH DECAL RED	Bajaj spare parts
52DT0275	SIDE FAIRING RH DECAL BRIGHT YELLO	Bajaj spare parts
52DT0276	K8 FAIRING RH DECAL EBONY	Bajaj spare parts
52DT0277	SIDE FAIRING LH DECAL RED	Bajaj spare parts
52DT0278	SIDE FAIRING LH DECAL BRIGHT YELL	Bajaj spare parts
52DT0279	SIDE FAIRING LH DECAL/EBONY BLK	Bajaj spare parts
52DT0280	SEAT COWL LH WITH DECAL PASSION RED	Bajaj spare parts
52DT0281	SEAT COWL LH WITH DECAL BRIGHT YELLOW	Bajaj spare parts
52DT0282	K8 SEAT COWL LH WITH DECAL EBONY BLACK	Bajaj spare parts
52DT0283	SEAT COWL RH WITH DECAL PASSION RED	Bajaj spare parts
52DT0284	SEAT COWL RH WITH DECAL BRIGHT YELLOW	Bajaj spare parts
52DT0285	K8 SEAT COWL RH WITH DECAL EBONY BLACK	Bajaj spare parts
52DT0454	SF FOR ASSLY MAGNETO COVER DT541206	Bajaj spare parts
52DT0456	K8 SIDE FAIRING LH MET WH RED DCA	Bajaj spare parts
52DT0457	K8 SIDE FAIRING RH MET WH RED DCAL	Bajaj spare parts
52DT0458	K8 SIDE FAIRING LH MET WH S BLUE DCAL	Bajaj spare parts
52DT0459	K8 SIDE FAIRING RH MET WH S BLUE DCAL	Bajaj spare parts
52DT0460	K8 SIDE FAIRING LH PEWTERGREY BLK GREY	Bajaj spare parts
52DT0461	K8 SIDE FAI RH PEWTERGREY BLK GREY	Bajaj spare parts
52DT0462	K8 FR. FAIRING UG PASSION RED	Bajaj spare parts
52DT0463	K8 FR. FAIRING UG SAFFIRE BLUE	Bajaj spare parts
52DT0464	K8 FR. FAIRING MET BLK DCAL	Bajaj spare parts
52DT0465	"K8 SIDE FAIRING FLAP LH DCAL	Bajaj spare parts
52DT0466	"K8 SIDE FAIRING FLAP RH DCAL	Bajaj spare parts
52DT0467	"K8 SEAT COWL LH MET WH RED DCAL	Bajaj spare parts
52DT0468	"K8 SEAT COWL RH MET WH RED DCAL	Bajaj spare parts
52DT0469	"K8 SEAT COWL LH MET WH BLUE DCAL	Bajaj spare parts
52DT0470	K8 SEAT COWL RH MET WH BLUE DCAL	Bajaj spare parts
52DT0471	K8 SEAT COWL LH GLOASS PEWTER GREY	Bajaj spare parts
52DT0472	K8 SEAT COWL RH GLOASS PEWTER GREY	Bajaj spare parts
52DT0475	K8 FR. FENDER GLOSS PEWTER GREY	Bajaj spare parts
52DT0476	K8 TANK COVER TOP UG PASSION RED	Bajaj spare parts
52DT0477	K8 TANK COVER TOP UG SAFIRE BUE DCAL	Bajaj spare parts
52DT0478	K8 TANK COVER TOP MET BLK GREY DCAL	Bajaj spare parts
52DT0479	"K8 FR. FENDER MET WH ABS RED DCAL	Bajaj spare parts
52DT0480	"K8 FR. FENDER MET WH ABS BLUE DCAL	Bajaj spare parts
52DT0481	K8 FR.FENDER GLOSS PEWTER GREY ABS	Bajaj spare parts
52DT0641	SF FOR DT541203 -MAGNETO COVER ASSY CPL	Bajaj spare parts
52DT0657	CYLINDER HEAD COVER ASSLY - DT511027	Bajaj spare parts
52DT1077	COWL RADIATOR SUB ASSLY K8 BS6	Bajaj spare parts
52DT1106	K8 FENDER FRONT SATIN BLACK+DECAL	Bajaj spare parts
52DT1113	SIDE FAIRING LH DT181213 BURNT RED+DECAL	Bajaj spare parts

52DT1117	SIDE FAIRING RH BURNT RED+S BLACK+DECAL	Bajaj spare parts
52DT1125	SIDE FAIRING LH DT181213 PEWTER GREY+DEC	Bajaj spare parts
52DT1126	SIDE FAIRING RH DT181220 PEWTER GREY+DEC	Bajaj spare parts
52DT1127	SIDE FAIRING LH DT181213 P MET WHT+DECAL	Bajaj spare parts
52DT1128	SIDE FAIRING RH DT181220 P MET WHT+DECAL	Bajaj spare parts
52DT1129	SEAT COWL LH DT181206 SA BLACK+RED DECAL	Bajaj spare parts
52DT1130	SEAT COWL LH DT181206 S BLACK+GREY DECAL	Bajaj spare parts
52DT1131	SEAT COWL LH DT181206 S BLACK+WHITE DECA	Bajaj spare parts
52DT1132	SEAT COWL RH DT181208 SA BLACK+RED DECAL	Bajaj spare parts
52DT1133	SEAT COWL RH DT181208 S BLACK+GREY DECAL	Bajaj spare parts
52DT1134	SEAT COWL RH DT181208 S BLACK+WHITE DEC	Bajaj spare parts
52DT1168	K8 BS6 SILENCER END CHAMBER ASSEMBLY	Bajaj spare parts
52DT1169	K8 BS6 TIE ROD (DT561418) ASSEMBLY WITH	Bajaj spare parts
52DT1181	BALANCER ASSLY-DT531200 WITH DOME NUT	Bajaj spare parts
52DU0071	FENDERFRONT UNPAINTED	Bajaj spare parts
52DU0104	LEVER COMP SUB ASSLY	Bajaj spare parts
52DU0156	COVER GEN.SUB ASSLY WITH RIVET	Bajaj spare parts
52DU0197	ASSLY CLUTCH COVER WITH PTFE BUSH(HR)	Bajaj spare parts
52DU0239	ASSY OHC (GRI-GRAY)	Bajaj spare parts
52DU0240	PIPE INTAKE	Bajaj spare parts
52DU0249	COVER GENERATORCT 100	Bajaj spare parts
52DU0289	FENDOR BALCK JET	Bajaj spare parts
52DU0290	FENDOR FLAM RED	Bajaj spare parts
52DU0555	SWING ARM(DU171018) WITH BUSH	Bajaj spare parts
52DU0575	COWLING BLK RED	Bajaj spare parts
52DU0576	COWLING FLAME RED WITH	Bajaj spare parts
52DU0577	COWL BLUE DEC CT100	Bajaj spare parts
52DU0578	COWL BLK BLUE WITH DEC(CT100)	Bajaj spare parts
52DU0579	SEAT COWL BLK RED WITH RED DEC(CT100 BR)	Bajaj spare parts
52DU0580	SEAT COWL FLAME RED WITH DEC(CT100 SKD)	Bajaj spare parts
52DU0581	SEAT COWL E.BLUE WITH DEC(CT100 SKD)	Bajaj spare parts
52DU0582	SEAT COWL BLACK BLUE WITH DEC(CT100 SKD)	Bajaj spare parts
52DU0583	SIDE CVR LH BLACK RED	Bajaj spare parts
52DU0584	SIDE CVR LH FLAME	Bajaj spare parts
52DU0585	SIDE CVR LH E.BLUE WT DEC(CT100 SKD)	Bajaj spare parts
52DU0586	SIDE CVR LH BLACK BLUE	Bajaj spare parts
52DU0587	SIDE CVR RH BLACK RED.	Bajaj spare parts
52DU0588	SIDE CVR RH FLAME RED	Bajaj spare parts
52DU0589	SIDE CVR RH E.BLUE WT DEC(CT100 SKD)	Bajaj spare parts
52DU0590	SIDE CVR RH BLACK BLU	Bajaj spare parts
52DU0622	SEAT COWL BLK RED WITH RED DEC(CT100 BR)	Bajaj spare parts
52DU0623	SEAT COWL FLAME RED WITH DEC(CT100 SKD)	Bajaj spare parts
52DU0624	SEAT COWL E.BLUE WITH DEC(CT100 SKD)	Bajaj spare parts
52DU0625	SEAT COWL BLACK BLUE WITH DEC(CT100 SKD)	Bajaj spare parts
52DU0626	SIDE CVR LH Blk (CT100)	Bajaj spare parts

52DU0627	SIDE CVR LH FLAME RED	Bajaj spare parts
52DU0628	SIDE CVR LH E.BLUE WT DEC(CT100 SKD)	Bajaj spare parts
52DU0629	SIDE CVR LH BLACK	Bajaj spare parts
52DU0630	SIDE CVR RH BLACK	Bajaj spare parts
52DU0631	SIDE CVR RH FLAME RED	Bajaj spare parts
52DU0632	SIDE CVR RH E.BLUE WT DEC(CT100 SKD)	Bajaj spare parts
52DU0633	SIDE CVR RH BLK BLU WTE Dec	Bajaj spare parts
52DU0634	FUEL TANK BLACK RED WITH DEC(CT100 BR)	Bajaj spare parts
52DU0635	FUEL TANK FLAME RED WITH DEC(CT100 FR)	Bajaj spare parts
52DU0636	FUEL TANK E.BLUE WITH DEC(CT100 EB)	Bajaj spare parts
52DU0637	FUEL TANK BLACK BLUE WITH DEC(CT100 BB)	Bajaj spare parts
52DU0781	F.TANK EB BLK WITH BLK RED DKL CT100BS4	Bajaj spare parts
52DU0782	F.TANK EB BLK WITH BLK BLU DKL CT100BS4	Bajaj spare parts
52DU0784	FUEL TANK ELE. BLUE WITH DECAL CT100 BS4	Bajaj spare parts
52DU0826	FUEL TANK BLACK RED WITH DECAL CT100 BS4	Bajaj spare parts
52DU0828	FUEL TANK FLAME RED WITH DECAL CT100 BS4	Bajaj spare parts
52DU0829	TANK BLUE WITH DECAL	Bajaj spare parts
52DU0922	FUEL TANK BLACK RED WITH DECAL	Bajaj spare parts
52DU0923	FUEL TANK BLACK BLU WITH DECAL	Bajaj spare parts
52DU0924	FUEL TANK FLAME RED WITH DECAL	Bajaj spare parts
52DU0926	SEAT COWL EBONY BLACK WH RED DKL CT100ES	Bajaj spare parts
52DU0927	SIDE COVER LH EB. BLK WH RED DKL CT100ES	Bajaj spare parts
52DU0928	SIDE COVER RH EB. BLK WH RED DKL CT100ES	Bajaj spare parts
52DU0929	COWLING EBONY BLACK WITH RED DKL CT100ES	Bajaj spare parts
52DU0931	SEAT COWL EBONY BLACK WH BL DKL CT100ES	Bajaj spare parts
52DU0932	SIDE COVER LH EB. BLK WH BL DKL CT100ES	Bajaj spare parts
52DU0933	SIDE COVER RH EB. BLK WH BL DKL CT100ES	Bajaj spare parts
52DU0934	COWLING EBONY BLACK WITH BL DKL CT100ES	Bajaj spare parts
52DU0936	SEAT COWL FLAME RED WITH DECAL CT100ES	Bajaj spare parts
52DU0937	SIDE COVER LH FLAME RED WH DKL CT100ES	Bajaj spare parts
52DU0938	SIDE COVER RH FLAME RED WH DKL CT100ES	Bajaj spare parts
52DU0939	COWLING FLAME RED WITH DECAL CT100ES	Bajaj spare parts
52DU0944	COWLING ELECTRON BLUE WITH DECAL CT100ES	Bajaj spare parts
52DU1004	FUEL TANK BLACK BLUE WITH DECAL CT KS	Bajaj spare parts
52DU1083	SEAT COWL EBONY BLACK WH BLUE DECAL(CTES	Bajaj spare parts
52DU1085	SIDE COVER LH EB. BLK WH RED DKL (CT-ES	Bajaj spare parts
52DU1086	SIDE COVER LH EB. BLK WH BL DKL (CT-ES	Bajaj spare parts
52DU1088	SIDE COVER RH EB. BLK WH RED DKL CT100ES	Bajaj spare parts
52DU1089	SIDE COVER RH EB. BLK WH BL DKL CT100ES	Bajaj spare parts
52DU1257	FRONT FENDER WH BRACE S/A EB.BLK(CT CBS	Bajaj spare parts
52DU1258	FRONT FENDER WH BRACE S/A FL.RED(CT CBS	Bajaj spare parts
52DU1446	CHAINCASE ASSLY UPPER & LOWER CT-110	Bajaj spare parts
52DU1448	SEAT COWL EB BLACK WITH BLUE DCAL(CT-110	Bajaj spare parts
52DU1449	SIDE COVR LH EB BLACK WH BLU DCAL(CT-110	Bajaj spare parts
52DU1450	SIDE COVR RH EB BLACK WH BLU DCAL(CT-110	Bajaj spare parts

52DU1451	COWLING EB BLACK WITH BLUE DECAL(CT-110)	Bajaj spare parts
52DU1452	FUEL TANK BLACK BLUE WITH DECAL(CT-110)	Bajaj spare parts
52DU1472	SEAT COLW FL RED W RED DKL CT110	Bajaj spare parts
52DU1473	SD CVR LH RED W RED DKL CT110	Bajaj spare parts
52DU1474	SD CVR RH FL RED W RED DKL CT110	Bajaj spare parts
52DU1475	COWLING FL RED W RED DKL CT110	Bajaj spare parts
52DU1477	FUEL TANK FL RED W RED DKL CT110	Bajaj spare parts
52DU1491	SEAT COLW MT WILD GRN W YLW DKL CT-110	Bajaj spare parts
52DU1492	SD CVR LH MT WILD GRN W YLW DKL CT110	Bajaj spare parts
52DU1493	SD CVR RH MT WILD GRN W YLW DKL CT110	Bajaj spare parts
52DU1494	COWLING MT WILD GRN W YLW DKL CT110	Bajaj spare parts
52DU1496	FUEL TANK MT WILD GRN W YELLOW DKL CT110	Bajaj spare parts
52DU1498	FR FNDR WH BRACE S/A MATE WILD GRE(CT110	Bajaj spare parts
52DU1651	CARRIER MASK EB BLK W BLU DKL CT110 UG	Bajaj spare parts
52DU1652	CARRIER MASK FL RED W RED DKL CT110 UG	Bajaj spare parts
52DU1653	CARRIER MASK MT GRN W YELL DKL CT110 UG	Bajaj spare parts
52DU1656	TANK EB BLK W BL DKL CT100 ES BS6	Bajaj spare parts
52DU1657	TANK FL RED W RED DKL CT100 ES BS6	Bajaj spare parts
52DU1658	TANK MT WLD GRN W YELL DKL CT100 ES BS6	Bajaj spare parts
52DU1665	ST COWL EB BLK W BL DKL CT100 ES/KS BS6	Bajaj spare parts
52DU1666	ST COWL FL RED W RED DKL CT100 ES/KS BS6	Bajaj spare parts
52DU1667	ST COWL MT GRN W YEL DKL CT100 ES/KS BS6	Bajaj spare parts
52DU1674	TANK EB BLK W BL DKL CT100 KS BS6	Bajaj spare parts
52DU1675	TANK FL RED W RED DKL CT100 KS BS6	Bajaj spare parts
52DU1676	TANK MT WLD GRN W YELL DKL CT100 KS BS6	Bajaj spare parts
52DU1753	CHAINCASE ASSLY UPPER & LOWER CT-100	Bajaj spare parts
52DU1872	ST COWL EB BLK W RED DKL CT100 KS UG BS6	Bajaj spare parts
52DU1873	COWLING EB BLK W RED DKL CT100 KS UG BS6	Bajaj spare parts
52DU1875	TANK EB BLK W RED DKL CT100KS UG BS6	Bajaj spare parts
52DU1876	FUEL TANK ASY BLK RED W DKL CT100KS BS6	Bajaj spare parts
52DU1877	SIDE COV LH EB BLK W RED DKL CT100KS BS6	Bajaj spare parts
52DU1878	SIDE COV EB BLK W RED DKL CT100KS BS6	Bajaj spare parts
52DU1885	SEAT COWL EB BLK W RED DKL CT110 ES BS6	Bajaj spare parts
52DU1886	COWLING EB BLK W RED DKL CT110 ES BS6	Bajaj spare parts
52DV0022	STEP PILLION LH SUB ASSY	Bajaj spare parts
52DV0024	STEP PILLION RH SUB AVE	Bajaj spare parts
52DV0025	STAND SIDE WITH DAMPER	Bajaj spare parts
52DV0032	BREATHER PIPE WITH CLIPS	Bajaj spare parts
52DV0051	LEVER CHANGE ASSLY	Bajaj spare parts
52DV0052	CHANGE LEVER ASSLY	Bajaj spare parts
52DV0055	LEVER CHANGE ARM COMP	Bajaj spare parts
52DY0012	FUEL TANK ELECTRON BLUE WITH DECAL CT125	Bajaj spare parts
52DY0133	CHAINCASE U/L WITH PACKING CT 125 CKD	Bajaj spare parts
52DY0152	CHAINCASE UPPER & LOWER CT-125 SKD	Bajaj spare parts
52DY0329	CARRIER MASK EB BLK WH BLUE DECAL CT110X	Bajaj spare parts

52DY0330	CARRIER MASK FLAME RED WH DECAL CT110X	Bajaj spare parts
52DY0331	CARRIER MASK MT WILD GRN WH DECAL CT110X	Bajaj spare parts
52DY0332	CARRIER MASK EB BLK WH RED DECAL CT110X	Bajaj spare parts
52DY0337	SIDE COVER LH EB BLK W BLUE DECAL CT110X	Bajaj spare parts
52DY0338	SIDE COVER LH FLAME RED WH DECAL CT110X	Bajaj spare parts
52DY0339	SIDE COVER LH MT WILD GRN W DECAL CT110X	Bajaj spare parts
52DY0340	SIDE COVER LH EB BLK WH RED DECAL CT110X	Bajaj spare parts
52DY0341	SIDE COVER RH EB BLK W BLUE DECAL CT110X	Bajaj spare parts
52DY0342	SIDE COVER RH FLAME RED WH DECAL CT110X	Bajaj spare parts
52DY0343	SIDE COVER RH MT WILD GRN W DECAL CT110X	Bajaj spare parts
52DY0344	SIDE COVER RH EB BLK WH RED DECAL CT110X	Bajaj spare parts
52DY0345	FUEL TANK EB BLK WH BLUE DECAL CT110X	Bajaj spare parts
52DY0346	FUEL TANK FLAME RED WH DECAL CT110X	Bajaj spare parts
52DY0347	FUEL TANK MT WILD GRN WH DECAL CT110X	Bajaj spare parts
52DY0348	FUEL TANK EB BLK WH RED DECAL CT110X	Bajaj spare parts
52DY0353	CHAINCASE ASY UPPER & LOWER BLACK CT110X	Bajaj spare parts
52DY0354	COVER LH RR WH LABEL SLICK BLACK CT110X	Bajaj spare parts
52DY0357	CASE BATTERY S/A CT-110X BS-VI	Bajaj spare parts
52DY0364	BELLY PAN WITH BEADING ASLY CT110X BS6	Bajaj spare parts
52DY0395	COVER LH RR WH LABEL SL BLK CT110X KS	Bajaj spare parts
52DY0447	CHAINCASE ASY UPP & LOW BLACK CT125X	Bajaj spare parts
52DY0448	COVER LH RR W LABEL SL BLK CT125X BS6	Bajaj spare parts
52DY0455	CARRIER MASK EB BLK W SIL GR DKL CT110X	Bajaj spare parts
52DY0457	SIDE CVR LH EB BLK W SIL GR DKL CT110X	Bajaj spare parts
52DY0458	SIDE CVR RH EB BLK W SIL GR DKL CT110X	Bajaj spare parts
52DY0459	TANK EB BLK W SIL GR DKL CT110X	Bajaj spare parts
52DY0464	CARRIER MASK EB BLK WH BLUE DECAL CT125X	Bajaj spare parts
52DY0466	CARRIER MASK EB BLK WH RED DECAL CT125X	Bajaj spare parts
52DY0470	FUEL TANK EB BLK WH BLUE DECAL CT125X	Bajaj spare parts
52DY0472	FUEL TANK EB BLK WH RED DECAL CT125X	Bajaj spare parts
52DY0473	SIDE COVER LH EB BLK W BLUE DECAL CT125X	Bajaj spare parts
52DY0475	SIDE COVER LH EB BLK WH RED DECAL CT125	Bajaj spare parts
52DY0476	SIDE COVER RH EB BLK W BLUE DECAL CT125X	Bajaj spare parts
52DY0478	SIDE COVER RH EB BLK WH RED DECAL CT125	Bajaj spare parts
52DY0493	CARRIER MASK EB BLK WH GREEN DKL CT125X	Bajaj spare parts
52DY0495	FUEL TANK EB BLK WH GREEN DECAL CT125X	Bajaj spare parts
52DY0497	SIDE COVER LH EB BLK W GREEN DKL CT125X	Bajaj spare parts
52DY0498	SIDE COVER RH EB BLK W GREEN DKL CT125X	Bajaj spare parts
52DY0519	SF CYL HEAD_DY511062 WI SAI OBD2A	Bajaj spare parts
52DZ0006	FILTER S/A WITH BREATHER TUBE	Bajaj spare parts
52DZ0016	FENDER FR PLATINEINA	Bajaj spare parts
52DZ0019	C'CASE LH BREA TUBE	Bajaj spare parts
52DZ0046	ADJUSTER CHAIN RH	Bajaj spare parts
52DZ0047	CHAIN ADJUSTER S/A LH	Bajaj spare parts
52DZ0307	FLAP COWLING WITH BKT COWLING UPPER	Bajaj spare parts

52JA0023	KIT OF JA CASE PUMP	Bajaj spare parts
52JA0027	STUD JA541015 PREC	Bajaj spare parts
52JA0028	NUT	Bajaj spare parts
52JA0029	BOLT (JA541014) PRECOATED	Bajaj spare parts
52JB0045	CHAIN ADJUSTER RH S/A (KG XCD 125)	Bajaj spare parts
52JB0231	CYL.BLOCK ASSY DiscoM	Bajaj spare parts
52JB0232	CYL HEAD ASSY DISCO	Bajaj spare parts
52JB0233	CRANKCASE MG SIDE DISCO	Bajaj spare parts
52JB5504	ASSLY MANIFOLD INTAKE DISCOVER 110	Bajaj spare parts
52JC0001	FLAP TANK LH MASK	Bajaj spare parts
52JC0002	FLAP TANK RHMASK	Bajaj spare parts
52JC0010	COVER LH RR ASSLY JC	Bajaj spare parts
52JC0019	LAMP SHADE ASSL COMP	Bajaj spare parts
52JC0209	SF FOR FINISH PART JC101029 CRANKCASE RH	Bajaj spare parts
52JC0210	SF FOR FINISH PART JC101045 CRANKCASE LH	Bajaj spare parts
52JD0032	S/F FRONT FENDER ASSEMBLY FOR SPRINT	Bajaj spare parts
52JD0033	S/F SIDE COVER LH LOWER ASSLY	Bajaj spare parts
52JD0034	S/F SIDE COVER RH LOWER ASSLY	Bajaj spare parts
52JD0035	S/F SPOILER SUB ASSLY FOR SPRINT	Bajaj spare parts
52JD0067	WINDSHIELD WITH MASK	Bajaj spare parts
52JD0175	FR NO PLATE SUBASSLY W	Bajaj spare parts
52JD0195	COVER SIDE LH RED DCL	Bajaj spare parts
52JD0204	FENDER FRONT ASSLY PL BLUE pulsar 135	Bajaj spare parts
52JD0207	ASSLY COVER SIDE LH BL	Bajaj spare parts
52JD0215	ASSLY COVER SIDE RH	Bajaj spare parts
52JD0216	ASSLY COVER SIDE LH	Bajaj spare parts
52JD0303	FRONT FENDER ASSLY BRILLIANT BLUE	Bajaj spare parts
52JD0316	SPOILER ASSLY BRILLIANT BLUE WH DECAL	Bajaj spare parts
52JD0366	FR.FENDER S/A EB BLK	Bajaj spare parts
52JD0367	FR.FENDER S/A FLAME RED	Bajaj spare parts
52JD0368	FR.FENDER S/A EL BL.	Bajaj spare parts
52JD0375	SIDE COVER RH S/A EB. BLK. PULSAR	Bajaj spare parts
52JD0378	SIDE COVER LH ASLY EB BLK	Bajaj spare parts
52JD0391	SEAT COWL ASSLY WH DKL EL. BLUE	Bajaj spare parts
52JD0419	FUEL TANK FLAME RED WH RED DECAL P	Bajaj spare parts
52JD0420	FUEL TANK ELECTRON BLUE WH BLUE DCL	Bajaj spare parts
52JD0478	COWL RH FLAM RED/DCL PUL	Bajaj spare parts
52JD0479	COWLING LH ELE BLUE WH DECAL PULSAR	Bajaj spare parts
52JD0480	COWLING RH ELE BLUE WH DECAL PULSAR	Bajaj spare parts
52JD0544	FUEL TANK EBONY BLACK WITH DECAL	Bajaj spare parts
52JD0593	SIDE COVER LH ASLY EB. BLK	Bajaj spare parts
52JD0597	SIDE COVER RH ASSLY EB.BLK	Bajaj spare parts
52JD0598	SIDE COVER RH ASSLY RO.BLE	Bajaj spare parts
52JD0599	SEAT COWL ASSLY WH DCL EB.BLK	Bajaj spare parts
52JD0600	SEAT COWL ASLY WH DCL RO.BLE	Bajaj spare parts

52JD0603	COWLING LH EBONY BLACK	Bajaj spare parts
52JD0604	COWLING LH ROYAL BLUE	Bajaj spare parts
52JD0610	SPOILER ASLY RO.BLU WH DECAL	Bajaj spare parts
52JD0639	COWLING RH ROYAL BLUE	Bajaj spare parts
52JD0643	EVAP F.T CAP WITH LOCK SET	Bajaj spare parts
52JD0651	COVER LH RR S/A MATTE SLATE GRAY	Bajaj spare parts
52JD0653	SD CVR LH ASSLY FLAME RED P 135 UG	Bajaj spare parts
52JD0655	SIDE CVR RH ASLY FLAME RED P135 UG	Bajaj spare parts
52JD0656	COWLING LH FLAME RED	Bajaj spare parts
52JD0657	COWLING RH FLAME RED	Bajaj spare parts
52JD0659	SEAT COWL WH DCL FLAME RED P135 UG	Bajaj spare parts
52JD0662	SPOILR ASLY FLAME RED WH DCL P135 UG	Bajaj spare parts
52JD0734	TANK EBONY BLACK WITH DECAL ROUSER 135	Bajaj spare parts
52JD0746	TANK FLAME RED WITH DECAL PULSAR 135	Bajaj spare parts
52JD0765	COWL LH RYL BLE WH CHROM DKL P135UG	Bajaj spare parts
52JD0766	COWLING RH RYL BLU WH CHR DCL P135UG	Bajaj spare parts
52JD0770	SEAT COWL RYL BLU WH C DKL P135 UG	Bajaj spare parts
52JD0774	SDCVR LH ASLY EB.BLK.CHROME DCLP135UGBS4	Bajaj spare parts
52JD0775	SDCVR LH ASLY RYL.BLUCHROME DCLP135UGBS4	Bajaj spare parts
52JD0778	SDCVR RH ASLY EB.BLK CHROME DCLP135UGBS4	Bajaj spare parts
52JD0779	SDCVR.RH.ASLY.RYL.BLUCHROME DCLP135UGBS4	Bajaj spare parts
52JD0780	SPOILER ASLY EB.BLK CHROME DCL P135UGBS4	Bajaj spare parts
52JD0781	SPOILER ASLY RYL BLU CHROME DCLP135UGBS4	Bajaj spare parts
52JD0783	TANK RYL BLU CHROME DCL (P 135 BSIV+AHO)	Bajaj spare parts
52JD0812	FR.FENDER PASSION RED WH DCL P-125 WVTA	Bajaj spare parts
52JD0822	COWLING RH PASSION RED WITH DECAL	Bajaj spare parts
52JD0860	SIDE COVER LH ASSLY PASSION RED	Bajaj spare parts
52JD0861	SIDE COVER RH ASSLY PASSION RED	Bajaj spare parts
52JD0862	SEAT COWL PASSION RED WITH DECAL	Bajaj spare parts
52JD0865	SPOILER ASLY PASN RED WH DKL	Bajaj spare parts
52JD0866	TANK PASSION RED WITH DKL	Bajaj spare parts
52JD0889	S. COV LH ASY PEWTER GRAY WH SPARK BLK D	Bajaj spare parts
52JD0893	S. COV LH ASY PEWTER GRAY WH BRGT.YELLOW	Bajaj spare parts
52JD0895	S. COV RH ASY PEWTER GRAY WH BRGT.YELLOW	Bajaj spare parts
52JD0898	SEAT COWL MATTE PEWTER GRAY WH PERL WHT.	Bajaj spare parts
52JD0934	BELLY PAN LH BRIGHT YELLOW S/A(P_125WVTA	Bajaj spare parts
52JD0935	BELLY PAN RH BRIGHT YELLOW	Bajaj spare parts
52JD0953	SD CVR LH ASLY SAFFIRE BLUE P-135 UG BS4	Bajaj spare parts
52JD0956	SD CVR RH ASLY C. WINE RED P-135 UG BS4	Bajaj spare parts
52JD0957	SD CVR RH ASLY SAFFIRE BLUE P-135 UG BS4	Bajaj spare parts
52JD0960	TANK C. WINE RED WH DCL P-135 UGBS4	Bajaj spare parts
52JD1323	TANK KHI EBONY BLACK WH DECAL PULSAR-135	Bajaj spare parts
52JD1324	TANK KHI EBONY BLACK WH DECAL ROUSER-135	Bajaj spare parts
52JD1330	TANK KHI PASSION RED WTH DECAL PULSAR135	Bajaj spare parts
52JD1331	TANK KHI PASSION RED WTH DECAL ROUSER135	Bajaj spare parts

52JD8001	FUEL TANK PULSAR 135 AFTER PT	Bajaj spare parts
52JE0012	CRANKCASE CLUTCH	Bajaj spare parts
52JE0013	CRANKCASE MAGNET SIDE	Bajaj spare parts
52JE0016	CYL BLOCK ASSY Sprint	Bajaj spare parts
52JE0017	COVER MAGNETO SPRINT	Bajaj spare parts
52JE0049	MLS COVER LH RR SUB ASSLY FOR SPRINT	Bajaj spare parts
52JE0074	ASSEMBLY HEAD COVER K11	Bajaj spare parts
52JE0080	ASSLY CYL. HEAD COVER P145 UG	Bajaj spare parts
52JE0182	ASSLY COVER MAGNETO K15UG JE541252	Bajaj spare parts
52JE0212	SF FOR MAGNETO COVER ASSLY JE541238	Bajaj spare parts
52JE0270	FINISH CRANKCASE LH (JE541062)	Bajaj spare parts
52JE0299	SF FOR MAGNETO COVER ASSLY JE541278	Bajaj spare parts
52JE0450	ASLY COVR MAGNETO JE541278 "SATIN BLACK"	Bajaj spare parts
52JE5506	COVER MAGNETO ASSLY-MATT SLATE GRAY PUL	Bajaj spare parts
52JF0021	LCGS WITH SPRING ASSLY K11	Bajaj spare parts
52JF0025	TANK COVER ASSY COMP (K11) RED	Bajaj spare parts
52JF0026	TANK COVER ASSY COMP (K11) BLUE	Bajaj spare parts
52JF0027	TANK COVER ASSY COMP (K11) WHITE	Bajaj spare parts
52JF0034	SEAT COWL SUBASSLY COMP-K11 BLACK	Bajaj spare parts
52JF0035	SEAT COWL SUBASSLY COMP-K11 BLUE	Bajaj spare parts
52JF0036	SEAT COWL SUBASSLY COMP-K11 RED	Bajaj spare parts
52JF0037	SEAT COWL SUBASSLY COMP-K11 WHITE	Bajaj spare parts
52JF0047	ENGINE STAY LH ASSLY COMP-K11	Bajaj spare parts
52JF0062	ASSLY TIE ROD WITH NUT K11	Bajaj spare parts
52JF0074	TANK SIDE COVER LH E BLACK K11 SPD	Bajaj spare parts
52JF0078	TANK SIDE COVER RH E BLACK K11 SPD	Bajaj spare parts
52JF0080	SEAT COWL S BLUE K11 SPD	Bajaj spare parts
52JF0081	SEAT COWL P RED K11 SPD	Bajaj spare parts
52JF0082	SEAT COWL E BLACK K11 SPD	Bajaj spare parts
52JF0083	SEAT COWL M WHITE K11 SPD	Bajaj spare parts
52JF0089	TIE ROD WITH NUT ASSLY K16 BTIE ROD WITH	Bajaj spare parts
52JF0090	ENGINE STAY RH ASSLY COMPLETE K11 & K	Bajaj spare parts
52JF0110	FENDER ASSLY COMP WITH DECAL WHITE K11	Bajaj spare parts
52JF0175	FRONT NO PLATE KIT FOR PULSAR FOR SPARES	Bajaj spare parts
52JF0228	FRONT FENDER ASSLY MET WHITE K11UG	Bajaj spare parts
52JF0229	FRONT FENDER ASSLY P RED K11 UG	Bajaj spare parts
52JF0230	FRONT FENDER ASSLY SAFIRE BLUE K11 UG	Bajaj spare parts
52JF0239	SIDE COVER LH ASSLY SAFIRE BLUE K11 UG	Bajaj spare parts
52JF0242	SIDE COVER RH ASSLY SAFIRE BLUE K11 UG	Bajaj spare parts
52JF0294	ASSLY FRONT FENDER ABS K10 PLUM REDABS	Bajaj spare parts
52JF0295	ASSLY SEAT COWL LH K10 PLUM RED	Bajaj spare parts
52JF0296	ASSLY SEAT COWL RH K10 PLUM RED	Bajaj spare parts
52JF0297	ASSLY SIDE COVER LH K10	Bajaj spare parts
52JF0299	ASSLY FRONT FENDER K10 TWILIGHT BLUEABS	Bajaj spare parts
52JF0300	ASSLY SEAT COWL LH K10 TWILIGHT BLUE	Bajaj spare parts



52JF0301	ASSLY SEAT COWL RH K10 TWILIGHT BLUE	Bajaj spare parts
52JF0302	ASSLY SIDE COVER RH K10	Bajaj spare parts
52JF0304	ASSLY FRONT FENDER K10 CLASSIC WHITEABS	Bajaj spare parts
52JF0305	ASSLY SEAT COWL LH	Bajaj spare parts
52JF0306	SEAT COWL RH	Bajaj spare parts
52JF0308	STEP ASSLY MAIN COMP LH SLATE GREY MATTE	Bajaj spare parts
52JF0320	ASSLY FR FENDER ABS K10 PLUM RED (NON A	Bajaj spare parts
52JF0322	ASSLY FR FENDER K10 CLASSIC WHITE	Bajaj spare parts
52JF0327	ASSEMBLY BATTERY CASE K10	Bajaj spare parts
52JF0328	BKT ECU MTG LOWER SUB ASSLY	Bajaj spare parts
52JF0348	ASSLY CHANGE LEVER COMP - K10	Bajaj spare parts
52JF0411	K11 UG TANK COVER TOP PASSION RED DCAL	Bajaj spare parts
52JF0412	K11 UG SEAT COWL ASSLY SATIN BLK	Bajaj spare parts
52JF0418	K11 UG SHROUD COVER LH + DCAL	Bajaj spare parts
52JF0419	K11 UG TANK COVER TOP SAFIRE BLUE DCAL	Bajaj spare parts
52JF0420	K11 UG SEAT COWL ASSLY SATIN BLK	Bajaj spare parts
52JF0426	K11 UG SHROUD COVER LH + DCAL	Bajaj spare parts
52JF0427	K11 UG TANK COVER TOP MET WH + DCAL	Bajaj spare parts
52JF0428	K11 UG SEAT COWL ASSLY SATIN BLK	Bajaj spare parts
52JF0434	K11 UG SIDE MASK LH SATIN BLACK D	Bajaj spare parts
52JF0435	K11 UG SIDE MASK RH SATIN BLACK D	Bajaj spare parts
52JF0455	K11 UG TANKCOVER LH SATIN BLK + PAS RE	Bajaj spare parts
52JF0456	K11 UG TANKCOVER RH SAT BLACK + SAF BLUE	Bajaj spare parts
52JF0457	K11 UG TANKCOVER LH SAT BLACK + SAF BLUE	Bajaj spare parts
52JF0458	K11 UG TANKCOVER RH SATIN BLK + PAS RED	Bajaj spare parts
52JF0459	K11 UG TANK COVER LH SAT BLK + M WHITE	Bajaj spare parts
52JF0460	K11 UG TANK COVER RH SAT BLK	Bajaj spare parts
52JF0568	K15 ASLY SIDE COVER LH SATIN BLK SAF	Bajaj spare parts
52JF0590	K11UG SEAT COWL SATIN BLK+PEWTER GREY DE	Bajaj spare parts
52JF0592	K11UG TANKCOVER LH SAT BLK + PEWTER GREY	Bajaj spare parts
52JF0593	K11UG TANKCOVER RH SAT BLK + PEWTER GREY	Bajaj spare parts
52JF0594	K11 UG TANK COVER TOP PEWTER GREY DCAL	Bajaj spare parts
52JF0597	K11 UG FRONT FENDER + PEWTER GREY DECAL	Bajaj spare parts
52JF0598	ASSLY COVER SIDE LH PEWTER GREY K11 BSI	Bajaj spare parts
52JF0600	ASSLY COVER SIDE RH PEWTER GREY K11 BSIV	Bajaj spare parts
52JF0603	K4 UG SIDE MASK LH SATIN BLK +PEWTER GRE	Bajaj spare parts
52JF0604	K4 UG SIDE MASK RH SATIN BLK + PEWTER GR	Bajaj spare parts
52JF0612	ASSLY FR FENDER K10 GRAP MAT BLK NON ABS	Bajaj spare parts
52JF0613	ASSLY SEAT COWL LH K10 GRAP MAT BLK	Bajaj spare parts
52JF0626	K10 FR FENDER GRAP MAT BLK DCAL ABS	Bajaj spare parts
52JF0627	K10 FR FENDER GRAP MAT BLK DCAL NON ABS	Bajaj spare parts
52JF0628	K10 SEAT COWL LH GRAP MATE BLK DCAL	Bajaj spare parts
52JF0629	K10 SEAT COWL RH GRAP MATE BLK DCAL	Bajaj spare parts
52JF0682	K15FI ASLY SIDE COVER RH SATIN BLK + PE	Bajaj spare parts
52JF0727	FR FENDER SAT BLK K10 ABS WTH BLUE DECAL	Bajaj spare parts

52JF0728	FR FENDER SAT BL K10 NON ABS+DEC C BLUE	Bajaj spare parts
52JF0729	FR FENDER SAT BLK K10 ABS+DEC GLAM GREN	Bajaj spare parts
52JF0731	FR FENDER SAT BK K10 ABS+DEC GRAP BLK	Bajaj spare parts
52JF0732	FR FENDER SAT BLK K10 ABS+DECAL RAC RED	Bajaj spare parts
52JF0733	FR FENDER SAT BK K10 NONABS+DEC RAC RED	Bajaj spare parts
52JF0746	K10 SEAT COWL LH ROCK MATT BLK+DECAL	Bajaj spare parts
52JF0747	K10 SEAT COWL RH ROCK MATT BLK+DECAL	Bajaj spare parts
52JF0758	SEAT COWL LH K10 CAL GLACIER BLUE+ DEC	Bajaj spare parts
52JF0759	SEAT COWL RH K10 GLACIER BLUE+DEC	Bajaj spare parts
52JF0774	FR FNDR SAT BK K10 NON ABS+DEC GRA BLK	Bajaj spare parts
52JF0783	SEAT COWL LH K10 CANYON RED+DEC	Bajaj spare parts
52JF0784	SEAT COWL RH K10 CANYON RED+DEC	Bajaj spare parts
52JF0817	ASSLY BELLY PAN K10 STONE MATTE BLACK	Bajaj spare parts
52JF1225	SF FOR DT541203 -MAGNETO COVER ASSY -UG	Bajaj spare parts
52JF1279	K10 UG SEAT COWL LH CHARCOAL BLK +DCL	Bajaj spare parts
52JF1280	K10 UG SEAT COWL RH CHARCOAL BLACK + DEC	Bajaj spare parts
52JF1345	K10 UG BELLY PAN LH SATIN BLACK + DECAL	Bajaj spare parts
52JF1346	K10 UG BELLY PAN RH SATIN BLACK + DECAL	Bajaj spare parts
52JF1349	K10 UG FRT FENDER S. BLACK + GR.MAT.BLK	Bajaj spare parts
52JF1351	K10 UG BELLY PAN LH SATIN BLACK + DECAL	Bajaj spare parts
52JF1352	K10 UG BELLY PAN RH SATIN BLACK + DECAL	Bajaj spare parts
52JF1353	K10 UG SEAT COWL LH S. BLK+G GREEN + DEC	Bajaj spare parts
52JF1354	K10 UG SEAT COWL RH S. BLK+G GREEN + DEC	Bajaj spare parts
52JF1355	K10 UG FRT FENDER S. BLACK + GLAM GREEN	Bajaj spare parts
52JF1477	SIDE COVER LH ASSLY SAFIRE BLUE K11 BS6	Bajaj spare parts
52JF1479	ASSLY COVER SIDE LH PEWTER GREY K11 BSI	Bajaj spare parts
52JF1486	COVER SIDE ASSY LH RED DECAL K11 BS6	Bajaj spare parts
52JF1488	COVER SIDE ASSY LH WHITE DECAL K11 BS6	Bajaj spare parts
52JF1532	K10 FRAME ASSEMBLY FOR CKD	Bajaj spare parts
52JF1565	K10 B FRONT FENDER AURORA GREEN	Bajaj spare parts
52JF1696	SF FOR COVER LH ASSLY JF541216	Bajaj spare parts
52JF1714	COWL OIL COOLER ASSLY COMP K11 BS6	Bajaj spare parts
52JF1768	K10 BELLY PAN LH SATIN BLACK + RED DECAL	Bajaj spare parts
52JF1769	K10 BELLY PAN RH SATIN BLACK + RED DECAL	Bajaj spare parts
52JF1770	ASSLY FRONT FENDER K10 B CANYON RED	Bajaj spare parts
52JF1774	K10 SEAT COWL LH CANYON RED + DECAL	Bajaj spare parts
52JF1776	K10 B SEAT COWL RH CANYON RED	Bajaj spare parts
52JF1800	BALANCER ASSEMBLY-JF531214 WITH DOME NUT	Bajaj spare parts
52JF1858	TANK COVER SIDE LH PEARL MET WHITE+DECAL	Bajaj spare parts
52JF1859	TANK COVER SIDE RH PEARL MET WHITE+DECAL	Bajaj spare parts
52JF1860	TANK COVER SIDE LH PEWTER GREY+DECAL	Bajaj spare parts
52JF1861	TANK COVER SIDE RH PEWTER GREY+DECAL	Bajaj spare parts
52JF1862	TANK COVER SIDE LH BURNT RED+DECAL	Bajaj spare parts
52JF1863	TANK COVER SIDE RH BURNT RED+DECAL	Bajaj spare parts
52JF1864	TANK SIDE COVER LH PLASMA BLUE+S BLK+DEC	Bajaj spare parts

52JF1865	TANK SIDE COVER RH PLASMA BLUE+S BLK+DEC	Bajaj spare parts
52JF1866	SEAT COWL ASSY JF181001 P MET WHT+DECAL	Bajaj spare parts
52JF1867	SEAT COWL ASSY JF181001 BURNT RED+DECAL	Bajaj spare parts
52JF1868	SEAT COWL ASSY JF181001 PEWTR GRAY+DECAL	Bajaj spare parts
52JF1869	SEAT COWL ASSY JF181001 PLASMA BLUE+DECA	Bajaj spare parts
52JF1870	SIDE MASK LH JL181233 SA BLACK+WHITE DEC	Bajaj spare parts
52JF1871	SIDE MASK LH JL181233 SA BLACK+RED DECAL	Bajaj spare parts
52JF1872	SIDE MASK LH JL181233 SA BLACK+GREY DECL	Bajaj spare parts
52JF1873	SIDE MASK LH JL181233 SA BLACK+BLUE DEC	Bajaj spare parts
52JF1874	SIDE MASK RH JL181234 SA BLACK+WHITE DEC	Bajaj spare parts
52JF1875	SIDE MASK RH JL181234 SATN BLACK+RED DEC	Bajaj spare parts
52JF1876	SIDE MASK RH JL181234 SA BLACK+GREY DEC	Bajaj spare parts
52JF1877	SIDE MASK RH JL181234 SA BLACK+BLUE DEC	Bajaj spare parts
52JF1882	BELLY PAN LH JF181286 SA BLK+WHITE DECAL	Bajaj spare parts
52JF1883	BELLY PAN LH JF181286 SATIN BLK+RED DEC	Bajaj spare parts
52JF1884	BELLY PAN LH JF181286 SATIN BLK+GREY DEC	Bajaj spare parts
52JF1885	BELLY PAN LH JF181286 SATIN BLK+BLUE DEC	Bajaj spare parts
52JF1886	BELLY PAN RH JF181288 SA BLK+WHITE DECAL	Bajaj spare parts
52JF1887	BELLY PAN RH JF181288 SATIN BLK+RED DEC	Bajaj spare parts
52JF1888	BELLY PAN RH JF181288 SATIN BLK+GREY DEC	Bajaj spare parts
52JF1889	BELLY PAN RH JF181288 SATIN BLK+BLUE DEC	Bajaj spare parts
52JF1897	K10 UG FRT FENDER RACING RED	Bajaj spare parts
52JF1921	TANK COVER TOP PEWTER GREY+DECAL K11 BS6	Bajaj spare parts
52JF1922	TANK COVER TOP PLASMA BLUE+S BLK+DEC K11	Bajaj spare parts
52JF1923	TANK COVER TOP BURNT RED+DECAL K11 BS6	Bajaj spare parts
52JF1924	TANK COVER TOP PEARL MET WHITE+DECAL K11	Bajaj spare parts
52JF1930	FRONT FENDER ASSLY K11 BS6 S BLACK+DECAL	Bajaj spare parts
52JF1931	K11 BS6 TIE ROD (JF561428) WITH NUT ASS	Bajaj spare parts
52JF1932	K11BS6ASSLYLEVER COMPCHANGE GEAR(JF561425	Bajaj spare parts
52JF1941	FRONT FENDER ASSLY K201B SATIN BLACK+DEC	Bajaj spare parts
52JF1943	BKT SIDE COVER WITH GROMMET - K201B	Bajaj spare parts
52JF1946	TIE ROD WITH NUT ASSLY K201B	Bajaj spare parts
52JF1954	COWL OIL COOLER ASSLY COMP K201B	Bajaj spare parts
52JF2081	K201B TANK COVER SIDE RH PEWTER GREY+DCL	Bajaj spare parts
52JF2082	K201B TANK COVER SIDE LH PEWTER GREY+DCL	Bajaj spare parts
52JF2083	K201B SEAT COWL ASSY PEWTR GRAY+DECAL	Bajaj spare parts
52JF2085	K201B TANK COVER SIDE LH BURNT RED+DECAL	Bajaj spare parts
52JF2086	K201B TANK COVER SIDE RH BURNT RED+DECAL	Bajaj spare parts
52JF2089	K201B SEAT COWL ASSY JF181001 B. RED+DCL	Bajaj spare parts
52JF2095	K201B TANK COVER SIDE LH FIERY ORG+DECAL	Bajaj spare parts
52JF2096	K201B TANK COVER SIDE RH FIERY ORG+DECAL	Bajaj spare parts
52JF2098	SIDE MASK LH SATIN BLACK+DECAL FIERY ORG	Bajaj spare parts
52JF2099	SIDE MASK RH SATIN BLACK+DECAL FIERY ORG	Bajaj spare parts
52JF2100	BELLY PAN LH JF181286 SATIN BLK+ORG DEC	Bajaj spare parts
52JF2101	BELLY PAN RH JF181288 SATIN BLK+ORG DEC	Bajaj spare parts

52JF2103	K201B SEAT COWL ASSY JF181001 F. ORG+DCL	Bajaj spare parts
52JF2107	K201B TANK COVER SIDE LH BEACH BLUE+DECL	Bajaj spare parts
52JF2108	K201B TANK COVER SIDE RH BEACH BLUE+DECL	Bajaj spare parts
52JF2110	SIDE MASK LH SATIN BLACK+DECL BEACH BLUE	Bajaj spare parts
52JF2111	SIDE MASK RH SATIN BLACK+DECL BEACH BLUE	Bajaj spare parts
52JF2112	BELLY PAN LH JF181286 SATIN BLK+BLUE DEC	Bajaj spare parts
52JF2113	BELLY PAN RH JF181288 SATIN BLK+BLUE DEC	Bajaj spare parts
52JF2115	K201B SEAT COWL ASSY JF181001 B. BLUE+DC	Bajaj spare parts
52JF2207	K10 UG SEAT COWL LH R RED BLK +DCL N C&G	Bajaj spare parts
52JF2209	K10 UG SEAT COWL RH R RED BLK +DCL N C&G	Bajaj spare parts
52JF2227	K10 UG BELLY PAN RH SAT BLK+DEC N C&G	Bajaj spare parts
52JF2228	K10 UG BELLY PAN LH SAT BLK+DEC N C&G	Bajaj spare parts
52JF2230	K10 BELLY PAN RH SAT BLK+RED DEC N C&G	Bajaj spare parts
52JF2231	K10 BELLY PAN LH SAT BLK+RED DEC N C&G	Bajaj spare parts
52JF2238	K10SIDE MASK LH SUB ASSLY R RED+DEC	Bajaj spare parts
52JF2239	K10SIDE MASK RH SUB ASSLY R RED+DEC	Bajaj spare parts
52JF2245	TANK COVER TOP RACING RED + DECAL	Bajaj spare parts
52JF2279	BELLY PAN LH SAT BLK+GREY DEC NEW C&G	Bajaj spare parts
52JF2280	BELLY PAN RH SAT BLK+GREY DEC NEW C&G	Bajaj spare parts
52JF2307	K10B ASLY SEAT COWL LH ABS SPAR BLACK	Bajaj spare parts
52JF2309	K10B ASLY SEAT COWL RH ABS SPAR BLACK	Bajaj spare parts
52JF2311	K10B ASSLY FRONT FENDER SPARK BLK	Bajaj spare parts
52JF2312	K10B ASLY TANK COVER SPARK BLK N C&G	Bajaj spare parts
52JF2313	T COVER LH PLAT SILVER+SPARK BLK DEC	Bajaj spare parts
52JF2314	T COVER RH PLAT SILVER+SPARK BLK DEC	Bajaj spare parts
52JF2315	TANK COVER TOP SPARK BLACK + DECAL	Bajaj spare parts
52JF2316	K10B ASSLY SIDE COVER RH PLAT SILVER	Bajaj spare parts
52JF2317	K10B ASSLY SIDE COVER LH PLAT SILVER	Bajaj spare parts
52JF2320	K10B ASSLY BELLY PAN SPARK BLK N C&G	Bajaj spare parts
52JF2321	K10B BELLY PAN LH SAT BLK+SPR BLK DEC	Bajaj spare parts
52JF2322	K10B BELLY PAN RH SAT BLK+SPR BLK DEC	Bajaj spare parts
52JF2323	K10SIDE MASK LH SUB ASLY SPARK BLK+DEC	Bajaj spare parts
52JF2324	K10SIDE MASK RH SUB ASLY SPARK BLK+DEC	Bajaj spare parts
52JF2326	T COVER LH PLAT SILV MATT+ R RED DEC	Bajaj spare parts
52JF2327	T COVER RH PLAT SILV MATT+ R RED DEC	Bajaj spare parts
52JF2329	K10 SEAT COWL LH CITRUS RUSH+ DECAL	Bajaj spare parts
52JF2331	K10 SEAT COWL RH CITRUS RUSH+ DECAL	Bajaj spare parts
52JF2332	K10 B ASSLY FRONT FENDER CITRUS RUSH	Bajaj spare parts
52JF2334	K10TANK COVER LH PLAT SILV+CITRUS DCL	Bajaj spare parts
52JF2335	K10TANK COVER RH PLAT SILV+CITRUS DCL	Bajaj spare parts
52JF2336	K10TANK COVER TOP CITRUS RUSH+ DCL	Bajaj spare parts
52JF2340	K10 BELLY PAN LH SAT BLK+CITRUS DEC	Bajaj spare parts
52JF2341	K10 BELLY PAN RH SAT BLK+CITRUS DEC	Bajaj spare parts
52JF2342	K10SIDE MASK LH SUB ASSLY CIT RUSH+DEC	Bajaj spare parts
52JF2343	K10SIDE MASK RH SUB ASSLY CIT RUSH+DEC	Bajaj spare parts

52JF2442	K10C WINDSHILED JF232000 W AURORA GRN DE	Bajaj spare parts
52JF2443	K10C WINDSHILED JF232000 W CHR BLK DECAL	Bajaj spare parts
52JF2472	K10 FRAME ASSLY JF111280 WITH SPACER	Bajaj spare parts
52JF2935	K10 FRAME ASSLY JF111366 WITH SPACER	Bajaj spare parts
52JF2996	TANK COVER SIDE LH PEARL MET WHITE+DECAL	Bajaj spare parts
52JF2997	TANK COVER SIDE RH PEARL MET WHITE+DECAL	Bajaj spare parts
52JF3036	SEAT COWL ASSY JF181001 P MET WHITE+DEC	Bajaj spare parts
52JF3037	BELLY PAN LH PERL MET WH S BLK+DECAL	Bajaj spare parts
52JF3038	BELLY PAN RH PERL MET WH S BLK+DECAL	Bajaj spare parts
52JF3040	TANK COVER SIDE LH EBONY BLACK+DECAL	Bajaj spare parts
52JF3041	TANK COVER SIDE RH EBONY BLACK+DECAL	Bajaj spare parts
52JF3043	SEAT COWL ASSY JF181001 EBONY BLACK+ DEC	Bajaj spare parts
52JF3044	BELLY PAN LH EBONY BLACK S BLK+DECAL	Bajaj spare parts
52JF3045	BELLY PAN RH EBONY BLACK S BLK+DECAL	Bajaj spare parts
52JG0308	FRAME ASSLY-ABS VER WI BRG RACE	Bajaj spare parts
52JG0309	FRAME ASSLY WI BRG RACE	Bajaj spare parts
52JG0310	FRAME ASSLY US VER WI BRG RACE	Bajaj spare parts
52JG1096	JG111195 ADV FRM RR ASY AFTR BLK POWD CT	Bajaj spare parts
52JG1103	PEDAL ASSLY BRAKE ADVENTURE	Bajaj spare parts
52JG1108	ADV 390 TANK SPOILER LH CER WHITE + DCL	Bajaj spare parts
52JG1109	ADV 390 TANK SPOILER RH CER WHITE + DCL	Bajaj spare parts
52JG1110	ADV 390 TANK SPOILER LH MET BLACK + DCL	Bajaj spare parts
52JG1111	ADV 390 TANK SPOILER RH MET BLACK + DCL	Bajaj spare parts
52JG1112	ADV.390 SEATCOWL UPPER CERA WHITE + DCL	Bajaj spare parts
52JG1113	ADV.390 SEATCOWL UPPER MET.BLACK + DCL	Bajaj spare parts
52JG1175	ADV 250 TANK SPOILER LH BLKGLOSS + DCL	Bajaj spare parts
52JG1176	ADV 250 TANK SPOILER RH BLKGLOSS + DCL J	Bajaj spare parts
52JG1177	ADV 250 TANK SPOILER LH ECORG + DCL JG23	Bajaj spare parts
52JG1178	ADV 250 TANK SPOILER RH ECORG + DCL JG23	Bajaj spare parts
52JG1181	ADV250 SEAT COWL UPP ELCORG+DECAL	Bajaj spare parts
52JG1182	ADV250 SEAT COWL UPPER BLK GLOSS+DECAL	Bajaj spare parts
52JG1238	BALANCER ASSEMBLY-JG531231 WITH DOME NUT	Bajaj spare parts
52JG1239	ADVENTURE BELLY PAN BRACKET SUB ASSLY	Bajaj spare parts
52JG1419	ADV390 TANK SPOILR LH LIQ METALGLOSS+DCL	Bajaj spare parts
52JG1420	ADV390 TANK SPOILR RH LIQ METALGLOSS+DCL	Bajaj spare parts
52JG1421	S.COWL UPR CERA WHITE GLOSS+DCL ADV 390	Bajaj spare parts
52JG1422	S.COWL UPR LIQ METAL GLOSS+DCL ADV 390	Bajaj spare parts
52JG1423	ADV 390 TANK SPOILER RH EB ORG GLOSS+DCL	Bajaj spare parts
52JG1424	ADV 390 TANK SPOILER LH EB ORG GLOSS+DCL	Bajaj spare parts
52JG1435	ADV250 TANK SPOILR LH CERWHITE GLOS+DCL	Bajaj spare parts
52JG1436	ADV250 TNK SPOILRRH C WHITEGLOS+DCL BLUE	Bajaj spare parts
52JG1437	ADV250 TNK SPOILR LH C WHITE GLOS+DCL ORG	Bajaj spare parts
52JG1438	ADV250 TNK SPOILR RH C WHITE GLOS+DCL ORG	Bajaj spare parts
52JG1439	ADV250 S COWL UPR CE WHITE GLOS+DCL ORG	Bajaj spare parts
52JG1440	ADV250 S COWL UPR CE WHITE GLOS+DCL BLUE	Bajaj spare parts

52JG1623	ADV-X390 SPOILER LH EB ORG GLOSS DCL+LQR	Bajaj spare parts
52JG1624	ADV-X390 SPOILER RH EB ORG GLOSS DCL+LQR	Bajaj spare parts
52JG1625	ADV-X390 SEAT CWL UPR ORG GLOSS DCL+LQR	Bajaj spare parts
52JG1626	ADV-X390 FR FENDR JG181445 +DCL	Bajaj spare parts
52JG1630	TANK ASSLY JG171160 WING BLUE MET. MAT	Bajaj spare parts
52JG1633	ADV-X390 BLCK SPOILR LH BLK GLOS DCL+LQR	Bajaj spare parts
52JG1634	ADV-X390 BLCK SPOILR RH BLK GLOS DCL+LQR	Bajaj spare parts
52JG1635	ADV-X390 BLACK FR FENDR JG181445 +DCL	Bajaj spare parts
52JH0018	ASSLY STAY MAIN STEP LH (C101)	Bajaj spare parts
52JH0019	ASSLY MAIN STEP RH (C101)	Bajaj spare parts
52JH0020	ASSLY PILLION STEP COMP RH (C101)	Bajaj spare parts
52JH0021	ASSLY PILLION STEP COMP LH (C101)	Bajaj spare parts
52JH0022	ASSLY BRAKE PEDAL (C101)	Bajaj spare parts
52JH0064	SD CVR RH EBONY BLACK WH DCL C 101	Bajaj spare parts
52JH0075	FUEL TANK COCKTIL WINE RED WH DKL C101	Bajaj spare parts
52JH0088	GRAB HANDLE WITH (PT + PRIMER) C101	Bajaj spare parts
52JH0412	SIDE COVER LH SAFFIRE BLUE TH DECAL	Bajaj spare parts
52JH0415	SIDE COVER RH SAFFIRE BLU WH DECAL	Bajaj spare parts
52JH0427	FUEL TANK SAFFIRE BLUE WITH DECAL	Bajaj spare parts
52JH0433	EVAP FUEL TANK CAP WITH LOCK SET C101	Bajaj spare parts
52JH0448	COVER SEAT PILLION FLAME RED	Bajaj spare parts
52JH0449	CVR SEAT PILLION SAFFIRE BLUE S/ACVR SEA	Bajaj spare parts
52JH0541	FUEL TANK EB.BLACK WITH DECAL	Bajaj spare parts
52JH0542	FUEL TANK PEARL WHITE WITH DCL	Bajaj spare parts
52JH0543	FUEL TANK COCKTAIL WINE RED DCL	Bajaj spare parts
52JH0544	FUEL TANK DARK MONTEGO BLUE DCL	Bajaj spare parts
52JH0691	ASSLY BACKREST MATTE SLIK BLACK	Bajaj spare parts
52JH0773	ASSEMBLY OF INTAKE MANIFOLD -V15 POWER U	Bajaj spare parts
52JH0775	SD CVR RH EB.BLK WH DKL V15 POWR UP	Bajaj spare parts
52JH0797	SIDE COVER LH C.W.RED WH DKL V15 PWR UP	Bajaj spare parts
52JH0798	SIDE COVER RH C.W.RED WH DKL V15 PWR UP	Bajaj spare parts
52JH0800	SIDE COVER LH D.MON.BLU WH DKL V15 PWR U	Bajaj spare parts
52JH0801	SIDE COVER RH D.MON.BLU WH DKL V15 PWR U	Bajaj spare parts
52JH1029	CRANKCASE RH WITH PLUG P110 5G	Bajaj spare parts
52JH1120	CCRHS/A-JH541007(MODINO1DIA)BLACK WPLUG	Bajaj spare parts
52JH5505	TAPPET COVER C101B WITH O RING-V12	Bajaj spare parts
52JH5506	ASSLY OHC COVER C101B WITH O RING	Bajaj spare parts
52JH5507	PLATINUM SILVER COVER MAGNETO ASSLY V15/	Bajaj spare parts
52JH5511	FULL FINISH CCRH (JH541007) BLACK	Bajaj spare parts
52JK0382	SD CVR LH EB.BLK WH BLU DKL PLATINA 110	Bajaj spare parts
52JK0385	SEAT COWL S/A EB.BLK WH BLU(PLATINA 110	Bajaj spare parts
52JK0386	COWLING WH EB.BLK WH BLU DKL(PLATINA 110	Bajaj spare parts
52JK0388	SD CVR LH EB.BLK WH GRY DKL PLATINA 110	Bajaj spare parts
52JK0390	SEAT COWL EB.BLK WH GRY DKL (PLATINA 110	Bajaj spare parts
52JK0392	COWLING WH EB.BLK WH GRY DKL(PLATINA 110	Bajaj spare parts

52JK0394	SIDE CVR LH ELEC.BLUE DKL PLATINA 110	Bajaj spare parts
52JK0395	SIDE CVR RH ELEC.BLUE DKL PLATINA 110	Bajaj spare parts
52JK0396	SEAT COWL ELEC.BLUE DKL (PLATINA 110	Bajaj spare parts
52JK0398	COWLING WH ELEC.BLUE DKL(PLATINA 110	Bajaj spare parts
52JK0400	SD CVR LH C.WINE RED DKL PLATINA 110	Bajaj spare parts
52JK0402	SEAT COWL C.WINE RED DKL (PLATINA 110	Bajaj spare parts
52JK0404	COWLING WH C.WINE RED DKL(PLATINA 110	Bajaj spare parts
52JK0408	TANK EB.BLK WH BLU DKL(PLATINA 110 CBS)	Bajaj spare parts
52JK0410	TANK EB.BLK WH GRAY DKL(PLATINA 110 CBS)	Bajaj spare parts
52JK0441	COVER LH RR SL BLK W LBL PL-110DISC CBS	Bajaj spare parts
52JK0442	COWLING EB BLK W BLU DKL PL-110DISC CBS	Bajaj spare parts
52JK0444	COWLING EB BLK W RED DKL PL-110DISC CBS	Bajaj spare parts
52JK0446	COWLING CW RED W DKL PL-110DISC CBS	Bajaj spare parts
52JK0448	FR FENDER EB BLK W BLU DKL PL-110DI CBS	Bajaj spare parts
52JK0450	FR FENDER EB BLK W RED DKL PL-110DI CBS	Bajaj spare parts
52JK0452	FR FENDER CW RED W DKL PL-110DISC CBS	Bajaj spare parts
52JK0454	SD COV LH COB BLU W BLU DKL PL-110DI CBS	Bajaj spare parts
52JK0455	SD COV RH COB BLU W BLU DKL PL-110DI CBS	Bajaj spare parts
52JK0456	SD COV LH RYL BRGDY RED DKL PL-110DI CBS	Bajaj spare parts
52JK0457	SD COV RH RYL BRGDY RED DKL PL-110DI CBS	Bajaj spare parts
52JK0458	SD COV LH TR RED-CW RED DKL PL-110DI CBS	Bajaj spare parts
52JK0459	SD COV RH TR RED-CW RED DKL PL-110DI CBS	Bajaj spare parts
52JK0460	SEAT COWL EB BLK W BLU DKL PL-110DI CBS	Bajaj spare parts
52JK0462	SEAT COWL EB BLK W RED DKL PL-110DI CBS	Bajaj spare parts
52JK0464	SEAT COWL CW RED W DKL PL-110DISC CBS	Bajaj spare parts
52JK0473	FUEL TANK EB BLK W BLU DKL PL-110DI CBS	Bajaj spare parts
52JK0475	FUEL TANK EB BLK W RED DKL PL-110DI CBS	Bajaj spare parts
52JK0477	FUEL TANK CW RED W DKL PL-110DISC CBS	Bajaj spare parts
52JK0714	FUEL TANK EB BLK WH BLU DECAL PL110 DI	Bajaj spare parts
52JK0715	FUEL TANK CW RED W DKL PL-110DI BS6	Bajaj spare parts
52JK0716	FUEL TANK EB BLK W RED DKL PL-110DI BS6	Bajaj spare parts
52JK0720	SD COV RH COB BLU W BLU DKL PL-110DI BS6	Bajaj spare parts
52JK0721	SD COV RH RYL BRGDY RED DKL PL-110DI BS6	Bajaj spare parts
52JK0722	SD COV RH TR RED-CW RED DKL PL-110DI BS6	Bajaj spare parts
52JK0723	COWLING EB BLK W BLU DKL PL-110DI BS6	Bajaj spare parts
52JK0724	COWLING EB BLK W RED DKL PL-110DI BS6	Bajaj spare parts
52JK0725	COWLING CW RED DKL PL-110DI BS6	Bajaj spare parts
52JK0835	ST COWL EB BLK W BLU DKL PLA-110 4G DISC	Bajaj spare parts
52JK0837	ST COWL EB BLK W RED DKL PLA-110 4G DS	Bajaj spare parts
52JK0839	ST COWL CW RED W DKL PLA-110 4G DS	Bajaj spare parts
52JK0841	TANK EB BLK W BLU DKL PLA-110 4G DS	Bajaj spare parts
52JK0843	TANK EB BLK W RED DKL PLA-110 4G DS	Bajaj spare parts
52JK0845	TANK CW RED W DKL PLA-110 4G DS	Bajaj spare parts
52JK0870	COVER LH RR SL BLK W LBL PLA-110 DS ABS	Bajaj spare parts
52JK0887	COWLING W DKL CH BLK PLA-110 DS ABS	Bajaj spare parts

52JK0888	COWLING W DKL S BLK-BLU PLA-110 DS ABS	Bajaj spare parts
52JK0889	COWLING W DKL S BLK-RED PLA-110 DS ABS	Bajaj spare parts
52JK0890	COWLING W DKL VOL MAT RED PLA-110 DS ABS	Bajaj spare parts
52JK0895	FR FENDER W DKL CH BLK PLA-110 DS ABS	Bajaj spare parts
52JK0898	FR FENDER W DKL V MAT RED PLA-110 DS ABS	Bajaj spare parts
52JK0903	SEAT COWL W DKL CH BLK PLA-110 DS ABS	Bajaj spare parts
52JK0904	SEAT COWL W DKL S BLK-BLU PLA-110 DS ABS	Bajaj spare parts
52JK0906	SEAT COWL W DKL V MAT RED PLA-110 DS ABS	Bajaj spare parts
52JK0911	TANK W DKL CH BLK PLA-110 DS ABS BS6	Bajaj spare parts
52JK0914	TANK W DKL V MAT RED PLA-110 DS ABS BS6	Bajaj spare parts
52JK0919	SIDE CVR LH W DKL EB BLK PLA-110 DS ABS	Bajaj spare parts
52JK0922	SIDE CVR LH W DKL IND MET PLA-110 DS ABS	Bajaj spare parts
52JK0923	SIDE CVR RH W DKL EB BLK PLA-110 DS ABS	Bajaj spare parts
52JK0926	SIDE CVR RH W DKL IND MET PLA-110 DS ABS	Bajaj spare parts
52JK0929	COWLING W DKL S BEACH-BLU PLA-110 DS ABS	Bajaj spare parts
52JK0931	FR FENDER W DKL S BCH-BLU PLA-110 DS ABS	Bajaj spare parts
52JK0933	SEAT COWL W DKL S BCH-BLU PLA-110 DS ABS	Bajaj spare parts
52JK0935	TANK W DKL S BCH-BLU PLA-110 DS ABS BS6	Bajaj spare parts
52JK0937	SIDE CVR LH W DKL GAR RED PLA-110 DS ABS	Bajaj spare parts
52JK0938	SIDE CVR RH W DKL GAR RED PLA-110 DS ABS	Bajaj spare parts
52JK0939	ST COWL EB BLK W BLU DKL PLA-110 5G DRUM	Bajaj spare parts
52JK0940	ST COWL EB BLK W RED DKL PLA-110 5G DRUM	Bajaj spare parts
52JK0941	ST COWL CW RED W DKL PLA-110 5G DRUM	Bajaj spare parts
52JK0949	SEAT COWL W DKL CH BLK PLA-110 DS CBS	Bajaj spare parts
52JK0950	SEAT COWL W DKL S BCH-BLU PLA-110 DS CBS	Bajaj spare parts
52JK0951	SEAT COWL W DKL V MAT RED PLA-110 DS CBS	Bajaj spare parts
52JK0955	TANK W DKL CH BLK PLA-110 DS CBS BS6	Bajaj spare parts
52JK0956	TANK W DKL S BCH-BLU PLA-110 DS CBS BS6	Bajaj spare parts
52JK0957	TANK W DKL V MAT RED PLA-110 DS CBS BS6	Bajaj spare parts
52JK0961	FR FENDER ASLY CH BLK PLA-110 DS CBS	Bajaj spare parts
52JK0962	FR FENDER ASLY S BCH-BLU PLA-110 DS CBS	Bajaj spare parts
52JK0963	FR FENDER ASLY V MAT RED PLA-110 DS CBS	Bajaj spare parts
52JK1088	TANK EB BLK W GP GRAY DKL PLA-110 DR	Bajaj spare parts
52JK1090	COWLING EB BLK W G P GRAY DKL PLA-110 DR	Bajaj spare parts
52JK1092	SIDE CVR LH G P GRAY W DKL PLA-110 DR	Bajaj spare parts
52JK1093	SIDE CVR RH G P GRAY W DKL PLA-110 DR	Bajaj spare parts
52JK1094	FR FENDER EB BLK W GP GRAY DKL P-110 DR	Bajaj spare parts
52JK1096	SEAT COWL EB BLK W GP GRAY DKL P-110 DR	Bajaj spare parts
52JK1165	FR FENDER EB BLK W DKL PLATINA 110 ABS	Bajaj spare parts
52JK1166	FR FENDER GL PW GREY W DKL PLA-110 ABS	Bajaj spare parts
52JK1167	FR FENDER CW RED W DKL PLATINA 110 ABS	Bajaj spare parts
52JK1171	CARIER MASK EB BLK W DKL PLATINA 110 ABS	Bajaj spare parts
52JK1172	CARIER MASK GL PW GREY W DKL PLA-110 ABS	Bajaj spare parts
52JK1173	CARIER MASK CW RED W DKL PLATINA 110 ABS	Bajaj spare parts
52JK1177	SIDE COVER LH GP GRY-EB BLK DKL P110 ABS	Bajaj spare parts



52JK1178	SIDE COVER RH GP GRY-EB BLK DKL P110 ABS	Bajaj spare parts
52JK1179	SIDE COVER LH EB BLK-GP GRY DKL P110 ABS	Bajaj spare parts
52JK1180	SIDE COVER RH EB BLK-GP GRY DKL P110 ABS	Bajaj spare parts
52JK1181	SIDE COVER LH GR RED-CW RED DKL P110 ABS	Bajaj spare parts
52JK1182	SIDE COVER RH GR RED-CW RED DKL P110 ABS	Bajaj spare parts
52JK1183	SEAT COWL EB BLK W DKL PLATINA 110 ABS	Bajaj spare parts
52JK1184	SEAT COWL GL PW GREY W DKL PLA-110 ABS	Bajaj spare parts
52JK1185	SEAT COWL CW RED W DKL PLATINA 110 ABS	Bajaj spare parts
52JK1190	FUEL TANK GL PW GREY W DKL PLA-110 ABS	Bajaj spare parts
52JK1191	FUEL TANK CW RED W DKL PLATINA 110 ABS	Bajaj spare parts
52JK1196	FR FENDER SAF BLUE W DKL PLATINA 110 ABS	Bajaj spare parts
52JK1198	CARRIER MASK SAFFIRE BLUE W DKL P110 ABS	Bajaj spare parts
52JK1200	SIDE COVER LH DARK MTGO BLU DKL P110 ABS	Bajaj spare parts
52JK1201	SIDE COVER RH DARK MTGO BLU DKL P110 ABS	Bajaj spare parts
52JK1202	SEAT COWL SAF BLUE W DKL PLATINA 110 ABS	Bajaj spare parts
52JK1204	FUEL TANK SAF BLUE W DKL PLATINA 110 ABS	Bajaj spare parts
52JL0054	COVER SIDE ASSLY LH SATIN BLK	Bajaj spare parts
52JL0055	COVER SIDE ASSLY RH BLK	Bajaj spare parts
52JL0059	FENDER FRONT WTH GUIDE RED	Bajaj spare parts
52JL0065	FENDER FRONT WTH GUIDE BLU	Bajaj spare parts
52JL0066	FENDER FRONT WTH GUIDE BLK	Bajaj spare parts
52JL0067	FENDER FR WTH GUIDE N FLAP	Bajaj spare parts
52JL0072	BKT SIDE STAND	Bajaj spare parts
52JL0095	COVER RH JL	Bajaj spare parts
52JL0141	ASSLY-DISC FRONT JL KHI	Bajaj spare parts
52JL0142	ASSLY-DISC -REAR JL KHI	Bajaj spare parts
52JL0156	ENG STAY ASSLY LH WITH BLACK COL	Bajaj spare parts
52JL0157	ENG STAY ASSLY RH WITH BLACK COLOUR	Bajaj spare parts
52JL0158	STEP ASSLY.MAIN LH MTL COLOUR	Bajaj spare parts
52JL0159	STEP ASSLY.MAIN RH MTL COLOUR	Bajaj spare parts
52JL0181	TANK COVER TOP SAFFIRE BLUE	Bajaj spare parts
52JL0182	TANK COVER COMP SUBASLY	Bajaj spare parts
52JL0188	FENDER FR WTH GUIDE N P RED DECAL	Bajaj spare parts
52JL0189	FENDER FR WTH GUIDE N S BLUE DECA	Bajaj spare parts
52JL0190	FENDER FR WTH GUIDE N M WHITE DECAL	Bajaj spare parts
52JL0191	SIDE MASK LH E BLACK WITH DECAL	Bajaj spare parts
52JL0192	SIDE MASK RH E BLACK WITH DECAL	Bajaj spare parts
52JL0193	SIDE MASK LH P RED WITH DECAL	Bajaj spare parts
52JL0194	SIDE MASK RH P RED WITH DECAL	Bajaj spare parts
52JL0195	SIDE MASK LH S BLUE WITH DECAL	Bajaj spare parts
52JL0196	SIDE MASK RH S BLUE WITH DECAL	Bajaj spare parts
52JL0197	SIDE MASK LH M WHITE WITH DECAL	Bajaj spare parts
52JL0198	SIDE MASK RH M WHITE WITH DECAL	Bajaj spare parts
52JL0218	COVER SIDE TANK LH SAF BLUE	Bajaj spare parts
52JL0254	PILLION STEP RH Assly	Bajaj spare parts

52JL0255	PILLION STEP LH ASSLY WITH MOONLIGHT	Bajaj spare parts
52JL0315	SEAT COWL ASSLY COMP (K16) PASS RED	Bajaj spare parts
52JL0316	SEAT COWL ASSLY COMP (K16) BLUE	Bajaj spare parts
52JL0317	SEAT COWL ASSLY COMP (K16) BLACK	Bajaj spare parts
52JL0353	FAIRING FR LH SAFFIRE BLUE	Bajaj spare parts
52JL0354	SIDE FAIRING FR LH E BLACK K16A SPD	Bajaj spare parts
52JL0420	ASSLY LEVER COMP CHANGE GEAR K16 A	Bajaj spare parts
52JL0892	SF FOR ASSLY CLUTCH COVER JL541233	Bajaj spare parts
52JL0917	K4 UG TANK COVER TOP PASSION RE	Bajaj spare parts
52JL0918	K4 UG SIDE MASK LH SATIN BLK RED DCAL	Bajaj spare parts
52JL0919	K4 UG SIDE MASK RH SATIN BLK RED DCAL	Bajaj spare parts
52JL0920	K4 UG SEAT COWL ASSLY MATTE PEWTER GREY	Bajaj spare parts
52JL0923	K4 UG FRONT FENDER MATPEWTGREY+ RED DCAL	Bajaj spare parts
52JL0926	K4 UG TANK COVER TOP SPARKLE BLACK DECAL	Bajaj spare parts
52JL0927	K4 UG SIDE MASK LH SATIN BLK BLK DCAL	Bajaj spare parts
52JL0928	K4 UG SIDE MASK RH SATIN BLK BLK DCAL	Bajaj spare parts
52JL0929	K4 UG SEAT COWL ASSLY MATTE PETER GEY	Bajaj spare parts
52JL0932	K4 UG FRONT FENDER MATPEWGREY+ BLK DCAL	Bajaj spare parts
52JL0935	K4 UG TANK COVER TOP METALLIC WHITE WITH	Bajaj spare parts
52JL0936	K4 UG SIDE MASK LH SATIN BLK WHITE DCA	Bajaj spare parts
52JL0937	SIDE MASK RH SATIN BLK WHITE DCAL	Bajaj spare parts
52JL0938	K4 UG SEAT COWL ASSLY MATT PEWTER GREY	Bajaj spare parts
52JL0941	K4 UG FRONT FENDER MATPGREY+ WHITE DCAL	Bajaj spare parts
52JL0979	K4 UG TANK COVER TOP BRIGHT YEL + DCAL	Bajaj spare parts
52JL0980	K4 UG SIDE MASK LH SATIN BLK + YEL DCAL	Bajaj spare parts
52JL0981	K4 UG SIDE MASK RH SATIN BLK + YEL DCAL	Bajaj spare parts
52JL0982	K4 UG SEAT COWL ASSLY MATT PEWTER GREY	Bajaj spare parts
52JL0985	K4 UG FRONT FENDER + YEL DCAL	Bajaj spare parts
52JL0992	COVER SIDE ASSY LH RED DECAL K4 BSIV UG	Bajaj spare parts
52JL0993	COVER SIDE ASSY LH BLACK DECAL K4 BSIV	Bajaj spare parts
52JL0994	COVER SIDE ASSY LH WHITE DECAL K4 BSIV	Bajaj spare parts
52JL0995	COVER SIDE ASSY LH YELLOW DECAL K4 BSIV	Bajaj spare parts
52JL0996	COVER SIDE ASSY RH RED DECAL K4 BSIV UG	Bajaj spare parts
52JL0997	COVER SIDE ASSY RH BLACK DECAL K4 BSIV	Bajaj spare parts
52JL0998	COVER SIDE ASSY RH WHITE DECAL K4 BSIV	Bajaj spare parts
52JL0999	COVER SIDE ASSY RH YELLOW DECAL K4 BSIV	Bajaj spare parts
52JL1018	ASSLY FR.FENDER RED DCAL K4 BSIV UG	Bajaj spare parts
52JL1019	ASSLY FR.FENDER BLACK DCAL K4 BSIV UG	Bajaj spare parts
52JL1020	ASSLY FR.FENDER WHITE DCAL K4 BSIV UG	Bajaj spare parts
52JL1021	ASSLY FR. FENDER + YELLOW DCAL K4 BSIVUG	Bajaj spare parts
52JL1024	STEP ASSLY MAIN LH SLATE GREY K4 UG BSIV	Bajaj spare parts
52JL1029	JL TANK COVER LH BRIGHT YELLOW + MATT PE	Bajaj spare parts
52JL1033	JL TANK COVER RH B YELLOW + MT PTR GREY	Bajaj spare parts
52JL1035	STEP ASSLY MAIN RH SLATE GREY K4 UG BSIV	Bajaj spare parts
52JL1053	K14 UG ASLY SIDE COVER LH SATIN BLK + RE	Bajaj spare parts

52JL1055	K14 UG ASLY SIDE COVER RH SATIN BLK RE	Bajaj spare parts
52JL1061	K14 UG ASLY SIDE COVER LH SATIN BLK + WH	Bajaj spare parts
52JL1065	K14 UG ASLY SIDE COVER LH SATIN BLK+YEL	Bajaj spare parts
52JL1067	K14 UG ASLY SIDE COVER RH SATIN BLK YE	Bajaj spare parts
52JL1627	K4 NON INTEGRAL EVAP LOCK SET	Bajaj spare parts
52JL1779	SF FOR COVER LH ASSLY JL541274	Bajaj spare parts
52JL1890	BALANCER ASSEMBLY-JL531205 WITH DOME NUT	Bajaj spare parts
52JL1932	SIDE MASK LH SATIN BLK+DECL WHITE	Bajaj spare parts
52JL1933	SIDE MASK LH SATIN BLACK+DECAL BURNT RED	Bajaj spare parts
52JL1934	SIDE MASK LH SATIN BLACK+DECAL GREY	Bajaj spare parts
52JL1935	SIDE MASK LH SATIN BLACK+DEC PLASMA BLUE	Bajaj spare parts
52JL1936	SIDE MASK RH SATIN BLK+DECL WHITE	Bajaj spare parts
52JL1937	SIDE MASK LH SATIN BLACK+DECAL BURNT RED	Bajaj spare parts
52JL1938	SIDE MASK RH SATIN BLACK+DECAL GREY	Bajaj spare parts
52JL1939	SIDE MASK RH SATIN BLACK+DEC PLASMA BLUE	Bajaj spare parts
52JL1940	SIDE COVER LH SATIN BLACK+DECAL	Bajaj spare parts
52JL1943	BELLY PAN LH SATIN BLK+DECL FLURO YELLOW	Bajaj spare parts
52JL1944	BELLY PAN LH SATIN BLACK+DECAL BURNT RED	Bajaj spare parts
52JL1945	BELLY PAN LH SATIN BLACK+DEC PLASMA BLUE	Bajaj spare parts
52JL1946	BELLY PAN RH SATIN BLK+DEC FLURO YELLOW	Bajaj spare parts
52JL1947	BELLY PAN RH SATIN BLACK+DECAL BURNT RED	Bajaj spare parts
52JL1948	BELLY PAN RH SATIN BLACK+DEC PLASMA BLUE	Bajaj spare parts
52JL1975	TANK COVER SIDE LH PEARL MET WHITE+DECAL	Bajaj spare parts
52JL1976	TANK COVER SIDE RH PEARL MET WHITE+DECAL	Bajaj spare parts
52JL1977	TANK COVER SIDE LH BURNT RED+DECAL	Bajaj spare parts
52JL1978	TANK COVER SIDE RH BURNT RED+DECAL	Bajaj spare parts
52JL1979	TANK COVER SIDE LH PEWTER GREY+DECAL	Bajaj spare parts
52JL1980	TANK COVER SIDE RH PEWTER GREY+DECAL	Bajaj spare parts
52JL1983	SEAT COWL ASSY PLASMA BLUE+SA BLK+DECAL	Bajaj spare parts
52JL1984	SEAT COWL ASSY JL181005 PEWTE GREY+DECAL	Bajaj spare parts
52JL1985	SEAT COWL ASSY BURNT RED+SA BLK+DECAL	Bajaj spare parts
52JL1986	BELLY PAN LH SATIN BLACK+DECAL PEW GREY	Bajaj spare parts
52JL1987	BELLY PAN RH SATIN BLACK+DECAL PEW GREY	Bajaj spare parts
52JL1992	SEAT COWL ASSY JL181005 P MET WHITE+DEC	Bajaj spare parts
52JL1994	TANK COVER SIDE LH PLASMA BLUE+DECAL	Bajaj spare parts
52JL1995	TANK COVER SIDE RH PLASMA BLUE+DECAL	Bajaj spare parts
52JL1996	K4 TANK COVER TOP ASLYPLASMABLUESATINBLK	Bajaj spare parts
52JL1997	K4TANKCVRTOPASLYPEARLMETALICWHITESATINB	Bajaj spare parts
52JL1998	K4 TANK COVER TOP ASSLY BURNT RED SA BLK	Bajaj spare parts
52JL1999	K4 TANK COVER TOP ASSLYPEWTERGREY SA BLK	Bajaj spare parts
52JL2012	K4 BS6 ABS FENDER FRONT SATIN BLACK+DEC	Bajaj spare parts
52JL2018	K4 BS6 ASLY SIDE COVER LH SATIN BLACK+D	Bajaj spare parts
52JL2019	K4 BS6 COVER SIDE ASSY RH SATIN BLACK+DE	Bajaj spare parts
52JL2033	K4 BS6 ASSEMBLY TIE ROD(JL561412)WITHNUT	Bajaj spare parts
52JL2034	K4BS6 ASSLYLEVER COMPCHANGEGEAR JL561413	Bajaj spare parts

52JL2046	K4 SIDE COVER ASY LH SATIN BLACK NON FI	Bajaj spare parts
52JL2048	K4 SIDE COVER ASY RH SATIN BLACK NON FI	Bajaj spare parts
52JL2073	JL111246 FRAME WITH SATIN URBAN WHITE PC	Bajaj spare parts
52JL2179	BELLY PAN LH SAT BLK+DEC PEW GREY N C&G	Bajaj spare parts
52JL2180	BELLY PAN RH SAT BLK+DEC PEW GREY N C&G	Bajaj spare parts
52JL2567	TANK COVER SIDE LH PEARL MET WHITE+DECAL	Bajaj spare parts
52JL2568	TANK COVER SIDE RH PEARL MET WHITE+DECAL	Bajaj spare parts
52JL2570	SEAT COWL ASSY JL181005 P MET WHITE+ R D	Bajaj spare parts
52JL2571	BELLY PAN LH PERL MET WH S BLK+DECAL	Bajaj spare parts
52JL2572	BELLY PAN RH PERL MET WH S BLK+DECAL	Bajaj spare parts
52JL2574	TANK COVER SIDE LH EBONY BLACK+DECAL	Bajaj spare parts
52JL2575	TANK COVER SIDE RH EBONY BLACK+DECAL	Bajaj spare parts
52JL2577	SEAT COWL ASSY JL181005 EBONY BLACK+ B D	Bajaj spare parts
52JL2578	BELLY PAN LH EBONY BLACK S BLK+DECAL	Bajaj spare parts
52JL2579	BELLY PAN RH EBONY BLACK S BLK+DECAL	Bajaj spare parts
52JL2580	SIDE MASK LH SATIN BLACK+DECAL	Bajaj spare parts
52JL2581	SIDE MASK RH SATIN BLACK+DECAL	Bajaj spare parts
52JL2584	K4 TC FRONT FENDER ASSLY_JF181500_DEC	Bajaj spare parts
52JM0013	COVER LH RR	Bajaj spare parts
52JM0018	WINDSHIELD WITH FRAM	Bajaj spare parts
52JM0020	ARM LEVER CHANGE	Bajaj spare parts
52JN0094	COWL FR FLAME RED DE	Bajaj spare parts
52JN0136	TAPPET COVER O RING	Bajaj spare parts
52JP0050	LOCK SET 3 IN 1 WITH CAP EVAP MY17	Bajaj spare parts
52JP0065	SEAT COWL LOWER LHDCALKT21	Bajaj spare parts
52JP0067	SEAT COWL LOWER RHDCALKT21	Bajaj spare parts
52JP0069	SEAT COWL LOWER LHDCALKT22	Bajaj spare parts
52JP0071	SEAT COWL LOWER RHDCALKT22	Bajaj spare parts
52JP0077	DUKE MY17 TANK COVER LH WHI	Bajaj spare parts
52JP0079	DUKE MY17 TANK COVER LH WHI+DCALKT22	Bajaj spare parts
52JP0085	DUKE MY17 TANK COVER RH WHI	Bajaj spare parts
52JP0087	DUKE MY17 TANK COVER RH WHI+DCALKT22	Bajaj spare parts
52JP0093	DUKE MY17 TANK COVER LH EB ORGDCALKT21	Bajaj spare parts
52JP0095	DUKE MY17 TANK COVER LH EB ORGDCALKT22	Bajaj spare parts
52JP0101	DUKE MY17 TANK COVER RH EB ORGDCALKT21	Bajaj spare parts
52JP0103	DUKE TANK CVR RH	Bajaj spare parts
52JP0112	FR ASSLY FR (BLK) +RACE DUKE SPD	Bajaj spare parts
52JP0126	JP111002 CHAS RR AFTR POW CT WTH EL ORNG	Bajaj spare parts
52JP0127	JP111002 CHAS RR AFTR POW CT WTH WHITE	Bajaj spare parts
52JP0185	FRONT FRAME (ELEC ORG-D390)FOR SPD	Bajaj spare parts
52JP0203	REAR FRAME JP111002	Bajaj spare parts
52JP0339	LED HEAD LAMP ASSLY DUKE MY18	Bajaj spare parts
52JP0346	ASSLY DUKE MY18 FRONT FENDER E BLK - EU	Bajaj spare parts
52JP0604	DUKE 125 DOM TANK CVR TOP WHITE+DCL	Bajaj spare parts
52JP0605	DUKE125 DOM TANK CVR TOP ASSLY WHITE+DCL	Bajaj spare parts

52JP0606	DUKE125DOM TANK CVR TOP EBONY BLACK+DCL	Bajaj spare parts
52JP0607	DUKE125DOM TNK CVR TOP ASSLY EBYBLK+DCL	Bajaj spare parts
52JP0608	DUKE125 DOM TNK CVR TOP ELECT ORG + DCL	Bajaj spare parts
52JP0609	DUKE125DOM TNKCVR TOP ASSLY ELECTORG+DCL	Bajaj spare parts
52JP0610	SEAT COWL RH WITH DECAL DUKE 125 DOM	Bajaj spare parts
52JP0612	SEAT COWL LH WITH DECAL DUKE 125 DOM	Bajaj spare parts
52JP0668	ASSLY AIR FILTER DUKE 250 MY20	Bajaj spare parts
52JP0669	ASSLY AIR FILTER DUKE 390 MY 20	Bajaj spare parts
52JP0670	ASSEMBLY PREMUFFLER WITH CHILD PARTS	Bajaj spare parts
52JP0797	ASSEMBLY PREMUFFLER DUKE 200 BS6	Bajaj spare parts
52JP0798	ASSLY AIR FILTER DUKE 200 MY 20	Bajaj spare parts
52JP0885	DUKE 390 TCOVER RH CER WHITE + DCL	Bajaj spare parts
52JP0887	DUKE 390 TCOVER LH CER WHITE + DCL	Bajaj spare parts
52JP0889	DUKE 390 SEAT COWL RH CER WHITE + DCL	Bajaj spare parts
52JP0891	DUKE 390 SEAT COWL LH CER WHITE + DCL	Bajaj spare parts
52JP0900	KTM DUKE MY20 SIDE MASK LH EB BLACK+DCL	Bajaj spare parts
52JP0901	KTM DUKE MY20 SIDE MASK RH EB BLACK+DCL	Bajaj spare parts
52JP0902	SWING ARM SUB ASSLY DUKE 390 MY20	Bajaj spare parts
52JP0903	JP111002 FRAME REAR-CERAMIC WHITE	Bajaj spare parts
52JP0904	JP111002 FRAME REAR-BLACK	Bajaj spare parts
52JP0905	JP111002 FRAME REAR-BLACK	Bajaj spare parts
52JP0906	JP111002 FRAME REAR-SILVER METALLIC MATT	Bajaj spare parts
52JP0913	DUKE 390 TCVR RH SILVER METALLIC MAT+DCL	Bajaj spare parts
52JP0915	DUKE 390 TCVR LH SILVER METALLIC MAT+DCL	Bajaj spare parts
52JP0918	DUKE 390 SEAT COWL RH EBONY BLACK + DCL	Bajaj spare parts
52JP0920	DUKE 390 SEAT COWL LH EBONY BLACK + DCL	Bajaj spare parts
52JP0922	DUKE 250 TCOVER RH DARK GAL MATT + DCL	Bajaj spare parts
52JP0924	DUKE 250 TCOVER LH DARK GAL MATT + DCL	Bajaj spare parts
52JP0926	DUKE 250 TCOVER RH SILVER MET MATT+ DCL	Bajaj spare parts
52JP0928	DUKE 250 TCVRLH SILVER METALLICMATT+DCL	Bajaj spare parts
52JP0930	DUKE 250 SEAT COWL RHDARKGALVANO MAT+DCL	Bajaj spare parts
52JP0932	DUKE 250 SEAT COWL RH EBONY BLACK + DCL	Bajaj spare parts
52JP0934	DUKE 250 SEAT COWL LH DARK GAL MAT +DCL	Bajaj spare parts
52JP0936	DUKE 250 SEAT COWL LH EB BLACK + DCL	Bajaj spare parts
52JP0938	ASSLY DUKE250 FRT FENDER DARK GALV MAT	Bajaj spare parts
52JP0939	DUKE 250 MY20 SIDE MASK LH DARK GALV+DCL	Bajaj spare parts
52JP0940	DUKE 250 MY20 SIDE MASK RH DARK GALV+DCL	Bajaj spare parts
52JP0942	DUKE 250 SIDE MASK LH SLVR MET MATT+DCL	Bajaj spare parts
52JP0943	DUKE 250 SIDE MASK RH SLVR MET MATT+DCL	Bajaj spare parts
52JP0951	LED HEAD LAMP ASSLY DUKE MY20	Bajaj spare parts
52JP0952	DUKE 200 TANK COVER LH EB.ORANGE+DECAL	Bajaj spare parts
52JP0953	DUKE 200 TANK COVER RH EB.ORANGE+DECAL	Bajaj spare parts
52JP0956	DUKE 200 SIDE MASK LH EBONY BLACK+DECAL	Bajaj spare parts
52JP0957	DUKE 200 SIDE MASK RH EBONY BLACK+DECAL	Bajaj spare parts
52JP0959	DUKE 200 T COVER RH CERAMIC WHITE+DCAL	Bajaj spare parts

52JP0960	DUKE 200 T COVER LH CERAMIC WHITE+DCAL	Bajaj spare parts
52JP0963	ASSLY DUKE MY20 FR FENDER CER WHITE	Bajaj spare parts
52JP1127	SIDE MASK LH FR FRG DARK GAL MATT+DECAL	Bajaj spare parts
52JP1128	SIDE MASK RH FR FRG DARK GAL MATT+DECAL	Bajaj spare parts
52JP1131	SIDE MASK LH FR FRG SILVR MET MATT+DECAL	Bajaj spare parts
52JP1132	SIDE MASK RH FR FRG SILVR MET MATT+DECA	Bajaj spare parts
52JP1146	BALANCER ASSEMBLY-JP531206 WITH DOME NUT	Bajaj spare parts
52JP1171	MY17EVAP TANKJP171001EB BLK+LAC+KTM LOGO	Bajaj spare parts
52JP1173	MY17 FUEL TANK JP171007 EB BLK+LAC+LOGO	Bajaj spare parts
52JP1179	SIDE MASK LH FR FRG SILVR MET MATT+DECAL	Bajaj spare parts
52JP1180	SIDE MASK RH FR FRG SILVR MET MATT+DECAL	Bajaj spare parts
52JP1181	SIDE MASK LH FR FRG DARK GAL MATT+DECAL	Bajaj spare parts
52JP1182	SIDE MASK RH FR FRG DARK GAL MATT+DECAL	Bajaj spare parts
52JP1183	LED HEAD LAMP ASSLY DUKE 250 BS6 MY20	Bajaj spare parts
52JP1387	DUKE125DOMSEATCOWLLOWERRH JP181005 +DE	Bajaj spare parts
52JP1389	DUKE125DOM SEATCOWLLH LOW. JP181006 +DE	Bajaj spare parts
52JP1391	DUKE 125 DOM TANK COVER LH EB.ORANGE+DEC	Bajaj spare parts
52JP1393	DUKE 125 DOM TANK COVER RH EB.ORANGE+DEC	Bajaj spare parts
52JP1395	DUKE 125 DOM TANK COVER LH CE. WHITE+DC	Bajaj spare parts
52JP1397	DUKE 125 DOM TANK COVER RH CE WHITE+DECA	Bajaj spare parts
52JP1737	DUKE 125 SEAT COWL UPR RH ORG GLS + DCL	Bajaj spare parts
52JP1738	DUKE 125 SEAT COWL UPR LH ORG GLS + DCL	Bajaj spare parts
52JP1739	DUKE 125 DOM TANK CVR RH CE WHT+BLUE DCL	Bajaj spare parts
52JP1741	DUKE 125 DOM TANK CVR LH CE WHT+BLUE DCL	Bajaj spare parts
52JP1744	DUKE 200 SEAT COWL UP RH ORG OUTER+DECAL	Bajaj spare parts
52JP1746	DUKE 200 SEAT COWL UP LH ORG GLOSS+DECAL	Bajaj spare parts
52JP1749	DUKE 200 TANK CVR RH DARK SILVER +DECAL	Bajaj spare parts
52JP1751	DUKE 200 TANK CVR LH DARK SILVER + DECAL	Bajaj spare parts
52JP1753	DUKE FORK PROTECTOR OTR LH SIV MATT+TAPE	Bajaj spare parts
52JP1754	DUKE FORK PROTECTOR OTR RH SIL MAT+TAPE	Bajaj spare parts
52JP1769	DUKE 390 T COVER ASLY RH LIQ METAL+DECAL	Bajaj spare parts
52JP1771	D390 T COVER ASSLY LH LIQ METAL+DECAL	Bajaj spare parts
52JP1773	DUKE 390 TANK CVR RH DARK GAL MAT+DECAL	Bajaj spare parts
52JP1775	D390 T CVR LH JP181206 DARK GAL MATT+DCL	Bajaj spare parts
52JP1777	D 390 SEAT COWL RH ORG GLOSS + DECAL	Bajaj spare parts
52JP1779	D390 SEAT COWL LH ORG GLOSS + DECAL	Bajaj spare parts
52JP1785	PROTECTOR JP181419 LIQUID METAL MAT+TAPE	Bajaj spare parts
52JP1786	PROTECTOR JP181420 RH LIQU MET MAT +TAPE	Bajaj spare parts
52JP1817	MY22 TANK JP171001 DUKE EB ORG GLOSS+LQR	Bajaj spare parts
52JP1844	DUKE 250 TANK COVER RH BLACK GLOSS+ DCL	Bajaj spare parts
52JP1846	DUKE 250 TANK COVER LH BLACK GLOSS+ DCL	Bajaj spare parts
52JP1851	PROTECTOR FORK OUTER LH ASSLY ELE-ORNGE	Bajaj spare parts
52JP1852	PROTECTOR FORK OUTER RH ASSLY ELE-ORNGE	Bajaj spare parts
52JP1946	TANK JP171001 DUKE LIQUID METAL MATT+LAQR	Bajaj spare parts
52JP2018	FRAME ASSLY REAR JP111002 SLATE GREY	Bajaj spare parts

52JR0070	K17 B/D/F BATTERY CASE ASSLY W GROMMET	Bajaj spare parts
52JR0077	K17D TANK COVER MIDDLE ASSLY	Bajaj spare parts
52JR0086	K17 FRAME ASSLY JR111130 WITH SPACER	Bajaj spare parts
52JR0087	K17D FRAME ASSLY JR111105 WITH SPACER	Bajaj spare parts
52JR0094	K17B SIDE COVER LH ASLY EB BLK+SIB SILVR	Bajaj spare parts
52JR0095	K17B SIDE COVER RH ASLY EB BLK+SIB SILVR	Bajaj spare parts
52JR0102	K17 ABS FR FENDER SUB ASSLY GT BLK DECAL	Bajaj spare parts
52JR0104	K17 ABS FR FENDER SUB ASSLY R.RED DECAL	Bajaj spare parts
52JR0108	K17 FAIRING FRONT LH GLOSS TECH BLK+DEC	Bajaj spare parts
52JR0109	K17 FAIRING FRONT RH GLOSS TECH BLK+DEC	Bajaj spare parts
52JR0110	K17 FAIRING FRONT LH GLOSS R. RED+DECAL	Bajaj spare parts
52JR0111	K17 FAIRING FRONT RH GLOSS R. RED+DECAL	Bajaj spare parts
52JR0113	K17 FAIRING FRONT RH GLOSS SP YELLOW+DEC	Bajaj spare parts
52JR0115	K17B SEAT COWL LH CLOSS TECHNO BLK+DEC	Bajaj spare parts
52JR0116	K17B SEAT COWL RH CLOSS TECHNO BLK+DEC	Bajaj spare parts
52JR0118	K17B COWL SEAT LH GLOS Y RACING RED+DEC	Bajaj spare parts
52JR0119	K17B COWL SEAT RH GLOS Y RACING RED+DEC	Bajaj spare parts
52JR0121	K17B COWL SEAT LH GLOS Y SP YELLOW+DEC	Bajaj spare parts
52JR0122	K17B COWL SEAT RH GLOS Y SP YELLOW+DEC	Bajaj spare parts
52JR0124	K17 TANK GLOSSY TECHNO BLACK+ DECAL+LACQ	Bajaj spare parts
52JR0125	K17 TANK GLOSSY RACING RED+ DECAL+LACQ	Bajaj spare parts
52JR0126	K17 TANK GLOSSY SPORT YELLOW+ DECAL+LACQ	Bajaj spare parts
52JR0127	K17 BELLY PAN TOP LH GLOSS TEC.BLK+DECAL	Bajaj spare parts
52JR0128	K17 BELLY PAN TOP RH GLOSS TEC.BLK+DECAL	Bajaj spare parts
52JR0130	K17 BELLY PAN TOP LH GLOSSY RAC.RED+DEC	Bajaj spare parts
52JR0131	K17 BELLY PAN TOP RH GLOSSY RAC.RED+DEC	Bajaj spare parts
52JR0136	K17 FLAP TANK LH GLOS T.BLK+S.BLK+DEC	Bajaj spare parts
52JR0137	K17 SHROUD LH GLOS TECH BLK+DECAL	Bajaj spare parts
52JR0139	K17 FLAP TANK RH GLOS TEC.BLK+S.BLK+DEC	Bajaj spare parts
52JR0140	K17 SHROUD RH GLOS TECH BLK+DECAL	Bajaj spare parts
52JR0145	K17 FLAP TANK LH GLOSS R.RED+S.BLK+DECAL	Bajaj spare parts
52JR0146	K17 SHROUD LH GLOSS R.RED+DECAL	Bajaj spare parts
52JR0148	K17 FLAP TANK RH GLOSS R.RED+S.BLK+DECAL	Bajaj spare parts
52JR0149	K17 SHROUD RH GLOSS R.RED+DECAL	Bajaj spare parts
52JR0157	K17 RR COVER WITH BOLT & TRNSPRT WASHER	Bajaj spare parts
52JR0160	K17D SEAT COWL LH CLOSS TECHNO BLK+DEC	Bajaj spare parts
52JR0161	K17D SEAT COWL RH CLOSS TECHNO BLK+DEC	Bajaj spare parts
52JR0163	K17D COWL SEAT LH GLOS Y RACING RED+DEC	Bajaj spare parts
52JR0164	K17D COWL SEAT RH GLOS Y RACING RED+DEC	Bajaj spare parts
52JR0167	K17D COWL SEAT RH GLOS Y SP YELLOW+DEC	Bajaj spare parts
52JR0168	K17D TANK GLOSSY TECHN BLACK+ DEC+LACQ	Bajaj spare parts
52JR0169	K17D TANK GLOSSY RACING RED+ DEC+LACQ	Bajaj spare parts
52JR0170	K17D TANK GLOSSY SPORT YELLOW+ DEC+LACQ	Bajaj spare parts
52JR0171	K17D SIDE COVER LH ASLY EB BLK+SIB SILVR	Bajaj spare parts
52JR0172	K17D SIDE COVER RH ASLY EB BLK+SIB SILVR	Bajaj spare parts

52JR0175	K17D SIDE COVER FRNT LH GLOS TEC BLK+DEC	Bajaj spare parts
52JR0177	K17D SIDE COVER FRNT RH GLOS TEC BLK+DEC	Bajaj spare parts
52JR0179	K17D SIDE COVER FRNT LH GLOS RAC RED+DEC	Bajaj spare parts
52JR0181	K17D SIDE COVER FRNT RH GLOS RAC RED+DEC	Bajaj spare parts
52JR0183	K17D SIDE COVER FRNT LH GLOS SPT YEL+DEC	Bajaj spare parts
52JR0185	K17D SIDE COVER FRNT RH GLOS SPT YEL+DEC	Bajaj spare parts
52JR0187	K17D FAIRING FRNT LH GLOS D TECH BLK+DEC	Bajaj spare parts
52JR0188	K17D FAIRING FRNT RH GLOS D TECH BLK+DEC	Bajaj spare parts
52JR0190	K17D FAIRING FR0NT LH GLOSS RUSH RED+DEC	Bajaj spare parts
52JR0191	K17D FAIRING FR0NT RH GLOSS RUSH RED+DEC	Bajaj spare parts
52JR0199	K17 P150 BATTERY CASE WITH GROMMET	Bajaj spare parts
52JR0201	K17 P150 TIE ROD WITH NUT	Bajaj spare parts
52JR0208	K17 P150 SIDE COVER LH SUB ASSLY	Bajaj spare parts
52JR0209	K17 P150 SIDE COVER RH SUB ASSLY	Bajaj spare parts
52JR0241	K17K SIDE COVER LH SUB ASSLY	Bajaj spare parts
52JR0242	K17K SIDE COVER RH SUB ASSLY	Bajaj spare parts
52JR0248	K17 ABS FR FENDER ASSLY CARIBEAN BLUE	Bajaj spare parts
52JR0251	K17 FAIRING FRONT LH GLOS CARIB BLU+DEC	Bajaj spare parts
52JR0252	K17 FAIRING FRONT RH GLOS CARIB BLU+DEC	Bajaj spare parts
52JR0254	K17B COWL SEAT LH GLOS CARIBEAN BLUE+DEC	Bajaj spare parts
52JR0255	K17B COWL SEAT RH GLOS CARIBEAN BLUE+DEC	Bajaj spare parts
52JR0257	K17 BELLY PAN TOP LH GLOSS CARB BLUE+DEC	Bajaj spare parts
52JR0258	K17 BELLY PAN TOP RH GLOS CARB BLUE+DECA	Bajaj spare parts
52JR0260	K17 FLAP TANK LH GLOS CARB BLUE+S.BLK+DE	Bajaj spare parts
52JR0261	K17 SHROUD LH GLOSS CARIBEAN BLUE+DECAL	Bajaj spare parts
52JR0263	K17 FLAP TANK RH GLOS CARB BLU+S.BLK+DEC	Bajaj spare parts
52JR0264	K17 SHROUD RH GLOSS CARIBEAN BLUE+DEC	Bajaj spare parts
52JR0265	K17 TANK GLOSS CARIBEAN BLUE+ DECAL+LACQ	Bajaj spare parts
52JR0271	K17E SEAT COWL LH GLOSS TECHNO BLK+DEC	Bajaj spare parts
52JR0272	K17E SEAT COWL RH GLOSS TECHNO BLK+DEC	Bajaj spare parts
52JR0274	K17E SEAT COWL LH GLOSS RACING RED+DEC	Bajaj spare parts
52JR0275	K17E SEAT COWL RH GLOSS RACING RED+DEC	Bajaj spare parts
52JR0278	K17E RR COVER WITH BOLT & TRNSPRT WASHER	Bajaj spare parts
52JR0279	K17E BATTERY CASE ASSLY W GROMMET	Bajaj spare parts
52JR0287	K17D COWL SEAT LH GLOS Y CARIBN BLU+DEC	Bajaj spare parts
52JR0288	K17D COWL SEAT RH GLOS Y CARIBN BLU+DEC	Bajaj spare parts
52JR0290	K17D FAIRING FR0NT LH INDIGO MAT BLU+DEC	Bajaj spare parts
52JR0291	K17D FAIRING FR0NT RH INDIGO MAT BLU+DEC	Bajaj spare parts
52JR0293	K17D SIDE COVER FRNT RH GLOS Y C BLU+DEC	Bajaj spare parts
52JR0295	K17D SIDE COVER FRNT LH GLOSS Y C BLU+DEC	Bajaj spare parts
52JR0309	K17D TANK GLOSS CARIBEAN BLUE+ DECAL+LAC	Bajaj spare parts
52JR0323	K17 2-CH TIE ROD ASSLY	Bajaj spare parts
52JR0328	K17B SIDE COVER RH ASLY S BLK_MATT BLK	Bajaj spare parts
52JR0329	K17B SIDE COVER LH ASLY S BLK_MATT BLK	Bajaj spare parts
52JR0330	K17 TANK GLOSSY BRKLYN BLACK+ DECAL+LACQ	Bajaj spare parts



52JR0331	K17 ABS FR FENDER SUB ASSLY BRK BLK_DECA	Bajaj spare parts
52JR0332	K17 FRONT FENDER TOP GLOS BRKLYN BLK_DEC	Bajaj spare parts
52JR0334	K17B FAIRING FRNT LH GLOS BRKLYN BLK+DEC	Bajaj spare parts
52JR0335	K17B FAIRING FRNT RH GLOS BRKLYN BLK_DEC	Bajaj spare parts
52JR0337	K17B SEAT COWL LH GLOSS BRKLYN BLK_DEC	Bajaj spare parts
52JR0338	K17B SEAT COWL RH GLOSS BRKLYN BLK_DEC	Bajaj spare parts
52JR0340	K17 BELLY PAN TOP LH GLOSS BRKYN.BLK+DEC	Bajaj spare parts
52JR0341	K17 BELLY PAN TOP RH GLOSS BRKYN BLK_DEC	Bajaj spare parts
52JR0343	K17B FLAP TANK LH GLOS BRKLN BLK_DEC	Bajaj spare parts
52JR0344	K17B SHROUD LH GLOS BRKLN BLK_DEC	Bajaj spare parts
52JR0346	K17B FLAP TANK RH GLOS BRKLN BLK_DEC	Bajaj spare parts
52JR0347	K17B SHROUD RH GLOS BRKLN BLK_DEC	Bajaj spare parts
52JR0351	K17D SIDE COVER LH ASLY S.BLK+MAT BLK	Bajaj spare parts
52JR0352	K17D SIDE COVER RH ASLY S.BLK+MAT BLK	Bajaj spare parts
52JR0353	K17D TANK GLOSSY BRK BLK+ DEC+LACQ	Bajaj spare parts
52JR0355	K17D FAIRING FRNT LH CH MT BLK_DEC	Bajaj spare parts
52JR0356	K17D FAIRING FRNT RH CH MT BLK_DEC	Bajaj spare parts
52JR0358	K17D SEAT COWL LH GLOSS BRKLYN BLK_DEC	Bajaj spare parts
52JR0359	K17D SEAT COWL RH GLOSS BRKLYN BLK_DEC	Bajaj spare parts
52JR0361	K17D SIDE COVER FRNT RH G BRK BLK+DEC	Bajaj spare parts
52JR0363	K17D SIDE COVER FRNT LH G BRK BLK+DEC	Bajaj spare parts
52JR0389	K17E COWL SEAT LH GLOS CARIBEAN BLUE+DEC	Bajaj spare parts
52JR0390	K17E COWL SEAT RH GLOS CARIBEAN BLUE+DEC	Bajaj spare parts
52JR0392	K17E COWL SEAT LH GLOS SP YELLOW+DEC	Bajaj spare parts
52JR0423	K17 ABS FR FENDER SUB ASSLY B BLK_BLUE D	Bajaj spare parts
52JR0424	K17 FRONT FENDER TOP GLOS BR BLK_BLU DEC	Bajaj spare parts
52JR0426	K17 FAIRING FRNT LH GLOS BRK BLK_BLU DEC	Bajaj spare parts
52JR0427	K17 FAIRING FRNT RH GLOS BRK BLK_BLU DEC	Bajaj spare parts
52JR0429	K17E SEAT COWL LH GLOS BRK BLK_BLUE DEC	Bajaj spare parts
52JR0431	K17 BELLY PAN TOP LH GLOS BRK BLK_BLU DE	Bajaj spare parts
52JR0432	K17 BELLY PAN TOP RH GLOS BRK BLK_BLU DE	Bajaj spare parts
52JR0434	K17 FLAP TANK LH GLOS BRKLYN BLK_BLK DEC	Bajaj spare parts
52JR0435	K17 SHROUD LH GLOSS BRKLN BLK_BLUE DEC	Bajaj spare parts
52JR0437	K17 FLAP TANK RH GLOS BRKLYN BLK_BLK DEC	Bajaj spare parts
52JR0438	K17 SHROUD RH GLOSS BRKLN BLK_BLUE DEC	Bajaj spare parts
52JR0440	K17E SEAT COWL RH GLOS BRK BLK_BLUE DEC	Bajaj spare parts
52JR0445	K17E SEAT COWL LH GLOS BKLYN BLK_RED DE	Bajaj spare parts
52JR0446	K17E SEAT COWL RH GLOS BKLYN BLK_RED DE	Bajaj spare parts
52JR0451	K17E SIDE COVER RH ASLY S BLK_MATT BLK	Bajaj spare parts
52JR0496	K17TANK GLOS Y BRK BLK+ DEC+LACQ JR171170	Bajaj spare parts
52JR0635	K17 P150 SEAT COWL LH RACING RED+DEC	Bajaj spare parts
52JR0636	K17 P150 SEAT COWL RH RACING RED+DEC	Bajaj spare parts
52JR0638	K17 P150 SEAT COWL LH CARIBB BLUE+DEC	Bajaj spare parts
52JR0639	K17 P150 SEAT COWL RH CARIBB BLUE+DEC	Bajaj spare parts
52JR0641	K17 P150 SEAT COWL LH EBONY BLK+DEC	Bajaj spare parts

52JR0642	K17 P150 SEAT COWL RH EBONY BLK+DEC	Bajaj spare parts
52JR0643	K17 P150 ABS FRNT FENDER ASLY RACING RED	Bajaj spare parts
52JR0644	K17 P150 FRNT FENDER TOP RACING RED+DEC	Bajaj spare parts
52JR0645	K17 P150 ABS FRNT FENDER ASSLY CARIB BLU	Bajaj spare parts
52JR0646	K17 P150 FRONT FENDER TOP CARIB BLU+DEC	Bajaj spare parts
52JR0647	K17 P150 ABS FRNT FENDER ASSLY EBONY BLK	Bajaj spare parts
52JR0648	K17 P150 FRONT FENDER TOP EB BLK+DEC	Bajaj spare parts
52JR0654	K17 P150 BELLY PAN LH RECING RED+DEC	Bajaj spare parts
52JR0656	K17 P150 BELLY PAN RH RECING RED+DEC	Bajaj spare parts
52JR0658	K17 P150 BELLY PAN LH CARIB BLU+DEC	Bajaj spare parts
52JR0660	K17 P150 BELLY PAN RH CARIB BLU+DEC	Bajaj spare parts
52JR0662	K17 P150 BELLY PAN LH EBONY BLK+DEC	Bajaj spare parts
52JR0664	K17 P150 BELLY PAN RH EBONY BLK+DEC	Bajaj spare parts
52JR0666	K17 P150 FAIRING LH RACING RED + DEC	Bajaj spare parts
52JR0668	K17 P150 FAIRING RH RACING RED + DEC	Bajaj spare parts
52JR0671	K17 P150 FAIRING LH CARIB BLUE + DEC	Bajaj spare parts
52JR0673	K17 P150 FAIRING RH CARIB BLUE + DEC	Bajaj spare parts
52JR0676	K17 P150 FAIRING LH EB BLACK + DEC	Bajaj spare parts
52JR0678	K17 P150 FAIRING RH EB BLACK + DEC	Bajaj spare parts
52JR0681	K17 P150 TANK SPOILR ASLY LH RUSH RED+DE	Bajaj spare parts
52JR0683	K17 P150 TANK SPOILR ASLY RH RUSH RED+DE	Bajaj spare parts
52JR0685	K17 P150 TANK SPOILER ASLY LH IND BLU+DE	Bajaj spare parts
52JR0687	K17 P150 TANK SPOILER ASLY RH IND BLU+DE	Bajaj spare parts
52JR0689	K17 P150 TANK SPOILR ASLY LH CHAR BLK+DE	Bajaj spare parts
52JR0691	K17 P150 TANK SPOILR ASLY RH CHAR BLK+DE	Bajaj spare parts
52JR0702	K17 P150 TANK ASEMBLY RACING RED + DEC	Bajaj spare parts
52JR0703	K17 P150 TANK ASEMBLY CARIBEN BLU + DEC	Bajaj spare parts
52JR0704	K17 P150 TANK ASEMBLY EBON BLACK + DEC	Bajaj spare parts
52JR0725	K17 P150 BELLY PAN LH EB BLK+WHITE DEC	Bajaj spare parts
52JR0727	K17 P150 BELLY PAN RH EB BLK+WHITE DEC	Bajaj spare parts
52JR0729	K17 P150 BELLY PAN LH EB BLK+MTR BLU DEC	Bajaj spare parts
52JR0731	K17 P150 BELLY PAN RH EB BLK+MTR BLU DEC	Bajaj spare parts
52JR0733	K17P150 TANK SPOILR LH CHAR BLK+WHIT DEC	Bajaj spare parts
52JR0735	K17 P150 TANK SPOILR RH CHAR BLK+WHIT DE	Bajaj spare parts
52JR0737	K17P150 TANK SPOILR LH CHAR BLK+M.BLU DE	Bajaj spare parts
52JR0739	K17P150 TANK SPOILR RH CHA BLK+M.BLU DEC	Bajaj spare parts
52JR0741	K17 P150 SEAT COWL LH EBONY BLK+WHIT DEC	Bajaj spare parts
52JR0742	K17 P150 SEAT COWL RH EBONY BLK+WHIT DEC	Bajaj spare parts
52JR0744	K17P150 SEAT COWL LH EBONY BLK+M.BLU DEC	Bajaj spare parts
52JR0745	K17P150 SEAT COWL RH EBONY BLK+M.BLU DEC	Bajaj spare parts
52JR0747	K17 P150 FAIRING LH EB BLACK +WHIT DEC	Bajaj spare parts
52JR0748	K17 P150 FAIRING RH EB BLACK +WHIT DEC	Bajaj spare parts
52JR0750	K17 P150 FAIRING LH EB BLACK +BLU DEC	Bajaj spare parts
52JR0751	K17 P150 FAIRING RH EB BLACK +BLU DEC	Bajaj spare parts
52JU0018	SWING ARM SUB ASSY COMP	Bajaj spare parts

52JU0155	TANK COVER JU EBONY BLACK WITH DECAL	Bajaj spare parts
52JU0184	FRAME ASSLY (BLACK) WI BRG RACE	Bajaj spare parts
52JU0207	D200 SEAT COWL LH SATIN BLK + DCAL	Bajaj spare parts
52JU0210	D200 SEAT COWL RH ASSLY + DCAL	Bajaj spare parts
52JU0213	D200 SIDE MASK LH EBONY BLK + DCAL	Bajaj spare parts
52JU0214	D200 SIDE MASK RH EBONY BLK + DCAL	Bajaj spare parts
52JU0217	TANK COVER TOP+DECALS - ELEC ORANGE	Bajaj spare parts
52JU0219	D200 TANK COVER EBONY BLK + DCAL	Bajaj spare parts
52JU0432	FUEL TANK EVAP WITH BKT DUKE 200 DOM SPD	Bajaj spare parts
52JU0459	FUEL TANK WITH BKT DUKE 200 DOM MY16 SPD	Bajaj spare parts
52JU0488	FRONT FENDER DOMESTIC FOR SPD	Bajaj spare parts
52JU0653	KT18 SIDE COVER LH DARK GALVANO MATT+DEC	Bajaj spare parts
52JU0654	KT18 SIDE COVER RH DARK GALVANO MATT+DEC	Bajaj spare parts
52JU0655	KT18 SEAT COWL LH SILVER META GLOSSY+DEC	Bajaj spare parts
52JU0656	KT18 SEAT COWL RH SILVER META GLOSSY+DEC	Bajaj spare parts
52JU0657	KT18 FRONT FENDER DARK GALVAN MATT+EMBLM	Bajaj spare parts
52JU0660	KT17 SEAT COWL LH DARK GALVANO MATT+DEC	Bajaj spare parts
52JU0661	KT17 SEAT COWL RH DARK GALVANO MATT+DEC	Bajaj spare parts
52JU0662	KT17 FRONT FENDER DARK GALVAN MATT+EMBLM	Bajaj spare parts
52JU0723	SWING ARM SUB ASSY COMP HUSKVERNA 390	Bajaj spare parts
52JU0727	KT16 SEAT COWL LH SILVER META GLOSSY+DEC	Bajaj spare parts
52JU0728	KT16 SEAT COWL RH SILVER META GLOSSY+DEC	Bajaj spare parts
52JU0740	KT18 SIDE COVER LH DARK GALVANO MATT+DEC	Bajaj spare parts
52JU0741	KT18 SIDE COVER RH DARK GALVANO MATT+DEC	Bajaj spare parts
52JU0744	KT31 SIDE COVER LH ADVE SILVER SATIN + D	Bajaj spare parts
52JU0745	KT31 SIDE COVER RH ADVE SILVER SATIN+DEC	Bajaj spare parts
52JU0746	SEAT COWL LH SVARTPILEN 200	Bajaj spare parts
52JU0747	SEAT COWL RH SVARTPILEN 200	Bajaj spare parts
52JU0763	KT31 SEAT COWL RH DARK GALVANO MATT+DEC	Bajaj spare parts
52JU0765	KT31 SEAT COWL LH DARK GALVANO MATT+DEC	Bajaj spare parts
52JU0773	JU111012 HUSQ FRAME FR WITH BLK POW COAT	Bajaj spare parts
52JU0782	SIDE COVER LH DARK GALVANO MATT+DEC WIT	Bajaj spare parts
52JU0783	SIDE COVER RH DARK GALVANO MATT+DEC WITH	Bajaj spare parts
52JU0803	VITPILEN PT TOP COVER SUB ASSEMBLY	Bajaj spare parts
52JU1059	SVRT 125MY21 SIDE CVR RH DRK GAL MTKC+DE	Bajaj spare parts
52JU1060	SVRT125MY21 SIDE CVR RH DRKGALMT KC+3D D	Bajaj spare parts
52JU1061	SVRT 125MY21 SIDE CVR LH DRK GAL MTKC+DE	Bajaj spare parts
52JU1062	SVRT 125MY21 SIDE CVRLH DRKGALMTKC+3D DE	Bajaj spare parts
52JU1067	SVART 125 MY 21 HUSQ PT TOP COVER SUB AS	Bajaj spare parts
52JU1082	HUSQ VIT SEAT COWL LH-DARK GALMATT+DE KC	Bajaj spare parts
52JU1083	HUSQ VIT SEAT COWL RH-DARK GALMATT+DE KC	Bajaj spare parts
52JU1091	KT17 FRONT FENDER DRK GALVAN MATT+EMB KC	Bajaj spare parts
52JU1162	SVART 125 MY 22 HUSQ PT TOP COVER SUBASS	Bajaj spare parts
52JU1174	SVART 125 MY22 PT SIDE COVER ASLY LH	Bajaj spare parts
52JU1178	SVART 125 MY 22 PT SIDE COVER ASLY RH	Bajaj spare parts

52JU1208	SVT 250.MY22 S.CVR LH BLK- BLU_MS + LQR	Bajaj spare parts
52JU1209	SVT 250.MY22 S.CVR RH BLK- BLU_MS + LQR	Bajaj spare parts
52JU1283	FRONT FENDER JU181431 BLK MN SHINE+ DCL	Bajaj spare parts
52JU1289	VIT250 SIDE CVR LH CER WHITE MAT+LQR+DCL	Bajaj spare parts
52JU1291	VIT250 SIDE CVR RH CER WHITE MAT+LQR+DCL	Bajaj spare parts
52JU1292	HUSQ VIT FRONT FENDER CER WHITE MAT+DCAL	Bajaj spare parts
52JV0117	SD CVR LH EL.BLUE WITH DECAL BM125	Bajaj spare parts
52JV0118	SD CVR LH EB.BLACK WITH DECAL BM125	Bajaj spare parts
52JV0120	SD CVR RH EL.BLUE WITH DECAL BM125	Bajaj spare parts
52JV0122	SD CVR RH PASN RED WITH DECAL BM125	Bajaj spare parts
52JV0143	SILVER COVER MAGNETO ASSLY BM125X	Bajaj spare parts
52JV0229	SD CVR LH EB.BLACK WITH DECAL BM125X	Bajaj spare parts
52JV0231	SD CVR RH EL.BLUE WITH DECAL BM125X	Bajaj spare parts
52JV0232	SD CVR RH EB.BLACK WITH DECAL BM125X	Bajaj spare parts
52JY0031	COVER TANK ASLY COMP-KTM390	Bajaj spare parts
52JY0175	JY HAND GUARD MASKING	Bajaj spare parts
52JY0180	JY HAND GUARD MASKING RH	Bajaj spare parts
52JY0185	BOLT FLANGE PRECOATED M10X1.25	Bajaj spare parts
52JY0527	TANK COVER JY EBONY BLACK WITH DECAL	Bajaj spare parts
52JY0547	LOCK SET 3 IN 1 WITH EVAP E10 MY16	Bajaj spare parts
52JY0629	SUB ASSLY FRONT FENDER RC	Bajaj spare parts
52JY0631	SUB ASSLY LOWER FAI KT06 CHINA	Bajaj spare parts
52JY0666	TANK ASSLY COMP ASIA RC 200 DOM EVAP MY	Bajaj spare parts
52JY0667	BKT C SAMPLE TOP SUB ASSLY	Bajaj spare parts
52JY0721	OUTER FAIRING LH DCAL	Bajaj spare parts
52JY0722	OUTER FAIRING RH DCAL	Bajaj spare parts
52JY0723	RC390 MY17 INNER FAIRING LH DCAL	Bajaj spare parts
52JY0724	INNER FAIRING RH DCAL	Bajaj spare parts
52JY0725	RC390 MY17 TANK COVER TOP DCAL	Bajaj spare parts
52JY0726	RC390 MY17 UNDER TRAY BOTTOM DCAL	Bajaj spare parts
52JY0727	RC390 MY17 BELLY PAN DCAL	Bajaj spare parts
52JY0731	ASSLY MY17 FR FENDER	Bajaj spare parts
52JY0746	RC200 OUTER FAI LH+DEC	Bajaj spare parts
52JY0747	RC200 DOM MY17 OUTER FAI RH DCAL	Bajaj spare parts
52JY0748	RC200 DOM MY17 INNER FAI LH DCAL	Bajaj spare parts
52JY0749	RC200 DOM MY17 INNER FAI RH DCAL	Bajaj spare parts
52JY0750	RC200 DOM MY17 TANK COVER TOP DCAL	Bajaj spare parts
52JY0751	RC200 DOM MY17 UNDER TRAY BOTTOM DCAL	Bajaj spare parts
52JY0752	RC200 DOM MY17 BELLY PAN RH DCAL	Bajaj spare parts
52JY0755	BELLY PAN LH WITH DECAL	Bajaj spare parts
52JY0797	Jasly Frame RC200	Bajaj spare parts
52JY0798	MUFFLER WITH HEAT SHIELD ASSEMBLY MY 17	Bajaj spare parts
52JY0822	CLUTCH CABLE RC250	Bajaj spare parts
52JY0823	CLUTCH CABLE KT06 KT22 MY17	Bajaj spare parts
52JY0835	ASLY FRM RC250 MY17+BRG RACE SPD BLK	Bajaj spare parts

52JY0943	JY111161_MY18 FRAME ASSY WITH EB ORANGE	Bajaj spare parts
52JY0955	BALANCER SHAFT (JY531221) WITH DOME NUT	Bajaj spare parts
52JY0983	FRAME ASSLY OF RC 390 MY 18 INHOUSE	Bajaj spare parts
52JY1387	RC 200 DOM MY18 RC TANK COVER TOP IN EBO	Bajaj spare parts
52JY1388	RC 200 DOM MY18 RC FAIRING INNER LH IN	Bajaj spare parts
52JY1389	RC 200 DOM MY18 RC FAIRING INNER RH IN K	Bajaj spare parts
52JY1390	RC 200 DOM MY18 FAIRING OUTER LH IN EBON	Bajaj spare parts
52JY1391	RC 200 DOM MY18 FAIRING OUTER RH IN EBON	Bajaj spare parts
52JY1392	RC 200 DOM MY18 RC BELLY PAN LH IN EBONY	Bajaj spare parts
52JY1393	RC 200 DOM MY18 RC BELLY PAN RH IN EBONY	Bajaj spare parts
52JY1595	FAME ASSLY OF RC390 MY18 INHOUSE BLACK	Bajaj spare parts
52JY1905	RC OUTER FAIRING RH JY181223 BLACK+DECAL	Bajaj spare parts
52JY1906	RC OUT FAIRING RHJY181223 EBORANGE+DECAL	Bajaj spare parts
52JY1907	RC OUT FAIRING LHJY181222 EB BLACK+DECAL	Bajaj spare parts
52JY1908	RC OUT FAIRING LHJY181222 EB ORANGE+DECA	Bajaj spare parts
52JY1909	RC TANK COVER TOP WHITE 56JY225S+ DECAL	Bajaj spare parts
52JY1910	RC TANK COVER TOP ORANGE 56JY221T+ DECAL	Bajaj spare parts
52JY1911	RC INNER FAIRING RH EB BLACK+WHITE DECAL	Bajaj spare parts
52JY1912	RC INNER FAIRING RH EB BLACK+ORANGE DECA	Bajaj spare parts
52JY1913	RC INNER FAIRING LH EB BLACK+WHITE DECA	Bajaj spare parts
52JY1914	RC INNER FAIRING LH EB BLACK+ORANGE DECA	Bajaj spare parts
52JY1915	RC 125 BELLY RH IN WHITE + BLACK DECAL	Bajaj spare parts
52JY1916	RC 125 BELLY LH IN WHITE + BLACK DECAL	Bajaj spare parts
52JY1917	RC 125 BELLY LH IN BLACK + ORANGE DECAL	Bajaj spare parts
52JY1918	RC 125 BELLY RH IN BLACK + ORANGE DECAL	Bajaj spare parts
52JY1921	RC OUT LH FAIRING ASSLY EB BLACK+DECAL	Bajaj spare parts
52JY1922	RC OUT LH FAIRING ASSLY EB ORANGE+DECAL	Bajaj spare parts
52JY1923	ASSLY RC 125 SIDE FAIRING RH EB ORANGE	Bajaj spare parts
52JY1924	ASSLY RC 125 SIDE FAIRING RH WH BLACK	Bajaj spare parts
52JY1927	UNDER TRAY ASSLY RC 125 ORG+DCL	Bajaj spare parts
52JY1928	UNDER TRAY ASSLY RC 125 WHITE+DCL	Bajaj spare parts
52JY1940	JY111232_RC FRM ASSY_BLACK POWDR COTNG	Bajaj spare parts
52JY1981	RC TANK COVER DARK GALVANO MATT+DECAL	Bajaj spare parts
52JY1982	RC 200 FRONT FENDER EBONY BLACK+DECAL	Bajaj spare parts
52JY1983	RC 200 INNER FAIRING LH EBONY BLACK+DEC	Bajaj spare parts
52JY1984	RC 200 INNER FAIRING RH EBONY BLACK+DEC	Bajaj spare parts
52JY1985	RC 200 OUTER FAIRING LH EBONY BLACK+DEC	Bajaj spare parts
52JY1986	RC 200 OUTER FAIRING RH EBONY BLACK+DEC	Bajaj spare parts
52JY1989	RC 200 UNDER TRAY BOTT EB.ORANGE+DECAL	Bajaj spare parts
52JY1995	RC390 FRONT FENDER DARK GAL MATT+DECAL	Bajaj spare parts
52JY1996	RC 390 TANK COVER DARK GAL MATT+DECAL	Bajaj spare parts
52JY1997	RC INNER FAIRING LH DARK GAL MATT+DECAL	Bajaj spare parts
52JY1998	RC INNER FAIRING RH DARK GAL MATT+DECAL	Bajaj spare parts
52JY2002	RC390 UNDER TRAY BOTTM CERAMIC WHITE+DEC	Bajaj spare parts
52JY2016	RC390 MY 20 BELLY PAN+DECAL	Bajaj spare parts

52JY2215	RC OUTER FAIRING RH CERAMIC WHITE+DECAL	Bajaj spare parts
52JY2216	RC OUTER FAIRING LH CERAMIC WHITE+DECAL	Bajaj spare parts
52JY2217	RC INNER FAIRING RH CERAMIC WHITE+DECAL	Bajaj spare parts
52JY2218	RC INNER FAIRING LH CERAMIC WHITE+DECAL	Bajaj spare parts
52JY2219	RC FRONT FENDER CERAMIC WHITE+DECAL	Bajaj spare parts
52JY2220	RC TANK COVER TOP EB ORANGE+DECAL	Bajaj spare parts
52JY2221	RC UNDER TRAY BOTTOM CERAMIC WHITE+DECAL	Bajaj spare parts
52JY2222	ASSLY RC 125 SIDE FAIRING LH CERAM WHITE	Bajaj spare parts
52JY2223	ASSLY RC 125 SIDE FAIRING RH CERAM WHITE	Bajaj spare parts
52JY2224	ASSLY RC125 TANK COVER TOP E ORANGE MY20	Bajaj spare parts
52JY2227	RC FR FENDER ASSLY CERMIC WHITE DOM MY20	Bajaj spare parts
52JY2230	RC390 BS6 OUTER FAIRING LH CERAM WHITE+D	Bajaj spare parts
52JY2231	RC390 BS6 OUTER FAIRING RH CERAM WHITE+D	Bajaj spare parts
52JY2393	TANK COVER JY171002 EC ORANGE MATT+DECAL	Bajaj spare parts
52JY2394	FRONT FENDER JY181401 E ORANGE MATT+DECA	Bajaj spare parts
52JY2395	INNER FAIRING LH JY181220 E.ORG MATT+DEC	Bajaj spare parts
52JY2396	INNER FAIRING RH JY181221 E.ORG MATT+DEC	Bajaj spare parts
52JY2397	RC UNDER TRAY BOTTOMJY181211 C WHITE+DEC	Bajaj spare parts
52JY2398	RC FAIRING OUTER LH EBONY BLACK+DECAL	Bajaj spare parts
52JY2399	RC FAIRING OUTER RH EBONY BLACK+DECAL	Bajaj spare parts
52JY2400	UNDER TRAY BOTTOM JY181211 E ORG MAT+DEC	Bajaj spare parts
52JY2401	TANK COVER TOP JY171002 SL MET MATT+DECL	Bajaj spare parts
52JY2402	RC FRONT FENDER EBONY BLACK+DECAL	Bajaj spare parts
52JY2403	OUTER FAIRING LH JY181222 S MET MAT+DECL	Bajaj spare parts
52JY2404	OUTER FAIRING RH JY181223 S MET MATT+DECL	Bajaj spare parts
52JY2405	RC INNER FAIRING LH JY181220 C WHITE+DEC	Bajaj spare parts
52JY2406	RC INNER FAIRING RH JY181221 C WHITE+DEC	Bajaj spare parts
52JY2407	TANK COVER TOP JY171002 CER WHITE+DECAL	Bajaj spare parts
52JY2408	RC FRONT FENDER JY181401 CER WHITE+DECAL	Bajaj spare parts
52JY2409	RC FAIRING INNER LH EBONY BLACK+DECAL	Bajaj spare parts
52JY2410	RC FAIRING INRH	Bajaj spare parts
52JY2411	OUTER FAIRING LH JY181222 BLACK MATT+DEC	Bajaj spare parts
52JY2412	OUTER FAIRING RH JY181223 BLACK MATT+DEC	Bajaj spare parts
52JY2506	AIR FILTER SUB ASSLY RC 200 MY21	Bajaj spare parts
52JY2524	RC MY21 FRAME REAR JY111164 EB ORG GLOSS	Bajaj spare parts
52JY2525	RC MY21 FRAME REAR JY111164 BLACK GLOSS	Bajaj spare parts
52JY2538	RC 390 GEN 2 INR SIDE FAIRING BLUE LH+DL	Bajaj spare parts
52JY2539	RC 390 GEN 2 INR SIDE FAIRING BLUE RH+DL	Bajaj spare parts
52JY2540	RC 390 GEN 2 OUT SIDE FAIRING BLUE RH+DL	Bajaj spare parts
52JY2541	RC 390 GEN 2 OUT SIDE FAIRING BLUE LH+DL	Bajaj spare parts
52JY2542	RC 390 GEN 2 COVER TANK BLUE + DCL	Bajaj spare parts
52JY2543	RC 390 GEN 2 SEAT COWL LH BLUE + DCL	Bajaj spare parts
52JY2544	RC 390 GEN 2 SEAT COWL RH BLUE + DCL	Bajaj spare parts
52JY2545	RC 390 GEN 2 INR SIDE FAIRING BLK LH+DCL	Bajaj spare parts
52JY2546	RC 390 GEN 2 INR SIDE FAIRING BLK RH + D	Bajaj spare parts

52JY2547	RC 390 GEN 2 OUT SIDE FAIRING BLK LH+DL	Bajaj spare parts
52JY2548	RC 390 GEN 2 OUT SIDE FAIRING BLK RH+DL	Bajaj spare parts
52JY2549	RC 390 GEN 2 COVER TANK ORG MAT + DCL	Bajaj spare parts
52JY2550	RC 390 GEN 2 SEAT COWL LH BLK + DCL	Bajaj spare parts
52JY2551	RC 390 GEN 2 SEAT COWL RH BLK + DCL	Bajaj spare parts
52JY2554	RC 200 GEN 2 INN FRNG LH SILVR GLOS+DL	Bajaj spare parts
52JY2555	RC 200 GEN 2 INN FRNG RH SILVR GLOS+DL	Bajaj spare parts
52JY2556	RC 200 GEN 2 OUT FAIRG LH ORG + DCL	Bajaj spare parts
52JY2557	RC 200 GEN 2 OUT FAIRG RH ORG + DCL	Bajaj spare parts
52JY2558	RC 200 GEN 2 COVER TANK SILV + DCL	Bajaj spare parts
52JY2559	RC 200 GEN 2 SEAT COWL BOTM LH SILV + DC	Bajaj spare parts
52JY2560	RC 200 GEN 2 SEAT COWL BOTM RH SILV + DC	Bajaj spare parts
52JY2561	RC 125 GEN 2 SIDE FRG OTR RH ORG MAT+DCL	Bajaj spare parts
52JY2562	RC 125 GEN 2 SIDE FRG OTR LH ORG MAT+DCL	Bajaj spare parts
52JY2563	RC 125 GEN 2 SIDE FRG OTR RH EB BLK+DCL	Bajaj spare parts
52JY2564	RC 125 GEN 2 SIDE FRG OTR LH EB BLK+DCL	Bajaj spare parts
52JY2566	RC125 GEN 2 S FRG INR RH BLK MET GLS+DCL	Bajaj spare parts
52JY2567	RC125 GEN 2 S FRG INR LH BLK MET GLS+DCL	Bajaj spare parts
52JY2568	RC 125 GEN 2 PT COVER BLK MET GLS+DCL	Bajaj spare parts
52JY2569	RC 200 GEN 2 INN FAIRING LH BLK GLOS+DCL	Bajaj spare parts
52JY2570	RC 125 GEN 2 SIDE FRG INR RH CER WHT+DCL	Bajaj spare parts
52JY2571	RC 200 GEN 2 INN FAIRING RH BLK GLOS+DCL	Bajaj spare parts
52JY2572	RC125 GEN 2 SIDE FRG INR LH CER WHT+DCL	Bajaj spare parts
52JY2573	RC 200 GEN 2 OUT FAIRG LH ORG GLOSS + DC	Bajaj spare parts
52JY2574	RC125 GEN 2 PT COVER CER WHITE+DCL	Bajaj spare parts
52JY2575	RC 200 GEN 2 OUT FAIRG RH ORG GLOS + DCL	Bajaj spare parts
52JY2577	RC 200 GEN 2 COVER TANK BLK + DCL	Bajaj spare parts
52JY2578	RC 200 GEN 2 SEAT COWL BOTM LH EB BLK+DL	Bajaj spare parts
52JY2579	RC 200 GEN 2 SEAT COWL BOTM RH EB BLK+DL	Bajaj spare parts
52JY2580	RC125 GEN 2 SEAT COWL LH BTM WHT GLS+DCL	Bajaj spare parts
52JY2581	RC125 GEN 2 SEAT COWL RH BTM WHT GLS+DCL	Bajaj spare parts
52JY2582	RC125 GEN 2 SEAT COWL LH BTM EB BLK +DCL	Bajaj spare parts
52JY2583	RC125 GEN 2 SEAT COWL RH BTM EB BLK +DCL	Bajaj spare parts
52JY2622	RC390 MY21PETROL TANK EB ORANGE+DECAL	Bajaj spare parts
52JY2623	RC200+RC125 MY21 PETROL TANK EB ORNG+DEC	Bajaj spare parts
52JY2624	RC125 MY21 PETROL TANK ASLY MAT BLK+DCAL	Bajaj spare parts
52JY2659	LOCK 3 IN 1 WITHOUT CAP EVP RC390MY21	Bajaj spare parts
52JY2943	RC390 INR SIDE FAIRING EB ORG MAT LH+DCL	Bajaj spare parts
52JY2944	RC390 INR SIDE FAIRING EB ORG MAT RH+DCL	Bajaj spare parts
52JY2945	RC390 OUTER FAIRING EB ORG GLOSS RH+DCL	Bajaj spare parts
52JY2946	RC390 OUTER FAIRING EB ORG GLOSS LH+DCL	Bajaj spare parts
52JY2947	RC 390 COVER TANK EB ORANGE MAT + DCL	Bajaj spare parts
52JY2952	FENDER FRONT JY181419 EB ORG MAT+ DCL	Bajaj spare parts
52JY2961	RC 200 INR FAIRING EB ORG MAT RH + DCL	Bajaj spare parts
52JY2963	RC200 SEAT COWL BTM JY181352 BLK MAT+DCL	Bajaj spare parts

52JY2964	SEAT COWL BTM JY181351LH BLK MATT+DCL	Bajaj spare parts
52JY2965	RC 200 COVER TANK EB ORG MATT + DCL	Bajaj spare parts
52JY2966	RC200 OUTER FAIRING EB ORG GLOSS LH +DCL	Bajaj spare parts
52JY2967	RC 200 OUTER FAIRING EB ORG GLOSS RH+DCL	Bajaj spare parts
52JY2971	RC 200 FRONT FENDER ASSLY ORG MAT + DCL	Bajaj spare parts
52JY2972	RC200 INR SIDE FAIRING EB ORG MAT LH+DCL	Bajaj spare parts
52JY2988	GPRC200/390 FUEL TANKJY171174 EB ORG+DCL	Bajaj spare parts
52JZ0018	COWLING E BLK/RED DECAL	Bajaj spare parts
52JZ0023	COWLING BLK/BLUE DECAL	Bajaj spare parts
52JZ0050	PANEL SIDE RH BL+BLUE DIS	Bajaj spare parts
52JZ0051	PANEL SIDE LH BL+BLUE DIS	Bajaj spare parts
52JZ0054	COWLING BLACK BLUE	Bajaj spare parts
52JZ0100	COWLING BLCK GOLD MCM	Bajaj spare parts
52JZ0118	COWLING (JZ740153) ASLY	Bajaj spare parts
52JZ0264	LEVER COMP GEAR SHIFT-SPR	Bajaj spare parts
52JZ0599	COWLING WINE RED WITH RED DECAL	Bajaj spare parts
52JZ0624	FUEL TANK E. BLACK WITH RED DEC	Bajaj spare parts
52JZ0628	GRAB HANDLE	Bajaj spare parts
52JZ0673	COWL SEAT E.BLACK WITH GOLD DECAL	Bajaj spare parts
52JZ0674	FAIRING E.BLACK WITH GOLD DECAL	Bajaj spare parts
52JZ0700	TANK FUEL E.BLACK WITH GOLD DECALTANK FU	Bajaj spare parts
52JZ0922	F.TANK ASSLY EB.BLACK WH BLUE DEC	Bajaj spare parts
52JZ0923	F.TANK ASSLY EB.BLACK WH RED DEC	Bajaj spare parts
52JZ0924	F.TANK ASSLY EL.BLUE WH BLUE DEC	Bajaj spare parts
52JZ0925	F.TANK ASSLY FL.RED WH RED DEC	Bajaj spare parts
52JZ0926	COWL BLK WH BLUE DEC	Bajaj spare parts
52JZ0927	COWL BLK WH RED DEC	Bajaj spare parts
52JZ0928	COWL EL.BLUE WH BLUE	Bajaj spare parts
52JZ0938	ST.CWL ASSLY EB.BLACK WH BLUE DEC	Bajaj spare parts
52JZ0939	ST.CWL ASSLY EB.BLACK WH RED DEC	Bajaj spare parts
52JZ0940	ST.CWL ASSLY EL.BLUE WH BLUE DEC	Bajaj spare parts
52JZ0960	CHAIN CASE ASSLY UPPER LOWER	Bajaj spare parts
52JZ1516	TANK ASLY EB.BLACK WH BLUE DCL	Bajaj spare parts
52JZ1517	TANK ASLY EB. BLACK WH RED DCL	Bajaj spare parts
52JZ1518	TANK ASLY EL. BLUE WH BLUE DCL	Bajaj spare parts
52JZ1519	TANK ASLY FL. RED WH RED DCL	Bajaj spare parts
52JZ1762	ASSLY MANIFOLD INTAKE DISCOVER 125UG	Bajaj spare parts
52JZ1775	SIDE COVER RH WH EB.BLCK DECAL(D-125 UG	Bajaj spare parts
52JZ1798	SEAT COWL EBONY BLCK WITH DECAL	Bajaj spare parts
52JZ1799	SEAT COWL FLAME RED WITH DECAL(D-125 UG	Bajaj spare parts
52JZ1804	COWLING EBONY BLACK WITH DECAL (D-125 UG	Bajaj spare parts
52JZ1805	COWLING FLAME RED WITH DECAL (D-125 UG)	Bajaj spare parts
52JZ1811	SIDE COVER LH WH EB.BLCK DECAL(D-125 UG	Bajaj spare parts
52JZ1816	TANK EBONY BLACK WITH DECAL (D-125 UG)	Bajaj spare parts
52JZ1817	TANK FLAME RED WITH DECAL (D-125 UG)	Bajaj spare parts



52JZ1823	SEAT COWL EBONY BLACK WH DECAL (D-110 UG	Bajaj spare parts
52JZ1841	COVER MAGNETO ASSEMBLY - GRIC GRAY D125U	Bajaj spare parts
52JZ1844	TANK SAFFIRE BLUE WITH DECAL(D-125 UG)	Bajaj spare parts
52JZ1845	TANK ASLY SAFFIRE BLUE WH DECAL(D-125 UG	Bajaj spare parts
52JZ1850	COWLING SAFFIRE BLUE WITH DECAL (D125 UG	Bajaj spare parts
52JZ1852	SEAT COWL SAFFIRE BLU WH DECAL (D125 UG	Bajaj spare parts
52JZ1854	SEAT COWL SAFFIRE BLU WH DECAL (D110 UG	Bajaj spare parts
52JZ2042	SEAT COWL EBON BLK WH GRY DCAL D 125 UG	Bajaj spare parts
52JZ2044	COWLING EBONY BLCK WH GRY DECAL D 125 UG	Bajaj spare parts
52JZ2322	CHAIN CASE ASSLY UPPER & LOWER D-125UG	Bajaj spare parts
52JZ2831	COWLING EB BLK W GRN DKL D110/125UG	Bajaj spare parts
52JZ2832	COWLING EB BLK W BLU DKL D110/125UG	Bajaj spare parts
52JZ2833	COWLING FL RED W DKL D110/125UG	Bajaj spare parts
52JZ2842	SEAT COWL EB BLK-RED DKL D125UG	Bajaj spare parts
52JZ2843	SEAT COWL EB BLK-GRN DKL D125UG	Bajaj spare parts
52JZ2845	SEAT COWL FL RED W DKL D125UG	Bajaj spare parts
52JZ2854	SIDE COVER LH EB BLK-RED DKL D110/125UG	Bajaj spare parts
52JZ2855	SIDE COVER LH EB BLK-GRN DKL D110/125UG	Bajaj spare parts
52JZ2856	SIDE COVER LH EB BLK-BLU DKL D110/125UG	Bajaj spare parts
52JZ2857	SIDE COVER LH FL RED W DKL D110/125UG	Bajaj spare parts
52JZ2859	SIDE COVER RH EB BLK-GRN DKL D110/125UG	Bajaj spare parts
52JZ2860	SIDE COVER RH EB BLK-BLU DKL D110/125UG	Bajaj spare parts
52JZ2861	SIDE COVER RH FL RED W DKL D110/125UG	Bajaj spare parts
52JZ2965	FF CYL. HEAD JZ511122 BLACK	Bajaj spare parts
52JZ8001	TANK FUEL D 102 AFTER PT	Bajaj spare parts
52PA0015	COWLING E BLK/BLUE DECAL	Bajaj spare parts
52PA0016	COWLING E BLK/MAGN DECAL	Bajaj spare parts
52PA0017	COWLING F RED/RED DECAL	Bajaj spare parts
52PA0020	COVER SIDE LH BLKBL	Bajaj spare parts
52PA0021	PANEL SIDE RH	Bajaj spare parts
52PA0023	PANEL SIDE RH BLCK RED	Bajaj spare parts
52PA0026	COVER SIDE LH RED	Bajaj spare parts
52PA0027	COVER SIDE RH FLAME RED D	Bajaj spare parts
52PA0052	PANEL SIDE RH BLCK/GREEN	Bajaj spare parts
52PA0054	CHAIN CASE UPPER +	Bajaj spare parts
52PA0137	PANEL SIDE LH RED MAGENTA	Bajaj spare parts
52PA0138	PANEL SIDE RH RED MAGENTA	Bajaj spare parts
52PA0140	COWLING RED MAGENTA	Bajaj spare parts
52PA0145	COWLING GOLD MAGENTA	Bajaj spare parts
52PA0518	SIDE COVER RH EL. BLUE WH DECAL	Bajaj spare parts
52PA0523	COWLING WINE RED WH DECAL	Bajaj spare parts
52PA0554	COWL PLATINUM ICE BLU/BLK	Bajaj spare parts
52PA0555	COWL.SILVER WH GOLD	Bajaj spare parts
52PA0561	SEAT COWL PLATINUM SILVER WH GOLD DECAL	Bajaj spare parts
52PA0568	SIDE COVER RH BLUE DECAL	Bajaj spare parts

52PA0701	SEAT COWL S/A EB. BLK WH RED DECAL D125M	Bajaj spare parts
52PA1177	CHAIN CASE ASSLY UPPER & LOWER D-110UG	Bajaj spare parts
52PD0012	COVER RH PD SILVER	Bajaj spare parts
52PD0013	COVER LH SIL PULSAR	Bajaj spare parts
52PD0065	PD WINE RED FRONT FENDER ASSLY	Bajaj spare parts
52PD0066	PD PLASMA BLUE FRONT FENDER ASSLY	Bajaj spare parts
52PD0067	PD MN BLACK FRONT FENDER ASSLY	Bajaj spare parts
52PD0081	AVENGER TANK COVER ASSLY WITH LED	Bajaj spare parts
52PD0087	TANK COVER ASSLY PD A101	Bajaj spare parts
52PD0088	FRONT FENDER ASSLY EBONY BLACK A101	Bajaj spare parts
52PD0090	COVER LH RR SUB ASSLY FOR A101	Bajaj spare parts
52PD0106	GRAB REAR ASSLY COMPLETE PD A101	Bajaj spare parts
52PD0109	COVER LH MATT BLK	Bajaj spare parts
52PD0114	GRAB REAR ASSLY COMPLETE	Bajaj spare parts
52PD0117	TANK COVER ASSLY PD A102	Bajaj spare parts
52PD0135	ASSLY MAGNETO COVER	Bajaj spare parts
52PD0140	BLK SIDE COVER LH DEC	Bajaj spare parts
52PD0141	BLACK SIDE COVER RH	Bajaj spare parts
52PD0144	FUEL TANK BLACK/3D DECAL A101-E	Bajaj spare parts
52PD0150	FRONT RIM WITH DECAL A102	Bajaj spare parts
52PD0151	REAR RIM WITH DECAL A102	Bajaj spare parts
52PD0156	ACK REAR FENDER WITH DECAL	Bajaj spare parts
52PD0158	HANDLE HOLDER WITH DECAL	Bajaj spare parts
52PD0160	FUEL TANK 3D DEC MATTE BLACK	Bajaj spare parts
52PD0161	BLACK METALLIC SIDE COVER	Bajaj spare parts
52PD0162	BLACK METALLIC SIDE COVER	Bajaj spare parts
52PD0166	FRONT FENDER EBONY BLACK	Bajaj spare parts
52PD0211	WINDSHIELD & DAMPER ASSLY PD	Bajaj spare parts
52PD0242	SIDE STAND ASSLY WITH DAMPER A102A WVTA	Bajaj spare parts
52PD0272	FUEL TANK GOLDEN BEIGE WITH 3D DCL A101	Bajaj spare parts
52PD0273	SIDE COVER LH GOLDEN BEIGE WITH DCL A101	Bajaj spare parts
52PD0286	SEAT ASSLY COMP GOLDEN BEIGE PD A101	Bajaj spare parts
52PD0329	SIDE COVER LH MATT OLIVE GREEN ASSLY COM	Bajaj spare parts
52PD0330	SIDE COVER RH MATT OLIVE GREEN ASSLY COM	Bajaj spare parts
52PD0376	GOLDEN BEIGE FUEL TANK BS IV + 3D A101	Bajaj spare parts
52PD0377	FUEL TANK BS IV/3D DECAL A101 - EB	Bajaj spare parts
52PD0378	PD FUEL TANK MATT OLIVE GREEN WITH 3D	Bajaj spare parts
52PD0379	PD FUEL TANK VIBRANT RED WITH 3D DECAL	Bajaj spare parts
52PD0382	PD FUEL TANK BS IV MATT OLIVE GREEN	Bajaj spare parts
52PD0387	PD FUEL TANK VIBRANT RED WITH 3D DECAL	Bajaj spare parts
52PD0562	WINDSHIELD WITH DAMPER CRUISE-UG	Bajaj spare parts
52PD0588	ASSLY SIDE COVER LH BLK MATT METTALIC	Bajaj spare parts
52PD0589	ASSLY SIDE COVER RH BLK MATT METTALIC	Bajaj spare parts
52PD0599	SIDE CVR LH PD MATE CLASIC WHITE + DECAL	Bajaj spare parts
52PD0600	SIDE CVR RH PD MATE CLASIC WHITE + DECAL	Bajaj spare parts

52PD0603	SIDE COVER LH PD CLASIC WHITE (W3)	Bajaj spare parts
52PD0604	SIDE COVER RH PD CLASIC WHITE (W3)	Bajaj spare parts
52PD0606	SIDE CVR LH PD TROPICAL NIGHT + DECAL	Bajaj spare parts
52PD0607	SIDE CVR RH PD TROPICAL NIGHT + DECAL	Bajaj spare parts
52PD0674	PD UG FUEL TNK TRPCL NIT+3D DCAL CRU 220	Bajaj spare parts
52PD0675	PD UG FUEL TNK CLSC WHIT+3D DCAL CRU 220	Bajaj spare parts
52PD0677	PD UG FUEL TNK CLSC WHITE+3D DCAL STR 220	Bajaj spare parts
52PD0678	PD UG FUEL TNK KHI EB BL+3D DCAL STR 180	Bajaj spare parts
52PD0679	PD UG FUEL TNK SPICY RED+3D DCAL STR 180	Bajaj spare parts
52PD0826	PD 220 FUEL TANK ASSLY BSIII WIN RED SPD	Bajaj spare parts
52PD0828	PD 220 FUEL TANK ASLY BSIII PLSM BLU SPD	Bajaj spare parts
52PD0830	PD 220 CRU FUEL TANK ASLY BS3 EB BLK SPD	Bajaj spare parts
52PD0832	PD 220 FUEL TANK ASLY BS3 MATT BLK SPD	Bajaj spare parts
52PD0834	PD 220 CR FUEL TANK ASLY BS3 GOLD BG SPD	Bajaj spare parts
52PD0970	PD160 S.COVER LH PD181217 SPICY RED+DEC	Bajaj spare parts
52PD0971	PD160 S.COVER RH PD181218 SPICY RED+DEC	Bajaj spare parts
52PD0972	PD160 S.COVER LH PD181217 EB.BLACK+DEC	Bajaj spare parts
52PD0973	PD160 S.COVER RH PD181218 EB.BLACK+DEC	Bajaj spare parts
52PD1022	PD BS6 TANK52PD1021 EBONY BLACK+3D DECAL	Bajaj spare parts
52PD1025	PD BS6 TANK 52PD1023 SPICY RED+3D DECAL	Bajaj spare parts
52PD1030	PD BS6 TANK 52PD1029 CLASS WHITE+3D DECA	Bajaj spare parts
52PD1032	PD BS6 TANK52PD1031 BLK MATT MAT+3D DCAL	Bajaj spare parts
52PD1034	PD BS6 TANK52PD1033 MATT CLASS WHIT+3D D	Bajaj spare parts
52PD1036	PD BS6 TANK52PD1035 TROPICALNIGHT+3D DCL	Bajaj spare parts
52PD1038	COVER LH RR 220 STREET BLACK ABS BS6	Bajaj spare parts
52PD1045	S/F ASSEMBLY COVER MAGNETO BS6	Bajaj spare parts
52PD1056	ASSEMBLY COVER MAGNETO BS6 - BLACK	Bajaj spare parts
52PD1057	ASSEMBLY COVER MAGNETO BS6 - MOON LIGHT	Bajaj spare parts
52PD1276	SF K17 LH COVER WITH CAP TDC PD541249	Bajaj spare parts
52PD1280	ASSLY COVER HEAD COMP. PD511525	Bajaj spare parts
52PD1291	S/F ASSEMBLY COVER MAGNETO PD541289	Bajaj spare parts
52PD1612	ASSLY MAGNETO COVER WITH CAP TDC	Bajaj spare parts
52PD1615	COVER ASSLY HEAD PD511536 FOR K17E	Bajaj spare parts
52PD1620	OIL FILTER CAP PD571011 WITH O' RING	Bajaj spare parts
52PD1621	CAP CAM SPROCKET PD511095 WITH O' RING	Bajaj spare parts
52PD1622	GPS PD351016 WITH O' RING	Bajaj spare parts
52PD1661	MAGNETO COVER ASSLY PD541249	Bajaj spare parts
52PD1663	CAP OIL FILTER WITH O' RING PD571011	Bajaj spare parts
52PD1674	COVER ASSLY MAGNETO PD541255	Bajaj spare parts
52PD1698	COVER ASLY MAGNETO (PD541255) - MSGREY	Bajaj spare parts
52PD1703	ASSLY CRANKCASE LH-SPD P150	Bajaj spare parts
52PD1704	ASSLY CLUTCH COVER-SPD P150	Bajaj spare parts
52PF0219	CKD_SET OF SWING ARM ASSLY	Bajaj spare parts
52PF0315	SIDE CVR LH S/A CANDY RED	Bajaj spare parts
52PF0316	SIDE CVR LH BLUE(PLATINA B104D)	Bajaj spare parts

52PF0317	SIDE CVR LH S/A EBONY BLK	Bajaj spare parts
52PF0318	SIDE CVR RH CNDY RED WH DEC	Bajaj spare parts
52PF0319	SIDE CVR RH EL BLUE DEC	Bajaj spare parts
52PF0320	SIDE CVR RH EBONY BLK WH DEC	Bajaj spare parts
52PF0325	SEAT CWL S/A EL BLUE WH DEC(PL B104D)	Bajaj spare parts
52PF0326	SEAT CWL S/A EBONY BLK WH DEC(PL B104D)	Bajaj spare parts
52PF0327	FAIRING CANDY RED	Bajaj spare parts
52PF0328	FAIRING EL BLUE WH	Bajaj spare parts
52PF0329	FAIRING EBONY BLK WH	Bajaj spare parts
52PF0333	FRONT FENDER CANDY RED WITH BR(PL B104D)	Bajaj spare parts
52PF0334	FRONT FENDER EL BLUE WITH BR(PL B104D)	Bajaj spare parts
52PF0335	FRONT FENDER BLK	Bajaj spare parts
52PF0336	FUEL TANK CANDY RED W. DECAL (PL B104D)	Bajaj spare parts
52PF0358	SEAT CWL S/A CANDY RED W. DECAL	Bajaj spare parts
52PF0359	SEAT COWL S/A ELECT. BL. W. DEC.	Bajaj spare parts
52PF0360	SEAT COWL S/A EBONY BL. W. DECAL	Bajaj spare parts
52PF0367	SIDE COVER LH BLACK SILVER GRAY	Bajaj spare parts
52PF0368	SIDE COVER RH BLACK SILVER GRAY	Bajaj spare parts
52PF0369	FAIRING BLACK SILVER GRAY	Bajaj spare parts
52PF0373	SEAT COWL S/A BLACK SILVER GRAY	Bajaj spare parts
52PF0374	SEAT COWL S/A BLACK SILVER GRAY	Bajaj spare parts
52PF0525	FR FENDER ARCTIC WHT WH BRAC PLA B104 D	Bajaj spare parts
52PF0526	FL TANK ARCTIC WHT WH DECAL PLA B1014 D	Bajaj spare parts
52PF0558	FUEL TANK CANDY RED WT DECAL PLATINA ES	Bajaj spare parts
52PF0612	SWING ARM S/A (PLATINA ES UG)	Bajaj spare parts
52PF0622	FAIRING RED DKL PLATINA	Bajaj spare parts
52PF0630	SD CVR LH PLA SLV WH PASN RED DCL BM150	Bajaj spare parts
52PF0631	SD CVR RH PLA SLV WH PASN RED DCL BM150	Bajaj spare parts
52PF0683	FR NO PLATE KIT FOR PLA-100ES FOR SPARES	Bajaj spare parts
52PF0726	FAIRING BLK DKL	Bajaj spare parts
52PF0727	FAIRING ELE BLUE DKL	Bajaj spare parts
52PF0728	SIDE CVR LH RED DKL PLA	Bajaj spare parts
52PF0729	SIDE CVR LH BLK DKL PLA	Bajaj spare parts
52PF0730	SIDE CVR LH EL BLUE WH DKL PLATINA ES UG	Bajaj spare parts
52PF0731	SIDE CVR RH RED PLA	Bajaj spare parts
52PF0732	SIDE CVR RH BLK DKL PLA	Bajaj spare parts
52PF0733	SIDE CVR RH EL BLUE WH DKL PLATINA ES UG	Bajaj spare parts
52PF0734	SEAT COWL FLRED PLATINA	Bajaj spare parts
52PF0735	SEAT COWL EBONY BLK DKL	Bajaj spare parts
52PF0740	FUEL TANK FLAME RED WH DKL PLATINA ES UG	Bajaj spare parts
52PF0741	F/T EBONY BLK/DKL PLATINA ES UG	Bajaj spare parts
52PF0742	FUEL TANK ELEC BLUE WH DKL PLATINA ES UG	Bajaj spare parts
52PF0761	PLATINUM SILVER COVER CLUTCH ASSLY	Bajaj spare parts
52PF0762	PLATINUM SILVER COVER MAGNETO ASSLY	Bajaj spare parts
52PF0773	ASSLY SARI GUARD (PLATINA ES UG)	Bajaj spare parts

52PF0783	PLAT SIL COVER MAGNETO ASSLY B104E KS	Bajaj spare parts
52PF0914	TANK FLAME RED WITH DECAL PLATINA BS-IV	Bajaj spare parts
52PF0915	FL TANK EBONY BLACK WH DECAL PLATINA	Bajaj spare parts
52PF0916	FL TANK ELECTRON BLUE WH DKL PLATINA	Bajaj spare parts
52PF1038	SILVER MANIFOLD INTAKE - CT100 ES/KS	Bajaj spare parts
52PF1140	ASSEMBLY MANIFOLD INTAKE PLATINA 125	Bajaj spare parts
52PF1146	SD COVER LH ELECTRON BLUE WH DKL PLATINA	Bajaj spare parts
52PF1147	SD COVER RH ELECTRON BLUE WH DKL PLATINA	Bajaj spare parts
52PF1148	SEAT COWL ELECTRON BLUE WH DKL PLATINA	Bajaj spare parts
52PF1150	COWLING WITH ELECTRON BLUE DECAL PLATINA	Bajaj spare parts
52PF1152	SD COVER LH EBONY BLACK WH DKL PLATINA	Bajaj spare parts
52PF1153	SD COVER RH EBONY BLACK WH DKL PLATINA	Bajaj spare parts
52PF1154	SEAT COWL EBONY BLACK WH DKL PLATINA	Bajaj spare parts
52PF1156	COWLING WITH EBONY BLACK DECAL PLATINA	Bajaj spare parts
52PF1158	SD COVER LH C.WINE RED WH DKL PLATINA	Bajaj spare parts
52PF1159	SD COVER RH C.WINE RED WH DKL PLATINA	Bajaj spare parts
52PF1160	SEAT COWL C.WINE RED WH DKL PLATINA ES	Bajaj spare parts
52PF1162	COWLING WITH C.WINE RED DECAL PLATINA ES	Bajaj spare parts
52PF1164	FUEL TANK ELECTRON BLUE WH DKL (PLATINA	Bajaj spare parts
52PF1165	FUEL TANK EBONY BLACK WH DKL (PLATINA	Bajaj spare parts
52PF1166	FUEL TANK C.WINE RED WH DKL (PLATINA ES	Bajaj spare parts
52PF1323	COVER MAGNETO ASSEMBLY - CT100KS	Bajaj spare parts
52PF1737	MANIFOLD INTAKE D110 BS VI	Bajaj spare parts
52PF1827	COWLING COCKTAIL WINE RED WH DCL BM-150	Bajaj spare parts
52PF1830	SI CVR RH COCKTAIL WI RED WH DCL BM 150	Bajaj spare parts
52PF1861	SEAT COWL ELE BLUE WH DEC(PL_100_KS_CBS)	Bajaj spare parts
52PF1863	SEAT COWL EB BLAK WH DEC(PLA 100 KS CBS)	Bajaj spare parts
52PF1865	SEAT COW COC WE RED WH DEC(PL-100 KS CBS	Bajaj spare parts
52PF1930	CLUTCH	Bajaj spare parts
52PF1931	MAGNETO	Bajaj spare parts
52PF1984	COWLING ARCTIC WHITE W DECAL BM150UG	Bajaj spare parts
52PF2105	SLICK BLACK COVER ASSEMBLY MAGNETO	Bajaj spare parts
52PF2129	COVER MAGNETO B104D (PF541245)	Bajaj spare parts
52PF2134	SLEEVE CARBURETTOR WITH CLAMP- CT 100ES	Bajaj spare parts
52PF2343	SIDE COVER RH EB BLACK W DKL PL100ES-UG	Bajaj spare parts
52PF2344	SIDE COVER RH ELEC BLUE W DKL PL100ES-UG	Bajaj spare parts
52PF2345	SIDE COVER RH C WI RED W DKL PL100ES-UG	Bajaj spare parts
52PF2346	COWLING WITH EB BLK DCAL PLATINA100ES UG	Bajaj spare parts
52PF2347	COWLING WITH EL BLU DCAL PLATINA100ES UG	Bajaj spare parts
52PF2348	COWLING WITH CW RED DCAL PLATINA100ES UG	Bajaj spare parts
52PF2733	COWLING EB BLK W MT RED DKL PLATINA 100	Bajaj spare parts
52PF2734	COWLING EB BLK W BR GLD DKL PLATINA 100	Bajaj spare parts
52PF2735	COWLING EB BLK W BLUE DKL PLATINA 100	Bajaj spare parts
52PF2739	TANK EB BLK W MT RED DKL PLATINA 100	Bajaj spare parts
52PF2740	TANK EB BLK W BR GLD DKL PLATINA 100	Bajaj spare parts

52PF2741	TANK EB BLK W BLUE DKL PLATINA 100	Bajaj spare parts
52PF2745	SD CVR LH EB BLK-MT RED DKL PLATINA 100	Bajaj spare parts
52PF2746	SD CVR LH EB BLK-BR GLD DKL PLATINA 100	Bajaj spare parts
52PF2747	SD CVR LH EB BLK-BLUE DKL PLATINA 100	Bajaj spare parts
52PF2748	SD CVR RH EB BLK-MT RED DKL PLATINA 100	Bajaj spare parts
52PF2749	SD CVR RH EB BLK-BR GLD DKL PLATINA 100	Bajaj spare parts
52PF2750	SD CVR RH EB BLK-BLUE DKL PLATINA 100	Bajaj spare parts
52PF2751	ST COWL EB BLK W MT RED DKL PLATINA 100	Bajaj spare parts
52PF2752	ST COWL EB BLK W BR GLD DKL PLATINA 100	Bajaj spare parts
52PF2753	ST COWL EB BLK W BLUE DKL PLATINA 100	Bajaj spare parts
52RA0038	ASSEMBLY CHASSIS BARE MAXIMA Z LPG-RA111	Bajaj spare parts
52RA0072	ASSLY REGULATOR KIT LPG COMBODIA	Bajaj spare parts
52RA0102	ED COATED ASSLY CHASSIS BARE-Z LPG	Bajaj spare parts
52RA0117	ED COATED ASSBLY CHASSIS Z LPG- BI FUEL	Bajaj spare parts
56AT4922	PAINTED BODY ASSLY X WIDE DSL BS6 -BLACK	Bajaj spare parts
56BF3R22	ASSLY CHANNEL QTR GLS MTG LH PAINT-BLACK	Bajaj spare parts
56DH046D	FAIRING(DJ181117) CHARCOAL BLACK	Bajaj spare parts
56DH047T	PAINTED FAIRING P150 BSIV KHI EBONY BLAC	Bajaj spare parts
56DH052V	FRONT FENDOR WINE RED K1	Bajaj spare parts
56DH053F	PAINTED FENDER FRONT P150 BSIV	Bajaj spare parts
56DH054R	PAINTED FR. FENDER P150 BSIV KHI PASS RE	Bajaj spare parts
56DH055N	FRONT FENDOR K1 SAFFIRE BLUE	Bajaj spare parts
56DH056D	FRONT FENDER(DH161257) CHARCOAL BLACK	Bajaj spare parts
56DH057Q	PAINTED FENDER FRONT BSIV ROYAL BLU	Bajaj spare parts
56DH057T	PAINTED FENDER FRONT BSIV KHI EB BL	Bajaj spare parts
56DH076D	K1 FLAP LH DH141054 CHARCOAL BLACK	Bajaj spare parts
56DH07X3	FLAP LH K1 E BLACK	Bajaj spare parts
56DH086D	K1 FLAP RH DH141055 CHARCOAL BLACK	Bajaj spare parts
56DH08X3	FLAP RH K1 E BLACK	Bajaj spare parts
56DH2323	PULSAR 150 FUEL TANK PRIMER	Bajaj spare parts
56DH2Y33	WHEEL FRONT 1.85X17 DR(DH151136)MATT BLK	Bajaj spare parts
56DH2Z9L	WHEEL FRONT 1.85X17(JZ131064) MAT C BLK	Bajaj spare parts
56DH3B33	WHEEL REAR MT 2.15X17(DH151144)MATT BLAC	Bajaj spare parts
56DH3X1Y	STEP HOLDER LH MATTE SLATE GRA	Bajaj spare parts
56DH3Y1Y	STEP HOLDER RH MATTE SLATE GRA	Bajaj spare parts
56DH456E	SEAT COWL PL SILVER	Bajaj spare parts
56DH4E67	COVER ST. MOTER DH102309 SLICK BLACK	Bajaj spare parts
56DH4T67	STEP HOLDER LH(DH161563) SLICK BLACK	Bajaj spare parts
56DH4U67	STEP HOLDER RH(DH161564) SLICK BLACK	Bajaj spare parts
56DH5H1Y	HOLDER STEP RH(DH161690)GRAY SLATE MATTE	Bajaj spare parts
56DH5H67	HOLDER STEP RH(DH161690)SLICK BLACK	Bajaj spare parts
56DH5U78	GRAB HANDLE LH(DK161432) SOLAR RED	Bajaj spare parts
56DH5UD6	GRAB HANDLE LH TREE FROG GREEN	Bajaj spare parts
56DH5V78	GRAB HANDLE RH(DK161433) SOLAR RED	Bajaj spare parts
56DH5VD6	GRAB HANDLE RH TREE FROG GREEN	Bajaj spare parts

56DH619L	WHEEL REAR 2.15X17 (JR131273) MAT C BLK	Bajaj spare parts
56DH6D51	WHEEL FR DH151077(TUBELESS) MILKY WHITE	Bajaj spare parts
56DH6D9L	WHEEL FRONT 1.85X17(DH151077) BLACK C MA	Bajaj spare parts
56DH6E51	WHEEL RR DH151079(TUBELESS) MILKY WHITE	Bajaj spare parts
56DH70Y9	GRAB HANDLE(DH221014) SPRINT MATTE BLACK	Bajaj spare parts
56DH8Q7B	PANEL BRAKE FRONT(DH151137) BLACK	Bajaj spare parts
56DH9A9L	WHEEL FR 1.85X17 DR(DH151111)BALC C MATT	Bajaj spare parts
56DH9D1Y	K1 COVER LH RR DH102505 MATT SLATE GREY	Bajaj spare parts
56DH9D67	K1 COVER LH RR DH102505 SLICK BLACK	Bajaj spare parts
56DH9VY9	HOLDER HANDLE LH(DH181140)BLACK SPRINT M	Bajaj spare parts
56DH9WY9	HOLDER HANDLE RH(DH181142)BLACK SPRINT M	Bajaj spare parts
56DH9XY9	BRACKET UPPER(DH181143)BLACK SPRINT MATT	Bajaj spare parts
56DJ04A7	K2/K1R FRT FAIRING MATT VOLCANIC RED	Bajaj spare parts
56DJ04X3	PUL.180 FAIRING KHI EBONY BLACK	Bajaj spare parts
56DJ386D	K2 BELLY PAN LH DJ161438- CHARCOAL BLACK	Bajaj spare parts
56DJ38X3	K1R/K2/K3- BELLY PAN LH -KHI EBONY BLACK	Bajaj spare parts
56DJ396D	K2 BELLY PAN RH DJ161439- CHARCOAL BLACK	Bajaj spare parts
56DJ39X3	K1R/K2/K3- BELLY PAN RH -KHI EBONY BLACK	Bajaj spare parts
56DJ3X1Y	K2 HOLDER STEP LH GREY MATTE SLATE	Bajaj spare parts
56DJ3X67	K1R HOLDER STEP LH DK161429 SLICK BLACK	Bajaj spare parts
56DJ3Y1Y	K2 HOLDER STEP RH GREY MATTE SLATE	Bajaj spare parts
56DJ3Y67	K1R/K2 HOLDER STEP RH DK161431 SLICK BLK	Bajaj spare parts
56DJ3Z1Y	K2 COVER LH RR GREY MATTE SLATE	Bajaj spare parts
56DJ4E1Y	COVER MOTOR STARTER (DH102309)	Bajaj spare parts
56DJ5U63	K2 GRAB HANDLE LH DK161432-SPORTY ORANGE	Bajaj spare parts
56DJ5U6E	K2 GRAB HANDLE DK161432-PLATINUM SILVER	Bajaj spare parts
56DJ5U9J	K2 GRAB HANDLE LH DK161432 - SATIN RED	Bajaj spare parts
56DJ5V63	K2 GRAB HANDLE RH DK161433-SPORTY ORANGE	Bajaj spare parts
56DJ5V6E	K2 GRAB HANDLE RH DK161433 -PLAT SILVER	Bajaj spare parts
56DJ5V9J	K2 GRAB HANDLE RH DK161433 - SATIN RED	Bajaj spare parts
56DJ6D55	K2/K3 - FRONT WHEEL IN MILKY WHITE	Bajaj spare parts
56DJ6E55	K2/K3 - REAR WHEEL IN MILKY WHITE	Bajaj spare parts
56DJ9D67	K1 COVER LH RR DJ101784 SLICK BLACK	Bajaj spare parts
56DK0123	PRIMERED PULSAR 220 DTSFi	Bajaj spare parts
56DK0323	PETROL TANK 220 SF PRIMERED	Bajaj spare parts
56DK052V	FRONT FENDOR WINE RED K2/K3	Bajaj spare parts
56DK054R	K2/K3 FRONT FENDER IN PASSION RED	Bajaj spare parts
56DK055N	FRONT FENDOR K2/K3 SAFFIRE BLUE	Bajaj spare parts
56DK056D	K2 FRONT FENDER-DK161084- CHARCOAL BLACK	Bajaj spare parts
56DK057Q	K2/K3 FRONT FENDER ROYAL BLUE	Bajaj spare parts
56DK05X3	FRONT FENDOR EBONY BLACK K1	Bajaj spare parts
56DK31Y9	"HANDLE HOLDER LH, SPRINT MATT BLACK"	Bajaj spare parts
56DK32Y9	"HANDLE HOLDER RH, SPRINT MATT BLACK"	Bajaj spare parts
56DK33Y9	BRACKET UPPER BLACK SPRINT MATTE	Bajaj spare parts
56DK4527	SEAT COWL WINE RED	Bajaj spare parts

56DK452V	SEAT COWL K1/K2/K3 WINE RED CLIP NUT & G	Bajaj spare parts
56DK455N	SEAT COWL SAFFIRE BLUE	Bajaj spare parts
56DK455Y	SEAT COWL MET. WHITE	Bajaj spare parts
56DK45X3	SEAT COWL ASLY E BLACK W/O DCL	Bajaj spare parts
56DT0233	K10UG STAY HANGER LH-DT113409 MATT BLACK	Bajaj spare parts
56DT0333	K10UG STAY HANGER RH-DT113410 MATT BLACK	Bajaj spare parts
56DT05X3	FENDOR FRONT EBONY BLACK K-8	Bajaj spare parts
56DT074X	DT FAIRNG FLAP SATIN BLACK LH	Bajaj spare parts
56DT084X	DT FAIRNG FLAP RH SATIN BLACK	Bajaj spare parts
56DT09C8	FRAME DT111214 S URBAN WHITE+SCHWARTZ BLK	Bajaj spare parts
56DT09Y9	K10 FRAME - SPRINT MATTE BLACK	Bajaj spare parts
56DT106T	DT SEAT COWL RH BRIGHT YELLOW	Bajaj spare parts
56DT10X3	DT SEAT COWL RH EBONY BLACK	Bajaj spare parts
56DT11X3	DT SEAT COWL LH EBONY BLACKDT SEAT COWL	Bajaj spare parts
56DT124X	SIDE COVER -LH	Bajaj spare parts
56DT134X	SIDE COVER -RH	Bajaj spare parts
56DT1RX3	DT TANK COVER TOP M/T EBONY BLACK	Bajaj spare parts
56DT2232	TANK COVER TOP DT171002 PEWTER GREY	Bajaj spare parts
56DT2242	TANK COVER TOP DT171002 PEARL MET WHITE	Bajaj spare parts
56DT224Z	TANK COVER TOP DT171002 BURNT RED	Bajaj spare parts
56DT235Z	FUEL TANK K8 MONOCOAT BLACK	Bajaj spare parts
56DT28Y9	K 10 SWING ARM - SPRINT MATTE BLACK	Bajaj spare parts
56DT2Z4R	K8 WHEEL FRONT MATTE PASSION RED	Bajaj spare parts
56DT2Z5N	K8 WHEEL FRONT MATTE SAFIRE BLUE	Bajaj spare parts
56DT3133	K8 HANDLE HOLDER LH MATTE BLACK	Bajaj spare parts
56DT3233	K8 HANDLE HOLDER RH MATTE BLACK	Bajaj spare parts
56DT3333	K8 UPPER BRACKET MATTE BLACK	Bajaj spare parts
56DT366B	FR BEZEL-M.LIGHT SILV	Bajaj spare parts
56DT36X3	FRONT BEZEL LOWER DT181252 EBONY BLACK	Bajaj spare parts
56DT3SY9	K10 STEP RIDER LH SPRINT MATTE BLACK	Bajaj spare parts
56DT3T4X	STEP RIDER RH JL113011 SATIN BLACK	Bajaj spare parts
56DT3TY9	K10 STEP RIDER RH SPRINT MATTE BLACK	Bajaj spare parts
56DT3X1Y	K8 HOLDER STEP LH SLATE GREY	Bajaj spare parts
56DT3X4X	HOLDER STEP LH DT113002 SATIN BLACK	Bajaj spare parts
56DT3XY9	K10 STEP HOLDER LH - SPRINT MATT BLACK	Bajaj spare parts
56DT3Y1Y	K8 HOLDER STEP RH SLATE GREY	Bajaj spare parts
56DT3Y4X	HOLDER STEP RH DT113036 SATIN BLACK	Bajaj spare parts
56DT3YY9	K10 STEP HOLDER RH - SPRINT MATT BLACK	Bajaj spare parts
56DT4J1Y	K8 STEP HOLDER PILLION SLATE GREY	Bajaj spare parts
56DT4J4X	STEP HOLDER PILLON LH DT113006 SATIN BLK	Bajaj spare parts
56DT4JY9	K10 STEP PILL. ASLY LH SPRINT MATT BLACK	Bajaj spare parts
56DT4K1Y	K8 STEP HOLDER PILLION RH STALE GREY	Bajaj spare parts
56DT4K4X	STEP HOLDER PILLON RH DT113008 SATIN BLK	Bajaj spare parts
56DT4KY9	K10 STEP PILL. ASLY RH SPRINT MATT BLACK	Bajaj spare parts
56DT4S1Y	K8 HOLDER STEP RH - NON ABS SLATE GREY	Bajaj spare parts



56DT5U36	K10UG GRAB HANDLE LH-SILK MATT BLACK	Bajaj spare parts
56DT5V36	K10 UG GRAB HANDLE RH - SILK MATT BLACK	Bajaj spare parts
56DT654Y	K8 FRONT FAIRING BURNT RED+SPARKLING BLK	Bajaj spare parts
56DT65B1	K8 FRONT FAIRING C BLACK+SPARKLING BLACK	Bajaj spare parts
56DT65B7	K8 FRONT FAIRING P BLUE+SPARKLING BLACK	Bajaj spare parts
56DT6R37	K10 REAR WHEEL IN MATTE GOLDEN SAND	Bajaj spare parts
56DT6T37	K10 FRONT WHEEL IN MATTE GOLDEN SAND	Bajaj spare parts
56DT6Z28	COVER CYL HEAD-DT511069"SEMI GLOS Y BLAK"	Bajaj spare parts
56DTD74X	SEAT COWL CENTRAL TOP DT181210 SATIN BLK	Bajaj spare parts
56DTD86B	CAP STERI TOP BOLT DT121032 MOON LIG.SIL	Bajaj spare parts
56DTD96B	CAP FORK TOP BOLT DT151043 MOON LIG.SIL.	Bajaj spare parts
56DTE14X	K8 BS6 CHAMBER LH (DT591131) SATIN BLACK	Bajaj spare parts
56DTE24X	K8 BS6 CHAMBER RH ( DT591132) SATIN BLAC	Bajaj spare parts
56DU057R	FRONT FENDER MATTE WILD GREEN (DU161096)	Bajaj spare parts
56DU1BY9	GRAB HANDLE(DU221016) BLACK SPRINT MATTE	Bajaj spare parts
56DU6AY9	HOLD. HANDLE LOWER(FD181031)BLK SPRI MAT	Bajaj spare parts
56DU6B3Q	HOLDER - HANDLE :- UPPER(FD181030)SILVER	Bajaj spare parts
56DU70Y9	GRAB HANDLE(DU221001) BLACK SPRINT MATTE	Bajaj spare parts
56DU9TY9	HOLDER HANDLE UPPER(DU181170)BLK SPRI MA	Bajaj spare parts
56DU9UY9	HOLDER HANDLE LOWER(DU181171)BLK SPRI MA	Bajaj spare parts
56DY057R	FRONT FENDER MATT WILD GREEN(DF161243)	Bajaj spare parts
56DY6D33	WHEEL FRONT MT 1.85X17 DR(JK131046)BLACK	Bajaj spare parts
56DY8Q7B	PANEL BRAKE FRONT(DU151069)BLACK	Bajaj spare parts
56DY9A33	WHEEL FRONT MT 1.85X17(JK131048)BLACK	Bajaj spare parts
56DY9D3Q	COVER REAR LH(DY541205)SILVER	Bajaj spare parts
56DYR84X	CALIPER ASSEMBLY (JH131886) SATIN BLACK	Bajaj spare parts
56GL059S	H105 FRT FENDER GL181402 INDIGO METALLIC	Bajaj spare parts
56GL059T	H105 FRT FENDER GL181402 VELLUTO ROSSO	Bajaj spare parts
56GL059U	H105 FRT FENDER GL181402 HAZELNUT	Bajaj spare parts
56GL059V	H105 FRT FENDER GL181402 BROOKLYN BLACK	Bajaj spare parts
56GL05D3	FENDER FRONT-GL181402 CITRUS RUSH	Bajaj spare parts
56GL613V	WHEEL REAR GL131234 SLATE GRAY	Bajaj spare parts
56GL614X	WHEEL REAR GL131234 SATIN BLACK	Bajaj spare parts
56GL7L9R	H105 SHIELD ASSLY UPPGL181025 COARS GREY	Bajaj spare parts
56GL7L9V	H105 SHIELD ASSLY UPPGL181025 BROKLN BLK	Bajaj spare parts
56GL7M9S	H105 COV H BAR FRT GL181309INDIGO METALI	Bajaj spare parts
56GL7M9U	H105 COV H BAR FRT GL181309 HAZEL NUT	Bajaj spare parts
56GL7M9V	H105 COV H BAR FRT GL181309 BROOKLYN BLK	Bajaj spare parts
56GL7N9V	H105 COV H BAR REARGL181240 BROOKLYN BLK	Bajaj spare parts
56GL7ND3	COVER HANDLEBAR REAR-GL181240 CITRUS RUS	Bajaj spare parts
56GL7ND5	COVER HANDLEBAR REAR-GL181240 CYBER WHIT	Bajaj spare parts
56GL7Q9S	H 105 LID COVER GL181052 INDIGO METALLIC	Bajaj spare parts
56GL7Q9T	H 105 LID COVER GL181052 VELLUTO ROSSO	Bajaj spare parts
56GL7Q9U	H 105 LID COVER GL181052 HAZELNUT	Bajaj spare parts
56GL7Q9V	H 105 LID COVER GL181052 BROOKLYN BLACK	Bajaj spare parts

56GL7QD3	LID BOX GLOVE-GL181052 CITRUS RUSH	Bajaj spare parts
56GL7QD5	LID BOX GLOVE-GL181052 CYBER WHITE	Bajaj spare parts
56GL7R9S	H105 SHIELD FRT LOW GL181090 INDIGO META	Bajaj spare parts
56GL7R9T	H105 SHIELD FRT LOW GL181090VELLUT ROSSO	Bajaj spare parts
56GL7R9V	H105 SHIELD FRT LOW GL181090 BROOKLY BLK	Bajaj spare parts
56GL7S9U	H105 SHIELD LOW RH GL181028 HAZELNUT	Bajaj spare parts
56GL7S9V	H105 SHIELD LOW RH GL181028 BROOKLYN BLK	Bajaj spare parts
56GL7SD3	SHIELD LOWER RH-GL181028 CITRUS RUSH	Bajaj spare parts
56GL7SD5	SHIELD LOWER RH-GL181028 CYBER WHITE	Bajaj spare parts
56GL7T9U	H105 SHIELD LOW LH GL181029 HAZELNUT	Bajaj spare parts
56GL7T9V	H105 SHIELD LOW LH GL181029 BROOKLYN BLK	Bajaj spare parts
56GL7TD3	SHIELD LOWER LH-GL181029 CITRUS RUSH	Bajaj spare parts
56GL7TD5	SHIELD LOWER LH-GL181029 CYBER WHITE	Bajaj spare parts
56GL7U9R	H105 ASSLY SIDE PANELGL181040 COARS GREY	Bajaj spare parts
56GL7U9S	H105 ASSLY SIDE PANELGL181040 INDIGO MET	Bajaj spare parts
56GL7U9T	H105 ASSLY SIDE PANELGL181040VELUT ROSSO	Bajaj spare parts
56GL7U9U	H105 ASSLY SIDE PANEL GL181040 HAZELNUT	Bajaj spare parts
56GL7U9V	H105 ASSLY SIDE PANELGL181040BROOKLY BLK	Bajaj spare parts
56GL7UD3	PANEL ASSEMBLY BODY-GL181040 CITRUS RUSH	Bajaj spare parts
56GL7UD5	PANEL ASSEMBLY BODY-GL181040 CYBER WHITE	Bajaj spare parts
56GL7V9S	H105 PANEL FRT NECK GL181026 INDIGO META	Bajaj spare parts
56GL7V9U	H105 PANEL FRT NECK GL181026 HAZELNUT	Bajaj spare parts
56GL7V9V	H105 PANEL FRT NECKGL181026 BROOKLYN BLK	Bajaj spare parts
56GL7VD3	PANEL SHIELD UPPER-GL181026 CITRUS RUSH	Bajaj spare parts
56GL9S9T	H105 TRIM FOOTREST GL113047 VELUT ROSSO	Bajaj spare parts
56GL9S9V	H105 TRIM FOOTREST GL113047 BROOKLY BLK	Bajaj spare parts
56GL9SD3	TRIM FOOTREST SIDE-GL113047 CITRUS RUSH	Bajaj spare parts
56GLB39S	H105 BOX GLOVE-COVER GL181153 INDIGO MET	Bajaj spare parts
56GLB39T	H105 BOX GLOVE-COVER GL181153 VELU ROSS	Bajaj spare parts
56GLB39U	H105 BOX GLOVE-COVER GL181153 HAZELNUT	Bajaj spare parts
56GLC64X	AP WHEEL FRONT-GL131058 SATIN BLACK	Bajaj spare parts
56JD052V	FRONT FENDER P135(JD181400) C. WINE RED	Bajaj spare parts
56JD053F	PAINTED PART FRONT FENDER P135 FLAME RED	Bajaj spare parts
56JD055N	FRONT FENDER P135(JD181400) SAFFIRE BLUE	Bajaj spare parts
56JD057Q	PAINTED PART FRO FENDER ROYAL BLUE	Bajaj spare parts
56JD05X3	PAINTED PART FRONT FENDER EB BLACK	Bajaj spare parts
56JD2X23	FUEL TANK P 135 BSIV PRIMER	Bajaj spare parts
56JD3X1Y	STEP HOLDER LH(JD113026) SLATE MATTE GRA	Bajaj spare parts
56JD3Y1Y	STEP HOLDER RH(JD113027) SLATE MATTE GRA	Bajaj spare parts
56JD4A1Y	CAP FILTER(JE541218)P135 MATT SLATE GRAY	Bajaj spare parts
56JD5H1Y	HOLDER STEP RH	Bajaj spare parts
56JE1X3V	CAP OIL FILTER (JE541234) "SLATE GREY"	Bajaj spare parts
56JE1X4X	CAP OIL FILTER (JE541234) "SATIN BLACK"	Bajaj spare parts
56JE1X67	SLICK BLACK CAP OIL FILTER (JE541208)	Bajaj spare parts
56JF093V	FRAME ASSEMBLYJF111303 SLAT GREY+ SA BLK	Bajaj spare parts

56JF09AM	K11 2CH FRAME JF111361 SLATE GREY+SAT BL	Bajaj spare parts
56JF09C8	FRAME JF111283 S URBAN WHITE+SCHWARTZ BLK	Bajaj spare parts
56JF124X	COVER SIDE LH SATIN BLACK K11	Bajaj spare parts
56JF126E	COVER SIDE LH S BLK+PLAT SILVER JF181788	Bajaj spare parts
56JF134X	COVER SIDE RH SATIN BLACK K11	Bajaj spare parts
56JF136E	COVER SIDE RH S BLK+PLAT SILVER JF181789	Bajaj spare parts
56JF141U	K10 SIDE MASK LH PLUM RED	Bajaj spare parts
56JF141V	K10 SIDE MASK LH TWILIGHT BLUE	Bajaj spare parts
56JF144X	K10 UG SIDE MASK LH IN SATIN BLACK	Bajaj spare parts
56JF148T	K10 SIDE MASK LH GRAPHITE MATT BLACK	Bajaj spare parts
56JF148X	K10 SIDE MASK LH CANYON RED	Bajaj spare parts
56JF148Y	K10 SIDE MASK LH GLACIER BLUE	Bajaj spare parts
56JF149A	K10 SIDE MASK LH SAVANNA GREEN	Bajaj spare parts
56JF14W3	K10 SIDE MASK LH CLASSIC WHITE	Bajaj spare parts
56JF151U	K10 SIDE MASK RH PLUM RED	Bajaj spare parts
56JF151V	K10 SIDE MASK RH TWILIGHT BLUE	Bajaj spare parts
56JF154X	K10 UG SIDE MASK RH IN SATIN BLACK	Bajaj spare parts
56JF158T	K10 SIDE MASK RH GRAPHITE MATT BLACK	Bajaj spare parts
56JF158X	K10 SIDE MASK RH CANYON RED	Bajaj spare parts
56JF158Y	K10 SIDE MASK RH GLACIER BLUE	Bajaj spare parts
56JF159A	K10 SIDE MASK RH SAVANNA GREEN	Bajaj spare parts
56JF15W3	K10 SIDE MASK RH CLASSIC WHITE	Bajaj spare parts
56JF181Y	STEP PILLION LH K10 SLATE GREY	Bajaj spare parts
56JF191Y	STEP PILLION RH K10 SLATE GREY	Bajaj spare parts
56JF1B4X	GRAB HANDLE JF231418 SATIN BLACK	Bajaj spare parts
56JF1X36	"CAP OIL FILTER (JL571001) ""SILK MATTE	Bajaj spare parts
56JF201U	K10 TANK SIDE COVER LH PLUM RED	Bajaj spare parts
56JF201V	K10 TANK SIDE COVER LH TWILIGHT BLUE	Bajaj spare parts
56JF208T	K10 TANK COVER LH GRAPHITE MATT BLACK	Bajaj spare parts
56JF208X	K10 TANK COVER LH CANYON RED	Bajaj spare parts
56JF208Y	K10 TANK COVER LH GLACIER BLUE	Bajaj spare parts
56JF20W3	K10 TANK SIDE COVER LH CLASSIC WHITE	Bajaj spare parts
56JF211U	K10 TANK SIDE COVER RH PLUM RED	Bajaj spare parts
56JF211V	K10 TANK SIDE COVER RH TWILIGHT BLUE	Bajaj spare parts
56JF218T	K10 TANK COVER RH GRAPHITE MATT BLACK	Bajaj spare parts
56JF218X	K10 TANK COVER RH CANYON RED	Bajaj spare parts
56JF218Y	K10 TANK COVER RH GLACIER BLUE	Bajaj spare parts
56JF21W3	K10 TANK SIDE COVER RH CLASSIC WHITE	Bajaj spare parts
56JF221U	K10 TANK COVER TOP PLUM RED	Bajaj spare parts
56JF221V	K10 TANK COVER TOP TWILIGHT BLUE	Bajaj spare parts
56JF226D	K10 T.COVER TOP JF171018 CHARCOAL BLACK	Bajaj spare parts
56JF228T	TANK COVER TOP GRAPHITE MATT BLACK	Bajaj spare parts
56JF228X	K10 TANK COVER TOP CANYON RED	Bajaj spare parts
56JF228Y	K10 TANK COVER TOP GLACIER BLUE	Bajaj spare parts
56JF229A	K10 TANK COVER TOP SAVANNA GREEN	Bajaj spare parts

56JF22W3	K10 TANK COVER TOP CLASSIC WHITE	Bajaj spare parts
56JF244X	K10 SHROUD LH SATIN BLACK	Bajaj spare parts
56JF246B	SHORUD LH M/LIGHT SIL PLSR	Bajaj spare parts
56JF254X	K10 SHROUD RH SATIN BLACK	Bajaj spare parts
56JF256B	SHROUD RH M/ LIGHT SILV PLSR	Bajaj spare parts
56JF28Y9	K10B SWING ARMJF122100-SPRINT MATT BLACK	Bajaj spare parts
56JF296D	K10C HAND GUARD LH JF231230 CHARCL BLACK	Bajaj spare parts
56JF298X	K10C HAND GUARD LH JF231230 RACING RED	Bajaj spare parts
56JF299A	K10C HAND GUARD LH JF231230 AURORA GREEN	Bajaj spare parts
56JF2B4X	SIDE COVER LH SATIN BLACK PULSAR 400	Bajaj spare parts
56JF2C4X	SIDE COVER RH SATIN BLACK PULSAR 400	Bajaj spare parts
56JF2Z3V	WHEEL FRONT (JF131011) SLATE GREY	Bajaj spare parts
56JF2Z7S	WHEEL FRONT (JF131011) SATIN URBAN WHITE	Bajaj spare parts
56JF306D	K10C HAND GUARD RH JF231233 CHRCOL BLACK	Bajaj spare parts
56JF308X	K10C HAND GUARD RH JF231233 RACING RED	Bajaj spare parts
56JF309A	K10C HAND GUARD RH JF231233 AURORA GREEN	Bajaj spare parts
56JF31Y9	HANDLE HOLDERLH NS200 BRAZ MAT.SPRNT BLK	Bajaj spare parts
56JF32Y9	HANDLE HOLDERRH NS200 BRAZ MAT.SPRNT BLK	Bajaj spare parts
56JF3333	K10 UG BRKT UPPER-JF151040- MATT BLACK	Bajaj spare parts
56JF33Y9	NS 200 BRKT UPP. JF151067 MAT.SPRNT BLK	Bajaj spare parts
56JF364X	BELLY PAN RH JF181288 SATIN BLACK	Bajaj spare parts
56JF374X	BELLY PAN LH JF181286 SATIN BLACK	Bajaj spare parts
56JF3832	PULSAR 160 NS BELLY PAN LH GLOSSY PEWTER	Bajaj spare parts
56JF384R	BELLY PAN LH K11 UG PASSION RED	Bajaj spare parts
56JF385N	BELLY PAN LH K11 UG SAFFIRE BLUE	Bajaj spare parts
56JF385Y	K11 UG BELLY PAN LH METALLIC PEARL WHITE	Bajaj spare parts
56JF388T	K10 BELLY PAN LH GRAPHITE MATTE BLACK.	Bajaj spare parts
56JF388X	K10 BELLY PAN LH CANYON RED	Bajaj spare parts
56JF388Y	K10 BELLY PAN LH GLACIER BLUE	Bajaj spare parts
56JF3932	PULSAR 160 NS BELLY PAN RH GLOSSY PEWTER	Bajaj spare parts
56JF394R	BELLY PAN RH K11 UG PASSION RED	Bajaj spare parts
56JF395N	BELLY PAN RH K11 UG SAFFIRE BLUE	Bajaj spare parts
56JF395Y	K11 UG BELLY PAN RH METALLIC PEARL WHITE	Bajaj spare parts
56JF398T	K10 BELLY PAN RH GRAPHITE MATTE BLACK.	Bajaj spare parts
56JF398X	K10 BELLY PAN RH CANYON RED	Bajaj spare parts
56JF398Y	K10 BELLY PAN RH GLACIER BLUE	Bajaj spare parts
56JF3B3V	WHEEL REAR (JF131206) SLATE GREY	Bajaj spare parts
56JF3S1Y	RIDER STEP LH K10 SLATE GREY	Bajaj spare parts
56JF3S57	STEP RIDER LH JL113009 SATIN SILVER	Bajaj spare parts
56JF3T1Y	RIDER STEP RH K10 SLATE GREY	Bajaj spare parts
56JF3T4X	STEP RIDER RH JF113006 SATIN BLACK	Bajaj spare parts
56JF3T57	STEP RIDER RH JF113006 SATIN SILVER	Bajaj spare parts
56JF3X1Y	HOLDER STEP LH K10 GREY MATTE SLATE	Bajaj spare parts
56JF3X4X	STEP HOLDER RIDER LH JF113050 SATIN BLK	Bajaj spare parts
56JF3XY9	K10UG STEP HOLDER LHJF113031-SPRT MT BLK	Bajaj spare parts

56JF3Y1Y	HOLDER STEP RH K10 GREY MATTE SLATE	Bajaj spare parts
56JF3YY9	K10UG STEP HOLDER RHJF113033-SPRT MT BLK	Bajaj spare parts
56JF4517	SEAT COWL ASSY JF181001 FIERY ORG+SA BLK	Bajaj spare parts
56JF4S4X	STEP HOLDER RH JF113046 SATIN BALCK	Bajaj spare parts
56JF503V	FRAME ASSEMBLY JF111351 SLAT GREY+ SA BL	Bajaj spare parts
56JF5AW4	K10 UG HANDLE HOLDER UPPER-GLOSSY BLACK	Bajaj spare parts
56JF5BW4	K10 UG HANDLE HOLDER LOWER-GLOSSY BLACK	Bajaj spare parts
56JF5T84	STRUCTURE BACKREST JF231234 BLACK GLOSS	Bajaj spare parts
56JF6R33	K10 UG REAR WHEEL(JF131217) - MATT BLACK	Bajaj spare parts
56JF6T33	K10 UG FRT WHEEL(JF131026) - MATT BLACK	Bajaj spare parts
56JF8C6D	K10UG T.COVER LH JF171020 CHARCOAL BLACK	Bajaj spare parts
56JF8C9A	K10 UG TANK COVER LH GLAMOUR GREEN	Bajaj spare parts
56JF8D6D	K10UG T.COVER RH JF171021 CHARCOAL BLACK	Bajaj spare parts
56JF8D9A	K10 UG TANK COVER RH GLAMOUR GREEN	Bajaj spare parts
56JF8L4X	K10 LAMP MASK JF181266 SATIN BLACK	Bajaj spare parts
56JF8L6D	K10 HD LAMP MASK JF181266 CHARCOAL BLACK	Bajaj spare parts
56JF8L8X	K10 CARRIER MASK CANYON RED	Bajaj spare parts
56JF8L9A	K10UG MASK HEADLAMP JF181266-GLAM GREEN	Bajaj spare parts
56JF8U33	REAR WHEEL 3X17, JF131242 MATT BLACK	Bajaj spare parts
56JF8U7D	REAR WHEEL 3.00X17 JF131242 SILVER	Bajaj spare parts
56JF8U7S	WHEEL REAR (JF131233) SATIN URBAN WHITE	Bajaj spare parts
56JF9J9L	DOMINAR HANDLE BAR JF151041-MATTE BLACK	Bajaj spare parts
56JF9N33	FRONT WHEEL JF131039-MATT BLACK	Bajaj spare parts
56JF9N7D	WHEEL FRONT 2.5X17 JF131039 SILVER	Bajaj spare parts
56JFA833	K10 B BRACKET UPPER JF151057 MATTEBLACK	Bajaj spare parts
56JFK84X	BKT SADDLE TOP LH JF231424 SATIN BLACK	Bajaj spare parts
56JFK94X	BKT SADDLE TOP RH JF231423 SATIN BLACK	Bajaj spare parts
56JFL1Y9	SWING ARM JF122137 SPRINT MATTE BLACK	Bajaj spare parts
56JG05X3	FRONT FENDER DUKE EBONY BLACK	Bajaj spare parts
56JG104X	SEAT COWL RH DUKE SATIN BLACK	Bajaj spare parts
56JG114X	SEAT COWL LH DUKE SATIN BLACK	Bajaj spare parts
56JG124X	SIDE COVER LH DUKE SATIN BLACK	Bajaj spare parts
56JG134X	SIDE COVER RH DUKE SATIN BLACK	Bajaj spare parts
56JG14X3	SIDE MASK LH DUKE EBONY BLACK	Bajaj spare parts
56JG15X3	SIDE MASK RH DUKE EBONY BLACK	Bajaj spare parts
56JG1833	ADV250STEP PILLION LHJG113108 MATT BLACK	Bajaj spare parts
56JG1884	ADV250 STEP PILLION LHJG113108 BLK GLOSS	Bajaj spare parts
56JG1933	ADV250STEP PILLION RHJG113109 MATT BLACK	Bajaj spare parts
56JG1984	ADV250 STEP PILLION RHJG113109 BLK GLOSS	Bajaj spare parts
56JG221T	DUKE 125 TANK COVER TOP- ELECTR ORANGE	Bajaj spare parts
56JG22X3	TANK COVER TOP DUKE EBONY BLACK	Bajaj spare parts
56JG296W	HAND GUARD JG231212-BLACK METALIC MATT	Bajaj spare parts
56JG29X3	HAND GUARD LH JG231212 BLACK GLOSS	Bajaj spare parts
56JG306W	HAND GUARD RHJG231213-BLACK METALIC MATT	Bajaj spare parts
56JG30X3	HAND GUARD RH JG231213 BLACK GLOSS	Bajaj spare parts

56JG3X33	ADV250HOLDER STEPLH JG113106 MATT BLACK	Bajaj spare parts
56JG3XD1	S HOLD RIDER LHJG113084 BL MATT ANODIZED	Bajaj spare parts
56JG3Y33	ADV250HOLDER STEPRH JG113107 MATT BLACK	Bajaj spare parts
56JG3Y84	ADV250HOLDER STEPRH JG113107 BLACK GLOSS	Bajaj spare parts
56JG3YD1	S HOLD RIDER RHJG113085 BL MATT ANODIZED	Bajaj spare parts
56JG4D33	ADV250 MASK MIDDLE JG181363 SATIN BLACK	Bajaj spare parts
56JG4D45	ADV390 COVR MASK MIDDLE GUNMETAL METALIC	Bajaj spare parts
56JG4JD1	S HOL PILLION LHJG113081 BL MAT ANODIZED	Bajaj spare parts
56JG4KD1	S HOL PILLION RHJG113083 BL MAT ANODIZED	Bajaj spare parts
56JG6X28	WATER PUMP COVER JG601024 HR BLACK	Bajaj spare parts
56JG9X33	BRKET UPPER BLK MAT PODER COTED JG151050	Bajaj spare parts
56JH04X3	FAIRING ASLY C101A EB BLACK	Bajaj spare parts
56JH052V	PAINTED PART FRONT FENDER C101A C W RED	Bajaj spare parts
56JH05X3	FRONT FENDER C101A EB BLACK	Bajaj spare parts
56JH3E23	PAINTED PART FUEL TANK V 15 BSIV PRIMER	Bajaj spare parts
56JH453F	PAINTED PART SEATCOWL C101A FLM RED	Bajaj spare parts
56JH455N	ASSLY SEAT COWL SAFFIRE BLUE	Bajaj spare parts
56JH7043	PAINTED GRAB-V12 (JH231400) RUSTIC ORNG	Bajaj spare parts
56JH706E	PAINTED GRAB-V12 (JH231400) PL.SILVER	Bajaj spare parts
56JK2323	PAINTED PART FUEL TANK FOR NEW F.G PRIMR	Bajaj spare parts
56JK2Z33	WHEEL FR MT 1.85X17(JK131044) BLACK MATT	Bajaj spare parts
56JK2Z7S	WHEEL FR 1.85X17(JK131044)SATIN URBAN WH	Bajaj spare parts
56JK617S	WHEEL RR 1.85X17(JK131228)SATIN URBAN WH	Bajaj spare parts
56JK6D33	WHEEL REAR 1.85X17(JK131228)BLACK MAT	Bajaj spare parts
56JK6D3Q	WHEEL FRONT MT 1.85X17(JK131044) SILVER	Bajaj spare parts
56JK6E3Q	WHEEL REAR 1.85X17(JK131228) SILVER	Bajaj spare parts
56JK8M7B	PANEL BRAKE FRONT(JK131817) BLACK	Bajaj spare parts
56JK8N7B	PANEL REAR BRAKE(JA131205) BLACKPANEL RE	Bajaj spare parts
56JK8R7B	PANEL BRAKE REAR(JK131825)BLACK	Bajaj spare parts
56JKA133	WHEEL FRONT1.85X17(JK131059) WITH NEUTRA	Bajaj spare parts
56JKA17S	WHEEL FR 1.85X17(JK131059)SAT URBAN WHIT	Bajaj spare parts
56JKA233	WHEEL REAR1.85X17(JK131232) WITH NEUTRAL	Bajaj spare parts
56JKA27S	WHEEL RR 1.85X17(JK131232)SAT URBAN WHT	Bajaj spare parts
56JL0101	STEP PILLION ASY CO.LH MLT COLOR	Bajaj spare parts
56JL0201	STEP ASSY COMPT PILION RH	Bajaj spare parts
56JL023G	BLINKER BKT MOON LIGHT	Bajaj spare parts
56JL026B	ENGINE STAY LH MOON LIGHT SILVER	Bajaj spare parts
56JL036B	ENGINE STAY RH MOON LIGHT SILVER	Bajaj spare parts
56JL0401	CAP TANK (MOON LIGHT SILVER)	Bajaj spare parts
56JL0601	ENG STAY LH WITH BLACK COLOR	Bajaj spare parts
56JL0701	ENG STAY RH WITH BLACK COLOR	Bajaj spare parts
56JL09AM	K4 2CH FRAME JL111246 SLATE GREY+SAT BLK	Bajaj spare parts
56JL09C8	FRAME JL111246 S URBAN WHITE+SCHWARTZ BLK	Bajaj spare parts
56JL104R	SEAT COWL ASSY PASSION RED	Bajaj spare parts
56JL105N	SEAT COWL ASSY SAFFIRE BLUE	Bajaj spare parts

56JL105Y	SEAT COWL ASSY METALLIC WHITE	Bajaj spare parts
56JL10X3	SEAT COWL ASSY EBONY BLACK	Bajaj spare parts
56JL144R	SIDE MASK LH PASSION RED	Bajaj spare parts
56JL145N	SIDE MASK LH SAFFIRE BLUE	Bajaj spare parts
56JL14X3	SIDE MASK LH EBONY BLACK	Bajaj spare parts
56JL154R	SIDE MASK RH PASSION RED	Bajaj spare parts
56JL155N	SIDE MASK RH SAFFIRE BLUE	Bajaj spare parts
56JL15X3	SIDE MASK RH EBONY BLACK	Bajaj spare parts
56JL184X	STEP PILLION LH JL113014 SATIN BLACK	Bajaj spare parts
56JL194X	STEP PILLION RH JL113016 SATIN BLACK	Bajaj spare parts
56JL1R42	TANK COVER TOP JL171825 PEARL MET WHITE	Bajaj spare parts
56JL1W3V	SF PAINTED MAGNETO COVER ASSLY	Bajaj spare parts
56JL1X3V	PAINTED PART CAP OIL FILTER JL571001	Bajaj spare parts
56JL1X4X	CAP OIL FILTER JL571001 SATIN BLACK	Bajaj spare parts
56JL2042	JL TANK COVER LH METALLIC WHITEMATT PEW	Bajaj spare parts
56JL2045	JL TANK COVER LH P=RED MT PEWTER GRE	Bajaj spare parts
56JL2046	JL TANK COVER LH SP. BLACK MT PEWTER G	Bajaj spare parts
56JL204K	TANK COVER SIDE LH PLASMA BLUE+SA BLACK	Bajaj spare parts
56JL204R	TANK COVER SIDE LH PASSION RED	Bajaj spare parts
56JL205Y	TANK COVER SIDE LH METALLIC WHITE	Bajaj spare parts
56JL20X3	TANK COVER SIDE LH EBONY BLACK	Bajaj spare parts
56JL2142	JL TANK COVER RH METALLIC WHITE MATT P	Bajaj spare parts
56JL2145	JL TANK COVER RH P RED MT PEWTER GREY	Bajaj spare parts
56JL2146	JL TANK COVER RH SPARKLE BLACK MATT PE	Bajaj spare parts
56JL214R	TANK COVER SIDE RH PASSION RED	Bajaj spare parts
56JL215N	TANK COVER SIDE RH SAFFIRE BLUE	Bajaj spare parts
56JL215Y	TANK COVER SIDE RH METALLIC WHITE	Bajaj spare parts
56JL21X3	TANK COVER SIDE RH EBONY BLACK	Bajaj spare parts
56JL2217	TANK COVER TOP FIERY ORANGE+SATIN BLACK	Bajaj spare parts
56JL2218	TANK COVER TOP BEACH BLUE+SATIN BLACK	Bajaj spare parts
56JL2242	TANK COVER TOP PEARL MET WHITE+SA BLACK	Bajaj spare parts
56JL224R	TANK COVER TOP K16A PASSION RED	Bajaj spare parts
56JL225N	TANK COVER TOP K16A SAFFIRE BLUE	Bajaj spare parts
56JL225Y	JL TANK COVER TOP METALLIC WHITE	Bajaj spare parts
56JL227T	TANK COVER TOP JL171825 EBONY BLACK	Bajaj spare parts
56JL228W	TANK COVER TOP JL171825 PEWTR GREY+S BLK	Bajaj spare parts
56JL22C4	TANK COVER TOP JL171825 BURNT RED+SA BLK	Bajaj spare parts
56JL22C7	TANK COVER TOP JL171825 PLASMA BL+SA BLK	Bajaj spare parts
56JL22X3	TANK COVER TOP EBONY BLACK	Bajaj spare parts
56JL244X	SHROUD INNER LH JL181227 SATIN BLACK	Bajaj spare parts
56JL254X	SHROUD INNER RH JL181230 SATIN BLACK	Bajaj spare parts
56JL2Z7S	FRONT WHEEL JL131004 SATIN URBAN WHITE	Bajaj spare parts
56JL315X	HANDLE HOLDER LH STOIC BLACK	Bajaj spare parts
56JL325X	HANDLE HOLDER RH STOIC BLACK	Bajaj spare parts
56JL335X	UPPER BRACKET STOIC BLACK	Bajaj spare parts

56JL3831	JL BELLY PAN LH SPARKLE BLACK	Bajaj spare parts
56JL384R	BELLY PAN LH K4 UG PASSION RED	Bajaj spare parts
56JL385Y	JL BELLY PAN LH METALLIC WHITE	Bajaj spare parts
56JL386T	BELLY PAN LH K4 UG BRIGHT YELLOW	Bajaj spare parts
56JL3931	JL BELLY PAN RH SPARKLE BLACK	Bajaj spare parts
56JL394R	BELLY PAN RH K4 UG PASSION RED	Bajaj spare parts
56JL395Y	JL BELLY PAN RH METAALIC WHITE	Bajaj spare parts
56JL396T	BELLY PAN RH K4 UG BRIGHT YELLOW	Bajaj spare parts
56JL3S4X	STEP RIDER LH JL113009 SATIN BLACK	Bajaj spare parts
56JL3X1Y	JL HOLDER STEP LH SLATE GREY	Bajaj spare parts
56JL3X4X	STEP HOLDER LH (JL113057) SATIN BLACK	Bajaj spare parts
56JL3X6B	HOLDER STEP LH (JL113057)MOON LIGHT SILV	Bajaj spare parts
56JL3Y1Y	JL HOLDER STEP RH SLATE GREY	Bajaj spare parts
56JL3Y4X	STEP HOLDER RH (JL113002) SATIN BLACK	Bajaj spare parts
56JL3Y6B	HOLDER STEP RH(JL113002) MOON LIGHT SILV	Bajaj spare parts
56JL4J1Y	JL STEP HOLDER PILLION SLATE GREY	Bajaj spare parts
56JL4J4X	STEP HOLDER PILLON LH JL113013 SATIN BLK	Bajaj spare parts
56JL4J6B	STEP HOLDER- PILLION LH MOON LIGHT SILV	Bajaj spare parts
56JL4K1Y	JL STEP HOLDER PILLION RH SLATE GREY	Bajaj spare parts
56JL4K4X	STEP HOLDER PILLON RH JL113015 SATIN BLK	Bajaj spare parts
56JL4K6B	STEP HOLDER - PILLION RH MOON LIGHT SI	Bajaj spare parts
56JL4L1Y	JL FLAP HOLDER LH SLATE GREY	Bajaj spare parts
56JL4L4X	FLAP HOLDER LH JL113026 SATIN BLACK	Bajaj spare parts
56JL4L6B	FLAP HOLDER LH MOON LIGHT SLIVER	Bajaj spare parts
56JL4M1Y	JL FLAP HOLDER RH SLATE GREY	Bajaj spare parts
56JL4M4X	FLAP HOLDER RH JL113027 SATIN BLACK	Bajaj spare parts
56JL4M6B	JL FLAP HOLDER RH MOON LIGHT SILVER	Bajaj spare parts
56JL4S6B	HOLDER STEP LH (JL113034) MOON LIGHT SIL	Bajaj spare parts
56JL5F1Y	"STEP HOLDER RH-K16A, SLATE GRAY"	Bajaj spare parts
56JL5F4X	STEP HOLDER RH JL113060 SATIN BLACK	Bajaj spare parts
56JL5F6B	HOLDER STEP RH (JL113060)MOON LIGHT SILV	Bajaj spare parts
56JL664X	SIDE FAIRING REAR RH K16A SATIN	Bajaj spare parts
56JL6F4X	BRACKET R BLINKER MTG JL113800 SATIN BLK	Bajaj spare parts
56JL8U7S	REAR WHEEL JL131209 SATIN URBAN WHITE	Bajaj spare parts
56JP0231	ENGINE HANGER LH MAT BLACK KT19	Bajaj spare parts
56JP024U	ENGINE HANGER LH ALUMINIUM SILVER KT09	Bajaj spare parts
56JP0331	ENGINE HANGER RH MAT BLACK KT19	Bajaj spare parts
56JP034U	ENGINE HANGER RH ALUMINIUM SILVER KT09	Bajaj spare parts
56JP051T	DUKE MY22 JP181400FR FENDR ELE-ORNG GLOS	Bajaj spare parts
56JP0544	DUKE 200 FRONT FENDER CERAMIC WHITE	Bajaj spare parts
56JP055S	KTM DUKE MY17 FRONT FENDER WHITE	Bajaj spare parts
56JP0581	DUKE250 FRT.FENDERJP181400 DARK GALV MAT	Bajaj spare parts
56JP058S	DUKEJP181400 FR FENDER LIQUID METAL MATT	Bajaj spare parts
56JP05A9	FRONT FENDER JP181400 SIL.METALIC MATT	Bajaj spare parts
56JP05X3	DUKE FR.FENDER EB BLK	Bajaj spare parts



56JP1044	DUKE390 SEATCOWL UP RHJP181007 CER WHITE	Bajaj spare parts
56JP105S	KTM DUKE MY17 SEAT COWL UPPER RH WHITE	Bajaj spare parts
56JP1144	DUKE390 SEATCOWL UP RHJP181007 CER WHITE	Bajaj spare parts
56JP115S	KTM DUKE MY17 SEAT COWL UPPER LH WHITE	Bajaj spare parts
56JP141T	KTM DUKE MY17 SIDE MASK LH EB ORANGE	Bajaj spare parts
56JP14X3	KTM SIDE MASK LH EB BLK	Bajaj spare parts
56JP151T	KTM DUKE MY17 SIDE MASK RH EB ORANGE	Bajaj spare parts
56JP15X3	KTM SIDE MASK RH BLK	Bajaj spare parts
56JP201T	KTM DUKE MY17 TANK COVER LH EB ORANGE	Bajaj spare parts
56JP211T	KTM DUKE MY17 TANK COVER RH EB ORANGE	Bajaj spare parts
56JP2X44	MY17 EVAP TANK JP171001 CERAMIC WHITE	Bajaj spare parts
56JP2X8S	MY22 EVAP TANK JP171001 LIQUID METAL MATT	Bajaj spare parts
56JP4B1T	DUKE SIDE MASK LH	Bajaj spare parts
56JP4B44	SIDE MASK JP181281 LH CE WHT GLOSS	Bajaj spare parts
56JP4BX3	Side Mask Bulb LH ebony black	Bajaj spare parts
56JP4C1T	DUKE SIDE MASK RH	Bajaj spare parts
56JP4C44	SIDEMASK WHT	Bajaj spare parts
56JP4CX3	DUKE SIDE MASK RH	Bajaj spare parts
56JP4D1T	DUKE MASK BULB HL EB ORANGE	Bajaj spare parts
56JP4D81	MIDDLE MASK JP181284 DARK GALAVANO MATT	Bajaj spare parts
56JP4DA9	MIDDLE MASK SILVMETMAT JP181284 DUKE 250	Bajaj spare parts
56JP4DX3	DUKE MASK BULB HL EB BLACK	Bajaj spare parts
56JP601T	FRONT WHEEL EB ORANGE DUKE/RC MY17	Bajaj spare parts
56JP60Z3	FRONT WHEEL BLACK MY17 DUKE/RC	Bajaj spare parts
56JP611T	REAR WHEEL EB ORANGE DUKE/RC MY17	Bajaj spare parts
56JP61Z3	REAR WHEEL BLACK MY17 DUKE / RC	Bajaj spare parts
56JPB131	ENGINE HANGER LH (JP113402) BLACK GLOSSY	Bajaj spare parts
56JPB231	ENGINE HANGER RH (JP113403) BLACK GLOSSY	Bajaj spare parts
56JPC243	MASK JP181254 LH FR FRNG ELE-ORNG MATT	Bajaj spare parts
56JPC343	MASK JP181255 RH FR FRNG ELE-ORNG MATT	Bajaj spare parts
56JPE544	PROTECTOR FORK OUTER LHJP181419CER WHITE	Bajaj spare parts
56JPE585	FORK PROTR OUT LHJP181419 D GALV MATT KC	Bajaj spare parts
56JPE5X3	PROTECTOR FORK OUTER LHJP181419 EB BLACK	Bajaj spare parts
56JPE644	PROTECTOR FORK OUTER RHJP181420CER WHITE	Bajaj spare parts
56JPE685	FORK PROTR OUT RHJP181420 D GALV MATT KC	Bajaj spare parts
56JPE6X3	PROTECTOR FORK OUTER RHJP181420 EB BLACK	Bajaj spare parts
56JR1857	STEP PILLION LH JL113014 SATIN SILVER	Bajaj spare parts
56JR1957	STEP PILLION RH JL113016 SATIN SILVER	Bajaj spare parts
56JR1B1Y	GRAB HANDLE JR231403 MATT SLAT GREY	Bajaj spare parts
56JR33Y9	BRACKET UPPER JR151021 MATT SPRINT BLACK	Bajaj spare parts
56JR3S4X	STEP RIDER LH JF113025 SATIN BLACK	Bajaj spare parts
56JR3S57	STEP RIDER LH JF113025 SATIN SILVER	Bajaj spare parts
56JR3T4X	STEP RIDER RH JF113026 SATIN BLACK	Bajaj spare parts
56JR3T57	STEP RIDER RH JF113026 SATIN SILVER	Bajaj spare parts
56JR3X4X	K17 HOLDER STEP LH JR113039 SATIN BLACK	Bajaj spare parts

56JR3X57	HOLDER STEP LH JR113039 SATIN SILVER	Bajaj spare parts
56JR3Y4X	HOLDER STEP RH JR113041 SATIN BLACK	Bajaj spare parts
56JR3Y57	HOLDER STEP RH JR113041 SATIN SILVER	Bajaj spare parts
56JR4J4X	HOLDER STEP PILION LH JR113048SATIN BLK	Bajaj spare parts
56JR4J57	HOLDER STEP PILION LH JR113048SATIN SILV	Bajaj spare parts
56JR4K4X	HOLDER STEP PILION RH JR113050SATIN BLK	Bajaj spare parts
56JR4K57	HOLDER STEP PILION RH JR113050SATIN SILV	Bajaj spare parts
56JR4S4X	HOLDER STEP PILION RH JR113092SATIN BLK	Bajaj spare parts
56JR4S57	HOLDER STP PILL RH JR113092 SATIN SILVER	Bajaj spare parts
56JR5U1Y	GRAB HANDLE LH JR231413 MATT SLAT GREY	Bajaj spare parts
56JR5U4U	GRAB HANDLE LH JR231405 MATT ALUM SILVER	Bajaj spare parts
56JR5UY9	K17 GRAB HANDLE LH JR231405 SPR MATT BLK	Bajaj spare parts
56JR5V1Y	GRAB HANDLE RH JR231414 MATT SLAT GREY	Bajaj spare parts
56JR5V4U	GRAB HANDLE RH JR231406 MATT ALUM SILVER	Bajaj spare parts
56JR5VY9	K17 GRAB HANDLE RH JR231406 SPR MATT BLK	Bajaj spare parts
56JR9A1Y	K17 FRONT WHEEL JR131040 MATT SLATE GREY	Bajaj spare parts
56JR9A4X	K17 FRONT WHEEL JR131040 SATIN BLACK	Bajaj spare parts
56JR9B1Y	K17 REAR WHEEL JR131246 MATT SLATE GREY	Bajaj spare parts
56JR9B4X	K17 REAR WHEEL JR131246 SATIN BLACK	Bajaj spare parts
56JR9J33	K17B HANDLEBAR TUBE JR151065 MATT BLACK	Bajaj spare parts
56JR9J4X	HANDLEBAR JR151053 SATIN BLACK	Bajaj spare parts
56JR9J57	HANDLE BAR JR151020 SATIN SILVER	Bajaj spare parts
56JR9TY9	HOLDER HANDLE UPERJR151024 MAT SPRNT BLK	Bajaj spare parts
56JR9UY9	HOLDER HANDLE LOWRJR151025 MAT SPRNT BLK	Bajaj spare parts
56JR9XY9	BRACKET UPPER JR151015 MATT SPRINT BLK	Bajaj spare parts
56JRA8Y9	BRACKET UPPER JR151054 MATT SPRNT BLK	Bajaj spare parts
56JRA9X3	CARRIER MASK JR181273 GLOSS BLACK	Bajaj spare parts
56JRD91Y	CAP FORK JR151041 MATT SLAT GREY	Bajaj spare parts
56JRD94X	CAP FORK TOP BOLT SATIN BLACK	Bajaj spare parts
56JRJ74X	COVER SIDE RR LH JR181331 SATIN BLACK	Bajaj spare parts
56JRJ84X	COVER SIDE RR RH JR181333 SATIN BLACK	Bajaj spare parts
56JRL44X	STRUCTUR PLAT NUM REAR JR232807SATIN BLK	Bajaj spare parts
56JRL533	CAP TUBE ARM SWING JR122039 MATT BLACK	Bajaj spare parts
56JRL6Y9	HOLDER HANDLE LH JR151012MATT SPRNT BLK	Bajaj spare parts
56JRL7Y9	HOLDER HANDLE RH JR151014MATT SPRNT BLK	Bajaj spare parts
56JRP3E2	FORK CAP TOP JR151041 MATTE DEEP COPPER	Bajaj spare parts
56JRU2Y9	HOLDER HANDLE LH JR151057MATT SPRNT BLK	Bajaj spare parts
56JRU3Y9	HOLDER HANDLE LH JR151057MATT SPRNT BLK	Bajaj spare parts
56JRU757	HOLDER STEP LH JR113037 SATIN SILVER	Bajaj spare parts
56JRU857	HOLDER STEP RH JR113038 SATIN SILVER	Bajaj spare parts
56JRU957	HOLDER STEP PILLION LH JR113052 SAT SILV	Bajaj spare parts
56JRV157	HOLDER STEP PILLION RH JR113054 SAT SILV	Bajaj spare parts
56JRV5Y9	BRACKET UPPER JR151001 MATT SPRNT BLK	Bajaj spare parts
56JRV657	STEP RIDER RH JR113120 SATIN SILVER	Bajaj spare parts
56JRX1X9	MANIFOLD INTAKE PD581445 BLK SEMI GLOS Y	Bajaj spare parts

56JU0233	STAY HANGER LH JU113415 BM BLACK MATT PC	Bajaj spare parts
56JU024U	STAY HANGER LH JU113415 BM ALUMINIUM SIL	Bajaj spare parts
56JU0333	STAY HANGER RH JU113416 BM BLACK MATT PC	Bajaj spare parts
56JU034U	STAY HANGER RH JU113416 BM ALUMINIUM SIL	Bajaj spare parts
56JU1005	SEAT COWL RH JU181006 BEIGE GREY MATT	Bajaj spare parts
56JU1008	SEAT COWL RH JU18006 DARK SILV MET GLOSS	Bajaj spare parts
56JU1105	SEAT COWL LH JU181005 BEIGE GREY MATT	Bajaj spare parts
56JU1108	SEAT COWL LH JU18005 DARK SILV MET GLOSS	Bajaj spare parts
56JU141T	DUKE 200 SIDE MASK LH ELEC ORANGE	Bajaj spare parts
56JU151T	DUKE 200 SIDE MASK RH ELEC ORANGE	Bajaj spare parts
56JU2205	COVER TOP JU171041 BEIGE GREY MATT	Bajaj spare parts
56JU2208	COVER TOP JU171041 DARK SILVER MET GLOSS	Bajaj spare parts
56JU2272	HUSKVERNA COVER TOP-ADVENT.SILVER GLOSS	Bajaj spare parts
56JU2282	HUSKVERNA COVER TOP-DARK GALVANO GLOSSY	Bajaj spare parts
56JU334U	BRACKET UPPER JU151029 ALUMINIUM SILVER	Bajaj spare parts
56JU3XD1	S HOLD RIDER LHJU113026 BL MATT ANODIZED	Bajaj spare parts
56JU3YD1	S HOLD RIDER RHJU113027 BL MATT ANODIZED	Bajaj spare parts
56JU5A33	BRACKET UPPER JU151029 BLACK MATT PC	Bajaj spare parts
56JU601T	FRONT WHEEL JU 200 DOM EB OR	Bajaj spare parts
56JU611T	REAR WHEEL JU 200 DOM. EB OR	Bajaj spare parts
56JUB131	STAY HANGER LH JU113415 BLACK GLOSSY	Bajaj spare parts
56JUB231	STAY HANGER RH JU113416 BLACK GLOSSY	Bajaj spare parts
56JY05X3	RC FRONT FENDER EBONY BLACK	Bajaj spare parts
56JY144X	SIDE MASK LH SATIN BLACK	Bajaj spare parts
56JY154X	SIDE MASK RH SATIN BLACK	Bajaj spare parts
56JY1K4X	JY SATIN BLACK HUGGER ENVELOP HEAVY DUTY	Bajaj spare parts
56JY221T	RC TANK COVER TOP ELECTRONIC ORANGE	Bajaj spare parts
56JY225S	RC TANK COVER TOP KTM WHITE	Bajaj spare parts
56JY2281	RC TANK COVER JY171002 DARK GALVANO MATT	Bajaj spare parts
56JY341T	RC FAIRING OUTER LH ELECTRONIC ORANGE	Bajaj spare parts
56JY3444	RC OUTER FAIRING LHJY181222 CERAMIC WHIT	Bajaj spare parts
56JY34X3	RC FAIRING OUTER LH EBONY BLACK	Bajaj spare parts
56JY351T	RC FAIRING OUTER RH ELECTRONIC ORANGE	Bajaj spare parts
56JY3544	RC OUTER FAIRING RHJY181223 CERAMIC WHIT	Bajaj spare parts
56JY355S	FAIRING OUTER RH KTM WHITE FOR KT-06	Bajaj spare parts
56JY35X3	RC FAIRING OUTER RH EBONY BLACK	Bajaj spare parts
56JY385S	RC BELLY PAN LH WHITE	Bajaj spare parts
56JY38X3	RC BELLY PAN RH	Bajaj spare parts
56JY395S	RC BELLY PAN RH WHITE	Bajaj spare parts
56JY39X3	RC BELLY PAN LH	Bajaj spare parts
56JY3X33	STEP HOLDER LH (JY113035) BLACK MATT	Bajaj spare parts
56JY3Y33	STEP HOLDER RH (JY113037) BLACK MATT	Bajaj spare parts
56JY401T	RC UNDER TRAY BOTTOM ELECTRONIC ORANGE	Bajaj spare parts
56JY4044	RC UNDER TRAY BOTTOMJY181211 CERAM WHITE	Bajaj spare parts
56JY405S	UNDER TRAY BOTTOM KTM	Bajaj spare parts

56JY406A	ANTHRACITE BLACK MATT	Bajaj spare parts
56JY434X	FAIRING INNER LH SATIN BLACK	Bajaj spare parts
56JY4381	RC INNER FAIRING LHJY181220 DRK GALV MAT	Bajaj spare parts
56JY43X3	RC FAIRING INNER LH EBONY BLACK	Bajaj spare parts
56JY444X	FAIRING INNER RH SATIN BLACK	Bajaj spare parts
56JY4481	RC INNER FAIRING RHJY181221 DRK GALV MAT	Bajaj spare parts
56JY44X3	RC FAIRING INNER RH EBONY BLACK	Bajaj spare parts
56JY461T	RC COVER BLINKER LH ELECTRONIC ORANGE	Bajaj spare parts
56JY4644	RC COV BLINKER LH JY181266 CERAMIC WHITE	Bajaj spare parts
56JY465S	COVER BLINKER FRONT LH IN KTM WHITE	Bajaj spare parts
56JY4681	BLINKER COV FRT LHJY181266 DARK GAL MATT	Bajaj spare parts
56JY46X3	RC COVER BLINKER LH EBONY BLACK	Bajaj spare parts
56JY471T	RC COVER BLINKER RH ELECTRONIC ORANGE	Bajaj spare parts
56JY4744	RC COV BLINKER RH JY181267 CERAMIC WHITE	Bajaj spare parts
56JY475S	COVER BLINKER FRONT RH IN KTM WHITE	Bajaj spare parts
56JY4781	BLINKER COV FRT RHJY181267 DARK GAL MATT	Bajaj spare parts
56JY47X3	RC BLINKER COVER RH EBONY BLACK	Bajaj spare parts
56JY4J33	STEP HOLDER PILLON LH JY113039 BLACK MAT	Bajaj spare parts
56JY4K33	STEP HOLDER PILLON RH JY113041 BLACK MAT	Bajaj spare parts
56JY4W33	TRIPPLE CLAMP UPPER JY151042 BLACK MATT	Bajaj spare parts
56JY534X	COVER BLINKER FR.LH( UK VERSION)	Bajaj spare parts
56JY544X	COVER BLINKER FR.RH( UK VERSION)	Bajaj spare parts
56JY5D28	CYL. BLOCK (JY521021) SATIN BLACK	Bajaj spare parts
56JY5D6A	CYL. BLOCK (JY521021) ANTHRASITE BLACK	Bajaj spare parts
56JY5U31	GRAB HANDLE LH JY231407 BLACK GLOSS	Bajaj spare parts
56JY5U33	GRAB HANDLE LH JY231407 BLACK MATT	Bajaj spare parts
56JY5V31	GRAB HANDLE RH JY231408 BLACK GLOSS	Bajaj spare parts
56JY5V33	GRAB HANDLE RH JY231408 BLACK MATT	Bajaj spare parts
56JYA628	CYL. BLOCK JY521012 SATIN BLACK	Bajaj spare parts
56JYG186	FENDER FRONT JY181419 ATLANTIC BLUE MATT	Bajaj spare parts
56JYG1X3	FENDER FRONT JY181419 EBONY BLACK	Bajaj spare parts
56JYG343	SEAT COWL TOP JY181780 EB ORANGE MATT	Bajaj spare parts
56JYG344	SEAT COWL TOP JY181353 CERMI WHITE GLOSS	Bajaj spare parts
56JYG372	SEAT COWL TOP JY181353 ADV SILVER GLOSS	Bajaj spare parts
56JYG386	SEAT COWL TOPJY181353 ATLANTIC BLUE MATT	Bajaj spare parts
56JYG391	SEAT COWL TOP JY181353 CERMI WHITE MATT	Bajaj spare parts
56JYG392	SEAT COWL TOP JY181353 ADV SILVER MATT	Bajaj spare parts
56JYG3X3	SEAT COWL TOP JY181353 EBONY BLACK	Bajaj spare parts
56JYL261	STR FAIRING MIDDLE JY181386 SPECKLE BLK	Bajaj spare parts
56JZ0123	TANK FUEL D 102 AFTER PRIMER PAINTING	Bajaj spare parts
56JZ053E	PAINTED PART FR FENDER D125 ELE BLUE	Bajaj spare parts
56JZ05X3	PAINTED PART FRONT FENDER D106A EB BLK	Bajaj spare parts
56JZ1X3N	CAP FILTER B104E GRI GRAY (PF541254)	Bajaj spare parts
56JZ2323	FUEL TANK D106A HF PRIMER	Bajaj spare parts
56JZ2Y7D	SILVER WHEEL FRONT 1.4X17 DRUM	Bajaj spare parts

56JZ2Z1Y	WHEEL FRONT MT JZ131064 MATT SLAT GREY	Bajaj spare parts
56JZ2Z7D	SILVER WHEEL FRONT 1.4X17-DISC	Bajaj spare parts
56JZ3233	HANDLE HOLDER(DS181006)Sprint Matt Black	Bajaj spare parts
56JZ3A1Y	WHEEL REAR MT JZ131294 MATT SLAT GREY	Bajaj spare parts
56JZ3A7D	SILVER WHEEL 1.6X17130 DR REAR	Bajaj spare parts
56JZ607B	WHEEL FRONT DRUM-1.4X17-(JZ131042)BLACK	Bajaj spare parts
56JZ611Y	WHEEL REAR MT JZ131271 MATT SLAT GREY	Bajaj spare parts
56JZ6A33	HOLDER ASSLY HANDLE LOW(FD181031)SPT BLK	Bajaj spare parts
56JZ6J3F	FRONT FENDER(JZ181475)FLAME RED	Bajaj spare parts
56JZ6J5N	FRONT FENDER(JZ181475) SAFFIRE BLUE	Bajaj spare parts
56JZ6JX3	FRONT FENDER(JZ181475) EBONY BLACK	Bajaj spare parts
56JZ8M7B	PANEL BRAKE FRONT(PF131616) BLACK	Bajaj spare parts
56PA0123	FUELTANK DISCO M 94 AFTER PRIMER	Bajaj spare parts
56PA0223	FUEL TANK D105A PRIMER	Bajaj spare parts
56PA053E	PAINTED PART FRONT FENDER D125M ELE	Bajaj spare parts
56PA055N	FRONT FENDOR (JB181417) SAFFIRE BLUE	Bajaj spare parts
56PA2323	FUEL TANK D125M WITH PRIMER	Bajaj spare parts
56PA2Y3Q	WHEEL FR MT 1.85X17 DRUM(PA131052)SILVER	Bajaj spare parts
56PA6JX3	FENDER FRONT(JZ181472) EBONY BLACK	Bajaj spare parts
56PD069C	PD UG REAR FENDER IN TROPICAL NIGHT	Bajaj spare parts
56PD06P6	AVENGER FENDER REAR GOLDEN BEIGE	Bajaj spare parts
56PD06W3	PD UG REAR FENDER IN CLASSIC WHITE (W3)	Bajaj spare parts
56PD06X3	REAR FENDER ASSLY EB BLACK STREET 220 UG	Bajaj spare parts
56PD1X1Y	CAP FILTER OIL (PD571011) - M SLATE GREY	Bajaj spare parts
56PD2X23	PD BS IV FUEL TANK - PRIMERED	Bajaj spare parts
56PD4E6B	COVER MOTOR STARTER DH102309 MOON LIGHT	Bajaj spare parts
56PD4H9C	PD UG FRT. FENDER IN TROPICAL NIGHT	Bajaj spare parts
56PD4HW3	PD UG FRT. FENDER IN CLASSIC WHITE (W3)	Bajaj spare parts
56PD4HX3	PD SOFT MOUNTING FENDER EBONY BLACK	Bajaj spare parts
56PD6Q6B	ENG ASLY PD501043 MOON LIGHT SILVR A104A	Bajaj spare parts
56PD6Q7B	ENGINE ASSLY PD501043 BLACK COLOUR A105B	Bajaj spare parts
56PD7G33	PD UG HOLDER FORK UPPER IN MATTE BLACK	Bajaj spare parts
56PD9R6B	ENGINE ASSLY AVENGER PD501066 - CRUISE	Bajaj spare parts
56PDP867	Eng Assly K17E PD501030 - Slick Black	Bajaj spare parts
56PF053B	FRONT FENDOR E BLK	Bajaj spare parts
56PF053E	PAINTED PART FRONT FENDER E BLUE	Bajaj spare parts
56PF1T4R	COWLING PAINTED	Bajaj spare parts
56PF1X67	SLICK BLACK CAP FILTER(PF541254)	Bajaj spare parts
56PF772V	FRONT FENDER (PF181420) C. WINE RED	Bajaj spare parts
56PF773F	PAINTED PART FR FEN P100ES/KS FLAME RED	Bajaj spare parts
56PF8M3Q	PANEL ASSLY BRAKE FR. SILVER (PF131616)	Bajaj spare parts
56PF8N3Q	PANEL ASSLY BRAKE RR(JA131205) SILVER	Bajaj spare parts
56PFC723	PAINTED FUELTANK PL 110 ABS PRIMER	Bajaj spare parts
59010005	SCREW M4 X0.7X15	Bajaj spare parts
59010007	Screw	Bajaj spare parts

59010010	SCREW CSUNK FILLER	Bajaj spare parts
59010013	SCREW MUSHROOM HEAD	Bajaj spare parts
59020001	SCREW SELF TAPPING 3.5X9.	Bajaj spare parts
59040001	BOLT HEX. M6X16L	Bajaj spare parts
59040002	BOLT HEX. M6X25L	Bajaj spare parts
59040003	BOLT FLANGE M8X30L	Bajaj spare parts
59040005	BOLT WITH WASHER	Bajaj spare parts
59040006	NUT FORK	Bajaj spare parts
59040017	BOLT FLANGED M8	Bajaj spare parts
59040023	BOLT HEX WITH FLANGE	Bajaj spare parts
59040026	BOLT FLANGE HEXAGONA	Bajaj spare parts
59040029	BOLT HEX FLANGE	Bajaj spare parts
59040038	BOLT	Bajaj spare parts
59040040	BOLT STEPED	Bajaj spare parts
59040041	BOLT FLANGED-M8X1.25XL 185XBLACK	Bajaj spare parts
59040042	BOLT FLANGE FOR K3 E	Bajaj spare parts
59040043	BOLT HEX SOCKET HEAD	Bajaj spare parts
59040048	BOLT FLANGE M8X1.25	Bajaj spare parts
59040050	BOLT FLANGE M8X1X148L	Bajaj spare parts
59050002	STUD M10 ( BOLT STUD CYLI	Bajaj spare parts
59050008	STUD M10BOLT CYL	Bajaj spare parts
59100002	SPRING DOWEL SLEEVE	Bajaj spare parts
59110002	WASHER PLAIN	Bajaj spare parts
59110004	WASHER COPPER PLATED	Bajaj spare parts
59110008	WASHER	Bajaj spare parts
59120003	WASHER BELLVILLE	Bajaj spare parts
59150003	NUT U M12	Bajaj spare parts
59150005	NUT FLANGED M8	Bajaj spare parts
59150012	NUT NYLOC M10 X1.	Bajaj spare parts
59150014	NUT FLANGE	Bajaj spare parts
59170007	CIRCLIP EXTERNAL MFV	Bajaj spare parts
59190002	SEAL OIL DIA. 50X10	Bajaj spare parts
59200006	BEARING BALL	Bajaj spare parts
59200007	BEARING NEEDLE	Bajaj spare parts
59200012	BEARING NEEDDLE S	Bajaj spare parts
59200027	BEARING HK1516(15*21*16	Bajaj spare parts
59200028	BALANCER RH BEARING 6204N	Bajaj spare parts
59200029	BALANCER LH BEARING 6204	Bajaj spare parts
59200032	BEARING BALL 6204 Z	Bajaj spare parts
59210006	RING O	Bajaj spare parts
59210012	RING O BOTTOM SEAL	Bajaj spare parts
59210013	RING O MFV VANAZ LPG	Bajaj spare parts
59210015	RING O MFV SOLENOID	Bajaj spare parts
59210016	O_RING MFV-LPG KIT	Bajaj spare parts
59210017	RING O M/S LPG KIT	Bajaj spare parts

59210019	RING O	Bajaj spare parts
59210023	RING O	Bajaj spare parts
59210024	RING O	Bajaj spare parts
59210028	RING O	Bajaj spare parts
60111405	CABLE TIE LK-RLSBL 4.5 1.5 150 B	Bajaj spare parts
60111415	CABLE TIE LOCK 5 1.7 160 N-66 B	Bajaj spare parts
60111417	CLIP PSTVE HT-27.4 15 D15 PA66 B	Bajaj spare parts
60111418	CABLE TIE LK-RLSBL 4.6191 PA66 B	Bajaj spare parts
60111420	CABLE TIE LOCK 4.8 1.2 160 PA66 B	Bajaj spare parts
60111528	FUSE 10A MINI	Bajaj spare parts
60111530	FUSE 30A MINI	Bajaj spare parts
60111534	FUSE 15A GLASS	Bajaj spare parts
60111546	FUSE BLADE BIG 5A	Bajaj spare parts
71111618	PRINTED PREVENTIVE MAIN. ENCYCLOPEDIA	Bajaj spare parts
71111717	KTM 390 Spare parts Catalogue	Bajaj spare parts
71111769	SPARE PARTS HAND BOOK	Bajaj spare parts
71111881	SPARE PARTS CATALOGUE K8	Bajaj spare parts
71112105	SUGAM SERVICE-RE 2S	Bajaj spare parts
71112106	Service Coupon-RE 4S	Bajaj spare parts
71112107	Service Cop-RE Diesal	Bajaj spare parts
71112108	Service Coupon-RE 2S	Bajaj spare parts
71112109	Service Coupon-RE 4S	Bajaj spare parts
71112110	Service Copu-RE Diesel	Bajaj spare parts
71112147	SPARE PARTS CATALOGUE PLATINA 100ES & K	Bajaj spare parts
71112164	SPARE PARTS CATALOGUE CT 100 BSIV	Bajaj spare parts
71112198	SPARE PARTS CATALOGUE PULSAR 200 NS BSI	Bajaj spare parts
71112282	OWNERS MANUAL BAJAJ MAXIMA CRAGO	Bajaj spare parts
71112298	O.M.PULSAR 220-AUG15	Bajaj spare parts
71112317	SPC AVENGER 220 (A101) BS IV	Bajaj spare parts
71112320	SPARE PARTS CATALOGUE - AVENGER 150	Bajaj spare parts
71112390	OWNERS MANUAL BAJAJ MAXIMA CARGO CNG	Bajaj spare parts
71112414	SPARE PARTS CATALOGUE - V15 & V12 BS IV	Bajaj spare parts
71112504	BOOK KTM DUKE 200 SPC	Bajaj spare parts
71112505	KTM RC SPC	Bajaj spare parts
71112519	"SPC 4S COMPACT,MAXIMA C RL"	Bajaj spare parts
71112583	SPARE PARTS CATALOGUE PULSAR 180 BS IV	Bajaj spare parts
71112614	PRINTED O&M DOMINAR 400	Bajaj spare parts
71112653	DUKE 250_DUKE 390 MY 17 SPC	Bajaj spare parts
71112789	O.M. PULSAR 160	Bajaj spare parts
71112797	SPARE PART CATLOUGE_2S BS4	Bajaj spare parts
71112901	3 YEAR AMC BOOKLET PRINTED CV	Bajaj spare parts
76010937	LOCTITE L 638 BOTTL	Bajaj spare parts
82011001	CAN GLOSSY BLACK 300 COMPAIN	Bajaj spare parts
82011003	CAN ECO GREEN 300 T/UP COMPAIN	Bajaj spare parts
82011005	CAN GOLDEN YELLOW 300 T/UP COMPAIN	Bajaj spare parts

82011012	NEPTUNE BLUE TOUCHUP AEROSOL - 400 ML	Bajaj spare parts
82110773	SPRAY BOTTLE IN ARTIC WHITE	Bajaj spare parts
83010457	Chain Lube Spray 500 ML	Bajaj spare parts
83010496	OIL TRANSMISSION 75W80- 180 ML	Bajaj spare parts
83020473	GREASE PETAMO GHY441	Bajaj spare parts
83020605	THROTTLE BODY CLEANER-1000 ML	Bajaj spare parts
83020607	THROTTLE BODY CLEANING SOLVEN150	Bajaj spare parts
83020630	RE BGO POWER 10K BS6-CW (2 ltr Packs)	Bajaj spare parts
83020651	OIL TRANSMISION GEAR 9 FE 75W-80	Bajaj spare parts
AA101003	CRANKCASE CL.SIDE RE 4S	Bajaj spare parts
AA101009	BUSH GEAR PRIMARY	Bajaj spare parts
AA101013	GASKET BLOCK	Bajaj spare parts
AA101015	GUIDE CHAIN	Bajaj spare parts
AA101031	PINION PRIMARY	Bajaj spare parts
AA101033	CRANKSHAFT ASSY 4S PETR/C	Bajaj spare parts
AA101046	GEAR MULTIPLE	Bajaj spare parts
AA101048	SHAFT MAIN	Bajaj spare parts
AA101051	GEAR SPEED 2	Bajaj spare parts
AA101052	GEAR SPEED 3	Bajaj spare parts
AA101054	GUIDE GEAR SHIFTER	Bajaj spare parts
AA101055	WASHER THRUST GUIDE BUSH	Bajaj spare parts
AA101056	GEAR REVERSE CONTROL	Bajaj spare parts
AA101057	GEAR IDLER	Bajaj spare parts
AA101058	WASHER THRUST IDLER	Bajaj spare parts
AA101061	CUP GEAR SHIFTER	Bajaj spare parts
AA101063	HOUSING CLUTCH	Bajaj spare parts
AA101076	DIPSTICK CLUTCH COVER	Bajaj spare parts
AA101077	GASKET COVER CLUTCH	Bajaj spare parts
AA101084	GASKET SECTOR FLANGE	Bajaj spare parts
AA101108	GEAR SELECTOR	Bajaj spare parts
AA101116	SPROCKET CRANKSHAFT	Bajaj spare parts
AA101122	GEAR STARTER	Bajaj spare parts
AA101123	"SPRING PLATE UPPER"	Bajaj spare parts
AA101124	"SPRING PLATE LOWER"	Bajaj spare parts
AA101134	GUIDE CHAIN TENSIONR	Bajaj spare parts
AA101137	SHAFT ROCKER ARM	Bajaj spare parts
AA101138	PLUNGER OIL	Bajaj spare parts
AA101139	SPRING PLUNGER	Bajaj spare parts
AA101142	HOLDER CLUTCH	Bajaj spare parts
AA101143	PAD RUBBER	Bajaj spare parts
AA101145	BUSH GEAR STARTER	Bajaj spare parts
AA101150	COWLING CLUTCH SIDE RE 4S	Bajaj spare parts
AA101154	STRAINER OIL 4S PETR / C	Bajaj spare parts
AA101156	WASHER THRUST GEAR MULTI	Bajaj spare parts
AA101162	GASKET HEAD	Bajaj spare parts



AA101194	BRACKET FR MOUNTING	Bajaj spare parts
AA101207	HOUSING CLUTCH	Bajaj spare parts
AA101209	SPRING TORSIONAL	Bajaj spare parts
AA101210	PLATE FRICTION	Bajaj spare parts
AA101212	PIN SPRING TENSION	Bajaj spare parts
AA101213	COLLAR	Bajaj spare parts
AA101215	GUIDE SPRING	Bajaj spare parts
AA101216	SPRING CLUTCH	Bajaj spare parts
AA101220	GROMMET PICKUP	Bajaj spare parts
AA101221	TUBE	Bajaj spare parts
AA101226	TUBE BREATHER	Bajaj spare parts
AA101228	CAMSHAFT 4S PETR/CNG	Bajaj spare parts
AA101249	SPACER PAD HAND START	Bajaj spare parts
AA101258	COVER GR SHIFTER 4S PETR/	Bajaj spare parts
AA101260	FLANGE GEAR SHIFTER	Bajaj spare parts
AA101261	SECTOR WITH LEVER	Bajaj spare parts
AA101277	PIN LEVER SUPPORT HAND ST	Bajaj spare parts
AA101283	GASKET SILENCER	Bajaj spare parts
AA101286	GEAR ASSY SECTOR	Bajaj spare parts
AA101289	SPINDLE HANDSTART	Bajaj spare parts
AA101294	TUBE CONNECTING II	Bajaj spare parts
AA101295	BUSH DRIVE	Bajaj spare parts
AA101297	SUPPORT ASSEMBLY COMPLETE - HAND START	Bajaj spare parts
AA101328	GASKET CRANKCASE	Bajaj spare parts
AA101329	LEVER DRIVER SIDE	Bajaj spare parts
AA101334	RING PISTON SET 4S PETR	Bajaj spare parts
AA101345	KEY WOOD RUFF	Bajaj spare parts
AA101347	TUBE II CONNECTING	Bajaj spare parts
AA101364	SPRING CLUTCH	Bajaj spare parts
AA101370	CRANKCASE CASE 4S PETR /	Bajaj spare parts
AA101373	INTERNAL COWLING	Bajaj spare parts
AA101384	FAN CRANKSHAFT	Bajaj spare parts
AA101392	SHAFT MULTIPLE GEAR	Bajaj spare parts
AA101396	SPRING CLIP	Bajaj spare parts
AA101400	SPRING DAMPER A	Bajaj spare parts
AA101401	SPRING DAMPER B	Bajaj spare parts
AA101424	GEAR DRIVE OIL PUMP	Bajaj spare parts
AA101437	SCREW PRECOATED	Bajaj spare parts
AA101446	CYL BL.ASSY 3WH 4S	Bajaj spare parts
AA101447	PISTON ASSLY 3W4S	Bajaj spare parts
AA101448	RING PISTON SET RE 4S	Bajaj spare parts
AA101449	RING PISTON SET SPARES	Bajaj spare parts
AA101454	PISTON ASY SLIPPER	Bajaj spare parts
AA101455	RING PISTON SET	Bajaj spare parts
AA101460	PISTON ASY SLIPPER	Bajaj spare parts

AA101463	CRANKCASE ASY RE4S MITSUB	Bajaj spare parts
AA101466	COVER CLUTCH	Bajaj spare parts
AA101469	CLUTCH ASSY 4S PETR / CNG	Bajaj spare parts
AA101470	PLATE CLUTCH 4S PETR / CN	Bajaj spare parts
AA101471	WHEEL CLUTCH	Bajaj spare parts
AA101472	PLATE CLUTCH	Bajaj spare parts
AA101473	HUB CLUTCH	Bajaj spare parts
AA101474	HOLDER CLUTCH	Bajaj spare parts
AA101475	BOLT BANJO	Bajaj spare parts
AA101478	PLATE FRICTION	Bajaj spare parts
AA101479	RELEASE CLUTCH OUTER	Bajaj spare parts
AA101481	CABLE INR CLH RLE	Bajaj spare parts
AA101499	KIT CONNECT ROD RE4S	Bajaj spare parts
AA101512	COWLING INTERNALRE 4S	Bajaj spare parts
AA101555	GEAR REVERSE CONTRO	Bajaj spare parts
AA101564	GUIDE CHAIN	Bajaj spare parts
AA101565	GUIDE CHAIN	Bajaj spare parts
AA101567	SHAFT MAIN	Bajaj spare parts
AA101569	CHAIN TIMING	Bajaj spare parts
AA101570	BUSH SINTERED	Bajaj spare parts
AA101577	MANIFOLD INLET	Bajaj spare parts
AA101578	SILENCER ASSY COMPLETE	Bajaj spare parts
AA101588	GEAR MULTIPLE	Bajaj spare parts
AA101592	CLUTCH HSG ASSY	Bajaj spare parts
AA101593	CLUTCH COMPLETE	Bajaj spare parts
AA101594	INSULATOR	Bajaj spare parts
AA101598	CLUTCH COMP	Bajaj spare parts
AA101599	CLUTCH HOUSING ASSLY	Bajaj spare parts
AA101602	PRIMARY PINION	Bajaj spare parts
AA101614	COVER DIFFERENTIAL	Bajaj spare parts
AA101624	PIPE OIL COOL	Bajaj spare parts
AA101643	PIPE OIL HOT	Bajaj spare parts
AA101647	GEAR MULTIPLE IV	Bajaj spare parts
AA101648	COVER DIFFERENTIAL	Bajaj spare parts
AA101665	BRACKET FIX END CABLE GUIDE	Bajaj spare parts
AA101666	ASSEMBLY CAM SHAFT	Bajaj spare parts
AA101667	STICK DIP CLUTCH COVER	Bajaj spare parts
AA101668	COVER FAN	Bajaj spare parts
AA101680	FLANGE ASSY GEAR SHIFTER	Bajaj spare parts
AA101689	"NUT HEX.-M6X1, A/F 13"	Bajaj spare parts
AA101692	COVER FAN	Bajaj spare parts
AA101708	NEEDLE ROLLER BEARING	Bajaj spare parts
AA101713	ENGINE ASSLY COMPLETE	Bajaj spare parts
AA101721	FLANGE S.G.HSG. SIDE	Bajaj spare parts
AA101722	FLANGE DIFF.GEAR SIDE	Bajaj spare parts

AA101734	BUSH SINTERED-REV.LEVER	Bajaj spare parts
AA101735	CRANKCASE MAGNETO SIDE	Bajaj spare parts
AA101736	SECTOR ASSY COMP.WITH LEVER	Bajaj spare parts
AA101742	BUSH -FAREMETER	Bajaj spare parts
AA101743	ASSLY FAREMETER COMPLETE	Bajaj spare parts
AA101745	HOUSING -FAREMETER	Bajaj spare parts
AA101747	SEAL RUBBER-FAREMETER	Bajaj spare parts
AA101750	ASSLY PINION-FAREMETER	Bajaj spare parts
AA101753	GROMMET-AIR FILTER INLET	Bajaj spare parts
AA101755	ASSLY EXHAUST TUBE	Bajaj spare parts
AA101779	GEAR MULTIPLE	Bajaj spare parts
AA101780	GEAR SPEED- 2ND	Bajaj spare parts
AA101781	GEAR SPEED - 3RD	Bajaj spare parts
AA101782	GEAR SPEED - 4TH	Bajaj spare parts
AA101786	SILENCER ASSY. COMPLETE	Bajaj spare parts
AA101787	ASSLY EXHAUST TUBE	Bajaj spare parts
AA101795	ASSLY BKT-CL CABLE & HT COIL	Bajaj spare parts
AA101814	COLLAR CAMSHAFT	Bajaj spare parts
AA101816	RUBBER ISOLATOR	Bajaj spare parts
AA101819	FLANGE ASSY GEAR SHIFTER	Bajaj spare parts
AA101821	COVER GEAR SHIFTER	Bajaj spare parts
AA101823	BRACKET CABLE ARRESTER	Bajaj spare parts
AA101826	CONNECTOR -OIL SUPPLY	Bajaj spare parts
AA101830	SILENCER ASSY. COMP.	Bajaj spare parts
AA101831	MUFFLER ASSY. COMPLETE	Bajaj spare parts
AA101835	ASSLY EXHAUST TUBE	Bajaj spare parts
AA101838	GASKET -MANIFOLD	Bajaj spare parts
AA101843	SEAT -SPRING VALVE	Bajaj spare parts
AA101844	SEAL - HEAD COVER	Bajaj spare parts
AA101859	BS4 VALVE INTAKE	Bajaj spare parts
AA101860	BS4 VALVE EXHAUST	Bajaj spare parts
AA101863	CAMSHAFT	Bajaj spare parts
AA101864	ASSLY CAMSHAFT	Bajaj spare parts
AA101865	BS4 ASSY PISTON LPG FMG	Bajaj spare parts
AA101868	GUIDE STEM	Bajaj spare parts
AA101869	PAD SEALING-FAN COVER	Bajaj spare parts
AA101870	PAD SEALING 1-COWLING INTAKE	Bajaj spare parts
AA101871	PAD SEALING 2-COWLING INTAKE	Bajaj spare parts
AA101873	GASKET CYLINDER	Bajaj spare parts
AA101875	SPRING FOR ENGINE VALVE	Bajaj spare parts
AA101878	CLIP	Bajaj spare parts
AA101883	VALVE PRESSURE RELIEF ASSLY	Bajaj spare parts
AA101884	VALVE PRESSURE RELIEF	Bajaj spare parts
AA101885	PAD SEALING - FAN COVER(LEFT)	Bajaj spare parts
AA101939	BRACKET CABLE CLUTCH	Bajaj spare parts

AA101944	SILENCER ASSY COMPLETE	Bajaj spare parts
AA101945	MUFFLER ASSY COMPLETE	Bajaj spare parts
AA101949	ASSLY CRANKSHAFT-205FL	Bajaj spare parts
AA101950	SEAL OIL	Bajaj spare parts
AA101952	ASSLY HOT AIR DEFLECTOR	Bajaj spare parts
AA101953	BS4 ASSY EX.TUBE LPG	Bajaj spare parts
AA101969	BRACKET H.T. COIL MOUNTING	Bajaj spare parts
AA101970	ASSLY FAN COVER	Bajaj spare parts
AA101997	ASSLY EXHAUST TUBE	Bajaj spare parts
AA102000	COVER CLUTCH-205FL	Bajaj spare parts
AA102003	ASSLY CAMSHAFT	Bajaj spare parts
AA102014	ENGINE ASSY. COMPLETE RE205 FL	Bajaj spare parts
AA102018	ASSLY SECTOR COMP.REV.CONTROL	Bajaj spare parts
AA102026	COVER DIFFERENTIAL	Bajaj spare parts
AA102031	BRACKET HOLDING - REVERSE CABLE	Bajaj spare parts
AA102043	ASSLY EXHAUST TUBE	Bajaj spare parts
AA102046	SILENCER ASSLY COMPLETE	Bajaj spare parts
AA102047	MUFFLER ASSY COMPLETE	Bajaj spare parts
AA102055	BRACKET -CABLE OIL PR. SWITCH	Bajaj spare parts
AA102060	MUFFLER ASSLY COMPLETE	Bajaj spare parts
AA102071	SILENCER ASSY COMPLETE	Bajaj spare parts
AA102072	ASSLY EXHAUST TUBE	Bajaj spare parts
AA102075	ASSLY HOT AIR DEFLECTOR	Bajaj spare parts
AA102077	ENGINE ASSY BS4-COMPACT GASOLINE 4S	Bajaj spare parts
AA102079	TUBE ASSLY SAI WITH FLANGE	Bajaj spare parts
AA102082	GASKET	Bajaj spare parts
AA102087	WIRE CIRCLIP 19.2X1.2 WIRE DIA	Bajaj spare parts
AA102093	ASSLY CYLINDER HEAD	Bajaj spare parts
AA102094	CHAIN TIMING-205FL	Bajaj spare parts
AA102097	PIPE ASSLY OIL COOL	Bajaj spare parts
AA102100	PIPE ASSEMBLY OIL HOT	Bajaj spare parts
AA102110	SLEEVE	Bajaj spare parts
AA102114	CLIP NUT	Bajaj spare parts
AA102115	SILENCER ASSY COMPLETE	Bajaj spare parts
AA102117	ASSLY EXHAUST TUBE	Bajaj spare parts
AA102124	GASKET SILENCER	Bajaj spare parts
AA102132	INSERT RESTRICTOR FILTER	Bajaj spare parts
AA102133	INSERT RESTRICTOR BODY	Bajaj spare parts
AA102154	HOOK ENGINE BREATHER TUBE	Bajaj spare parts
AA102158	ENGINE ASSLY PETROL 4S	Bajaj spare parts
AA102161	CLUTCH COMPLETE	Bajaj spare parts
AA102162	PLATE ASSLY-CLUTCH	Bajaj spare parts
AA102163	SPRING DETENT	Bajaj spare parts
AA102164	SELECTOR GEAR	Bajaj spare parts
AA102165	SPRING CLUTCH	Bajaj spare parts

AA102166	HUB CLUTCH	Bajaj spare parts
AA102167	COVER ASSLY-GEAR SHIFTER	Bajaj spare parts
AA102171	GASKET EXHAUST	Bajaj spare parts
AA102179	SILENCER ASSLY	Bajaj spare parts
AA102189	PLATE ASSEMBLY	Bajaj spare parts
AA102193	GROMMET	Bajaj spare parts
AA102195	COOLER OIL	Bajaj spare parts
AA102196	GUARD COOLER OIL	Bajaj spare parts
AA102197	BRACKET COOLER OIL	Bajaj spare parts
AA102203	BRACKET SUPPORT COOLER OIL	Bajaj spare parts
AA102209	COVER DIFFERENTIAL	Bajaj spare parts
AA102210	GASKET COVER DIFFERENTIAL	Bajaj spare parts
AA102224	CRANKCASE ASSEMBLY CLUTCH SIDE	Bajaj spare parts
AA102225	CRANKCASE CLUTCH SIDE	Bajaj spare parts
AA102227	CRANKCASE MAGNETO SIDE	Bajaj spare parts
AA102237	MANIFOLD INTAKE	Bajaj spare parts
AA102239	ENGINE ASSEMBLY	Bajaj spare parts
AA102244	CRANKCASE MAGNETO SIDE	Bajaj spare parts
AA102263	SILENCER ASSEMBLY	Bajaj spare parts
AA102264	PIPE ASSEMBLY A	Bajaj spare parts
AA102266	ENGINE ASSEMBLY	Bajaj spare parts
AA102277	GEAR ASSLY SECTOR	Bajaj spare parts
AA102281	ASSEMBLY HANDLE STARTING	Bajaj spare parts
AA102301	SPACER	Bajaj spare parts
AA102320	PIPE ASSEMBLY A	Bajaj spare parts
AA102324	HEAD CYLINDER ASSEMBLY	Bajaj spare parts
AA102344	LEVER STARTING FRONT	Bajaj spare parts
AA102345	LEVER STARTING ENGINE	Bajaj spare parts
AA102347	TUBE ASSEMBLY CONNECTING	Bajaj spare parts
AA102350	JOINT BALL	Bajaj spare parts
AA102351	CONNECTOR	Bajaj spare parts
AA102363	SHAFT KICK	Bajaj spare parts
AA102364	TUBE ASSEMBLY	Bajaj spare parts
AA102370	GRIP HANDLE STARTING	Bajaj spare parts
AA102378	MUFFLER ASSEMBLY	Bajaj spare parts
AA102406	GEAR SPEED FIRST	Bajaj spare parts
AA102411	GEAR STARTER	Bajaj spare parts
AA102432	DIFFERENTIAL ASSEMBLY	Bajaj spare parts
AA102433	HOUSING ASSEMBLY GEAR SATELLITE	Bajaj spare parts
AA102434	GEAR DIFFERENTIAL	Bajaj spare parts
AA102457	SILENCER ASSEMBLY	Bajaj spare parts
AA102615	SILENCER ASSEMBLY	Bajaj spare parts
AA102616	MUFFLER ASSEMBLY	Bajaj spare parts
AA111049	GROMMET STARTER MOTOR BRACKET.	Bajaj spare parts
AA111051	STATOR ASSY4S PETR / CNG	Bajaj spare parts

AA111052	PICK UP ASSY AEL	Bajaj spare parts
AA111058	PLUG SPARK 4S PETR / CNG	Bajaj spare parts
AA111067	SUPPORT ASY.STARTER MOTOR	Bajaj spare parts
AA111072	ROTOR 4S PETR / CNG	Bajaj spare parts
AA111074	CAP SPARK PLUG WITH RESIS	Bajaj spare parts
AA111077	GROMMET H.T.CABLE	Bajaj spare parts
AA111078	BRACKET ASSY MOUNTIN	Bajaj spare parts
AA111079	COVER ASSEMBLY	Bajaj spare parts
AA111080	BRACKET END COVER	Bajaj spare parts
AA111081	BRACKET ASSY INTERME	Bajaj spare parts
AA111082	ARMATURE ASSY	Bajaj spare parts
AA111083	DRIVE ASSEMBLY	Bajaj spare parts
AA111085	KITBRUSH BOX ASMBLY	Bajaj spare parts
AA111086	SPRING PINION RETURN	Bajaj spare parts
AA111087	CIRCLIP DRIVE ASSY	Bajaj spare parts
AA111091	IGNITER DC DIGITAL	Bajaj spare parts
AA111092	MOTOR STARTER ASSY	Bajaj spare parts
AA111093	BKT FIXING ASSY ST M	Bajaj spare parts
AA111094	SHAFT GEAR	Bajaj spare parts
AA111095	UNIT SHAFT GEAR	Bajaj spare parts
AA111107	DIGITAL CDI WITH STARTER	Bajaj spare parts
AA111110	DC IGNITER (PETROL)	Bajaj spare parts
AA111117	BOLT -TIE	Bajaj spare parts
AA111118	GASKET	Bajaj spare parts
AA111119	ASSLY CDI-PETROL FL	Bajaj spare parts
AA111120	DAMPER FOR CDI-205FL	Bajaj spare parts
AA111122	ASSLY CDI UNIT-205FL EXPORT	Bajaj spare parts
AA111124	ASSLY CDI-205FL EXP.EURO II	Bajaj spare parts
AA111132	COIL H.T. WITH CABLE AND CAP-LH	Bajaj spare parts
AA111134	COIL H.T. WITH CABLE AND CAP-RH	Bajaj spare parts
AA111141	CLIP H.T. CABLE HOLDING	Bajaj spare parts
AA111146	CAP PVC HT COIL	Bajaj spare parts
AA111147	CAP SPARK PLUG SOLID POST	Bajaj spare parts
AA111148	GROMMET SPARK PLUG	Bajaj spare parts
AA111151	ROTOR ASSLY	Bajaj spare parts
AA111153	PLUG SPARK WITH SOLID POST-FMG	Bajaj spare parts
AA111154	PLUG SPARK SOLID POST-BOSH	Bajaj spare parts
AA111156	ASSLY CDI MULTI MAP -GASOLINE	Bajaj spare parts
AA111157	CAP SPARK PLUG-LH	Bajaj spare parts
AA111165	H T COIL WITH GND PLATE	Bajaj spare parts
AA111178	CDI MULTI MAP ASSY -GASOLINE DOM	Bajaj spare parts
AA111180	CAP SPARK PLUG LH S POST	Bajaj spare parts
AA111181	CAP SPARK PLUG RH S POST	Bajaj spare parts
AA111192	ROTOR ASSLY	Bajaj spare parts
AA111194	STATOR ASSLY	Bajaj spare parts

AA111195	SENSOR PICK UP	Bajaj spare parts
AA111196	CDI ASSLY MULTI MAP-GASOLINE	Bajaj spare parts
AA111202	ROTOR ASSLY	Bajaj spare parts
AA111203	STATOR ASSLY	Bajaj spare parts
AA111205	MOTOR STARTER	Bajaj spare parts
AA111220	CDI	Bajaj spare parts
AA111224	GROMMET CAP PLUG SPARK	Bajaj spare parts
AA121006	ELEMENT OIL FILTER	Bajaj spare parts
AA121010	GASKET OIL FILTER COVER	Bajaj spare parts
AA121045	CLAMP DUCT CARBURETR	Bajaj spare parts
AA121059	GEAR OIL PUMP	Bajaj spare parts
AA121060	PUMP OIL 4S PETR / CNG /	Bajaj spare parts
AA121071	CLAMP CARBU DUCT	Bajaj spare parts
AA121090	CARBURETTOR KEIHIN RE 4S	Bajaj spare parts
AA121097	CARBURETTOR M/S. UCAL	Bajaj spare parts
AA121104	JET MAIN MJ	Bajaj spare parts
AA121126	FILTER AIR ASSY	Bajaj spare parts
AA121127	HOSE ASSY INTEGRAL	Bajaj spare parts
AA121135	COOLER OIL	Bajaj spare parts
AA121142	CARBURETTOR ASSY.(EXPORT)	Bajaj spare parts
AA121146	COVER AIR FILTER ASSY.	Bajaj spare parts
AA121147	VALVE DUST EJECTOR	Bajaj spare parts
AA121148	GASKET SEALING	Bajaj spare parts
AA121149	CLIP AIR FILTER	Bajaj spare parts
AA121150	ELEMENT AIR FILTER	Bajaj spare parts
AA121151	ASSEMBLY AIR FILTER	Bajaj spare parts
AA121187	PLUNGER ASSLY	Bajaj spare parts
AA121195	ASSLY COMT INTEGRAL DUCT	Bajaj spare parts
AA121199	CARBURETTOR ASSLY	Bajaj spare parts
AA121201	CONE REVERSE AIR INLET	Bajaj spare parts
AA121204	ASSEMBLY AIR FILTER	Bajaj spare parts
AA121214	ADJUSTER	Bajaj spare parts
AA121218	MANIFOLD INTAKE	Bajaj spare parts
AA121226	INSULATOR FOR MANIFOLD	Bajaj spare parts
AA121230	MANIFOLD INTAKE-BOTH SIDE FLANGE	Bajaj spare parts
AA121241	ASSLY DUCT INTEGRAL COMPLETE	Bajaj spare parts
AA121242	ASSLY INTAKE MANIFOLD	Bajaj spare parts
AA121244	TUBE S.A.I. OUTLET	Bajaj spare parts
AA121245	TUBE S.A.I. INLET-1	Bajaj spare parts
AA121246	TUBE S.A.I. INLET-2	Bajaj spare parts
AA121247	TUBE VACUUM	Bajaj spare parts
AA121250	ASSLY AIR FILTER CLAMP	Bajaj spare parts
AA121257	CARBURETTOR ASSY.-FLANGE TYPE	Bajaj spare parts
AA121259	ASSEMBLY AIR FILTER	Bajaj spare parts
AA121262	POSITION SENSOR O RING	Bajaj spare parts

AA121264	HOSE -AIR VENT	Bajaj spare parts
AA121265	TUBE OVERFLOW CARB.	Bajaj spare parts
AA121268	INSERT RESTRICTOR	Bajaj spare parts
AA121269	ASSLY AIR FILTER	Bajaj spare parts
AA121280	CARBURETTOR ASSY. FOR EVAP	Bajaj spare parts
AA121282	TUBE SAI OUTLET	Bajaj spare parts
AA121285	ASSLY HOSE INTEGRAL COMP	Bajaj spare parts
AA121286	ASSLY HOSE INTEGRAL	Bajaj spare parts
AA121290	TUBE SAI INLET	Bajaj spare parts
AA121291	TUBE VACUUM FOR SAI	Bajaj spare parts
AA121304	TUBE INLET - SAI FILTER	Bajaj spare parts
AA121305	FILTER ASSLY-AIR	Bajaj spare parts
AA121306	MANIFOLD INTAKE	Bajaj spare parts
AA121307	HOSE ASSLY COMPLETE-INTEGRAL	Bajaj spare parts
AA121322	HOSE ASSLY	Bajaj spare parts
AA121324	CARBURETTOR ASSLY	Bajaj spare parts
AA121328	TUBE BREATHER 1	Bajaj spare parts
AA121329	TUBE BREATHER 2	Bajaj spare parts
AA121336	OIL PUMP ASSLY	Bajaj spare parts
AA121344	SLEEVE FILTER AIR	Bajaj spare parts
AA121368	PIPE BREATHER	Bajaj spare parts
AA121369	BODY THROTTLE ASSEMBLY	Bajaj spare parts
AA121370	GRILL INTAKE AIR	Bajaj spare parts
AA121373	FILTER ASSEMBLY AIR	Bajaj spare parts
AA121381	PIPE INTAKE AIR	Bajaj spare parts
AA121388	PIPE BREATHER	Bajaj spare parts
AA121390	GRILL INTAKE AIR INNER	Bajaj spare parts
AA121397	FILTER ASSEMBLY AIR	Bajaj spare parts
AA131002	GEAR DIFFERENTIAL R.E.	Bajaj spare parts
AA131004	GASKET HOUSING FAREMETER	Bajaj spare parts
AA131014	COVER DIFFERENTIAL	Bajaj spare parts
AA131016	GASKET COVER DIFFERE	Bajaj spare parts
AA131017	DIPSTICK DIFFERENTIAL	Bajaj spare parts
AA131024	BELLOW DIFFERENTIAL	Bajaj spare parts
AA131033	HOUSING SATELLITE GEAR	Bajaj spare parts
AA131036	SECTOR COMP.REV.CONT	Bajaj spare parts
AA131044	TENSION SPRING	Bajaj spare parts
AA131049	GASKETDIFFER COVER	Bajaj spare parts
AA131063	ASSLY SECTOR COMP.REV.CONTROL	Bajaj spare parts
AA131074	ASSLY BRACKET REV. & OIL PIPE	Bajaj spare parts
AA141008	CAP FUEL TANK	Bajaj spare parts
AA141046	CLIP SPRING BAND	Bajaj spare parts
AA141048	CLIP SPRING BAND DI	Bajaj spare parts
AA141067	CLIP SWIVEL SPACER	Bajaj spare parts
AA141071	ASSLY FUEL TANK WELDED	Bajaj spare parts



AA141079	BAFFLE FUEL SPILLAGE	Bajaj spare parts
AA141080	GROMMET FOR BAFFLE FUEL SPILLAGE	Bajaj spare parts
AA141081	PIPE FILTER TO CARBURETOR	Bajaj spare parts
AA141082	SLEEVE FILTER TO CARBURETOR	Bajaj spare parts
AA141083	ASSLY PIPE FILTER TO CARB.	Bajaj spare parts
AA141085	PIPE TANK TO FILTER	Bajaj spare parts
AA141088	GROMMET BAFFLE NON FACE SEALING	Bajaj spare parts
AA141090	HOOK CLIP	Bajaj spare parts
AA141095	ASSLY WELDED FUEL TANK	Bajaj spare parts
AA141101	ASSLY PIPE FUEL TANK TO CARBU	Bajaj spare parts
AA141103	SLEEVE FILTER TO CARBURETOR	Bajaj spare parts
AA141104	ASSLY PIPE FILTER TO CAR	Bajaj spare parts
AA141105	RING O- F TANK CAP	Bajaj spare parts
AA141106	ASSLY CAP FUEL TANK	Bajaj spare parts
AA141115	ASSLY FUEL CAP WITH HANDLE	Bajaj spare parts
AA141137	PIPE TANK TO FILTER-EVAP	Bajaj spare parts
AA141139	PIPE FILTER TO CARBU-EVAP	Bajaj spare parts
AA141140	CAP ASSLY EVAP	Bajaj spare parts
AA141144	TANK ASSLY WELDED-FUEL	Bajaj spare parts
AA141161	PIPE TANK RO VALVE	Bajaj spare parts
AA141164	PIPE RO VALVE CANISTER	Bajaj spare parts
AA141177	LOCATOR VALVE ROLL OVER	Bajaj spare parts
AA141179	LOCATOR CANISTER	Bajaj spare parts
AA141180	DAMPER CANISTER	Bajaj spare parts
AA141183	PIPE CANISTER-VALVE PURGE	Bajaj spare parts
AA141188	BRACKET	Bajaj spare parts
AA141198	PIPE ASSEMBLY VALVE PURGE-ENGINE	Bajaj spare parts
AA141199	PIPE VALVE PURGE-ENGINE	Bajaj spare parts
AA141200	PIPE ASSEMBLY TANK-MANIFOLD	Bajaj spare parts
AA141216	GROMMET	Bajaj spare parts
AA151009	PIPE BRAKE REAR I	Bajaj spare parts
AA151012	PIPE BRAKE REAR I	Bajaj spare parts
AA151036	PIPE ASSY REAR SINGLE PIE	Bajaj spare parts
AA151039	HOSE BRAKE FRONT RE205 FL	Bajaj spare parts
AA151044	KIT BRAKE SHOE	Bajaj spare parts
AA151047	Hub Fr. Wheel	Bajaj spare parts
AA151049	SPACER	Bajaj spare parts
AA151052	CABLE BRAKE PARKING REAR RH	Bajaj spare parts
AA151053	BRAKE CABL1204 145LH	Bajaj spare parts
AA151056	ASSLY HAND LEVER GRIP	Bajaj spare parts
AA151057	ASSLY FRONT CABLE	Bajaj spare parts
AA151058	ASSLY EQUALISER	Bajaj spare parts
AA151059	ASSLY REAR CABLE LH	Bajaj spare parts
AA151060	BRACKET EQUALIZER	Bajaj spare parts
AA151061	COVER EQUALIZER	Bajaj spare parts

AA151069	PANEL ASSLY BRAKE REAR RH	Bajaj spare parts
AA151071	PANEL ASSLY BRAKE REAR LH	Bajaj spare parts
AA151074	PANEL ASSLY BRAKE-FRONT	Bajaj spare parts
AA151080	LEVER ASSLY BRAKE PARKING	Bajaj spare parts
AA151081	EQUALIZER ASSEMBLY	Bajaj spare parts
AA151083	CABLE BRAKE PARKING REAR	Bajaj spare parts
AA151084	HUB FRONT	Bajaj spare parts
AA151109	PIPE ASSEMBLY BRAKE REAR	Bajaj spare parts
AA151112	RESERVOIR OIL BRAKE	Bajaj spare parts
AA151124	BEARING NEEDLE ROLLER	Bajaj spare parts
AA151128	PANEL ASSEMBLY BRAKE FRONT	Bajaj spare parts
AA151165	LEVER ASSEMBLY BRAKE PARKING	Bajaj spare parts
AA151166	RATCHET	Bajaj spare parts
AA161073	MEMBER ENGINE MOUNTING R	Bajaj spare parts
AA161080	COVER PLATE ELECTRICAL UN	Bajaj spare parts
AA161081	PACKING COVER	Bajaj spare parts
AA161190	HOUSING HEADLAMP LH REFL	Bajaj spare parts
AA161191	HOUSING HEADLAMP RH REFL	Bajaj spare parts
AA161215	DASHBOARD PLASTIC REFL	Bajaj spare parts
AA161216	COVER SPEEDOMETER REFL	Bajaj spare parts
AA161218	TRIM UPPER SMALL LH	Bajaj spare parts
AA161219	TRIM UPPER SMALL RH	Bajaj spare parts
AA161220	ENGINE MOUNTING MEMBER REAR FL	Bajaj spare parts
AA161225	BRACKET CONTROL MOUNTING	Bajaj spare parts
AA161265	ASSY PLATE ELECTRICAL REAR FL	Bajaj spare parts
AA161268	BEADING HOUSING HEADLAMP FL	Bajaj spare parts
AA161269	BEADING STEERING COVER UPPER FL	Bajaj spare parts
AA161270	BEADING STG COVER	Bajaj spare parts
AA161283	COVER REAR ELECTRICAL PLATE FL	Bajaj spare parts
AA161290	BRACKET HARNESS CLAMP	Bajaj spare parts
AA161295	ASSLY PLATE ELEC REAR FL	Bajaj spare parts
AA161305	DASHBOARD PLASTIC	Bajaj spare parts
AA161306	COVER SPEEDOMETER	Bajaj spare parts
AA161307	LID TOOL BOX RH	Bajaj spare parts
AA161308	LID TOOL BOX LH	Bajaj spare parts
AA161309	TOOLBOX RH SIDE	Bajaj spare parts
AA161310	COVER MIDDLE PORTION	Bajaj spare parts
AA161315	ASSLY ENGINE MOUNTING MEMEBER	Bajaj spare parts
AA161327	TRIM UPPER SMALL LH	Bajaj spare parts
AA161328	TRIM UPPER SMALL RH	Bajaj spare parts
AA161337	ASSEMBLY ENGINE MTG MEMBER	Bajaj spare parts
AA161351	ASSLY TRAY BATTERY FI	Bajaj spare parts
AA161357	COVER SPEEDOMETER	Bajaj spare parts
AA161358	DASHBOARD ASSLY	Bajaj spare parts
AA161363	COVER ECU	Bajaj spare parts

AA161375	BRACKET ECU	Bajaj spare parts
AA161383	MEMBER ASSLY ENGINE	Bajaj spare parts
AA161392	PLATE ASSLY ELECTRICAL REAR	Bajaj spare parts
AA161420	BRACKET ASSEMBLY	Bajaj spare parts
AA161433	TRIM UPPER LH	Bajaj spare parts
AA161435	TRIM UPPER RH	Bajaj spare parts
AA161437	TRIM MIDDLE	Bajaj spare parts
AA161438	TRIM MIDDLE UPPER	Bajaj spare parts
AA161439	COVER SPEAKER LH	Bajaj spare parts
AA161440	COVER SPEAKER RH	Bajaj spare parts
AA161443	LID TOOLBOX	Bajaj spare parts
AA161444	COVER MIDDLE	Bajaj spare parts
AA161446	DASHBOARD	Bajaj spare parts
AA161447	HOUSING RADIO	Bajaj spare parts
AA161456	BOX UTILITY	Bajaj spare parts
AA161472	TRIM ASSEMBLY MIDDLE UPPER	Bajaj spare parts
AA161473	COVER ASSEMBLY SPEAKER LH	Bajaj spare parts
AA161474	COVER ASSEMBLY SPEAKER RH	Bajaj spare parts
AA161480	COVER ASSEMBLY MIDDLE	Bajaj spare parts
AA161481	BOX ASSEMBLY UTILITY	Bajaj spare parts
AA161529	COVER ASSEMBLY DASHBOARD	Bajaj spare parts
AA171006	BUSH SILENT ARM	Bajaj spare parts
AA171008	DISTANCE PIECE TRAIL ARM	Bajaj spare parts
AA171009	SPACER RINGDIST	Bajaj spare parts
AA171011	PIN ASSEMBLY PIVOT	Bajaj spare parts
AA171022	ASSLY DISTANCE PIECE TA TUBE	Bajaj spare parts
AA171024	RING SPACER TR ARM TUBE	Bajaj spare parts
AA171025	ASSLY STEERING COLUMN	Bajaj spare parts
AA171027	ASSLY STEERING COLUMN	Bajaj spare parts
AA171030	SHOCKABSORBER FRONT	Bajaj spare parts
AA171032	SPRING SUSPENSION FRONT	Bajaj spare parts
AA171033	SPRING SUSPENSION REAR	Bajaj spare parts
AA181019	LOCK SET RE 4 S	Bajaj spare parts
AA181022	BEARING RACE LOWER	Bajaj spare parts
AA181023	COVER DUST LOWER	Bajaj spare parts
AA181034	LOCK SET COMPACT 4S EXP	Bajaj spare parts
AA181039	COLUMN ASSEMBLY STEERING	Bajaj spare parts
AA181058	COVER BEARING UPPER	Bajaj spare parts
AA181059	RACE INNER UPPER	Bajaj spare parts
AA181066	SET LOCK	Bajaj spare parts
AA181067	SET LOCK	Bajaj spare parts
AA191010	REVERS CABL2300 4S A	Bajaj spare parts
AA191026	CABLE INNER CLUTCH 4S PET	Bajaj spare parts
AA191029	CABLE CLUTCH RE 4S	Bajaj spare parts
AA191032	LEVER CLUTCH	Bajaj spare parts

AA191051	CABLE INNER SPEEDO RE 4S	Bajaj spare parts
AA191064	CLUTCH CABLE RE 4S	Bajaj spare parts
AA191065	CABLE ACCELERATOR RE 4S	Bajaj spare parts
AA191068	REVERS CABL1435 205	Bajaj spare parts
AA191071	SPEEDO CABL2452 205D	Bajaj spare parts
AA191073	CABLE ACCELERATER	Bajaj spare parts
AA191077	CLUTCH CABLE COMPLETE	Bajaj spare parts
AA191080	CABLE INNER SPEEDOMETER	Bajaj spare parts
AA191082	GEAR CABL2525 205& D	Bajaj spare parts
AA191083	GEAR CABL2539 205& D	Bajaj spare parts
AA191085	CLUTCH CABL2691 205	Bajaj spare parts
AA191091	ACC CABL 2827 COM 4S	Bajaj spare parts
AA191092	CABLE CLUTCH	Bajaj spare parts
AA191093	GEAR CABL2524 COM 4S	Bajaj spare parts
AA191094	GEAR CABL2520 COM 4S	Bajaj spare parts
AA191101	CABLE ASSLY CHOKE RE205DFL	Bajaj spare parts
AA191102	SPEEDO CABL2418 COM4	Bajaj spare parts
AA191103	CABLE CLUTCH	Bajaj spare parts
AA191113	ASSLY REVERSE LEVER	Bajaj spare parts
AA191114	RATCHET REVERSE LEVER	Bajaj spare parts
AA191115	CABLE REVERSE LEVER	Bajaj spare parts
AA191116	LEVER REVERSE CONTROL	Bajaj spare parts
AA191117	SPRING TENSION REVERSE CONTROL	Bajaj spare parts
AA191119	PIVOT PIN REVERSE LEVER	Bajaj spare parts
AA191120	PIN UPPER REVERSE LEVER	Bajaj spare parts
AA191121	SPRING FOR SWITCH	Bajaj spare parts
AA191122	PIN ASSLY	Bajaj spare parts
AA191129	SPEEDOMETER	Bajaj spare parts
AA191134	CABLE SPEEDOMETER	Bajaj spare parts
AA191139	CABLE ACCELERATOR	Bajaj spare parts
AA191140	CABLE CHOKE	Bajaj spare parts
AA191164	INSTRUMENT CLUSTER	Bajaj spare parts
AA201012	RELAY STARTER	Bajaj spare parts
AA201048	BOX ASSY FUSE PETR	Bajaj spare parts
AA201088	SWITCH - WIPER :- 'USA' MARKET	Bajaj spare parts
AA201090	BRACKET MOUNTING	Bajaj spare parts
AA201091	BLINKER FR LH RE 4S / CNG	Bajaj spare parts
AA201093	BLINK FR RH RE/4S/CNG	Bajaj spare parts
AA201100	LAMP TAIL RH RE 4S	Bajaj spare parts
AA201152	MOTOR WIPER RE 4S	Bajaj spare parts
AA201157	LAMP TAIL RE 4S	Bajaj spare parts
AA201160	LAMP TAILRH RE 4S	Bajaj spare parts
AA201161	LENS TAIL LIGHT WI	Bajaj spare parts
AA201171	BLINKER RE 4S	Bajaj spare parts
AA201185	BOX ASSLY WITH FUSE RE4S	Bajaj spare parts

AA201190	FUSE BOX	Bajaj spare parts
AA201194	INDICATOR ASSLY	Bajaj spare parts
AA201199	LAMP TAIL LH	Bajaj spare parts
AA201201	LAMP TAIL RH	Bajaj spare parts
AA201227	LAMP 12V 18/5W	Bajaj spare parts
AA201235	HARNESS WIRING FRONT	Bajaj spare parts
AA201239	HORN DC 12V WITH TRAN	Bajaj spare parts
AA201242	HARNESS WIRING	Bajaj spare parts
AA201250	HARNESS WIRING FR 205D PET FL	Bajaj spare parts
AA201252	CABLE BATTERY RE205 FL	Bajaj spare parts
AA201256	SWITCH CONTROL RH	Bajaj spare parts
AA201258	LABEL PARKING ON/OFF	Bajaj spare parts
AA201260	HARNESS WIRING FRONT	Bajaj spare parts
AA201262	Rubber Cap H.Lamp	Bajaj spare parts
AA201263	ASSLY WIPER MOTOR BIG FL	Bajaj spare parts
AA201264	SCREW PAN CROSS M5X40L	Bajaj spare parts
AA201265	HARNESS REAR RE205 D	Bajaj spare parts
AA201272	ASSLY INDICATOR	Bajaj spare parts
AA201275	HARNESS WIRING FR	Bajaj spare parts
AA201276	HARNESS WIRING RR	Bajaj spare parts
AA201278	SPEEDOMETER ASSLY	Bajaj spare parts
AA201281	SP.METER ASSY WITH 0.95 RATIO	Bajaj spare parts
AA201287	BATTERY CABLE RE205D	Bajaj spare parts
AA201288	CAPACITOR PIGTAIL	Bajaj spare parts
AA201293	CAP RUBBER BLACK ID 7.0	Bajaj spare parts
AA201305	LAMP ENGINE CABIN RE COMPACT	Bajaj spare parts
AA201310	HARNESS BODY	Bajaj spare parts
AA201312	HARNESS WIRING REAR COMPACT 4S	Bajaj spare parts
AA201313	ASSLY INDICATOR RH	Bajaj spare parts
AA201314	CABLE BATTERY RE COMPACT 4S	Bajaj spare parts
AA201315	HARNESS WIRING FR	Bajaj spare parts
AA201320	SPACER FOR SWITCH	Bajaj spare parts
AA201325	SWITCH OIL PRESSURE	Bajaj spare parts
AA201329	HARNESS WIRING REAR EXPORT	Bajaj spare parts
AA201330	HARNESS WIRING REAR	Bajaj spare parts
AA201331	HARNESS REVERSE SWITCH	Bajaj spare parts
AA201332	ASSLY REVERSE SWITCH WITH HARNESS	Bajaj spare parts
AA201341	LAMP 12V 1.7W	Bajaj spare parts
AA201344	CABLE FOR FAREMETER LAMP	Bajaj spare parts
AA201345	TANK UNIT BS4	Bajaj spare parts
AA201358	HARNESS FRONT RE 4S PETROL	Bajaj spare parts
AA201359	CABLE BATTERY RE COMPACT 4S	Bajaj spare parts
AA201361	HARNESS BODY RE 4S PETROL	Bajaj spare parts
AA201362	ASSLY INDICATOR RH	Bajaj spare parts
AA201363	TANK UNIT	Bajaj spare parts

AA201368	HARNESS WIRING-FRONT	Bajaj spare parts
AA201369	HARNESS WIRING-REAR	Bajaj spare parts
AA201370	CABLE BATTERY POSITIVE	Bajaj spare parts
AA201374	INDICATOR ASSLY-FI-RH	Bajaj spare parts
AA201375	PUMP-FUEL MODULE-FI	Bajaj spare parts
AA201378	HARNESS WIRING-BODY FI	Bajaj spare parts
AA201379	CABLE BATTERY	Bajaj spare parts
AA201380	CABLE EARTH - ENGINE TO CHASSIS	Bajaj spare parts
AA201382	UNIT TRANSIL	Bajaj spare parts
AA201383	TANK UNIT-FI	Bajaj spare parts
AA201384	BOX ASSLY-FUSE	Bajaj spare parts
AA201385	PLATE ASSLY-ELECTRICAL-FRONT	Bajaj spare parts
AA201387	CLAMP CABLE	Bajaj spare parts
AA201391	CABLE BATTERY -VE	Bajaj spare parts
AA201397	INDICATOR ASSLY-RH	Bajaj spare parts
AA201404	INDICATOR LED MIL	Bajaj spare parts
AA201407	REGULATOR ASSLY FI	Bajaj spare parts
AA201414	HARNESS WIRING-FRONT-PETROL	Bajaj spare parts
AA201415	HARNESS WIRING-REAR-PETROL	Bajaj spare parts
AA201432	HARNESS WIRING REAR	Bajaj spare parts
AA201442	HARNESS WIRING FRONT	Bajaj spare parts
AA201481	INDICATOR POD RH	Bajaj spare parts
AA201483	ASSEMBLY PLATE ELECTRICAL FRONT	Bajaj spare parts
AA201484	CABLE PLATE ELECTRICAL FRONT	Bajaj spare parts
AA201506	HARNESS WIRING FRONT	Bajaj spare parts
AA201507	HARNESS WIRING REAR	Bajaj spare parts
AA201508	HARNESS WIRING BODY	Bajaj spare parts
AA201515	SOCKET CHARGER	Bajaj spare parts
AA201521	HARNESS WIRING REAR	Bajaj spare parts
AA201522	HARNESS WIRING BODY	Bajaj spare parts
AA201530	HARNESS WIRING FRONT	Bajaj spare parts
AA201538	UNIT TRANSIL	Bajaj spare parts
AA201582	BOX ASSEMBLY FUSE	Bajaj spare parts
AA201616	INDICATOR POD RH	Bajaj spare parts
AA201629	HARNESS WIRING REAR	Bajaj spare parts
AA201631	HARNESS WIRING FRONT	Bajaj spare parts
AA201687	SENSOR LEVEL FUEL	Bajaj spare parts
AA201692	SENSOR LEVEL FUEL	Bajaj spare parts
AA201703	HARNESS WIRING REAR	Bajaj spare parts
AA201704	HARNESS WIRING BODY	Bajaj spare parts
AA201705	HARNESS WIRING FRONT	Bajaj spare parts
AA210017	ASSLY DRIVER SEAT	Bajaj spare parts
AA210019	ASSLY DRIVER BACKREST	Bajaj spare parts
AA210022	ASSLY PASSENGER SEAT	Bajaj spare parts
AA210024	ASSLY PASSENGER BACKREST	Bajaj spare parts

AA210027	ASSLY SEAT DRIVER WHITE	Bajaj spare parts
AA210036	ASSLY DRIVER SEAT BROWN	Bajaj spare parts
AA210037	ASSLY DRIVER BACKREST BROWN	Bajaj spare parts
AA210038	ASSLY PASS SEAT BROWN	Bajaj spare parts
AA210039	ASSLY PASS BACKREST BROWN	Bajaj spare parts
AA210040	SEAT ASSLY-DRIVER-WHITE	Bajaj spare parts
AA210052	BACKREST ASSLY DRIVER BROWN	Bajaj spare parts
AA221005	MIRROR ASSY LH 4S PETR /	Bajaj spare parts
AA221006	MIRROR ASSY RH 4S PETR /	Bajaj spare parts
AA221028	EMBLEM 4S	Bajaj spare parts
AA221030	TOOL KIT COMT RE205D FL	Bajaj spare parts
AA221033	TOOLKIT COMPLETE	Bajaj spare parts
AA221042	MIRROR LH	Bajaj spare parts
AA221043	MIRROR RH	Bajaj spare parts
AA231026	BEADING WINDSHIELD	Bajaj spare parts
AA231110	PASSENGER SEAT ASSLY	Bajaj spare parts
AA231117	DOOR ASSLY SIDE FILLING	Bajaj spare parts
AA231126	DAMPER FOR DOOR SIDE FILLING	Bajaj spare parts
AA231129	DAMPER FOR SEAT DRIVER	Bajaj spare parts
AA231140	SEAT DRIVER	Bajaj spare parts
AA231142	CLAMP AIR FILTER	Bajaj spare parts
AA231154	CUSHION	Bajaj spare parts
AA231223	COVER WIPER MOTOR	Bajaj spare parts
AA231239	BEADING ONE PIECE W/S GLASS	Bajaj spare parts
AA231245	BOLT COMBINATION	Bajaj spare parts
AA231252	GROMMET AIR INTAKE CUT OUT	Bajaj spare parts
AA231255	GLASS GREEN WINDSHLD	Bajaj spare parts
AA231262	ASSLY PASSENGER SEAT WHITE	Bajaj spare parts
AA231263	ASSLY PASS BACKREST WHITE	Bajaj spare parts
AA231267	HOOD ASSEMBLY BLACK	Bajaj spare parts
AA231273	RUBBER PLUG ON BODY	Bajaj spare parts
AA231279	ASSLY SEAT PASSENGER	Bajaj spare parts
AA231297	HOOD COMPLETE	Bajaj spare parts
AA231306	MAT LUGGAGE COMPARTMENT	Bajaj spare parts
AA231320	HOOD COMPLETE BLACK	Bajaj spare parts
AA231322	HOOD COMPLETE WHITE	Bajaj spare parts
AA231330	HOOD COMPLETE YELLOW	Bajaj spare parts
AA231379	BACKREST ASSLY PASSENGER	Bajaj spare parts
AA231409	LABEL PARKING-IGNITION	Bajaj spare parts
AA231434	LABEL PETROL	Bajaj spare parts
AA231437	LABEL BS6 RH	Bajaj spare parts
AA231438	LABEL PETROL	Bajaj spare parts
AA231456	BRACKET PLATE NUMBER	Bajaj spare parts
AA231483	SEAT ASSEMBLY DRIVER BROWN	Bajaj spare parts
AA231534	SEAT ASSEMBLY DRIVER	Bajaj spare parts

AA231535	SEAT ASSEMBLY DRIVER BLACK	Bajaj spare parts
AA231536	BACKREST ASSEMBLY DRIVER BLACK	Bajaj spare parts
AA231544	BOOT	Bajaj spare parts
AA231549	HOOD ASSEMBLY BLACK	Bajaj spare parts
AA231550	HOOD ASSEMBLY MUSHROOM	Bajaj spare parts
AA231552	HOOD ASSEMBLY WHITE	Bajaj spare parts
AA231573	EMBLEM BAJAJ RE	Bajaj spare parts
AA231649	RIVET BLIND	Bajaj spare parts
AA251001	FARE CABLE 1100 FL	Bajaj spare parts
AA251003	CABLE INNER FAREMTR 4S PE	Bajaj spare parts
AA251005	LABEL COMPACT 4S WHITE	Bajaj spare parts
AA251006	LABEL COMPACT 4S BLACK	Bajaj spare parts
AA991000	HARNESS WIRING REAR	Bajaj spare parts
AA991022	PLATE ASSEMBLY	Bajaj spare parts
AB101014	GUIDE GEAR STARTER	Bajaj spare parts
AB101038	GROMMET BREATHER	Bajaj spare parts
AB101067	CROSS	Bajaj spare parts
AB101084	PIPE BREATHER	Bajaj spare parts
AB111015	PLUG SPARK 4S PETR / CNG	Bajaj spare parts
AB111107	YOKE AND MAGNET ASSE	Bajaj spare parts
AB121017	CLAMP INTAKE DUCT	Bajaj spare parts
AB151035	DISC SHOE HOLDING FR	Bajaj spare parts
AB151048	HOSE FLEXIBLE BRAKE FRON	Bajaj spare parts
AB151049	BOLT M10 X 1	Bajaj spare parts
AB151052	PIPE BRAKE FRONT	Bajaj spare parts
AB151054	CONTAINER OIL WITH CAP	Bajaj spare parts
AB151063	CYL COMP TANDOM+OIL	Bajaj spare parts
AB151072	CAP BRAKE OIL RES	Bajaj spare parts
AB151073	KIT MAJOR TMC 4S PETR /	Bajaj spare parts
AB151074	KIT MINOR TMC 4S PETR / C	Bajaj spare parts
AB151079	SCREW BLEEDER	Bajaj spare parts
AB151090	CYLINDER. WHEEL FR	Bajaj spare parts
AB151091	CYLINDER. WHEEL RR	Bajaj spare parts
AB151092	KIT MAJOR WHEEL CYL.ASY.D	Bajaj spare parts
AB151093	KIT MINOR WH CYL 4S PETR	Bajaj spare parts
AB151094	KIT MAJOR WHEEL CYL.DIA.2	Bajaj spare parts
AB151095	KIT MINOR WH CYL 4S PETR	Bajaj spare parts
AB151126	PEDAL BREAK ASSEMBLY	Bajaj spare parts
AB161159	CLIP	Bajaj spare parts
AB161182	PLATE CHECK MTG MUDGUARD	Bajaj spare parts
AB161183	PLATE HEAD LAMP HOUSING	Bajaj spare parts
AB171003	HUB WHEEL FRONT	Bajaj spare parts
AB171013	BUSH TOP RUBBER	Bajaj spare parts
AB171014	CUP LOCATING TOP BUSH	Bajaj spare parts
AB171015	SPACER NUT SPRING CU	Bajaj spare parts



AB171016	BUSH FR SHOCK ABS	Bajaj spare parts
AB171017	SPRING FR SUSP 4S PETR/C	Bajaj spare parts
AB171019	SHOCK ABS FR 4S PETR/CNG/	Bajaj spare parts
AB171020	BUSH - NEEDLE	Bajaj spare parts
AB171022	CUP GREASE NUT	Bajaj spare parts
AB171023	CAP FR WHEEL HUB	Bajaj spare parts
AB171031	BOLT SHOCK MOUNTING	Bajaj spare parts
AB171034	AXLE FRONT FE 4S	Bajaj spare parts
AB171037	SPACER	Bajaj spare parts
AB171044	SHOCK ABSORBER FRONT FE	Bajaj spare parts
AB181002	COLUMN STEERING 4S PETR /	Bajaj spare parts
AB181011	BEARING RACE LOWER INNER	Bajaj spare parts
AB181012	BALL STEEL NLON CAGE	Bajaj spare parts
AB181017	BALL STEEL+NYLON CAGE	Bajaj spare parts
AB181019	BEARING RACE UPPER OUTER	Bajaj spare parts
AB181020	WASHER SPACER TOP BRG RA	Bajaj spare parts
AB181022	PLATE ASSY LOWER	Bajaj spare parts
AB181033	RACE BEARING LOWER OUTER	Bajaj spare parts
AB201004	CAP (STARTER RELAY)	Bajaj spare parts
AB201017	CAP BATTERY	Bajaj spare parts
AB201065	HOUSING HEAD LAMP	Bajaj spare parts
AB201072	LAMP HEAD 4S PETR / CNG /	Bajaj spare parts
AB201075	SWITCH R BR 4S PETR / CNG	Bajaj spare parts
AB201076	RELAY FLASHER HAZARD	Bajaj spare parts
AB201077	SWITCH HAZARD WARNING GC10	Bajaj spare parts
AB201083	GEAR ASSY HELICAL WIPER MOTOR	Bajaj spare parts
AB201084	GEAR ASSY REDUCTION	Bajaj spare parts
ABOX2424	ACC BOX ASSLY REFL 145 PETROL	Bajaj spare parts
ABOXAF11	ACC BOX ASSLY REFRESH	Bajaj spare parts
ABOXAF12	ACC BOX ASSLY REFRESH	Bajaj spare parts
ABOXAF18	ACCESSORIES BOX FOR COMPACT 4S CNG BSVI	Bajaj spare parts
ABOXAL27	ACCESSORIES BOX REFL CARGO	Bajaj spare parts
ABOXAN23	ACC BOX FOR RE CARGO CNG	Bajaj spare parts
ABOXAT04	maxima Wider body CNG/LPG accessories bo	Bajaj spare parts
ABOXAT12	ACCESSORIES BOX FOR XW CNG/LPG BSVI	Bajaj spare parts
ABOXBA08	ACC BOX ASSLY REFL 445 DSL TW HL	Bajaj spare parts
ABOXBA10	ACC BOX ASSLY 445 DSL	Bajaj spare parts
ABOXBB07	ACC BOX ASSLY REFL 445L	Bajaj spare parts
ABOXBB12	ACC-BOX-BAJAJ MAXIMA WB	Bajaj spare parts
ABOXBH04	ACC BOX ASSLY 445 UG	Bajaj spare parts
ABOXBH09	ACCESSORIES BOX MAXIMA Z-BSVI	Bajaj spare parts
AC201021	GASKET FOR TAIL LIGHT	Bajaj spare parts
AE101006	ENGINE GEAR	Bajaj spare parts
AE101007	SILENCER RE 2S 5PFLANGE	Bajaj spare parts
AE101014	CLUTCH ASSY BIGGER 5P	Bajaj spare parts

AE101015	PLATE DRIVEN BIG CLUT	Bajaj spare parts
AE101016	PLATE ASSY DRIVING BIG CL	Bajaj spare parts
AE101042	CRANKCASE ASSY EXT.PICKUP 5P RE 2S	Bajaj spare parts
AE101069	PIPE BREATHER FOR 3WH2SRE	Bajaj spare parts
AE101070	TUBE BREATHER	Bajaj spare parts
AE101071	BUSH CLUTCH	Bajaj spare parts
AE121001	VALVE REED	Bajaj spare parts
AE121006	CARBURETTOR UCAL	Bajaj spare parts
AE121007	JET MAIN 90 UCAL CARB	Bajaj spare parts
AE131010	COVER DIFFERENTIAL `RE 5	Bajaj spare parts
AE131011	GEAR DIFFERENTIAL 5 P RE	Bajaj spare parts
AF010163	EMBLEM BAJAJ RE	Bajaj spare parts
AF101014	EXE TUBE W/O CAT LH	Bajaj spare parts
AF101023	ENGINE ASSLY COMPLETE	Bajaj spare parts
AF101035	TUBE BREATHER	Bajaj spare parts
AF101043	SILENCER ASSY.COMP-BASFSILENCER ASSY.COM	Bajaj spare parts
AF101048	ASSLY EXHAUST TUBE-BASF	Bajaj spare parts
AF101054	ASSLY PISTON - 10.5 CR	Bajaj spare parts
AF101058	BS4 ASSY PISTON CNG SPRL	Bajaj spare parts
AF101073	ENGINE ASSY. COMPLETE RE205 FL	Bajaj spare parts
AF101075	SILENCER ASSLY COMPLETE	Bajaj spare parts
AF101076	MUFFLER ASSY COMPLETE	Bajaj spare parts
AF101080	ASSLY EXHAUST TUBE	Bajaj spare parts
AF101087	COVER CLUTCH-205FL	Bajaj spare parts
AF101088	ENGINE ASSY. BS4-COMPACT CNG 4S	Bajaj spare parts
AF101097	BS4 ASSY EX.TUBE CNG	Bajaj spare parts
AF101147	CLUTCH ASSEMBLY	Bajaj spare parts
AF101148	HOUSING ASSEMBLY CLUTCH	Bajaj spare parts
AF101152	PINON PRIMARY	Bajaj spare parts
AF101167	NUT CLIP	Bajaj spare parts
AF101170	ENGINE ASSEMBLY	Bajaj spare parts
AF101198	COWLING ASSEMBLY EXHAUST	Bajaj spare parts
AF101202	ENGINE ASSEMBLY	Bajaj spare parts
AF101208	GEAR IDLER	Bajaj spare parts
AF101209	GEAR REVERSE	Bajaj spare parts
AF101235	SILENCER ASSEMBLY	Bajaj spare parts
AF101236	PIPE ASSEMBLY A	Bajaj spare parts
AF101243	MUFFLER ASSEMBLY	Bajaj spare parts
AF101272	HEAD CYLINDER	Bajaj spare parts
AF101277	CRANKSHAFT ASSEMBLY	Bajaj spare parts
AF101340	GASKET CRANKCASE	Bajaj spare parts
AF101420	HEAD CYLINDER ASSEMBLY	Bajaj spare parts
AF101421	HEAD CYLINDER	Bajaj spare parts
AF101432	SILENCER ASSEMBLY	Bajaj spare parts
AF101440	GEAR SPEED SECOND	Bajaj spare parts

AF101441	GEAR SPEED THIRD	Bajaj spare parts
AF101442	GEAR MULTIPLE	Bajaj spare parts
AF101444	CRANKCASE MAGNETO SIDE	Bajaj spare parts
AF101445	VALVE EXHAUST	Bajaj spare parts
AF101452	CRANKCASE CLUTCH SIDE	Bajaj spare parts
AF101465	PINION PRIMARY	Bajaj spare parts
AF101470	CRANKCASE CLUTCH SIDE	Bajaj spare parts
AF101473	BRACKET MOTOR STARTER	Bajaj spare parts
AF101480	SILENCER ASSEMBLY	Bajaj spare parts
AF101481	PIPE ASSEMBLY A	Bajaj spare parts
AF101482	MUFFLER ASSEMBLY	Bajaj spare parts
AF101548	BRACKET	Bajaj spare parts
AF101743	BRACKET PIPE COOLER OIL	Bajaj spare parts
AF101758	SLEEVE PLUG SPARK	Bajaj spare parts
AF101772	SPROCKET CRANKSHAFT	Bajaj spare parts
AF101857	SILENCER ASSEMBLY	Bajaj spare parts
AF101858	MUFFLER ASSEMBLY	Bajaj spare parts
AF111010	COIL H.TRE4S	Bajaj spare parts
AF111012	COIL H. T. 4S CNG	Bajaj spare parts
AF111016	CONTROLLER IGNITER & GAS	Bajaj spare parts
AF111021	STARTER MOTOR ASSY COMPT	Bajaj spare parts
AF111022	ASSLY CDI - CNG FL	Bajaj spare parts
AF111023	ASSLY BRACKET FIXING	Bajaj spare parts
AF111026	ASSLY. CDI MULTIMAP - CNG	Bajaj spare parts
AF111031	CAP SPARK PLUG LH SOLID POST	Bajaj spare parts
AF111032	CAP SPARK PLUG RH SOLID POST	Bajaj spare parts
AF111033	GROMMET FOR HT CABLE	Bajaj spare parts
AF111034	GROMMET FOR SPARK PLUG CAP-LH	Bajaj spare parts
AF111035	GROMMET FOR SPARK PLUG CAP RH	Bajaj spare parts
AF111046	BRACKET COIL IGNITION	Bajaj spare parts
AF111049	COIL ASSEMBLY IGNITION LH	Bajaj spare parts
AF111050	COIL ASSEMBLY IGNITION RH	Bajaj spare parts
AF111052	ECU EMS ASSEMBLY	Bajaj spare parts
AF111073	ROTOR ASSEMBLY	Bajaj spare parts
AF111113	BRACKET COIL IGNITION	Bajaj spare parts
AF111116	COIL ASSEMBLY IGNITION	Bajaj spare parts
AF121001	CONNECTOR	Bajaj spare parts
AF121004	REFUELLING UNIT	Bajaj spare parts
AF121012	WASHER	Bajaj spare parts
AF121018	PLUG DUST MICRO SWITCH	Bajaj spare parts
AF121023	RING O	Bajaj spare parts
AF121025	WASHER	Bajaj spare parts
AF121026	RING O	Bajaj spare parts
AF121027	SEAT	Bajaj spare parts
AF121028	SPRING	Bajaj spare parts

AF121029	WASHER 3W4SRECNG	Bajaj spare parts
AF121030	WASHER 3W4SRECNG	Bajaj spare parts
AF121032	RING O	Bajaj spare parts
AF121034	SPRING	Bajaj spare parts
AF121036	RING - O FOR 3W-4S-RE-CNG	Bajaj spare parts
AF121039	SPRING VALVE RELIEF	Bajaj spare parts
AF121040	SCREW ADJUST	Bajaj spare parts
AF121043	RETAINER	Bajaj spare parts
AF121044	PLATE MOUNTING	Bajaj spare parts
AF121045	SCREW M3 X 14 L	Bajaj spare parts
AF121046	SCREW M3 X 15 L	Bajaj spare parts
AF121058	WASHER 2ND STAG REGU	Bajaj spare parts
AF121070	SCREW - CHEESE HEAD FOR 3W-4S-RE-CNG	Bajaj spare parts
AF121085	WASHER	Bajaj spare parts
AF121104	RING O	Bajaj spare parts
AF121105	RETAINER	Bajaj spare parts
AF121106	RING O	Bajaj spare parts
AF121107	FILTER FIRST STAGE REDUC	Bajaj spare parts
AF121108	WASHER 4.5 X 11	Bajaj spare parts
AF121125	FIRST STAGE CYLINDER <(>&	Bajaj spare parts
AF121126	FIRST STAGE PISTON S	Bajaj spare parts
AF121127	PAD HLDRSRV SUBASY	Bajaj spare parts
AF121130	DIAPHRAGM ASSY 3RD STAGE	Bajaj spare parts
AF121133	FILTER COMPT-FUEL FOR 3WH-RE	Bajaj spare parts
AF121148	DUCT INTEGRAL	Bajaj spare parts
AF121316	Plug Drain Filter Sol Valve	Bajaj spare parts
AF121323	BOLT FOR FILTER SOLENOID	Bajaj spare parts
AF121327	NUT - LOCK:-FILTER SOLENOID VALVE(VANAZ)	Bajaj spare parts
AF121328	BELLOW ACCELE CABLE	Bajaj spare parts
AF121418	ASY COMP INTEGRAL DUCT	Bajaj spare parts
AF121422	CARBURETOR ASSY	Bajaj spare parts
AF121427	REGULATOR CNG TWO STAGE	Bajaj spare parts
AF121428	SEAT	Bajaj spare parts
AF121445	FLOAT BODY ASSLY	Bajaj spare parts
AF121465	COVER OIL FILTER	Bajaj spare parts
AF121487	ASSLY CNG REGULATOR	Bajaj spare parts
AF121489	BRACKET LPR MOUNTING VANAZ	Bajaj spare parts
AF121505	ASSLY AIR FILTER	Bajaj spare parts
AF121507	ASSLY COMP INTEGRAL DUCT	Bajaj spare parts
AF121514	HOSE LOW PRESSURE CNG	Bajaj spare parts
AF121519	BRACKET CARBURETTOR HOLDING	Bajaj spare parts
AF121521	REGULATOR TWO STAGE 205FL CNG	Bajaj spare parts
AF121522	CARBURETTOR ASSY.UCAL	Bajaj spare parts
AF121526	ASSLY DUCT INTEGRAL COMPLETE	Bajaj spare parts
AF121527	CARBURETTOR ASSY. FLANGE TYPE	Bajaj spare parts

AF121534	CARBURETTOR ASSY. FOR EVAP	Bajaj spare parts
AF121541	REGULATOR TWO STAGE CNG 4S	Bajaj spare parts
AF121547	ASSLY DUCT INTEGRAL - FI	Bajaj spare parts
AF121548	BRACKET HOLDING TH. BODY - FI	Bajaj spare parts
AF121550	INSULATOR FOR FI	Bajaj spare parts
AF121554	BODY FLOW CONTROL	Bajaj spare parts
AF121555	SCREW FLOW CONTROL	Bajaj spare parts
AF121567	SCREW FLOW CONTROL	Bajaj spare parts
AF121568	INJECTOR	Bajaj spare parts
AF121571	BODY THROTTLE ASSEMBLY	Bajaj spare parts
AF121574	PIPE BREATHER	Bajaj spare parts
AF121612	FILTER OIL	Bajaj spare parts
AF141030	VALVE CNG	Bajaj spare parts
AF141059	CYLINDER CNG 30LTR RE4S C	Bajaj spare parts
AF141071	PIPE FUEL SOLENOID TO CARB	Bajaj spare parts
AF141072	PIPE FUEL FILTER TO SOLENOID	Bajaj spare parts
AF141074	ASSLY TANK FUEL LIMP HOME	Bajaj spare parts
AF141075	TANK FUEL LIMP HOME 3 LTR	Bajaj spare parts
AF141082	PIPE FUEL SOLENOID TO CARB.	Bajaj spare parts
AF141097	VALVE CNG	Bajaj spare parts
AF141099	SOLENOID	Bajaj spare parts
AF141100	FILTER	Bajaj spare parts
AF141101	HOSE SOLENOID-RAIL	Bajaj spare parts
AF141102	ELBOW	Bajaj spare parts
AF141105	RAIL ASSEMBLY CNG	Bajaj spare parts
AF141108	HOSE SOLENOID-FILTER	Bajaj spare parts
AF141111	REGULATOR LOW PRESSURE CNG	Bajaj spare parts
AF141112	REGULATOR HIGH PRESSURE CNG	Bajaj spare parts
AF141113	HOSE SOLENOID-REGULATOR	Bajaj spare parts
AF141115	VALVE CNG	Bajaj spare parts
AF141122	VALVE CNG	Bajaj spare parts
AF141126	TANK ASSEMBLY FUEL	Bajaj spare parts
AF141137	PIPE ASSEMBLY TANK-JOINT	Bajaj spare parts
AF141150	HOSE FILTER-LPR	Bajaj spare parts
AF141208	FILTER	Bajaj spare parts
AF141216	HOSE RAIL-INJECTOR	Bajaj spare parts
AF151022	SPACER	Bajaj spare parts
AF151037	PANEL ASSEMBLY BRAKE FRONT	Bajaj spare parts
AF151038	PANEL ASSEMBLY BRAKE REAR LH	Bajaj spare parts
AF151039	PANEL ASSEMBLY BRAKE REAR RH	Bajaj spare parts
AF151079	DRUM BRAKE	Bajaj spare parts
AF151080	HUB FRONT	Bajaj spare parts
AF151086	CLAMP	Bajaj spare parts
AF151089	WHEEL 3.00BX8H2	Bajaj spare parts
AF151091	TYRE 4.00-8	Bajaj spare parts

AF151105	PIPE ASSEMBLY BRAKE REAR	Bajaj spare parts
AF161024	LABEL CNG	Bajaj spare parts
AF161040	LABEL CNG DELHI REQMT	Bajaj spare parts
AF161059	PIN FOR CYL. CL STRAP	Bajaj spare parts
AF161097	BEADING STRAP	Bajaj spare parts
AF161098	STRAP ASSY	Bajaj spare parts
AF161100	PACKING LOWER FOR GA	Bajaj spare parts
AF161131	BRACKET ECU UPPER	Bajaj spare parts
AF161144	COVER PLATE ELECTRICAL REAR	Bajaj spare parts
AF161178	SPACER	Bajaj spare parts
AF161186	BRACKET ENGINE FRONT	Bajaj spare parts
AF161207	'LATE ASSEMBLY ELECTRICAL FRONT	Bajaj spare parts
AF161231	SPACER	Bajaj spare parts
AF161257	BEADING	Bajaj spare parts
AF161281	ISOLATOR	Bajaj spare parts
AF161296	BRACKET LH	Bajaj spare parts
AF161297	BRACKET RH	Bajaj spare parts
AF161300	MEMBER ASSEMBLY ENGINE	Bajaj spare parts
AF161305	PLATE ASSEMBLY ELECTRICAL	Bajaj spare parts
AF161448	BRACKET ASSEMBLY ENGINE FRONT	Bajaj spare parts
AF161572	TRAY ASSEMBLY BATTERY	Bajaj spare parts
AF161591	PLATE ASSEMBLY ELECTRICAL FRONT	Bajaj spare parts
AF161837	GROMMET	Bajaj spare parts
AF161838	BRACKET DASHBOARD FRONT LH	Bajaj spare parts
AF161839	BRACKET DASHBOARD FRONT RH	Bajaj spare parts
AF170008	CAP LINK FRONT	Bajaj spare parts
AF170012	SPRING SHOCKABSORBER REAR	Bajaj spare parts
AF181010	LOCK SET RE 4S GAS VEHICL	Bajaj spare parts
AF181031	SET LOCK	Bajaj spare parts
AF181039	SET LOCK	Bajaj spare parts
AF181047	COVER HANDLEBAR	Bajaj spare parts
AF181055	SET LOCK	Bajaj spare parts
AF191005	ACC CABL2974 205M AS	Bajaj spare parts
AF191007	CHOKE CABL2582 205D	Bajaj spare parts
AF191012	CABLE ACCELERATOR COMPLETE FI	Bajaj spare parts
AF191030	CABLE ACCELERATOR	Bajaj spare parts
AF191032	CLAMP	Bajaj spare parts
AF191033	CLAMP	Bajaj spare parts
AF191041	GROMMET	Bajaj spare parts
AF191074	SPRING TENSION	Bajaj spare parts
AF191075	CABLE REVERSE	Bajaj spare parts
AF191078	SPEEDOMETER CLUSTER	Bajaj spare parts
AF201001	RELAY	Bajaj spare parts
AF201008	REGULATOR	Bajaj spare parts
AF201010	SWITCH MICRO VANAZ 4S CNG	Bajaj spare parts

AF201022	SOLENOID GAS	Bajaj spare parts
AF201036	REGULATOR	Bajaj spare parts
AF201046	HARNESS WIRING FRONT 4S	Bajaj spare parts
AF201053	SWITCH ON OFF RE 4S CNG	Bajaj spare parts
AF201067	SOLENOID CNG+PAPER FILTER	Bajaj spare parts
AF201081	LAMP ASSEMBLY CABIN	Bajaj spare parts
AF201094	SWITCH BRAKE RE 4S	Bajaj spare parts
AF201141	FUSE BOX	Bajaj spare parts
AF201144	INDICATOR ASSLY RH POD(CN	Bajaj spare parts
AF201146	SWITCH START	Bajaj spare parts
AF201162	HARNESS WIRING (FRONT)	Bajaj spare parts
AF201163	HARNESS WIRING(CHASSIS)	Bajaj spare parts
AF201172	HARNESS WIRING FR 205D CNG FL	Bajaj spare parts
AF201173	HARNESS WIRING REAR 205D	Bajaj spare parts
AF201180	HARNESS REAR FL	Bajaj spare parts
AF201184	HARNESS FRONT RE COMPACT 4S CNG	Bajaj spare parts
AF201185	HARNESS REAR RE COMPACT 4S CNG	Bajaj spare parts
AF201188	HARNESS WIRING REAR CNG	Bajaj spare parts
AF201189	HARNESS BODY GAS	Bajaj spare parts
AF201193	HARNESS BODY GAS	Bajaj spare parts
AF201196	HARNESS FRONT RE COMPACT 4S CNG	Bajaj spare parts
AF201200	HARNESS WIRING FRONT	Bajaj spare parts
AF201201	HARNESS WIRING-REAR	Bajaj spare parts
AF201205	HARNESS WIRING-FRONT-CNG	Bajaj spare parts
AF201206	HARNESS WIRING-REAR-CNG	Bajaj spare parts
AF201207	CABLE BATTERY-POSITIVE	Bajaj spare parts
AF201208	CABLE PLATE ELECTRICAL	Bajaj spare parts
AF201210	HARNESS WIRING FRONT CNG	Bajaj spare parts
AF201213	HARNESS WIRING REAR CNG	Bajaj spare parts
AF201218	INDICATOR POD RH	Bajaj spare parts
AF201220	HARNESS WIRING FRONT	Bajaj spare parts
AF201221	HARNESS WIRING REAR	Bajaj spare parts
AF201222	HARNESS WIRING BODY	Bajaj spare parts
AF201226	BOX ASSLY FUSE	Bajaj spare parts
AF201231	CABLE EARTH	Bajaj spare parts
AF201236	INDICATOR POD RH	Bajaj spare parts
AF201238	REGULATOR	Bajaj spare parts
AF201248	REGULATOR	Bajaj spare parts
AF201257	CABLE PLATE ELECTRICAL FRONT	Bajaj spare parts
AF201262	RELAY STARTER	Bajaj spare parts
AF201266	CAP ECU	Bajaj spare parts
AF201267	CABLE SENSOR TEMPERATURE	Bajaj spare parts
AF201272	HARNESS WIRING BODY	Bajaj spare parts
AF201273	CABLE BATTERY POSITIVE	Bajaj spare parts
AF201274	GROMMET RELAY STARTER	Bajaj spare parts

AF201285	HARNESS WIRING REAR	Bajaj spare parts
AF201286	HARNESS WIRING BODY	Bajaj spare parts
AF201295	HARNESS WIRING FRONT	Bajaj spare parts
AF201296	HARNESS WIRING REAR	Bajaj spare parts
AF201297	HARNESS WIRING BODY	Bajaj spare parts
AF201298	SWITCH SELECTOR FUEL	Bajaj spare parts
AF201311	HARNESS WIRING FRONT	Bajaj spare parts
AF201326	UNIT INJECTOR DRIVER	Bajaj spare parts
AF201332	UNIT RESISTOR	Bajaj spare parts
AF201334	SWITCH CONTROL LH	Bajaj spare parts
AF201335	SWITCH CONTROL RH	Bajaj spare parts
AF201336	ASSEMBLY PLATE ELECTRICAL FRONT	Bajaj spare parts
AF201349	BEEPER	Bajaj spare parts
AF201351	CABLE PLATE ELECTRICAL	Bajaj spare parts
AF201352	HARNESS WIRING FRONT	Bajaj spare parts
AF201353	HARNESS WIRING REAR	Bajaj spare parts
AF201356	RELAY	Bajaj spare parts
AF201360	SENSOR LEVEL FUEL	Bajaj spare parts
AF201392	UNIT RESISTOR	Bajaj spare parts
AF201411	HARNESS WIRING REAR	Bajaj spare parts
AF201437	HARNESS WIRING FRONT	Bajaj spare parts
AF201438	HARNESS WIRING REAR	Bajaj spare parts
AF210003	ASSLY SEAT DRIVER GREEN	Bajaj spare parts
AF210011	SEAT ASSLY-DRIVER-GREEN	Bajaj spare parts
AF221006	BRACKET EXTINGUISHER FIRE SAFEX	Bajaj spare parts
AF221007	EXTINGUISHER FIRE AND BKT ASSY	Bajaj spare parts
AF221011	PLATE COMPLIANCE CNG	Bajaj spare parts
AF221022	ASSLY BRACKET FIRE EXTING MTG	Bajaj spare parts
AF231078	BACKREST DRIVER	Bajaj spare parts
AF231079	SEAT ASSY PASS. BL.RE4S INDONESIA	Bajaj spare parts
AF231183	ASSLY PASSENGER SEAT GREEN	Bajaj spare parts
AF231184	ASSLY BACKREST PASS GREEN	Bajaj spare parts
AF231213	HOOD COMPLETE BLACK	Bajaj spare parts
AF231214	HOOD COMPLETE MUSHROOM	Bajaj spare parts
AF231215	HOOD COMPLETE GREEN	Bajaj spare parts
AF231467	FOAM	Bajaj spare parts
AF231468	FOAM	Bajaj spare parts
AF231499	LABEL BS6 FRONT	Bajaj spare parts
AF231500	LABEL BS6 REAR	Bajaj spare parts
AF231573	HINGE DOOR REAR	Bajaj spare parts
AF231650	PLATE SCUFF LH	Bajaj spare parts
AF231657	FRAME ASSEMBLY HOOD	Bajaj spare parts
AF231702	LATCH DOOR LH	Bajaj spare parts
AF231703	LATCH DOOR RH	Bajaj spare parts
AF231708	DAMPER	Bajaj spare parts



AF231720	TUBE ASSEMBLY SUPPORT BACKREST	Bajaj spare parts
AF231722	BACKREST ASSEMBLY DRIVER	Bajaj spare parts
AF231741	PLATE SCUFF LH	Bajaj spare parts
AF231742	PLATE SCUFF RH	Bajaj spare parts
AF231743	PLATE SCUFF RH	Bajaj spare parts
AF231754	COVER PANEL BODY LH	Bajaj spare parts
AF231755	COVER PANEL BODY RH	Bajaj spare parts
AF231756	TRIM DOOR INNER LH	Bajaj spare parts
AF231757	TRIM DOOR INNER RH	Bajaj spare parts
AF231775	PLATE STRIKER	Bajaj spare parts
AF231779	HOOD ASSEMBLY BLACK	Bajaj spare parts
AF231780	HOOD ASSEMBLY GREEN	Bajaj spare parts
AF231781	HOOD ASSEMBLY MUSHROOM	Bajaj spare parts
AF231782	HOOD ASSEMBLY YELLOW	Bajaj spare parts
AF231783	HOOD ASSEMBLY PINK	Bajaj spare parts
AF231784	HOOD ASSEMBLY SALMON ORANGE	Bajaj spare parts
AF990012	SEPARATOR	Bajaj spare parts
AF990016	SEPARATOR	Bajaj spare parts
AF990038	CABLE HARNESS	Bajaj spare parts
AF990041	SLEEVE	Bajaj spare parts
AG101010	SHAFT DRIVE 3WH RE 2S LPG	Bajaj spare parts
AG101011	DRIVE SHAFT PUMP OIL	Bajaj spare parts
AG101012	CRANKSHAFT ASSY RE 4S	Bajaj spare parts
AG101039	ASSEMBLY SILENCER	Bajaj spare parts
AG101041	ENGINE ASSY COMPACT 2S-BS4 ES	Bajaj spare parts
AG101053	ENGINE ASSEMBLY	Bajaj spare parts
AG121072	ASSLY COMP. INTEGRAL DUCT	Bajaj spare parts
AG121077	CARBURETOR ASSY	Bajaj spare parts
AG121096	ASSLY HOSE COMPLETE INTEGRAL	Bajaj spare parts
AG121097	INSERT RESTRICTOR - BELLOW A/F INLET BSI	Bajaj spare parts
AG121098	INSERT RESTRICTOR ELBOW DIA.13 BSIV	Bajaj spare parts
AG121099	CARBURETTOR ASSLY-LPG	Bajaj spare parts
AG201026	ASSLY INDICATOR LPG	Bajaj spare parts
AG201030	HARNESS FRONT RE145 ES LPG	Bajaj spare parts
AG201031	HARNESS REAR RE145 ES LPG	Bajaj spare parts
AG201032	SWITCH G O P LPG HORIZONTAL FL	Bajaj spare parts
AG201035	ASSLY GAS INDICATOR LPG FL	Bajaj spare parts
AG201038	ASSLY CDI RE145 NES GAS	Bajaj spare parts
AG201039	HARNESS REAR RE145 NES LPG	Bajaj spare parts
AG201046	HARNESS FRONT ES	Bajaj spare parts
AG201047	HARNESS REAR ES	Bajaj spare parts
AG201054	HARNESS REAR ES	Bajaj spare parts
AG201057	HARNESS FRONT RE 2S LPG ES	Bajaj spare parts
AG201058	ASSLY GAS INDICATOR LPG	Bajaj spare parts
AG201059	HARNESS ES-LPG-REAR	Bajaj spare parts

AG201061	HARNESS FRONT-ES-LPG	Bajaj spare parts
AG201064	HARNESS FRONT-ES-LPG	Bajaj spare parts
AG201065	HARNESS REAR-ES-LPG	Bajaj spare parts
AG201069	INDICATOR ASSEMBLY	Bajaj spare parts
AG201071	HARNESS WIRING FRONT ES LPG	Bajaj spare parts
AG201072	HARNESS WIRING REAR	Bajaj spare parts
AG201075	HARNESS WIRING FRONT LPG ES	Bajaj spare parts
AH111058	BRACKET VCU MOUNTING TOP	Bajaj spare parts
AH111119	NUT	Bajaj spare parts
AH111204	FOOTREST	Bajaj spare parts
AH122036	SHOCKABSORBER REAR	Bajaj spare parts
AH122069	ASSEMBLY ARM TRAILING RH	Bajaj spare parts
AH122089	SPRING SUSPENSION REAR	Bajaj spare parts
AH131144	WHEEL 3.00BX12H2	Bajaj spare parts
AH131148	TYRE 130/80-R12 C TL	Bajaj spare parts
AH131211	PLATE LOCK	Bajaj spare parts
AH131617	DRUM ASSEMBLY BRAKE	Bajaj spare parts
AH131840	HOSE	Bajaj spare parts
AH131845	PIPE ASSEMBLY BRAKE FRONT	Bajaj spare parts
AH131850	ASSLY ROD BRAKE FRONT	Bajaj spare parts
AH131851	ROD BRAKE FRONT	Bajaj spare parts
AH131852	BRACKET EQUALIZER	Bajaj spare parts
AH131853	COVER EQUALIZER	Bajaj spare parts
AH131859	CABLE BRAKE PARKING REAR LH	Bajaj spare parts
AH131861	PIN	Bajaj spare parts
AH131866	CYLINDER ASSEMBLY TANDEM MASTER	Bajaj spare parts
AH131867	CYLINDER TANDEM MASTER	Bajaj spare parts
AH151116	COLUMN ASSEMBLY STEERING	Bajaj spare parts
AH162014	SLEEVE	Bajaj spare parts
AH181044	TRIM ASSLY MIDDLE	Bajaj spare parts
AH181066	TRAY ASSEMBLY	Bajaj spare parts
AH181284	COVER BATTERY	Bajaj spare parts
AH182403	COVER PILLAR C TOP LH	Bajaj spare parts
AH182404	COVER PILLAR C TOP RH	Bajaj spare parts
AH185002	BEADING MUDGUARD	Bajaj spare parts
AH185003	MUDGUARD REAR RH	Bajaj spare parts
AH185005	MUDGUARD REAR LH	Bajaj spare parts
AH185007	CLIP	Bajaj spare parts
AH185012	CLIP	Bajaj spare parts
AH191050	BRACKET BACKREST	Bajaj spare parts
AH191051	BRACKET	Bajaj spare parts
AH191065	BRACKET	Bajaj spare parts
AH213078	BRACKET PILLAR B OUTER LH	Bajaj spare parts
AH213079	BRACKET PILLAR B OUTER RH	Bajaj spare parts
AH213080	BRACKET PILLAR B INNER RH	Bajaj spare parts

AH213081	BRACKET PILLAR B INNER LH	Bajaj spare parts
AH231800	MAT FOOTREST	Bajaj spare parts
AH291005	ASSEMBLY POWER PACK	Bajaj spare parts
AH291012	ASSEMBLY POWER PACK	Bajaj spare parts
AH301053	ASSEMBLY MCU	Bajaj spare parts
AH301207	MOTOR DRIVE	Bajaj spare parts
AH351800	SENSOR INDICATOR GEAR	Bajaj spare parts
AH353000	MOTOR GEAR SHIFT	Bajaj spare parts
AH401014	LAMP CABIN	Bajaj spare parts
AH401402	SWITCH CONTROL RH	Bajaj spare parts
AH401408	HOLDER MAGNET	Bajaj spare parts
AH401409	SWITCH BRAKE PARKING	Bajaj spare parts
AH401444	SWITCH CONTROL LH	Bajaj spare parts
AH402274	FUSE 15A	Bajaj spare parts
AH402286	FUSE 7.5A	Bajaj spare parts
AH402305	CABLE MAINS AC	Bajaj spare parts
AH402316	FUSE 10A	Bajaj spare parts
AH402330	FUSE 5A	Bajaj spare parts
AH402382	CLIP	Bajaj spare parts
AH402386	FUSE 30A	Bajaj spare parts
AH402387	FUSE 25A	Bajaj spare parts
AH402801	MOTOR WIPER	Bajaj spare parts
AH403007	RELAY COOLING BOX	Bajaj spare parts
AH403217	GROMMET	Bajaj spare parts
AH403250	CONVERTER DC-DC	Bajaj spare parts
AH403607	SENSOR SPEED	Bajaj spare parts
AH404123	HARNESS WIRING FRONT	Bajaj spare parts
AH404144	HARNESS WIRING REAR	Bajaj spare parts
AH404171	CABLE CHARGER MAINS	Bajaj spare parts
AH404176	HARNESS WIRING FRONT	Bajaj spare parts
AH404199	FUSE 70A	Bajaj spare parts
AH552027	PIPE ASSEMBLY BREATHER	Bajaj spare parts
AK201012	FUSE 10A BLADE TYPE	Bajaj spare parts
AL101019	WASHER	Bajaj spare parts
AL101020	ISOLATOR RUBBER	Bajaj spare parts
AL101029	PULLEY	Bajaj spare parts
AL101030	ROPE - PULLEY	Bajaj spare parts
AL101037	BOLT ISOLATOR	Bajaj spare parts
AL101038	BOLT PULLY	Bajaj spare parts
AL101040	SILENCER TUBUCRADLE	Bajaj spare parts
AL101053	GUARD SPLASH	Bajaj spare parts
AL103000	ASSLY AIR INTAKE Z PIPE	Bajaj spare parts
AL103003	PLUG DRAIN	Bajaj spare parts
AL111009	ECU EMS ASSEMBLY	Bajaj spare parts
AL111015	ECU EMS ASSEMBLY	Bajaj spare parts

AL121015	TUBE FUEL 3	Bajaj spare parts
AL121019	CLIP PIPE AIR	Bajaj spare parts
AL121020	JOINT	Bajaj spare parts
AL121031	PIPE FUEL OVER FLOW	Bajaj spare parts
AL121060	FILTER AIR ASSLY	Bajaj spare parts
AL121062	ELEMENT AIR FILTER	Bajaj spare parts
AL121063	TUBE AIR-1FILTER	Bajaj spare parts
AL121068	SEAL RING FLAT	Bajaj spare parts
AL121069	CLAMP FLAT	Bajaj spare parts
AL121070	COVER	Bajaj spare parts
AL121075	TUBE AIR INTAKE	Bajaj spare parts
AL131006	BUSH FAREMETER	Bajaj spare parts
AL131007	SHAFT FAREMETER	Bajaj spare parts
AL131020	GASKET DIFFERE COVER	Bajaj spare parts
AL131032	CROSS 7 MM	Bajaj spare parts
AL131051	GASKET GEAR BOX COVER	Bajaj spare parts
AL131055	CROSS DIFFERENTIAL	Bajaj spare parts
AL131058	GEAR SATELLITE	Bajaj spare parts
AL131059	GEAR BEVEL	Bajaj spare parts
AL131074	PLUG OIL	Bajaj spare parts
AL131075	BUFFER RUBBER	Bajaj spare parts
AL131076	PLUG OIL DIFFERENTIAL	Bajaj spare parts
AL131081	SHAFT GEAR REVERSE CONTRO	Bajaj spare parts
AL131127	BOLT DIFF. PRECOATING	Bajaj spare parts
AL131128	GEAR SHIFTER ASSY GC100	Bajaj spare parts
AL133000	ASSLY TRANSMISSION	Bajaj spare parts
AL133003	ASSLY DRIVE SHAFT LH	Bajaj spare parts
AL133004	ASSLY DRIVE SHAFT RH	Bajaj spare parts
AL133005	BAR SHAFT LH	Bajaj spare parts
AL133006	BAR SHAFT RH	Bajaj spare parts
AL141039	LOCK CAP TANK FUEL	Bajaj spare parts
AL141048	TANK ASSEMBLY	Bajaj spare parts
AL141054	PIPE TANK TO FILTER	Bajaj spare parts
AL141058	PIPE AIR VENT	Bajaj spare parts
AL141069	PIPE ASSEMBLY FUEL	Bajaj spare parts
AL141070	PIPE ASSEMBLY FUEL	Bajaj spare parts
AL141071	PIPE ASSEMBLY FUEL	Bajaj spare parts
AL141078	CLAMP ASSEMBLY	Bajaj spare parts
AL151004	AXLE FRONT GC1000	Bajaj spare parts
AL151005	DISTANCE PIECE	Bajaj spare parts
AL151007	COLLAR	Bajaj spare parts
AL151008	SPACER ASSY	Bajaj spare parts
AL151011	NUT COLLAR	Bajaj spare parts
AL151012	CLIP LOCKING	Bajaj spare parts
AL151014	RIM WHEEL GC1000	Bajaj spare parts

AL151027	FLANGE BACK PLATE	Bajaj spare parts
AL151041	SPRING RETURN SHOE	Bajaj spare parts
AL151045	CYLINDER WHEEL LH GC 1000	Bajaj spare parts
AL151052	CAP - BLEEDER	Bajaj spare parts
AL151053	WASHER - SPRING (B6)	Bajaj spare parts
AL151054	BOLT - M6 X 12	Bajaj spare parts
AL151061	STRUT SUBASSEMBLY RH	Bajaj spare parts
AL151062	SPRING SHOE SET TRAILIN	Bajaj spare parts
AL151064	CYLINDER WHEEL RH	Bajaj spare parts
AL151089	NUT SPECIAL M16 X 1.5P	Bajaj spare parts
AL151093	DRUM BRAKE FR GC1000	Bajaj spare parts
AL151096	KIT MAJOR ASY	Bajaj spare parts
AL151097	KITMINORMC ASSY.	Bajaj spare parts
AL151104	LEVERHAND BRAKE	Bajaj spare parts
AL151130	KIT MAJOR CYLINDER	Bajaj spare parts
AL151131	KIT MINORWHEEL CYL	Bajaj spare parts
AL151141	BRAKE CABL1656 445L	Bajaj spare parts
AL151151	DRUM BRAKE RR C.I. GC 10	Bajaj spare parts
AL151168	PAD HEEL REST	Bajaj spare parts
AL151169	PIPE ASSY REAR BRAKE	Bajaj spare parts
AL151171	CYLINDER COMP.TANDOM	Bajaj spare parts
AL151176	SHOE BRAKE LEADING	Bajaj spare parts
AL151177	SHOE COMP TRAIL W RH	Bajaj spare parts
AL151178	SHOE COMP TRAIL W LH	Bajaj spare parts
AL151179	SHOE TRAILING W/O HB	Bajaj spare parts
AL151187	CLAMP BRAKE HOSE	Bajaj spare parts
AL151192	BACKPLATE FRONT	Bajaj spare parts
AL151193	CYLINDER WHEEL FRONT	Bajaj spare parts
AL151194	AUTO ADJUSTER FRONT	Bajaj spare parts
AL151205	BOLT MOUNTING W/CYL	Bajaj spare parts
AL151210	ASSLY WHEEL CYLINDER REAR RH	Bajaj spare parts
AL151211	ASSLY AUTO ADJUSTER REAR LH	Bajaj spare parts
AL151212	ASSLY AUTO ADJUSTER REAR RH	Bajaj spare parts
AL151220	ASSLY BRAKE PIPE RR2 3WCARGO	Bajaj spare parts
AL151222	BRAKE CABL1340 CARGO	Bajaj spare parts
AL151223	BRAKE CABL1806 CARGO	Bajaj spare parts
AL151231	ASSLY WHEEL CYLINDER FRONT	Bajaj spare parts
AL151235	ASSLY BRAKE PANEL WITH FLANGE	Bajaj spare parts
AL151236	PANEL ASS FR 3WH CARGO	Bajaj spare parts
AL151237	ASSLY PANEL REAR LH	Bajaj spare parts
AL151238	ASSLY PANEL REAR RH	Bajaj spare parts
AL151242	DRUM BRAKE FRONT	Bajaj spare parts
AL151243	HUB FRONT CARGO	Bajaj spare parts
AL151246	ASSLY RIM 3.50 B X 10	Bajaj spare parts
AL151249	ASSLY DRIVE FLANGE	Bajaj spare parts

AL151252	NUT CONICAL M12	Bajaj spare parts
AL151254	WIRE CIRCLIP	Bajaj spare parts
AL151266	FLANGE BACK PLATE	Bajaj spare parts
AL151277	PANEL ASSLY REAR LH	Bajaj spare parts
AL151278	PANEL ASSLY REAR RH	Bajaj spare parts
AL151279	ASSLY PANEL BRAKE-FLANGE	Bajaj spare parts
AL161069	PACKING CHASSIS	Bajaj spare parts
AL161152	PLATE NUMBER GC 1000	Bajaj spare parts
AL161171	LOCK GLOVE BOX LID	Bajaj spare parts
AL161180	NUT CLIP M4 X 0.7P	Bajaj spare parts
AL161184	HINGE - GLOVE BOX LID	Bajaj spare parts
AL161185	CLIP - GLOVE BOX LID (RE-GC DASHBOARD)	Bajaj spare parts
AL161186	PIN - DASHBOARD HINGE	Bajaj spare parts
AL161226	FLAP MUDGUARDGC100	Bajaj spare parts
AL161229	STRIP MUDGUARD FLAP	Bajaj spare parts
AL161236	PLUG -BLINKER HOUSING	Bajaj spare parts
AL161247	RUBBER ISOLATOR	Bajaj spare parts
AL161249	RUBBER ISOLATOR ENGI	Bajaj spare parts
AL161250	PLATE STOPPER	Bajaj spare parts
AL161251	SPACER RUBBER ISOLAT	Bajaj spare parts
AL161252	PLATE UPPER ISOLATOR	Bajaj spare parts
AL161253	BRACKET ISOLATOR	Bajaj spare parts
AL161302	SUPPORT ENGINE MIDDLE	Bajaj spare parts
AL161362	LOCK STERO LID WITH	Bajaj spare parts
AL161376	CRADLE HYDROMED	Bajaj spare parts
AL161377	MUDGUARD REAR	Bajaj spare parts
AL161379	COVER SWITCH	Bajaj spare parts
AL161381	COVER STEERING	Bajaj spare parts
AL161382	LID GLOVE BOX	Bajaj spare parts
AL161383	COVER WIPER MOTOR	Bajaj spare parts
AL161390	LID STEREO ASSEMBLY	Bajaj spare parts
AL161392	Packing tray frame	Bajaj spare parts
AL161498	COVER SPEEDO METER	Bajaj spare parts
AL161502	TOOL BOX LID LH	Bajaj spare parts
AL161503	TOOL BOX LID RH	Bajaj spare parts
AL161505	PLATE LOWER ISOLATOR	Bajaj spare parts
AL161518	BEADING HEADLAMP HOUSING	Bajaj spare parts
AL161565	HSG.DL BLINKER LH	Bajaj spare parts
AL161567	HSG.HL BLINKER RH	Bajaj spare parts
AL161626	CRADLE HYDROFORMED FL	Bajaj spare parts
AL161645	CLIP PIPE FOR DIA 3 TO 16	Bajaj spare parts
AL161661	PANEL CONNECTING LH	Bajaj spare parts
AL161662	PLATE FOR HINGE RE 3WH CARGO	Bajaj spare parts
AL161705	EXTENSION PANEL SILL OUTER LH	Bajaj spare parts
AL161706	EXTENSION PANEL SILL OUTER RH	Bajaj spare parts

AL161744	PLATE STUD CABIN MTG	Bajaj spare parts
AL161775	CRADLE HYDROFORMED	Bajaj spare parts
AL161828	BUSH	Bajaj spare parts
AL171010	BEARING BALL	Bajaj spare parts
AL171011	BUSH SILENT ARM TRAILING	Bajaj spare parts
AL171012	DISTANCE PIECE	Bajaj spare parts
AL171014	RING SPACER TRAILING AR	Bajaj spare parts
AL171017	DAMPER RUBBER REAR SUSPE	Bajaj spare parts
AL171020	PIN PIVOT	Bajaj spare parts
AL171025	BOLT FOR AXLE	Bajaj spare parts
AL171027	CIRCLIP WIRE	Bajaj spare parts
AL171029	FLANGE WHEEL	Bajaj spare parts
AL171031	SHOCK ABSORBER RR GC 1000	Bajaj spare parts
AL171036	RUBBER MOUNTING /	Bajaj spare parts
AL171039	SPRING II SUSPENSION REA	Bajaj spare parts
AL171045	SPRING SUSPENSION FRONT	Bajaj spare parts
AL171047	SHOCK ABS. FR. GC 1000	Bajaj spare parts
AL171048	LINER BUSH	Bajaj spare parts
AL171051	BOLT FOR LINK PIVOT	Bajaj spare parts
AL171053	PLATE LOCK	Bajaj spare parts
AL171058	PIN LOCKING LINK RH	Bajaj spare parts
AL171065	BLOCK - SLIDER	Bajaj spare parts
AL171066	BOLT FOR AXLE	Bajaj spare parts
AL171067	BUSH RUBBER FR SHOCK ABSO	Bajaj spare parts
AL171068	AXLE ASSLY REAR WHEE	Bajaj spare parts
AL171081	BUSH LINK PIVOT	Bajaj spare parts
AL171091	LINK ASSLY LH	Bajaj spare parts
AL171093	LINK ASSLY RH	Bajaj spare parts
AL171095	SLEEVE BEARING	Bajaj spare parts
AL171104	CAP LINK PIVOT	Bajaj spare parts
AL171115	BUSH LINK PIVOT	Bajaj spare parts
AL171127	LINK ASSLY RH	Bajaj spare parts
AL171138	ASSLY REAR SHOCKABSORBER	Bajaj spare parts
AL171139	ASSLY FRONT SHOCKABSORBER	Bajaj spare parts
AL171143	ASSLY DIST. PIECE TA TUBE	Bajaj spare parts
AL171147	ASSLY DISTANCE PIECE TA IGUS	Bajaj spare parts
AL171150	RUBBER SEAT SPRING REAR	Bajaj spare parts
AL171151	SHOCKABSORBER FRONT	Bajaj spare parts
AL171153	COVER PIVOT TUBE TA IGUS	Bajaj spare parts
AL171157	LOCATOR DISTANCE PIECE	Bajaj spare parts
AL171158	BOLT TRAILING ARM PIVOT	Bajaj spare parts
AL171172	SHOCKABSORBER REAR	Bajaj spare parts
AL181003	BEARING RACE LOWER OUTER	Bajaj spare parts
AL181004	BEARING RACE LOWER INNER	Bajaj spare parts
AL181005	COVER DUST TOP	Bajaj spare parts

AL181006	COVER DUST BOTTOM	Bajaj spare parts
AL181007	BALLS WITH CAGE	Bajaj spare parts
AL181009	BALLS WITH CAGE UPPR	Bajaj spare parts
AL181046	SET LOCK	Bajaj spare parts
AL191001	GEAR CABL3140 GC MAX	Bajaj spare parts
AL191002	CABLE INNER GEAR GC1000	Bajaj spare parts
AL191003	GEAR CABL2750 GC MAX	Bajaj spare parts
AL191004	ACC CABL3570 GC MAX	Bajaj spare parts
AL191006	CABLE INNER ACC.	Bajaj spare parts
AL191008	CABLE STOP ENGINE GC	Bajaj spare parts
AL191012	CABLE DECOMPRES GC1000	Bajaj spare parts
AL191020	SPEEDO CABL2443 COM	Bajaj spare parts
AL191028	SCREW M4 X 0.7	Bajaj spare parts
AL191033	CABLE DECOMPRESSION	Bajaj spare parts
AL191035	CLUTCH CABL2451 445L	Bajaj spare parts
AL191038	DECOM CABL2566 445M	Bajaj spare parts
AL191039	KNOBCABLE DECOMPRES	Bajaj spare parts
AL191040	KNOBCABLE COM ENGIN	Bajaj spare parts
AL191043	INSTRUMENT CLUSTER	Bajaj spare parts
AL191060	REVERS CABL2690 CARG	Bajaj spare parts
AL191062	ACC CABL3136 CARGO D	Bajaj spare parts
AL191063	CABLE ASSY COMP ENG STOP	Bajaj spare parts
AL191064	SPEEDO CABL2543 CARG	Bajaj spare parts
AL191065	DECOM CABL2631 CARGO	Bajaj spare parts
AL191069	SPEEDO CABL2543 CARG	Bajaj spare parts
AL191070	CLUTCH CABL3090 CARG	Bajaj spare parts
AL191071	GEAR CABL2780 CARGO	Bajaj spare parts
AL191072	GEAR CABL2784 CARGO	Bajaj spare parts
AL191076	CABLE GEAR BLACK	Bajaj spare parts
AL191077	CABLE GEAR WHITE	Bajaj spare parts
AL191078	SPEEDOMETER CABLE COMPLETE	Bajaj spare parts
AL191079	SPEEDOMETER INNER CABLE	Bajaj spare parts
AL191081	CABLE INNER SPEEDOMETER	Bajaj spare parts
AL191082	CABLE ASSLY SPEEDOMETER	Bajaj spare parts
AL191083	CABLE ACCELERATOR	Bajaj spare parts
AL191085	CABLE ACCELERATOR	Bajaj spare parts
AL191086	CABLE GEAR WHITE	Bajaj spare parts
AL191087	CABLE GEAR BLACK	Bajaj spare parts
AL191088	CABLE CLUTCH	Bajaj spare parts
AL191089	CABLE REVERSE	Bajaj spare parts
AL191090	CABLE SPEEDOMETER	Bajaj spare parts
AL191091	CABLE DECOMPRESSION	Bajaj spare parts
AL191095	CABLE STOP ENGINE	Bajaj spare parts
AL201012	RELAY LIGHT HEAD	Bajaj spare parts
AL201015	BLINKER FR LH GC 1000	Bajaj spare parts



AL201017	BLINKER FR RH GC 1000	Bajaj spare parts
AL201022	MOTOR WIPER GC1000	Bajaj spare parts
AL201023	TIMER FOR GLOW PLUG	Bajaj spare parts
AL201024	RELAY SINGLE POLE&2 NO CO	Bajaj spare parts
AL201027	LAMP ASEMBLYHEADLH	Bajaj spare parts
AL201029	LAMP ASSEMBLY HEAD RH	Bajaj spare parts
AL201031	SWITCH 2 POSITION GC1000	Bajaj spare parts
AL201032	SPRING HEAD	Bajaj spare parts
AL201034	PUMP FUEL GC1000	Bajaj spare parts
AL201038	REGULATOR 1PH SERIES	Bajaj spare parts
AL201039	LAMP CABIN GC1000	Bajaj spare parts
AL201043	CABLE ASSY FRONT LI	Bajaj spare parts
AL201044	CABLE ASSY FRONT LI	Bajaj spare parts
AL201051	BLINKER FR LH GC 1000	Bajaj spare parts
AL201060	SWITCH CONTROL LH GC1000	Bajaj spare parts
AL201061	SWITCH CONTROL RH GC1000	Bajaj spare parts
AL201062	SCREW M4 X 0.7	Bajaj spare parts
AL201065	LAMP HEAD LH GC 1000	Bajaj spare parts
AL201066	LAMP HEAD RH GC 1000	Bajaj spare parts
AL201070	CLIP P	Bajaj spare parts
AL201073	LIGHT CABIN LIGHT	Bajaj spare parts
AL201078	LABEL PARKING ON OFF	Bajaj spare parts
AL201082	FUSE BOX	Bajaj spare parts
AL201086	COVER CONTROL SWITCH	Bajaj spare parts
AL201087	COVER CONTROL SWITC	Bajaj spare parts
AL201100	CHARGER MOBILE	Bajaj spare parts
AL201119	HEAD LIGHT LH (SYM H	Bajaj spare parts
AL201120	LAMP HEAD RH	Bajaj spare parts
AL201127	CLIP PLASTIC TWIN DIA 17	Bajaj spare parts
AL201129	WIRING HARNESS CHASSIS RR	Bajaj spare parts
AL201130	CABLE BATTERY	Bajaj spare parts
AL201137	UNIT CONTROL FLUID LEVEL SENSOR	Bajaj spare parts
AL201145	CABLE BATTERY	Bajaj spare parts
AL201146	HARNESS WIRING REAR CARGO-DIESEL	Bajaj spare parts
AL201153	HARNESS WIRING REAR	Bajaj spare parts
AL201156	CABLE BATTERY	Bajaj spare parts
AL201161	HARNESS WIRING REAR	Bajaj spare parts
AL201162	HARNESS WIRING REAR	Bajaj spare parts
AL201166	CABLE BATTERY	Bajaj spare parts
AL201175	SWITCH CONTROL RH	Bajaj spare parts
AL201183	HARNESS WIRING FRONT	Bajaj spare parts
AL201184	HARNESS WIRING REAR	Bajaj spare parts
AL211017	BACKREST DRIVER FOR RE 900 FL	Bajaj spare parts
AL211019	FRAME DRIVER SEAT FOR RE 900 FL	Bajaj spare parts
AL211023	SEAT ASSLY DRIVER	Bajaj spare parts

AL221036	LABEL MAXIMA C REAR BLACK	Bajaj spare parts
AL221037	LABEL POWER CLUCTH	Bajaj spare parts
AL221038	LABEL POWER ENGINE	Bajaj spare parts
AL221040	LABEL MAXIMA C REAR WHITE	Bajaj spare parts
AL230010	LABEL C-MAXIMA C BLACK	Bajaj spare parts
AL230011	LABEL C-MAXIMA C WHITE	Bajaj spare parts
AL230012	LABEL BS4 -MAXIMA C	Bajaj spare parts
AL230018	FRAME SEAT DRIVER	Bajaj spare parts
AL230020	BACKREST DRIVER	Bajaj spare parts
AL230021	DECAL BS6 RH	Bajaj spare parts
AL230022	DECAL BS6 LH	Bajaj spare parts
AL241023	WIPER ARM BLADE ASLY	Bajaj spare parts
AL241189	SPRING GLASS LOCK	Bajaj spare parts
AL241220	HANDLE ASSLY LHDOL	Bajaj spare parts
AL241221	HANDLE RHDOOR LOCK	Bajaj spare parts
AL241277	HANDLE ASSLY LH	Bajaj spare parts
AL241278	HANDLE ASSLY RH	Bajaj spare parts
AL241285	PACKING SHIELD AND	Bajaj spare parts
AL241344	LATCH STRIKER DOOR	Bajaj spare parts
AL241395	KNOB DOOR LOCK	Bajaj spare parts
AL241405	HINGE PIN	Bajaj spare parts
AL241442	BEADING DOOR RE900 FL	Bajaj spare parts
AL241445	JOINT PLATE LH	Bajaj spare parts
AL241446	JOINT PLATE RH	Bajaj spare parts
AL241455	ASSLY HINGE UPPER LH -GLASS SW	Bajaj spare parts
AL241456	ASSLY HINGE LOWER LH-GLASS SW	Bajaj spare parts
AL241457	HANDLE LH FOR GLASS SWIVEL	Bajaj spare parts
AL241460	LOCK PAD FOR GLASS SWIVEL	Bajaj spare parts
AL241465	HANDLE RH-GLASS SWIVEL	Bajaj spare parts
AL241474	HINGE ASSY LOWER RH-GLASS SWIVEL	Bajaj spare parts
AL241475	COVER DOOR LATCH FOR RE 900 FL	Bajaj spare parts
AL241477	SPACER FOR HINGE ASSLY LOWER	Bajaj spare parts
AL241478	SPACER FOR HINGE ASSLY UPPER	Bajaj spare parts
AL241479	PIN STEP FOR HANDLE	Bajaj spare parts
AL241480	SPACER WITH COLLAR GLASS MTG	Bajaj spare parts
AL241481	SCREW STEPPED M6X1X11	Bajaj spare parts
AL241482	ASSLY HINGE UPPER RH-GLASS SW	Bajaj spare parts
AL241577	RUBBER PACKING CARGO	Bajaj spare parts
AL241578	PACKING UPPER CABIN	Bajaj spare parts
AL241603	ASSLY HINGE UPPER LH	Bajaj spare parts
AL241606	ASSLY HINGE LOWER LH	Bajaj spare parts
AL241609	ASSLY HINGE UPPER RH	Bajaj spare parts
AL241614	ASSLY HINGE LOWER RH	Bajaj spare parts
AL241633	ASSLY TRAY LOAD BODY COMPLETE	Bajaj spare parts
AL241662	STRIP DOOR LIMITING CARGO	Bajaj spare parts

AL241679	RUBBER PACKING RH	Bajaj spare parts
AL241689	BEADING FRONT LH SW GLASS	Bajaj spare parts
AL241690	BEADING FRONT RH SW GLASS	Bajaj spare parts
AL241691	BEADING REAR LH SW GLASS	Bajaj spare parts
AL241692	BEADING REAR RH SW GLASS	Bajaj spare parts
AL241693	GLASS SWIVEL	Bajaj spare parts
AL241695	BEADING FIXED GLASS	Bajaj spare parts
AL241696	GLASS FIXED CARGO	Bajaj spare parts
AL241697	PACKING CABIN	Bajaj spare parts
AL241700	LATCH MECHANISM LH	Bajaj spare parts
AL241701	LATCH MECHANISM RH	Bajaj spare parts
AL241761	BRACKET STRIKER MTG	Bajaj spare parts
AL241767	RUBBER STOPPER TRAY REAR DOOR	Bajaj spare parts
AL241769	PACKING BALLATA	Bajaj spare parts
AL241774	LEVER GLASS LOCK	Bajaj spare parts
AL241775	LOCK GLASS	Bajaj spare parts
AL241784	BOLT CONBINATION TRAY	Bajaj spare parts
AL241788	BEADING FIXED GLASS BACK	Bajaj spare parts
AL241796	BEADING FIXED GLASS	Bajaj spare parts
AL241803	GROMMET SW GLASS LOCKING HANDLE LH	Bajaj spare parts
AL241804	GROMMET SW GL LOCKING HANDLE RH	Bajaj spare parts
AL241806	CAP LATCH COVER	Bajaj spare parts
AL241811	ASSLY LATCH -SLIDING GLASS WINDOW	Bajaj spare parts
AL241817	CATCH PLATE - SLIDING GLASS LATCH	Bajaj spare parts
AL241872	CLAMP TOGGLE	Bajaj spare parts
AL241873	WINDOW ASSEMBLY REAR	Bajaj spare parts
AM101041	ENGINE ASSY. COMPLETE RE205 FL	Bajaj spare parts
AM101048	ENGINE ASSY. BS4-COMPACT LPG 4S	Bajaj spare parts
AM101051	BS4 SILENCER LPG ASSY COMP	Bajaj spare parts
AM101052	BS4 MUFFLER ASSY LPG	Bajaj spare parts
AM101059	ENGINE ASSLY LPG 4S	Bajaj spare parts
AM101064	ENGINE ASSEMBLY	Bajaj spare parts
AM101094	ENGINE ASSEMBLY	Bajaj spare parts
AM101107	GEAR ASSEMBLY DIFFERENTIAL	Bajaj spare parts
AM101108	GEAR DIFFERENTIAL	Bajaj spare parts
AM101114	SHAFT DRIVE	Bajaj spare parts
AM101140	ENGINE ASSEMBLY	Bajaj spare parts
AM101169	CRANKSHAFT ASSEMBLY	Bajaj spare parts
AM101170	SPROCKET CRANKSHAFT	Bajaj spare parts
AM101171	GUIDE CHAIN TIGHT SIDE	Bajaj spare parts
AM101172	GUIDE CHAIN SLACK SIDE	Bajaj spare parts
AM101173	SPROCKET CAMSHAFT	Bajaj spare parts
AM101174	CHAIN	Bajaj spare parts
AM101192	CAMSHAFT	Bajaj spare parts
AM110003	ASSLY. CDI MULTIMAP - LPG	Bajaj spare parts

AM110018	ECU EMS ASSEMBLY	Bajaj spare parts
AM121051	FILTER PAPER RE 4S LPG	Bajaj spare parts
AM121077	MIXER TUBE NYLON.	Bajaj spare parts
AM121078	INSERT BELLOW RE4S.	Bajaj spare parts
AM121083	DIAPHRAGM SUB ASYRE	Bajaj spare parts
AM121091	BREATHER II	Bajaj spare parts
AM121105	HOSE FLEXIBLE ASSY.	Bajaj spare parts
AM121112	CARBURETTOR M/S UCAL	Bajaj spare parts
AM121117	BODY THROTTLE	Bajaj spare parts
AM121120	REGULATOR LPG TWO STAGE	Bajaj spare parts
AM121123	CONTROLLER AIR INLET	Bajaj spare parts
AM121140	ASSLY LPG REGULATOR	Bajaj spare parts
AM121148	ASSLY LPR BRACKET	Bajaj spare parts
AM121154	BREATHER HOSE	Bajaj spare parts
AM121158	ASSLY COMPLETE INTEGRAL DUCT	Bajaj spare parts
AM121162	INSERT RESTRICTOR	Bajaj spare parts
AM121163	HOSE LOW PRESSURE LPG	Bajaj spare parts
AM121169	CARBURETTOR ASSY.- UCAL	Bajaj spare parts
AM121170	ASSLY LPG REGULATOR 205FL	Bajaj spare parts
AM121171	REGULATOR TWO STAGE 205FL LPG	Bajaj spare parts
AM121172	BODY THROTTLE ASSY-RE205 FL LPG	Bajaj spare parts
AM121177	ASSLY DUCT INTEGRAL COMPLETE	Bajaj spare parts
AM121178	CARBURETTOR ASSY.	Bajaj spare parts
AM121180	BODY THROTTLE ASSY-FLANGE TYPE	Bajaj spare parts
AM121187	CARBURETTOR ASSY.	Bajaj spare parts
AM121192	BRACKET -LPR MOUNTING	Bajaj spare parts
AM121193	HOSE -LOW PRESSURE-LPG	Bajaj spare parts
AM121207	FILTER ASSEMBLY AIR	Bajaj spare parts
AM121209	FILTER ASSEMBLY AIR	Bajaj spare parts
AM121213	ELEMENT FILTER AIR	Bajaj spare parts
AM121216	FILTER ASSEMBLY AIR	Bajaj spare parts
AM141003	CYLINDER LPG	Bajaj spare parts
AM141004	PIPE TANK FUELFILTE	Bajaj spare parts
AM141031	ADAPTER ASSEMBLY WITH CAP-LPG	Bajaj spare parts
AM141067	SOLENOID LPG	Bajaj spare parts
AM141085	HOSE SOLENOID-REGULATOR	Bajaj spare parts
AM141086	HOSE MFV-SOLENOID	Bajaj spare parts
AM141088	SOLENOID ASSEMBLY	Bajaj spare parts
AM141089	BRACKET SOLENOID	Bajaj spare parts
AM141094	BRACKET CYLINDER LH	Bajaj spare parts
AM141095	BRACKET CYLINDER RH	Bajaj spare parts
AM141104	HOSE FILTER-REGULATOR	Bajaj spare parts
AM141105	HOSE FILTER-RAIL	Bajaj spare parts
AM141106	GROMMET	Bajaj spare parts
AM141107	CLAMP	Bajaj spare parts

AM141111	CLAMP	Bajaj spare parts
AM141134	HOSE RAIL-INJECTOR	Bajaj spare parts
AM161020	LABEL LPG	Bajaj spare parts
AM191002	CABLE ACCELERATOR	Bajaj spare parts
AM191005	SPEEDO CABL2418 COM4	Bajaj spare parts
AM191035	SPEEDOMETER CLUSTER	Bajaj spare parts
AM201044	FUSE BOX PARKING+HAZARD R	Bajaj spare parts
AM201060	FUSE BOX ASSEMBLY	Bajaj spare parts
AM201063	INDICATOR ASLY RH POD(LPG	Bajaj spare parts
AM201075	CABLE ASSLY	Bajaj spare parts
AM201077	HARNESS WIRING(REROUTING)	Bajaj spare parts
AM201078	HARNESS WIRING(200CC)	Bajaj spare parts
AM201087	HARNESS WIRING FR 205D LPG FL	Bajaj spare parts
AM201097	HARNESS WR REAR 205D LPG	Bajaj spare parts
AM201100	HARNESS REAR FL	Bajaj spare parts
AM201106	HARNESS FRONT RE COMPACT 4S LPG	Bajaj spare parts
AM201107	HARNESS REAR RE COMPACT 4S LPG	Bajaj spare parts
AM201109	HARNESS WIRING FR RE 205D LPG	Bajaj spare parts
AM201110	INDICATOR ASSLY RH POD LPG	Bajaj spare parts
AM201114	HARNESS FRONT	Bajaj spare parts
AM201116	SWITCH CONTROL RH WITH DIODE	Bajaj spare parts
AM201119	HARNESS WIRING REAR LPG	Bajaj spare parts
AM201127	HARNESS FRONT RE COMPACT 4S LPG	Bajaj spare parts
AM201128	HARNESS FRONT RE COMPACT LPG MF	Bajaj spare parts
AM201129	HARNESS WIRING-REAR	Bajaj spare parts
AM201134	HARNESS FRONT	Bajaj spare parts
AM201136	HARNESS WIRING-FRONT-LPG	Bajaj spare parts
AM201137	HARNESS WIRING-REAR-LPG	Bajaj spare parts
AM201138	HARNESS WIRING-FRONT-LPG	Bajaj spare parts
AM201139	HARNESS WIRING-REAR-LPG	Bajaj spare parts
AM201140	HARNESS WIRING FRONT LPG	Bajaj spare parts
AM201141	CABLE PLATE ELECTRICAL FRONT	Bajaj spare parts
AM201142	HARNESS WIRING FRONT LPG	Bajaj spare parts
AM201148	HARNESS WIRING REAR	Bajaj spare parts
AM201163	ASSEMBLY PLATE ELECTRICAL FRONT	Bajaj spare parts
AM201185	CABLE EARTH ENGINE-CHASSIS	Bajaj spare parts
AM201189	HARNESS WIRING FRONT	Bajaj spare parts
AM201190	HARNESS WIRING REAR	Bajaj spare parts
AM201222	HARNESS WIRING FRONT	Bajaj spare parts
AM201223	HARNESS WIRING REAR	Bajaj spare parts
AM201225	SWITCH SELECTOR FUEL	Bajaj spare parts
AM201236	UNIT TRANSIL	Bajaj spare parts
AM201237	UNIT INJECTOR DRIVER	Bajaj spare parts
AM201241	CABLE PLATE ELECTRICAL	Bajaj spare parts
AM201242	HARNESS WIRING FRONT	Bajaj spare parts

AM201243	HARNESS WIRING REAR	Bajaj spare parts
AM201246	INDICATOR POD RH	Bajaj spare parts
AM201282	HARNESS WIRING REAR	Bajaj spare parts
AM201283	HARNESS WIRING REAR	Bajaj spare parts
AM201313	HARNESS WIRING FRONT	Bajaj spare parts
AM201314	HARNESS WIRING REAR	Bajaj spare parts
AM220006	PLATE COMPLIANCE LPG	Bajaj spare parts
AN101009	VALVE INTAKE	Bajaj spare parts
AN101010	VALVE EXHAUST	Bajaj spare parts
AN101012	GASKET HEAD	Bajaj spare parts
AN101033	CRANKCASE MAGNETO	Bajaj spare parts
AN101062	CAP SEALING	Bajaj spare parts
AN101063	CLUTCH HOUSING ASSY	Bajaj spare parts
AN101066	PISTON RING SET	Bajaj spare parts
AN101069	CLUTCH ASY COMP	Bajaj spare parts
AN101070	CRANKCASE CLUTCH SID	Bajaj spare parts
AN101083	TUBE BREATHER	Bajaj spare parts
AN101104	SECTOR COM REVERSE	Bajaj spare parts
AN101109	CLUTCH COVER	Bajaj spare parts
AN101113	NUT DOMED CAP	Bajaj spare parts
AN101116	SECTOR COMPLETE RC	Bajaj spare parts
AN101123	CYL BLOCK ASSY 3W4S 205	Bajaj spare parts
AN101127	CRANKCASE CLUTCH SIDE	Bajaj spare parts
AN101129	GASKET CENTRAL	Bajaj spare parts
AN101135	GASKET CYLINDER	Bajaj spare parts
AN101140	SPRING ENGINE VALVE	Bajaj spare parts
AN101147	PLATE STOPPER	Bajaj spare parts
AN101149	GASKET HEAD	Bajaj spare parts
AN101152	CRANKSHAFT ASSLY	Bajaj spare parts
AN101155	SPROCKET CRANKSHAFT	Bajaj spare parts
AN101157	FAN	Bajaj spare parts
AN101161	COVER CLUTCH	Bajaj spare parts
AN101162	COWLING INTAKE SIDE	Bajaj spare parts
AN101165	COVER FAN	Bajaj spare parts
AN101166	GUIDE CHAIN	Bajaj spare parts
AN101175	CONNECTOR OIL SUPPLY	Bajaj spare parts
AN101177	HEAD COVER	Bajaj spare parts
AN101181	SLEEVE SPARK PLUG	Bajaj spare parts
AN101182	BOLT SOCKET HEAD	Bajaj spare parts
AN101186	GASKET, CLUTCH COVER	Bajaj spare parts
AN101188	BOLT SPECIAL	Bajaj spare parts
AN101189	PLATE STOPPER	Bajaj spare parts
AN101190	OIL FILTER ASSEMBLY	Bajaj spare parts
AN101197	MAINSHAFT	Bajaj spare parts
AN101198	SLEEVE MAINSHAFT	Bajaj spare parts

AN101200	"SPACER, SLEEVE"	Bajaj spare parts
AN101201	GEAR REVERSE CONTROL	Bajaj spare parts
AN101202	FAN BASE	Bajaj spare parts
AN101203	INTERNAL COWLING	Bajaj spare parts
AN101232	PIPE COMPLETE,BANJO	Bajaj spare parts
AN101238	BOLT RESTRICTOR	Bajaj spare parts
AN101239	RUBBER SLEEVE SPARK	Bajaj spare parts
AN101250	PIN GUIDE CHAIN	Bajaj spare parts
AN101257	GUIDE CHAIN (TENSIONER SIDE)	Bajaj spare parts
AN101258	RUBBER CAP SPARK PLUG	Bajaj spare parts
AN101259	PISTON ASSEMBLY	Bajaj spare parts
AN101298	COVER DIFFERENTIAL	Bajaj spare parts
AN101300	SECTOR COMP REV CONTROL	Bajaj spare parts
AN101305	BRACKET REVERSE CABLE	Bajaj spare parts
AN101307	PIPE OIL COOL	Bajaj spare parts
AN101308	PIPE OIL HOT	Bajaj spare parts
AN101312	GASKET DIFFERENTIAL COVER	Bajaj spare parts
AN101322	SHIELD EXHAUST TUBE	Bajaj spare parts
AN101323	DECOMPRESSION ASSLY	Bajaj spare parts
AN101328	GEAR REVERSE CONTROL	Bajaj spare parts
AN101334	BRACKET SUPPORT	Bajaj spare parts
AN101336	DIFFERENTIAL GEAR	Bajaj spare parts
AN101337	ASSLY DIFFERENTIAL GEAR	Bajaj spare parts
AN101338	IDLER GEAR	Bajaj spare parts
AN101339	SHAFT MULTIPLE GEAR	Bajaj spare parts
AN101341	PINION PRIMARY	Bajaj spare parts
AN101342	PINION PRIMARY	Bajaj spare parts
AN101343	PINION PRIMARY	Bajaj spare parts
AN101346	IDLER GEAR	Bajaj spare parts
AN101347	WASHER THRUST	Bajaj spare parts
AN101348	CLIP -HOSE	Bajaj spare parts
AN101352	PLATE FOR CABLE HOLDING	Bajaj spare parts
AN101354	DIFFERENTIAL GEAR	Bajaj spare parts
AN101355	HOUSING GEAR SATELLITE	Bajaj spare parts
AN101356	GEAR DIFFERENTIAL	Bajaj spare parts
AN101357	ASSY PISTON RE 205 FL	Bajaj spare parts
AN101361	PLATE HOLDER	Bajaj spare parts
AN101375	SHAFT CLUTCH RELEASE	Bajaj spare parts
AN101376	SPRING TORSION CLUTCH LEVER	Bajaj spare parts
AN101379	GEAR 1ST SPEED	Bajaj spare parts
AN101390	PINION PRIMARY	Bajaj spare parts
AN101391	BKT CLUTCH CABLE & HT COIL	Bajaj spare parts
AN101404	ASSLY DIFFERENTIAL GEAR	Bajaj spare parts
AN101405	GEAR DIFFERENTIAL	Bajaj spare parts
AN101406	HOUSING ASSY-SATELLITE GEAR	Bajaj spare parts

AN101407	DRIVE SHAFT ASSLY	Bajaj spare parts
AN101420	BREATHER PIPE	Bajaj spare parts
AN101421	RUBBER COUPLING CNG	Bajaj spare parts
AN101423	BRACKET FOR OILCOOLER FL	Bajaj spare parts
AN101429	SEAT VALVE SPRING	Bajaj spare parts
AN101434	GEAR BEVEL SG. HSG. SIDE	Bajaj spare parts
AN101435	GEAR BEVEL DIFF. GEAR SIDE	Bajaj spare parts
AN101436	GEAR IDLER (M 2.5)	Bajaj spare parts
AN101437	GEAR REVERSE CONTROL	Bajaj spare parts
AN101438	GEAR DIFFERENTIAL	Bajaj spare parts
AN101440	CLIP CARB PIPE ROUTING	Bajaj spare parts
AN101441	SILENCER ASSY COMPLETE	Bajaj spare parts
AN101442	MUFFLER ASSY COMPLETE	Bajaj spare parts
AN101447	INSERT RESTRICTOR - BELLOW A/F INLET	Bajaj spare parts
AN101448	INSERT RESTRICTOR - ELBOW	Bajaj spare parts
AN101450	ENGINE ASSY. BS4-MAXIMA C CNG	Bajaj spare parts
AN101452	BS4 SILENCER CNG ASSY COMP	Bajaj spare parts
AN101453	BS4 MUFFLER ASSY CNG COMP	Bajaj spare parts
AN101468	ENGINE ASSLY-MAXIMA C PETROL UG	Bajaj spare parts
AN101472	SILENCER ASSLY-COMPLETE	Bajaj spare parts
AN101474	MUFFLER ASSLY-COMPLETE	Bajaj spare parts
AN101478	ASSLY EXHAUST TUBE	Bajaj spare parts
AN101486	HEAD CYLINDER	Bajaj spare parts
AN101487	HEAD CYLINDER ASSLY	Bajaj spare parts
AN101488	CLUTCH COMPLETE	Bajaj spare parts
AN101489	HOUSING ASSLY CLUTCH	Bajaj spare parts
AN101492	HOOK	Bajaj spare parts
AN101498	PIPE ASSLY BREATHER	Bajaj spare parts
AN101547	ENGINE ASSEMBLY	Bajaj spare parts
AN101550	PIPE BREATHER FILTER SIDE	Bajaj spare parts
AN101657	PINION PRIMARY	Bajaj spare parts
AN111004	STATOR ASSEMBLYGCC	Bajaj spare parts
AN111005	ROTOR ASSEMBLY GCC	Bajaj spare parts
AN111009	ROTOR ASSLY	Bajaj spare parts
AN111013	STATOR ASSEMBLY(200CC)	Bajaj spare parts
AN111014	DC IGNITER	Bajaj spare parts
AN111015	SPARK PLUG CAP	Bajaj spare parts
AN111017	H. T. COIL WITH CABLE - LH	Bajaj spare parts
AN111018	H. T. COIL WITH CABLE - RH	Bajaj spare parts
AN111030	CDI_RE205 FL	Bajaj spare parts
AN111031	CDI	Bajaj spare parts
AN111037	ASSLY CDI_RE CARGO CNG	Bajaj spare parts
AN111043	COIL HT LH WITH CABLE	Bajaj spare parts
AN111045	COIL HT RH WITH CABLE	Bajaj spare parts
AN111052	CDI ASSLY	Bajaj spare parts



AN111054	ASSLY CDI- MAXIMA C PETROL UG	Bajaj spare parts
AN111062	ECU EMS ASSEMBLY	Bajaj spare parts
AN111077	CDI	Bajaj spare parts
AN121111	CONNECTOR CLUTCH COV	Bajaj spare parts
AN121184	BELLOW -INTAKE ELBOW COMPLETE	Bajaj spare parts
AN121185	BELLOW -INTAKE ELBOW	Bajaj spare parts
AN121201	MANIFOLD INTAKE	Bajaj spare parts
AN121205	COOLER -OIL	Bajaj spare parts
AN121206	BRACKET OIL COOLER MTG.	Bajaj spare parts
AN121215	DUCT A/F INLET COMPLETE	Bajaj spare parts
AN121217	CARBURETTOR ASSLY	Bajaj spare parts
AN121219	TUBE BREATHER II	Bajaj spare parts
AN121220	HOSE LOW PRESSURE CNG	Bajaj spare parts
AN121234	CARBURETTOR ASLY-MAXIMA C PETROL	Bajaj spare parts
AN121240	BELLOW COMPLETE-ELBOW-INTAKE	Bajaj spare parts
AN121242	TUBE INLET SAI FILTER	Bajaj spare parts
AN121248	FILTER ASSLY AIR	Bajaj spare parts
AN121251	PUMP FUEL-VACUUM	Bajaj spare parts
AN121252	BRACKET PUMP FUEL	Bajaj spare parts
AN121255	TUBE VACUUM-PUMP FUEL	Bajaj spare parts
AN121259	SPACER ASSLY PUMP FUEL	Bajaj spare parts
AN121283	FILTER ASSEMBLY AIR	Bajaj spare parts
AN121287	FILTER ASSEMBLY AIR	Bajaj spare parts
AN121288	FILTER ASSEMBLY AIR	Bajaj spare parts
AN121319	DUCT FILTER AIR INLET	Bajaj spare parts
AN131003	GEAR DIFFERENTIAL	Bajaj spare parts
AN131004	HOUSING SATELLITE	Bajaj spare parts
AN131007	CAP OIL FILLING	Bajaj spare parts
AN131018	BOLT DIFFERENTIAL - PRE COATING (GC-CNG)	Bajaj spare parts
AN131022	SPRING TENSION	Bajaj spare parts
AN131023	SECTOR COMP GC CNG	Bajaj spare parts
AN131026	FAREMETER GEAR GC CN	Bajaj spare parts
AN131032	SECTOR COMPLETE REVE	Bajaj spare parts
AN141008	PIPE:FUEL : - TANK TO FUEL FILTER	Bajaj spare parts
AN141041	CYLINDER CNG WC40L	Bajaj spare parts
AN141047	ASSLY PIPE FUEL WITH FILTER	Bajaj spare parts
AN141049	ASSLY PIPE FILTER TO SOLENOID	Bajaj spare parts
AN141050	ASSLY SOLENOID_ CARBURETTOR	Bajaj spare parts
AN141053	ASSLY TANK FUEL LIMP HOME	Bajaj spare parts
AN141054	STRAP ASSLY	Bajaj spare parts
AN141056	STRAP PACKING RUBBER	Bajaj spare parts
AN141057	PACKING LOWER CNG CYL	Bajaj spare parts
AN141061	ASSLY 1ST STAGE RED UNIT	Bajaj spare parts
AN141069	ASSLY FUEL TANK WELDED	Bajaj spare parts
AN141079	ASSLY FUEL COCK	Bajaj spare parts

AN141084	SLEEVE FILTER TO CARBURETTOR	Bajaj spare parts
AN141119	FILLER ASSLY FUEL	Bajaj spare parts
AN141120	HOSE FILLER FUEL	Bajaj spare parts
AN141124	PIPE TANK FUEL TO FILTER	Bajaj spare parts
AN141126	PIPE FILTER TO PUMP FUEL	Bajaj spare parts
AN141130	PIPE ASSLY PUMP FEED-CARBURETTOR	Bajaj spare parts
AN141131	PIPE BREATHER FUEL	Bajaj spare parts
AN141132	PIPE FILTER FUEL-NRV	Bajaj spare parts
AN141133	PIPE JOINT T-JOINT	Bajaj spare parts
AN141134	PIPE JOINT-TANK	Bajaj spare parts
AN141139	JOINT	Bajaj spare parts
AN141140	SLEEVE JOINT-TANK	Bajaj spare parts
AN141143	HOSE REGULATOR-SOLENOID	Bajaj spare parts
AN141146	REGULATOR HIGH PRESSURE CNG	Bajaj spare parts
AN141154	PIPE ASSEMBLY TANK-JOINT	Bajaj spare parts
AN141156	PIPE ASSEMBLY INJECTOR-JOINT	Bajaj spare parts
AN141174	HOSE SOLENOID-FILTER	Bajaj spare parts
AN141220	HOSE SOLENOID-FILTER	Bajaj spare parts
AN151003	BRAKE CABL1239 MAXIM	Bajaj spare parts
AN151004	BRAKE CABL1706 MAXIM	Bajaj spare parts
AN151036	PIPE ASSEMBLY BRAKE REAR	Bajaj spare parts
AN160912	BRACKET ENGINE MOUNTING FRONT	Bajaj spare parts
AN161048	LINER: BATTERY BASE TRAY	Bajaj spare parts
AN161074	CLAMP BATTERY	Bajaj spare parts
AN161075	ROD TIE BATTERY	Bajaj spare parts
AN161086	COVER SWITCH	Bajaj spare parts
AN161126	DOOR ASSY FOR BOX CNG KIT	Bajaj spare parts
AN161130	BOLT STEP(M6X1X14)	Bajaj spare parts
AN161220	DASHBOARD FL CNG	Bajaj spare parts
AN161235	ASSLY BOX CNG KIT	Bajaj spare parts
AN161263	ASSLY ENGINE MTG MEMBER REAR	Bajaj spare parts
AN161302	MEMBER ASSLY-ENGINE MOUNTING	Bajaj spare parts
AN161316	PLATE ASSLY ELECTRICAL-REAR	Bajaj spare parts
AN161334	BRACKET ENGINE FRONT	Bajaj spare parts
AN161343	MEMBER ASSEMBLY ENGINE REAR	Bajaj spare parts
AN161356	BRACKET ASSEMBLY ECU	Bajaj spare parts
AN170004	SPRING SUSPENSION REAR	Bajaj spare parts
AN181015	SET LOCK	Bajaj spare parts
AN181026	FORK ASSEMBLY	Bajaj spare parts
AN191002	CABLE INNER GEAR	Bajaj spare parts
AN191008	CLUSTER INSTRUMENT	Bajaj spare parts
AN191013	CABLE INNER REVERSE	Bajaj spare parts
AN191017	HANDLE - REVERSE LEVER	Bajaj spare parts
AN191053	ASSLY REVERSE LEVER	Bajaj spare parts
AN191056	GEAR CABLE COMP WHITE FLGEAR CABLE COMP	Bajaj spare parts

AN191058	CHOKE CABLE	Bajaj spare parts
AN191059	CABLE REVERSE FLCABLE REVERSE FL	Bajaj spare parts
AN191060	CLUTCH CABLE	Bajaj spare parts
AN191061	SPEEDO CABLESPEEDO CABLE	Bajaj spare parts
AN191062	GEAR CABLE COMP BLACK FLGEAR CABLE COMP	Bajaj spare parts
AN191064	CABLE INNER SPEEDO	Bajaj spare parts
AN191068	CABLE REVERSE COMPLETE	Bajaj spare parts
AN191070	ASSLY CABLE SPEEDOMETER	Bajaj spare parts
AN191071	CABLE INNER SPEEDOMETER	Bajaj spare parts
AN191080	CABLE ACCELERATOR	Bajaj spare parts
AN191095	CABLE BRAKE PARKING LH	Bajaj spare parts
AN191096	CABLE BRAKE PARKING RH	Bajaj spare parts
AN191114	INSTRUMENT CLUSTER	Bajaj spare parts
AN191117	CABLE CLUTCH	Bajaj spare parts
AN191118	CABLE GEAR BLACK	Bajaj spare parts
AN191119	CABLE REVERSE	Bajaj spare parts
AN191120	CABLE GEAR WHITE	Bajaj spare parts
AN201012	FUSE BOX	Bajaj spare parts
AN201052	BATTERY CABLE	Bajaj spare parts
AN201053	HARNESS REAR CARGO CNG	Bajaj spare parts
AN201054	HARNESS FRONT CARGO CNG	Bajaj spare parts
AN201061	ASSLY REVERSE SWITCH_CABLE	Bajaj spare parts
AN201065	HARNESS FRONT- RE CARGO CNG	Bajaj spare parts
AN201066	HARNESS REAR- RE CARGO CNG	Bajaj spare parts
AN201067	CABLE BATTERY- RE CARGO CNG	Bajaj spare parts
AN201070	HARNESS FRONT RE CARGO PETROL	Bajaj spare parts
AN201071	HARNESS REAR RE CARGO PETROL	Bajaj spare parts
AN201077	SENSOR LEVEL FUEL	Bajaj spare parts
AN201078	HARNESS TANK UNIT RE CARGO PETROL	Bajaj spare parts
AN201087	HARNESS WIRING FRONT CARGO CNG	Bajaj spare parts
AN201088	CABLE BATTERY CARGO CNG	Bajaj spare parts
AN201089	HARNESS WIRING REAR CARGO CNG	Bajaj spare parts
AN201098	HARNESS FRONT	Bajaj spare parts
AN201099	HARNESS REAR	Bajaj spare parts
AN201100	CABLE BATTERY	Bajaj spare parts
AN201119	HARNESS WIRING FRONT PETROL	Bajaj spare parts
AN201120	CLUSTER INSTRUMENT	Bajaj spare parts
AN201123	HARNESS WIRING FRONT	Bajaj spare parts
AN201125	HARNESS WIRING REAR	Bajaj spare parts
AN201141	HARNESS WIRING REAR CNG	Bajaj spare parts
AN201157	CABLE BATTERY	Bajaj spare parts
AN201161	HARNESS WIRING REAR	Bajaj spare parts
AN201163	UNIT RESISTOR	Bajaj spare parts
AN201172	HARNESS WIRING REAR	Bajaj spare parts
AN201194	HARNESS WIRING REAR	Bajaj spare parts

AN201243	SOCKET CHARGER	Bajaj spare parts
AN201286	HARNESS WIRING REAR	Bajaj spare parts
AN201290	HARNESS WIRING FRONT	Bajaj spare parts
AN211001	SEAT DRIVER	Bajaj spare parts
AN241095	TRAY ASSEMBLY LOAD	Bajaj spare parts
AP101005	GASKET CYLINDER BLOCK	Bajaj spare parts
AP101013	CLUTCH ASLY COMPLETE	Bajaj spare parts
AP101014	HOUSING CLUTCH	Bajaj spare parts
AP101015	ENGINE GEAR	Bajaj spare parts
AP101018	SPRING CLUTCH	Bajaj spare parts
AP101019	HOLDER SPRING CLUTCH	Bajaj spare parts
AP101022	SHAFT CLUTCH	Bajaj spare parts
AP101030	PLATE BREATHER	Bajaj spare parts
AP101032	BENDIX DRIVE	Bajaj spare parts
AP101035	COVER MAGNETO	Bajaj spare parts
AP101039	HOLDER STATOR HARNES	Bajaj spare parts
AP101041	CLUTCH BUSH ASSY	Bajaj spare parts
AP101043	BEARING NEEDLE BENDX	Bajaj spare parts
AP101050	DAMPER A	Bajaj spare parts
AP101051	DAMPER B	Bajaj spare parts
AP101052	GASKET SILENCER	Bajaj spare parts
AP101054	BRACKET OIL FEED	Bajaj spare parts
AP101055	SPRING PLATE LOWER	Bajaj spare parts
AP101056	SPRING PLATE UPPER	Bajaj spare parts
AP101057	SPACER PAD	Bajaj spare parts
AP101060	WASHER BELLEVILLE	Bajaj spare parts
AP101061	FITTING BREATHER	Bajaj spare parts
AP101071	COVER BENDIX ASSY	Bajaj spare parts
AP101074	SEAL OIL 22X47X7	Bajaj spare parts
AP101078	SHAFT MAIN	Bajaj spare parts
AP101079	GUIDE BUSH	Bajaj spare parts
AP101081	GEAR SHIFTER ASSEMBL	Bajaj spare parts
AP101092	DAMPER	Bajaj spare parts
AP101093	GEAR REVERSE CONTROL	Bajaj spare parts
AP101095	COVER DIFFERENTIAL	Bajaj spare parts
AP101138	GEAR IDLER	Bajaj spare parts
AP101139	DIFFERENTIAL GEAR	Bajaj spare parts
AP101140	DIFF GEAR	Bajaj spare parts
AP101146	STUD M7	Bajaj spare parts
AP101149	PIN SHAFT RETAINER	Bajaj spare parts
AP101150	CLIP WIRE	Bajaj spare parts
AP101157	GEAR MULTIPLE ASSY	Bajaj spare parts
AP101158	GEAR MULTIPLE	Bajaj spare parts
AP101159	GEAR CORONA	Bajaj spare parts
AP101160	PLATE CUSH GEAR	Bajaj spare parts

AP101162	SPRING	Bajaj spare parts
AP101164	PIN SPRING RETAINER	Bajaj spare parts
AP101165	BEARING MAIN SHAFT	Bajaj spare parts
AP101172	TUBE BREATHER	Bajaj spare parts
AP101174	SPRING CLIP	Bajaj spare parts
AP101178	ROD PUSH	Bajaj spare parts
AP101185	SPACER MAIN SHAFT	Bajaj spare parts
AP101187	SLEEVE MAIN SHAFT	Bajaj spare parts
AP101192	ROD BUSH ASSEMBLY	Bajaj spare parts
AP101194	GASKET SILENCER	Bajaj spare parts
AP101198	CUP SPRING DETENT	Bajaj spare parts
AP101206	BOLT FLANGE M5	Bajaj spare parts
AP101207	RING O	Bajaj spare parts
AP101209	NUT FLANGE	Bajaj spare parts
AP101210	BOLT SOCKET	Bajaj spare parts
AP101213	NUT CASTLE PRECOATE	Bajaj spare parts
AP101220	BOLT ALLEN M5	Bajaj spare parts
AP101226	SEAL OIL CLUTCH SIDE	Bajaj spare parts
AP101227	SPACER	Bajaj spare parts
AP101235	HOLDER	Bajaj spare parts
AP101236	BEARING BALL	Bajaj spare parts
AP101243	BEARING ROLL SMALL E	Bajaj spare parts
AP101244	BEARING ROLL SMALL E	Bajaj spare parts
AP101245	BEARING ROLL SMALL E	Bajaj spare parts
AP101249	GEAR SHIFTER ASSEMBL	Bajaj spare parts
AP101255	SCREW PAN M5X10(PRE-COATED)	Bajaj spare parts
AP101257	KEY WOODRUFF-C'SHAFT MAG SIDE	Bajaj spare parts
AP101263	COVER SEPERATOR	Bajaj spare parts
AP101264	COVER FAN	Bajaj spare parts
AP101268	SEAL OIL MAG SIDE	Bajaj spare parts
AP101269	SHROUD LH	Bajaj spare parts
AP101279	LEVER ASSLY CLUTCH	Bajaj spare parts
AP101281	HOLDER CLUTCH CABLE	Bajaj spare parts
AP101282	GASKET COVER BENDIX	Bajaj spare parts
AP101289	BUSH SINTERED	Bajaj spare parts
AP101290	PLATE CLUTCH	Bajaj spare parts
AP101291	PLATE CLUTCH OUTER	Bajaj spare parts
AP101292	PLATE CLUTCH FRICTION	Bajaj spare parts
AP101295	PISTON OVERSIZE 0.5	Bajaj spare parts
AP111007	MOTOR STARTER	Bajaj spare parts
AP111012	CAP SPARK PLUG RES	Bajaj spare parts
AP111023	SWITCH NEUTRAL CABLE	Bajaj spare parts
AP111025	BRACKET DRIVE END	Bajaj spare parts
AP111026	BRACKET REAR END	Bajaj spare parts
AP111027	ARMATURE ASSY	Bajaj spare parts

AP111028	YOKE ASSY	Bajaj spare parts
AP111029	BRUSH ASSY. KIT	Bajaj spare parts
AP111030	BRUSH CARBON HOLDER	Bajaj spare parts
AP111031	RING'O' FOR SPIGOT	Bajaj spare parts
AP111032	RING'O' FOR YOKE	Bajaj spare parts
AP111033	BOLT TIE	Bajaj spare parts
AP111034	PINION GEAR ASSLY	Bajaj spare parts
AP111054	KIT SPRING RETURN	Bajaj spare parts
AP121001	REED VALVE ASSY COMP	Bajaj spare parts
AP121003	GASKET REED VALVE	Bajaj spare parts
AP121004	GASKET MANIFOLD	Bajaj spare parts
AP121020	HOSE OIL IN	Bajaj spare parts
AP121034	RING O COMPRESSOR	Bajaj spare parts
AP121043	STRAINER OIL	Bajaj spare parts
AP121064	CLAMP	Bajaj spare parts
AP121067	FILTER OIL	Bajaj spare parts
AP121068	HOSE FILTER OIL	Bajaj spare parts
AP121073	RAIL OIL FEED ASSEMB	Bajaj spare parts
AP121074	CLIP HOSE	Bajaj spare parts
AP121086	GROMMET OIL RAIL	Bajaj spare parts
AP121106	GROMMET OIL PIPE	Bajaj spare parts
AP121128	PUMP OIL ELECTRICAL	Bajaj spare parts
AP121132	ELEMENT AIRFILTERTW	Bajaj spare parts
AP121133	FILTER AIR ASSY	Bajaj spare parts
AP121137	RING O DIRECT INJECTOR	Bajaj spare parts
AP121143	CLAMP	Bajaj spare parts
AP141008	CAP OIL TANK	Bajaj spare parts
AP141012	TANK OIL	Bajaj spare parts
AP151002	AXLE FRONT WHEEL	Bajaj spare parts
AP151012	DRUM BRAKE WITH STUD	Bajaj spare parts
AP151017	BACK PANEL ASSLY FRONT	Bajaj spare parts
AP151019	DRUM BRAKE WITH STUDS	Bajaj spare parts
AP151025	DISTANCE PIECE	Bajaj spare parts
AP151031	FLANGE BACKPLATE	Bajaj spare parts
AP161047	COVER HANDLE BAR	Bajaj spare parts
AP161048	HANDLE BAR BODY	Bajaj spare parts
AP161054	FRAME DRIVER SEAT	Bajaj spare parts
AP171001	SPRING FRONT	Bajaj spare parts
AP191019	CABLE COMPLETE REVERSE	Bajaj spare parts
AP201006	SWITCH OIL SENSOR	Bajaj spare parts
AP201012	LABEL PARKING ON OFF	Bajaj spare parts
AP201021	FLASHER HAZARD CUT OFF	Bajaj spare parts
AP201025	FUSE 15A (BLADE TYPE)	Bajaj spare parts
AP201026	FUSE BOX ASSY 15A FUSE	Bajaj spare parts
AP201029	RALAY STARTER	Bajaj spare parts

AP201037	PLATE ELECTRICAL UNI	Bajaj spare parts
AP201048	SWITCH IGN PRK ONOFF	Bajaj spare parts
AP201052	LIGHT ASSY HEAD RH	Bajaj spare parts
AP201054	LIGHT ASSY HEAD LH	Bajaj spare parts
AP201057	WIPER MOTORW/CAPACI	Bajaj spare parts
AP201058	CABIN LIGHT ASSLY.	Bajaj spare parts
AP201066	RUBBER CAP	Bajaj spare parts
AP201075	SWITCH LOCK IGN WITHKEY	Bajaj spare parts
AP201083	IGNITION SWITCH(KEY)	Bajaj spare parts
AP201105	HARNESS PIGTAIL ETS(MINDA	Bajaj spare parts
AP201109	HARNESS PIGTAIL	Bajaj spare parts
AS101002	ENGINE ASSLY COMPLETE	Bajaj spare parts
AS101005	GEAR MULTIPLE ASSY COMP RE	Bajaj spare parts
AS101007	ASSLYSILENCERBS-4 -BSIV	Bajaj spare parts
AS101011	ENGINE ASSY RE COMPACT 2S-BS4 ES	Bajaj spare parts
AS101016	ASSLY CYLINDER BLOCK PISTON	Bajaj spare parts
AS110001	CDI RE145 BS4 ES	Bajaj spare parts
AS120001	ASSLY COMP. INTEGRAL DUCT	Bajaj spare parts
AS121007	SLEEVE CARBURETTOR CNG FL	Bajaj spare parts
AS121010	INSERT RESTRICTER DIA. 15	Bajaj spare parts
AS121011	CLIP HOSE STRAP TWO WAY	Bajaj spare parts
AS121019	REGULATOR CNG TWO STAGE	Bajaj spare parts
AS121021	ASSLY CARBURETTOR CNG-LPG	Bajaj spare parts
AS121025	ASSLY HOSE COMPLETE INTEGRAL	Bajaj spare parts
AS140003	PIPE FUEL SOLENOID TO CARBU	Bajaj spare parts
AS160006	TRAY PLASTIC _7AH BATTERY	Bajaj spare parts
AS160011	PACKING RUBBER BATTERY	Bajaj spare parts
AS160028	ASSLY CROSS MBR WITH DAMP	Bajaj spare parts
AS190007	SPEEDOMETER COMPLETE	Bajaj spare parts
AS201006	HARNESS WIRING REAR 145 CNG	Bajaj spare parts
AS201007	HARNESS WIRING FRONT 145 CNG	Bajaj spare parts
AS201010	ASSLY INDICATOR CNG	Bajaj spare parts
AS201015	HARNESS FRONT RE145 ES CNG	Bajaj spare parts
AS201016	HARNESS REAR RE145 ES CNG	Bajaj spare parts
AS201017	SWITCH G O P CNG HORIZONTAL FL	Bajaj spare parts
AS201018	ASSLY CDI DAMPER DELLORTO FL	Bajaj spare parts
AS201024	FUSE BOX ASSLY RE145 NES CNG	Bajaj spare parts
AS201025	ASSLY CDI WITH DAMPER	Bajaj spare parts
AS201026	HARNESS REAR RE145 NES CNG	Bajaj spare parts
AS201034	HARNESS FRONT ES	Bajaj spare parts
AS201035	HARNESS REAR ES	Bajaj spare parts
AS201037	HARNESS FRONT NES	Bajaj spare parts
AS201038	HARNESS REAR NES	Bajaj spare parts
AS201041	HARNESS REAR ES	Bajaj spare parts
AS201042	HARNESS REAR NES	Bajaj spare parts

AS201043	ASSY CDI WITH DAMP GAS ES-BSIV	Bajaj spare parts
AS201049	HARNESS FRONT RE 2S CNG ES	Bajaj spare parts
AS201051	TELL TALE INDICATOR ASSY GAS ES	Bajaj spare parts
AS201052	ASSLY GAS INDICATOR CNG	Bajaj spare parts
AS201053	HARNESS-ES-CNG-REAR	Bajaj spare parts
AS201056	HARNESS FRONT-ES-CNG	Bajaj spare parts
AS201060	HARNESS FRONT-ES-CNG	Bajaj spare parts
AS201061	HARNESS REAR-ES-CNG	Bajaj spare parts
AS201070	INDICATOR ASSEMBLY CNG	Bajaj spare parts
AS201077	HARNESS WIRING FRONT CNG ES	Bajaj spare parts
AS201078	HARNESS WIRING REAR CNG ES	Bajaj spare parts
AS201083	REGULATOR	Bajaj spare parts
AS230005	CLAMP	Bajaj spare parts
AT111042	BRACKET ASSLY-ELECTRIC UNIT	Bajaj spare parts
AT111105	CLAMP BATTERY MTG	Bajaj spare parts
AT111137	BRACKET LAMP TAIL LH	Bajaj spare parts
AT111138	BRACKET ASSLY LAMP TAIL RH	Bajaj spare parts
AT111219	ROD ASSEMBLY BATTERY	Bajaj spare parts
AT111254	PLATE ASSEMBLY ELECTRICAL REAR	Bajaj spare parts
AT111273	PLATE ASSEMBLY ELECTRICAL REAR	Bajaj spare parts
AT113809	COVER ASSEMBLY-MIDDLE	Bajaj spare parts
AT113839	SLEEVE	Bajaj spare parts
AT113841	SLEEVE	Bajaj spare parts
AT113842	SLEEVE	Bajaj spare parts
AT113847	REINFORCEMENT BRACKET STEERING	Bajaj spare parts
AT121003	LINK ASSEMBLY LH	Bajaj spare parts
AT121004	LINK ASSEMBLY RH	Bajaj spare parts
AT131010	WHEEL 3.00BX12H2	Bajaj spare parts
AT131401	CRADLE ASSLY-SPARE WHEEL MTG	Bajaj spare parts
AT131406	CRADLE ROPE	Bajaj spare parts
AT131407	ASSLY CROSS MBR SP WH MTG	Bajaj spare parts
AT131416	HOOK CRADLE LOCKING SPARE WH MTG	Bajaj spare parts
AT131419	COVER WHEEL SPARE	Bajaj spare parts
AT131422	COVER WHEEL SPARE TOP	Bajaj spare parts
AT131800	LEVER ASSLY-PARKING BRAKE	Bajaj spare parts
AT131801	LEVER-PARKING BRAKE	Bajaj spare parts
AT131802	RATCHET	Bajaj spare parts
AT131807	WASHER	Bajaj spare parts
AT131809	BRACKET MOUNTING ASSLY	Bajaj spare parts
AT131810	SLEEVE	Bajaj spare parts
AT131817	CABLE BRAKE PARKING FRONT	Bajaj spare parts
AT131818	CABLE BRAKE PARKING REAR LH	Bajaj spare parts
AT131819	CABLE BRAKE PARKING REAR RH	Bajaj spare parts
AT131820	BRACKET EQUALISER	Bajaj spare parts
AT151000	LOCK SET	Bajaj spare parts



AT151014	BRACKET STEERING UPPER	Bajaj spare parts
AT151015	BRACKET STEERING LOWER	Bajaj spare parts
AT161002	SHAFT ASSLY REVERSE	Bajaj spare parts
AT161004	CABLE COMPLETE-REVERSE	Bajaj spare parts
AT161005	RATCHET LEVER REVERSE	Bajaj spare parts
AT161012	GROMMET	Bajaj spare parts
AT161014	ASSEMBLY PEDAL BRAKE	Bajaj spare parts
AT161209	BRACKET REVERSE CABLE STOPPER	Bajaj spare parts
AT161210	CABLE ACCELERATOR	Bajaj spare parts
AT161211	CABLE CHOKE	Bajaj spare parts
AT161212	CABLE SPEEDOMETER	Bajaj spare parts
AT161213	CABLE SPEEDOMETER INNER	Bajaj spare parts
AT161215	CABLE ACCELERATOR	Bajaj spare parts
AT171013	TANK ASSLY LIMP HOME	Bajaj spare parts
AT171018	PIPE ASSEMBLY TANK-INJECTOR	Bajaj spare parts
AT171021	TANK ASSEMBLY FUEL	Bajaj spare parts
AT171803	PIPE ASSEMBLY TANK-JOINT	Bajaj spare parts
AT172037	STRAP ASSLY-MOUNTING	Bajaj spare parts
AT172038	PACKING-RUBBER-CYLINDER MOUNTING	Bajaj spare parts
AT172044	PIPE ASSLY-STEEL	Bajaj spare parts
AT172045	HOSE ASSLY-FUEL SUPPLY	Bajaj spare parts
AT172050	CRADLE ASSLY TWIN CNG CYLINDR	Bajaj spare parts
AT172051	VALVE ASSLY-QUARTER TURN	Bajaj spare parts
AT172054	PIPE-T JOINT TO CARBURATOR	Bajaj spare parts
AT172056	PIPE ASLY-T JOINT TO CARBURATTOR	Bajaj spare parts
AT172062	PIPE ASSLY-FUEL FILTER TO PUMP	Bajaj spare parts
AT172068	PIPE ASSLY-FUEL RETURN	Bajaj spare parts
AT172073	ASSLY VALVE QUARTER TURN	Bajaj spare parts
AT172080	HOSE MFV-LPR	Bajaj spare parts
AT172081	HOSE MFV-FILLER VALVE	Bajaj spare parts
AT172082	ASSLY FILLER VALVE	Bajaj spare parts
AT172083	BRACKET ASSEMBLY FILLER VALVE	Bajaj spare parts
AT172086	REGULATOR TWO STAGE LPG	Bajaj spare parts
AT172088	REGULATOR TWO STAGE CNG	Bajaj spare parts
AT172090	BRACKET CYLINDER MOUNTING LPG-LH	Bajaj spare parts
AT172092	BRACKET ASSEMBLY CYLINDER RH	Bajaj spare parts
AT172094	VALVE MULTIFUNCTION	Bajaj spare parts
AT172096	ASSLY UNIT SENDER	Bajaj spare parts
AT172097	GAUGE LPG	Bajaj spare parts
AT172098	VALVE SOLENOID LPG	Bajaj spare parts
AT172099	PIPE VENT	Bajaj spare parts
AT172101	BRACKET REGULATOR	Bajaj spare parts
AT172102	PIPE SOLENOID-LPR	Bajaj spare parts
AT172103	SOLENOID LPG	Bajaj spare parts
AT172104	HOSE SOLENOID LPG-LPR	Bajaj spare parts

AT172105	VALVE ASSEMBLY CNG	Bajaj spare parts
AT172114	HOSE SOLENOID-RAIL CNG	Bajaj spare parts
AT172115	HOSE REGULATOR-SOLENOID CNG	Bajaj spare parts
AT172117	REGULATOR ASSEMBLY HIGH PRESSURE	Bajaj spare parts
AT172121	REGULATOR ASSEMBLY	Bajaj spare parts
AT172126	BRACKET REGULATOR	Bajaj spare parts
AT172129	HOSE LPR-RAIL	Bajaj spare parts
AT172130	SOLENOID CNG	Bajaj spare parts
AT172136	VALVE ASSEMBLY FRONT	Bajaj spare parts
AT172137	VALVE ASSEMBLY REAR	Bajaj spare parts
AT172138	PIPE ASSY CONNECTING CYLINDER	Bajaj spare parts
AT172139	HOSE SOLENOID-FILTER	Bajaj spare parts
AT172140	FILTER	Bajaj spare parts
AT172141	HOSE REGULATOR-FILTER	Bajaj spare parts
AT172142	HOSE FILTER-RAIL	Bajaj spare parts
AT172143	HOSE MFV-SOLENOID	Bajaj spare parts
AT172144	HOSE SOLENOID-REGULATOR	Bajaj spare parts
AT181203	COVER CYLINDER	Bajaj spare parts
AT181204	COVER ASSEMBLY CYLINDER	Bajaj spare parts
AT181205	LID COVER	Bajaj spare parts
AT181206	BRACKET LID	Bajaj spare parts
AT181208	BRACKET COVER LH	Bajaj spare parts
AT181209	BRACKET COVER LOWER LH	Bajaj spare parts
AT181210	BRACKET COVER LOWER RH	Bajaj spare parts
AT181211	BRACKET STOPPER LID	Bajaj spare parts
AT181212	BRACKET LOCK	Bajaj spare parts
AT182402	TRIM DOOR LH	Bajaj spare parts
AT182403	TRIM DOOR RH	Bajaj spare parts
AT184601	MIRROR ASSLY-RH	Bajaj spare parts
AT184602	MIRROR ASSLY-LH	Bajaj spare parts
AT186001	ASSEMBLY HOOD	Bajaj spare parts
AT186003	STRIP HOOD	Bajaj spare parts
AT191009	FRAME DRIVER SEAT	Bajaj spare parts
AT191012	BACKREST ASSEMBLY-PASSENGER	Bajaj spare parts
AT191016	CUSHION ASSEMBLY-SEAT PASSENGER	Bajaj spare parts
AT191020	FRAME PASSENGER SEAT TUBULAR	Bajaj spare parts
AT191022	BRACKET ASSEMBLY-HINGE	Bajaj spare parts
AT191025	SEAT ASSLY DRIVER BLACK	Bajaj spare parts
AT191027	BACKREST ASSEMBLY DRIVER BLACK	Bajaj spare parts
AT191031	FRAME ASSEMBLY SEAT DRIVER	Bajaj spare parts
AT191040	SEAT ASSEMBLY PASSENGER II	Bajaj spare parts
AT191041	BACKREST ASSEMBLY PASSENGER II	Bajaj spare parts
AT191052	SEAT ASSMBLY DRIVER	Bajaj spare parts
AT191053	BACKREST ASSEMBLY DRIVER	Bajaj spare parts
AT211371	FRAME ASSLY HOOD	Bajaj spare parts

AT211571	DAMPER	Bajaj spare parts
AT213001	Stripe hood fixing RR	Bajaj spare parts
AT213060	HOOD ASSEMBLY YELLOW	Bajaj spare parts
AT213061	HOOD ASSEMBLY GREEN	Bajaj spare parts
AT231001	TOOLKIT COMPLETE	Bajaj spare parts
AT231005	JACK ASSLY-SCREW	Bajaj spare parts
AT232603	SET LOCK	Bajaj spare parts
AT233009	DECAL BS6 LH	Bajaj spare parts
AT233010	DECAL BS6 REAR	Bajaj spare parts
AT233011	DECAL BS6 RH	Bajaj spare parts
AT241021	DAMPER	Bajaj spare parts
AT242000	LATCH DOOR LH	Bajaj spare parts
AT242001	LATCH DOOR RH	Bajaj spare parts
AT244044	TAPE	Bajaj spare parts
AT351001	STATOR ASSEMBLY	Bajaj spare parts
AT351002	ROTOR ASSEMBLY	Bajaj spare parts
AT351201	COIL ASSLY IGNITION	Bajaj spare parts
AT351202	CDI	Bajaj spare parts
AT351203	CDI	Bajaj spare parts
AT351205	COIL ASSEMBLY IGNITION LH	Bajaj spare parts
AT351213	COIL ASSEMBLY IGNITION LH	Bajaj spare parts
AT351405	ECU EMS ASSEMBLY	Bajaj spare parts
AT402006	REGULATOR	Bajaj spare parts
AT402007	REGULATOR	Bajaj spare parts
AT402211	HARNESS REAR RE MAXIMA CNG 2 CYL	Bajaj spare parts
AT402212	CABLE BATTERY	Bajaj spare parts
AT402214	CABLE EARTH	Bajaj spare parts
AT402218	HARNESS FRONT	Bajaj spare parts
AT402219	HARNESS REAR	Bajaj spare parts
AT402221	HARNESS WIRING FRONT	Bajaj spare parts
AT402223	HARNESS WIRING FRONT	Bajaj spare parts
AT402225	HARNESS WIRING REAR	Bajaj spare parts
AT402234	HARNESS WIRING FRONT CNG	Bajaj spare parts
AT402235	HARNESS WIRING REAR CNG	Bajaj spare parts
AT402236	CABLE BATTERY	Bajaj spare parts
AT402238	HARNESS WIRING FRONT LPG	Bajaj spare parts
AT402239	HARNESS WIRING REAR LPG	Bajaj spare parts
AT402243	HARNESS WIRING REAR CNG	Bajaj spare parts
AT402259	HARNESS WIRING REAR	Bajaj spare parts
AT402260	HARNESS WIRING FRONT	Bajaj spare parts
AT402262	HARNESS WIRING FRONT	Bajaj spare parts
AT402263	HARNESS WIRING REAR	Bajaj spare parts
AT402269	HARNESS WIRING FRONT CNG	Bajaj spare parts
AT402271	HARNESS WIRING FRONT	Bajaj spare parts
AT402273	HARNESS WIRING REAR	Bajaj spare parts

AT402274	HARNESS WIRING FRONT	Bajaj spare parts
AT402275	HARNESS WIRING REAR	Bajaj spare parts
AT402293	HARNESS WIRING REAR	Bajaj spare parts
AT402294	HARNESS WIRING REAR	Bajaj spare parts
AT402322	HARNESS WIRING FRONT	Bajaj spare parts
AT402323	HARNESS WIRING REAR	Bajaj spare parts
AT402324	HARNESS WIRING REAR	Bajaj spare parts
AT402409	CLUSTER INSTRUMENT CNG	Bajaj spare parts
AT402413	SPEEDOMETER	Bajaj spare parts
AT402415	SPEEDOMETER	Bajaj spare parts
AT402418	SPEEDOMETER	Bajaj spare parts
AT402419	SPEEDOMETER	Bajaj spare parts
AT402440	INSTRUMENT CLUSTER	Bajaj spare parts
AT403000	RELAY	Bajaj spare parts
AT403213	CABLE PLATE ELECTRICAL	Bajaj spare parts
AT501016	ENGINE ASSEMBLY	Bajaj spare parts
AT501018	ENGINE ASSEMBLY	Bajaj spare parts
AT501030	ENGINE ASSEMBLY	Bajaj spare parts
AT511009	HEAD CYLINDER	Bajaj spare parts
AT511201	CAMSHAFT	Bajaj spare parts
AT531007	CRANKSHAFT ASSEMBLY	Bajaj spare parts
AT531008	SPROCKET	Bajaj spare parts
AT581048	PIPE INLET-A	Bajaj spare parts
AT581051	ELBOW ASSLY	Bajaj spare parts
AT581052	INSERT RESTRICTOR ELBOW	Bajaj spare parts
AT581054	TUBE SAI INLET	Bajaj spare parts
AT581057	ELBOW RUBBER-AIR FILTER INLET	Bajaj spare parts
AT581059	INSERT RESTRICTOR-BELLOW INLET	Bajaj spare parts
AT581061	ELBOW ASSLY	Bajaj spare parts
AT581078	HOSE RAIL-INJECTOR	Bajaj spare parts
AT581079	HOSE RAIL-INJECTOR	Bajaj spare parts
AT581204	"CARBURETTOR ASSY.-SPACO,LPG MEGA"	Bajaj spare parts
AT581205	CARBURETOR LPG	Bajaj spare parts
AT990402	SEPARATOR	Bajaj spare parts
AT990405	PLATE	Bajaj spare parts
AU172002	VALVE MULTI FUNCTION	Bajaj spare parts
AU172034	CASE LOWER	Bajaj spare parts
AU172036	RING `O' (ID-6.2,C/S-1.78)	Bajaj spare parts
AU172037	RETAINER 80% - AUTO FILL LIMITER	Bajaj spare parts
AU172038	BRACKET 80% - AUTO FILL LIMITER	Bajaj spare parts
AU172039	SPRING 80% - AUTO FILL LIMITER	Bajaj spare parts
AU172040	SPRING LOCATOR 80% FILL LIMITER	Bajaj spare parts
AU172042	LEVER 80% FILL LIMITER	Bajaj spare parts
AU172043	FLOAT ROD GUIDE	Bajaj spare parts
AU172047	SCREW ALLEN-M4X10L	Bajaj spare parts

AU172048	CAP -PRV	Bajaj spare parts
AU172049	RETAINER -PRV	Bajaj spare parts
AU172051	WASHER -ID12.5,OD16.5,T1.5	Bajaj spare parts
AU172052	PLUG FUSIBLE WITH AL	Bajaj spare parts
AU172054	SPRING	Bajaj spare parts
AU172055	SPINDLE -PRV	Bajaj spare parts
AU172056	SPRING ADJUSTING SCREW	Bajaj spare parts
AU172057	RETAINER	Bajaj spare parts
AU172058	RING `O'-(ID8,C/S1.5)	Bajaj spare parts
AU172059	BUSH SEALING	Bajaj spare parts
AU172060	SCREW FOR COUPLING	Bajaj spare parts
AU172062	CLIP	Bajaj spare parts
AU172065	"WASHER ID18.2,OD21,T"	Bajaj spare parts
AU172066	CONNECTOR INLET	Bajaj spare parts
AU172067	RETAINER 80%-ALTERNATE	Bajaj spare parts
AU172068	PIN 80%-ALTERNATE	Bajaj spare parts
AU172069	TUBE -DIP	Bajaj spare parts
AU172070	PIPE -VAPOUR PRV	Bajaj spare parts
AU172072	RIVET PIN	Bajaj spare parts
AU172073	RING O	Bajaj spare parts
AU172074	SCREW ALLEN MFV	Bajaj spare parts
AU172078	ASSY -MULTIFUNCTION VALVE COMP.	Bajaj spare parts
AU351201	COIL H.T. WITH CABLE AND CAP-LH	Bajaj spare parts
AU351202	COIL H.T. WITH CABLE-LH	Bajaj spare parts
AU351204	COIL H.T. WITH CABLE -RH	Bajaj spare parts
AU351205	BRACKET-HT COIL MOUNTING	Bajaj spare parts
AU402204	BOX ASSLY FUSE	Bajaj spare parts
AU402601	GAUGE CONTENT LPG	Bajaj spare parts
AU403001	SOLENOID GAS ASSY ME	Bajaj spare parts
AU511002	CYLINDER HEAD BSIV WITHOUT SAI	Bajaj spare parts
AU511003	CYLINDER HEAD ASSLY WITHOUT SAI	Bajaj spare parts
AU511005	CAMSHAFT ASSEMBLY	Bajaj spare parts
AU541007	CRANKCASE MAGNETO SIDE FI	Bajaj spare parts
AU541012	BRACKET-MAGNTO HRNSS-CRANKCASE	Bajaj spare parts
AU581007	LTER AIR	Bajaj spare parts
AU581406	PIPE ASLY TANK TO INTK MANIFOLD	Bajaj spare parts
AU591001	SILENCER ASSLY COMPLETE-FI	Bajaj spare parts
AU591002	ASSLY EXHAUST TUBE-FI	Bajaj spare parts
AU601400	BASE FAN	Bajaj spare parts
AU611000	INJECTOR FUEL	Bajaj spare parts
AU611200	BRACKET HARNESS HOLDING	Bajaj spare parts
AY141202	FLANGE WHEEL SIDE	Bajaj spare parts
AY161205	CABLE SPEEDOMETER	Bajaj spare parts
AY171009	TUBE VACUUM-PUMP FUEL	Bajaj spare parts
AY171807	ASSLY PIPE PUMP-CARBURETTOR	Bajaj spare parts

AY171812	TAP FUEL	Bajaj spare parts
AY171813	VALVE NON RETURN	Bajaj spare parts
AY171816	PIPE JOINT L-TANK	Bajaj spare parts
AY171818	PUMP FUEL VACUUM	Bajaj spare parts
AY186000	HOOD ASSLY MUSHROOM	Bajaj spare parts
AY191000	BACKREST DRIVER BROWN	Bajaj spare parts
AY191007	SEAT ASSLY DRIVER BLACK- Z	Bajaj spare parts
AY191008	SEAT ASSLY DRIVER BROWN- Z	Bajaj spare parts
AY191009	HOOK SEAT DRIVER	Bajaj spare parts
AY191010	ASSLY SEAT PASSENGER BROWN	Bajaj spare parts
AY402204	HARNESS WIRING-FRONT	Bajaj spare parts
AY402205	HARNESS WIRING-REAR	Bajaj spare parts
AY403600	SENSOR LEVEL FUEL	Bajaj spare parts
AY511202	CAMSHAFT ASSEMBLY	Bajaj spare parts
AY581200	CARBURETTOR ASSLY	Bajaj spare parts
AY581400	MANIFOLD ASSLY	Bajaj spare parts
AY581403	PIPE ASSEMBLY TANK-MANIFOLD	Bajaj spare parts
AZ109017	SWITCH UNIT REGULATOR RECTIFIER	Bajaj spare parts
AZ111012	BRACKET UPPER FOR FUEL TANK	Bajaj spare parts
AZ111109	ROD BATTERY CLAMP	Bajaj spare parts
AZ111112	CLAMP BATTERY TOP UG	Bajaj spare parts
AZ111154	TRAY ASY-BATTERY_ STARTER RELAY	Bajaj spare parts
AZ111156	PLATE ASSLY ELECTRICAL REAR	Bajaj spare parts
AZ111166	PANEL ASSLY DEFLECTOR	Bajaj spare parts
AZ111174	SUPPORT DEFLECTOR FRONT	Bajaj spare parts
AZ113402	ASSLY REAR CROSS MEMBER FL	Bajaj spare parts
AZ113406	ASSLY ENG MOUNT RR CROSS MBR	Bajaj spare parts
AZ113415	MEMBER ASSLY ENGINE MOUNTING	Bajaj spare parts
AZ113419	BRACKET ASSEMBLY ENGINE FRONT	Bajaj spare parts
AZ113450	BRACKET ASSEMBLY ENGINE FRONT	Bajaj spare parts
AZ122005	BUSH SILENT TA UG	Bajaj spare parts
AZ122007	ASSLY DIST PIECE TA TUBE UG	Bajaj spare parts
AZ122008	SHOCKABSORBER REAR SUSP UG	Bajaj spare parts
AZ122009	SPRING REAR SUSP UG	Bajaj spare parts
AZ122016	BOLT FLANGED-M14X1.5XL303XBRIGHT	Bajaj spare parts
AZ122032	ASSEMBLY ARM TRAILING LH	Bajaj spare parts
AZ122033	ASSEMBLY ARM TRAILING RH	Bajaj spare parts
AZ131004	ASSLY WHEEL RIM	Bajaj spare parts
AZ131005	ASSLY CROSS MBR SP WH MTG UG	Bajaj spare parts
AZ131015	WHEEL 3.00BX10H2	Bajaj spare parts
AZ131403	PIVOT PIN	Bajaj spare parts
AZ131404	HOOK CRADLE LOCKING SP WH MTG	Bajaj spare parts
AZ131412	CABLE SPARE WHEEL CRADLE	Bajaj spare parts
AZ131415	CRADLE ASSLY WHEEL SPARE	Bajaj spare parts
AZ131416	COVER WHEEL SPARE	Bajaj spare parts

AZ131601	DRUM BRAKE	Bajaj spare parts
AZ131603	HUB REAR	Bajaj spare parts
AZ131605	HUB FRONT	Bajaj spare parts
AZ131606	FLANGE ASSEMBLY DRIVE	Bajaj spare parts
AZ131802	PIPE BRAKE RR-2 FL	Bajaj spare parts
AZ131803	ASSLY PKB LEVER WITH GRIP	Bajaj spare parts
AZ131804	ASSLY EQUALIAZER COMPLETE UG	Bajaj spare parts
AZ131805	EQUALIZER BRACKET PKB MOUNTING	Bajaj spare parts
AZ131806	COVER EQUALIZER PBK UG	Bajaj spare parts
AZ131807	ASSLY ROD FRONT PKB UG	Bajaj spare parts
AZ131808	ASSLY CABLE REAR PKB UG	Bajaj spare parts
AZ131809	ASSLY BRAKE PIPE REAR 2 UG	Bajaj spare parts
AZ131815	NUT SPECIAL PKB UG	Bajaj spare parts
AZ131816	ASSLY ROD AND BRACKET UG	Bajaj spare parts
AZ131817	ASSLY PIPE BRAKE-REAR	Bajaj spare parts
AZ131830	PIPE ASSEMBLY BRAKE REAR	Bajaj spare parts
AZ131831	PIPE ASSEMBLY BRAKE REAR LH	Bajaj spare parts
AZ131832	PIPE ASSEMBLY BRAKE REAR RH	Bajaj spare parts
AZ131833	BRACKET CIRCUIT BRAKE	Bajaj spare parts
AZ131834	PANEL ASSEMBLY BRAKE FRONT	Bajaj spare parts
AZ131835	PANEL ASSEMBLY BRAKE REAR LH	Bajaj spare parts
AZ131836	PANEL ASSEMBLY BRAKE REAR RH	Bajaj spare parts
AZ131842	PIPE ASSEMBLY BRAKE REAR	Bajaj spare parts
AZ141221	ASSLY DRIVE SHAFT	Bajaj spare parts
AZ151026	FORK ASSEMBLY	Bajaj spare parts
AZ161000	REVERSE LEVER	Bajaj spare parts
AZ161001	SPRING TENSION	Bajaj spare parts
AZ161003	CHOKE CABL2848 COM+4	Bajaj spare parts
AZ161009	GROMMET	Bajaj spare parts
AZ161207	GEAR CABL2555 COM+ 4	Bajaj spare parts
AZ161208	GEAR CABL2569 COM+ 4	Bajaj spare parts
AZ161209	ACC CABL2905 COM+ 4S	Bajaj spare parts
AZ161212	REVERS CABL1326 FL4S	Bajaj spare parts
AZ161213	KNOB CHOKE	Bajaj spare parts
AZ161215	SPEEDO CABL2443 COM	Bajaj spare parts
AZ161217	CLUTCH CABL2058 COM	Bajaj spare parts
AZ161220	SLEEVE PVC	Bajaj spare parts
AZ161221	CABLE SPEEDOMETER	Bajaj spare parts
AZ161222	CABLE SPEEDOMETER-INNER	Bajaj spare parts
AZ161229	CABLE BRAKE PARKING REAR RH	Bajaj spare parts
AZ171003	TANK FUEL LIMPHOME	Bajaj spare parts
AZ171006	ASSEMBLY CAP FUEL TANK	Bajaj spare parts
AZ171009	Assly SUP BKT LAMP	Bajaj spare parts
AZ171016	TANK ASSEMBLY FUEL	Bajaj spare parts
AZ171803	PIPE FUEL TANK TO FIL	Bajaj spare parts

AZ171805	PIPE FUEL PUMP TO T JOINT	Bajaj spare parts
AZ171807	PIPE FUEL RETURN	Bajaj spare parts
AZ171808	JOINT T	Bajaj spare parts
AZ171811	JOINT T	Bajaj spare parts
AZ171812	ASSLY PIPE FUEL FILTER	Bajaj spare parts
AZ171815	PIPE FUEL TANK TO FILTER UG	Bajaj spare parts
AZ171816	PIPE FUEL FILTER TO PUMP UG	Bajaj spare parts
AZ171817	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
AZ171818	PIPE FUEL RETURN UG	Bajaj spare parts
AZ171819	ASSLY PIPE FUEL TANK TO FILTR	Bajaj spare parts
AZ171820	ASSEMBLY PIPE FUEL FILTR TO PUMP	Bajaj spare parts
AZ171821	ASSEMBLY PIPE FUEL PUMP TO T JNT	Bajaj spare parts
AZ171822	ASSEMBLY PIPE FUEL RETURN UG	Bajaj spare parts
AZ171827	ASSEMBLY PIPE T JOINT TO CARBURETTOR	Bajaj spare parts
AZ171828	PIPE T JOINT TO CARBURETTOR UG	Bajaj spare parts
AZ171835	ASSLY FUEL PIPE T JOINT TO CARBU	Bajaj spare parts
AZ171836	PIPE FUEL FROM T JOINT TO CARBU	Bajaj spare parts
AZ171839	ASSLY TANK FUEL LIMPHOME UG	Bajaj spare parts
AZ171840	HOOK	Bajaj spare parts
AZ171841	PIPE ASSEMBLY TANK-JOINT	Bajaj spare parts
AZ172004	BRACKET LPR MOUNTING	Bajaj spare parts
AZ172006	REGULATOR CNG TWO STAGE R	Bajaj spare parts
AZ172009	BREATHER HOSE	Bajaj spare parts
AZ172013	UNIT 1ST STAGE REDUCTION	Bajaj spare parts
AZ172017	TUBE ASSY STEEL	Bajaj spare parts
AZ172030	HOSE REG TO MIXER	Bajaj spare parts
AZ172036	ASSEMBLY HPR CNG UG UNIT	Bajaj spare parts
AZ172037	ASSEMBLY STRAP GAS CYLINDER	Bajaj spare parts
AZ172040	ASSEMBLY CRADLE CYLINDER MTG UG	Bajaj spare parts
AZ172049	RUBBER BEADING FOR STRAP UG	Bajaj spare parts
AZ172054	PACKING	Bajaj spare parts
AZ172055	PACKING LOWER CNG CYL MTG	Bajaj spare parts
AZ172056	ASSLY VALVE QUARTER TURN UG	Bajaj spare parts
AZ172063	REGULATOR CNG TWO STAGE	Bajaj spare parts
AZ172074	CLAMP ASSLY	Bajaj spare parts
AZ172076	REGULATOR TWO STAGE CNG	Bajaj spare parts
AZ172081	HOSE ASSEMBLY	Bajaj spare parts
AZ172084	PIPE DUCT-REGULATOR	Bajaj spare parts
AZ172087	HOSE SOLENOID-RAIL GAS	Bajaj spare parts
AZ172089	REGULATOR ASSEMBLY	Bajaj spare parts
AZ172090	BRACKET REGULATOR	Bajaj spare parts
AZ172091	HOSE SOLENOID-REGULATOR	Bajaj spare parts
AZ172096	HOSE SOLENOID-FILTER	Bajaj spare parts
AZ172119	ASSEMBLY STRAP CYLINDER	Bajaj spare parts
AZ181004	TRIM DOOR TOP-LH	Bajaj spare parts



AZ181005	TRIM DOOR BOTTOM-LH	Bajaj spare parts
AZ181006	TRIM DOOR TOP-RH	Bajaj spare parts
AZ181007	TRIM DOOR BOTTOM-RH	Bajaj spare parts
AZ181204	COVER TRIM	Bajaj spare parts
AZ181207	COVER ASSEMBLY SEAT DRIVER	Bajaj spare parts
AZ181209	LID COVER	Bajaj spare parts
AZ181210	BRACKET HINGE COVER	Bajaj spare parts
AZ181211	BRACKET HINGE LID	Bajaj spare parts
AZ181213	BRACKET COVER LOWER	Bajaj spare parts
AZ181214	BRACKET COVER LH	Bajaj spare parts
AZ181215	BRACKET STOPPER LID	Bajaj spare parts
AZ181216	BRACKET LOCK	Bajaj spare parts
AZ181217	BRACKET COVER LOWER LH	Bajaj spare parts
AZ181218	CLIP	Bajaj spare parts
AZ181220	BRACKET LOCK	Bajaj spare parts
AZ181401	FLAP MUD-REAR	Bajaj spare parts
AZ182401	TRIM PAD PASS BODY LH UG	Bajaj spare parts
AZ182402	TRIM PAD PASS BODY RH UG	Bajaj spare parts
AZ182403	CAP SPARE WHEEL MTG CUTOUT UG	Bajaj spare parts
AZ182404	RIVET PLASTIC FOR 6.5MM HOLE	Bajaj spare parts
AZ185001	GRILL AIR INTAKE SNORKEL TOP UG	Bajaj spare parts
AZ185002	GRILL AIR INTAKE SNORKEL BTM UG	Bajaj spare parts
AZ185003	PACKING SNORKEL COVER UG	Bajaj spare parts
AZ185005	GRILL AIR INTAKE SNORKEL TOP UG	Bajaj spare parts
AZ185006	GRILL AIR INTAKE SNORKEL BTM UG	Bajaj spare parts
AZ185007	PACKING SNORKEL COVER UG	Bajaj spare parts
AZ185008	COVER STEERING	Bajaj spare parts
AZ185010	ASSLY COVER STEERING	Bajaj spare parts
AZ185011	COVER ASSEMBLY STEERING	Bajaj spare parts
AZ186001	HOOD COMPLETE UG	Bajaj spare parts
AZ191003	ASSLY DRIVER SEAT COMP UG	Bajaj spare parts
AZ191004	FRAME ASSEMBLY SEAT DRIVER	Bajaj spare parts
AZ191010	DRIVER SEAT CUSHION PAN UG	Bajaj spare parts
AZ191022	SEAT ASSEMBLY DRIVER	Bajaj spare parts
AZ191024	BACKREST ASSEMBLY DRIVER	Bajaj spare parts
AZ192000	ASSLY BELT LAP DRIVER SEAT UG	Bajaj spare parts
AZ211093	ASSLY HOOD FRAME UG	Bajaj spare parts
AZ211094	ASSLY HOOD PIPE SIDE LH UG	Bajaj spare parts
AZ211098	ASSLY HOOD PIPE SIDE RH UG	Bajaj spare parts
AZ211188	PIPE CROSS C D PILLAR	Bajaj spare parts
AZ211325	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
AZ213006	HOOD COMPLETE REX (YELLOW) FL	Bajaj spare parts
AZ213011	PIPE C PILLAR UG	Bajaj spare parts
AZ213025	PIPE SUPPORT D PILLAR LH UG	Bajaj spare parts
AZ213026	PIPE SUPPORT D PILLAR RH UG	Bajaj spare parts

AZ213028	BRACKET C PLR SUPP SIDE OUTER UG	Bajaj spare parts
AZ213030	ASSLY B PILLAR UG	Bajaj spare parts
AZ213031	PIPE MIDDLE D PILLAR FRONT UG	Bajaj spare parts
AZ213045	BRACKET HOOD CON INNER LH UG	Bajaj spare parts
AZ213046	BRACKET HOOD CON INNER RH UG	Bajaj spare parts
AZ213047	BRACKET B PLR SUPP SIDE OUTER UG	Bajaj spare parts
AZ213050	ASSLY D PILLAR LH UG	Bajaj spare parts
AZ213051	ASSLY D PILLAR RH UG	Bajaj spare parts
AZ213054	ASSLY PIPE MIDDLE D PILLAR UG	Bajaj spare parts
AZ213126	HOOD ASSEMBLY YELLOW	Bajaj spare parts
AZ231000	TOOL KIT COMPLETE FL	Bajaj spare parts
AZ231005	TOOLKIT	Bajaj spare parts
AZ232600	LOCK SET RE 205M CNG/ LPG	Bajaj spare parts
AZ232601	LOCK SET	Bajaj spare parts
AZ232602	LOCK SET RE205X FL	Bajaj spare parts
AZ232607	SET LOCK	Bajaj spare parts
AZ232610	SET LOCK	Bajaj spare parts
AZ233006	LABEL COMPACT PLUS WHITE	Bajaj spare parts
AZ233007	LABEL COMPACT PLUS BLACK	Bajaj spare parts
AZ233008	EMBLEM BAJAJ	Bajaj spare parts
AZ233009	EMBLEM MAXIMA	Bajaj spare parts
AZ233012	LABEL BAJAJ MAXIMA-WHITE	Bajaj spare parts
AZ233013	LABEL BAJAJ MAXIMA-BLACK	Bajaj spare parts
AZ233014	LABEL Z-MAXIMA BLACK	Bajaj spare parts
AZ233015	LABEL Z-MAXIMA WHITE	Bajaj spare parts
AZ233016	LABEL BS4-MAXIMA Z	Bajaj spare parts
AZ241029	DAMPER	Bajaj spare parts
AZ241031	DAMPER SIDE DOOR UPR UG	Bajaj spare parts
AZ241032	DAMPER SIDE DOOR LWR UG	Bajaj spare parts
AZ241039	GUIDE KNOB MTG SIDE DOOR UG	Bajaj spare parts
AZ241401	ASSLY HINGE SIDE DOOR LH UG	Bajaj spare parts
AZ241402	ASSLY HINGE SIDE DOOR RH UG	Bajaj spare parts
AZ242002	LATCH ASSLY SIDE DOOR LH	Bajaj spare parts
AZ242003	LATCH ASSLY SIDE DOOR RH	Bajaj spare parts
AZ242004	PLATE STRIKER LATCH	Bajaj spare parts
AZ244017	ASSLY HINGE EAC UG	Bajaj spare parts
AZ244026	CABLE DOOR HOLDING UG	Bajaj spare parts
AZ244039	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
AZ245000	LATCH ASSEMBLY	Bajaj spare parts
AZ247000	ASSLY HINGE RR UPPER DOOR UG	Bajaj spare parts
AZ351001	ROTOR ASSEMBLY	Bajaj spare parts
AZ351002	STATOR ASSEMBLY	Bajaj spare parts
AZ351010	STATOR ASSEMBLY	Bajaj spare parts
AZ351206	PLUG SPARK	Bajaj spare parts
AZ351207	PLUG SPARK	Bajaj spare parts

AZ351209	COIL HT WITH CABLE AND CAP - LH	Bajaj spare parts
AZ351214	COIL ASSEMBLY IGNITION LH	Bajaj spare parts
AZ351216	CDI ASSLY	Bajaj spare parts
AZ351217	COIL ASSEMBLY IGNITION RH	Bajaj spare parts
AZ351222	COIL ASSEMBLY IGNITION LH	Bajaj spare parts
AZ351401	ECU EMS ASSEMBLY	Bajaj spare parts
AZ401001	ASSLY TAILLAMP LH UG	Bajaj spare parts
AZ401002	ASSLY TAILLAMP RH UG	Bajaj spare parts
AZ401400	SWITCH G O P CNG VERTICAL FL	Bajaj spare parts
AZ402005	REGULATOR ASSEMBLY	Bajaj spare parts
AZ402208	CABLE BATTERY RE205M FL	Bajaj spare parts
AZ402211	HARNESS WIRING FR 205X CNG FLHARNESS WIR	Bajaj spare parts
AZ402212	HARNESS WIRING RR 205X CNG FLHARNESS WIR	Bajaj spare parts
AZ402214	HARNESS WIRING FRONT INT DB	Bajaj spare parts
AZ402216	HARNESS WIRING FRONT UG	Bajaj spare parts
AZ402217	HARNESS WIRING REAR	Bajaj spare parts
AZ402218	HARNESS WIRING EARTH UG	Bajaj spare parts
AZ402220	HARNESS WIRING REAR	Bajaj spare parts
AZ402222	HARNESS WIRING FRONT INT DB	Bajaj spare parts
AZ402223	CABLE BATTERY	Bajaj spare parts
AZ402224	HARNESS WIRING-REAR	Bajaj spare parts
AZ402225	CABLE BATTERY NEGATIVE	Bajaj spare parts
AZ402230	HARNESS WIRING-REAR CNG	Bajaj spare parts
AZ402231	HARNESS WIRING FRONT CNG	Bajaj spare parts
AZ402232	HARNESS WIRING REAR	Bajaj spare parts
AZ402243	CABLE BATTERY POSITIVE	Bajaj spare parts
AZ402245	HARNESS WIRING FRONT	Bajaj spare parts
AZ402246	HARNESS WIRING REAR	Bajaj spare parts
AZ402253	HARNESS WIRING FRONT	Bajaj spare parts
AZ402254	HARNESS WIRING REAR	Bajaj spare parts
AZ402258	BOX ASSEMBLY FUSE	Bajaj spare parts
AZ402263	HARNESS WIRING FRONT	Bajaj spare parts
AZ402264	HARNESS WIRING REAR	Bajaj spare parts
AZ402287	HARNESS WIRING FRONT	Bajaj spare parts
AZ402288	HARNESS WIRING REAR	Bajaj spare parts
AZ402402	SPEEDOMETER ASSLY OF 0.85 RATIO	Bajaj spare parts
AZ402403	SPEEDOMETER ASSLY OF 0.85 RATIO	Bajaj spare parts
AZ402414	INSTRUMENT CLUSTER	Bajaj spare parts
AZ402600	INDICATOR ASSLY RH POD	Bajaj spare parts
AZ402602	INDICATOR POD RH	Bajaj spare parts
AZ402608	SENSOR LEVEL FUEL	Bajaj spare parts
AZ501002	ENGINE ASSY. COMPLETE	Bajaj spare parts
AZ501005	ENGINE ASSY. COMPLETE	Bajaj spare parts
AZ501006	ENGINE ASSY. BS4-COMPACT+ CNG	Bajaj spare parts
AZ501007	ENGINE ASSY COMPLETE -UG	Bajaj spare parts

AZ501014	GUARD MAGNETO	Bajaj spare parts
AZ501021	ENGINE ASSEMBLY	Bajaj spare parts
AZ511010	SLEEVE SPARK PLUG	Bajaj spare parts
AZ511201	VALVE INTAKE	Bajaj spare parts
AZ511202	VALVE EXHAUST	Bajaj spare parts
AZ511204	CAMSHAFT ASSLY	Bajaj spare parts
AZ511207	SHAFT ROCKER ARM INTAKE	Bajaj spare parts
AZ511208	SHAFT ROCKER ARM EXHAUST	Bajaj spare parts
AZ521000	CYLINDER BLOCK COMPLETE	Bajaj spare parts
AZ521003	GASKET -CYLINDER HEAD	Bajaj spare parts
AZ521004	BLOCK CYLINDER	Bajaj spare parts
AZ521200	ASSLY PISTON	Bajaj spare parts
AZ531000	ASSLY CRANK SHAFT	Bajaj spare parts
AZ531003	ROD CONNECTING	Bajaj spare parts
AZ551000	ASSLY MAIN SHAFT	Bajaj spare parts
AZ551001	SHAFT CLUTCH RELEASE	Bajaj spare parts
AZ551002	SHAFT ASSLY MAIN	Bajaj spare parts
AZ551003	SHAFT MAIN	Bajaj spare parts
AZ551200	GEAR BEVEL SG. HSG. SIDE	Bajaj spare parts
AZ551201	GEAR BEVEL DIFF. GEAR SIDE	Bajaj spare parts
AZ551202	PINION PRIMARY	Bajaj spare parts
AZ551203	GEAR PRIMARY HELICAL	Bajaj spare parts
AZ551206	CLUTCH ASSY COMPLETE	Bajaj spare parts
AZ551210	GEAR MULTIPLE	Bajaj spare parts
AZ551211	GEAR SPEED-2ND	Bajaj spare parts
AZ551212	GEAR SPEED-3RD	Bajaj spare parts
AZ551213	GEAR SPEED-4TH	Bajaj spare parts
AZ551217	PINION PRIMARY	Bajaj spare parts
AZ551404	HOUSING ASSLY CLUTCH	Bajaj spare parts
AZ551602	GEAR DIFFERENTIAL	Bajaj spare parts
AZ551603	GEAR REVERSE CONTROL	Bajaj spare parts
AZ551604	GEAR IDLER	Bajaj spare parts
AZ551605	GEAR ASSLY DIFFERENTIAL	Bajaj spare parts
AZ551609	PIPE BREATHER	Bajaj spare parts
AZ552602	PINION FAREMETER	Bajaj spare parts
AZ552604	GEAR FAREMETER	Bajaj spare parts
AZ571200	BRACKET OIL COOLER MTG WITH BELLOW	Bajaj spare parts
AZ571201	BRACKET FOR OIL COOLER MTG	Bajaj spare parts
AZ571202	BRACKET OIL COOLER 3RD SUPPORT	Bajaj spare parts
AZ571203	COOLER ASSLY-OIL	Bajaj spare parts
AZ571209	PIPE ASSEMBLY-BANJO	Bajaj spare parts
AZ571210	COOLER ASSLY OIL	Bajaj spare parts
AZ571211	COOLER OIL	Bajaj spare parts
AZ571212	GROMMET	Bajaj spare parts
AZ571213	COLLAR	Bajaj spare parts

AZ571214	PIPE ASSLY OIL HOT	Bajaj spare parts
AZ571215	PIPE ASSLY OIL COOL	Bajaj spare parts
AZ571219	PIPE ASSEMBLY OIL HOT	Bajaj spare parts
AZ571220	PIPE ASSEMBLY OIL COOL	Bajaj spare parts
AZ571226	COOLER OIL	Bajaj spare parts
AZ571227	GUARD COOLER OIL	Bajaj spare parts
AZ571228	BRACKET COOLER OIL	Bajaj spare parts
AZ571230	BRACKET FOR OIL COOLER MTG	Bajaj spare parts
AZ571231	PIPE ASSEMBLY OIL COOL	Bajaj spare parts
AZ571232	PIPE ASSEMBLY OIL HOT	Bajaj spare parts
AZ581009	ARRESTER BACK FIRE	Bajaj spare parts
AZ581013	ELBOW RUBBER	Bajaj spare parts
AZ581018	PIPE AIR INTAKE UPPER	Bajaj spare parts
AZ581021	ELBOW TOP END	Bajaj spare parts
AZ581024	CLIP DUCT AIR BODY	Bajaj spare parts
AZ581026	MIXER BODY	Bajaj spare parts
AZ581030	DUCT INTEGRAL	Bajaj spare parts
AZ581033	BELLOW PIPE A/F INLET	Bajaj spare parts
AZ581034	PIPE AIR FILTER INLET	Bajaj spare parts
AZ581039	VENTURI OD 32 ID 23.8	Bajaj spare parts
AZ581041	INSERT RESTRICTER	Bajaj spare parts
AZ581047	TUBE BREATHER	Bajaj spare parts
AZ581049	ASSLY COMP INTEGRAL DUCT	Bajaj spare parts
AZ581057	INSERT RESTRICTER-ELBOW	Bajaj spare parts
AZ581069	ASSLY COMPLETE INTEGRAL DUCT	Bajaj spare parts
AZ581071	ASSLY BELLOW PIPE AF INLET	Bajaj spare parts
AZ581073	INSERT RESTRICTOR ELBOW DIA.13	Bajaj spare parts
AZ581074	ASSLY ELBOW WITH RESTRICTOR	Bajaj spare parts
AZ581075	ASSLY ELBOW RUBBER	Bajaj spare parts
AZ581076	ELBOW RUBBER	Bajaj spare parts
AZ581090	BELLOW ASSLY INLET	Bajaj spare parts
AZ581091	INSERT	Bajaj spare parts
AZ581095	DUCT ASSEMBLY FILTER AIR OUTLET	Bajaj spare parts
AZ581097	SLEEVE MANIFOLD	Bajaj spare parts
AZ581111	FILTER ASSEMBLY AIR	Bajaj spare parts
AZ581113	PIPE BREATHER COVER SIDE	Bajaj spare parts
AZ581114	PIPE BREATHER FILTER SIDE	Bajaj spare parts
AZ581115	CONNECTOR ASSEMBLY	Bajaj spare parts
AZ581217	CARBURETTOR ASSY.-UCAL	Bajaj spare parts
AZ581219	CARBURETTOR ASSY-FLANGE TYPE	Bajaj spare parts
AZ581220	TUBE BREATHER II	Bajaj spare parts
AZ581224	CARBURETTOR ASSY- UG CNG	Bajaj spare parts
AZ581231	BRACKET BODY THROTTLE	Bajaj spare parts
AZ581408	MANIFOLD INTAKE-BOTH SIDE FLANGE	Bajaj spare parts
AZ581409	ASSLY MANIFOLD WITH NIPPLE	Bajaj spare parts

AZ581412	MANIFOLD INTAKE	Bajaj spare parts
AZ581419	MANIFOLD INTAKE	Bajaj spare parts
AZ582200	BRACKET FOR SAI UNIT MTG	Bajaj spare parts
AZ582400	TUBE SAI INLET-1	Bajaj spare parts
AZ582405	TUBE ASSEMBLY SAI	Bajaj spare parts
AZ591011	ASSEMBLY - EXHAUST TUBE	Bajaj spare parts
AZ591014	MUFFLER ASSY. COMPLETE	Bajaj spare parts
AZ591016	SHIELD HEAT - 1	Bajaj spare parts
AZ591028	SILENCER ASSY. COMP-BASF	Bajaj spare parts
AZ591033	ASSLY EXHAUST TUBE	Bajaj spare parts
AZ591048	MUFFLER ASSLY COMPLETE	Bajaj spare parts
AZ591049	SILENCER ASSLY. COMPLETE	Bajaj spare parts
AZ591064	GASKET EXHAUST	Bajaj spare parts
AZ591066	SILENCER ASSEMBLY	Bajaj spare parts
AZ591067	MUFFLER ASSEMBLY	Bajaj spare parts
AZ601402	FAN BASE	Bajaj spare parts
AZ601403	FAN	Bajaj spare parts
AZ601404	FAN COVER	Bajaj spare parts
AZ601405	ASSLY FAN COVER	Bajaj spare parts
AZ601408	CAP COVER HEAD	Bajaj spare parts
AZ601409	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
AZ601410	COWLING ASSEMBLY EXHAUST	Bajaj spare parts
AZ601413	Cowling Intake	Bajaj spare parts
AZ601414	PAD	Bajaj spare parts
AZ601421	BASE FAN	Bajaj spare parts
AZ611200	BODY THROTTLE ASSEMBLY	Bajaj spare parts
AZ611201	BODY THROTTLE ASSEMBLY	Bajaj spare parts
AZ621016	TUBE STARTING ASSY. COMPLETE	Bajaj spare parts
AZ621019	ASSEMBLY STARTING HANDLE	Bajaj spare parts
AZ621022	SUPPORT ASY SPINDLE LEVER	Bajaj spare parts
AZ621202	LEVER STARTER	Bajaj spare parts
AZ990108	BREATHER RESTRICTOR	Bajaj spare parts
AZ990403	SEPARATOR	Bajaj spare parts
BA100300	STUD M6X1	Bajaj spare parts
BA101093	RING SET PISTON GC 1000	Bajaj spare parts
BA102003	PLUG OIL HOLE	Bajaj spare parts
BA102004	PLUG	Bajaj spare parts
BA102005	GASKET COVER SIDE STD	Bajaj spare parts
BA102006	PIPE PIN	Bajaj spare parts
BA102007	SHAFT BALANCER	Bajaj spare parts
BA102008	PIPE PIN	Bajaj spare parts
BA102009	PIN	Bajaj spare parts
BA102011	HEAD CYLINDER	Bajaj spare parts
BA102014	VALVE INLET GC 1000	Bajaj spare parts
BA102016	GASKET HEAD CYLINDER	Bajaj spare parts

BA102018	CAP SEALING	Bajaj spare parts
BA102019	SPRING VALVE	Bajaj spare parts
BA102020	SPRING RETAINER VALVE	Bajaj spare parts
BA102021	GUIDE VALVE INLET	Bajaj spare parts
BA102022	COLLET VALVE SPRING	Bajaj spare parts
BA102023	GUIDE VALVE EXHAUST	Bajaj spare parts
BA102025	SEAT VALVE INLET	Bajaj spare parts
BA102026	SEAT VALVE EXHAUST	Bajaj spare parts
BA102027	PIPE JOINT OIL TUBE	Bajaj spare parts
BA102029	GASKET SILENCER	Bajaj spare parts
BA102033	ARM ROCKER INLET GC 1000	Bajaj spare parts
BA102034	ARM ROCKER EXHAUST	Bajaj spare parts
BA102036	NUT	Bajaj spare parts
BA102038	PLUG OIL	Bajaj spare parts
BA102042	GASKET COVER HEAD	Bajaj spare parts
BA102043	TUBE BREATHER	Bajaj spare parts
BA102047	BOLT DECOMP.	Bajaj spare parts
BA102048	TAPPET	Bajaj spare parts
BA102054	GEAR CAM	Bajaj spare parts
BA102055	SHIM CAMSHAFT	Bajaj spare parts
BA102062	CIRCLIP PISTON PIN	Bajaj spare parts
BA102064	METAL CRANK PIN	Bajaj spare parts
BA102065	BOLT CONNECTING ROD	Bajaj spare parts
BA102066	WASHER CONNECTING ROD	Bajaj spare parts
BA102068	BEARING CRANKSHAFT	Bajaj spare parts
BA102069	WASHER THRUST 1	Bajaj spare parts
BA102071	GEAR CRANK SHAFT	Bajaj spare parts
BA102072	GEAR 1 BALANCER	Bajaj spare parts
BA102075	WEIGHT BALANCER	Bajaj spare parts
BA102076	CASE BALANCER	Bajaj spare parts
BA102077	GEAR 2 BALANCER	Bajaj spare parts
BA102078	KEY FEATHER	Bajaj spare parts
BA102079	FILTER OIL	Bajaj spare parts
BA102080	GAUGE OIL	Bajaj spare parts
BA102084	PLUG	Bajaj spare parts
BA102087	PACKING	Bajaj spare parts
BA102088	COOLER OIL	Bajaj spare parts
BA102090	COLLAR VIBROI.Rubb	Bajaj spare parts
BA102096	COVER OIL COOLER (PPCP)	Bajaj spare parts
BA102099	KEY WOODRUFF	Bajaj spare parts
BA102100	NUT FLYWHEEL	Bajaj spare parts
BA102104	FAIRING CYLINDER GC1000	Bajaj spare parts
BA102113	CARTRIDGE FILTER OIL	Bajaj spare parts
BA102118	CAP SEALING CRANK	Bajaj spare parts
BA102126	BUSH CRANKSHAFT	Bajaj spare parts

BA102127	BALL	Bajaj spare parts
BA102129	KEY WOODRUFF	Bajaj spare parts
BA102130	KEY WOODRUFF	Bajaj spare parts
BA102131	GASKET COVER SIDE UNDER S	Bajaj spare parts
BA102132	GASKET COVER SIDE	Bajaj spare parts
BA102146	TUBE BREATHER	Bajaj spare parts
BA102147	CLIP PIPE	Bajaj spare parts
BA102149	CAMSHAFT ASSY GC1000	Bajaj spare parts
BA102150	RING SET PISTON GC 1000	Bajaj spare parts
BA102156	CLIP HOSE	Bajaj spare parts
BA102158	BRACKET ENGINE FR	Bajaj spare parts
BA102159	BRACKET ENGINE RR	Bajaj spare parts
BA102160	ISOLATOR RUBBER	Bajaj spare parts
BA102161	ISOLATOR RUBBER	Bajaj spare parts
BA102164	BRACKET MTG. MAIN HSG.	Bajaj spare parts
BA102167	BUSH connecting rod	Bajaj spare parts
BA102174	PIN CRANK METAL UNDER SI	Bajaj spare parts
BA102175	BEARING MAIN US	Bajaj spare parts
BA102176	PLUG OIL	Bajaj spare parts
BA102186	SCREW LOCK 1	Bajaj spare parts
BA102187	SCREW LOCK 2	Bajaj spare parts
BA102197	TUBE OIL 3 COOLER TO FIL	Bajaj spare parts
BA102207	PIPE BREATHER JOINT	Bajaj spare parts
BA102208	CRANKSHAFT ASSY RE DIESEL	Bajaj spare parts
BA102215	SEAL COVER DUST	Bajaj spare parts
BA102216	COVER DUST ALTERANATOR	Bajaj spare parts
BA102221	SILENCER RE DIESEL	Bajaj spare parts
BA102222	RUBBER 3	Bajaj spare parts
BA102233	BOLT - LONG HEAD	Bajaj spare parts
BA102235	TUBE 1 OIL	Bajaj spare parts
BA102244	PIPE INTAKE	Bajaj spare parts
BA102254	BUSH HEAD COVER LEVER DECOMP.	Bajaj spare parts
BA102255	BOLT CASE BALANCER	Bajaj spare parts
BA102258	Hose clip	Bajaj spare parts
BA102259	SUB ASSY HEAD COVER	Bajaj spare parts
BA102263	SPRING TORSION	Bajaj spare parts
BA102264	HEAD COVER ASSY RE DE	Bajaj spare parts
BA102267	SHAFT COMP. DECOMP	Bajaj spare parts
BA102270	BOLT CYLINDER HEAD	Bajaj spare parts
BA102279	SCREW ADJUST ROCKER	Bajaj spare parts
BA102283	COVER SIDE ASSY	Bajaj spare parts
BA102286	SIDE COVER KUBOTA CARGO	Bajaj spare parts
BA102290	COVER SIDE	Bajaj spare parts
BA102292	CLIP GUIDE	Bajaj spare parts
BA102293	SPRING	Bajaj spare parts



BA102295	WASHER THRUST CRANK CASE	Bajaj spare parts
BA102296	WASHER THRUST SIDE COVER	Bajaj spare parts
BA102301	BRACKET COMP ROCKER ARM	Bajaj spare parts
BA102303	SHAFT ROCKER ARM	Bajaj spare parts
BA102304	WASHER THRUST	Bajaj spare parts
BA102305	SPACER	Bajaj spare parts
BA102308	BRACKET DECOMP	Bajaj spare parts
BA102309	WASHER THRUST-CRANKCASE	Bajaj spare parts
BA103003	TUBE EXHAUST	Bajaj spare parts
BA103004	SILENCER	Bajaj spare parts
BA103009	BRACKET AIR CLEANER	Bajaj spare parts
BA103010	ENGINE ASSLY COMPLETE	Bajaj spare parts
BA103011	SILENCER ASSEMBLY	Bajaj spare parts
BA103012	WASHER SPECIAL	Bajaj spare parts
BA103017	PIPE RESV. TO FIP BENJO	Bajaj spare parts
BA103022	RESERVOIR FUEL	Bajaj spare parts
BA103024	PIPE RESV. TO JOINT T	Bajaj spare parts
BA103027	HOSE AIR FILTER TO MANIFOLD	Bajaj spare parts
BA103031	ASSLY BRACKET RESERVIOR	Bajaj spare parts
BA103032	BRACKET DECOMPRESSION FOR CABLE	Bajaj spare parts
BA103035	ASSLY CUP AIR SUCTION	Bajaj spare parts
BA103037	HOSE RUBBER SLEEVE BODY END	Bajaj spare parts
BA103040	ASSLY ENGINE AND TRANS COMP.	Bajaj spare parts
BA103041	ASSLY OIL FILTER	Bajaj spare parts
BA103043	BS4 INSERT COVER OIL FILTER	Bajaj spare parts
BA103044	ASSLY AIR FILTER	Bajaj spare parts
BA103045	ASSLY ELEMENT	Bajaj spare parts
BA103049	CYCLOPACK	Bajaj spare parts
BA103320	ASSEMBLY ENGINE BS4	Bajaj spare parts
BA103322	ASSLY SILENCER COMPLETE	Bajaj spare parts
BA103323	TUBE EXHAUST	Bajaj spare parts
BA103326	SILENCER BS4	Bajaj spare parts
BA103335	MANIFOLD INTAKE	Bajaj spare parts
BA103340	BRACKET TANK SURGE	Bajaj spare parts
BA103341	HOSE TANK SURGE	Bajaj spare parts
BA103342	ASSLY TANK SURGE	Bajaj spare parts
BA103604	MANIFOLD INTAKE	Bajaj spare parts
BA103608	COOLER EGR	Bajaj spare parts
BA103609	PIPE ASSY COOLER EGR-MANIFOLD	Bajaj spare parts
BA103611	MANIFOLD EXHAUST	Bajaj spare parts
BA103622	MUFFLER ASSEMBLY	Bajaj spare parts
BA103625	PIPE FILTER OIL INLET	Bajaj spare parts
BA103626	PIPE FILTER OIL OUTLET	Bajaj spare parts
BA103628	SILENCER ASSEMBLY	Bajaj spare parts
BA103629	FILTER ASSEMBLY OIL	Bajaj spare parts

BA103637	GASKET MANIFOLD INTAKE	Bajaj spare parts
BA103641	HOUSING CLUTCH	Bajaj spare parts
BA103648	PIPE PUMP-COOLER EGR I	Bajaj spare parts
BA103651	GASKET COOLER EGR INLET	Bajaj spare parts
BA103653	FILTER FUEL	Bajaj spare parts
BA103656	PIPE ASSEMBLY MANIFOLD-SENSOR	Bajaj spare parts
BA103659	PIPE MANIFOLD-SENSOR PRESSURE II	Bajaj spare parts
BA103661	BRACKET SENSOR PRESSURE	Bajaj spare parts
BA103662	PIPE ASSEMBLY COOLANT INLET	Bajaj spare parts
BA103663	PIPE ASSEMBLY COOLANT OUTLET	Bajaj spare parts
BA103664	BRACKET HARNESS	Bajaj spare parts
BA103667	SHIELD	Bajaj spare parts
BA103668	MANIFOLD VALVE EGR	Bajaj spare parts
BA103669	BOSS	Bajaj spare parts
BA103670	BRACKET VALVE NON RETURN	Bajaj spare parts
BA103673	TANK ASSEMBLY SURGE	Bajaj spare parts
BA103676	CAP	Bajaj spare parts
BA103686	COOLER EGR	Bajaj spare parts
BA103687	PIPE ASSEMBLY OUTLET	Bajaj spare parts
BA103690	SENSOR FLOW AIR	Bajaj spare parts
BA103713	PINION DIFFERENTIAL	Bajaj spare parts
BA103724	SILENCER ASSEMBLY	Bajaj spare parts
BA111006	"CORD, GLOW PLUG"	Bajaj spare parts
BA111016	RING GEAR	Bajaj spare parts
BA111017	PLUG GLOW	Bajaj spare parts
BA111023	STATOR ASSYSINGLE PHASE	Bajaj spare parts
BA111077	ECU EMS ASSEMBLY	Bajaj spare parts
BA122001	PIPE FUEL OVERFLOW	Bajaj spare parts
BA122002	CLAMP CORD	Bajaj spare parts
BA122003	CLIP PIPE	Bajaj spare parts
BA122005	JOINT T	Bajaj spare parts
BA122011	PACKING	Bajaj spare parts
BA122012	SEAL HEAT	Bajaj spare parts
BA122013	CLAMP NOZZLE	Bajaj spare parts
BA122014	CLAMP PIPE	Bajaj spare parts
BA122029	GEAR COMPL GOVERNOR	Bajaj spare parts
BA122032	STOPPER	Bajaj spare parts
BA122034	COLLAR - GOVERNOR WEIGHT	Bajaj spare parts
BA122036	LEVER 1 GOVERNOR	Bajaj spare parts
BA122041	PIN SHAFT GOVERNOR	Bajaj spare parts
BA122044	SPRING GOVERNOR	Bajaj spare parts
BA122047	SHAFT LEVER SPEED	Bajaj spare parts
BA122048	KEY FEATHER	Bajaj spare parts
BA122049	DISC FRICTION	Bajaj spare parts
BA122050	SPRING STOP	Bajaj spare parts

BA122051	NUT (LOCK)	Bajaj spare parts
BA122052	CAP	Bajaj spare parts
BA122062	PIPE BAND	Bajaj spare parts
BA122064	GASKET FLANGE	Bajaj spare parts
BA122065	ROTOR OIL PUMP GC1000	Bajaj spare parts
BA122066	COVER PUMP OIL	Bajaj spare parts
BA122071	VALVE	Bajaj spare parts
BA122072	FILTER FUEL 0.5 LITRE	Bajaj spare parts
BA122075	BAND ASSEMBLY -	Bajaj spare parts
BA122078	TUBE FUEL	Bajaj spare parts
BA122086	ELEMENT FUEL FILTER	Bajaj spare parts
BA122134	BOLT CENTRE	Bajaj spare parts
BA122135	WASHER	Bajaj spare parts
BA122143	WASHER COPPER	Bajaj spare parts
BA122174	"SHIM FIP, T = 0.3"	Bajaj spare parts
BA122180	HOSE AIR1	Bajaj spare parts
BA122181	SLEEVE RUBBER HOSE	Bajaj spare parts
BA122182	HOSEAIR2 MAN TO FI	Bajaj spare parts
BA122184	HOSE AIR 1 ASSY	Bajaj spare parts
BA122192	ELEMENT ASSLY	Bajaj spare parts
BA122204	COVER OIL PUMP	Bajaj spare parts
BA122205	ROTOR ASSLY OIL PUMP	Bajaj spare parts
BA122216	HOLDER RELEASE	Bajaj spare parts
BA122218	SCREW SPECIAL	Bajaj spare parts
BA122229	MANIFOLD AIR INTAKE	Bajaj spare parts
BA122237	PIPE INTAKE AIR	Bajaj spare parts
BA122239	PIPE ASSEMBLY CHASSIS-FILTER AIR	Bajaj spare parts
BA132004	CLUTCH DISC ASSY GC 1000	Bajaj spare parts
BA132005	COVER CLUTCH PRESSURE PLA	Bajaj spare parts
BA132006	RETAINER BEARING	Bajaj spare parts
BA132007	BEARING CLUTCH	Bajaj spare parts
BA132012	BUSH TOP	Bajaj spare parts
BA132013	BUSH BOTTOM	Bajaj spare parts
BA132014	SLEEVE	Bajaj spare parts
BA132017	LEVER CLUTCH	Bajaj spare parts
BA132019	PIN CLUTCH LEVER	Bajaj spare parts
BA132022	WASHER LOCK CLUTCH	Bajaj spare parts
BA132031	SHAFT ASSLY MAIN	Bajaj spare parts
BA132045	WASHER TAB	Bajaj spare parts
BA132059	GEAR DIFFERENTIAL	Bajaj spare parts
BA132064	WASHER	Bajaj spare parts
BA132088	CIRCLIP EXTERNAL	Bajaj spare parts
BA132094	FLYWHEEL	Bajaj spare parts
BA132095	BOLT SPECIAL	Bajaj spare parts
BA132104	NUT M27 X 1.5	Bajaj spare parts

BA132111	SHAFT PROPELLER RH	Bajaj spare parts
BA132112	SHAFT PROPELLER LH	Bajaj spare parts
BA132116	BUSHING	Bajaj spare parts
BA132121	BRACKET CLUTCH	Bajaj spare parts
BA132122	DOWEL HOLLOW	Bajaj spare parts
BA132134	CIRCLIP	Bajaj spare parts
BA132140	STEM RE DIESEL	Bajaj spare parts
BA132141	BLOCK SLIDER	Bajaj spare parts
BA132157	GEAR SHIFTER ASSY RE DIES	Bajaj spare parts
BA132171	FLANGE SATELITE GEAR HOUS	Bajaj spare parts
BA132172	FLANGE DIFF GEAR	Bajaj spare parts
BA132173	FLANGE WHEEL	Bajaj spare parts
BA132179	BREATHER ASSEMBLY DIFF.	Bajaj spare parts
BA132188	CROSS	Bajaj spare parts
BA132201	BOLT FLANGE DIFFEREN	Bajaj spare parts
BA132211	CLUTCH RELEASE BEARI	Bajaj spare parts
BA132239	SHAFT PROPELLER	Bajaj spare parts
BA132242	SHAFT PROPELLER	Bajaj spare parts
BA132244	SLEEVE RETAINER	Bajaj spare parts
BA132246	GASKET RETAINER SLEEVE	Bajaj spare parts
BA132272	LOCK WASHER	Bajaj spare parts
BA133016	HOUSING MAIN	Bajaj spare parts
BA133018	COVER DIFFERENTIAL	Bajaj spare parts
BA133022	DISC ASSEMBLY CLUTCH	Bajaj spare parts
BA133023	COVER ASSY.CL PRESSURE PLATE	Bajaj spare parts
BA133025	ASSEMBLY PROPELLER SHAFT-RH	Bajaj spare parts
BA133028	ASSEMBLY SHAFT PROPELLER-LH	Bajaj spare parts
BA133031	GEAR DIFFERENTIAL DAMPER	Bajaj spare parts
BA133032	ASSEMBLY DIFFERENTIAL DAMPER	Bajaj spare parts
BA133033	PINION DIFFERENTIAL DAMPER	Bajaj spare parts
BA133039	CL COVER BS3 HAND	Bajaj spare parts
BA133040	ASSLY DISC CLUTCH-HAND	Bajaj spare parts
BA133050	ASSLY TRANSMISSION	Bajaj spare parts
BA133052	ASSLY PROPELLER SHAFT RH	Bajaj spare parts
BA133055	ASSLY PROPELLER SHAFT LH	Bajaj spare parts
BA133057	PIN-HARD CHROME	Bajaj spare parts
BA133058	BELLOW SPHERICAL LARGE	Bajaj spare parts
BA133059	BELLOW LINEAR SMALL	Bajaj spare parts
BA133060	CLAMP EAR	Bajaj spare parts
BA133061	CLAMP LOW PROFILE	Bajaj spare parts
BA133062	RUBBER BUFFER-SBO 60 OZ	Bajaj spare parts
BA133064	SLIDER BLOCK WITH CROSS HOLES	Bajaj spare parts
BA133065	CL COVER BS4 HAND	Bajaj spare parts
BA133066	CLAMP EAR - OMEGA	Bajaj spare parts
BA133067	CLUTCH ASSEMBLY	Bajaj spare parts

BA141013	TRAINER FUEL	Bajaj spare parts
BA141017	BOLT BANJO	Bajaj spare parts
BA141019	CAP ASSY FUEL TANK	Bajaj spare parts
BA141029	PIPE FILTER TO PUM	Bajaj spare parts
BA141030	PIPE ASSLY. FUEL TANK TO FILTER	Bajaj spare parts
BA141033	JOINT T	Bajaj spare parts
BA141034	CLAMP	Bajaj spare parts
BA141041	ASSLY FUEL TANK WELD FL	Bajaj spare parts
BA141053	ASSLY PIPE FUEL OVERFLOW	Bajaj spare parts
BA141058	ASSEMBLY FUEL TANK WELD	Bajaj spare parts
BA141067	PIPE ASSLY FUEL-OVERFLOW	Bajaj spare parts
BA141074	PIPE ASSEMBLY TANK FUEL-FILTER	Bajaj spare parts
BA141076	PIPE ASSEMBLY	Bajaj spare parts
BA141080	PIPE FILTER-PUMP	Bajaj spare parts
BA151001	PIPE BRAKE HYDRAULIC	Bajaj spare parts
BA161029	PACKING CLAMP BATTERY	Bajaj spare parts
BA161030	CHANNEL FIXING ENGINE MTG	Bajaj spare parts
BA161031	CHANNEL FIXING GEAR BOX M	Bajaj spare parts
BA161134	BRACKET ASSY	Bajaj spare parts
BA161146	PLATE FOR ELECTRICAL UNITS	Bajaj spare parts
BA161167	BRACKET ENGINE MTG REAR LH FL	Bajaj spare parts
BA161195	ISOLATOR RUBBER	Bajaj spare parts
BA161206	SPACER	Bajaj spare parts
BA171005	SPRING SUSPENSION REAR	Bajaj spare parts
BA171007	BUSH RUBBER REA	Bajaj spare parts
BA171008	WASHER CUPTOP SID	Bajaj spare parts
BA171009	SHOCK ABSORBER RR	Bajaj spare parts
BA171017	ASSLY REAR SHOCK-ABSORBER	Bajaj spare parts
BA171018	ASSLY FRONT SHOCK-ABSORBER	Bajaj spare parts
BA171019	SPRING REAR SUSPENSION	Bajaj spare parts
BA171020	SPRING SUSPENSION FRONT	Bajaj spare parts
BA171024	SHOCK ABSORBER REAR	Bajaj spare parts
BA181004	COLUMN STEERING 4S PETR /	Bajaj spare parts
BA181014	LOCK SET	Bajaj spare parts
BA181021	ASSLY GEAR CONTROL TUBE	Bajaj spare parts
BA181022	RING GEAR INDICATOR 5 SPEED	Bajaj spare parts
BA181023	SET LOCK	Bajaj spare parts
BA191009	CABLE GEAR BLACK RE DIESE	Bajaj spare parts
BA191012	CABLE ACC.RE DIES	Bajaj spare parts
BA191014	CABLE INNER ACCELERATOR R	Bajaj spare parts
BA191019	CABLE STOP ENGINE RE DIE	Bajaj spare parts
BA191022	CABLE DECOMP RE DIESEL	Bajaj spare parts
BA191024	CABLE INNER DECOMP RE DIE	Bajaj spare parts
BA191027	CLUTCH CABL2086 445	Bajaj spare parts
BA191031	NUT SPECIAL CLUTCH ADJUS	Bajaj spare parts

BA191032	SPRING ADJUSTER CLUTCH	Bajaj spare parts
BA191040	SLEEVE PROTECTION	Bajaj spare parts
BA191051	GEAR CABL2700 445 WH	Bajaj spare parts
BA191052	GEAR CABL2700 445 BL	Bajaj spare parts
BA191058	DECOM CABL1644 445	Bajaj spare parts
BA191059	STOP CABL2895 445 IN	Bajaj spare parts
BA191077	REVERS CABL2580 COMD	Bajaj spare parts
BA191080	GRIP HAND FL	Bajaj spare parts
BA191082	DECOM CABL2704 COM D	Bajaj spare parts
BA191083	CLUTCH CABL2079 COMD	Bajaj spare parts
BA191084	ACC CABL3014 COM DSL	Bajaj spare parts
BA191085	SPEEDO CABL2363 COMD	Bajaj spare parts
BA191086	SPEEDO CABL2363 COMD	Bajaj spare parts
BA191087	CABLE DECOMPRESSION	Bajaj spare parts
BA191090	DECOM CABL2696 COM D	Bajaj spare parts
BA191092	CLUTCH CABL2823 COMD	Bajaj spare parts
BA191093	REVERS CABL2590 COMD	Bajaj spare parts
BA191094	GEAR CABL2680 FL DSL	Bajaj spare parts
BA191095	GEAR CABL2664 FL DSL	Bajaj spare parts
BA191097	CABLE ASSLY ENG STOP	Bajaj spare parts
BA191105	SPEEDOMETER	Bajaj spare parts
BA191106	CABLE CLUTCH	Bajaj spare parts
BA201006	CLAMP	Bajaj spare parts
BA201017	RELAY STARTER	Bajaj spare parts
BA201022	CAP - INSULATING (EARTH)	Bajaj spare parts
BA201033	SWITCH REVERSE LIGHT 4S P	Bajaj spare parts
BA201070	BLINKER RE DIESEL	Bajaj spare parts
BA201072	HARNESS WIRING ANT SUS RE	Bajaj spare parts
BA201082	SWITCH OIL PRESSURE GC10	Bajaj spare parts
BA201093	BLINKER GC1000	Bajaj spare parts
BA201120	BLINKER RE DIESEL	Bajaj spare parts
BA201122	CABLE (BATTERY/ARTH)	Bajaj spare parts
BA201128	HARNESS WIRINGS SP T	Bajaj spare parts
BA201148	HARNESS WIRING(CHASSIS)	Bajaj spare parts
BA201153	HARNESS WIRING(FRONT)	Bajaj spare parts
BA201155	CABLE BATTERY RE 445 FL	Bajaj spare parts
BA201158	REGULATOR 1PH FL	Bajaj spare parts
BA201162	SWITCH FLOAT(LOW FUEL)	Bajaj spare parts
BA201168	HARNESS WIRING REAR TWIN HL	Bajaj spare parts
BA201169	HARNESS WIRING FR RE445	Bajaj spare parts
BA201170	HARNESS WIRING FRONT TWIN HL	Bajaj spare parts
BA201171	SWITCH CONTROL LH	Bajaj spare parts
BA201172	SWITCH CONTROL RH	Bajaj spare parts
BA201176	HARNESS WIRING REAR RE445	Bajaj spare parts
BA201178	HARNESS REAR RE445 TWIN HL	Bajaj spare parts

BA201180	HARNESS WIRING FRONT RE445	Bajaj spare parts
BA201182	CABLE BATTERY RE445	Bajaj spare parts
BA201184	HARNESS FRONT RE COMPACT DIESEL	Bajaj spare parts
BA201185	HARNESS REAR RE COMPACT DIESEL	Bajaj spare parts
BA201186	SPEEDOMETER WITH LAMP RE445	Bajaj spare parts
BA201187	HARNESS WIRING FRONT 445 TW HL	Bajaj spare parts
BA201188	ASSLY INDICATOR RH POD	Bajaj spare parts
BA201191	HARNESS WIRING FRONT	Bajaj spare parts
BA201193	HARNESS BODY	Bajaj spare parts
BA201195	ASSLY INDICATOR RH	Bajaj spare parts
BA201196	HARNESS WIRING FRONT RE445 COMPACT	Bajaj spare parts
BA201197	HARNESS BODY	Bajaj spare parts
BA201201	CABLE BATTERY	Bajaj spare parts
BA201202	CABLE EARTH-ENGINE TO CHASSIS	Bajaj spare parts
BA201203	HARNESS WIRING REAR COMPACT	Bajaj spare parts
BA201218	HARNESS WIRING FRONT DIESEL	Bajaj spare parts
BA201219	HARNESS WIRING REAR DIESEL	Bajaj spare parts
BA201220	CABLE BATTERY	Bajaj spare parts
BA201221	HARNESS WIRING FRONT	Bajaj spare parts
BA201232	HARNESS WIRING FRONT	Bajaj spare parts
BA201233	HARNESS WIRING REAR	Bajaj spare parts
BA201234	CABLE BATTERY	Bajaj spare parts
BA201235	HARNESS WIRING BODY	Bajaj spare parts
BA201239	INDICATOR POD RH	Bajaj spare parts
BA201248	HARNESS WIRING FRONT	Bajaj spare parts
BA201249	HARNESS WIRING REAR	Bajaj spare parts
BA201258	CABLE BATTERY	Bajaj spare parts
BA201263	HARNESS WIRING REAR	Bajaj spare parts
BA201266	HARNESS WIRING FRONT	Bajaj spare parts
BA201269	HARNESS WIRING FRONT	Bajaj spare parts
BA201271	HARNESS WIRING REAR	Bajaj spare parts
BA210007	ASSLY BACKREST PASSENGER SEAT	Bajaj spare parts
BA220003	EMBLEM DIESEL	Bajaj spare parts
BA220006	TOOLKIT COMPLETE	Bajaj spare parts
BA231013	GRILL AIR SUCT HOL	Bajaj spare parts
BA231096	BACKREST ASY FOAM PAS BLUE	Bajaj spare parts
BA231166	HOOD COMPLETE - MUSHROOM	Bajaj spare parts
BA231167	HOOD COMPLETE YELLOW WITH INR BEIGE	Bajaj spare parts
BA231168	HOOD COMPLETE BLACK WITH INR BEIGE	Bajaj spare parts
BA231196	LABEL DIESEL	Bajaj spare parts
BA231197	LABEL DIESEL	Bajaj spare parts
BA231200	PLATE PARKING-IGNITION	Bajaj spare parts
BA231230	BACKREST PASSENGER BROWN	Bajaj spare parts
BA231236	HOOD ASSEMBLY GREEN	Bajaj spare parts
BA231237	HOOD ASSEMBLY YELLOW	Bajaj spare parts

BA231238	HOOD ASSEMBLY MUSHROOM	Bajaj spare parts
BA231239	HOOD ASSEMBLY BLACK	Bajaj spare parts
BA250004	LOCK SET	Bajaj spare parts
BA250005	LOCK SET RE445	Bajaj spare parts
BB100902	BOLT SPECIAL	Bajaj spare parts
BB101045	ROD PUSH	Bajaj spare parts
BB101086	HEAD CYLINDER ASSLY	Bajaj spare parts
BB101090	SEAL VALVE STEM	Bajaj spare parts
BB101091	GASKET CYLINDER HEAD	Bajaj spare parts
BB101095	PISTON Assly Comp.	Bajaj spare parts
BB101110	CASE SPIRAL COMPLETE	Bajaj spare parts
BB101168	BOLT CONNECTING ROD - M7X1	Bajaj spare parts
BB101170	BUSH PISTON PIN	Bajaj spare parts
BB101171	ADJUSTER WITH NUT	Bajaj spare parts
BB101172	BALANCER WEIGHT	Bajaj spare parts
BB101173	WEIGHT COMPLETE BALANCER	Bajaj spare parts
BB101176	BRACKET DECOMP	Bajaj spare parts
BB103003	SILENCER ASSLY	Bajaj spare parts
BB103004	COVER GOVERNOR	Bajaj spare parts
BB103005	ENGINE ASSLY	Bajaj spare parts
BB103006	TUBE OIL-S COVER TO FILTER	Bajaj spare parts
BB103007	TUBE OIL-FILTER TO S COVER	Bajaj spare parts
BB103008	GAUGE OIL	Bajaj spare parts
BB103010	PLUG OIL GAUGE	Bajaj spare parts
BB103011	ASSLY STRAINER	Bajaj spare parts
BB103019	SPRING STOP SWITCH	Bajaj spare parts
BB103030	LEVER ASS SP ADJ COMP	Bajaj spare parts
BB103038	ASSLY CRANKCASE	Bajaj spare parts
BB103040	ASSEMBLY CYLINDER HEAD	Bajaj spare parts
BB103043	PUMP FUEL INJECTION	Bajaj spare parts
BB103044	SHIM FUEL PUMP-0.15T	Bajaj spare parts
BB103045	SHIM FUEL PUMP -0.1T	Bajaj spare parts
BB103046	GASKET -CYLINDER HEAD	Bajaj spare parts
BB103052	ASSEMBLY CAMSHAFT	Bajaj spare parts
BB103054	TUBE FILTER TO MANIFOLD	Bajaj spare parts
BB103055	GASKET MANIFOLD	Bajaj spare parts
BB103056	SPRING	Bajaj spare parts
BB103057	PLUG	Bajaj spare parts
BB103058	TUBE OIL COOLER TO HEAD	Bajaj spare parts
BB103061	LIMITER DEVICE -ASSY FUEL	Bajaj spare parts
BB103069	WIRE CLIP	Bajaj spare parts
BB103071	ASSLY PLUG DRAIN	Bajaj spare parts
BB103084	BANJO BOLT	Bajaj spare parts
BB103101	BRACKET AIR FILTER	Bajaj spare parts
BB103125	SHIM FIP-0.4 MM	Bajaj spare parts



BB103126	SHIM FIP-0.45 MM	Bajaj spare parts
BB103127	SHIM FIP-0.5 MM	Bajaj spare parts
BB103128	SHIM FIP-0.55 MM	Bajaj spare parts
BB103129	SHIM FIP-0.6 MM	Bajaj spare parts
BB103130	SHIM FIP-0.65 MM	Bajaj spare parts
BB103131	SHIM FIP-0.7 MM	Bajaj spare parts
BB103132	SHIM FIP NBR	Bajaj spare parts
BB103320	ASSLY ENGINE	Bajaj spare parts
BB103322	BS4 ASSLY PISTON COMP.	Bajaj spare parts
BB103330	BS4 CRANKSHAFT ASSY. With bush	Bajaj spare parts
BB103332	ASSLY CRANKCASE COMPLETE	Bajaj spare parts
BB103334	CRANKCASE	Bajaj spare parts
BB103336	ASSLY CYLINDER HEAD	Bajaj spare parts
BB103337	BS4 CYLINDER HEAD COMPLETE	Bajaj spare parts
BB103340	BS4 ROD PUSH	Bajaj spare parts
BB103343	BS4 PIPE HIGH PRESSURE	Bajaj spare parts
BB103348	ASSLY SILENCER COMPLETE	Bajaj spare parts
BB103349	MANIFOLD EXHAUST	Bajaj spare parts
BB103352	BS4 TUBE OIL FILTER INLET	Bajaj spare parts
BB103353	BS4 TUBE OIL FILTER OUTLET	Bajaj spare parts
BB103355	BS4 ASSLY OIL FILTER	Bajaj spare parts
BB103356	SILENCER ASSLY	Bajaj spare parts
BB103357	BS4 GASKET EXHAUST MANIFOLD	Bajaj spare parts
BB103358	ASSLY CAT	Bajaj spare parts
BB103368	BS4 GASKET CAT ASSLY	Bajaj spare parts
BB103374	ASSLY CRANKCASE	Bajaj spare parts
BB103379	COVER FOR GOVERNOR LEVER	Bajaj spare parts
BB103382	BS4 GASKET EXHAUST	Bajaj spare parts
BB103389	COWLING CRANKCASE	Bajaj spare parts
BB103398	BRACKET EARTHING CABLE	Bajaj spare parts
BB103406	COVER ASSLY-GOVERNOR	Bajaj spare parts
BB103419	ELBOW ASSLY BOTTOM	Bajaj spare parts
BB103421	CONROD ASSEMBLY	Bajaj spare parts
BB103435	CRANKCASE	Bajaj spare parts
BB103436	SHAFT ASSEMBLY	Bajaj spare parts
BB103440	SPRING TORSION	Bajaj spare parts
BB103441	SPRING TENSION	Bajaj spare parts
BB103456	VALVE EXHAUST	Bajaj spare parts
BB103457	GUIDE VALVE	Bajaj spare parts
BB103459	LEVER ASSEMBLY	Bajaj spare parts
BB103461	SEAL OIL	Bajaj spare parts
BB103463	SHIM FIP 0.3 THK	Bajaj spare parts
BB103464	SHIM FIP 0.35 THK	Bajaj spare parts
BB103601	ASSLY ENGINE	Bajaj spare parts
BB103627	GASKET HEAD CYLINDER	Bajaj spare parts

BB103633	EGR COOLER	Bajaj spare parts
BB103634	EGR VALVE	Bajaj spare parts
BB103637	PIPE ASSEMBLY OUTLET	Bajaj spare parts
BB103644	MANIFOLD INTAKE	Bajaj spare parts
BB103645	MANIFOLD EXHAUST	Bajaj spare parts
BB103646	DUCT MANIFOLD INTAKE	Bajaj spare parts
BB103647	GASKET COOLER EGR	Bajaj spare parts
BB103648	GASKET VALVE EGR	Bajaj spare parts
BB103649	SILENCER ASSLY	Bajaj spare parts
BB103650	GASKET CATALYST	Bajaj spare parts
BB103651	CATALYST ASSEMBLY	Bajaj spare parts
BB103658	MUFFLER ASSEMBLY	Bajaj spare parts
BB103671	GASKET VALVE EGR INLET	Bajaj spare parts
BB103676	TANK COOLANT	Bajaj spare parts
BB103679	CLAMP	Bajaj spare parts
BB103680	BUSH	Bajaj spare parts
BB103684	HOUSING CLUTCH	Bajaj spare parts
BB103685	COVER FAN	Bajaj spare parts
BB103686	COVER MOTOR STARTER	Bajaj spare parts
BB103693	COVER SENSOR PICK UP	Bajaj spare parts
BB103694	SENSOR PICK UP	Bajaj spare parts
BB103696	ASSEMBLY HEAD CYLINDER	Bajaj spare parts
BB103699	FLYWHEEL	Bajaj spare parts
BB103711	PIPE COOLANT	Bajaj spare parts
BB103714	COVER CRANKCASE	Bajaj spare parts
BB103718	CLAMP ASSEMBLY	Bajaj spare parts
BB103719	PIPE ASSEMBLY MANIFOLD-SENSOR	Bajaj spare parts
BB103722	GASKET FLANGE	Bajaj spare parts
BB103724	PIPE MANIFOLD-SENSOR PRESSURE II	Bajaj spare parts
BB103729	CLAMP FILTER AIR	Bajaj spare parts
BB103734	TUBE BREATHER	Bajaj spare parts
BB103735	PIPE ASSEMBLY COOLANT INLET	Bajaj spare parts
BB103736	PIPE ASSEMBLY COOLANT OUTLET	Bajaj spare parts
BB103738	JOINT	Bajaj spare parts
BB103744	PIPE ASSEMBLY COOLANT I	Bajaj spare parts
BB103745	PIPE ASSEMBLY COOLANT II	Bajaj spare parts
BB103747	SEAL OIL MAGNETO SIDE	Bajaj spare parts
BB103748	SEAL OIL CLUTCH SIDE	Bajaj spare parts
BB103749	VALVE NON RETURN	Bajaj spare parts
BB103750	SHIELD	Bajaj spare parts
BB103765	MANIFOLD VALVE EGR	Bajaj spare parts
BB103770	FILTER ASSEMBLY AIR	Bajaj spare parts
BB103781	PIPE COOLANT	Bajaj spare parts
BB103783	VALVE EGR	Bajaj spare parts
BB103795	COOLER EGR	Bajaj spare parts

BB103796	PIPE ASSEMBLY OUTLET	Bajaj spare parts
BB103799	COVER SENSOR PICK UP	Bajaj spare parts
BB103800	DUCT MANIFOLD INTAKE	Bajaj spare parts
BB103817	BRACKET DECOMPRESSOR	Bajaj spare parts
BB103850	DIFFERENTIAL ASSEMBLY	Bajaj spare parts
BB103851	GEAR DIFFERENTIAL	Bajaj spare parts
BB103852	PINION DIFFERENTIAL	Bajaj spare parts
BB103853	SHAFT ASSEMBLY MAIN	Bajaj spare parts
BB103854	GEAR THIRD DRIVEN	Bajaj spare parts
BB103855	GEAR FOURTH DRIVEN	Bajaj spare parts
BB103856	GEAR FIFTH DRIVEN	Bajaj spare parts
BB103857	SHAFT ASSEMBLY GEAR MULTIPLE	Bajaj spare parts
BB103858	GEAR MULTIPLE 1	Bajaj spare parts
BB103859	GEAR MULTIPLE 2	Bajaj spare parts
BB103861	GEAR FIRST DRIVEN	Bajaj spare parts
BB103862	GEAR SECOND DRIVEN	Bajaj spare parts
BB103863	GEAR REVERSE	Bajaj spare parts
BB103864	SHAFT INPUT	Bajaj spare parts
BB103865	GEAR ASSEMBLY IDLER	Bajaj spare parts
BB103880	GASKET COVER HEAD CYLINDER	Bajaj spare parts
BB109025	BREATHER ASSLY	Bajaj spare parts
BB109045	MANIFOLD EXHAUST	Bajaj spare parts
BB109047	SHIELD	Bajaj spare parts
BB111009	GLOW PLUG	Bajaj spare parts
BB111010	ALTERNATOR (1-PHASE)	Bajaj spare parts
BB111014	ALTERNATOR -1PHASE-BS4	Bajaj spare parts
BB112010	ECU EMS ASSEMBLY	Bajaj spare parts
BB112015	ECU EMS ASSEMBLY	Bajaj spare parts
BB121029	FLAP AIR INTAKE	Bajaj spare parts
BB121043	FILTER FUEL 0.5 L	Bajaj spare parts
BB121050	ELEMENT FUEL FULTER	Bajaj spare parts
BB121079	LIMITER DEVICE ASSY FUEL	Bajaj spare parts
BB121080	LEVER COMPLETE GOVE	Bajaj spare parts
BB121082	LEVER 2 GOVERNOR	Bajaj spare parts
BB121083	SEAL OIL SHAFT GOVER.	Bajaj spare parts
BB121084	LEVER 3 GOVERNOR	Bajaj spare parts
BB121085	SHIM GOVERNOR	Bajaj spare parts
BB121086	PUMP ASSY INJECTION	Bajaj spare parts
BB121093	PIPE INJECTION (BOSCH FIE	Bajaj spare parts
BB121094	NOZZLE HOLDER ASSLY (BOSC	Bajaj spare parts
BB121097	SPRING TENSION (IDLING)	Bajaj spare parts
BB121099	JOINT	Bajaj spare parts
BB121104	TUBE AIR INTAKE 1	Bajaj spare parts
BB121107	ELBOW RUBBER LOWER END	Bajaj spare parts
BB121108	ELBOW RUBBER TOP END	Bajaj spare parts

BB121109	RUBBER FLAP DRAIN	Bajaj spare parts
BB121111	RUBBER COMP ELBOW CHASSIS END	Bajaj spare parts
BB121112	INTAKE AIR	Bajaj spare parts
BB121113	TUBE AIR INTAKE	Bajaj spare parts
BB122222	BANJO BOLT M14X1.5	Bajaj spare parts
BB122223	WASHER COPPER	Bajaj spare parts
BB122224	MANIFOLD AIR INTAKE	Bajaj spare parts
BB122225	ASSLY PIPE OVERFLOW	Bajaj spare parts
BB122226	PIPE OVERFLOW	Bajaj spare parts
BB122228	ASSLY PIPE OVERFLOW COMP	Bajaj spare parts
BB122246	PUMP FUEL	Bajaj spare parts
BB122247	INJECTOR	Bajaj spare parts
BB131024	CLAMP 2	Bajaj spare parts
BB131040	HOSE CLAMP DIA.60	Bajaj spare parts
BB131128	GEAR SHIFTER ASSEMBL	Bajaj spare parts
BB131136	CLUTCH SHAFT ASSEMBL	Bajaj spare parts
BB131138	SPRING CLUTCH	Bajaj spare parts
BB131144	SHAFT PROPELLER RH	Bajaj spare parts
BB131147	SHAFT PROPELLER LH	Bajaj spare parts
BB131166	BUSH	Bajaj spare parts
BB131199	COVER DIFFERENTIAL	Bajaj spare parts
BB132003	HOUSING CLUTCH	Bajaj spare parts
BB132009	COVER DIFFERENTIAL	Bajaj spare parts
BB133003	ASSLY SHAFT MULTIPLE GEAR	Bajaj spare parts
BB133004	SHAFT MULTIPLE GEAR	Bajaj spare parts
BB133005	GEAR MULTIPLE1	Bajaj spare parts
BB133006	GEAR MULTIPLE2	Bajaj spare parts
BB133010	SHAFT MAIN	Bajaj spare parts
BB133013	GEAR REVERSE MAIN SHAFT	Bajaj spare parts
BB133014	GEAR SPEED-1	Bajaj spare parts
BB133015	GEAR SPEED-2	Bajaj spare parts
BB133016	GEAR SPEED-3	Bajaj spare parts
BB133017	GEAR SPEED-4	Bajaj spare parts
BB133018	GEAR SPEED-5	Bajaj spare parts
BB133022	COVER GEAR BOX	Bajaj spare parts
BB133025	HOUSING MAIN	Bajaj spare parts
BB133026	GEAR ASSY.REVERSE CONTROL	Bajaj spare parts
BB133028	ASSEMBLY GEAR SHIFTER	Bajaj spare parts
BB133041	COVER GEAR SHIFTER	Bajaj spare parts
BB133042	GASKET GEAR SHIFTER	Bajaj spare parts
BB133044	KEY	Bajaj spare parts
BB133049	LEVER REVERSE LOCK	Bajaj spare parts
BB133050	SPACER	Bajaj spare parts
BB133051	SPRING	Bajaj spare parts
BB133052	HOUSING SATELLITE	Bajaj spare parts

BB133054	BRACKET REV. CABLE	Bajaj spare parts
BB133055	HUB DIFFERENTIAL DAMPER	Bajaj spare parts
BB133061	ASSLY SHAFT MAIN	Bajaj spare parts
BB133062	GEAR DRIVE FARE METER	Bajaj spare parts
BB133066	SLEEVE DRIVE SHAFT	Bajaj spare parts
BB133068	STEM GEAR SELCTOR	Bajaj spare parts
BB133082	BUSH FARE METER	Bajaj spare parts
BB133084	CROSS	Bajaj spare parts
BB133085	GEAR SELECTOR	Bajaj spare parts
BB133093	RING SHOULDER	Bajaj spare parts
BB133095	ASSLY DRIVE SHAFT LH	Bajaj spare parts
BB133096	ASSLY DRIVE SHAFT RH	Bajaj spare parts
BB133097	ASSEMBLY DIFFERENTIAL DAMPER	Bajaj spare parts
BB133098	PINION DIFF DAMPER	Bajaj spare parts
BB133099	GEAR DIFFERENTIAL DAMPER	Bajaj spare parts
BB133114	BRACKET GEAR CABLE	Bajaj spare parts
BB133115	ASSLY GEAR SHIFTER	Bajaj spare parts
BB133117	BRACKET GEAR CABLE	Bajaj spare parts
BB133124	LEVER AND SECTOR COMPLETE	Bajaj spare parts
BB133130	SPRING	Bajaj spare parts
BB133132	GEAR SELECTOR	Bajaj spare parts
BB133134	COVER SHIFTER GEAR	Bajaj spare parts
BB133300	ASSLY TRANSMISSION	Bajaj spare parts
BB133311	FLYWHEEL CLUTCH	Bajaj spare parts
BB133312	BS4 GEAR SPEED 1	Bajaj spare parts
BB133313	GEAR SPEED-2	Bajaj spare parts
BB133314	GEAR SPEED-4	Bajaj spare parts
BB133315	SHAFT ASSEMBLY-MAIN	Bajaj spare parts
BB133316	GEAR SPEED 3	Bajaj spare parts
BB133317	SHAFT ASSLY GEAR MULTIPLE	Bajaj spare parts
BB133318	GEAR MULTIPLE 2	Bajaj spare parts
BB141006	TUBE FUEL FILTRE TO	Bajaj spare parts
BB141024	PIPE ASSY-FUEL-TANK	Bajaj spare parts
BB141033	PIPE ASSLY FUEL FILTER	Bajaj spare parts
BB141035	SLEEVE FILTER PUMP	Bajaj spare parts
BB141038	PIPE ASSLY	Bajaj spare parts
BB141039	PIPE FUEL OVERFLOW	Bajaj spare parts
BB141077	PIPE ASSLY FUEL OVERFLOW	Bajaj spare parts
BB141081	TANK ASSLY	Bajaj spare parts
BB141087	PIPE ASSEMBLY FUEL	Bajaj spare parts
BB151001	LEVER ASY HAND BRAKE	Bajaj spare parts
BB151024	PIPE BRAKE REAR FL	Bajaj spare parts
BB151025	PIPE BRAKE REAR 2 FL	Bajaj spare parts
BB151026	HOSE BRAKE FRONT FL	Bajaj spare parts
BB151030	HUB REAR	Bajaj spare parts

BB151031	BEARING HUB	Bajaj spare parts
BB151034	SEAL hub	Bajaj spare parts
BB151036	FLANGE DRIVE ASSY	Bajaj spare parts
BB151039	ASSLY BRAKE PEDAL WITH PAD FL	Bajaj spare parts
BB151040	CYLINDER COMPLETE TMC REFL	Bajaj spare parts
BB151042	ASSLY BACKPLATE REAR LH	Bajaj spare parts
BB151043	ASSLY BACKPLATE REAR RH	Bajaj spare parts
BB151052	SPACER DAMPENING PLATE RE445L	Bajaj spare parts
BB151053	ASSLY BRAKE PANLE WITH FLANGE	Bajaj spare parts
BB151055	PANEL ASSLY REAR LH FL	Bajaj spare parts
BB151056	PANEL ASSLY REAR RH FL	Bajaj spare parts
BB151062	SPRING KIT LH	Bajaj spare parts
BB151063	SPRING KIT RH	Bajaj spare parts
BB151064	SHOE CLAMPING KIT	Bajaj spare parts
BB151065	WHEEL CYLINDER MAJOR KIT	Bajaj spare parts
BB151066	WHEEL CYLINDER MINOR KIT	Bajaj spare parts
BB151073	HOSE REAR CIRCUIT-1	Bajaj spare parts
BB151075	ASSLY BRAKE PEDAL WITH PAD FL	Bajaj spare parts
BB151087	LEVER ASSLY PKB	Bajaj spare parts
BB151088	PLATE ASSLY PKB	Bajaj spare parts
BB151091	ASSLY BRAKE PIPE REAR	Bajaj spare parts
BB151095	WASHER CONICAL	Bajaj spare parts
BB161048	COVER LOCKABLE MAIN	Bajaj spare parts
BB161096	HOUSING HEADLAMP LH	Bajaj spare parts
BB161097	HOUSING HEADLAMP RH	Bajaj spare parts
BB161099	MUDGUARD FRONT	Bajaj spare parts
BB161100	TRIM UPPER LARGE LH FL	Bajaj spare parts
BB161101	TRIM UPPER LARGE RH FL	Bajaj spare parts
BB161107	BELLOW RUBBER	Bajaj spare parts
BB161122	MAT FLOOR FRONT LH	Bajaj spare parts
BB161123	DASHBOARD	Bajaj spare parts
BB161124	DASHBOARD COMPLETE	Bajaj spare parts
BB161130	BRACKET KNOB MOUNTING	Bajaj spare parts
BB161132	MAT FLOOR FRONT RH	Bajaj spare parts
BB161171	GUARD REAR	Bajaj spare parts
BB161175	BATTERY BASE FL	Bajaj spare parts
BB161182	BRACKET MTG TAIL LAMP LH	Bajaj spare parts
BB161184	BKT TLAMP & NO PLATE	Bajaj spare parts
BB161204	BRACKET TIE ROD	Bajaj spare parts
BB161226	CLAMP ASSLY BATTERY FL	Bajaj spare parts
BB161227	PACKING BATTERY BASE	Bajaj spare parts
BB161244	MUDFLAP REAR LH	Bajaj spare parts
BB161245	MUDFLAP REAR RH	Bajaj spare parts
BB161252	PLATE ASSY ELE UNIT MTG FL	Bajaj spare parts
BB161289	STOPPER BUMP EXT LIGHT LOAD APP	Bajaj spare parts

BB161296	NUT-M6X1XHEIGHT 16.5XBRIGHT	Bajaj spare parts
BB161306	PLATE STOPPER	Bajaj spare parts
BB161368	PLATE ASSEMBLY ELECTRICAL FRONT	Bajaj spare parts
BB161391	BRACKET ASSEMBLY SENSOR PRESSURE	Bajaj spare parts
BB171007	ASSLY WELD TRAILING ARM LH	Bajaj spare parts
BB171008	ASSLY REAR TRAILING ARM RH	Bajaj spare parts
BB171027	SPRING REAR SUSPENSION	Bajaj spare parts
BB171032	SPRING FRONT SUSP LIGHT LOAD APP	Bajaj spare parts
BB171036	BUSH RR SHOCKER PRE	Bajaj spare parts
BB171038	SPRING REAR SUSPENSION	Bajaj spare parts
BB171040	SHOCKABSORBER REAR KERALA	Bajaj spare parts
BB171041	SPRING REAR LIGHT LOAD APP	Bajaj spare parts
BB171051	ARM ASSLY TRAILING-LH	Bajaj spare parts
BB171052	ARM ASSLY TRAILING-RH	Bajaj spare parts
BB171055	PIECE ASSLY DISTANCE-TA - LL	Bajaj spare parts
BB171056	PIECE DISTANCE TRAILING ARM - LL	Bajaj spare parts
BB181007	FORK FR	Bajaj spare parts
BB181010	SPACER FORK FRONT RE445L	Bajaj spare parts
BB181011	LOCK SET MAXIMA	Bajaj spare parts
BB181012	ASSLY FORK FL	Bajaj spare parts
BB181034	RACE BEARING UPPER-INNER	Bajaj spare parts
BB181035	BALL WITH CAGE-SOLID OIL	Bajaj spare parts
BB181036	RACE BEARING UPPER-OUTER	Bajaj spare parts
BB181037	BALL WITH CAGE-SOLID OIL	Bajaj spare parts
BB181038	SET LOCK	Bajaj spare parts
BB181039	RACE BEARING LOWER OUTER	Bajaj spare parts
BB181040	RACE BEARING LOWER INNER	Bajaj spare parts
BB191003	INSTRUMENT CLUSTER	Bajaj spare parts
BB191004	ACC CABL3141 445L FI	Bajaj spare parts
BB191005	GEAR CABL2549 445L W	Bajaj spare parts
BB191006	GEAR CABL2536 445L B	Bajaj spare parts
BB191009	CLUTCH CABL2710 (LOC	Bajaj spare parts
BB191018	GEAR CABL2669 FL DSL	Bajaj spare parts
BB191019	GEAR CABL2648 FL DSL	Bajaj spare parts
BB191029	ASSLY CLUTCH PEDAL & DAMPER	Bajaj spare parts
BB191031	CLUTCH CABL2269 MAXI	Bajaj spare parts
BB191033	CLAMP FL	Bajaj spare parts
BB191035	ACC CABL3136 CUFT CO	Bajaj spare parts
BB191038	ACC CABL3041 MAXIMA	Bajaj spare parts
BB191051	CLUTCH CABL2988 MAXI	Bajaj spare parts
BB191053	SLEEVE FOR CABLES	Bajaj spare parts
BB191054	CABLE GEAR WHITE COMPLETE	Bajaj spare parts
BB191055	CABLE GEAR BLACK COMPLETE	Bajaj spare parts
BB191058	CABLE INNER SPEEDOMETER	Bajaj spare parts
BB191059	CABLE ASSLY SPEEDOMETER	Bajaj spare parts

BB191062	SPEEDOMETER	Bajaj spare parts
BB191066	CABLE REVERSE	Bajaj spare parts
BB191068	CABLE CLUTCH	Bajaj spare parts
BB191070	SPEEDOMETER	Bajaj spare parts
BB201003	CABLE ASSY(CABIN LIGHT)	Bajaj spare parts
BB201022	REGULATOR1PHASECHO	Bajaj spare parts
BB201025	INDICATOR ASSEMBLY	Bajaj spare parts
BB201030	LOCK BATTERY M6 KEY	Bajaj spare parts
BB201050	CLUSTER INSTRUMENT DR	Bajaj spare parts
BB201059	CABLE BATTERY RE445FL	Bajaj spare parts
BB201068	LIGHT ASSY HEAD LH WITH LAMP FL	Bajaj spare parts
BB201069	LIGHT ASSY HEAD RH WITH LAMP FL	Bajaj spare parts
BB201070	SPRING HEAD LAMP MOUNTING	Bajaj spare parts
BB201073	HARNESS WIRING RR RE445L FL	Bajaj spare parts
BB201074	HARNESS WIRING FR RE445L	Bajaj spare parts
BB201075	CABLE BATTERY 32AH RE445L	Bajaj spare parts
BB201076	HARNESS WIRING REAR RE445L	Bajaj spare parts
BB201078	LIGHT ASSY HEAD LH WITH LAMP FL	Bajaj spare parts
BB201079	LIGHT ASSY HEAD RH WITH LAMP F	Bajaj spare parts
BB201084	HARNESS WIRING FRONT MAXIMA	Bajaj spare parts
BB201092	HARNESS WIRING FR MAXIMA	Bajaj spare parts
BB201100	CLUSTER INSTRUMENT	Bajaj spare parts
BB201101	HARNESS WIRING FRONT FOR INT DASH	Bajaj spare parts
BB201103	CABLE BATTERY	Bajaj spare parts
BB201104	LAMP ASSLY TAIL-LH	Bajaj spare parts
BB201105	LAMP ASSLY TAIL-RH	Bajaj spare parts
BB201106	CABLE EARTH ENGINE TO CHASSIS	Bajaj spare parts
BB201107	HARNESS WIRING-REAR	Bajaj spare parts
BB201109	CABLE TAILLAMP WITH HOLDER LH	Bajaj spare parts
BB201110	CABLE TAILLAMP WITH HOLDER RH	Bajaj spare parts
BB201113	HARNESS FRONT	Bajaj spare parts
BB201120	CLUSTER INSTRUMENT	Bajaj spare parts
BB201144	SENSOR TEMPERATURE	Bajaj spare parts
BB201148	HARNESS WIRING FRONT	Bajaj spare parts
BB201149	HARNESS WIRING REAR	Bajaj spare parts
BB201156	REGULATOR	Bajaj spare parts
BB201160	SENSOR PRESSURE	Bajaj spare parts
BB201161	BOX ASSEMBLY FUSE	Bajaj spare parts
BB201165	CABLE BATTERY	Bajaj spare parts
BB201167	CABLE EARTH	Bajaj spare parts
BB201169	HARNESS WIRING REAR	Bajaj spare parts
BB201172	HARNESS WIRING FRONT	Bajaj spare parts
BB201173	HARNESS WIRING REAR	Bajaj spare parts
BB201175	SENSOR LEVEL COOLANT	Bajaj spare parts
BB201176	SWITCH DECOMPRESSION	Bajaj spare parts



BB201181	CABLE BATTERY	Bajaj spare parts
BB201184	HARNESS WIRING FRONT	Bajaj spare parts
BB201188	HARNESS WIRING REAR	Bajaj spare parts
BB211010	BACKREST ASSEMBLY	Bajaj spare parts
BB211012	SEAT DRIVER	Bajaj spare parts
BB211014	FRAME DRIVER SEAT FL	Bajaj spare parts
BB211016	SEAT ASSY DRIVER GREEN	Bajaj spare parts
BB211019	SEAT ASSY PASSENGER GREEN	Bajaj spare parts
BB211022	CLAMP FOR SEAT MTG	Bajaj spare parts
BB221002	MIRROR ASSY LH GC 1000 ME	Bajaj spare parts
BB221003	MIRROR ASSY RH GC 1000 ME	Bajaj spare parts
BB221004	JACK ASSEMBLY	Bajaj spare parts
BB221005	TOOLKIT COMPLETE	Bajaj spare parts
BB221008	TOOLKIT COMPLETE REG	Bajaj spare parts
BB221013	EMBLEM MAXIMA	Bajaj spare parts
BB221015	MUDFLAP FRONT	Bajaj spare parts
BB221017	MIRROR MAXIMA LH	Bajaj spare parts
BB221018	MIRROR MAXIMA RH	Bajaj spare parts
BB221023	LABEL MAXIMA WHITE	Bajaj spare parts
BB221024	LABEL MAXIMA BLACK	Bajaj spare parts
BB231131	CLIP FOR SEAT MOUNTI	Bajaj spare parts
BB231141	MATting FOOT STEP	Bajaj spare parts
BB231142	MATting FOOT STEP	Bajaj spare parts
BB231220	FRAME PASSENG SEAT T	Bajaj spare parts
BB231224	HOOD COMPLETE	Bajaj spare parts
BB231225	MATting CENTRAL	Bajaj spare parts
BB231227	BRACKET ASSY HINGE	Bajaj spare parts
BB231229	SEAT PASSENGER	Bajaj spare parts
BB231232	BACKREST PASSENGER	Bajaj spare parts
BB231266	BRACKET ASSLY LH	Bajaj spare parts
BB231268	DAMPER	Bajaj spare parts
BB231269	STRAP ASSLY SEAT CLA	Bajaj spare parts
BB231271	PLUG : MAT FIXING	Bajaj spare parts
BB231337	FRAME HOOD ASSY	Bajaj spare parts
BB231338	HOOD COMPLETE	Bajaj spare parts
BB231369	COVER REAR LH	Bajaj spare parts
BB231370	COVER REAR RH	Bajaj spare parts
BB231451	STIFFNER SIDE COVER RE445L FL	Bajaj spare parts
BB231506	HOOD COMPLETE GREEN	Bajaj spare parts
BB231644	CLIP COVER BODY	Bajaj spare parts
BB231658	LABEL MAXIMA BLACK	Bajaj spare parts
BB231659	LABEL MAXIMA WHITE	Bajaj spare parts
BB231698	LABEL BS4-FRONT	Bajaj spare parts
BB231699	LABEL BS4-MAXIMA	Bajaj spare parts
BB231712	LABEL X WIDE WHITE	Bajaj spare parts

BC511029	NOZZLE	Bajaj spare parts
BC551471	WASHER PLAIN- 1.2 THK.	Bajaj spare parts
BC551472	SPRING CLUTCH	Bajaj spare parts
BF111415	ASSLY ECU MTG BRACKET	Bajaj spare parts
BF111442	BATTERY CLAMP ROD LONG	Bajaj spare parts
BF111527	RIVET STEEL UPR STRUCTURE	Bajaj spare parts
BF111944	BRACKET UNIT TELEMATIC	Bajaj spare parts
BF113434	BRACKET LH&RH ENG SIDE 200CC	Bajaj spare parts
BF113435	BRACKET RR ENG SIDE 200CC	Bajaj spare parts
BF113447	RUBBER ISOLATOR REAR	Bajaj spare parts
BF113448	RUBBER ISOLATOR FRONT	Bajaj spare parts
BF113457	ASSY BRACKET & ISOLATOR REAR BIW SIDE	Bajaj spare parts
BF113461	ASSLY BKT & ISOLATOR FRONT BIW SIDE	Bajaj spare parts
BF113478	ISOLATOR SLEEVE INNER	Bajaj spare parts
BF113479	RUBBER ISOLATOR REAR RH	Bajaj spare parts
BF113480	ASSLY BKT N ISOLTR RR RH BIW	Bajaj spare parts
BF113830	CHANNEL RAIN LH	Bajaj spare parts
BF113831	CHANNEL RAIN RH	Bajaj spare parts
BF113835	TUBE ASSEMBLY VERTICAL	Bajaj spare parts
BF113837	TUBE ASSEMBLY CROSS	Bajaj spare parts
BF113843	BRACKET HOOK TOW	Bajaj spare parts
BF113844	TUBE STRUCTURE HOOK TOW	Bajaj spare parts
BF121003	ASSLY FRONT DAMPER	Bajaj spare parts
BF121068	JOINT SUSPENSION BALL JOINT	Bajaj spare parts
BF121071	SPRING FRONT 4WH	Bajaj spare parts
BF121094	BUSH UPPER CONTROL ARM	Bajaj spare parts
BF121096	STOPPER BUMP FRONT 4WH	Bajaj spare parts
BF121111	ASSLY LOWER LEAD ARM LH	Bajaj spare parts
BF121112	ASSLY LOWER LEAD ARM RH	Bajaj spare parts
BF121113	ASSLY UPPER LEAD ARM LH	Bajaj spare parts
BF121114	ASSLY UPPER LEAD ARM RH	Bajaj spare parts
BF121115	ASSLY KNUCKLE LH	Bajaj spare parts
BF121116	ASSLY KNUCKLE COMP. RH	Bajaj spare parts
BF121117	BUSH LOWER LEAD ARM INNER	Bajaj spare parts
BF121118	RUBBER BELLOW DUST COVER FRONT	Bajaj spare parts
BF121122	RUBBER SPRING SEAT FRONT	Bajaj spare parts
BF121129	BAR STABILIZER	Bajaj spare parts
BF121130	ASSLY DROP LINK STBLZR BAR RH	Bajaj spare parts
BF121131	BUSH STABILIZER BAR MOUNTING	Bajaj spare parts
BF121132	BRACKET STABILIZER BAR MOUNTING	Bajaj spare parts
BF121148	BUSH LOWER LEAD ARM OUTER	Bajaj spare parts
BF121149	WASHER LOWER LEAD ARM OUTER	Bajaj spare parts
BF121160	WASHER BUMPSTOPPER FRONT	Bajaj spare parts
BF121169	ASSLY LCA OUTER MOUNTING BKT	Bajaj spare parts
BF121172	ASSLY UCA MTG BRCKT & ARM LH	Bajaj spare parts

BF121173	ASSLY UCA MTG BKT. & ARM RH	Bajaj spare parts
BF121176	SLEEVE SHOCKER 4W	Bajaj spare parts
BF121198	ASSLY DROP LINK STBLZR BAR LH	Bajaj spare parts
BF121245	ASSLY UCA MTG BKT & ARM LH	Bajaj spare parts
BF121246	ASSLY UCA MTG BKT ARM RH	Bajaj spare parts
BF121259	SHOCKABSORBER FRONT	Bajaj spare parts
BF122056	REBOUND WASHER	Bajaj spare parts
BF122057	REAR SPRING	Bajaj spare parts
BF122064	BUMP STOPPER WASHER	Bajaj spare parts
BF122108	ASSY REAR SHOCK ABSORBER	Bajaj spare parts
BF122111	RUBBER SPRING SEAT REAR	Bajaj spare parts
BF122112	Stopper bump Rr. 4WH	Bajaj spare parts
BF122132	ASSLY SEMI-TA LH	Bajaj spare parts
BF122134	ASSLY SEMI-TA RH	Bajaj spare parts
BF122136	ASSLY DISTANCE PIECE	Bajaj spare parts
BF122155	Bolt	Bajaj spare parts
BF122168	SHOCKABSORBER REAR	Bajaj spare parts
BF131040	SPARE WHEEL KNOB	Bajaj spare parts
BF131043	BOLT FOR LOCK	Bajaj spare parts
BF131058	RING RETENTION WHEEL COVER	Bajaj spare parts
BF131061	TYRE 135/70-R12	Bajaj spare parts
BF131205	ASSLY WHEEL 4.00BX12H2	Bajaj spare parts
BF131207	WHEEL 3.50BX12H2	Bajaj spare parts
BF131412	TYRE 135/70 R 12	Bajaj spare parts
BF131417	VALVE V2.03.4	Bajaj spare parts
BF131428	TUBE 4.00D X 10	Bajaj spare parts
BF131486	NUT CONICAL M 10	Bajaj spare parts
BF131503	SLEEVE SPARE WHEEL	Bajaj spare parts
BF131505	HUB CAP - STEEL WHEEL	Bajaj spare parts
BF131506	HUB CAP - ALLOY WHEEL	Bajaj spare parts
BF131511	ASSLY BRACKET SPARE WHL MOUNT	Bajaj spare parts
BF131704	DRUM BRAKE 180 CI	Bajaj spare parts
BF131706	SPACER FOR SEAL	Bajaj spare parts
BF131707	NUT AXLE M16	Bajaj spare parts
BF131709	SPACER LOCATOR	Bajaj spare parts
BF131710	BOLT M10	Bajaj spare parts
BF131712	SEAL 28X47X7	Bajaj spare parts
BF131722	BEARING 30X55X13	Bajaj spare parts
BF131723	SEAL 41X60X7	Bajaj spare parts
BF131731	HUB FRONT 4WH	Bajaj spare parts
BF131732	SPACER BEARING	Bajaj spare parts
BF131733	AXLE FRONT 4WH	Bajaj spare parts
BF131756	NUT Hex Flanged	Bajaj spare parts
BF131758	HUB REAR	Bajaj spare parts
BF131759	ASSLY DRIVE FLANGE	Bajaj spare parts

BF131761	BALL BEARING DBL ROW ANGLR CNTCT	Bajaj spare parts
BF131762	SEAL OIL OUTBOARD	Bajaj spare parts
BF131769	SEAL OIL	Bajaj spare parts
BF131770	DRUM BRAKE	Bajaj spare parts
BF131856	BRAKE HOSE REAR	Bajaj spare parts
BF131857	SPRING TORSION FOR BRAKE PEDAL	Bajaj spare parts
BF131859	SPRING TORSION FOR CLUTCH PDL	Bajaj spare parts
BF131877	PIPE FRONT ASSY LH	Bajaj spare parts
BF131878	PIPE FRONT ASSY RH	Bajaj spare parts
BF131879	PIPE FRONT ASSY CENTRAL	Bajaj spare parts
BF131882	PIPE REAR ASSY LONG MEMBER	Bajaj spare parts
BF131883	PIPE REAR ASSY LH	Bajaj spare parts
BF131884	PIPE REAR ASSY RH	Bajaj spare parts
BF131887	CLAMP	Bajaj spare parts
BF131888	GROMMET	Bajaj spare parts
BF131911	ASSY TMC TOP SIDE MTG LHD	Bajaj spare parts
BF131924	CONNECTOR 3+2 COMBINATION	Bajaj spare parts
BF131926	PIPE FRONT ASSY UPPER RH	Bajaj spare parts
BF131927	PIPE REAR ASSY CENTRAL	Bajaj spare parts
BF131938	ASSLY TMC TOP SIDE MTG	Bajaj spare parts
BF131939	ASSLY BRAKE PANEL REAR RH	Bajaj spare parts
BF131940	ASSLY BRAKE PANEL REAR LH	Bajaj spare parts
BF131941	ASSLY BRAKE PANEL FRONT RH	Bajaj spare parts
BF131942	ASSLY BRAKE PANEL FRONT LH	Bajaj spare parts
BF131943	BRAKE FLUID BOTTLE	Bajaj spare parts
BF131944	ASSLY WHEEL CYLINDER 19.05	Bajaj spare parts
BF131985	BRACKET RESERVOIR MTG	Bajaj spare parts
BF132005	GROMMET	Bajaj spare parts
BF132007	ASSLY WHEEL CYLINDER 25.4	Bajaj spare parts
BF132013	CONNECTOR BRAKE PIPE(M10X1)	Bajaj spare parts
BF132015	CLIP BRAKE FRONT HOSE GUIDE	Bajaj spare parts
BF132016	CLAMP COVER	Bajaj spare parts
BF132027	PIPE ASSY TMC SECONDARY PORT	Bajaj spare parts
BF132029	PIPE ASSY TMC PRIMARY PORT	Bajaj spare parts
BF132032	PIPE OIL BOTTLE	Bajaj spare parts
BF132047	CLAMP TIE CABLE	Bajaj spare parts
BF132049	CAP CLAMP	Bajaj spare parts
BF132050	CLAMP	Bajaj spare parts
BF132091	PIPE ASSEMBLY MIDDLE REAR	Bajaj spare parts
BF151022	ASSLY SHT MTL U JOINT	Bajaj spare parts
BF151023	ASSLY U JOINT	Bajaj spare parts
BF152020	ASSLY STG GEAR WITH I SHAFT	Bajaj spare parts
BF152022	ASSLY STG GEAR & I SHAFT-LHD	Bajaj spare parts
BF152028	STEERING SHAFT WITH SHEET MTL UJ	Bajaj spare parts
BF152032	ASSLY OUTER BALL JOINT	Bajaj spare parts

BF152035	NUT NYLOC LINK DRAG M10X1.25	Bajaj spare parts
BF152036	NUT HEX ROD TIE M10X1.5 LH	Bajaj spare parts
BF152037	NUT HEX ROD TIE M10X1.5	Bajaj spare parts
BF153026	ASSLY STEERING COLUMN	Bajaj spare parts
BF153027	BOOT STEERING COLUMN ASSLY	Bajaj spare parts
BF153029	ASSEMBLY STG CLMN WITH SHEET MTL	Bajaj spare parts
BF153036	LINK DRAG	Bajaj spare parts
BF153037	TUBE ROD TIE	Bajaj spare parts
BF161000	ASSLY CLUTCH PEDAL	Bajaj spare parts
BF161006	SPRING CLUTCH TORSION LHD	Bajaj spare parts
BF161010	ASSLY SHAFT BRAKE PEDAL	Bajaj spare parts
BF161023	SPRING TORSION	Bajaj spare parts
BF161036	ACCELATOR CABLE LHD	Bajaj spare parts
BF161052	ASSLY GEAR SHIFTER	Bajaj spare parts
BF161054	SLEEVE REVERSE GEAR	Bajaj spare parts
BF161057	BUSH NYLON GEAR SHIFT	Bajaj spare parts
BF161059	KNOB GEAR SHIFT LEVER	Bajaj spare parts
BF161061	COVER GEAR KNOB	Bajaj spare parts
BF161119	BUSH PLASTIC FOR PEDAL	Bajaj spare parts
BF161126	BUSH ACCELERATOR PEDAL	Bajaj spare parts
BF161127	COVER GEAR SHIFT	Bajaj spare parts
BF161129	BRACKET MAIN	Bajaj spare parts
BF161137	PULLEY	Bajaj spare parts
BF161138	PIN PIVOT	Bajaj spare parts
BF161139	BRACKET EQUALIZER-L	Bajaj spare parts
BF161170	CLUTCH PEDAL DAMPER STOPPER	Bajaj spare parts
BF161175	BUSH PKB EQUALIZER	Bajaj spare parts
BF161186	BRACKET RVRS CBL ACTUATOR	Bajaj spare parts
BF161191	BUSH PLASTIC FOR BRAKE PEDAL	Bajaj spare parts
BF161199	SHAFT BRAKE PEDAL LHD	Bajaj spare parts
BF161236	GROMMET FUEL LINES	Bajaj spare parts
BF161243	ASSY GEAR SHIFTER CABLE BLACK	Bajaj spare parts
BF161245	ASSLY REVERSE DETENT CABLE	Bajaj spare parts
BF161265	ASSLY ACCELERATOR CABLE FI	Bajaj spare parts
BF161269	ASSLY GROMMET HOLDER	Bajaj spare parts
BF161277	ASSLY GEAR SHIFTR CABL WHIT	Bajaj spare parts
BF161283	CLIP CABLE LOCK	Bajaj spare parts
BF161284	RING SNAP	Bajaj spare parts
BF161285	ASSLY CLUTCH CABLE LHD	Bajaj spare parts
BF161286	ASSLY ACCELERATOR CABLE LHD	Bajaj spare parts
BF161287	CABLE PARKING BRAKE CABLE REAR	Bajaj spare parts
BF161296	LOCK CLIP	Bajaj spare parts
BF161301	HOOK FOR CABLE	Bajaj spare parts
BF161303	ASSLY CLUTCH CABLE LUG TYPE	Bajaj spare parts
BF161315	GROMMET	Bajaj spare parts

BF161318	GROMMET	Bajaj spare parts
BF161320	CABLE GEAR WHITE	Bajaj spare parts
BF161321	CABLE GEAR BLACK	Bajaj spare parts
BF161322	CABLE GEAR REVERSE	Bajaj spare parts
BF161325	CABLE ACCELERATOR	Bajaj spare parts
BF162011	ASSEMBLY PARKING BRAKE LEVER	Bajaj spare parts
BF162018	PIN CABLE HOLDER WITH HOLE	Bajaj spare parts
BF162028	GRIP PARKING BRAKE	Bajaj spare parts
BF162029	ASSLY PARKING BRAKE CABLE FRONT	Bajaj spare parts
BF162031	ASSLY PKB EQUALIZER COMP	Bajaj spare parts
BF162036	CLAMP FOR PKB CABLE	Bajaj spare parts
BF162039	ASSEMBLY PARKING BRAKE LEVER_LHD	Bajaj spare parts
BF162041	ASSEMBLY GROMMET AND HOLDER	Bajaj spare parts
BF162044	RATCHET COVER	Bajaj spare parts
BF162046	SWITCH MOUNTING PLATE RHD	Bajaj spare parts
BF162049	ASSLY TMC BRACKET	Bajaj spare parts
BF162057	ASSLY BRAKE PEDAL COMPLETE	Bajaj spare parts
BF162062	ASSLY CLUTCH PEDAL RHD	Bajaj spare parts
BF162066	ASSLY CLUTCH CABLE RHD	Bajaj spare parts
BF162067	ASSLY CLUTCH CABLE LHD	Bajaj spare parts
BF162071	SPRING TORSION FOR CLUTCH PEDAL	Bajaj spare parts
BF162072	SPRING TORSION FOR BRAKE PEDAL	Bajaj spare parts
BF162074	ASSLY A PEDAL DASH MOUNTED	Bajaj spare parts
BF162080	ASSLY A CABLE RHD	Bajaj spare parts
BF162083	RUBBER PAD BRAKE PEDAL	Bajaj spare parts
BF162103	SPRING ACCELERATOR PEDAL	Bajaj spare parts
BF162104	BUSH FOR PEDALS	Bajaj spare parts
BF162106	BRACKET APM	Bajaj spare parts
BF162116	HOLDER CABLE-CLUTCH	Bajaj spare parts
BF162117	CABLE CLUTCH	Bajaj spare parts
BF162144	DAMPER PEDAL BRAKE	Bajaj spare parts
BF171024	TANK FUEL	Bajaj spare parts
BF171032	RUBBER HOSE FILLER NECK	Bajaj spare parts
BF171036	ASSLY FUEL FILLER NECK	Bajaj spare parts
BF171037	CUP WASHER	Bajaj spare parts
BF171039	CLIP NUT FUEL TANK	Bajaj spare parts
BF171041	SPACER GASKET FSM	Bajaj spare parts
BF171055	NOZZLE INSERT VENT	Bajaj spare parts
BF171064	PIPE ASSLY BREATHER	Bajaj spare parts
BF171084	TUBE ASSEMBLY TANK	Bajaj spare parts
BF171085	BRACKET PIPE	Bajaj spare parts
BF171090	PIPE FILLER FUEL	Bajaj spare parts
BF171092	TUBE TANK FUEL	Bajaj spare parts
BF171604	RING O	Bajaj spare parts
BF171606	CAP FUEL TANK	Bajaj spare parts

BF171607	CAP FUEL VENT	Bajaj spare parts
BF171611	PIPE TANK TO ROV	Bajaj spare parts
BF171616	FUEL CAP ASSY WITH TETHER	Bajaj spare parts
BF171617	TANK CANISTER	Bajaj spare parts
BF171619	BRACKET PURGE CONTROL VALVE MTG	Bajaj spare parts
BF171622	STRAP ROV MOUNTING	Bajaj spare parts
BF171623	STRAP CANISTER MOUNTING	Bajaj spare parts
BF171624	BRACKET ASSLY CANISTER	Bajaj spare parts
BF171628	PIPE ASSLY PURGE VALVE-ENGINE	Bajaj spare parts
BF171629	PIPE ASSLY RO VALVE-CANISTER	Bajaj spare parts
BF171630	PIPE ASSLY CANISTER-VALVE PURGE	Bajaj spare parts
BF171821	GASKET FUEL PUMP MOUNTING	Bajaj spare parts
BF171825	PIPE FUEL FI	Bajaj spare parts
BF171826	PIPE FUEL FI	Bajaj spare parts
BF171827	PIPE FUEL FI	Bajaj spare parts
BF171846	BRACKET FUEL FILTER 1	Bajaj spare parts
BF171847	CLAMP FUEL PIPE	Bajaj spare parts
BF171849	PIPE BREATHER	Bajaj spare parts
BF171850	GROMMET	Bajaj spare parts
BF171854	ASSLY PIPE PA TANK TO FILTER	Bajaj spare parts
BF171855	ASSLY PIPE PA FILTER TO TANK	Bajaj spare parts
BF171858	STRIP BRACKET FUEL FILTER MTG	Bajaj spare parts
BF171859	CLAMP STUD MOUNTING DIA 9	Bajaj spare parts
BF172005	CONNECTOR CNG FUEL LINES	Bajaj spare parts
BF172011	TETHER CNG DUST CAP	Bajaj spare parts
BF172047	CYLINDER CNG	Bajaj spare parts
BF172064	ASSLY FILLING VALVE	Bajaj spare parts
BF172067	CLAMP ASSLY	Bajaj spare parts
BF172083	PACKING RUBBER UPPER REAR	Bajaj spare parts
BF172084	PACKING CYLINDER MTG LOWER REAR	Bajaj spare parts
BF172089	WASHER SPHERICAL STRAP TIGHTENING	Bajaj spare parts
BF172094	HOSE MFV-LPR	Bajaj spare parts
BF172100	ASSLY FLEX HOSE 2	Bajaj spare parts
BF172103	PACKING RUBBER METAL CLAMP LPG	Bajaj spare parts
BF172110	ASSLY VENT HOSE	Bajaj spare parts
BF172111	PIPE VENTILATION LPG MFV TO LPR	Bajaj spare parts
BF172112	VENT HOSE	Bajaj spare parts
BF172115	HOSE ASSY FLEX -LPG	Bajaj spare parts
BF172116	ASSLY LPG CYLINDER	Bajaj spare parts
BF172117	CLAMP LPG VENT PIPE	Bajaj spare parts
BF172120	ASSLY MULTIFUNCTION VALVE	Bajaj spare parts
BF172125	NUT RIVET M10X1.5	Bajaj spare parts
BF172126	CLAMP HOSE CNG	Bajaj spare parts
BF172127	ASSLY SPIGOT	Bajaj spare parts
BF172133	NUT RIVET M5X0.8P	Bajaj spare parts

BF172135	HOSE REGULATOR-RAIL	Bajaj spare parts
BF172137	REGULATOR LOW PRESSURE	Bajaj spare parts
BF172138	SOLENOID CNG	Bajaj spare parts
BF172146	O-RING CNG RAIL	Bajaj spare parts
BF172147	PIPE ASSEMBLY FILLING	Bajaj spare parts
BF172154	HOSE FILLER LPG-MFV	Bajaj spare parts
BF172164	PACKING RUBBER METAL CLAMP CNG	Bajaj spare parts
BF172167	NUT RIVET M6X1.0	Bajaj spare parts
BF172168	ASSLY FILLING PIPE FRONT	Bajaj spare parts
BF172170	RAIL ASSLY GAS	Bajaj spare parts
BF172177	ASSLY STRAP REAR	Bajaj spare parts
BF172186	ASSLY HPR AND SOLENOID	Bajaj spare parts
BF172197	ASSLY FILLING VALVE	Bajaj spare parts
BF172208	CONNECTOR T JOINT	Bajaj spare parts
BF172211	PIPE ASSEMBLY JOINT T-UNIT FILLING	Bajaj spare parts
BF172212	PIPE ASSEMBLY JOINT T-HPR	Bajaj spare parts
BF172213	ASSLY BRCKT LPG HOSE ROUTING	Bajaj spare parts
BF172215	CLAMP SPACER LPG HOSE	Bajaj spare parts
BF172225	CRADLE CYLINDER	Bajaj spare parts
BF172226	ASSLY LPG MTG CRADL	Bajaj spare parts
BF172231	ASSLY STRAP FRONT	Bajaj spare parts
BF172233	PACKING LOWER LPG CYL	Bajaj spare parts
BF172234	PACKING RUBBER UPPER	Bajaj spare parts
BF172236	CLAMP SPACER LPG HOSE	Bajaj spare parts
BF172238	NOZZLE GAS RAIL	Bajaj spare parts
BF172240	HOSE RAIL INJECTOR	Bajaj spare parts
BF172242	CLAMP HOSE	Bajaj spare parts
BF172274	HOSE RAIL-INJECTOR	Bajaj spare parts
BF172275	HOSE INJECTOR-MANIFOLD	Bajaj spare parts
BF172295	VALVE CNG	Bajaj spare parts
BF172297	PIPE ASSLY HPR-CONNECTOR T	Bajaj spare parts
BF172325	PIPE FILLING FRONT CNG	Bajaj spare parts
BF172332	PLUG	Bajaj spare parts
BF172335	ASSEMBLY GAUGE CNG-JOINT T	Bajaj spare parts
BF172346	BRACKET ASSY REGULATOR-SOLENOID	Bajaj spare parts
BF172365	FILTER	Bajaj spare parts
BF172367	FILTER	Bajaj spare parts
BF172408	HOSE HPR-LPR	Bajaj spare parts
BF172409	HOSE LPR-SOLENOID	Bajaj spare parts
BF172410	HOSE SOLENOID-RAIL	Bajaj spare parts
BF172416	PIPE ASSEMBLY GUAGE PRESSURE	Bajaj spare parts
BF172424	CLAMP PIPE RH	Bajaj spare parts
BF172425	CLAMP PIPE LH	Bajaj spare parts
BF172429	CONNECTOR GAUGE PRESSURE	Bajaj spare parts
BF172430	GAUGE ASSEMBLY PRESSURE	Bajaj spare parts



BF181036	HOUSING SWITCH REAR	Bajaj spare parts
BF181048	INSULATOR LH	Bajaj spare parts
BF181049	INSULATOR RH	Bajaj spare parts
BF181050	INSULATOR MIDDLE	Bajaj spare parts
BF181051	INSULATOR TOP	Bajaj spare parts
BF181052	NUT QUICKIE	Bajaj spare parts
BF181208	CLIP METALLIC TOWER	Bajaj spare parts
BF181227	COVER TELEMATIC	Bajaj spare parts
BF181308	COVER HOUSING FAN LOWER	Bajaj spare parts
BF181309	COVER HOUSING FAN UPPER	Bajaj spare parts
BF181800	BOX LUGGAGE COMPARTMENT	Bajaj spare parts
BF181809	BEADING FOR LUGGAGE BOX	Bajaj spare parts
BF181814	CLIP NUT M6	Bajaj spare parts
BF181830	ASSLY PIPE STRUCTURE SPACER	Bajaj spare parts
BF181834	PAD RUBBER SNAP LUG BOX	Bajaj spare parts
BF181839	ASSLY LUG BOX FOR HAT SEC-LH-RHD	Bajaj spare parts
BF181841	KNOB LOCK ASSLY DOOR LH	Bajaj spare parts
BF181842	LOCK ASSLY-DOOR-RH	Bajaj spare parts
BF181847	BRACKET ASSY STRUCTURE FRONT LH	Bajaj spare parts
BF181848	BRACKET ASSY STRUCTURE FRONT RH	Bajaj spare parts
BF181851	BOX LUGGAGE	Bajaj spare parts
BF182006	BUMPER FRONT	Bajaj spare parts
BF182008	BUMPER REAR LH	Bajaj spare parts
BF182009	BUMPER REAR RH	Bajaj spare parts
BF182011	METALLIC TOWER CLIP FASCIA	Bajaj spare parts
BF182013	CLIP NUT M5	Bajaj spare parts
BF182014	BUMPER FRONT DOMESTIC	Bajaj spare parts
BF182030	NUT CLIP	Bajaj spare parts
BF182031	GRILL FRONT	Bajaj spare parts
BF182209	SHELL INSTRUMENT PANEL	Bajaj spare parts
BF182211	LID GLOVE BOX LH	Bajaj spare parts
BF182228	SHROUD STEERING UPPER	Bajaj spare parts
BF182229	SHROUD STEERING LOWER	Bajaj spare parts
BF182241	HOUSING SWITCH	Bajaj spare parts
BF182266	METALLIC TOWER CLIP	Bajaj spare parts
BF182270	COVER CENTRAL	Bajaj spare parts
BF182272	HINGE PIN	Bajaj spare parts
BF182282	LID GLOVE BOX RH	Bajaj spare parts
BF182290	BRACKET SPEAKER MOUNTING LH	Bajaj spare parts
BF182295	UTILITY BOX	Bajaj spare parts
BF182296	BRACKET SPEAKER MOUNTING RH	Bajaj spare parts
BF182309	ASSLY CCB	Bajaj spare parts
BF182403	DOOR TRIM PANEL FRONT RH	Bajaj spare parts
BF182419	DOOR TRIM PANEL FRONT LH	Bajaj spare parts
BF182435	DOOR TRIM PANEL REAR RH	Bajaj spare parts

BF182450	DOOR TRIM PANEL REAR LH	Bajaj spare parts
BF182470	MAT FLOOR FRONT	Bajaj spare parts
BF182471	MAT FLOOR REAR	Bajaj spare parts
BF182475	GRAB HANDLE	Bajaj spare parts
BF182491	PANEL PLASTIC PARTITION LOWER	Bajaj spare parts
BF182492	COVER SPARE WHEEL	Bajaj spare parts
BF182516	DOOR TRIM UPPER FRONT LH	Bajaj spare parts
BF182517	DOOR TRIM UPPER FRONT RH	Bajaj spare parts
BF182518	DOOR TRIM UPPER REAR LH	Bajaj spare parts
BF182519	DOOR TRIM UPPER REAR RH	Bajaj spare parts
BF182539	WASHER ID 4.5 OD 12 THK .8	Bajaj spare parts
BF182543	LATCH CABLE ASSY RR	Bajaj spare parts
BF182544	HANDLE BARREL LH	Bajaj spare parts
BF182545	LEVER BARREL LH	Bajaj spare parts
BF182546	BARREL PIN	Bajaj spare parts
BF182548	LEVER INNER LOCK LH	Bajaj spare parts
BF182549	LEVER HOLDER LH	Bajaj spare parts
BF182550	LEVER LOCK	Bajaj spare parts
BF182551	SPRING LEVER LOCK	Bajaj spare parts
BF182554	LATCH CABLR ASSLY FR	Bajaj spare parts
BF182555	HANDLE BARREL RH	Bajaj spare parts
BF182556	LEVER BARREL RH	Bajaj spare parts
BF182558	LEVER HOLDER RH	Bajaj spare parts
BF182559	LEVER HOLDER RR LH	Bajaj spare parts
BF182560	LEVER HOLDER RR RH	Bajaj spare parts
BF182565	PIN PIN OUTER HANDLE RR	Bajaj spare parts
BF182567	LEVER INNER LOCK RH	Bajaj spare parts
BF182572	LINK OUTER FR	Bajaj spare parts
BF182573	LINK OUTER RR	Bajaj spare parts
BF182574	LINK INNER	Bajaj spare parts
BF182575	HANDLE LINK PIN	Bajaj spare parts
BF182588	COVER MIDDLE UPPER CNG	Bajaj spare parts
BF182589	COVER COVER MIDDLE LOWER	Bajaj spare parts
BF182590	COVER SIDE RH CNG	Bajaj spare parts
BF182591	COVER SIDE LH CNG	Bajaj spare parts
BF182599	ASSLY LATCH LH	Bajaj spare parts
BF182610	LOCK KNOB INNER RH	Bajaj spare parts
BF182613	BARREL LOCK RH	Bajaj spare parts
BF182615	ASSLY LATCH RH	Bajaj spare parts
BF182619	DOOR STRIKER	Bajaj spare parts
BF182624	SEAT BELT ELR REAR COVER RH	Bajaj spare parts
BF182625	SEAT BELT ELR REAR COVER LH	Bajaj spare parts
BF182634	FRONT ELR SEAT BELT	Bajaj spare parts
BF182638	BF232433 BKT FOR CNG LWR COVER	Bajaj spare parts
BF182649	LOCK KNOB INNER LH	Bajaj spare parts

BF182652	BARREL LOCK LH	Bajaj spare parts
BF182655	PEDAL COVER	Bajaj spare parts
BF182663	SPACER KNOB LOCK REAR DOOR	Bajaj spare parts
BF182665	TRIM DOOR-UPPER-FRONT-LH	Bajaj spare parts
BF182666	TRIM DOOR-UPPER-FRONT-RH	Bajaj spare parts
BF182667	TRIM DOOR-UPPER-REAR-LH	Bajaj spare parts
BF182668	TRIM DOOR-UPPER-REAR-RH	Bajaj spare parts
BF182676	BEADING	Bajaj spare parts
BF182694	FLAP ASSEMBLY VENT LH	Bajaj spare parts
BF182697	FLAP ASSEMBLY VENT RH	Bajaj spare parts
BF184005	SPACER WINDSHIELD GLASS	Bajaj spare parts
BF184007	GLASS WINDSHIELD ICAT	Bajaj spare parts
BF184601	ASSLY ORVM LH	Bajaj spare parts
BF184602	ASSLY ORVM RH	Bajaj spare parts
BF184620	ASSEMBLY IRVM	Bajaj spare parts
BF184624	ASSLY ORVM RH DOMESTIC	Bajaj spare parts
BF184629	ASSLY ORVM LH	Bajaj spare parts
BF184630	ASSLY ORVM RH	Bajaj spare parts
BF184637	ORVM LH	Bajaj spare parts
BF184638	ORVM RH	Bajaj spare parts
BF185010	CAP TR ARM MOUNTING LH	Bajaj spare parts
BF185011	CAP TR ARM MOUNTING RH	Bajaj spare parts
BF185014	GUARD SPLASH LH FR.	Bajaj spare parts
BF185015	GUARD SPLASH FRONT LH LOWER	Bajaj spare parts
BF185017	GRILL AIR INTAKE RH	Bajaj spare parts
BF185018	GRILL AIR INTAKE LH	Bajaj spare parts
BF185019	CLIP PLASTIC RIVET	Bajaj spare parts
BF185020	NUT QUICKIE	Bajaj spare parts
BF185025	GUARD SPLASH FRONT RH UPPER	Bajaj spare parts
BF185026	GUARD SPLASH FRONT RH LOWER	Bajaj spare parts
BF185065	SLEEVE PLASTIC	Bajaj spare parts
BF185068	MUDFLAP REAR RH	Bajaj spare parts
BF185069	MUDFLAP REAR LH	Bajaj spare parts
BF185071	MUDFLAP FRONT RH	Bajaj spare parts
BF185072	MUDFLAP FRONT LH	Bajaj spare parts
BF185077	GUARD SPLASH REAR RH FRONT	Bajaj spare parts
BF185078	GUARD SPLASH REAR RH REAR	Bajaj spare parts
BF185080	GUARD SPLASH REAR LH FRONT	Bajaj spare parts
BF185081	GUARD SPLASH REAR LH REAR	Bajaj spare parts
BF185083	MUDFLAP FOR DRIVE SHAFT LH	Bajaj spare parts
BF185084	MUDFLAP FOR DRIVE SHAFT RH	Bajaj spare parts
BF185086	BRACKET 1 MUDFLAP STA LH	Bajaj spare parts
BF185087	BRACKET 2 MUDFLAP STA LH	Bajaj spare parts
BF185088	BRACKET 3 MUDFLAP STA LH	Bajaj spare parts
BF185090	PLATE 1 MUDFLAP STA RH	Bajaj spare parts

BF185091	PLATE 2 MUDFLAP STA RH	Bajaj spare parts
BF185095	EMBLEM QUTE	Bajaj spare parts
BF185096	EMBLEM QCAR	Bajaj spare parts
BF186021	TOP HARD ROOF FRONT	Bajaj spare parts
BF186022	TOP HARD ROOF MIDDLE	Bajaj spare parts
BF186023	TAIL ROOF REAR OUTER	Bajaj spare parts
BF186024	BEADING HARD ROOF FRONT	Bajaj spare parts
BF186027	BEADING HARD ROOF MIDDLE	Bajaj spare parts
BF186028	BEADING TAILGATE	Bajaj spare parts
BF186029	TAIL GATE GLASS	Bajaj spare parts
BF186033	ASSLY TAILGATE	Bajaj spare parts
BF186051	INSERT RIB TAIL ROOF	Bajaj spare parts
BF186052	BRACKET UPPER TAIL ROOF	Bajaj spare parts
BF186058	DOME NUT ROOF	Bajaj spare parts
BF186060	TAIL GATE BEADING UPPER	Bajaj spare parts
BF186061	HEADLINER REAR	Bajaj spare parts
BF186063	HEADLINER FRONT	Bajaj spare parts
BF186066	CLIP	Bajaj spare parts
BF186069	HEADLINER REAR	Bajaj spare parts
BF186075	HEADLINER REAR	Bajaj spare parts
BF186076	HEADLINER FRONT	Bajaj spare parts
BF186077	HEADLINER REAR	Bajaj spare parts
BF186078	HEADLINER REAR	Bajaj spare parts
BF186080	HEADLINER REAR	Bajaj spare parts
BF186081	HEADLINER FRONT LHD	Bajaj spare parts
BF186601	STEERING WHEEL 2 SPOKE RE43 S	Bajaj spare parts
BF186605	COVER TOP STEERING WHEEL	Bajaj spare parts
BF186623	WHEEL STEERING	Bajaj spare parts
BF187000	ASSLY WIPER RE43 S 4WH BASE	Bajaj spare parts
BF187007	GROMMET WIPER	Bajaj spare parts
BF187009	WIPER ASSLY RE 43 LHD	Bajaj spare parts
BF191138	REAR SEAT LATCH PULLING KNOB	Bajaj spare parts
BF191147	BUSH NYLON BOTTOM	Bajaj spare parts
BF191148	BUSH NYLON TOP	Bajaj spare parts
BF191159	SEAT FRONT CUSHION PAN RSTNG PAD	Bajaj spare parts
BF191162	SPACER FOR SEAT MOUNTING BRACKET	Bajaj spare parts
BF191163	SPACER SEAT LEG MTG	Bajaj spare parts
BF191164	SPACER FOR RR SEAT LATERAL LATCH	Bajaj spare parts
BF191165	SPRING LATERAL LATCH REAR SEAT	Bajaj spare parts
BF191169	JUNCTION PIPE	Bajaj spare parts
BF191170	CO - DRIVER SEAT ASSEMBLY DOMESTIC	Bajaj spare parts
BF191172	CO - DRIVER SEAT CUSHION ASSLY DOMEST	Bajaj spare parts
BF191174	SLIDING OPERATING LEVER	Bajaj spare parts
BF191175	DRIVER SEAT ASSY DOMESTIC	Bajaj spare parts
BF191178	DRIVER SEAT SLIDING ASSY DOMESTIC	Bajaj spare parts

BF191181	BRACKET SLIDING MEMBER MOUNT	Bajaj spare parts
BF191188	CUSHION PAN ASSY FOR CO-DRIVER	Bajaj spare parts
BF191189	CLAMP METAL	Bajaj spare parts
BF191190	SPACER FOR REAR SEAT	Bajaj spare parts
BF191196	SEAT ASSEMBLY REAR BACK SPLIT 60	Bajaj spare parts
BF191197	FRAME ASSLY SEAT RR SPLIT 60	Bajaj spare parts
BF191201	CAP LEVER SEAT LATCH REAR	Bajaj spare parts
BF191202	SEAT ASSEMBLY REAR BACK SPLIT 40	Bajaj spare parts
BF191203	FRAME ASSLY SEAT RR SPLIT 40	Bajaj spare parts
BF191205	LATCH SEAT CENTRAL REAR	Bajaj spare parts
BF191206	BRACKET SEAT BACKREST MTG REAR	Bajaj spare parts
BF191207	CUSHION ASSLY-SEAT-REAR	Bajaj spare parts
BF191229	DAMPER	Bajaj spare parts
BF202205	ASSLY WASHER TANK	Bajaj spare parts
BF202206	TANK WINDSCREEN WASHER	Bajaj spare parts
BF202207	CAP WASHER TANK	Bajaj spare parts
BF202208	PIPE WASHER TANK	Bajaj spare parts
BF202209	NOZZLE T WASHER TANK	Bajaj spare parts
BF202210	GROMMET PUMP MOTOR	Bajaj spare parts
BF202211	GROMMET FOR WASHER TANK MOUNTING	Bajaj spare parts
BF202213	CLAMP -W	Bajaj spare parts
BF211318	RUBBER STOPPER FUEL FILLER LID	Bajaj spare parts
BF211363	GROMMET BLIND SLOT 16X20	Bajaj spare parts
BF211364	GROMMET BLIND DIA 10	Bajaj spare parts
BF211365	GROMMET BLIND DIA 18	Bajaj spare parts
BF211366	PANEL COVER REAR FLOOR	Bajaj spare parts
BF211370	BEADING STARTER MTR CUTOUT	Bajaj spare parts
BF211372	ASSLY AIR DEFLECTOR	Bajaj spare parts
BF211377	FLAP AIR DEFLECTOR	Bajaj spare parts
BF211379	ASSLY AIR DEFLECTOR SMALL	Bajaj spare parts
BF211381	FLAP AIR DEFLECTOR SMALL	Bajaj spare parts
BF211422	CAP GAS RAIL MTG	Bajaj spare parts
BF211436	ASSLY BACK PLATE NUT	Bajaj spare parts
BF211437	ASSLY BACK PLATE NUT SMALL	Bajaj spare parts
BF211438	CLIP DISTANCE AIR DEFLECTOR RH	Bajaj spare parts
BF211456	CLIP DISTANCE AIR DEFLECTOR LH	Bajaj spare parts
BF211478	PAINTED TESA TAPE DIA 19	Bajaj spare parts
BF211543	BATTERY CLAMPING BRACKET	Bajaj spare parts
BF211544	ARRESTER BATTERY CLAMP ROD	Bajaj spare parts
BF211620	ASSLY CAP ED HOLE	Bajaj spare parts
BF211648	ASSLY CAP ED HOLE	Bajaj spare parts
BF211941	BRACKET ECU UPPER	Bajaj spare parts
BF211948	BRACKET ASSEMBLY-ECU	Bajaj spare parts
BF213023	HINGE BODY SIDE LH	Bajaj spare parts
BF213025	HINGE HOOD SIDE	Bajaj spare parts

BF213125	HINGE ASSEMBLY-HOOD-RH	Bajaj spare parts
BF213129	ASSLY HOOD	Bajaj spare parts
BF231006	ASSLY SCREW JACK	Bajaj spare parts
BF231007	NUT WING	Bajaj spare parts
BF231012	TOOL KIT COMPLETE	Bajaj spare parts
BF231017	INSERT FOR NUT WING	Bajaj spare parts
BF231030	TOW HOOK RE60	Bajaj spare parts
BF231200	GUARD ENGINE BOTTOM	Bajaj spare parts
BF231406	CLAMP ROOF CARRIER BKT FRT RH	Bajaj spare parts
BF231408	CLAMP ROOF CARRIER BKT RR RH	Bajaj spare parts
BF231422	CARRIER ASSEMBLY ROOF	Bajaj spare parts
BF231806	FLAP RUBBER FOR LUGGAGE BOX	Bajaj spare parts
BF232000	HOLDER VISOR SUN	Bajaj spare parts
BF232433	BELL HOSE FOR SEAT BUCKLE	Bajaj spare parts
BF232434	ASSEMBLY SUNVISOR RH RE60	Bajaj spare parts
BF232441	BELT SEAT REAR	Bajaj spare parts
BF232606	SET LOCK RHD	Bajaj spare parts
BF233005	LABEL Q	Bajaj spare parts
BF233030	LABEL FOR HIRE FRONT BLACK	Bajaj spare parts
BF233031	LABEL FOR HIRE REAR BLACK	Bajaj spare parts
BF233032	LABEL FOR HIRE REAR RH BLACK	Bajaj spare parts
BF233033	LABEL FOR HIRE REAR LH BLACK	Bajaj spare parts
BF233034	LABEL FOR HIRE FRONT RH BLACK	Bajaj spare parts
BF233035	LABEL FOR HIRE FRONT LH BLACK	Bajaj spare parts
BF233036	LABEL FOR HIRE MIDDLE RH BLACK	Bajaj spare parts
BF233037	LABEL FOR HIRE MIDDLE LH BLACK	Bajaj spare parts
BF233039	LABEL FOR HIRE FRONT E GREEN	Bajaj spare parts
BF233040	LABEL FOR HIRE FRONT A WHITE	Bajaj spare parts
BF233041	LABEL FOR HIRE FRONT B RED	Bajaj spare parts
BF233042	LABEL FOR HIRE FRONT G YELLOW	Bajaj spare parts
BF233043	LABEL FOR HIRE FRONT N BLUE	Bajaj spare parts
BF233044	LABEL FOR HIRE REAR E GREEN	Bajaj spare parts
BF233049	LABEL FOR HIRE REAR RH E GREEN	Bajaj spare parts
BF233050	LABEL FOR HIRE REAR RH A WHITE	Bajaj spare parts
BF233051	LABEL FOR HIRE REAR RH B RED	Bajaj spare parts
BF233052	LABEL FOR HIRE REAR RH G YELLOW	Bajaj spare parts
BF233053	LABEL FOR HIRE REAR RH N BLUE	Bajaj spare parts
BF233054	LABEL FOR HIRE REAR LH E GREEN	Bajaj spare parts
BF233055	LABEL FOR HIRE REAR LH A WHITE	Bajaj spare parts
BF233056	LABEL FOR HIRE REAR LH B RED	Bajaj spare parts
BF233057	LABEL FOR HIRE REAR LH G YELLOW	Bajaj spare parts
BF233058	LABEL FOR HIRE REAR LH N BLUE	Bajaj spare parts
BF233059	LABEL FOR HIRE FRONT RH E GREEN	Bajaj spare parts
BF233060	LABEL FOR HIRE FRONT RH A WHITE	Bajaj spare parts
BF233061	LABEL FOR HIRE FRONT RH B RED	Bajaj spare parts

BF233062	LABEL FOR HIRE FRONT RH G YELLOW	Bajaj spare parts
BF233063	LABEL FOR HIRE FRONT RH N BLUE	Bajaj spare parts
BF233064	LABEL FOR HIRE FRONT LH E GREEN	Bajaj spare parts
BF233065	LABEL FOR HIRE FRONT LH A WHITE	Bajaj spare parts
BF233066	LABEL FOR HIRE FRONT LH B RED	Bajaj spare parts
BF233067	LABEL FOR HIRE FRONT LH G YELLOW	Bajaj spare parts
BF233068	LABEL FOR HIRE FRONT LH N BLUE	Bajaj spare parts
BF233069	LABEL FOR HIRE MIDDLE RH E GREEN	Bajaj spare parts
BF233070	LABEL FOR HIRE MIDDLE RH A WHITE	Bajaj spare parts
BF233071	LABEL FOR HIRE MIDDLE RH B RED	Bajaj spare parts
BF233072	LABEL FOR HIRE MIDDLE RH G YELLOW	Bajaj spare parts
BF233073	LABEL FOR HIRE MIDDLE RH N BLUE	Bajaj spare parts
BF233074	LABEL FOR HIRE MIDDLE LH E GREEN	Bajaj spare parts
BF233075	LABEL FOR HIRE MIDDLE LH A WHITE	Bajaj spare parts
BF233076	LABEL FOR HIRE MIDDLE LH B RED	Bajaj spare parts
BF233077	LABEL FOR HIRE MIDDLE LH G YELLOW	Bajaj spare parts
BF233078	LABEL FOR HIRE MIDDLE LH N BLUE	Bajaj spare parts
BF241026	ASSLY REAR DOOR COMP LH	Bajaj spare parts
BF241027	ASSLY REAR DOOR COMP RH	Bajaj spare parts
BF241088	BEADING BIW FRONT LH	Bajaj spare parts
BF241089	BEADING BIW FRONT RH	Bajaj spare parts
BF241090	BEADING BIW REAR LH	Bajaj spare parts
BF241091	BEADING BIW REAR RH	Bajaj spare parts
BF241145	ARM REST FRONT DOOR RH	Bajaj spare parts
BF241152	RIVET PLASTIC DOOR EDGE BEADING	Bajaj spare parts
BF241160	HOOK STRING MOUNTING ON BIW	Bajaj spare parts
BF241198	DOOR ASSLY FRONT LOCKABLE RH	Bajaj spare parts
BF241204	DOOR ASSLY FRONT LH	Bajaj spare parts
BF242039	PIN INNER HANDLE	Bajaj spare parts
BF242044	DOOR STRIKER	Bajaj spare parts
BF242202	HANDLE PLASTIC OTR FR LH	Bajaj spare parts
BF242203	HANDLE PLASTIC OTR FR RH	Bajaj spare parts
BF242204	HANDLE PLASTIC OTR RR LH	Bajaj spare parts
BF242205	HANDLE PLASTIC OTR RR RH	Bajaj spare parts
BF242206	HANDLE PLASTIC INNER LH	Bajaj spare parts
BF242207	HANDLE PLASTIC INNER RH	Bajaj spare parts
BF243023	BEADING FRONT DOOR BOTTOM LH	Bajaj spare parts
BF243024	BEADING FRONT DOOR BOTTOM RH	Bajaj spare parts
BF243025	BEADING REAR DOOR BOTTOM LH	Bajaj spare parts
BF243026	BEADING REAR DOOR BOTTOM RH	Bajaj spare parts
BF243049	DOOR FRONT SLIDING GLASS FT	Bajaj spare parts
BF243050	'DOOR FRONT SLIDING GLASS RR	Bajaj spare parts
BF243051	DOOR REAR SLIDING GLASS FR	Bajaj spare parts
BF243052	DOOR REAR SLIDING GLASS REAR	Bajaj spare parts
BF243053	GLASS FRT DOOR SLIDING FRT RH	Bajaj spare parts

BF243054	GLASS FRT DOOR SLIDING RR RH	Bajaj spare parts
BF243055	GLASS RR DOOR SLIDING FRT RH	Bajaj spare parts
BF243056	GLASS RR DOOR SLIDING RR RH	Bajaj spare parts
BF243057	CHANNEL FRT DOOR SLIDING TOP LH	Bajaj spare parts
BF243058	CHANNEL FRT DOOR SLIDING BTM LH	Bajaj spare parts
BF243059	CHANNEL RR DOOR SLIDING TOP LH	Bajaj spare parts
BF243060	CHANNEL RR DOOR SLIDING BTM LH	Bajaj spare parts
BF243061	CHANNEL FRT DOOR SLIDING TOP RH	Bajaj spare parts
BF243062	CHANNEL FRT DOOR SLIDING BTM RH	Bajaj spare parts
BF243063	CHANNEL RR DOOR SLIDING TOP RH	Bajaj spare parts
BF243064	CHANNEL RR DOOR SLIDING BTM RH	Bajaj spare parts
BF243065	ASSLY HINGE HOOD	Bajaj spare parts
BF243066	LOCK RE60 SLIDING GLASS	Bajaj spare parts
BF243067	RUBBER CAP FUEL LID	Bajaj spare parts
BF243073	COVER SLIDING FRT DOOR BTM LH	Bajaj spare parts
BF243074	COVER SLIDING FRT DOOR BTM RH	Bajaj spare parts
BF243087	PANEL DOOR FRAME SLIDING-RR LH	Bajaj spare parts
BF243088	PANEL DOOR FRAME SLIDING-RR RH	Bajaj spare parts
BF243089	PANEL DIVDNG CHNL SLIDING-FRT LH	Bajaj spare parts
BF243090	PANEL DIVDNG CHNL SLIDING-FRT RH	Bajaj spare parts
BF243091	GUIDE CHNL BEADING BTM FRT	Bajaj spare parts
BF243092	GUIDE CHNL BEADING FRT FRT	Bajaj spare parts
BF243093	GUIDE CHNL BEADING RR FRT	Bajaj spare parts
BF243096	BEADING CHANNEL SLIDING	Bajaj spare parts
BF243097	BEADING PARTITION SLIDING GLASS	Bajaj spare parts
BF243098	COVER SLIDING RR DOOR BTM LH	Bajaj spare parts
BF243099	COVER SLIDING RR DOOR BTM RH	Bajaj spare parts
BF243100	LATCH FRONT DOOR-FRONT GLASS-LH	Bajaj spare parts
BF243101	LATCH FRONT DOOR-FRONT GLASS-RH	Bajaj spare parts
BF243102	LATCH FRONT DOOR-REAR GLASS-LH	Bajaj spare parts
BF243103	LATCH FRONT DOOR-REAR GLASS-RH	Bajaj spare parts
BF243104	LATCH REAR DOOR-FRONT GLASS-LH	Bajaj spare parts
BF243105	LATCH REAR DOOR-FRONT GLASS-RH	Bajaj spare parts
BF243106	LATCH REAR DOOR-REAR GLASS-LH	Bajaj spare parts
BF243107	LATCH REAR DOOR-REAR GLASS-RH	Bajaj spare parts
BF243109	COVER LOUVER CLOSING-FRONT-LH	Bajaj spare parts
BF243110	COVER LOUVER CLOSING-FRONT-RH	Bajaj spare parts
BF243111	COVER LOUVER CLOSING-REAR-LH	Bajaj spare parts
BF243112	COVER LOUVER CLOSING-REAR-RH	Bajaj spare parts
BF243113	BEADING CHANNEL	Bajaj spare parts
BF243114	BEADING CHANNEL	Bajaj spare parts
BF243115	BEADING CHANNEL	Bajaj spare parts
BF243116	BEADING CHANNEL	Bajaj spare parts
BF243117	BEADING CHANNEL	Bajaj spare parts
BF243118	CHANNEL DOOR FRONT	Bajaj spare parts



BF243119	CHANNEL DOOR FRONT RH	Bajaj spare parts
BF243122	BRACKET	Bajaj spare parts
BF243129	BEADING HOOD	Bajaj spare parts
BF243133	BEADING DOOR FRONT LH	Bajaj spare parts
BF243138	BEADING FRONT RH LOWER	Bajaj spare parts
BF243139	BEADING REAR LH	Bajaj spare parts
BF243140	BEADING REAR RH	Bajaj spare parts
BF243141	BEADING FRONT RH	Bajaj spare parts
BF244000	ASSLY REAR ENG ACCESS CVR	Bajaj spare parts
BF244008	RUBBER BUMP STOPPER	Bajaj spare parts
BF244009	STRING ENGINE ACC COVER STOPPER	Bajaj spare parts
BF244023	TAILGATE ASSEMBLY	Bajaj spare parts
BF246000	BRACKET ORVM MOUNTING-FRONT LH	Bajaj spare parts
BF246001	BRACKET ORVM MOUNTING-FRONT RH	Bajaj spare parts
BF246009	FOAM BEADING	Bajaj spare parts
BF246010	BEADING ASSEMBLY DOOR FRONT LH	Bajaj spare parts
BF246011	BEADING ASSEMBLY DOOR FRONT RH	Bajaj spare parts
BF246012	BEADING ASSEMBLY DOOR REAR LH	Bajaj spare parts
BF246013	BEADING ASSEMBLY DOOR REAR RH	Bajaj spare parts
BF246015	TAPE	Bajaj spare parts
BF246017	BEADING DOOR REAR I	Bajaj spare parts
BF247002	BRACKET HINGE REAR BODY SIDE	Bajaj spare parts
BF247003	PIN ENG ACCESS CVR HINGE	Bajaj spare parts
BF247026	ASSLY HINGE FR DOOR LH BTM	Bajaj spare parts
BF247032	ASSLY HINGE RR DOOR LH BTM	Bajaj spare parts
BF253476	FAN	Bajaj spare parts
BF253483	BUSH	Bajaj spare parts
BF253487	DAMPER	Bajaj spare parts
BF253489	FAN ASSEMBLY FRONT	Bajaj spare parts
BF253490	FAN ASSEMBLY REAR	Bajaj spare parts
BF253494	COVER ASSEMBLY FAN FRONT	Bajaj spare parts
BF253495	COVER ASSEMBLY FAN REAR	Bajaj spare parts
BF301200	ASSLY WIPER MOTOR 4W	Bajaj spare parts
BF301201	WIPER MORTOR ASSY FOR LHD	Bajaj spare parts
BF351023	ASSLY ROTOR (WITH CLUTCH ASSLY)	Bajaj spare parts
BF351025	ASSLY STATOR	Bajaj spare parts
BF351067	STATOR ASSEMBLY	Bajaj spare parts
BF351203	SPARK PLUG CAP	Bajaj spare parts
BF351219	KIT H.T COILS (CNG)	Bajaj spare parts
BF351220	H T COIL WITH CABLE & CAP LH	Bajaj spare parts
BF351221	H T COIL WITH CABLE LH	Bajaj spare parts
BF351222	H T COIL WITH CABLE & CAP RH	Bajaj spare parts
BF351223	H T WITH CABLE RH	Bajaj spare parts
BF351229	GROMMET PRIMARY SPARK PLUG	Bajaj spare parts
BF351234	COIL HT1 WITH CAP	Bajaj spare parts

BF351236	COIL HT2 WITH CAP	Bajaj spare parts
BF351237	COIL HT WITH HIGHER OCV	Bajaj spare parts
BF351258	PLUG SPARK	Bajaj spare parts
BF351262	PAD ECU	Bajaj spare parts
BF351263	CAP PLUG SPARK	Bajaj spare parts
BF351601	STARTER MOTOR	Bajaj spare parts
BF351803	SWITCH GEAR INDICATOR	Bajaj spare parts
BF351804	O RING SPEED SENSOR	Bajaj spare parts
BF351806	RING MAGNET	Bajaj spare parts
BF351809	SPEED SENCER (DUEL OUT PUT)	Bajaj spare parts
BF351811	SENSOR PRESSURE-TEMPERATURE	Bajaj spare parts
BF351815	SENSOR GEAR INDICATOR _ETB	Bajaj spare parts
BF351816	SWITCH REVERSE ETB	Bajaj spare parts
BF351817	SENSOR PRESSURE	Bajaj spare parts
BF401014	LAMP NUMBER PLATE ILLUMINATION	Bajaj spare parts
BF401015	CABIN ROOF LIGHT	Bajaj spare parts
BF401018	ASSLY 4WC LH HEADLAMP	Bajaj spare parts
BF401118	ASSLY 4WB TAIL LAMP LH	Bajaj spare parts
BF401119	ASSLY 4WB TAIL LAMP RH	Bajaj spare parts
BF401128	ASSEMBLY SIDE INDICATOR RE60	Bajaj spare parts
BF401135	HEAD LAMP LH ASYM BEAM LHD 60 55W	Bajaj spare parts
BF401138	ASSLY 4WH TAIL LAMP RH 16W	Bajaj spare parts
BF401139	ASSLY 4WH TAIL LAMP LH 16W	Bajaj spare parts
BF401144	HEAD LAMP ASS LH ASY RHD 60 55W	Bajaj spare parts
BF401145	HEAD LAMP ASS RH ASY RHD 60 55W	Bajaj spare parts
BF401152	BULB CLEAR W16W 12V	Bajaj spare parts
BF401158	ASSLY COMBI SWITCH AHO LHD	Bajaj spare parts
BF401163	HEAD LAMP CONTROL UNIT	Bajaj spare parts
BF401401	ASSY COMBINATION SWITCH	Bajaj spare parts
BF401404	SWITCH CLUTCH	Bajaj spare parts
BF401410	SWITCH BRAKE	Bajaj spare parts
BF401427	SWITCH FAN BLOWER	Bajaj spare parts
BF401430	DIODE TRANS UNIT	Bajaj spare parts
BF401433	ASSLY COMBINATION SWITCH _RHD	Bajaj spare parts
BF401443	DIODE UNIT AHO	Bajaj spare parts
BF401444	SWITCH HAZARD WITH ILLUMINATION	Bajaj spare parts
BF401451	SWITCH COMBINATION	Bajaj spare parts
BF401462	SWITCH BRAKE	Bajaj spare parts
BF401606	HORN -82 DIA-DOUBLE STRIP	Bajaj spare parts
BF401611	BEEPER	Bajaj spare parts
BF401818	12V-26AH WET BATTERY	Bajaj spare parts
BF402003	REGULATOR ASSLY	Bajaj spare parts
BF402004	ASSLY HEATER BLOWER CNTRLR	Bajaj spare parts
BF402009	FLASHER RELAY RE60 16W	Bajaj spare parts
BF402016	RELAY FLASHER	Bajaj spare parts

BF402206	ASSLY CABLE RELAY TO MOTOR	Bajaj spare parts
BF402213	CABLE ASSY BATTERY TO EAR 4WH	Bajaj spare parts
BF402219	HARNES WIRING DASHBRD_CNG	Bajaj spare parts
BF402221	GROMMET REAR HARNESS RECTANGULAR	Bajaj spare parts
BF402242	CABLE TIE STUD M5X14.2 MTG	Bajaj spare parts
BF402248	CABLE SOLENOID LPG	Bajaj spare parts
BF402267	HARNESS FOR PARKING BRAKE SWITCH	Bajaj spare parts
BF402269	FUSE 40A ATO BLADE TYPE	Bajaj spare parts
BF402271	HARNESS DB WITH SIDE INDICATOR	Bajaj spare parts
BF402272	HARNESS REAR RE60 GASOLINE	Bajaj spare parts
BF402273	FUSE BOX ASSMBLY	Bajaj spare parts
BF402274	HARNESS FRONT	Bajaj spare parts
BF402276	CAP DIAGNOSTIC COUPLER WATERPROOF	Bajaj spare parts
BF402280	HARNESS WIRING FRONT FI LHD	Bajaj spare parts
BF402286	HARNESS FOR HT COIL	Bajaj spare parts
BF402290	HARNESS WIRING DASHBOARD AHO	Bajaj spare parts
BF402291	HARNESS WIRING REAR_AHO	Bajaj spare parts
BF402310	FUSE 5A ATO	Bajaj spare parts
BF402323	HARNESS REAR DTSI	Bajaj spare parts
BF402328	HARNESS WIRING-REAR	Bajaj spare parts
BF402344	HARNESS DASHBOARD EPM44-LHD-AHO	Bajaj spare parts
BF402351	CABLE BATTERY-NEGATIVE	Bajaj spare parts
BF402352	CABLE MOTOR STARTER-EARTH	Bajaj spare parts
BF402358	HARNESS WIRING DASHBOARD LHD	Bajaj spare parts
BF402361	HARNESS WIRING DASHBOARD	Bajaj spare parts
BF402384	HARNESS WIRING FRONT	Bajaj spare parts
BF402385	HARNESS WIRING DASHBOARD	Bajaj spare parts
BF402387	CABLE SWITCH EMERGENCY	Bajaj spare parts
BF402397	HARNESS WIRING REAR	Bajaj spare parts
BF402404	ASSLY INSTRUMENT CONSOLE BASE	Bajaj spare parts
BF402407	ASSLY INSTRUMENT CLUSTER	Bajaj spare parts
BF402408	ASSLY INSTRUMENT CLUSTER	Bajaj spare parts
BF402427	SPEEDOMETER	Bajaj spare parts
BF402431	SPEEDOMETER	Bajaj spare parts
BF402601	KIT SENDER UNIT	Bajaj spare parts
BF403002	PUMP FUEL MODULE FI	Bajaj spare parts
BF403007	RELAY CNG CUT OFF	Bajaj spare parts
BF403012	PUMP FUEL MODULE FI	Bajaj spare parts
BF403210	UNIT INJECTOR DRIVER	Bajaj spare parts
BF403217	RELAY VCU	Bajaj spare parts
BF403222	UNIT INJECTOR DRIVER	Bajaj spare parts
BF403403	UNIT SPEAKER 3 INCH	Bajaj spare parts
BF403407	FM RADIO 6 POLE COUPLER	Bajaj spare parts
BF404001	HARNESS WIRING REAR	Bajaj spare parts
BF404009	HARNESS WIRING DASHBOARD LHD	Bajaj spare parts

BF404021	CABLE FAN	Bajaj spare parts
BF404024	HARNESS WIRING DASHBOARD	Bajaj spare parts
BF404063	CABLE SENSOR	Bajaj spare parts
BF404069	HARNESS WIRING REAR	Bajaj spare parts
BF404072	HARNESS WIRING REAR	Bajaj spare parts
BF404073	HARNESS WIRING DASHBOARD	Bajaj spare parts
BF501009	ASSLY ENGINE 200 CNG	Bajaj spare parts
BF501044	ENGINE ASSLY COMPLETE ( PREMIUM)	Bajaj spare parts
BF501049	ENGINE ASSLY COMPLETE - LPG	Bajaj spare parts
BF511014	NOZZLE BYPASS	Bajaj spare parts
BF511038	ROCKER ARM INTAKE ASSLY	Bajaj spare parts
BF511039	ROCKER ARM EXHAUST ASSLY	Bajaj spare parts
BF511040	ROCKER ARM SHAFT	Bajaj spare parts
BF511049	GASKET CYLINDER HEAD	Bajaj spare parts
BF511050	SLEEVE SPARK PLUG (M12)	Bajaj spare parts
BF511064	CYLINDER HEAD COMPLETE (CNG)	Bajaj spare parts
BF511074	SCREW BLEED	Bajaj spare parts
BF511075	O-RING	Bajaj spare parts
BF511077	HEAD CYLINDER ASSLY	Bajaj spare parts
BF511214	CHAIN SILENT	Bajaj spare parts
BF511222	PLATE STOPPER CLUTCH COVER	Bajaj spare parts
BF511226	SPROCKET CAM DRIVE	Bajaj spare parts
BF511236	VALVE INTAKE	Bajaj spare parts
BF511237	VALVE EXHAUST	Bajaj spare parts
BF511239	SPRING VALVE	Bajaj spare parts
BF511244	PLATE STOPPER ROCKER SHAFT	Bajaj spare parts
BF511254	SEAT VALVE SPRING	Bajaj spare parts
BF511258	SPROCKET CRANKSHAFT	Bajaj spare parts
BF511274	ASSLY CAMSHAFT 216	Bajaj spare parts
BF511276	GUIDE CHAIN SLACK SIDE	Bajaj spare parts
BF511279	SPACER CAM SHAFT SILENT CHAIN	Bajaj spare parts
BF511280	RETAINER VALVE SPRING	Bajaj spare parts
BF511281	VALVE INTAKE	Bajaj spare parts
BF511288	ASSLY ROCKER ARM EXHAUST	Bajaj spare parts
BF511292	SHAFT ROCKER ARM	Bajaj spare parts
BF511295	GUIDE CHAIN TIGHT SIDE 2V	Bajaj spare parts
BF511296	ASSLY ROCKER ARM INTAKE	Bajaj spare parts
BF511300	CAMSHAFT	Bajaj spare parts
BF511301	CAMSHAFT ASSLY	Bajaj spare parts
BF521012	GASKET CYLINDER BLOCK	Bajaj spare parts
BF521019	ASSEMBLY CYLINDER BLOCK	Bajaj spare parts
BF521207	ASSLY PISTON BOWL 1	Bajaj spare parts
BF521214	PISTON ASSLY	Bajaj spare parts
BF521217	PIN PISTON	Bajaj spare parts
BF531021	ASSLY GEAR BALANCER DRIVE	Bajaj spare parts

BF531023	NUT SPECIAL	Bajaj spare parts
BF531030	PIN FAN DRIVE	Bajaj spare parts
BF531039	NUT NUT( M20 X1.5)	Bajaj spare parts
BF531043	SPACER FAN	Bajaj spare parts
BF531044	BOLT SOCKET (M12 X1.25)	Bajaj spare parts
BF531051	SHAFT FAN	Bajaj spare parts
BF531052	GEAR FAN DRIVE	Bajaj spare parts
BF531055	CRANKSHAFT ASSLY	Bajaj spare parts
BF531058	ASSLY CONROD COMPLET	Bajaj spare parts
BF531059	ASSLY CRANKSHAFT COMPLETE	Bajaj spare parts
BF531200	BALANCER SHAFT	Bajaj spare parts
BF531201	BALANCER SHAFT ASSEMBLY	Bajaj spare parts
BF531207	GEAR BALANCER DRIVEN	Bajaj spare parts
BF531212	BALANCER SHAFT ASSLY	Bajaj spare parts
BF531213	GEAR BALANCER DRIVE	Bajaj spare parts
BF531214	GEAR BALANCER DRIVEN	Bajaj spare parts
BF541007	CRANKCASE MAGNETO SIDE	Bajaj spare parts
BF541008	CRANKCASE CLUTCH SIDE	Bajaj spare parts
BF541014	WASHER THRUST CRANKSHAFT	Bajaj spare parts
BF541015	INSERT	Bajaj spare parts
BF541016	BUSH SHIFT RAIL	Bajaj spare parts
BF541018	PLATE OIL SEPERATOR	Bajaj spare parts
BF541019	PLATE STOPPER STARTER GEAR	Bajaj spare parts
BF541029	PLATE	Bajaj spare parts
BF541030	GASKET CLUTCH COVER TOP	Bajaj spare parts
BF541039	DIPSTICK	Bajaj spare parts
BF541041	DOWEL SOLID	Bajaj spare parts
BF541043	STUD M10 CCCS	Bajaj spare parts
BF541044	STUD M10 CCMS	Bajaj spare parts
BF541046	NOZZLE OIL	Bajaj spare parts
BF541047	ASSLY TUBE DIPSTICK	Bajaj spare parts
BF541052	GASKET CRANKCASE	Bajaj spare parts
BF541053	PLATE LOCK INPUT SHAFT BEARING	Bajaj spare parts
BF541061	TUBE ASSLY DIPSTICK	Bajaj spare parts
BF541064	GASKET CRANKCASE	Bajaj spare parts
BF541082	CRANKCASE CLUTCH SIDE	Bajaj spare parts
BF541204	CLUTCH COVER	Bajaj spare parts
BF541205	COVER MAGNETO	Bajaj spare parts
BF541208	GASKET CLUTCH COVER	Bajaj spare parts
BF541209	GASKET MAGNETO COVER	Bajaj spare parts
BF541215	HOUSING GEAR SHIFTER	Bajaj spare parts
BF541216	PLATE STOPPER PICK UP	Bajaj spare parts
BF541221	COVER CYLINDER HEAD	Bajaj spare parts
BF541225	COVER GEAR SHIFTER	Bajaj spare parts
BF541226	COVER CLUTCH TOP	Bajaj spare parts

BF541242	SEAL OIL FAN DRIVE	Bajaj spare parts
BF541244	BRACKET CLUTCH CABLE	Bajaj spare parts
BF541246	GASKET FAREMETER	Bajaj spare parts
BF541247	SEAL OIL FAREMETER	Bajaj spare parts
BF551023	BUSH 1ST DRIVEN	Bajaj spare parts
BF551024	PLUNGER OIL	Bajaj spare parts
BF551025	SLEEVE SHIFTING REVERSE GEAR	Bajaj spare parts
BF551026	SHAFT REVERSE IDLER	Bajaj spare parts
BF551027	RING SNAP INPUT	Bajaj spare parts
BF551028	WASHER INPUT	Bajaj spare parts
BF551032	SPACER REV INPUT	Bajaj spare parts
BF551033	SPACER 1ST OUTPUT	Bajaj spare parts
BF551034	CIRCLIP 1ST OUTPUT	Bajaj spare parts
BF551035	WASHER 3RD OUTPUT	Bajaj spare parts
BF551037	RING SNAP OUTPUT	Bajaj spare parts
BF551039	PLATE LOCK	Bajaj spare parts
BF551040	BEARING CYL ROLL NJ204(20*47*14)	Bajaj spare parts
BF551043	SPACER 1	Bajaj spare parts
BF551044	SPACER 2	Bajaj spare parts
BF551055	BUSH 2ND DRIVEN	Bajaj spare parts
BF551056	WASHER SPLINE 2ND OUTPUT	Bajaj spare parts
BF551057	BUSH REV OUTPUT	Bajaj spare parts
BF551058	SPRING OIL PLUNGER	Bajaj spare parts
BF551059	CIRCLIP HEAVY TYPE	Bajaj spare parts
BF551060	ASSLY REV LOCK COMPLETE	Bajaj spare parts
BF551062	LOCK PLATE	Bajaj spare parts
BF551064	SPACER CLUTCH SHAFT	Bajaj spare parts
BF551218	GEAR 2ND INPUT	Bajaj spare parts
BF551219	GEAR 1ST OUTPUT	Bajaj spare parts
BF551220	GEAR 4TH OUTPUT	Bajaj spare parts
BF551223	GEAR 2ND OUTPUT	Bajaj spare parts
BF551227	GEAR REV INPUT	Bajaj spare parts
BF551228	GEAR REV OUTPUT	Bajaj spare parts
BF551230	GEAR COMP REV IDLER	Bajaj spare parts
BF551240	GEAR LIMITER	Bajaj spare parts
BF551243	ASSLY LIMITER	Bajaj spare parts
BF551261	BUSH REVERSE IDLER GEAR	Bajaj spare parts
BF551266	GEAR BEVEL SUN	Bajaj spare parts
BF551270	GEAR PRIMARY DRIVE (GR 2.67)	Bajaj spare parts
BF551275	GEAR PRIMARY DRIVE _GR-2.8	Bajaj spare parts
BF551401	SPRING JUDDER	Bajaj spare parts
BF551404	SHAFT CLUTCH RELEASE	Bajaj spare parts
BF551409	BUSH TOP	Bajaj spare parts
BF551410	BUSH BOTTOM	Bajaj spare parts
BF551414	SPRING TORSION CLUTCH	Bajaj spare parts

BF551417	HOLDER CLUTCH	Bajaj spare parts
BF551418	PLATE HOLDER	Bajaj spare parts
BF551419	COLLAR	Bajaj spare parts
BF551421	CLUTCH PLATE ASSLY	Bajaj spare parts
BF551422	CLUTCH HUB	Bajaj spare parts
BF551428	BODY SPRAG CLUTCH	Bajaj spare parts
BF551429	SPRAG CLUTCH COMPLETE	Bajaj spare parts
BF551430	BRACKET ACCELERATOR SUPPORT	Bajaj spare parts
BF551435	WASHER BELLEVILLE	Bajaj spare parts
BF551439	SPRING COMPRESSION	Bajaj spare parts
BF551440	CUP CLUTCH	Bajaj spare parts
BF551441	WASHER CLUTCH	Bajaj spare parts
BF551442	ASSLY CLUTCH	Bajaj spare parts
BF551443	ASSLY CLUTCH OUTER COMPLETE	Bajaj spare parts
BF551446	PLATE FRICTION REDUCED	Bajaj spare parts
BF551449	PLATE FRICTION	Bajaj spare parts
BF551450	ASSLY LEVER CLUTCH (4W)	Bajaj spare parts
BF551454	PLATE JUDDER	Bajaj spare parts
BF551455	PLATE CLUTCH	Bajaj spare parts
BF551456	CLUTCH ASSLY COMPLETE -OUTER	Bajaj spare parts
BF551457	CLUTCH ASSLY	Bajaj spare parts
BF551459	RACK CLUTCH	Bajaj spare parts
BF551605	SATELLITE PINION	Bajaj spare parts
BF551609	PIN DIFFERENTIAL	Bajaj spare parts
BF551610	WASHER BEVEL GEAR	Bajaj spare parts
BF551611	WASHER BEVEL PINION (SPH)	Bajaj spare parts
BF551613	SEAL OIL	Bajaj spare parts
BF551616	ASSLY DIFFERETIAL DAMPER	Bajaj spare parts
BF551617	CASE DIFFERRETIAL	Bajaj spare parts
BF551618	HUB DIFFERENTIAL	Bajaj spare parts
BF551619	GEAR DIFFERENTIAL DAMPER	Bajaj spare parts
BF551620	DAMPER DIFFERENTIAL	Bajaj spare parts
BF551626	SEAL OIL	Bajaj spare parts
BF551807	ASSLY DRIVE SHAFT WITH HUB BRG	Bajaj spare parts
BF561000	FORK 1ST	Bajaj spare parts
BF561006	FORK 2ND / 3RD	Bajaj spare parts
BF561007	FORK REVERSE GEAR	Bajaj spare parts
BF561008	SHIFTER GEAR REVERSE	Bajaj spare parts
BF561009	FORK 4TH/5TH GEAR	Bajaj spare parts
BF561010	GEAR SHIFTER GUIDE	Bajaj spare parts
BF561017	RAIL SHIFTER 1ST/2ND	Bajaj spare parts
BF561018	RAIL SHIFTER 4TT/5TH	Bajaj spare parts
BF561020	BEARING PLAIN	Bajaj spare parts
BF561021	BOLT M6 SPECIAL	Bajaj spare parts
BF561025	PLATE REVERSE INHIBITOR	Bajaj spare parts

BF561026	ASSLY GEAR SHIFTER	Bajaj spare parts
BF561027	PIN	Bajaj spare parts
BF561028	PIN OVERSHIFT	Bajaj spare parts
BF561041	BRACKET REVERSE LOCK	Bajaj spare parts
BF561043	ASSLY DRUM GEARSHIFT	Bajaj spare parts
BF561201	ASSLY lever drum actuation	Bajaj spare parts
BF561206	SPRING TENSION	Bajaj spare parts
BF561219	BOLT DETENT LEVER	Bajaj spare parts
BF561221	SPRING RETURN TORSION	Bajaj spare parts
BF561403	SPRING TORSION	Bajaj spare parts
BF561404	ASSLY DETENT LEVER	Bajaj spare parts
BF571020	ASSLY OIL PUMP	Bajaj spare parts
BF571026	PIPE OIL INPUT SHAFT AND MAGNETO	Bajaj spare parts
BF571028	PUMP OIL	Bajaj spare parts
BF581000	ASSLY AIR FILTER	Bajaj spare parts
BF581009	INSERT	Bajaj spare parts
BF581010	PIPE BREATHER	Bajaj spare parts
BF581012	TUBE INTAKE (FILTER TO BIW)	Bajaj spare parts
BF581016	FOAM BREATHER	Bajaj spare parts
BF581017	COVER BREATHER	Bajaj spare parts
BF581018	SEAL BREATHER	Bajaj spare parts
BF581020	PIPE BREATHER	Bajaj spare parts
BF581023	INSERT AIR FILTER MOUNTING	Bajaj spare parts
BF581024	DAMPER AIR FILTER MOUNTING	Bajaj spare parts
BF581028	FOAM FRESH AIR ENTRY DUCT BOTTOM	Bajaj spare parts
BF581029	SEAL FRESH AIR ENTRY DUCT	Bajaj spare parts
BF581030	GROMMET DUCT FRESH AIR INTAKE	Bajaj spare parts
BF581031	GASKET FRESH AIR INTAKE	Bajaj spare parts
BF581032	FOAM FRESH AIR ENTRY UPPER	Bajaj spare parts
BF581040	BRACKET PLENUM CHAMBER MTG	Bajaj spare parts
BF581048	FILTER ELEMENT	Bajaj spare parts
BF581049	ARRESTER FLAME	Bajaj spare parts
BF581059	ASSLY DUCT SUPPORT	Bajaj spare parts
BF581068	BREATHER PIPE I	Bajaj spare parts
BF581069	BREATHER PIPE II	Bajaj spare parts
BF581075	TUBE DRAIN	Bajaj spare parts
BF581077	BRACKET BREATHER PIPE SUPPORT	Bajaj spare parts
BF581084	SEAL PLENUM CHAMBER	Bajaj spare parts
BF581085	BRACKET AIR FILTER MTG	Bajaj spare parts
BF581086	ASSEMBLY AIR FILTER	Bajaj spare parts
BF581087	ASSLY CONNECTING TUBE	Bajaj spare parts
BF581089	ASSLY DUCT FRESH AIR ENTRY	Bajaj spare parts
BF581091	ASSLY PLENUM CHAMBER COMPLETE	Bajaj spare parts
BF581093	ASSLY CONNECTING TUBE	Bajaj spare parts
BF581095	BREATHER PIPE 1	Bajaj spare parts



BF581097	ASSLY AIR FILTER CNG	Bajaj spare parts
BF581125	ASSEMBLY AIR FILTER	Bajaj spare parts
BF581206	ASSLY ELECTRONICS THROTL BODY	Bajaj spare parts
BF581207	THROTTLE BODY ASSLY Ø33	Bajaj spare parts
BF581407	INSULATOR (CARB 2)	Bajaj spare parts
BF581409	O RING MANIFOLD	Bajaj spare parts
BF581419	SLEEVE MANIFOLD	Bajaj spare parts
BF581420	MANIFOLD INTAKE	Bajaj spare parts
BF581422	MANIFOLD LPG	Bajaj spare parts
BF581434	CAP INJECTOR	Bajaj spare parts
BF581437	MANIFOLD INTAKE	Bajaj spare parts
BF591004	ASSLY PIPE A	Bajaj spare parts
BF591073	ASSLY MUFFLER COMPLETE	Bajaj spare parts
BF591097	ASSEMBLY HEAT SHIELD	Bajaj spare parts
BF591120	GROMMET HEAT SHIELD MOUNTING	Bajaj spare parts
BF591121	SLEEVE HEAT SHIELD MOUNTING	Bajaj spare parts
BF591183	MUFFLER ASSEMBLY	Bajaj spare parts
BF591284	SHIELD ASSEMBLY MUFFLER	Bajaj spare parts
BF591294	MUFFLER ASSEMBLY	Bajaj spare parts
BF591321	MUFFLER ASSEMBLY	Bajaj spare parts
BF601000	ASSLY WATER PUMP	Bajaj spare parts
BF601009	HOSE WATER OUT 1	Bajaj spare parts
BF601012	GASKET THERMOSTAT	Bajaj spare parts
BF601013	CLAMP HOSE	Bajaj spare parts
BF601014	CLAMP HOSE BYPASS	Bajaj spare parts
BF601021	HOSE WATER IN (216CC)	Bajaj spare parts
BF601022	HOSE WATER OUT2 (216CC)	Bajaj spare parts
BF601023	HOSE BYPASS (216CC)	Bajaj spare parts
BF601024	BRACKET SUPPORT BY PASS HOSE	Bajaj spare parts
BF601027	ASSLY CAP THERMOSTAT COMPLETE	Bajaj spare parts
BF601028	CAP THERMOSTAT HOUSING PLASTIC	Bajaj spare parts
BF601205	DAMPER RUBBER	Bajaj spare parts
BF601206	COLLAR	Bajaj spare parts
BF601207	THERMOSTAT ASSLY	Bajaj spare parts
BF601208	BOTTLE COOLANT	Bajaj spare parts
BF601209	PIPE BOTTLE COOLANT	Bajaj spare parts
BF601211	GROMMET RADIATOR BKT	Bajaj spare parts
BF601215	ASSLY COOLANT TANK	Bajaj spare parts
BF601216	SHROUD RADIATOR	Bajaj spare parts
BF601222	DAMPER COOLANT TANK	Bajaj spare parts
BF601223	FLAP SHROUD	Bajaj spare parts
BF601225	FOAM SHROUD BOTTOM	Bajaj spare parts
BF601226	GROMMET PIPE BOTTLE COOLANT	Bajaj spare parts
BF601227	TUBE COOLANT TANK OVERFLOW	Bajaj spare parts
BF601228	BRACKET TUBE COOLANT OVERFLOW	Bajaj spare parts

BF601229	ASSLY RADIATOR BRACKET LH	Bajaj spare parts
BF601232	ASSLY RADIATOR BRACKET RH	Bajaj spare parts
BF601238	RADIATOR COMPLETE	Bajaj spare parts
BF601403	FAN COOLING - EC	Bajaj spare parts
BF601404	SHROUD COOLING UPPER	Bajaj spare parts
BF601407	SHROUD BOTTOM	Bajaj spare parts
BF601411	GROMMET SHROUD UPPER	Bajaj spare parts
BF601414	CLUTCH ELECTROMAGNETIC	Bajaj spare parts
BF611003	GAS INJECTOR (MATRIX)	Bajaj spare parts
BF611007	PIPE INJECTOR-MANIFOLD	Bajaj spare parts
BF611009	GAUGE CNG	Bajaj spare parts
BF611012	ASSLY INJECTOR CAP	Bajaj spare parts
BF611013	INJECTOR LPG	Bajaj spare parts
BF611017	PIPE ASSEMBLY TANK-INJECTOR	Bajaj spare parts
BF611220	ASSLY THROTTLE BODY	Bajaj spare parts
BF611226	BRACKET THROTTLE BODY	Bajaj spare parts
BF611229	ASSLY THROTTLE BODY	Bajaj spare parts
BF611232	BRACKET THROTTLE BODY	Bajaj spare parts
BF611236	BRACKET ASSEMBLY BODY THROTTLE	Bajaj spare parts
BF611241	BODY THROTTLE ASSEMBLY	Bajaj spare parts
BF621400	ASSLY GEAR STARTER	Bajaj spare parts
BF621402	NEEDLE BEARING (25X32X16)	Bajaj spare parts
BF990103	BUSH BIMETALLIC	Bajaj spare parts
BG113403	BRACKET TRANS. MTG	Bajaj spare parts
BG113802	HOUSING LEFT HEADLAM	Bajaj spare parts
BG113803	HOUSING RIGHT HEAD	Bajaj spare parts
BG113804	CLAMP BRAKE PIPE	Bajaj spare parts
BG113805	TRAY BATTERY	Bajaj spare parts
BG131802	BRAKE CABL1216 FL AS	Bajaj spare parts
BG141252	RUBBER BUFFER	Bajaj spare parts
BG141253	RUBBER BUFFER	Bajaj spare parts
BG141254	BELLOW	Bajaj spare parts
BG161214	BELLOW RUBBER CONL C	Bajaj spare parts
BG171006	ASSLY FUEL TANK WELDED	Bajaj spare parts
BG171800	PIPE FUEL BREATHER	Bajaj spare parts
BG171803	PIPE FUEL PUMP ENG	Bajaj spare parts
BG171804	PIPE FUEL OVERFLOW	Bajaj spare parts
BG171805	TAP FUEL FOR FUEL TANK	Bajaj spare parts
BG221003	PAD RUBBER FOR DOOR	Bajaj spare parts
BG231602	MIRROR ASSY RH	Bajaj spare parts
BG233002	EMBLEM BAJAJ RE FOR SCUDO	Bajaj spare parts
BG351601	DUST COVER	Bajaj spare parts
BG351602	MOTOR STARTER	Bajaj spare parts
BG351603	STARTER MOTOR (LTVS)	Bajaj spare parts
BG401401	IGNITION PARKING SWITCH	Bajaj spare parts

BG402214	GLOW PLUG RELAY	Bajaj spare parts
BG402606	TANK UNIT	Bajaj spare parts
BG403206	COMBINE CONTROL	Bajaj spare parts
BG501004	GAUGE OIL	Bajaj spare parts
BG501006	PLUG	Bajaj spare parts
BG541200	CASE SPIRAL	Bajaj spare parts
BG541201	GROMMET	Bajaj spare parts
BG551011	SPRING	Bajaj spare parts
BG551205	GEAR SPEED 2	Bajaj spare parts
BG551206	GEAR SPEED 3	Bajaj spare parts
BG551207	GEAR SPEED 4	Bajaj spare parts
BG551222	GEAR SPEED 2	Bajaj spare parts
BG551223	GEAR SPEED 3	Bajaj spare parts
BG551224	GEAR SPEED 4	Bajaj spare parts
BG551406	CLUTCH ASSEMBLY COMP	Bajaj spare parts
BG551613	HOUSING SATELLITE	Bajaj spare parts
BG551614	PIN	Bajaj spare parts
BG551615	DAMPER DIFFERENTIAL	Bajaj spare parts
BG551618	HUB DIFFERENTIAL DAMPER	Bajaj spare parts
BG552600	SHAFT DRIVE FARE METER	Bajaj spare parts
BG581000	BRACKET AIR FILTER	Bajaj spare parts
BG581006	CLAMP AIR CLEANER	Bajaj spare parts
BG581400	ASSY AIR INTAKE-TOP	Bajaj spare parts
BG581401	HOSE AIR INTAKE TOP	Bajaj spare parts
BG581402	HOSE AIR INTAKE BOTTOM	Bajaj spare parts
BG581404	DAMPER RUBBER	Bajaj spare parts
BG581405	MESH AIR INTAKE	Bajaj spare parts
BH111056	RUBBER BELLOW FL	Bajaj spare parts
BH111071	CAP WIPER MOTOR BIG FL	Bajaj spare parts
BH111088	GROMMET SHIELD	Bajaj spare parts
BH111092	GROMMET WIRING HARNESS FL	Bajaj spare parts
BH111116	GROMMET HEADLAMP MOUNTING BKT FL	Bajaj spare parts
BH111131	TRAY ASSLY-BATTERY	Bajaj spare parts
BH111217	PLATE ASSEMBLY ELECTRICAL FRONT	Bajaj spare parts
BH111222	TRAY ASSEMBLY BATTERY	Bajaj spare parts
BH111224	BRACKET SENSOR PRESSURE	Bajaj spare parts
BH113407	BRACKET ENGINE MTG REAR RH FL	Bajaj spare parts
BH113408	BRACKET ENGINE MTG REAR RH FL	Bajaj spare parts
BH113409	ASSLY ENG MTG BKT FR RH FL	Bajaj spare parts
BH113410	BRACKET ENGINE MTG FRONT RH FL	Bajaj spare parts
BH113411	RUBBER ISOLATOR FL	Bajaj spare parts
BH113417	PACKING RUBBER BELOW AIR FILTER	Bajaj spare parts
BH113805	ASSLY TRAY BATTERY FL	Bajaj spare parts
BH113811	BRACKET	Bajaj spare parts
BH113812	BRACKET TANK COOLANT REAR	Bajaj spare parts

BH121002	STRAP CABLE (210X6)	Bajaj spare parts
BH121004	DAMPER FR	Bajaj spare parts
BH121005	SPRING FRONT SUSPENSION FL	Bajaj spare parts
BH122000	SPRING REAR SUSPENSION	Bajaj spare parts
BH122002	PIN ASSEMBLY PIVOT	Bajaj spare parts
BH122020	BOLT FLNGE GUID M12X1.25	Bajaj spare parts
BH122024	SPACER BUSH TRAILING ARM	Bajaj spare parts
BH122025	SLEEVE INNER TRAILING ARM	Bajaj spare parts
BH122026	BUSH IGUS TRAILING ARM	Bajaj spare parts
BH122027	PIECE DISTANCE TA IGUS	Bajaj spare parts
BH122028	SPACER RING TA IGUS	Bajaj spare parts
BH122030	STOPPER DISC TRALING ARM	Bajaj spare parts
BH122039	ASSLY TRAILING ARM LH UG	Bajaj spare parts
BH122040	ASSLY TRAILING ARM RH UG	Bajaj spare parts
BH122100	ASSLY DISTANCE PIECE TA IGUS	Bajaj spare parts
BH131002	RIM WHEEL 3.0B X 10	Bajaj spare parts
BH131006	PANEL ASSEMBLY FRONT FL	Bajaj spare parts
BH131007	CLIP BRAKE PIPE FL	Bajaj spare parts
BH131021	HUB FRONT	Bajaj spare parts
BH131023	DRUM BRAKE	Bajaj spare parts
BH131024	ASSLY DISTANCE PIECE	Bajaj spare parts
BH131029	TYRE 4.00-10 TL	Bajaj spare parts
BH131203	HUB REFL	Bajaj spare parts
BH131204	DRIVE FLANGE REFL	Bajaj spare parts
BH131206	CAP HUB REAR FL	Bajaj spare parts
BH131209	PANEL ASSEMBLY LH	Bajaj spare parts
BH131212	ASSLY BRAKE PANEL RR LH FL	Bajaj spare parts
BH131213	ASSLY BRAKE PANEL RR RH FL	Bajaj spare parts
BH131217	ASSLY DRIVE FLANGE	Bajaj spare parts
BH131220	HUB REAR	Bajaj spare parts
BH131403	BOLT SPARE WHEEL MOUNTING FL	Bajaj spare parts
BH131404	CAP SPARE WHEEL FL	Bajaj spare parts
BH131405	CAP ANTI-THEFT FL	Bajaj spare parts
BH131407	ASSLY CAP SPARE WHEEL FL	Bajaj spare parts
BH131600	ASSEMBLY SPACER FL	Bajaj spare parts
BH131802	PIPE BRAKE RR-2 RE445M FL	Bajaj spare parts
BH131803	TMC WITH HOSE FL	Bajaj spare parts
BH131804	HOSE BRAKE FRONT FL	Bajaj spare parts
BH131809	DRUM BRAKE WITH STUDS FL	Bajaj spare parts
BH131813	LEVER PARKING BRAKE LH FL	Bajaj spare parts
BH131814	LEVER PARKING BRAKE RH FL	Bajaj spare parts
BH131817	SPACER GUIDE HOSE FL	Bajaj spare parts
BH131832	ASSLY PIPE BRAKE-REAR	Bajaj spare parts
BH131834	PIPE ASSEMBLY BRAKE REAR	Bajaj spare parts
BH141224	ASSLY DRIVE SHAFT LH	Bajaj spare parts

BH141225	ASSLY DRIVE SHAFT RH	Bajaj spare parts
BH151001	FORK ASSEMBLY	Bajaj spare parts
BH151007	EN: COVER DUST LOWER FL	Bajaj spare parts
BH151008	EN: COVER DUST TOP FL	Bajaj spare parts
BH151009	SPACER FORK FRONT FL	Bajaj spare parts
BH151010	SPACER DAMPENING PLATE FL	Bajaj spare parts
BH151062	FORK ASSLY REFL	Bajaj spare parts
BH151065	STEERING PLATE UPPER	Bajaj spare parts
BH151066	STEERING PLATE LOWER	Bajaj spare parts
BH151085	RACE BEARING LOWER INNER	Bajaj spare parts
BH151087	RACE BEARING LOWER OUTER	Bajaj spare parts
BH151089	BRACKET ASSLY HOSE BRAKE	Bajaj spare parts
BH151092	RACE INNER UPPER	Bajaj spare parts
BH151093	CAGE - BALL	Bajaj spare parts
BH151094	COVER BEARING UPPER	Bajaj spare parts
BH151095	RACE OUTER UPPER	Bajaj spare parts
BH151096	RACE OUTER LOWER	Bajaj spare parts
BH151097	RACE INNER LOWER	Bajaj spare parts
BH161004	INDICATOR RING GEAR HANDLE BAR	Bajaj spare parts
BH161007	SPRING RETURN CLUTCH PEDAL FL	Bajaj spare parts
BH161009	BRACKET CLUTCH PEDAL MTG FL	Bajaj spare parts
BH161010	DAMPER OVAL PAD FL	Bajaj spare parts
BH161011	CLUTCH PEDAL CABLE HOLDER FL	Bajaj spare parts
BH161012	PIN CABLE HOLDER FL	Bajaj spare parts
BH161014	CLUTCH CABLE HOLDER FL	Bajaj spare parts
BH161017	ASSLY BKT BRAKE PEDAL MTG FL	Bajaj spare parts
BH161019	ASSLY BRAKE PEDAL WITH PAD FL	Bajaj spare parts
BH161021	PIN CABLE HOLDER FL	Bajaj spare parts
BH161027	SPRING BRAKE PEDAL	Bajaj spare parts
BH161032	BRACKET ASSLY PEDAL BRAKE	Bajaj spare parts
BH161202	SPEEDO CABL24363 COM	Bajaj spare parts
BH161203	CABLE INNER SPEEDOMETER	Bajaj spare parts
BH161208	GEAR CABL2729 COM+ D	Bajaj spare parts
BH161209	GEAR CABL2728 COM+ D	Bajaj spare parts
BH161211	CLUTCH CABL3300 COM+	Bajaj spare parts
BH161214	BRAKE CABL1251 COM+4	Bajaj spare parts
BH161215	BRAKE CABL1188 COM+4	Bajaj spare parts
BH161216	REVERS CABL2620 FL D	Bajaj spare parts
BH161217	GEAR CABL2741 COM+ D	Bajaj spare parts
BH161218	GEAR CABL2745 COM+ D	Bajaj spare parts
BH161221	NUT HEXAGON	Bajaj spare parts
BH161222	REVERS CABL2610 FL D	Bajaj spare parts
BH161223	STOP CABL3032 FL DSL	Bajaj spare parts
BH161224	DECOM CABL2576 FL DS	Bajaj spare parts
BH161225	KNOB REVERSE	Bajaj spare parts

BH161226	KNOB CABLE ENG STOP FL	Bajaj spare parts
BH161227	CLUTCH CABL2596 COM	Bajaj spare parts
BH161229	ACC CABL3090 COM+ DS	Bajaj spare parts
BH161232	CABLE ASSLY DECOMP	Bajaj spare parts
BH161234	CABLE ACCELERATOR	Bajaj spare parts
BH161235	CABLE ENG STOP COMPLETE	Bajaj spare parts
BH161236	CABLE SPEEDOMETER COMPLETE	Bajaj spare parts
BH161237	CABLE REVERSE GEAR COMPLETE	Bajaj spare parts
BH161240	CABLE INNER SPEEDOMETER	Bajaj spare parts
BH161241	CABLE GEAR WHITE COMPLETE	Bajaj spare parts
BH161242	CABLE GEAR BLACK COMPLETE	Bajaj spare parts
BH161245	CABLE CLUTCH	Bajaj spare parts
BH161246	CABLE REVERSE	Bajaj spare parts
BH161247	CABLE DECOMPRESSION	Bajaj spare parts
BH171002	ASSLY FILTER FUEL	Bajaj spare parts
BH171007	ASSLY FUEL TANK WELDED UG	Bajaj spare parts
BH171018	TANK ASSEMBLY	Bajaj spare parts
BH171601	ASSLY FUEL CAP	Bajaj spare parts
BH171602	ASSLY FUEL CAP UG	Bajaj spare parts
BH171810	EN:ASSLY PIPE FILTER-FEED PUMP	Bajaj spare parts
BH171813	PIPE FUEL BREATHER UG	Bajaj spare parts
BH171816	PIPE TANK TO FILTER	Bajaj spare parts
BH171817	SLEEVE TANK TO FILTER	Bajaj spare parts
BH171818	ASSLY PIPE TANK TO FILTER	Bajaj spare parts
BH171821	ASSLY PIPE FILTER TO PUMP	Bajaj spare parts
BH171824	ASSLY PIPE PUMP TO ENGINE	Bajaj spare parts
BH171827	ASSLY PIPE OVERFLOW	Bajaj spare parts
BH171830	PIPE ASSLY FUEL-OVERFLOW	Bajaj spare parts
BH171831	PIPE ASSEMBLY TANK-FILTER	Bajaj spare parts
BH181203	COVER SPEEDOMETER FL	Bajaj spare parts
BH181204	COUPLER BOX FL	Bajaj spare parts
BH181401	FLAP MUD	Bajaj spare parts
BH181402	PLATE FOR MUDFLAP	Bajaj spare parts
BH181405	PLATE MUDFLAP SUPPORT LH FL	Bajaj spare parts
BH181406	PLATE MUDFLAP SUPPORT RH FL	Bajaj spare parts
BH184000	GLASS GREEN WINDSHLD ONE PI	Bajaj spare parts
BH185001	GRILL AIR INTAKE SNORKEL TOP	Bajaj spare parts
BH185002	GRILL AIR INTAKE SNORKEL BOTTOM	Bajaj spare parts
BH185003	PACKING SNORKEL FL	Bajaj spare parts
BH191009	SEAT AASLY. PASSENGER	Bajaj spare parts
BH191019	BACKREST DRIVER	Bajaj spare parts
BH191022	ASSLY PASSENGER BACKREST	Bajaj spare parts
BH191024	FRAME FOR PASSENGER BACKREST	Bajaj spare parts
BH191026	FRAME DRIVER SEAT FL	Bajaj spare parts
BH191030	BASE SEAT	Bajaj spare parts

BH191032	BRACKET SEAT BASE MTG FL	Bajaj spare parts
BH191052	ASSLY FRAME DRIVER SEAT	Bajaj spare parts
BH191053	FRAME DRIVER SEAT	Bajaj spare parts
BH191061	ASSLY PASSENGER SEAT UG	Bajaj spare parts
BH191075	ASSLY FRAME DRIVER SEAT UG	Bajaj spare parts
BH191077	BRACKET ASSLY HINGE MOUNTING	Bajaj spare parts
BH211051	Bkt. hook upper door	Bajaj spare parts
BH211057	Shouldder Bolt	Bajaj spare parts
BH211077	BOLT HEX WITH FLANGE	Bajaj spare parts
BH211158	RUBBER DAMPER REAR DOOR	Bajaj spare parts
BH211163	RUBBER DAMPER	Bajaj spare parts
BH211165	KNOB REAR DOOR FL	Bajaj spare parts
BH211201	ASSLY PLATE LINK FRAME BODY	Bajaj spare parts
BH213009	FRAME HOOD	Bajaj spare parts
BH213012	HOOD COMPLETE RE445M FL	Bajaj spare parts
BH232600	LOCK SET	Bajaj spare parts
BH232604	LOCK SET RE445X FL	Bajaj spare parts
BH233005	EMBLEM	Bajaj spare parts
BH233012	LABEL BS4-MAXIMA Z	Bajaj spare parts
BH241400	Hinge Door Rear	Bajaj spare parts
BH241402	CABLE DOOR HOLDING	Bajaj spare parts
BH241800	LATCH DOOR	Bajaj spare parts
BH351400	ECU EMS ASSEMBLY	Bajaj spare parts
BH401004	Lamp rear No. plate	Bajaj spare parts
BH401005	HARNESS WIRING TAIL LIGHT LH	Bajaj spare parts
BH401006	HARNESS WIRING TAIL LIGHT RH	Bajaj spare parts
BH401010	SPEEDOMETER COMP WITH LAMP	Bajaj spare parts
BH401016	LAMP PLATE NUMBER	Bajaj spare parts
BH401400	SWITCH REVERSE	Bajaj spare parts
BH401401	SWITCH CONTROL RH	Bajaj spare parts
BH402209	CABLE BATTERY RE 445 M FL	Bajaj spare parts
BH402220	ASSLY FUSE BOX BLADE TYPE FL	Bajaj spare parts
BH402224	HARNESS WIRING FRONT 445X FL	Bajaj spare parts
BH402225	HARNESS WIRING REAR RE445X FL	Bajaj spare parts
BH402231	HARNESS WIRING FRONT	Bajaj spare parts
BH402235	HARNESS WIRING REAR UG	Bajaj spare parts
BH402236	HARNESS FRONT RE COMPACT+ DIESEL	Bajaj spare parts
BH402237	HARNESS REAR RE COMPACT+DIESEL	Bajaj spare parts
BH402239	CABLE BATTERY	Bajaj spare parts
BH402241	CABLE BATTERY	Bajaj spare parts
BH402242	HARNESS WIRING FRONT	Bajaj spare parts
BH402243	CABLE BATTERY	Bajaj spare parts
BH402244	HARNESS WIRING REAR-DIESEL	Bajaj spare parts
BH402246	HARNESS WIRING FRONT	Bajaj spare parts
BH402247	HARNESS WIRING REAR	Bajaj spare parts

BH402248	CABLE BATTERY	Bajaj spare parts
BH402253	CABLE EARTH	Bajaj spare parts
BH402255	HARNESS WIRING FRONT	Bajaj spare parts
BH402256	HARNESS WIRING REAR	Bajaj spare parts
BH402260	HARNESS WIRING REAR	Bajaj spare parts
BH402266	HARNESS WIRING REAR	Bajaj spare parts
BH402267	HARNESS WIRING FRONT	Bajaj spare parts
BH402402	INSTRUMENT CLUSTER	Bajaj spare parts
BH402600	TANK UNIT	Bajaj spare parts
BH402601	INDICATOR RH POD	Bajaj spare parts
BH402602	HARNESS WIRING FOR IND RH POD	Bajaj spare parts
BH402607	Sensor Level Fuel	Bajaj spare parts
BH402608	INDICATOR TELL-TALE	Bajaj spare parts
BH403600	CABLE SENSOR TEMPERATURE	Bajaj spare parts
BH501022	ASSLY ENGINE BS4	Bajaj spare parts
BH541003	CRANKCASE	Bajaj spare parts
BH551004	ASSLY TRANSMISSION	Bajaj spare parts
BH551400	SHAFT CLUTCH	Bajaj spare parts
BH551402	SPRING CLUTCH LEVER	Bajaj spare parts
BH551403	LEVER CLUTCH	Bajaj spare parts
BH551404	BRACKET CLUTCH CABLE	Bajaj spare parts
BH551408	OBJ TULIP	Bajaj spare parts
BH551409	SPRING	Bajaj spare parts
BH551410	CIRCLIP	Bajaj spare parts
BH551411	TRIPOD FINISHED	Bajaj spare parts
BH551412	ROLLER FINISHED	Bajaj spare parts
BH551413	RETAINER SHEET	Bajaj spare parts
BH551420	PLUG	Bajaj spare parts
BH551421	DUSTSHIELD	Bajaj spare parts
BH551427	LEVER CLUTCH	Bajaj spare parts
BH551429	BRACKET CABLE CLUTCH	Bajaj spare parts
BH551614	GEAR DIFFERENTIAL DAMPER	Bajaj spare parts
BH551615	GEAR SUN LH	Bajaj spare parts
BH551616	GEAR SUN RH	Bajaj spare parts
BH551617	ASSEMBLY DIFFERENTIAL DAMPER	Bajaj spare parts
BH551618	PINION DIFFERENTIAL DAMPER	Bajaj spare parts
BH551800	CLIP LOCK DRIVE SHAFT	Bajaj spare parts
BH552005	HOUSING MAIN-5 SPEED	Bajaj spare parts
BH581005	ELBOW RUBBER LOWER EN	Bajaj spare parts
BH581010	Clip elbow lower end	Bajaj spare parts
BH581014	PIPE AIR INTAKE-I	Bajaj spare parts
BH581015	RUBBER ELBOW CHASSIS END LH	Bajaj spare parts
BH581016	PIPE AIR INTAKE	Bajaj spare parts
BH581019	PIPE AIR INTAKE-2	Bajaj spare parts
BH581020	FILTER ASSEMBLY AIR	Bajaj spare parts



BH581021	TUBE AIR INTAKE	Bajaj spare parts
BH581023	ELBOW RUBBER LOWER	Bajaj spare parts
BH581024	ELBOW RUBBER UPPER	Bajaj spare parts
BH581025	ELBOW RUBBER TOP	Bajaj spare parts
BH581027	PIPE AIR INTAKE UPPER	Bajaj spare parts
BH581028	HOSE RUBBER TOP	Bajaj spare parts
BH591001	SILENCER	Bajaj spare parts
BH591004	ASSLY SILENCER COMPLETE	Bajaj spare parts
BH591006	SILENCER ASSEMBLY	Bajaj spare parts
BH591007	MUFFLER ASSEMBLY	Bajaj spare parts
BH591013	CATALYST ASSEMBLY	Bajaj spare parts
BH591024	PIPE ASSEMBLY MANIFOLD-SENSOR	Bajaj spare parts
BH591027	PIPE MANIFOLD-SENSOR PRESSURE II	Bajaj spare parts
BH591028	BRACKET	Bajaj spare parts
BH601003	PIPE COOLANT	Bajaj spare parts
BH601006	PIPE ASSLY COOLANT INLET	Bajaj spare parts
BH601007	PIPE ASSEMBLY COOLANT OUTLET	Bajaj spare parts
BH601008	BRACKET VALVE NON RETURN	Bajaj spare parts
BH611400	LIMITER DEVICE ASSLY - FUEL	Bajaj spare parts
BJ551003	BUSH 4TH DRIVE	Bajaj spare parts
BJ551004	BUSH 5TH DRIVE	Bajaj spare parts
BJ551005	BUSH 3RD DRIVEN	Bajaj spare parts
BJ551006	SHAFT INPUT	Bajaj spare parts
BJ551009	SHAFT -OUTPUT	Bajaj spare parts
BJ551200	GEAR 3RD INPUT	Bajaj spare parts
BJ551201	GEAR 5TH INPUT	Bajaj spare parts
BJ551202	GEAR 3RD OUTPUT	Bajaj spare parts
BJ551203	GEAR 5H OUTPUT	Bajaj spare parts
BJ551204	GEAR -INPUT-4TH	Bajaj spare parts
BK121002	SHOCKABSORBER FRONT	Bajaj spare parts
BK121003	SPRING SHOCKABSORBER FRONT	Bajaj spare parts
BK122000	SHOCKABSORBER REAR	Bajaj spare parts
BK291001	ASSEMBLY POWER PACK	Bajaj spare parts
BK301200	MOTOR DRIVE	Bajaj spare parts
BK401802	CHARGER BATTERY	Bajaj spare parts
BK402245	HARNESS WIRING REAR	Bajaj spare parts
BK402250	CABLE CHARGER MAINS	Bajaj spare parts
BK402267	HARNESS WIRING REAR	Bajaj spare parts
BK402269	BOX ASSEMBLY JUNCTION	Bajaj spare parts
BK402275	BOX ASSEMBLY JUNCTION	Bajaj spare parts
CB101009	SEAL STEM VALVE	Bajaj spare parts
CB101022	VALVE COTTER	Bajaj spare parts
CB101082	BUSH REAR CUSHION	Bajaj spare parts
CB101114	GASKET PIPE EXHAUST	Bajaj spare parts
CB111008	CAP SPARK PLUG	Bajaj spare parts

CB121042	SCREW	Bajaj spare parts
CB121046	SCERW	Bajaj spare parts
CB151027	WASHER A SPEEDO GEAR	Bajaj spare parts
CB161105	NUT CLIP M5	Bajaj spare parts
CB201026	RELAY STARTER	Bajaj spare parts
CD101008	CYL BLOCK ASSY 3WH-2S	Bajaj spare parts
CD101079	GASKET BLOCK CYLINDER	Bajaj spare parts
CD101080	GASKET HOUSING GEAR SHIFT	Bajaj spare parts
CD101082	CRANKSHAFT ASSLY	Bajaj spare parts
CD101102	BUFFER KICK	Bajaj spare parts
CD201019	LAMP HEAD BRAVO	Bajaj spare parts
CE181015	NUT CLIPM4X0.7FR BLNK H'B	Bajaj spare parts
CF111019	PLUG SPARK UR4AC	Bajaj spare parts
CL201023	LAMP 12V 35/35WHS1 USA	Bajaj spare parts
CL201042	"LAMP 12V 1.7W,"	Bajaj spare parts
CM101129	WASHER - PLAIN	Bajaj spare parts
CM191049	SPRING CLIP	Bajaj spare parts
CM201054	"LAMP12V2W,WITHOUT"	Bajaj spare parts
CS101044	BEARING - NEEDLE:-BIG END (25 X 32 X 16)	Bajaj spare parts
CS101128	GASKET	Bajaj spare parts
CS101419	PLUG OIL-M8X1.25XL12XCL6.8XBLACK	Bajaj spare parts
CS121022	ROTOR OIL PU P INNER WAVE	Bajaj spare parts
CS141005	WASHER CAP FUEL TANK	Bajaj spare parts
CS141006	CAP TANK FUEL	Bajaj spare parts
CX141044	BALL STEEL	Bajaj spare parts
CX141045	SPACER	Bajaj spare parts
CX141046	RING O	Bajaj spare parts
CX201014	FUSE BOX	Bajaj spare parts
CZ131004	VALVE TYRE TUBELESS	Bajaj spare parts
CZ181407	PLUG	Bajaj spare parts
CZ181410	BOLT STEP FOR FRONT MUDGUARD MTG	Bajaj spare parts
CZ541005	"BOLT SPL, STAND SPRING MTG"	Bajaj spare parts
DB111007	CAP SPARK PLUG SEALED	Bajaj spare parts
DD101007	GASKET CYLINDER BLOCK	Bajaj spare parts
DD101014	RING SET PISTON STD CAL	Bajaj spare parts
DD101062	BOLT	Bajaj spare parts
DD101063	CAMSHAFT ASSY BOXER AR	Bajaj spare parts
DD101067	SPRING	Bajaj spare parts
DD101068	SPRING BELEVILLE	Bajaj spare parts
DD101097	DAMPER	Bajaj spare parts
DD101101	CRANKCASE LH BOXER AR / C	Bajaj spare parts
DD101105	CYL BLOCK ASSY CALIBE	Bajaj spare parts
DD101134	VALVE INTAKE CALIBER / CT100	Bajaj spare parts
DD101135	VALVE EXHAUST CAL/ CT 100	Bajaj spare parts
DD101211	SPRING STIFFER	Bajaj spare parts

DD101219	TUBE - RUBBER	Bajaj spare parts
DD101254	GUIDE KICK	Bajaj spare parts
DD101264	SCREW PAN CROSS	Bajaj spare parts
DD101309	BUSHING-FIRST GEAR	Bajaj spare parts
DD101318	BOLT PRECOATED	Bajaj spare parts
DD101325	CAP FILLER OIL	Bajaj spare parts
DD101336	LEVER CHANGE SHAFT	Bajaj spare parts
DD101343	GASKET HEAD CYLINDER	Bajaj spare parts
DD101347	BOLT	Bajaj spare parts
DD101349	BOLT	Bajaj spare parts
DD101350	STUD - M6	Bajaj spare parts
DD101366	BOLT FLANGE MTG SIL	Bajaj spare parts
DD101407	TENSIONER ASSY	Bajaj spare parts
DD101440	SPRING STIFFER	Bajaj spare parts
DD101475	WASHER SPECIAL	Bajaj spare parts
DD101478	CYL BLOCK ASY CALBER PUP	Bajaj spare parts
DD101481	DAMPER CYL HEAD	Bajaj spare parts
DD101492	WHEEL CL.ACL/CT 100	Bajaj spare parts
DD101493	HUB CLUTCH CALIBER	Bajaj spare parts
DD101495	LEVER CHGE WITH DAMPR	Bajaj spare parts
DD101517	GASKET OIL PIPE	Bajaj spare parts
DD101521	"WASHER CYL.HEAD,COPPER "	Bajaj spare parts
DD111011	GROMMET CAP SPARK PLUG	Bajaj spare parts
DD111012	GROMMET CABLE H. T.	Bajaj spare parts
DD111018	PLUG SPARK BOXER /CAL115/	Bajaj spare parts
DD111041	ROTOR ASSLY (FOR `CALIBER - 115')	Bajaj spare parts
DD111042	CDI WITH DAMPER CAL115	Bajaj spare parts
DD111048	CAP SPARK PLUG RESI	Bajaj spare parts
DD121007	BOLT M8 X 1.25 P X L 20	Bajaj spare parts
DD121013	FILTER FUEL	Bajaj spare parts
DD121142	CARBURETTOR CAL115	Bajaj spare parts
DD121168	VALVE FLOAT CALIBER115	Bajaj spare parts
DD121171	SCREW CARB CAL 115	Bajaj spare parts
DD121181	ELEMENT OIL FILTER	Bajaj spare parts
DD141024	CAP TANK	Bajaj spare parts
DD141055	ROTOR WITH KEY CALIBER	Bajaj spare parts
DD141227	BOLT FLANGED HEAD	Bajaj spare parts
DD141228	LABEL UNLEADED F	Bajaj spare parts
DD151008	LEVER BRAKE CAM	Bajaj spare parts
DD151009	INDICATOR FOR FRONT	Bajaj spare parts
DD151014	ROD TORQUE	Bajaj spare parts
DD161013	GROMMET FENDERR	Bajaj spare parts
DD161022	DAMPER FOR SIDE COVER	Bajaj spare parts
DD161038	CLAMP FRONT FENDER	Bajaj spare parts
DD161051	FLAP FOR FENDER - REAR :- FRONT	Bajaj spare parts

DD161052	BRACKET - ENGINE	Bajaj spare parts
DD161053	BRACKET ENGINE	Bajaj spare parts
DD161071	NUT U M10 X 1.25 6.5 H	Bajaj spare parts
DD161078	DAMPER	Bajaj spare parts
DD161107	LOCK SIDE COVER WITH KEY	Bajaj spare parts
DD161381	PIN STEP PILLION	Bajaj spare parts
DD181011	SEAL DUST	Bajaj spare parts
DD181029	PIPE INNER FORK CALIBER	Bajaj spare parts
DD181031	PIPE LH FORK OUTER CALIBE	Bajaj spare parts
DD181032	SEAL DUST CALIBER	Bajaj spare parts
DD181034	PIPE FORK OUTER RH CALIBE	Bajaj spare parts
DD181090	COVER TRAIL B CALIBER / C	Bajaj spare parts
DD181091	COVER TRAILCALIBER / CT 1	Bajaj spare parts
DD181108	DAMPER ASSY BR DRUM	Bajaj spare parts
DD181161	WINDSHIELD CAL 115	Bajaj spare parts
DD181162	FLAP COWLING	Bajaj spare parts
DD181176	BRACKET PLATE NUMBER	Bajaj spare parts
DD181183	BRACKET COWLING LOW	Bajaj spare parts
DD181184	BRACKET FORK LOWER	Bajaj spare parts
DD181186	COLLAR	Bajaj spare parts
DD181187	PLATE BRACKET NUMBER	Bajaj spare parts
DD181192	BRACKET SIGNAL	Bajaj spare parts
DD181200	WINDSHIELD CALIBER	Bajaj spare parts
DD181205	HOLDER FORK UPER	Bajaj spare parts
DD181207	HOLDER FORK UNDER	Bajaj spare parts
DD181247	BRACKET -COWLING:LOWR-PHILLIPINES:EXPORT	Bajaj spare parts
DD181252	LABEL - 'bajaj' WITH NEW 'B BAJAJ' LOGO	Bajaj spare parts
DD191006	CABLE SPEEDO CALIBER	Bajaj spare parts
DD191015	CLAMP RUBBER	Bajaj spare parts
DD191019	CABLE INNER Br.Boxr	Bajaj spare parts
DD191080	LEVER GRIP RH	Bajaj spare parts
DD191125	CABLE STA PLSR/CAL115	Bajaj spare parts
DD191131	CABLE CLUTCH CAL115	Bajaj spare parts
DD191132	CABLE ACCELERATOR TRICS C	Bajaj spare parts
DD191141	HOLDER LEVER RH	Bajaj spare parts
DD191142	LEVER GRIP RH	Bajaj spare parts
DD191144	BOOT FOR LEVER LH	Bajaj spare parts
DD191147	SCREW FOR CABLE ADJUSTER	Bajaj spare parts
DD191148	LEVER GRIP LH	Bajaj spare parts
DD201002	REFLECTOR REFLEX	Bajaj spare parts
DD201009	DAMPER	Bajaj spare parts
DD201010	DAMPER	Bajaj spare parts
DD201011	DAMPER	Bajaj spare parts
DD201024	CONDENSER	Bajaj spare parts
DD201072	SWITCH IGNITION CALIBER	Bajaj spare parts

DD201155	SWITCH CON LH CAL115C	Bajaj spare parts
DD201167	LAMP HEAD CALIBER	Bajaj spare parts
DD201170	SWITCH WITH LEVER	Bajaj spare parts
DD221003	PLUG	Bajaj spare parts
DD70013N	CRANKCASE CASE LH GREY CA	Bajaj spare parts
DD70023N	TENSIONER ADVIK GRI GRAY	Bajaj spare parts
DE151006	SPACER ASSY	Bajaj spare parts
DE151008	SEAL OIL	Bajaj spare parts
DE151011	GEAR SPEEDOMETER	Bajaj spare parts
DE151012	PLATE DRIVE GEAR SPEEDOME	Bajaj spare parts
DE151013	DISC KBX PULSAR	Bajaj spare parts
DE151014	CALIPER ASSY BRAKE FR	Bajaj spare parts
DE151015	CYLINDER MASTER FR KBX	Bajaj spare parts
DE151037	KIT DISC PAD PUL DTSI	Bajaj spare parts
DE151041	CLIP - LOCKING :- KBX	Bajaj spare parts
DE151043	INSULATOR KBX	Bajaj spare parts
DE151045	COVER DUST KBX	Bajaj spare parts
DE151046	SCREW BLEEDER KBX	Bajaj spare parts
DE151047	CAP BLEEDER KBX	Bajaj spare parts
DE151048	PAD SPRING KBX	Bajaj spare parts
DE151051	KIT MINOR CALIPER CAL115	Bajaj spare parts
DE151052	KIT MAJOR CALIPER	Bajaj spare parts
DE181031	SPRING-FRONT FORK	Bajaj spare parts
DE191009	LEVER GRIP RH DISC BRAK	Bajaj spare parts
DE191010	WASHER COPPER KBX	Bajaj spare parts
DE191020	SEALPRIMARYPISTON	Bajaj spare parts
DE191021	SEALSECONDPISTON	Bajaj spare parts
DE191023	SPRING RETURN	Bajaj spare parts
DE191024	CIRCLIP	Bajaj spare parts
DE191025	ROD PUSH	Bajaj spare parts
DE191028	DIAPHRAGM	Bajaj spare parts
DE191029	COVER RESERVOIR	Bajaj spare parts
DE191030	SCREW COVER MASTER CYLIN	Bajaj spare parts
DE191031	BOLT PIVOT	Bajaj spare parts
DE191032	NUT PIVOT	Bajaj spare parts
DE191033	CLAMP HOLDER RH	Bajaj spare parts
DE191034	SCREW CLAMP HOLDER RH	Bajaj spare parts
DE191036	WINDOW FOR MASTER CYLINDE	Bajaj spare parts
DE191043	KIT MAJOR MASTER CYL	Bajaj spare parts
DE191044	KIT BRAKEHOSE	Bajaj spare parts
DF101055	SCREW TAPPET	Bajaj spare parts
DF111015	MAGNETO ASSY BOXER / CT 1	Bajaj spare parts
DF111020	COUPLER STARTER ASSLY	Bajaj spare parts
DF111033	COIL H.T.SINGLEPOINTBOXER	Bajaj spare parts
DF111040	COIL - H. T. WITH EXTENDED I CORE	Bajaj spare parts

DF121003	PUMP OIL BOXER/CAL/WIND/C	Bajaj spare parts
DF121011	PUMP ASSLY OIL (FOR M	Bajaj spare parts
DF121023	AIR FILTER ASSY BOXER	Bajaj spare parts
DF141115	SEATLAB	Bajaj spare parts
DF141120	CAP ASSY FUELTANK	Bajaj spare parts
DF141128	DAMPER FUEL TANK	Bajaj spare parts
DF141129	DAMPER FUEL TANK	Bajaj spare parts
DF151003	DRUM BRAKE FR BOXER AR /	Bajaj spare parts
DF151014	PANEL ASSLY - BRAKE :- REAR	Bajaj spare parts
DF151016	ROD TORQUE	Bajaj spare parts
DF161102	BOLT FOR SIDE STAND	Bajaj spare parts
DF161104	FENDER RR BOXER AR	Bajaj spare parts
DF161159	BRACE FENDER REAR	Bajaj spare parts
DF161168	BRACKET-ENG UPPE RH	Bajaj spare parts
DF161242	FENDER FR BOXER	Bajaj spare parts
DF161245	MUDFLAP FRONT	Bajaj spare parts
DF161248	BRACKET RR NO. PLATE	Bajaj spare parts
DF161252	PLATE NUMBER REAR IN BLACK	Bajaj spare parts
DF161413	DAMPER STEP FRONT PVC	Bajaj spare parts
DF161415	BEADING CHAIN CASE	Bajaj spare parts
DF161416	CAP - CASE CHAIN	Bajaj spare parts
DF161425	HOLDER STEP	Bajaj spare parts
DF161426	BOLT STEPPED +FLANGE	Bajaj spare parts
DF181024	LOCK SET BYK	Bajaj spare parts
DF181059	WINDSHIELD BOXER	Bajaj spare parts
DF181085	SEAT SPRING FORK BKT UPPER	Bajaj spare parts
DF181088	DAMPER -FORK COVR FOR FR.	Bajaj spare parts
DF181089	WASHER PLAIN	Bajaj spare parts
DF181090	NUT STEERING BEARING	Bajaj spare parts
DF181091	DAMPER HANDLE HOLDER	Bajaj spare parts
DF181092	DAMPER HANDLE HOLDER	Bajaj spare parts
DF181097	BRACKET PLATE NO. FRONT	Bajaj spare parts
DF181098	SCREW SS M5 X L 14	Bajaj spare parts
DF181117	HANDLEBAR BOXER	Bajaj spare parts
DF191020	CLAMP	Bajaj spare parts
DF191026	GRIP - LEFT HAND	Bajaj spare parts
DF191027	GRIP ASSY RIGHT HAND	Bajaj spare parts
DF191046	LEVER-CHOKE	Bajaj spare parts
DF191066	LEVER RH	Bajaj spare parts
DF201053	SWITCH CONTROL RH	Bajaj spare parts
DF201058	HOLDER ASSY LAMP BOXER UG	Bajaj spare parts
DF201121	REGULATOR RECTIFIER UNIT	Bajaj spare parts
DF201138	LAMP TAIL BOXER	Bajaj spare parts
DF221007	MIRROR ASSY RH BOXER AR	Bajaj spare parts
DF221037	MIRROR ASSLY-LH	Bajaj spare parts

DG010014	HOSEBRAKE KIT	Bajaj spare parts
DG101029	COLLET	Bajaj spare parts
DG101187	BOLT	Bajaj spare parts
DG101263	CLAMP	Bajaj spare parts
DG101275	WASHER	Bajaj spare parts
DG101285	BOLT FOR SILENCER	Bajaj spare parts
DG101339	DAMPER	Bajaj spare parts
DG101417	GASKET EXHAUST	Bajaj spare parts
DG101418	GAUGE	Bajaj spare parts
DG101419	BUSHING RUBBER	Bajaj spare parts
DG101456	SEAL - OIL	Bajaj spare parts
DG101498	GASKET	Bajaj spare parts
DG111008	PLUG SPARK PULSAR DTSI	Bajaj spare parts
DG121002	CLIP SPRING	Bajaj spare parts
DG121003	CLAMP	Bajaj spare parts
DG121010	ELEMENT AIR FILTER	Bajaj spare parts
DG121012	GASKET	Bajaj spare parts
DG121040	CLAMP	Bajaj spare parts
DG141017	ROTOR	Bajaj spare parts
DG141019	DAMPER	Bajaj spare parts
DG141020	BRACKET	Bajaj spare parts
DG141024	PLUG	Bajaj spare parts
DG141026	BOLT	Bajaj spare parts
DG141027	WASHER	Bajaj spare parts
DG141029	TUBE FUEL GAUGE	Bajaj spare parts
DG141052	CAP TANK FROM M/S	Bajaj spare parts
DG141059	TRIM	Bajaj spare parts
DG151003	DRUM BRAKE FR ELIMINATOR	Bajaj spare parts
DG151005	SEAL OIL	Bajaj spare parts
DG151006	AXLE	Bajaj spare parts
DG151007	COLLAR	Bajaj spare parts
DG151008	WASHER	Bajaj spare parts
DG151009	CASE METER GEAR ELIMINATO	Bajaj spare parts
DG151022	BAND - RIM	Bajaj spare parts
DG151025	SPOKE INNER ELIMINATOR	Bajaj spare parts
DG151026	SPOKE OUTER ELIMINATOR	Bajaj spare parts
DG151058	SPRING	Bajaj spare parts
DG151059	CAM BRAKE	Bajaj spare parts
DG151060	LEVER BRAKE CAM	Bajaj spare parts
DG151062	COLLAR	Bajaj spare parts
DG151065	SLEEVE	Bajaj spare parts
DG151066	NUT	Bajaj spare parts
DG151067	COLLAR	Bajaj spare parts
DG151068	BOLT D-M8X1.25XL 41XCL9.8XBRIGHT	Bajaj spare parts
DG151075	SPOKE INNER ELIMINATOR	Bajaj spare parts

DG151076	SPOKE OUTER ELIMINATOR	Bajaj spare parts
DG151081	PANEL BRAKE REAR	Bajaj spare parts
DG151084	DRUM BRAKE RR ELIMINATOR	Bajaj spare parts
DG151085	COLLAR ASSEMBLY	Bajaj spare parts
DG151089	CALIPER ASSLY BREAK	Bajaj spare parts
DG151093	RIM 1.85 X 17 ELIMINATOR	Bajaj spare parts
DG151094	RIM 2.75 X 15 ELIMINATOR	Bajaj spare parts
DG151096	SHOE BRAKE ELIMINATOR	Bajaj spare parts
DG151102	DISC KBX	Bajaj spare parts
DG161108	DAMPER	Bajaj spare parts
DG161110	BOLT	Bajaj spare parts
DG161113	BOLT	Bajaj spare parts
DG161117	SCREW	Bajaj spare parts
DG161118	GROMMET	Bajaj spare parts
DG161120	CASE CHAIN	Bajaj spare parts
DG161121	SCREW	Bajaj spare parts
DG161124	DAMPER	Bajaj spare parts
DG161129	BOLT	Bajaj spare parts
DG161143	STEP RUBBER	Bajaj spare parts
DG161144	BOLT	Bajaj spare parts
DG161145	PIN	Bajaj spare parts
DG161146	SPRING - L	Bajaj spare parts
DG161147	SPRING - R	Bajaj spare parts
DG161152	STEP RUBBER	Bajaj spare parts
DG161153	BOLT SOCKET HEAD	Bajaj spare parts
DG161154	CAP PIVOT	Bajaj spare parts
DG161165	CAP TOOL CASE	Bajaj spare parts
DG161168	LOCK COVER SIDE	Bajaj spare parts
DG161182	COVER LH FENDER RR	Bajaj spare parts
DG161183	COVER RH FENDER RR	Bajaj spare parts
DG161186	STEP FRONT LH ELIMINATO	Bajaj spare parts
DG161187	STEP FRONT RH ELIMINATO	Bajaj spare parts
DG161189	PIN	Bajaj spare parts
DG161209	LABEL - INSTRUCTION FOR TYRE PRESSURE	Bajaj spare parts
DG161219	SPRING	Bajaj spare parts
DG161220	COVERSIDE RH FRELIMINATOR	Bajaj spare parts
DG161222	BOLT PRECOATED	Bajaj spare parts
DG161224	DAMPER	Bajaj spare parts
DG161225	DAMPER	Bajaj spare parts
DG161230	SHAFT STAND	Bajaj spare parts
DG161267	FLAP	Bajaj spare parts
DG161276	DAMPER(STAND SIDE)	Bajaj spare parts
DG171015	SHAFT SWING ARM	Bajaj spare parts
DG171016	SLEEVE	Bajaj spare parts
DG171018	BEARING NEEDLE	Bajaj spare parts



DG171019	SEAL OIL	Bajaj spare parts
DG171020	CAP CHAIN ADJUSTER	Bajaj spare parts
DG171022	NUT	Bajaj spare parts
DG171025	WASHER	Bajaj spare parts
DG171034	GUARD	Bajaj spare parts
DG171035	COLLAR SHOCKABSORBER	Bajaj spare parts
DG171036	DAMPER UPPER	Bajaj spare parts
DG171037	DAMPER LOWER	Bajaj spare parts
DG171038	BOLT PRECOATED	Bajaj spare parts
DG181003	WASHER	Bajaj spare parts
DG181004	SEAL OIL	Bajaj spare parts
DG181008	BOLT SOCKET	Bajaj spare parts
DG181010	PIPE FORK INNER	Bajaj spare parts
DG181011	BUSHING PIPE INNER	Bajaj spare parts
DG181013	BUSHING PIPE OUTER	Bajaj spare parts
DG181014	SPRING FRONT FORK ELIMIN	Bajaj spare parts
DG181015	SEAT - FORK SPRING	Bajaj spare parts
DG181019	SPRING FRONT K	Bajaj spare parts
DG181021	SEAL DUST ELIMINATOR	Bajaj spare parts
DG181022	RING SNAP	Bajaj spare parts
DG181023	SEAL OIL	Bajaj spare parts
DG181024	SPACER	Bajaj spare parts
DG181025	BOLT FRONT FORK	Bajaj spare parts
DG181026	RING - O	Bajaj spare parts
DG181028	CYLINDER COMPLETE - FORK	Bajaj spare parts
DG181034	CLAMP RUBBER	Bajaj spare parts
DG181040	CLAMP	Bajaj spare parts
DG181041	CLAMP	Bajaj spare parts
DG181053	WASHER	Bajaj spare parts
DG181054	DAMPER HANDLE HOLDER	Bajaj spare parts
DG181055	CAP STEERING LOCK	Bajaj spare parts
DG181057	SCREW	Bajaj spare parts
DG181058	WASHER - WAVE	Bajaj spare parts
DG181059	SPRING	Bajaj spare parts
DG181067	HOLDER HANDLE UPPER	Bajaj spare parts
DG181070	HOLDER HANDLE LOWER	Bajaj spare parts
DG181071	HOLDER HANDLE LOWER	Bajaj spare parts
DG181085	NUT	Bajaj spare parts
DG181087	NUT-U WITH CAP	Bajaj spare parts
DG181091	HOLDER K UPP	Bajaj spare parts
DG181093	COVER FORK ELIMINATOR	Bajaj spare parts
DG181099	BRACKET - NUMBER PLATE (FRONT)	Bajaj spare parts
DG181102	OUTER TUBE RH PC	Bajaj spare parts
DG181104	LOCK STEERING 1000 COMB.E	Bajaj spare parts
DG191010	LEVER GRIP LH	Bajaj spare parts

DG191012	LEVER GRIP LH	Bajaj spare parts
DG191013	BOLT	Bajaj spare parts
DG191014	NUT U M6 X 1	Bajaj spare parts
DG191045	WASHER	Bajaj spare parts
DG191046	SPRING	Bajaj spare parts
DG191048	BOLT	Bajaj spare parts
DG191050	PIN	Bajaj spare parts
DG191051	PIN	Bajaj spare parts
DG191064	NUT - FLANGE	Bajaj spare parts
DG191065	WASHER	Bajaj spare parts
DG191080	HOLDER LEVER LH	Bajaj spare parts
DG191086	CABLE ACCELERATOR ELIMINA	Bajaj spare parts
DG191087	CABLE ACCELERATOR ELIMIN	Bajaj spare parts
DG201023	PLUG	Bajaj spare parts
DG201027	MAT	Bajaj spare parts
DG201030	SWITCH ELIMINATOR	Bajaj spare parts
DG201049	LENS LAMP TAIL RED ELIMIN	Bajaj spare parts
DG201050	LENS CLEAR TAIL	Bajaj spare parts
DG201057	COLLAR FOR HEAD LIGHT	Bajaj spare parts
DG201061	SWITCH RR BRAKE ELIMINATO	Bajaj spare parts
DG201071	"LAMP 12V, 60 / 55 W"	Bajaj spare parts
DG201076	SCREW TAIL LIGHT LEN	Bajaj spare parts
DG201084	FUSE 30 AMPS BLADE TYPE	Bajaj spare parts
DG221010	SCREW	Bajaj spare parts
DG221016	GRIP FRAME LEFT	Bajaj spare parts
DG221019	GRIP FRAME RIGHT	Bajaj spare parts
DG221022	GRIP FRAME REAR	Bajaj spare parts
DG221027	PAD SEAT	Bajaj spare parts
DG221028	COVER SEAT PAD	Bajaj spare parts
DG221031	COVER GRIP FRAME LH	Bajaj spare parts
DG221032	COVER GRIP FRAME RH	Bajaj spare parts
DG221033	GUARD SARI ELIMINATOR	Bajaj spare parts
DG221038	GUARD FOR MUFFLER	Bajaj spare parts
DG221041	SCREW :- M2 X 0.4	Bajaj spare parts
DH010108	DECAL TANK SPOILR UPPER BLACK LH	Bajaj spare parts
DH010109	DECAL TANK SPOILR UPPER BLACK RH	Bajaj spare parts
DH010120	DECAL WHEEL FRONT LH	Bajaj spare parts
DH010121	DECAL WHEEL FRONT RH	Bajaj spare parts
DH010130	DECAL FLAP TANK UPPER LH BLUEDECAL FLAP	Bajaj spare parts
DH010131	DECAL FLAP TANK UPPER RH BLUEDECAL FLAP	Bajaj spare parts
DH010142	DECAL WHEEL LH BLUE	Bajaj spare parts
DH010143	DECAL WHEEL RH BLUE	Bajaj spare parts
DH010155	DECAL FLAP TANK UPPER LH RED	Bajaj spare parts
DH010156	DECAL FLAP TANK UPPER RH RED	Bajaj spare parts
DH010167	DECAL WHEEL LH RED	Bajaj spare parts

DH010168	DECAL WHEEL RH RED	Bajaj spare parts
DH010179	DECAL TANK UPPER LH BLACK-SILVER	Bajaj spare parts
DH010182	DECAL TANK MIDDLE RH BLK-SILVER	Bajaj spare parts
DH010184	DECAL TANK LOWER RH BLACK-SILVER	Bajaj spare parts
DH010185	DECAL TANK SPOILER LH BLK-SILVER	Bajaj spare parts
DH010186	DECAL TANK SPOILER RH BLK-SILVER	Bajaj spare parts
DH010187	DECAL COVER SIDE LH BLACK-SILVER	Bajaj spare parts
DH010188	DECAL COVER SIDE RH BLACK-SILVER	Bajaj spare parts
DH010189	DECAL COWL SEAT UPR LH BLK-SILVR	Bajaj spare parts
DH010197	DECAL TANK MIDDLE LH BLUE-SILVER	Bajaj spare parts
DH010201	DECAL TANK SPOILER LH BLUE-SILVR	Bajaj spare parts
DH010202	DECAL TANK SPOILER RH BLUE-SILVR	Bajaj spare parts
DH010209	DECAL WHEEL LH SILVER	Bajaj spare parts
DH010210	DECAL WHEEL RH SILVER	Bajaj spare parts
DH010211	DECAL FAIRING LH RED-SILVER	Bajaj spare parts
DH010212	DECAL FAIRING RH RED-SILVER	Bajaj spare parts
DH010219	DECAL SPOILER TANK LH RED-SILVER	Bajaj spare parts
DH010220	DECAL SPOILER TANK RH RED-SILVER	Bajaj spare parts
DH010221	DECAL COVER SIDE LWR LH RED-SLVR	Bajaj spare parts
DH010222	DECAL COVER SIDE LWR RH RED-SLVR	Bajaj spare parts
DH010232	DECAL FAIRING LH SAFFIRE BLUE	Bajaj spare parts
DH010240	DECAL SPOILER TANK LH S BLUE	Bajaj spare parts
DH010241	DECAL SPOILER TANK RH S BLUE	Bajaj spare parts
DH010259	DECAL SPOILER TANK LH WINE RED	Bajaj spare parts
DH010260	DECAL SPOILER TANK RH WINE RED	Bajaj spare parts
DH010306	DECAL SPOILER TANK LH E BLACK	Bajaj spare parts
DH010307	DECAL SPOILER TANK RH E BLACK	Bajaj spare parts
DH010320	DECAL TANK UPPER LH ROYAL BLUE	Bajaj spare parts
DH010321	DECAL TANK UPPER RH ROYAL BLUE	Bajaj spare parts
DH010324	DECAL TANK LOWER LH ROYAL BLUE	Bajaj spare parts
DH010326	DECAL SPOILER TANK LH ROYAL BLUE	Bajaj spare parts
DH010327	DECAL SPOILER TANK RH ROYAL BLUE	Bajaj spare parts
DH010331	DECAL COVER SIDE LOWER RH R BLUE	Bajaj spare parts
DH010342	DECAL SPOILER TANK LH WINE RED	Bajaj spare parts
DH010343	DECAL SPOILER TANK RH WINE RED	Bajaj spare parts
DH010352	DECAL FENDER LH	Bajaj spare parts
DH010353	DECAL FENDER RH	Bajaj spare parts
DH010354	DECAL TWIN DISC LH	Bajaj spare parts
DH010355	DECAL TWIN DISC RH	Bajaj spare parts
DH010359	DECAL TANK LOWER LH BLACK RED	Bajaj spare parts
DH010361	DECAL SPOILER TANK LH BLACK RED	Bajaj spare parts
DH010362	DECAL SPOILER TANK RH BLACK RED	Bajaj spare parts
DH010364	DECAL COVER SIDE UR RH BLACK RED	Bajaj spare parts
DH010368	DECAL COWL SEAT UR RH BLACK RED	Bajaj spare parts
DH010381	DECAL FAIRING FRONT LIME GREEN	Bajaj spare parts

DH010382	DECAL FAIRING FRONT PASSION RED	Bajaj spare parts
DH010383	DECAL WHEEL LIME GREEN	Bajaj spare parts
DH010384	DECAL WHEEL PASSION RED	Bajaj spare parts
DH010385	DECAL COWL SEAT LIME GREEN	Bajaj spare parts
DH010386	DECAL COWL SEAT PASSION RED	Bajaj spare parts
DH010387	DECAL 3D LIME GREEN	Bajaj spare parts
DH010388	DECAL 3D PASSION RED	Bajaj spare parts
DH010389	LABEL DOME TANK LIME GREEN	Bajaj spare parts
DH010390	LABEL DOME TANK PASSION RED	Bajaj spare parts
DH010395	DECAL COWL SEAT UPPER LH E BLACK	Bajaj spare parts
DH010397	DECAL WHEEL LH EBONY BLACK	Bajaj spare parts
DH010398	DECAL WHEEL RH EBONY BLACK	Bajaj spare parts
DH010399	DECAL BELLY PAN LH EBONY BLACK	Bajaj spare parts
DH010400	DECAL BELLY PAN RH EBONY BLACK	Bajaj spare parts
DH010401	DECAL FAIRING PLATINUM SILVER	Bajaj spare parts
DH010402	DECAL WHEEL PLATINUM SILVER	Bajaj spare parts
DH010403	DECAL DOME TANK PLATINUM SILVER	Bajaj spare parts
DH010404	DECAL COWL SEAT PLATINUM SILVER	Bajaj spare parts
DH010405	DECAL 3D PLATINUM SILVER	Bajaj spare parts
DH010406	DECAL BELLY PAN LH CW RED	Bajaj spare parts
DH010407	DECAL BELLY PAN RH CW RED	Bajaj spare parts
DH010408	DECAL BELLY PAN LH SAFFIRE BLUE	Bajaj spare parts
DH010410	DECAL BELLY PAN RH SAFFIRE BLUE	Bajaj spare parts
DH010411	DECAL BELLY PAN LH EBONY BLACK	Bajaj spare parts
DH010412	DECAL BELLY PAN RH EBONY BLACK	Bajaj spare parts
DH010413	DECAL WHEEL LH	Bajaj spare parts
DH010414	DECAL WHEEL RH	Bajaj spare parts
DH010415	DECAL FAIRING FRONT S ORANGE	Bajaj spare parts
DH010416	DECAL WHEEL SPORTY ORANGE	Bajaj spare parts
DH010417	DECAL PAD TANK SPORTY ORANGE	Bajaj spare parts
DH010418	DECAL COWL SEAT SPORTY ORANGE	Bajaj spare parts
DH010419	DECAL 3D SPORTY ORANGE	Bajaj spare parts
DH010429	DECAL DOME TANK	Bajaj spare parts
DH010442	DECAL COWL SEAT MATTE BLACK BLUE	Bajaj spare parts
DH010443	DECAL WHEEL MATTE BLACK BLUE	Bajaj spare parts
DH010444	DECAL FAIRING FRONT M BLACK BLUE	Bajaj spare parts
DH010445	DECAL 3D MATTE BLACK BLUE	Bajaj spare parts
DH010446	DECAL DOME TANK M BLACK BLUE	Bajaj spare parts
DH010447	DECAL COWL SEAT EBONY BLACK RED	Bajaj spare parts
DH010448	DECAL WHEEL EBONY BLACK RED	Bajaj spare parts
DH010449	DECAL FAIRING FRONT E BLACK RED	Bajaj spare parts
DH010450	DECAL 3D EBONY BLACK RED	Bajaj spare parts
DH010451	DECAL DOME TANK EBONY BLACK RED	Bajaj spare parts
DH010452	DECAL COWL SEAT E BLACK P SILVER	Bajaj spare parts
DH010454	DECAL FENDER LH EBONY BLACK RED	Bajaj spare parts

DH010465	DECAL BELLY PAN RH MATTE V RED	Bajaj spare parts
DH010466	DECAL FENDER LH EBONY BLACK BLUE	Bajaj spare parts
DH010474	DECAL SPOILER TANK LH E BLK BLUE	Bajaj spare parts
DH010477	DECAL SPOILER TANK RH M V RED	Bajaj spare parts
DH010502	DECAL BELLY PAN LIME GREEN LH	Bajaj spare parts
DH010503	DECAL BELLY PAN LIME GREEN RH	Bajaj spare parts
DH010510	DECAL FLAP TANK LH LIME GREEN	Bajaj spare parts
DH010511	DECAL FLAP TANK RH LIME GREEN	Bajaj spare parts
DH010512	DECAL FLAP TANK LH PASSION RED	Bajaj spare parts
DH010513	DECAL FLAP TANK RH PASSION RED	Bajaj spare parts
DH010514	DECAL FLAP TANK LH SUPER SILVER	Bajaj spare parts
DH010515	DECAL FLAP TANK RH SUPER SILVER	Bajaj spare parts
DH010564	DECAL FLAP TANK LH BLUE	Bajaj spare parts
DH010565	DECAL FLAP TANK RH BLUE	Bajaj spare parts
DH010566	DECAL FLAP TANK LH RED	Bajaj spare parts
DH010567	DECAL FLAP TANK RH RED	Bajaj spare parts
DH010570	DECAL BELLY PAN LH SOLAR RED	Bajaj spare parts
DH010571	DECAL BELLY PAN RH SOLAR RED	Bajaj spare parts
DH010574	DECAL DOME TANK SOLAR RED	Bajaj spare parts
DH010579	DECAL COWL SEAT C BLACK TF GREEN	Bajaj spare parts
DH010580	DECAL 3D C BLACK TF GREEN	Bajaj spare parts
DH010581	DECAL BELLY PAN LH BLK TF GREEN	Bajaj spare parts
DH010582	DECAL WHEEL C BLACK TF GREEN	Bajaj spare parts
DH010583	DECAL FAIRING FR C BLK TF GREEN	Bajaj spare parts
DH010584	DECAL DOME TANK C BLACK TF GREEN	Bajaj spare parts
DH010585	DECAL BELLY PAN RH BLK TF GREEN	Bajaj spare parts
DH010595	DECAL TANK FLAP LH FROG GREEN	Bajaj spare parts
DH010596	DECAL TANK FLAP RH FROG GREEN	Bajaj spare parts
DH010607	DECAL ABS	Bajaj spare parts
DH010614	DECAL SPOILER TANK LH SATIN P WH	Bajaj spare parts
DH010615	DECAL SPOILER TANK RH SATIN P WH	Bajaj spare parts
DH010616	DECAL COVER SIDE LH SATIN P WH	Bajaj spare parts
DH010617	DECAL COVER SIDE RH SATIN P WH	Bajaj spare parts
DH010622	DECAL BELLY PAN LH SATIN P WH	Bajaj spare parts
DH010623	DECAL BELLY PAN RH SATIN P WH	Bajaj spare parts
DH010628	DECAL FENDER MIDDLE	Bajaj spare parts
DH010629	DECAL SPOILER TANK LH SATIN P WH	Bajaj spare parts
DH010630	DECAL SPOILER TANK RH SATIN P WH	Bajaj spare parts
DH010631	DECAL FENDER LH RED	Bajaj spare parts
DH010632	DECAL FENDER RH RED	Bajaj spare parts
DH010635	DECAL FENDER MIDDLE	Bajaj spare parts
DH010640	DECAL SPOILER TANK LH SATIN S BL	Bajaj spare parts
DH010641	DECAL SPOILER TANK RH SATIN S BL	Bajaj spare parts
DH010646	DECAL BELLY PAN LH SATIN S BLUE	Bajaj spare parts
DH010647	DECAL BELLY PAN RH SATIN S BLUE	Bajaj spare parts

DH010653	DECAL SPOILER TANK RH SATIN S BLK	Bajaj spare parts
DH010661	DECAL SPOILER TANK LH V RED	Bajaj spare parts
DH010662	DECAL SPOILER TANK RH V RED	Bajaj spare parts
DH010666	DECAL BELLY PAN RH VOLCANIC RED	Bajaj spare parts
DH010667	DECAL BELLY PAN LH VOLCANIC RED	Bajaj spare parts
DH010675	DECAL SPOILER TANK LH SATIN S BLK	Bajaj spare parts
DH010679	DECAL BELLY PAN LH SATIN S BLACK	Bajaj spare parts
DH010680	DECAL BELLY PAN RH SATIN S BLACK	Bajaj spare parts
DH010684	DECAL SPOILER TANK LH SATIN S BL	Bajaj spare parts
DH010685	DECAL SPOILER TANK RH SATIN S BL	Bajaj spare parts
DH010688	DECAL FENDER LH PEARL WHITE	Bajaj spare parts
DH010689	DECAL FENDER RH PEARL WHITE	Bajaj spare parts
DH010690	DECAL SPOILER TANK LH V RED	Bajaj spare parts
DH010691	DECAL SPOILER TANK RH V RED	Bajaj spare parts
DH010696	DECAL SPOILER TANK LH SATIN S BLK	Bajaj spare parts
DH010697	DECAL SPOILER TANK RH SATIN S BLK	Bajaj spare parts
DH010714	DECAL SPOILER TANK LH SOLAR RED	Bajaj spare parts
DH010715	DECAL SPOILER TANK RH SOLAR RED	Bajaj spare parts
DH010718	DECAL BELLY PAN LH SOLAR RED	Bajaj spare parts
DH010719	DECAL BELLY PAN RH SOLAR RED	Bajaj spare parts
DH010728	DECAL SPOILER TANK LH P SILVER	Bajaj spare parts
DH010729	DECAL SPOILER TANK RH P SILVER	Bajaj spare parts
DH010732	DECAL BELLY PAN LH P SILVER	Bajaj spare parts
DH010733	DECAL BELLY PAN RH P SILVER	Bajaj spare parts
DH010750	DECAL SPOILER TANK LH T F GREEN	Bajaj spare parts
DH010751	DECAL SPOILER TANK RH T F GREEN	Bajaj spare parts
DH010754	DECAL BELLY PAN LH T FROG GREEN	Bajaj spare parts
DH010755	DECAL BELLY PAN RH T FROG GREEN	Bajaj spare parts
DH010765	DECAL BELLY PAN LH C BLK L GREEN	Bajaj spare parts
DH010766	DECAL BELLY PAN RH C BLK L GREEN	Bajaj spare parts
DH010767	DECAL FLAP TANK LH C BLK L GREEN	Bajaj spare parts
DH010768	DECAL FLAP TANK RH C BLK L GREEN	Bajaj spare parts
DH010771	DECAL SPOILER TANK LH E BL P RED	Bajaj spare parts
DH010772	DECAL SPOILER TANK RH E BL P RED	Bajaj spare parts
DH010779	DECAL BELLY PAN LH E BLACK P RED	Bajaj spare parts
DH010780	DECAL BELLY PAN RH E BLACK P RED	Bajaj spare parts
DH010830	DECAL SPOILER TANK S BLK SVR LH	Bajaj spare parts
DH010831	DECAL SPOILER TANK S BLK SVR RH	Bajaj spare parts
DH010834	DECAL BELLY PAN S BLK SILVER LH	Bajaj spare parts
DH010835	DECAL BELLY PAN S BLK SILVER RH	Bajaj spare parts
DH010842	DECAL SPOILER TANK S BLK BLUE LH	Bajaj spare parts
DH010843	DECAL SPOILER TANK S BLK BLUE RH	Bajaj spare parts
DH010846	DECAL BELLY PAN S BLACK BLUE LH	Bajaj spare parts
DH010847	DECAL BELLY PAN S BLACK BLUE RH	Bajaj spare parts
DH010854	DECAL SPOILER TANK S BL WHITE LH	Bajaj spare parts

DH010855	DECAL SPOILER TANK S BL WHITE RH	Bajaj spare parts
DH010858	DECAL BELLY PAN S BLUE WHITE LH	Bajaj spare parts
DH010859	DECAL BELLY PAN S BLUE WHITE RH	Bajaj spare parts
DH010866	DECAL SPOILER TANK S BLK RED LH	Bajaj spare parts
DH010867	DECAL SPOILER TANK S BLK RED RH	Bajaj spare parts
DH010870	DECAL BELLY PAN S BLACK RED LH	Bajaj spare parts
DH010871	DECAL BELLY PAN S BLACK RED RH	Bajaj spare parts
DH010876	DECAL SPOILER TANK S BLK BLUE LH	Bajaj spare parts
DH010877	DECAL SPOILER TANK S BLK BLUE RH	Bajaj spare parts
DH010880	DECAL SPOILER TANK S BLUE WH LH	Bajaj spare parts
DH010881	DECAL SPOILER TANK S BLUE WH RH	Bajaj spare parts
DH010884	DECAL SPOILER TANK S BLK RED LH	Bajaj spare parts
DH010885	DECAL SPOILER TANK S BLK RED RH	Bajaj spare parts
DH010888	DECAL SPOILER TANK S BLK SLVR LH	Bajaj spare parts
DH010889	DECAL SPOILER TANK S BLK SLVR RH	Bajaj spare parts
DH010909	DECAL WHEEL SOLAR RED LH	Bajaj spare parts
DH010910	DECAL WHEEL SOLAR RED RH	Bajaj spare parts
DH010913	DECAL SPOILER TANK SOLAR RED LH	Bajaj spare parts
DH010914	DECAL SPOILER TANK SOLAR RED RH	Bajaj spare parts
DH010917	DECAL 3D EBONY BLACK SOLAR RED	Bajaj spare parts
DH010918	DECAL 3D E BLK PLATINUM SILVER	Bajaj spare parts
DH010925	DECAL SPOILER TANK P SILVER LH	Bajaj spare parts
DH010926	DECAL SPOILER TANK P SILVER RH	Bajaj spare parts
DH010929	DECAL 3D C BLK TREE FROG GREEN	Bajaj spare parts
DH010933	DECAL WHEEL TREE FROG GREEN LH	Bajaj spare parts
DH010934	DECAL WHEEL TREE FROG GREEN RH	Bajaj spare parts
DH010937	DECAL SPOILER TANK T F GREEN LH	Bajaj spare parts
DH010938	DECAL SPOILER TANK T F GREEN RH	Bajaj spare parts
DH010953	DECAL 3D EBONY BLACK PASSION RED	Bajaj spare parts
DH010965	DECAL 3D C BLCACK LIME GREEN	Bajaj spare parts
DH011006	DECAL BELLY PAN B YELLOW G LH	Bajaj spare parts
DH011007	DECAL BELLY PAN B YELLOW G RH	Bajaj spare parts
DH011008	DECAL SPOILER TANK B YELLOW G LH	Bajaj spare parts
DH011009	DECAL SPOILER TANK B YELLOW G RH	Bajaj spare parts
DH011049	EMBLEM BAJAJ	Bajaj spare parts
DH011064	EMBLEM BAJAJ	Bajaj spare parts
DH101006	GASKET CRANKCASE	Bajaj spare parts
DH101016	GASKET CYLINDER	Bajaj spare parts
DH101018	BRACKET CABLE CLUTCH	Bajaj spare parts
DH101033	GASKET HEAD CYLINDER	Bajaj spare parts
DH101048	WASHER SPECIAL CAMSHAFT	Bajaj spare parts
DH101050	CHAIN CAM	Bajaj spare parts
DH101064	BODY CENTRIFUGAL OIL FIL	Bajaj spare parts
DH101065	COVER CENTRIFUGAL OIL FIL	Bajaj spare parts
DH101066	JOINT OIL DELIVERY B	Bajaj spare parts

DH101067	SPRING OIL DELIVERY B	Bajaj spare parts
DH101072	STOPPER BRG. BALANCER RH	Bajaj spare parts
DH101078	GEAR 4TH DRIVE	Bajaj spare parts
DH101079	WASHER SPLINE	Bajaj spare parts
DH101080	GEAR 3RD DRIVE	Bajaj spare parts
DH101082	GEAR 5TH DRIVE	Bajaj spare parts
DH101084	GEAR 2ND DRIVE	Bajaj spare parts
DH101098	PLATE CLUTCH	Bajaj spare parts
DH101108	GEAR 3RD DRIVEN	Bajaj spare parts
DH101110	GEAR 4TH DRIVEN	Bajaj spare parts
DH101111	BUSH GEAR 1ST DRIVEN	Bajaj spare parts
DH101113	GEAR 5TH DRIVEN	Bajaj spare parts
DH101121	SPRING RATCHET KICK START	Bajaj spare parts
DH101125	SPRING RUTU KIC STA	Bajaj spare parts
DH101141	RACK	Bajaj spare parts
DH101142	SHAFT RELEASE CLUTCH	Bajaj spare parts
DH101144	SPRING RETURN GS	Bajaj spare parts
DH101146	SHAFT GEAR SHIFT FORK	Bajaj spare parts
DH101152	RING O OIL LEVEL GAUGE	Bajaj spare parts
DH101154	GASKET COVER RH	Bajaj spare parts
DH101157	CAP CRANK CENTER	Bajaj spare parts
DH101158	CAP TIMING HOLE	Bajaj spare parts
DH101163	ROLLER CLUTCH	Bajaj spare parts
DH101164	SPRING CLUTCH STARTER	Bajaj spare parts
DH101169	BUSH GEAR STARTER INNER	Bajaj spare parts
DH101170	PLATE STARTER CL GEAR RET	Bajaj spare parts
DH101172	COLLER STARTER MOTOR	Bajaj spare parts
DH101180	LEVER ASSY	Bajaj spare parts
DH101184	COVER STARTER MOTO	Bajaj spare parts
DH101186	PLATE ROLLER CLUTCH	Bajaj spare parts
DH101188	GEAR COMPL STARTER COUNT	Bajaj spare parts
DH101195	NUT PRIMARY DRIVE LOCK	Bajaj spare parts
DH101197	GROMMET BREATHER	Bajaj spare parts
DH101199	PLATE STOPPER WIRING HARN	Bajaj spare parts
DH101203	PIPE BREATHER	Bajaj spare parts
DH101235	CIRCLIP	Bajaj spare parts
DH101246	TUBE RUBBER	Bajaj spare parts
DH101272	PLUG	Bajaj spare parts
DH101275	NUT SPECIAL	Bajaj spare parts
DH101292	DAMPER A COVER LH RR	Bajaj spare parts
DH101294	DAMPER B COVER LH RR	Bajaj spare parts
DH101295	WASHER ARM ROCKER	Bajaj spare parts
DH101301	SEAL SHIELD MUFFLER	Bajaj spare parts
DH101302	SCREW TRUSS	Bajaj spare parts
DH101319	BUSH GEAR 2ND DRIVEN	Bajaj spare parts



DH101321	BOLT SPECIAL M8	Bajaj spare parts
DH101333	GEAR 2 ND DRIVEN	Bajaj spare parts
DH101334	COLLAR - SPROCKET	Bajaj spare parts
DH101336	WASHER SPECIAL	Bajaj spare parts
DH101344	PLATE CLUTCH PRESSURE	Bajaj spare parts
DH101346	CLUTCH CENTER	Bajaj spare parts
DH101353	PINION KICK STARTER	Bajaj spare parts
DH101355	COVER COMP-CENTRIFUGAL OIL FILTER	Bajaj spare parts
DH101361	PLUG - CRANK PIN	Bajaj spare parts
DH101373	SCISSOR BALANCER	Bajaj spare parts
DH101376	CLUTCH CENTER	Bajaj spare parts
DH101379	SCREW CSK M6X16-PRECOATED	Bajaj spare parts
DH101380	SCREW PRECOATEDM6X1	Bajaj spare parts
DH101381	SCREW PRECOATED PAN	Bajaj spare parts
DH101385	BOLT FLANGED PREC M6	Bajaj spare parts
DH101386	PRECOATED FLANGED BOLT M6	Bajaj spare parts
DH101387	PRECOATED BOLT M8 X 20	Bajaj spare parts
DH101388	BOLT FLANGED PREC M5	Bajaj spare parts
DH101389	PRECOATED SCREW M6X2	Bajaj spare parts
DH101390	BOLT FLANGED PR	Bajaj spare parts
DH101392	PRECOATED TENS PIVOT	Bajaj spare parts
DH101393	BOLT GEAR SHIFT PREC	Bajaj spare parts
DH101394	BOLT PRECOATED SPEC	Bajaj spare parts
DH101395	TRUST SCREW	Bajaj spare parts
DH101396	BOLT PRE CTD GEAR SH	Bajaj spare parts
DH101397	LEVER CHANGE	Bajaj spare parts
DH101401	GEAR STARTER CLUTCH	Bajaj spare parts
DH101411	CAMSHAFT DTSI-150	Bajaj spare parts
DH101412	COLLAR CAM SPROCKET	Bajaj spare parts
DH101414	DAMPER RUBBER	Bajaj spare parts
DH101416	SHAFT OUTPUT TRANMISSION	Bajaj spare parts
DH101420	STOPPER RETAINING BEARIN	Bajaj spare parts
DH101422	DAMPER AXIAL RUBBER	Bajaj spare parts
DH101423	RING O GUIDE STARTER	Bajaj spare parts
DH101424	SPRING.TORSION	Bajaj spare parts
DH101430	DAMPER CYL HEAD	Bajaj spare parts
DH101434	CLUTCH CENTER	Bajaj spare parts
DH101468	SHIELD MUFFLER PUL DT	Bajaj spare parts
DH101481	GROMMET SHIELD MU	Bajaj spare parts
DH101483	SPRING CLUTCH CAPACITY	Bajaj spare parts
DH101484	HOLDER CLUTCH	Bajaj spare parts
DH101485	ROD CLUTCH LIFTER	Bajaj spare parts
DH101487	PLATE STOPPER BEARIN	Bajaj spare parts
DH101493	SHAFT GEAR SHIFT FORK	Bajaj spare parts
DH101496	SPACER GUIDE GEAR SHIFT	Bajaj spare parts

DH101501	PLATE ASSY CLUTCH	Bajaj spare parts
DH101502	SPRING STOPPER DRUM	Bajaj spare parts
DH101508	DAMPER CYL HEAD	Bajaj spare parts
DH101509	DAMPER	Bajaj spare parts
DH101520	NUT CLUTCH CENTER LOCK	Bajaj spare parts
DH101521	SHIELD ASSEMBLY WIRE	Bajaj spare parts
DH101527	CYL BL.ASSY PULSR K1.5up	Bajaj spare parts
DH101531	GEAR KICK IDLER	Bajaj spare parts
DH101533	BUSH SPRING	Bajaj spare parts
DH101536	GUIDE KICK	Bajaj spare parts
DH101537	RATCHET KICK STARTER	Bajaj spare parts
DH101538	PLATE STOPPER GEAR KICK I	Bajaj spare parts
DH101539	SPINDLE KICK STARTER	Bajaj spare parts
DH101540	SPINDLE KICK STARTER ASSY	Bajaj spare parts
DH101544	SPRING TORSION LEVER CLUT	Bajaj spare parts
DH101545	LEVER KICK STARTER	Bajaj spare parts
DH101555	CLUTCH CENTER	Bajaj spare parts
DH101557	PLATE CLUTCH	Bajaj spare parts
DH101581	PLATE STARTER CL GEAR RET	Bajaj spare parts
DH101607	SCREW TRUSS	Bajaj spare parts
DH101608	SHIELD EXHAUST TUB	Bajaj spare parts
DH101611	VALVE INTAKE PULSAR	Bajaj spare parts
DH101628	GEAR PRIMARY DRIVE	Bajaj spare parts
DH101635	PRECOATED BOLT FLANG	Bajaj spare parts
DH101638	PRECOATED BOLT FLANG	Bajaj spare parts
DH101639	BOLT PRECOATEDFLANG	Bajaj spare parts
DH101640	PRECOATED SLOTTED	Bajaj spare parts
DH101647	BOLT M6 HEX SOCKET	Bajaj spare parts
DH101648	NUT CLUTCH CENTER LO	Bajaj spare parts
DH101658	GEAR STARTER CLUTCH	Bajaj spare parts
DH101661	PLUG DRAIN MAGNETIC	Bajaj spare parts
DH101665	PISTON ASSEMBLY	Bajaj spare parts
DH101671	RING SNAP	Bajaj spare parts
DH101672	CRANKSHAFT PULSR 150 UG4	Bajaj spare parts
DH101680	GASKET CYL HEAD	Bajaj spare parts
DH101703	CAMSHAFT ASSLY	Bajaj spare parts
DH101705	LEVER COMP GEAR SHIF	Bajaj spare parts
DH101719	RUBBER TUBE	Bajaj spare parts
DH101741	CLUTCH PLATE ASSLY	Bajaj spare parts
DH101742	CLUTCH CENTRE	Bajaj spare parts
DH101743	SPRING CLUTCH CAPAC	Bajaj spare parts
DH101763	HEAD CYL	Bajaj spare parts
DH101773	CYL BLOCK ASSY PULSR150	Bajaj spare parts
DH101781	PLATE ROLLER CLUTCH	Bajaj spare parts
DH101782	BODYSTARTER CLUTCH	Bajaj spare parts

DH101784	GASKET NEUTRAL SWITC	Bajaj spare parts
DH101795	CLUTCH LIFTER BEARING	Bajaj spare parts
DH101860	CENTER ASSLY.CLUTCH(FCC)	Bajaj spare parts
DH101862	CENTER CLUTH FCC	Bajaj spare parts
DH101863	HEAD CYL ASSY WITH C	Bajaj spare parts
DH101864	CYL BL ASSY K1 blak pul150	Bajaj spare parts
DH101865	C'CASE LH PLSR150BL	Bajaj spare parts
DH101875	CRANKCASE LH SILVER	Bajaj spare parts
DH101876	CYL BLK ASSY K1 SILVR P150	Bajaj spare parts
DH101877	PLATE FRICTION SET	Bajaj spare parts
DH101878	CYL BLOCK (K1UG4 THICK LINER)	Bajaj spare parts
DH101881	BRACKET CLUTCH CABLE (P150)	Bajaj spare parts
DH101896	GASKET CRANKCASE	Bajaj spare parts
DH101916	BOLT FL-M12X1.5XL 15 X BRT X PRECOAT	Bajaj spare parts
DH101920	GEAR 5TH DRIVEN	Bajaj spare parts
DH101928	CAMSHAFT ASSLY COMPL DHUG4.5	Bajaj spare parts
DH102013	GEAR 2ND DRIVE	Bajaj spare parts
DH102015	SHAFT INPUT TRANSMISSION ASSLY	Bajaj spare parts
DH102022	GEAR 2ND DRIVEN	Bajaj spare parts
DH102050	ASSLY BODY BALANCER	Bajaj spare parts
DH102052	ASSLY BALANCER IDLER GEAR	Bajaj spare parts
DH102053	GEAR COMPL BALANCER IDLER	Bajaj spare parts
DH102056	ASSEMBLY ENGINE WITH MLT COVER	Bajaj spare parts
DH102087	ASSLY CLUTCH COMPLETE	Bajaj spare parts
DH102089	ASSLY CLUTCH PLATE	Bajaj spare parts
DH102092	HUB CLUTCH	Bajaj spare parts
DH102093	WHEEL CLUTCH	Bajaj spare parts
DH102094	HOLDER PLATE	Bajaj spare parts
DH102096	CLUTCH SPRING	Bajaj spare parts
DH102097	SPRING ANTI JUDDER	Bajaj spare parts
DH102098	PLATE ANTI JUDDER	Bajaj spare parts
DH102103	ASSLY CYL HEAD M/C WITH COVER	Bajaj spare parts
DH102104	ASSLY BODY BALANCER	Bajaj spare parts
DH102107	INSULATOR IM WITH CLAMP	Bajaj spare parts
DH102118	CLAMP INSULATOR IM	Bajaj spare parts
DH102125	BOLT SPECIAL CAMSHAFT	Bajaj spare parts
DH102139	SHIELD MUFFLER	Bajaj spare parts
DH102164	CRANKCASE LH	Bajaj spare parts
DH102165	CRANKCASE RH	Bajaj spare parts
DH102166	SEAL DUST	Bajaj spare parts
DH102174	METAL PIPE WITH FLANGE_SAI	Bajaj spare parts
DH102175	HOSE SAI UNIT TO SAI PIPE	Bajaj spare parts
DH102180	GASKET METAL PIPE WITH FLANGE_SAI	Bajaj spare parts
DH102189	GUIDE GEAR SHIFT	Bajaj spare parts
DH102198	WASHER CLUTCH HUB	Bajaj spare parts

DH102200	GUIDE STARTER ASSLY	Bajaj spare parts
DH102201	CAMSHAFT CAP	Bajaj spare parts
DH102209	CENTER ASSLY CLUTCH	Bajaj spare parts
DH102210	CENTER CLUTCH	Bajaj spare parts
DH102211	PLATE CLUTCH PRESSURE	Bajaj spare parts
DH102212	SPRING CLUTCH	Bajaj spare parts
DH102214	CLUTCH ASSLY	Bajaj spare parts
DH102220	ASSLY CRANKSHAFT BS IV	Bajaj spare parts
DH102229	SILENCER ASSLY	Bajaj spare parts
DH102230	GASKET HEAD CYLINDER	Bajaj spare parts
DH102232	TUBE BREATHER	Bajaj spare parts
DH102261	SHIELD CAT	Bajaj spare parts
DH102263	WIRE SHIELD	Bajaj spare parts
DH102272	SHIELD SILENCER	Bajaj spare parts
DH102274	ARRESTER COMPLETE FRAME	Bajaj spare parts
DH102276	CARTRIDGE ASSEMBLY	Bajaj spare parts
DH102277	ELEMENT ASSLY FILTER	Bajaj spare parts
DH102281	RING O	Bajaj spare parts
DH102292	GEAR 1ST DRIVEN-32T	Bajaj spare parts
DH102329	SLEEVE PLUG SPARK	Bajaj spare parts
DH102343	ENGINE ASSLY	Bajaj spare parts
DH102349	SHIELD MUFFLER	Bajaj spare parts
DH102350	SHIELD CAT	Bajaj spare parts
DH102351	SHIELD WIRE	Bajaj spare parts
DH102353	ASSEMBLY SILENCER	Bajaj spare parts
DH102354	SILENCER ASSEMBLY	Bajaj spare parts
DH102360	ENGINE ASSEMBLY	Bajaj spare parts
DH102363	SHIELD WIRE	Bajaj spare parts
DH102368	SHIELD WIRE	Bajaj spare parts
DH102386	CLUTCH ASSEMBLY	Bajaj spare parts
DH102387	HOUSING ASSEMBLY CLUTCH	Bajaj spare parts
DH102389	ELEMENT ASSEMBLY FILTER AIR	Bajaj spare parts
DH102390	ELEMENT FILTER AIR	Bajaj spare parts
DH102396	SILENCER ASSEMBLY	Bajaj spare parts
DH102398	SILENCER ASSEMBLY	Bajaj spare parts
DH102400	SHIELD CATALYST	Bajaj spare parts
DH102403	ENGINE ASSEMBLY	Bajaj spare parts
DH102406	BLOCK CYLINDER	Bajaj spare parts
DH102437	GEAR IDLER	Bajaj spare parts
DH102438	BUSH	Bajaj spare parts
DH102448	PIPE ASSEMBLY OIL	Bajaj spare parts
DH102452	ENGINE ASSEMBLY	Bajaj spare parts
DH102458	PIPE BREATHER	Bajaj spare parts
DH102459	CONNECTOR VALVE PURGE	Bajaj spare parts
DH102460	PIPE VALVE PURGE INLET	Bajaj spare parts

DH102461	PIPE VALVE PURGE OUTLET	Bajaj spare parts
DH102462	SENSOR ASSEMBLY PICK UP	Bajaj spare parts
DH102464	ENGINE ASSEMBLY	Bajaj spare parts
DH102465	INSULATOR	Bajaj spare parts
DH102471	CRANKSHAFT ASSEMBLY	Bajaj spare parts
DH102477	LEVER ASSEMBLY KICK	Bajaj spare parts
DH102487	CAMSHAFT ASSEMBLY	Bajaj spare parts
DH102490	CRANKCASE RH	Bajaj spare parts
DH102491	SILENCER ASSEMBLY	Bajaj spare parts
DH102501	HEAD CYLINDER-COVER ASSEMBLY	Bajaj spare parts
DH102508	SHAFT ASSEMBLY INPUT	Bajaj spare parts
DH102511	GEAR FIFTH DRIVE	Bajaj spare parts
DH102513	GEAR FIRST DRIVEN	Bajaj spare parts
DH102514	GEAR FIFTH DRIVEN	Bajaj spare parts
DH102523	BLOCK CYLINDER	Bajaj spare parts
DH102526	ENGINE ASSEMBLY	Bajaj spare parts
DH102529	SILENCER ASSEMBLY	Bajaj spare parts
DH102538	GUIDE CHAIN SLACK SIDE	Bajaj spare parts
DH102540	CRANKSHAFT ASSEMBLY	Bajaj spare parts
DH102545	COVER ASSEMBLY HEAD CYLINDER	Bajaj spare parts
DH102548	CRANKSHAFT ASSEMBLY	Bajaj spare parts
DH102552	SILENCER ASSEMBLY	Bajaj spare parts
DH102553	CAMSHAFT ASSEMBLY	Bajaj spare parts
DH102565	CRANKSHAFT ASSEMBLY	Bajaj spare parts
DH102566	SHIELD WIRE	Bajaj spare parts
DH102572	SILENCER ASSEMBLY	Bajaj spare parts
DH102576	GEAR THIRD DRIVEN	Bajaj spare parts
DH103701	HEAD CYLINDER-COVER ASSEMBLY	Bajaj spare parts
DH103728	SLEEVE MANIFOLD	Bajaj spare parts
DH103732	SILENCER ASSEMBLY	Bajaj spare parts
DH103752	SHIELD WIRE	Bajaj spare parts
DH103755	SHIELD MUFFLER	Bajaj spare parts
DH103756	SHIELD MUFFLER	Bajaj spare parts
DH103758	CHAIN	Bajaj spare parts
DH103763	CLAMP	Bajaj spare parts
DH103770	SILENCER ASSEMBLY	Bajaj spare parts
DH103775	SHIELD CATALYST	Bajaj spare parts
DH103778	CRANKSHAFT ASSEMBLY	Bajaj spare parts
DH103802	SHIELD MUFFLER	Bajaj spare parts
DH103807	CLUTCH ASSEMBLY	Bajaj spare parts
DH103810	SILENCER ASSEMBLY	Bajaj spare parts
DH103817	SILENCER ASSEMBLY	Bajaj spare parts
DH103838	ENGINE ASSEMBLY	Bajaj spare parts
DH103923	ENGINE ASSEMBLY	Bajaj spare parts
DH111009	COIL PULSER	Bajaj spare parts

DH111012	SLEEVE SPARK PLUG	Bajaj spare parts
DH111013	GROMMET SPARK PLUG	Bajaj spare parts
DH111015	CAP SPARK PLUG	Bajaj spare parts
DH111016	GROMMET SLEEVE SPARK PLU	Bajaj spare parts
DH111034	KIT BRUSH ASSY PULSAR	Bajaj spare parts
DH111039	COIL H.T. WITH EXTENDED	Bajaj spare parts
DH111040	COIL H T RH WITH EXTENDE	Bajaj spare parts
DH111058	MOTOR STARTER BLK	Bajaj spare parts
DH111067	CDI PULSAR 150 UG3	Bajaj spare parts
DH111072	CDI	Bajaj spare parts
DH111077	H T COIL WITH CAP - LH	Bajaj spare parts
DH111078	H T COIL WITH CAP - RH	Bajaj spare parts
DH111081	STATOR ASSY 8 POLE	Bajaj spare parts
DH111082	ROTOR ASSY	Bajaj spare parts
DH111083	ROTOR ASSY(W/O CL ASSLY)	Bajaj spare parts
DH111084	MOTOR STARTER	Bajaj spare parts
DH111104	CDI NON TPS ASSEMBLY K1	Bajaj spare parts
DH111109	KIT H.T.COILS	Bajaj spare parts
DH111111	COIL H.T. 1	Bajaj spare parts
DH111113	COIL H.T. 2	Bajaj spare parts
DH111114	MOTOR ASSLY STARTER	Bajaj spare parts
DH111117	CDI ASSLY	Bajaj spare parts
DH111122	STATOR ASSEMBLY	Bajaj spare parts
DH111123	ROTOR ASSEMBLY	Bajaj spare parts
DH111126	COIL ASSEMBLY IGNITION LH	Bajaj spare parts
DH111127	COIL ASSEMBLY IGNITION RH	Bajaj spare parts
DH111134	ECU EMS ASSEMBLY	Bajaj spare parts
DH111138	STATOR ASSEMBLY	Bajaj spare parts
DH111139	CDI	Bajaj spare parts
DH111141	ROTOR ASSEMBLY	Bajaj spare parts
DH111148	STATOR ASSEMBLY	Bajaj spare parts
DH111176	ECU EMS ASSEMBLY	Bajaj spare parts
DH111187	ROTOR ASSEMBLY	Bajaj spare parts
DH111195	STATOR ASSEMBLY	Bajaj spare parts
DH111196	ECU EMS ASSEMBLY	Bajaj spare parts
DH121010	MESH FILTER OIL PUMP	Bajaj spare parts
DH121011	PLATE PLUNGER OIL	Bajaj spare parts
DH121012	SPRING JOINT A	Bajaj spare parts
DH121014	INSULATOR CARBURET.	Bajaj spare parts
DH121015	PLUNGER OIL	Bajaj spare parts
DH121022	ELEMENT AIR FILTER	Bajaj spare parts
DH121038	CLAMP	Bajaj spare parts
DH121040	CARBURETTOR PULSAR DTSI	Bajaj spare parts
DH121048	DIAPHRAGM	Bajaj spare parts
DH121057	RING O	Bajaj spare parts

DH121059	FLOAT ASSY	Bajaj spare parts
DH121063	PIN	Bajaj spare parts
DH121064	SCREW	Bajaj spare parts
DH121087	WASHER	Bajaj spare parts
DH121093	NEEDLE ASSY	Bajaj spare parts
DH121096	KIT ADJUSTER PS CARB	Bajaj spare parts
DH121101	MAGNET ASSY	Bajaj spare parts
DH121102	SWITCH REED PULSAR DTSI	Bajaj spare parts
DH121106	INSULATOR CARBURETTOR	Bajaj spare parts
DH121123	CARBURETTOR PULSAR	Bajaj spare parts
DH121130	CARBURETTOR O RING	Bajaj spare parts
DH121132	TUBE CONNECTING	Bajaj spare parts
DH121134	PIPE DRAIN WITH CLIP	Bajaj spare parts
DH121138	CARBURETTOR ASSLY	Bajaj spare parts
DH121141	JET NEEDLE JN	Bajaj spare parts
DH121142	CLAMP AC BOX 52 MM	Bajaj spare parts
DH121150	SET ADJUSTER	Bajaj spare parts
DH121154	CARB ASSLY PULSAR 150 UG5	Bajaj spare parts
DH121162	FLOAT ASSLY	Bajaj spare parts
DH121166	JET KIT PULSAR 150 UG4.5	Bajaj spare parts
DH121167	FLOAT BODY ASSLY KIT (K1UG4.5)	Bajaj spare parts
DH121168	IDLING SCREW KIT	Bajaj spare parts
DH121169	SCREW PILOT PULSAR 150 UG4.5	Bajaj spare parts
DH121170	TOP CAP ASSLY KIT	Bajaj spare parts
DH121171	VACCUM PISTON KIT	Bajaj spare parts
DH121173	JET NEEDLE	Bajaj spare parts
DH121176	SCREW	Bajaj spare parts
DH121177	DRAIN SCREW	Bajaj spare parts
DH121178	FILTER AIR ASSLY	Bajaj spare parts
DH121188	CARBURETTOR BS29	Bajaj spare parts
DH121190	CLIP BAND DIA 53	Bajaj spare parts
DH121191	TUBE CONNECTING BS29	Bajaj spare parts
DH121202	ASSLY AIRFILTER FOR SAI	Bajaj spare parts
DH121208	HOSE SAI UNIT TO INTAKE MANIFOLD	Bajaj spare parts
DH121209	CARBURETTOR ASSLY FOR EVAP	Bajaj spare parts
DH121212	TUBE CONNECTING	Bajaj spare parts
DH121218	CARBURETTOR ASSLY WITHOUT EVAP	Bajaj spare parts
DH121227	HOSE UNIT SAI-PIPE SAI	Bajaj spare parts
DH121232	FILTER ASSEMBLY AIR	Bajaj spare parts
DH121237	FILTER ASSEMBLY AIR	Bajaj spare parts
DH121248	SLEEVE MANIFOLD	Bajaj spare parts
DH121249	FILTER ASSEMBLY AIR	Bajaj spare parts
DH121254	FILTER ASSEMBLY AIR	Bajaj spare parts
DH121256	BODY THROTTLE ASSEMBLY	Bajaj spare parts
DH121257	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts

DH121260	BODY THROTTLE ASSEMBLY	Bajaj spare parts
DH121261	FILTER ASSEMBLY AIR	Bajaj spare parts
DH121263	CARBURETTOR	Bajaj spare parts
DH121267	CARBURETTOR	Bajaj spare parts
DH121271	FILTER ASSEMBLY AIR	Bajaj spare parts
DH121303	TANK ASSEMBLY EXPANSION	Bajaj spare parts
DH121304	TANK EXPANSION	Bajaj spare parts
DH121315	BODY THROTTLE ASSEMBLY	Bajaj spare parts
DH121317	BODY THROTTLE ASSEMBLY	Bajaj spare parts
DH121319	FILTER ASSEMBLY AIR	Bajaj spare parts
DH121322	FILTER ASSEMBLY AIR	Bajaj spare parts
DH121325	FILTER ASSEMBLY AIR	Bajaj spare parts
DH121327	BODY THROTTLE ASSEMBLY	Bajaj spare parts
DH121328	INSULATOR	Bajaj spare parts
DH121330	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
DH121331	INJECTOR	Bajaj spare parts
DH121334	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
DH121347	CLAMP	Bajaj spare parts
DH141002	CAP TANK	Bajaj spare parts
DH141020	TAPE SEAT	Bajaj spare parts
DH141023	DAMPER REAR	Bajaj spare parts
DH141024	PIPE DRAIN	Bajaj spare parts
DH141048	ROTOR WITH KEY	Bajaj spare parts
DH141050	CAP TANK FUEL	Bajaj spare parts
DH141068	TUBE TANK TO INLINE CONNECTOR	Bajaj spare parts
DH141069	TUBE INLINE CON TO T CONNECTOR	Bajaj spare parts
DH141070	TUBE T CONNECTOR TO CANISTER	Bajaj spare parts
DH141071	TUBE CANISTER TO CONNECTOR	Bajaj spare parts
DH141072	TUBE PURGE VALVE TO CARBURATOR	Bajaj spare parts
DH141073	TUBE CANISTER DRAIN	Bajaj spare parts
DH141074	TUBE CANISTER BREATHER	Bajaj spare parts
DH141075	TUBE DRAIN	Bajaj spare parts
DH141077	TUBE CONNECTOR TO PURGE VALVE	Bajaj spare parts
DH141091	PIPE PUMP FUEL-CONNECTOR	Bajaj spare parts
DH141093	PIPE CANISTER-CONNECTOR	Bajaj spare parts
DH141094	PIPE CONNECTOR-VALVE PURGE	Bajaj spare parts
DH141095	PIPE VALVE PURGE-BODY THROTTLE	Bajaj spare parts
DH141103	PIPE CONNECTER	Bajaj spare parts
DH141125	PIPE	Bajaj spare parts
DH141146	PIPE FUEL	Bajaj spare parts
DH151029	BOLT STEP TORQUE ROD	Bajaj spare parts
DH151039	BOLT-FLANGE-PRE-COATED M8	Bajaj spare parts
DH151040	BOLT SOCKET HEAD	Bajaj spare parts
DH151047	COUPLING	Bajaj spare parts
DH151056	SPROCKET 44T 4 RUBBER	Bajaj spare parts



DH151057	WHEEL DIECAST 2.5X174LUG	Bajaj spare parts
DH151058	COUPLING ASSLY 44T	Bajaj spare parts
DH151062	CASE METER ASSLY	Bajaj spare parts
DH151077	WHEEL FRONT 1.85X17 (TUBELESS)	Bajaj spare parts
DH151079	WHEEL REAR 2.15X17 (TUBELESS)	Bajaj spare parts
DH151081	DISC FRONT BLACK	Bajaj spare parts
DH151083	DISC SENSOR SPEED FRONT	Bajaj spare parts
DH151084	DISC SENSOR SPEED REAR	Bajaj spare parts
DH151085	WHEEL FRONT 1.85 X 17	Bajaj spare parts
DH151086	DISC BRAKE DIA 260	Bajaj spare parts
DH151089	CALIPER ASSEMBLY FRONT	Bajaj spare parts
DH151090	COUPLING ASSEMBLY	Bajaj spare parts
DH151108	BRAKE SYSTEM FRONT	Bajaj spare parts
DH151109	ROD BRAKE	Bajaj spare parts
DH151114	PANEL BRAKE FRONT	Bajaj spare parts
DH151115	CAM ASSEMBLY BRAKE FRONT	Bajaj spare parts
DH151117	LEVER CAM BRAKE FRONT	Bajaj spare parts
DH151118	INDICATOR	Bajaj spare parts
DH151132	WHEEL REAR MT 2.15X17 DRUM	Bajaj spare parts
DH151151	UNIT ABS	Bajaj spare parts
DH151152	UNIT ABS WET	Bajaj spare parts
DH151164	DISC SENSOR SPEED	Bajaj spare parts
DH151172	UNIT ABS WET	Bajaj spare parts
DH161046	LOCK SEAT	Bajaj spare parts
DH161053	RUBBER STEP MAIN	Bajaj spare parts
DH161056	PLATE LOWER	Bajaj spare parts
DH161057	PIN MAIN STEP	Bajaj spare parts
DH161066	SPRING STAND SIDE	Bajaj spare parts
DH161073	INSTRUCTION LABLE	Bajaj spare parts
DH161100	SPACER STEP MAIN	Bajaj spare parts
DH161112	CUP REAR	Bajaj spare parts
DH161121	SPRING STAND MAIN	Bajaj spare parts
DH161133	GROMMET COVER SIDE REAR	Bajaj spare parts
DH161145	COVER SPRING STAND MAIN P	Bajaj spare parts
DH161146	COVER SPRING SIDE	Bajaj spare parts
DH161155	DAMPER SILENCER	Bajaj spare parts
DH161158	GROMMET COVER SIDE	Bajaj spare parts
DH161161	BUSH III SILENT	Bajaj spare parts
DH161189	BRACKET ENG LH	Bajaj spare parts
DH161190	BRACKET RH ENG FRONT	Bajaj spare parts
DH161194	STOPPER KICK	Bajaj spare parts
DH161229	BRACE FENDER	Bajaj spare parts
DH161231	LOCK <(>&<)> KEY-SIDE CVR	Bajaj spare parts
DH161233	REINFORCEMENT SEAT LOCK	Bajaj spare parts
DH161239	SPRING MAIN STAND	Bajaj spare parts

DH161240	SPRING SIDE STAND	Bajaj spare parts
DH161245	NUT U M8 X 1.25	Bajaj spare parts
DH161255	BOLT SPECIAL M8	Bajaj spare parts
DH161258	BRACE FENDER	Bajaj spare parts
DH161273	BUSH C.I.RR LH	Bajaj spare parts
DH161283	BOLT CHAIN CASE	Bajaj spare parts
DH161284	BEADING CHAIN CASE	Bajaj spare parts
DH161290	BRCKT SIDE STAND	Bajaj spare parts
DH161292	BRACKET	Bajaj spare parts
DH161293	GROMMET NO.PLATE	Bajaj spare parts
DH161297	INDICATOR MOUNTING BRACKET REAR	Bajaj spare parts
DH161301	BKT COMP RH ENG REAR	Bajaj spare parts
DH161304	BRACE FENDER ASSY	Bajaj spare parts
DH161305	GUARD SARI BLACK UG3	Bajaj spare parts
DH161309	PLUG FRONT FENDER	Bajaj spare parts
DH161330	GROMMET	Bajaj spare parts
DH161331	FRAME ASSY 150UG4	Bajaj spare parts
DH161360	COWL SEAT RED PULSAR 150	Bajaj spare parts
DH161361	COWL SEAT BLUE PULSAR 15	Bajaj spare parts
DH161362	COWL SEAT PULSAR 150	Bajaj spare parts
DH161363	Decl.Pulsar 150 Seat	Bajaj spare parts
DH161366	PAD I BATTERY BRACKET	Bajaj spare parts
DH161368	BAND BATTERY	Bajaj spare parts
DH161371	SEAT COWL Decal P-150 SILVER	Bajaj spare parts
DH161377	BOLT STEP	Bajaj spare parts
DH161386	FRAME ASSLY COMPLETE	Bajaj spare parts
DH161404	HOLDER STEP LH	Bajaj spare parts
DH161405	HOLDER STEP RH	Bajaj spare parts
DH161410	GRAB HANDLE ASSY	Bajaj spare parts
DH161416	BRACKET LOCK	Bajaj spare parts
DH161421	BRACKET FOR FLASHER / HCU	Bajaj spare parts
DH161424	FENDER REAR FRONT	Bajaj spare parts
DH161429	STRAP CANISTER	Bajaj spare parts
DH161452	DECAL FAIRING LH EBONY BLACK	Bajaj spare parts
DH161453	DECAL FAIRING RH EBONY BLACK	Bajaj spare parts
DH161454	DECAL TANK UPPER LH EBONY BLACK	Bajaj spare parts
DH161455	DECAL TANK UPPER RH EBONY BLACK	Bajaj spare parts
DH161456	DECAL TANK LOWER LH EBONY BLACK	Bajaj spare parts
DH161457	DECAL TANK LOWER RH EBONY BLACK	Bajaj spare parts
DH161458	DECAL TANK SPOILER LH EBONY BLACK	Bajaj spare parts
DH161459	DECAL TANK SPOILER RH EBONY BLACK	Bajaj spare parts
DH161460	DECAL SEAT COWL LH EBONY BLACK	Bajaj spare parts
DH161461	DECAL SEAT COWL RH EBONY BLACK	Bajaj spare parts
DH161462	SEAT COWL DECAL LH METALLIC WHITE	Bajaj spare parts
DH161463	SEAT COWL DECAL RH METALLIC WHITE	Bajaj spare parts

DH161468	MAIN STEP LH	Bajaj spare parts
DH161470	MAIN STEP RH	Bajaj spare parts
DH161471	SIDE STAND COMP	Bajaj spare parts
DH161472	ANTI-ABRASIVE TAPE(25X50X5)	Bajaj spare parts
DH161485	BRACKET LCM MTG (LOOSE)	Bajaj spare parts
DH161495	ASSLY ENG MTG BKT FRONT	Bajaj spare parts
DH161497	ASSLY BKT ENG MTG LOWER REAR	Bajaj spare parts
DH161499	FRAME ASSLY	Bajaj spare parts
DH161509	GUARD LADY FOOTREST	Bajaj spare parts
DH161510	GROMMET SARI GUARD	Bajaj spare parts
DH161516	CLAMP TUBES EVAP FRONT	Bajaj spare parts
DH161517	CLAMP EVAP ROUTING REAR	Bajaj spare parts
DH161540	BRACKET ENG MTG FRONT LOOSE UG	Bajaj spare parts
DH161551	ASSLY BRACKET ENG MTG TOP RH	Bajaj spare parts
DH161554	BRACKET FR N0. PLATE MOUNTING	Bajaj spare parts
DH161559	FLAP FENDER FRONT	Bajaj spare parts
DH161568	COVER SWITCH STAND SIDE	Bajaj spare parts
DH161569	FRAME ASSEMBLY	Bajaj spare parts
DH161572	HANGER ENGINE RH	Bajaj spare parts
DH161576	FRAME ASSEMBLY	Bajaj spare parts
DH161583	FRAME ASSEMBLY	Bajaj spare parts
DH161611	FRAME ASSEMBLY	Bajaj spare parts
DH161614	HANGER ENGINE LH	Bajaj spare parts
DH161616	FRAME ASSEMBLY	Bajaj spare parts
DH161620	BELLY PAN LH	Bajaj spare parts
DH161621	BELLY PAN RH	Bajaj spare parts
DH161622	BELLY PAN MIDDLE	Bajaj spare parts
DH161623	BRACKET BELLY PAN FRONT LH	Bajaj spare parts
DH161624	BRACKET BELLY PAN FRONT RH	Bajaj spare parts
DH161626	BRACKET BELLY PAN REAR RH	Bajaj spare parts
DH161630	BRACE FENDER FRONT	Bajaj spare parts
DH161634	FRAME ASSEMBLY	Bajaj spare parts
DH161641	HANGER ENGINE RH-HOOK	Bajaj spare parts
DH161661	BRACKET VALVE PURGE	Bajaj spare parts
DH161663	BRACKET REGULATOR	Bajaj spare parts
DH161677	BELLY PAN LH	Bajaj spare parts
DH161678	BELLY PAN RH	Bajaj spare parts
DH161679	BELLY PAN MIDDLE	Bajaj spare parts
DH161681	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
DH161686	BRACKET RELAY STARTER	Bajaj spare parts
DH161687	BRACKET SENSOR ROLL OVER	Bajaj spare parts
DH161692	BRACKET RELAY STARTER	Bajaj spare parts
DH161698	FRAME ASSEMBLY	Bajaj spare parts
DH161705	PEDAL ASSEMBLY BRAKE	Bajaj spare parts
DH161706	PEDAL BRAKE	Bajaj spare parts

DH161709	SHAFT ASSEMBLY BRAKE	Bajaj spare parts
DH161717	BOOT LINK EQUALIZER	Bajaj spare parts
DH161718	ASSEMBLY STEP RIDER LH	Bajaj spare parts
DH161719	STEP ASSEMBLY RIDER LH	Bajaj spare parts
DH161720	ASSEMBLY STEP RIDER RH	Bajaj spare parts
DH161721	STEP ASSEMBLY RIDER RH	Bajaj spare parts
DH161722	SLEEVE	Bajaj spare parts
DH161725	BRACKET SWITCH BRAKE	Bajaj spare parts
DH161731	HOLDER ECU	Bajaj spare parts
DH161732	HANGER ASSEMBLY ENGINE FRONT LH	Bajaj spare parts
DH161734	HANGER ASSEMBLY ENGINE FRONT RH	Bajaj spare parts
DH161736	HANGER ENGINE FRONT	Bajaj spare parts
DH161745	HANGER ENGINE RH	Bajaj spare parts
DH161746	BRACKET UNIT CONTROL	Bajaj spare parts
DH161749	BRACKET BELLY PAN REAR RH	Bajaj spare parts
DH161753	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
DH161756	NUT CLIP	Bajaj spare parts
DH161757	HANGER ENGINE RH	Bajaj spare parts
DH161758	HANGER ENGINE RH	Bajaj spare parts
DH161765	BRACKET COIL IGNITION RH	Bajaj spare parts
DH161768	FRAME ASSEMBLY	Bajaj spare parts
DH161771	FRAME ASSEMBLY	Bajaj spare parts
DH161775	TAPE INSULATION RH	Bajaj spare parts
DH161776	BRACKET	Bajaj spare parts
DH161777	HANGER ENGINE LH	Bajaj spare parts
DH161778	HANGER ENGINE LH	Bajaj spare parts
DH161781	BRACKET HOLDER CABLE	Bajaj spare parts
DH161788	SPRING TENSION	Bajaj spare parts
DH161803	FLAP ASSEMBLY SPEEDOMETER	Bajaj spare parts
DH161817	BELLY PAN MIDDLE	Bajaj spare parts
DH161823	STAND ASSEMBLY SIDE	Bajaj spare parts
DH161825	HOLDER STEP RIDER LH	Bajaj spare parts
DH161859	ASSEMBLY STEP RIDER LH	Bajaj spare parts
DH161862	HOLDER ECU	Bajaj spare parts
DH161865	HANGER ASSEMBLY ENGINE RH	Bajaj spare parts
DH161887	FRAME ASSEMBLY	Bajaj spare parts
DH161897	HANGER ASSEMBLY ENGINE LH	Bajaj spare parts
DH161907	BRACKET BELLY PAN REAR LH	Bajaj spare parts
DH171012	SHAFT ARM SWING	Bajaj spare parts
DH171013	COLLAR SWING ARM	Bajaj spare parts
DH171014	BUSH ARM SWING	Bajaj spare parts
DH171015	SEAL DUST ARM SWING PLSR	Bajaj spare parts
DH171019	NUT U SWING ARM	Bajaj spare parts
DH171023	SHOCK ABSORBER REAR	Bajaj spare parts
DH171024	HEX NUT (SWING ARM)	Bajaj spare parts

DH171031	SLEEVE SWING ARM	Bajaj spare parts
DH171039	SHOCKABSORBER REAR	Bajaj spare parts
DH171041	ARM ASSEMBLY SWING	Bajaj spare parts
DH171044	ARM ASSEMBLY SWING	Bajaj spare parts
DH171050	BUSH	Bajaj spare parts
DH171053	FORK FRONT	Bajaj spare parts
DH171056	BRACKET ASSEMBLY UNDER	Bajaj spare parts
DH171062	ARM ASSEMBLY SWING	Bajaj spare parts
DH171063	FORK FRONT	Bajaj spare parts
DH181009	GROMMET TOP FORK	Bajaj spare parts
DH181014	CUP - STEERING	Bajaj spare parts
DH181015	BOLT FORK	Bajaj spare parts
DH181022	WEIGHT HANDLE BAR	Bajaj spare parts
DH181025	BEARING - CONE	Bajaj spare parts
DH181026	BEARING RACE	Bajaj spare parts
DH181044	LOCK SET 4 IN 1 PULSAR D	Bajaj spare parts
DH181048	LAMP SHADE ASSY	Bajaj spare parts
DH181052	FAIRING MTG BKT UPPE	Bajaj spare parts
DH181055	HANDLEBAR UG3	Bajaj spare parts
DH181060	FORK FRONT BLACK	Bajaj spare parts
DH181063	TUBE OUTER LH BLACK	Bajaj spare parts
DH181064	TUBE OUTER RH BLACK	Bajaj spare parts
DH181066	LAMP SHADE ASSEMBLY	Bajaj spare parts
DH181069	LOCK SET 4 IN 1	Bajaj spare parts
DH181083	SPACER TUBE FORK FR	Bajaj spare parts
DH181086	FORK FRONT	Bajaj spare parts
DH181087	FORK PIPE SPINNING	Bajaj spare parts
DH181091	HOLDER FORK UPPER	Bajaj spare parts
DH181092	LAMP SHADE ASSY	Bajaj spare parts
DH181094	HANDLE HOLDER	Bajaj spare parts
DH181096	HOLDER HANDLE RH	Bajaj spare parts
DH181099	PLUG HANDLE HOLDER	Bajaj spare parts
DH181100	FORK FRONT	Bajaj spare parts
DH181101	TUBE OUTER RH	Bajaj spare parts
DH181103	HANDLE HOLDER LH (BLACK)	Bajaj spare parts
DH181104	HANDLE HOLDER RH (BLACK)	Bajaj spare parts
DH181105	BRACKET UPPER	Bajaj spare parts
DH181107	HANDLE HOLDER LH	Bajaj spare parts
DH181109	HANDLE HOLDER RH	Bajaj spare parts
DH181112	HANDLE HOLDER RH	Bajaj spare parts
DH181115	STEERING TOP BOLT	Bajaj spare parts
DH181119	LOCK SET 3 IN 1	Bajaj spare parts
DH181122	NUT STEERING K1 UG	Bajaj spare parts
DH181123	FORK FRONT UG	Bajaj spare parts
DH181124	ASSLY LEG LH	Bajaj spare parts

DH181125	ASSLY LEG RH	Bajaj spare parts
DH181126	PIPE SEAT	Bajaj spare parts
DH181127	PIPE FORK INNER	Bajaj spare parts
DH181128	TUBE SPACER	Bajaj spare parts
DH181129	SPRING MAIN	Bajaj spare parts
DH181130	LOCK SET EVAP SINGLE TRACK KEY	Bajaj spare parts
DH181131	HOLDER HANDLE BAR LH	Bajaj spare parts
DH181133	HOLDER HANDLE BAR RH	Bajaj spare parts
DH181135	HOLDER FORK UPPER	Bajaj spare parts
DH191001	LEVER BRAKE	Bajaj spare parts
DH191006	SPRING PEDAL BRAKE	Bajaj spare parts
DH191007	GRIP - HAND :- LH	Bajaj spare parts
DH191008	GRIP HAND RH	Bajaj spare parts
DH191010	CABLE CLUTCH PULSAR DTSI	Bajaj spare parts
DH191012	SPRING SWITCH BRAKE	Bajaj spare parts
DH191013	SPACER ASSY BRAKE SHAFT	Bajaj spare parts
DH191014	Grip assembly RH	Bajaj spare parts
DH191017	PIPE THROTTLE	Bajaj spare parts
DH191018	PAD LEVER BRAKE	Bajaj spare parts
DH191019	BOOT FOR LEVER	Bajaj spare parts
DH191023	CUP FOR BRAKE SHAFT	Bajaj spare parts
DH191025	COVER METER UPPER BLACK	Bajaj spare parts
DH191037	"LAMP 12V,"	Bajaj spare parts
DH191041	CABLE CLUTCH PULSAR DTSI	Bajaj spare parts
DH191056	INSTRUMENT CLUSTER	Bajaj spare parts
DH191060	KIT FASTENING CAP	Bajaj spare parts
DH191062	KIT OIL LEVEL WINDOW	Bajaj spare parts
DH191065	SPEEDOMETER	Bajaj spare parts
DH191066	ASSLY SPEEDOMETER K1UG	Bajaj spare parts
DH191067	GRIP HAND LH	Bajaj spare parts
DH191068	GRIP HAND RH	Bajaj spare parts
DH191069	GRIP ASSLY HAND RH	Bajaj spare parts
DH191070	SPEEDOMETER	Bajaj spare parts
DH191071	SPEEDOMETER	Bajaj spare parts
DH191074	SPEEDOMETER	Bajaj spare parts
DH191075	SPEEDOMETER ABS	Bajaj spare parts
DH191076	SPEEDOMETER	Bajaj spare parts
DH191077	SPEEDOMETER	Bajaj spare parts
DH191081	SPEEDOMETER	Bajaj spare parts
DH191082	CABLE THROTTLE	Bajaj spare parts
DH191083	CABLE BRAKE	Bajaj spare parts
DH191084	SPEEDOMETER	Bajaj spare parts
DH191085	SPEEDOMETER	Bajaj spare parts
DH191086	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
DH191087	CABLE THROTTLE	Bajaj spare parts

DH191088	CABLE BRAKE PEDAL-PANEL FRONT	Bajaj spare parts
DH191089	SPEEDOMETER	Bajaj spare parts
DH191094	CABLE BRAKE FRONT	Bajaj spare parts
DH191095	CLAMP	Bajaj spare parts
DH191097	CABLE THROTTLE	Bajaj spare parts
DH191099	SPEEDOMETER	Bajaj spare parts
DH191102	SPEEDOMETER	Bajaj spare parts
DH191103	SPEEDOMETER	Bajaj spare parts
DH191109	PIN	Bajaj spare parts
DH191115	INSTRUMENT CLUSTER	Bajaj spare parts
DH191116	INSTRUMENT CLUSTER	Bajaj spare parts
DH191117	INSTRUMENT CLUSTER	Bajaj spare parts
DH191121	CABLE THROTTLE	Bajaj spare parts
DH191125	INSTRUMENT CLUSTER	Bajaj spare parts
DH201018	UNIT REGULATOR & RECTIFIER	Bajaj spare parts
DH201038	UNIT TANK IMPROVED RESERVE	Bajaj spare parts
DH201048	H.BAR CONT.SWITCH LH	Bajaj spare parts
DH201049	SWITCH H BAR CONTROL	Bajaj spare parts
DH201055	SWITCH SIDE STAND	Bajaj spare parts
DH201062	UNIT TANK UG3	Bajaj spare parts
DH201065	MAGNET ASSEMBLY	Bajaj spare parts
DH201076	DC HORN LH	Bajaj spare parts
DH201077	DC HORN RH	Bajaj spare parts
DH201078	HARNESS WIRING (KS)	Bajaj spare parts
DH201079	SENSOR SPEED-ASSEMBLY	Bajaj spare parts
DH201080	SENSOR SPEED-CABLE	Bajaj spare parts
DH201081	CASING ASSEMBLY	Bajaj spare parts
DH201084	RELAY KILL	Bajaj spare parts
DH201085	WIRING HARNESS (SS) P-150	Bajaj spare parts
DH201086	WIRING HARNESS	Bajaj spare parts
DH201090	MAIN WIRING HARNESS (LCM)	Bajaj spare parts
DH201091	WIRING HARNESS W/O LCM	Bajaj spare parts
DH201093	SWITCH SIDE STAND	Bajaj spare parts
DH201095	HARNESS WIRING K1-UG	Bajaj spare parts
DH201096	CABLE EARTHING K1 UG	Bajaj spare parts
DH201098	HARNESS WIRING	Bajaj spare parts
DH201105	HARNESS WIRING AHO BSIV	Bajaj spare parts
DH201106	HARNESS WIRING	Bajaj spare parts
DH201107	HARNESS WIRING	Bajaj spare parts
DH201109	HARNESS WIRING	Bajaj spare parts
DH201110	HARNESS WIRING ABS	Bajaj spare parts
DH201111	SWITCH CONTROL LH	Bajaj spare parts
DH201112	SWITCH CONTROL RH	Bajaj spare parts
DH201113	HARNESS WIRING	Bajaj spare parts
DH201120	HARNESS WIRING ABS	Bajaj spare parts

DH201124	RELAY STARTER	Bajaj spare parts
DH201128	HARNESS WIRING	Bajaj spare parts
DH201130	CABLE HARNESS	Bajaj spare parts
DH201131	HARNESS WIRING	Bajaj spare parts
DH201132	HARNESS WIRING	Bajaj spare parts
DH201135	HARNESS WIRING	Bajaj spare parts
DH201141	HARNESS WIRING	Bajaj spare parts
DH201144	HORN	Bajaj spare parts
DH201145	HARNESS WIRING	Bajaj spare parts
DH201154	HARNESS WIRING	Bajaj spare parts
DH201156	SWITCH CONTROL RH	Bajaj spare parts
DH201157	SENSOR SPEED	Bajaj spare parts
DH201158	UNIT REGULATOR	Bajaj spare parts
DH201162	HARNESS WIRING	Bajaj spare parts
DH201163	HORN	Bajaj spare parts
DH201164	BULB	Bajaj spare parts
DH201168	HARNESS WIRING	Bajaj spare parts
DH201172	CABLE RELAY-MOTOR STARTER	Bajaj spare parts
DH201173	HARNESS WIRING	Bajaj spare parts
DH201174	HARNESS WIRING	Bajaj spare parts
DH201175	HARNESS WIRING	Bajaj spare parts
DH201177	HARNESS WIRING	Bajaj spare parts
DH201180	HARNESS WIRING	Bajaj spare parts
DH201195	HARNESS WIRING	Bajaj spare parts
DH201205	HARNESS WIRING	Bajaj spare parts
DH201206	HARNESS WIRING	Bajaj spare parts
DH201224	HARNESS WIRING	Bajaj spare parts
DH201235	CABLE EARTH	Bajaj spare parts
DH201243	HARNESS WIRING	Bajaj spare parts
DH201246	HARNESS WIRING	Bajaj spare parts
DH201251	HARNESS WIRING	Bajaj spare parts
DH201264	HARNESS WIRING	Bajaj spare parts
DH211005	BAND TOOL KIT	Bajaj spare parts
DH211012	SEAT ASSLY	Bajaj spare parts
DH211019	CABLE LATCH SEAT	Bajaj spare parts
DH221012	LEG GUARD LH UG	Bajaj spare parts
DH221013	LEG GUARD RH UG	Bajaj spare parts
DH221023	GUARD SAREE	Bajaj spare parts
DH71034L	TANK FUEL UG4 MISTY GRE	Bajaj spare parts
DH73032V	SEAT COWL ASSLY-COCKT WINE RED	Bajaj spare parts
DH73034K	SEAT COWL PLASM BLUE W/O	Bajaj spare parts
DH73034M	SEAT COWL MID BLACK PULSAR 150 UG4	Bajaj spare parts
DH74014K	FAIRING PL BLUE UG4	Bajaj spare parts
DH74014M	FAIRING MID BLACK U	Bajaj spare parts
DH910000	UNIT ABS WET	Bajaj spare parts



DH990000	SEAT ASSLY VALVE	Bajaj spare parts
DH990004	CABLE HARNESS	Bajaj spare parts
DH990005	SWITCH UNIT HEATER	Bajaj spare parts
DJ010024	DISC BRAKE KT MICRO	Bajaj spare parts
DJ010025	DISC BRAKE KIT MICRO	Bajaj spare parts
DJ010117	DECAL COWL SEAT UPR LH RED-SLVR	Bajaj spare parts
DJ010165	DECAL DOME TANK SPORTY ORANGE	Bajaj spare parts
DJ010166	DECAL FAIRING LH SPORTY ORANGE	Bajaj spare parts
DJ010168	DECAL FAIRING FRONT LH P RED	Bajaj spare parts
DJ010170	DECAL DOME TANK PASSION RED	Bajaj spare parts
DJ010171	DECAL COWL SEAT PASSION RED	Bajaj spare parts
DJ010172	DECAL FAIRING LH PASSION RED	Bajaj spare parts
DJ010174	DECAL FAIRING FRONT LH PM SILVER	Bajaj spare parts
DJ010176	DECAL DOME TANK PLATINUM SILVER	Bajaj spare parts
DJ010177	DECAL COWL SEAT PLATINUM SILVER	Bajaj spare parts
DJ010178	DECAL FAIRING LH PLATINUM SILVER	Bajaj spare parts
DJ010179	DECAL FAIRING RH PLATINUM SILVER	Bajaj spare parts
DJ010182	DECAL DOME TANK LIME GREEN	Bajaj spare parts
DJ010186	DECAL COWL SEAT SPORTY ORANGE	Bajaj spare parts
DJ010188	DECAL BELLY PAN LH SPORTY ORANGE	Bajaj spare parts
DJ010189	DECAL BELLY PAN RH SPORTY ORANGE	Bajaj spare parts
DJ010190	DECAL BELLY PAN LH PASSION RED	Bajaj spare parts
DJ010191	DECAL BELLY PAN RH PASSION RED	Bajaj spare parts
DJ010192	DECAL BELLY PAN LH PM SILVER	Bajaj spare parts
DJ010193	DECAL BELLY PAN RH PM SILVER	Bajaj spare parts
DJ010196	DECAL BELLY PAN LH EBONY BLK RED	Bajaj spare parts
DJ010197	DECAL BELLY PAN LH E BLK P SILVR	Bajaj spare parts
DJ010198	DECAL BELLY PAN LH C BLK S ORANG	Bajaj spare parts
DJ010202	DECAL BELLY PAN RH E BLACK RED	Bajaj spare parts
DJ010203	DECAL BELLY PAN RH E BLK P SILVR	Bajaj spare parts
DJ010204	DECAL BELLY PAN RH C BLK S ORANG	Bajaj spare parts
DJ101004	GASKET CYLINDER	Bajaj spare parts
DJ101006	HEAD CYLINDER PULSAR	Bajaj spare parts
DJ101010	VALVE INTAKE PULSAR DTSI	Bajaj spare parts
DJ101012	GASKET HEAD CYLINDER	Bajaj spare parts
DJ101027	CLUTCH CENTER	Bajaj spare parts
DJ101063	PLATE DRIVE SPROCKET	Bajaj spare parts
DJ101064	GASKET EXHAUST	Bajaj spare parts
DJ101106	RING SET PISTON STD PULSA	Bajaj spare parts
DJ101109	BUSH SPRING STARTER	Bajaj spare parts
DJ101110	GEAR 1ST DRIVEN	Bajaj spare parts
DJ101114	SHAFT OUTPUT	Bajaj spare parts
DJ101122	CLUTCH CENTER	Bajaj spare parts
DJ101125	VALVE EXHAUST	Bajaj spare parts
DJ101137	DECOMP ASSY	Bajaj spare parts

DJ101150	PLATE ASSY CLUTCH PULSAR	Bajaj spare parts
DJ101158	PISTON ASSY PULSAR	Bajaj spare parts
DJ101179	CLUTCH CENTER	Bajaj spare parts
DJ101213	CRANKCASE RH PULSAR	Bajaj spare parts
DJ101216	TENSIONER ASSEMBLY	Bajaj spare parts
DJ101217	COVER TAPPET PULSAR	Bajaj spare parts
DJ101225	CRANKCASE LH PULSAR	Bajaj spare parts
DJ101232	CARBURETTOR ASSEMBLY	Bajaj spare parts
DJ101253	HEAD CYLINDER	Bajaj spare parts
DJ101268	COVER ASSEMBLY LH RR	Bajaj spare parts
DJ101269	HEAD CYLINDER WITH C	Bajaj spare parts
DJ101275	CLUTCH PLATE ASSEMBL	Bajaj spare parts
DJ101300	BOLT FLANGE	Bajaj spare parts
DJ101302	BOLT FLANGE	Bajaj spare parts
DJ101305	BOLT FLANGE	Bajaj spare parts
DJ101312	PLATE DRIVE SPROCKET	Bajaj spare parts
DJ101314	PAN HEAD SCREW	Bajaj spare parts
DJ101325	CYL BL. ASSY Pulsr180	Bajaj spare parts
DJ101326	CYL BLOCK PULSAR 180-K2	Bajaj spare parts
DJ101327	CYL BLOCK ASSY PULSAR	Bajaj spare parts
DJ101344	C'CASE COMP LH	Bajaj spare parts
DJ101349	CENTER ASSLY.CLUTCH(FCC)	Bajaj spare parts
DJ101350	CLUTCH ASSLY D115	Bajaj spare parts
DJ101369	PLATE FRICTION KIT 180CC	Bajaj spare parts
DJ101371	BLOCK PISTON (DJ FO	Bajaj spare parts
DJ101372	CAM SHAFT (DJ ON JC)	Bajaj spare parts
DJ101373	CAMSHAFT 220F	Bajaj spare parts
DJ101389	ENGINE ASSY PLSR 180	Bajaj spare parts
DJ101390	CYL HEAD + COVER UG4	Bajaj spare parts
DJ101391	SILENCERDJUG4 W/O SHIELD(	Bajaj spare parts
DJ101662	SHIELD EXHAUST ORNG METT	Bajaj spare parts
DJ101672	ASSEMBLY ENGINE WITH MLT COVER	Bajaj spare parts
DJ101675	ASSLY SILENCER VAVE	Bajaj spare parts
DJ101689	ASSEMBLY BALANCER	Bajaj spare parts
DJ101705	DAMPER CRANKSHAFT	Bajaj spare parts
DJ101710	HOSE SAI UNIT TO PIPE SAI	Bajaj spare parts
DJ101712	ENGINE ASSLY BS IV_SAI	Bajaj spare parts
DJ101717	HEAD CYLINDER-COVER ASSEMBLY	Bajaj spare parts
DJ101738	SLEEVE PLUG SPARK	Bajaj spare parts
DJ101743	ENGINE ASSEMBLY	Bajaj spare parts
DJ101745	SILENCER ASSEMBLY	Bajaj spare parts
DJ101748	ENGINE ASSEMBLY	Bajaj spare parts
DJ101766	SILENCER ASSEMBLY	Bajaj spare parts
DJ101777	ENGINE ASSEMBLY	Bajaj spare parts
DJ101786	CRANKSHAFT ASSEMBLY	Bajaj spare parts

DJ101788	CAMSHAFT ASSEMBLY	Bajaj spare parts
DJ101794	SILENCER ASSEMBLY	Bajaj spare parts
DJ101811	HEAD CYLINDER-COVER ASSEMBLY	Bajaj spare parts
DJ101815	PISTON ASSEMBLY	Bajaj spare parts
DJ101822	ENGINE ASSEMBLY	Bajaj spare parts
DJ101858	SILENCER ASSEMBLY	Bajaj spare parts
DJ111004	STATOR ASSYPULSAR DTSI	Bajaj spare parts
DJ111008	CDI PULSAR DTSI	Bajaj spare parts
DJ111021	STATOR ASSYSSMODI	Bajaj spare parts
DJ111023	CDI ANALOG	Bajaj spare parts
DJ111024	MOTOR STARTER	Bajaj spare parts
DJ111059	STATOR ASSY	Bajaj spare parts
DJ111061	ROTOR ASSY COMPLETE	Bajaj spare parts
DJ111063	MOTOR STARTER	Bajaj spare parts
DJ111070	BRUSH ASSY KIT	Bajaj spare parts
DJ111092	DC CDI UNIT	Bajaj spare parts
DJ111094	STATOR ASSY 15.2 MM CORE	Bajaj spare parts
DJ111098	CDI NON TPS ASSLY K2	Bajaj spare parts
DJ121022	INSULATOR CARBURETTOR	Bajaj spare parts
DJ121030	INSULATOR CARB	Bajaj spare parts
DJ121039	TUBE CONNECTING	Bajaj spare parts
DJ121041	CARBURETTOR ASSY	Bajaj spare parts
DJ121044	JET NEEDLEJN	Bajaj spare parts
DJ121051	VACUUM PISTON KIT	Bajaj spare parts
DJ121052	IDLING SCREW KIT	Bajaj spare parts
DJ121053	RING O	Bajaj spare parts
DJ121054	SCREW	Bajaj spare parts
DJ121055	FLOAT ASSEMBLY	Bajaj spare parts
DJ121056	JET HOLDER KIT	Bajaj spare parts
DJ121057	NEEDLE ASSEMBLY	Bajaj spare parts
DJ121058	SET ADJUSTER	Bajaj spare parts
DJ121059	SET PLUNGER ASSEMBLY	Bajaj spare parts
DJ121068	TUBE CONNECTING	Bajaj spare parts
DJ121070	SWITCH REED	Bajaj spare parts
DJ121071	FILTER AIR (DJ UG4)	Bajaj spare parts
DJ121079	CARBURETTOR BS 29	Bajaj spare parts
DJ121080	ASSELY AIR FILTER	Bajaj spare parts
DJ121081	TUBE CONNECTING BS29	Bajaj spare parts
DJ121082	CARTRIDGE ASSLY	Bajaj spare parts
DJ121087	ASSLY AIR CLEANER COMP	Bajaj spare parts
DJ121089	TUBE SAI AIR FILTER	Bajaj spare parts
DJ121090	ASSLY MANIFOLD WITH NIPPLE	Bajaj spare parts
DJ121091	CARBURETTOR ASSLY FOR EVAP	Bajaj spare parts
DJ121094	CARBURETTOR ASSLY WITHOUT EVAP	Bajaj spare parts
DJ121096	INSULATOR INTEGRAL MANIFOLD	Bajaj spare parts

DJ121138	SLEEVE MANIFOLD	Bajaj spare parts
DJ121139	FILTER ASSEMBLY AIR	Bajaj spare parts
DJ121141	BODY THROTTLE ASSEMBLY	Bajaj spare parts
DJ121142	INJECTOR	Bajaj spare parts
DJ121143	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
DJ141002	CLAMP PIPE DRAIN	Bajaj spare parts
DJ141006	PIPE FUEL	Bajaj spare parts
DJ141008	DAMPER FRONT	Bajaj spare parts
DJ141056	FUEL COCK	Bajaj spare parts
DJ141061	BEADING (ON TANK FLAP)	Bajaj spare parts
DJ141070	TUBE CANISTER TO CONNECTOR	Bajaj spare parts
DJ141071	TUBE PURGE VALVE TO CARBURETOR	Bajaj spare parts
DJ141072	TUBE TANK TO T CONNECTOR	Bajaj spare parts
DJ141073	TUBE T CONNECTOR TO CANISTER	Bajaj spare parts
DJ141074	TUBE CONDENSATE FUEL DRAIN	Bajaj spare parts
DJ141077	TUBE CONNECTOR TO PURGE VALVE	Bajaj spare parts
DJ141078	TUBE FUEL	Bajaj spare parts
DJ151032	AXLE REAR PULSAR	Bajaj spare parts
DJ151033	SLEEVE	Bajaj spare parts
DJ151034	COLLAR	Bajaj spare parts
DJ151035	COLLAR	Bajaj spare parts
DJ151036	ADJUSTER CHAIN	Bajaj spare parts
DJ151037	ADJUSTER CHAIN RH	Bajaj spare parts
DJ151041	AXLE PULSAR 180	Bajaj spare parts
DJ151042	ROD TORQUE	Bajaj spare parts
DJ151047	PLATE ADJUSTER CHAIN	Bajaj spare parts
DJ151053	LOCK DRIVE CHAIN	Bajaj spare parts
DJ151057	CASE METER GEAR PULSAR DT	Bajaj spare parts
DJ151059	LEVER BRAKE REAR	Bajaj spare parts
DJ151067	CALIPER ETS ASSLY	Bajaj spare parts
DJ151068	SPRING PAD	Bajaj spare parts
DJ151069	BLEEDER SCREW	Bajaj spare parts
DJ151070	BLEEDER CAP	Bajaj spare parts
DJ151071	KIT DISC PAD PUL DTSI	Bajaj spare parts
DJ151072	PROTECTION BOOT	Bajaj spare parts
DJ151073	PROTECTION BOOT	Bajaj spare parts
DJ151074	KIT MINOR CALIPER PULSAR	Bajaj spare parts
DJ151075	KIT MAJOR CALIPER	Bajaj spare parts
DJ151076	HOSE BRAKE FRONT	Bajaj spare parts
DJ151077	WHEEL 1.6 X 17 DC BLACK	Bajaj spare parts
DJ151087	WHEEL DIECAST 2.5X174 LUG	Bajaj spare parts
DJ151088	COUPLING RUBBER	Bajaj spare parts
DJ151092	PANEL RR BRAKE	Bajaj spare parts
DJ151094	ROTOR SPEEDO	Bajaj spare parts
DJ151096	CHAIN 124 LINK -	Bajaj spare parts

DJ151111	COUPLING ASSY	Bajaj spare parts
DJ151119	PANEL REAR BRAKE	Bajaj spare parts
DJ151121	SPRING REAR BRAKE SWITCH	Bajaj spare parts
DJ151137	CALIPER ASSEMBLY REAR	Bajaj spare parts
DJ151144	CYLINDER ASSEMBLY MASTER FRONT	Bajaj spare parts
DJ161006	PAD I - RUBBER	Bajaj spare parts
DJ161007	PAD II - RUBBER	Bajaj spare parts
DJ161012	LABEL - GEAR SHIFT	Bajaj spare parts
DJ161068	GUIDE CABLE	Bajaj spare parts
DJ161069	NAIL CABLE GUIDE	Bajaj spare parts
DJ161072	BRCKT RR NUMBE	Bajaj spare parts
DJ161073	PLATE ASSY NUMBER REAR	Bajaj spare parts
DJ161079	FOAM LH FOR GRAB	Bajaj spare parts
DJ161080	FOAM RH FOR GRAB	Bajaj spare parts
DJ161088	BRACKETLH ENGINE	Bajaj spare parts
DJ161089	BRACKET RH ENG HANGE	Bajaj spare parts
DJ161090	DAMPER FOOT STEP	Bajaj spare parts
DJ161091	GROMMET FENDER FRONT	Bajaj spare parts
DJ161122	RUBBER STEP PILLION	Bajaj spare parts
DJ161126	STEP MAIN LH PULSAR /DIS	Bajaj spare parts
DJ161127	STEP MAIN RH PULSAR	Bajaj spare parts
DJ161128	STEP PILLION LH PULSAR D	Bajaj spare parts
DJ161129	STEP PILL.RH PULSAR	Bajaj spare parts
DJ161130	STEP MAIN LH PULSAR DTS-I	Bajaj spare parts
DJ161131	STEP MAIN RH PUL DTS-I	Bajaj spare parts
DJ161132	HOOK HARNESS LH	Bajaj spare parts
DJ161133	HOOK HARNESS RH	Bajaj spare parts
DJ161186	PLATE-SIDE pillon	Bajaj spare parts
DJ161214	STAND CENTER	Bajaj spare parts
DJ161218	STAND SIDE	Bajaj spare parts
DJ161221	COVER MUD RR	Bajaj spare parts
DJ161224	GUARD SARI BLACK PULSAR D	Bajaj spare parts
DJ161226	KIT LEG GUARD BLACK PULS	Bajaj spare parts
DJ161227	LABEL INSTRUCTIONBL	Bajaj spare parts
DJ161228	LABEL GEAR SHIFT-BLACK	Bajaj spare parts
DJ161229	CLIP NUT M5	Bajaj spare parts
DJ161247	BAND BATTERY PLSR 18	Bajaj spare parts
DJ161254	FENDER RR UG3	Bajaj spare parts
DJ161256	HOLDER STEP LH UG3	Bajaj spare parts
DJ161257	HOLDER STEP RH UG3	Bajaj spare parts
DJ161263	GRAB HANDLE UG3	Bajaj spare parts
DJ161278	TUBE SILENCER WITH WASHER	Bajaj spare parts
DJ161285	BOLT MAIN STEP	Bajaj spare parts
DJ161290	CHASS.NO. PROT TAPE	Bajaj spare parts
DJ161291	GROMMET SARI GUARD	Bajaj spare parts

DJ161295	DECAL PULSAR 180 RE	Bajaj spare parts
DJ161296	DECAL PULSAR PL BLUE	Bajaj spare parts
DJ161297	DECAL PULSAR 180 SLV	Bajaj spare parts
DJ161298	DECAL PULSR 180 MID BLK	Bajaj spare parts
DJ161301	ENGINE HANGER MTG BKT LH	Bajaj spare parts
DJ161302	ENGINE HANGER MTG BKT RH	Bajaj spare parts
DJ161304	COWL SEAT RED PULSAR 180	Bajaj spare parts
DJ161305	COWL SEAT BLUE PULSAR 18	Bajaj spare parts
DJ161306	DECAL PULSAR 180 SEAT	Bajaj spare parts
DJ161307	COWL SEAT BLACK PULSAR 18	Bajaj spare parts
DJ161313	SEAT COWL P 180 SILVER	Bajaj spare parts
DJ161314	DECAL PULSAR 180 SEAT COW	Bajaj spare parts
DJ161324	HOLDER STEP RH-DRUM	Bajaj spare parts
DJ161327	BRACKET LCM MTG (LOOSE)	Bajaj spare parts
DJ161379	DECAL SEAT COWL LH EBONY BLACK	Bajaj spare parts
DJ161380	DECAL SEAT COWL RH EBONY BLACK	Bajaj spare parts
DJ161385	BRACKET REAR BRAKE SWITCH	Bajaj spare parts
DJ161400	ASSLY FRAME EVAP	Bajaj spare parts
DJ161403	TANK 3D DECAL SATIN CHROME LH	Bajaj spare parts
DJ161404	TANK 3D DECAL SATIN CHROME RH	Bajaj spare parts
DJ161412	DECAL TANK 3D ROUSER SHADOW	Bajaj spare parts
DJ161416	DECAL 3D PULSAR	Bajaj spare parts
DJ161420	FRAME ASSEMBLY	Bajaj spare parts
DJ161433	HANGER ENGINE RH	Bajaj spare parts
DJ161436	BRACKET HOLDER MAGNET	Bajaj spare parts
DJ161438	BELLY PAN LH	Bajaj spare parts
DJ161439	BELLY PAN RH	Bajaj spare parts
DJ161440	BELLY PAN MIDDLE	Bajaj spare parts
DJ161441	BRACKET ASSEMBLY HARNESS	Bajaj spare parts
DJ161444	FRAME ASSEMBLY	Bajaj spare parts
DJ161445	FOAM	Bajaj spare parts
DJ161447	FRAME ASSEMBLY	Bajaj spare parts
DJ161449	BRACKET ASSY PLATE NUMBER FRONT	Bajaj spare parts
DJ161463	BRACKET BELLY PAN FRONT LH	Bajaj spare parts
DJ161464	BRACKET BELLY PAN FRONT RH	Bajaj spare parts
DJ161466	BRACKET BELLY PAN REAR RH	Bajaj spare parts
DJ161475	FRAME ASSEMBLY	Bajaj spare parts
DJ171008	CHAIN SLIDER	Bajaj spare parts
DJ171019	SHOCK ABSORBER RR PULSAR	Bajaj spare parts
DJ171031	ARM SWING	Bajaj spare parts
DJ171033	NUT U SWING ARM	Bajaj spare parts
DJ171035	ARM SWING ASSY	Bajaj spare parts
DJ171039	OIL SEAL	Bajaj spare parts
DJ171044	ADJUSTER CHAIN K2 K3 UG	Bajaj spare parts
DJ181011	WEIGHT HANDLEBAR	Bajaj spare parts

DJ181026	BRACKET FAIRING MOUNT	Bajaj spare parts
DJ181029	COLLAR FAIRING MOUNTING	Bajaj spare parts
DJ181033	WINDSHIELD PULSAR DTS-I	Bajaj spare parts
DJ181037	DECAL WINDSHIELD	Bajaj spare parts
DJ181041	HOLDER FORK UNDER	Bajaj spare parts
DJ181043	COVER FORK PULSAR DTSI	Bajaj spare parts
DJ181044	BELLOW FORK	Bajaj spare parts
DJ181052	TRAIL B(31 BLACK)	Bajaj spare parts
DJ181064	GROMMET MOUNTING FAIRING	Bajaj spare parts
DJ181065	NUT CLIP M6	Bajaj spare parts
DJ181067	HANDLE BAR PULSAR DTSI	Bajaj spare parts
DJ181069	PACKING FAIRING	Bajaj spare parts
DJ181083	SLEEVE	Bajaj spare parts
DJ181085	CUSHION RUBBER 31	Bajaj spare parts
DJ181086	PIPE FORK INNER 31 DIA. F	Bajaj spare parts
DJ181087	SEAL OIL FORK	Bajaj spare parts
DJ181088	STOPPER - OIL SEAL	Bajaj spare parts
DJ181089	SEAL DUST PULSAR DTS-I	Bajaj spare parts
DJ181090	FAIRING W/O MASKING	Bajaj spare parts
DJ181101	TUBE OUTER LH PULSAR DTS	Bajaj spare parts
DJ181102	TUBE OUTER RH PULSAR DT	Bajaj spare parts
DJ181103	PIPE FORK INNER	Bajaj spare parts
DJ181104	SPRING MAIN WITH SPACER T	Bajaj spare parts
DJ181110	LOCK SET 4 IN 1 MODULAR I	Bajaj spare parts
DJ181115	CAGE BEARING STEERING	Bajaj spare parts
DJ181117	FAIRING UG3	Bajaj spare parts
DJ181119	COVER SPEEDOMETER	Bajaj spare parts
DJ181120	HEAD LAMP MASK UG3	Bajaj spare parts
DJ181126	FOAM TAPE 25X15X2	Bajaj spare parts
DJ181130	SCREW FOR BACK COVER	Bajaj spare parts
DJ181131	WHEEL SPACER	Bajaj spare parts
DJ181137	CAP FORK	Bajaj spare parts
DJ191003	CABLE ACC PULSAR	Bajaj spare parts
DJ191004	HOLDER LH	Bajaj spare parts
DJ191005	CABLE SPEEDOMETER PULSAR	Bajaj spare parts
DJ191006	LEVER GRIP RH	Bajaj spare parts
DJ191008	CABLE ACCELERATOR PLSR DT	Bajaj spare parts
DJ191010	ROD BRAKE	Bajaj spare parts
DJ191013	CABLE ACCELERATOR PULSAR	Bajaj spare parts
DJ191014	CABLE ACCELERATOR PULSAR	Bajaj spare parts
DJ191015	CABLE CLUTCH PULSAR	Bajaj spare parts
DJ191021	LEVER - BRAKE	Bajaj spare parts
DJ191023	KIT MAJOR MASTER CYL PULS	Bajaj spare parts
DJ191024	LEVER GRIP RH ETS	Bajaj spare parts
DJ191025	BANJO BOLT	Bajaj spare parts

DJ191027	CLAMP HOLDER RH	Bajaj spare parts
DJ191028	BOLT CLAMP HOLDER	Bajaj spare parts
DJ191029	BOLT FR BRAKE LEVR	Bajaj spare parts
DJ191030	NUT FR BRAKE LEVER	Bajaj spare parts
DJ191031	SCREW	Bajaj spare parts
DJ191032	CYLINDER MASTER	Bajaj spare parts
DJ191034	RESERVOIR CAP	Bajaj spare parts
DJ191035	DIAPHRAGM	Bajaj spare parts
DJ191050	CABLE INNER SPEEDOMETER P	Bajaj spare parts
DJ191053	HOLDER ASSY LH CLUTCH SWITCH	Bajaj spare parts
DJ191054	HOLDER LH CLUTCH SWITCH	Bajaj spare parts
DJ191055	LEVER FOR CL.SWIT	Bajaj spare parts
DJ191056	CYL MASTER MICRO KBX	Bajaj spare parts
DJ191057	LEVER BRAKE FRONT MICRO S	Bajaj spare parts
DJ191058	CYL MASTER MICRO SW	Bajaj spare parts
DJ191059	LEVER BRAKE FR MICRO	Bajaj spare parts
DJ191061	CABLE ACC UG3	Bajaj spare parts
DJ191069	LEVER & SUPPORT HOLD	Bajaj spare parts
DJ191070	INSTRUMENT CLUSTER	Bajaj spare parts
DJ191071	INSTRUMENT CLUSTER P	Bajaj spare parts
DJ191081	HOLDER LH	Bajaj spare parts
DJ191082	LEVER &SUPPORT HOLDER ASSY	Bajaj spare parts
DJ191083	LEVER GRIP LEFT	Bajaj spare parts
DJ191084	SPEEDOMETER ASSY	Bajaj spare parts
DJ191085	SPEEDOMETER ASSLY	Bajaj spare parts
DJ191086	SPEEDOMETER	Bajaj spare parts
DJ191088	SPEEDOMETER	Bajaj spare parts
DJ191089	SPEEDOMETER	Bajaj spare parts
DJ191090	CABLE THROTTLE	Bajaj spare parts
DJ191091	SPEEDOMETER ABS	Bajaj spare parts
DJ191092	CABLE THROTTLE	Bajaj spare parts
DJ191099	SPEEDOMETER	Bajaj spare parts
DJ201016	REGULATOR	Bajaj spare parts
DJ201020	CABLE BATTERY PULSAR DTS	Bajaj spare parts
DJ201021	CABLE ASSY BATTERY	Bajaj spare parts
DJ201028	RELAY INTERLOCKING	Bajaj spare parts
DJ201035	CABLE ASSEMBLY	Bajaj spare parts
DJ201046	RIM HEAD LIGHT PULSAR / C	Bajaj spare parts
DJ201049	LENS BLINKER FR LH PULSAR	Bajaj spare parts
DJ201050	LENS BLINKER FR RH PULSAR	Bajaj spare parts
DJ201051	REFLECTOR WITH LENS	Bajaj spare parts
DJ201052	CABLE BRAKE FR PULSAR DTS	Bajaj spare parts
DJ201072	LAMP POSITION 12V / 5W	Bajaj spare parts
DJ201081	SWITCH REED PULSAR DTSI	Bajaj spare parts
DJ201100	SWITCH REAR BRAKE	Bajaj spare parts



DJ201102	REGULATOR	Bajaj spare parts
DJ201104	LAMP HEAD PULSAR DTS-I UG	Bajaj spare parts
DJ201106	MAGNET ASSY	Bajaj spare parts
DJ201108	CABLE BRAKE FR PULSAR DT	Bajaj spare parts
DJ201109	SWITCH FRONT BRAKE PULSA	Bajaj spare parts
DJ201112	SWITCH CONTROL RH KILL PU	Bajaj spare parts
DJ201113	BLINKER FLEXIBI R LH PU	Bajaj spare parts
DJ201114	BLINKER REAR RH	Bajaj spare parts
DJ201127	HARNESS WIRING P	Bajaj spare parts
DJ201132	LAMP HEAD ASSLY	Bajaj spare parts
DJ201137	COVER ELECT. CLUSTER HARNESS COUPLER	Bajaj spare parts
DJ201140	CABLE ASY.BATTERY T	Bajaj spare parts
DJ201141	SWITCH ELECTRONIC CO	Bajaj spare parts
DJ201144	SENSOR VHILE SPEED	Bajaj spare parts
DJ201151	HARNESS REAR SIDE RUBBER BOOT	Bajaj spare parts
DJ201153	HARNESS WIRING UG3	Bajaj spare parts
DJ201159	COVER TOP CLUSTER	Bajaj spare parts
DJ201164	REGULATOR ASSEMBLY	Bajaj spare parts
DJ201165	SWITCH BCU PLSR UG3	Bajaj spare parts
DJ201173	GROMMET FOR CABLES-REAR FENDER	Bajaj spare parts
DJ201174	BUTTON PUSH TRIP	Bajaj spare parts
DJ201176	LAMP HEAD ASSEMBLY	Bajaj spare parts
DJ201183	SENSOR SPEED	Bajaj spare parts
DJ201194	BODY CONTROL UNIT AC	Bajaj spare parts
DJ201195	CLUTCH SWITCH	Bajaj spare parts
DJ201201	HARNESS WIRING	Bajaj spare parts
DJ201202	REGULATOR ASSY	Bajaj spare parts
DJ201205	HARNESS WIRING	Bajaj spare parts
DJ201206	BLINKER RR.LH	Bajaj spare parts
DJ201207	BLINKER RR.RH (CL)	Bajaj spare parts
DJ201218	SEPEED SENSOR WITH "O" Ring	Bajaj spare parts
DJ201219	ASSY. FUSE BOX	Bajaj spare parts
DJ201241	BATTERY 12V 9AH MF DRY CHARGED	Bajaj spare parts
DJ201245	HARNESS WIRING (SS)	Bajaj spare parts
DJ201246	SWITCH CLUTCH VB	Bajaj spare parts
DJ201247	SCB HALL SENSOR ASSLY	Bajaj spare parts
DJ201248	WIRING HARNESS (SS) P-180	Bajaj spare parts
DJ201249	MAIN WIRING HARNESS	Bajaj spare parts
DJ201250	MAIN WIRING HARNESS	Bajaj spare parts
DJ201252	PIG.HARNESS BRK SWI	Bajaj spare parts
DJ201253	REAR BRAKE SWITCH	Bajaj spare parts
DJ201254	WIRING HARNESS	Bajaj spare parts
DJ201260	HARNESS UG	Bajaj spare parts
DJ201261	HARNESS WIRING AHO BSIV	Bajaj spare parts
DJ201262	HARNESS WIRING	Bajaj spare parts

DJ201264	HARNESS WIRING	Bajaj spare parts
DJ201265	HARNESS WIRING ABS	Bajaj spare parts
DJ201278	HARNESS WIRING	Bajaj spare parts
DJ211006	CABLE SEAT LOCK	Bajaj spare parts
DJ211007	DAMPER SEAT	Bajaj spare parts
DJ221003	MIRROR ASSY LH PULSAR DT	Bajaj spare parts
DJ221004	MIRROR ASSY RH PULSAR D	Bajaj spare parts
DJ221016	GUARD SARI BLACK	Bajaj spare parts
DJ221019	TOOL KIT	Bajaj spare parts
DJ221020	GUARD LEG LH K2 UG	Bajaj spare parts
DJ221021	GUARD LEG RH K2 UG	Bajaj spare parts
DJ710123	TANK FUEL	Bajaj spare parts
DJ71075F	P/TANK 150/180 CW RED PULS	Bajaj spare parts
DJ71075G	PULSAR P TANK 150,180 PL BLUE	Bajaj spare parts
DJ72012V	TANK FUEL K2 UP C WINE RE	Bajaj spare parts
DJ72014L	TANK FUEL MIST GREY	Bajaj spare parts
DJ72014M	TANK FUEL K2 UP MIDNIGHT	Bajaj spare parts
DJ72015C	TANK FUEL K2 UP ORANGE ME	Bajaj spare parts
DJ7301X3	FENDER FR BLACK PULSAR D	Bajaj spare parts
DJ73022V	FENDER FR CW RED PULSAR	Bajaj spare parts
DJ73024K	FENDER FR PL BLUE UG	Bajaj spare parts
DJ73024M	FENDER FR MIDNIGHT BLACK	Bajaj spare parts
DJ74012V	FAIRING RED PULSAR	Bajaj spare parts
DJ7401X3	FAIRINGBLACK PULSAR	Bajaj spare parts
DJ7401X4	FAIRINGRED PULSAR	Bajaj spare parts
DJ902503	BODY BALANCER ASSY	Bajaj spare parts
DK010050	KIT DISC BRAKE REAR FL CALIPER	Bajaj spare parts
DK010144	DECAL TANK UPPER RH BLACK-SILVER	Bajaj spare parts
DK010162	DECAL TANK LOWER RH BLUE-SILVER	Bajaj spare parts
DK010176	DECAL FAIRING LWR RH RED-SILVER	Bajaj spare parts
DK010244	DECAL WHEEL EBONY BLACK	Bajaj spare parts
DK010257	DECAL WHEEL MATTE VOLCANIC RED	Bajaj spare parts
DK010261	DECAL 3D	Bajaj spare parts
DK010266	DECAL COWL SEAT LWR LH E B-BLUE	Bajaj spare parts
DK010267	DECAL COWL SEAT LWR RH E B-BLUE	Bajaj spare parts
DK010272	DECAL WHEEL EBONY BLACK-BLUE	Bajaj spare parts
DK010279	DECAL DOME TANK	Bajaj spare parts
DK010282	DECAL COWL SEAT	Bajaj spare parts
DK010295	DECAL 3D COWL SEAT	Bajaj spare parts
DK010313	DECAL BELLY PAN LH SATIN P WHITE	Bajaj spare parts
DK010314	DECAL BELLY PAN RH SATIN P WHITE	Bajaj spare parts
DK010327	DECAL BELLY PAN LH SATIN S BLUE	Bajaj spare parts
DK010328	DECAL BELLY PAN RH SATIN S BLUE	Bajaj spare parts
DK010337	DECAL BELLY PAN LH VOLCANIC RED	Bajaj spare parts
DK010338	DECAL BELLY PAN RH VOLCANIC RED	Bajaj spare parts

DK010349	DECAL BELLY PAN LH SATIN S BLACK	Bajaj spare parts
DK010350	DECAL BELLY PAN RH SATIN S BLACK	Bajaj spare parts
DK010364	DECAL BELLY PAN S BLK BL LH	Bajaj spare parts
DK010365	DECAL BELLY PAN S BLK BL RH	Bajaj spare parts
DK010382	DECAL BELLY PAN S BLACK S LH	Bajaj spare parts
DK010383	DECAL BELLY PAN S BLACK S RH	Bajaj spare parts
DK010400	DECAL BELLY PAN S BLUE WHITE LH	Bajaj spare parts
DK010401	DECAL BELLY PAN S BLUE WHITE RH	Bajaj spare parts
DK010418	DECAL BELLY PAN S BLACK RED LH	Bajaj spare parts
DK010419	DECAL BELLY PAN S BLACK RED RH	Bajaj spare parts
DK101001	CLUTCH CENTER	Bajaj spare parts
DK101003	GASKET CYLINDER	Bajaj spare parts
DK101025	TENSIONER ASSEMBLY	Bajaj spare parts
DK101057	CRANKCASE RH	Bajaj spare parts
DK101059	GUIDE CHAIN SLACK	Bajaj spare parts
DK101063	GASKET CYLINDER BLOC	Bajaj spare parts
DK101064	CAM CHAIN 100 LINKS	Bajaj spare parts
DK101065	CRANKSHAFT COMPLETE	Bajaj spare parts
DK101068	SPROCKET CAM DRIVE (17 T)	Bajaj spare parts
DK101072	CLUTCH LIFTER ROD	Bajaj spare parts
DK101073	CLUTCH ASSY COMPLETE	Bajaj spare parts
DK101079	CAMSHAFT ASSLY	Bajaj spare parts
DK101091	PIN PISTON	Bajaj spare parts
DK101092	ASSEMBLY PISTON	Bajaj spare parts
DK101097	DAMPER AXIAL RUBBER	Bajaj spare parts
DK101102	GEAR THIRD DRIVE	Bajaj spare parts
DK101103	GEAR 4TH DRIVEN	Bajaj spare parts
DK101104	GEAR 5TH DRIVEN	Bajaj spare parts
DK101105	GEAR 3RD DRIVEN	Bajaj spare parts
DK101112	COOLER OIL	Bajaj spare parts
DK101123	BOLT RELIEF VALVE	Bajaj spare parts
DK101124	SENSOR THERMAL WITH	Bajaj spare parts
DK101126	SPACER CLUTCH	Bajaj spare parts
DK101135	BUSH DRUM CHANGE	Bajaj spare parts
DK101144	SHAFT OUTPUT T/M SUB ASSY	Bajaj spare parts
DK101150	DISC CL FRICTION	Bajaj spare parts
DK101151	PLATE CLUTCH	Bajaj spare parts
DK101153	SEAT JUDDER SPRING	Bajaj spare parts
DK101155	SPRING JUDDER	Bajaj spare parts
DK101158	GUIDE	Bajaj spare parts
DK101159	FORK GEAR SHIFT	Bajaj spare parts
DK101160	FORK GEAR SHIFT OUTP	Bajaj spare parts
DK101163	PLATE CL PRESSUR	Bajaj spare parts
DK101176	SHAFT STARTER COUNT	Bajaj spare parts
DK101177	LEVER CHANGE ARM ASL	Bajaj spare parts

DK101180	ROD TIE ASSEMBLY	Bajaj spare parts
DK101182	LEVER COMPLETE ASSLY	Bajaj spare parts
DK101183	LEVER COMPLETE CHANG	Bajaj spare parts
DK101185	WASHER PIVOT BOLT	Bajaj spare parts
DK101186	BOLT PIVOT LEVER CHANGE	Bajaj spare parts
DK101187	COLLAR PIVOT BOLT	Bajaj spare parts
DK101225	SWITCH OIL PRESSURE	Bajaj spare parts
DK101236	BOLT SPE BANJO OIL	Bajaj spare parts
DK101237	WASHER COPPER	Bajaj spare parts
DK101238	PIPE ASSEMBLY OIL	Bajaj spare parts
DK101245	COLLAR SPROCKET	Bajaj spare parts
DK101246	SEAT VALVE SPRING	Bajaj spare parts
DK101247	RETAINER VALVE SPRING	Bajaj spare parts
DK101251	PIN PARALEL CL SHAFT	Bajaj spare parts
DK101252	BRACKET CLUTCH CABLE	Bajaj spare parts
DK101253	SPRING GEAR SHIFT	Bajaj spare parts
DK101255	DISC CL FRICTION	Bajaj spare parts
DK101275	PIPE INLET OIL ASSY	Bajaj spare parts
DK101276	PIPE OUTLET ASSY OIL	Bajaj spare parts
DK101277	BRACKET UPPER	Bajaj spare parts
DK101278	BRACKET LOWER	Bajaj spare parts
DK101279	WASHER OIL COOLER	Bajaj spare parts
DK101284	HEX SOCKET HEAD SCRE	Bajaj spare parts
DK101289	COVER OIL COOLER	Bajaj spare parts
DK101305	WIRE SHIELD ASSLY.	Bajaj spare parts
DK101314	BOLT SOCKET HEAD M10X50	Bajaj spare parts
DK101325	HEAD CYL WITH COVER	Bajaj spare parts
DK101326	VALVE REPAIR KIT	Bajaj spare parts
DK101327	VALVE KIT SPARES	Bajaj spare parts
DK101328	RING SET PISTON	Bajaj spare parts
DK101329	CYL BL PISTON ASSY	Bajaj spare parts
DK101330	GUIDE CHAIN KIT	Bajaj spare parts
DK101338	HOLDER CLUTCH	Bajaj spare parts
DK101340	RING O OIL COOLER P	Bajaj spare parts
DK101352	RING O COLLAR SPROCK	Bajaj spare parts
DK101355	KIT FRICTION PLATES	Bajaj spare parts
DK101356	KIT FR CL PL.180CC	Bajaj spare parts
DK101366	BOLT SPECIAL BANJO	Bajaj spare parts
DK101378	CLAMP (ID 6.5*0.7)	Bajaj spare parts
DK101380	NEUTRAL SWITCH COMP	Bajaj spare parts
DK101382	DRUM GEAR SHIFT ASSY	Bajaj spare parts
DK101385	CRANKCASE LH	Bajaj spare parts
DK101386	PRECOATED SOC HD CAP	Bajaj spare parts
DK101416	BODY BALANCER ASSY	Bajaj spare parts
DK101436	NOZZLE INPUT SHAFT	Bajaj spare parts

DK101445	SHIM (0.6 THK.)	Bajaj spare parts
DK101449	SPRING VALVE RELIEF	Bajaj spare parts
DK101450	SHIM (0.45 THK.)	Bajaj spare parts
DK101451	SHIM (0.75 THK.)	Bajaj spare parts
DK101452	SHIM (0.9 THK.)	Bajaj spare parts
DK101469	PRESSURE RELIEF VALV	Bajaj spare parts
DK101471	SHAFT INPUT TRANS SUB ASS	Bajaj spare parts
DK101472	WASHER	Bajaj spare parts
DK101475	GUARD PILLION	Bajaj spare parts
DK101480	PLUNGER PUMP OIL	Bajaj spare parts
DK101503	ENG TEMPERATURE SENSOR	Bajaj spare parts
DK101560	FCC CLUTCH COMPLETE	Bajaj spare parts
DK101561	HOUSING COMPL CLUTCH	Bajaj spare parts
DK101563	CENTER ASSLY.CLUTCH(FCC)	Bajaj spare parts
DK101564	CENTER CLUTCH(FCC)	Bajaj spare parts
DK101565	PLATE CLUTCHFCC	Bajaj spare parts
DK101567	DISC C FRICTIONFCC	Bajaj spare parts
DK101568	DISC B FRICTIONFCC	Bajaj spare parts
DK101569	PLATE PRESSURE FCC	Bajaj spare parts
DK101570	SEAT SPRING JUDDER F	Bajaj spare parts
DK101571	SPRING JUDDER FCC	Bajaj spare parts
DK101573	HOLDER CLUTCH	Bajaj spare parts
DK101574	BOLT FLANGE 6X25	Bajaj spare parts
DK101577	SENSOR THERMAL	Bajaj spare parts
DK101581	C CASE LH (P220 BLA	Bajaj spare parts
DK101592	OIL PIPE	Bajaj spare parts
DK101596	SPRING STARTER CLUTC	Bajaj spare parts
DK101605	PLATE ROLLER CLUTCH	Bajaj spare parts
DK101614	CAMSHAFT (BLACK)	Bajaj spare parts
DK101625	CYL BLOCK ASSY PULSR 220	Bajaj spare parts
DK101630	PIPE INLET OIL COOL	Bajaj spare parts
DK101631	PIPE OUTLET OIL COO	Bajaj spare parts
DK101632	GEAR 5TH DRIVE	Bajaj spare parts
DK101634	COOLER OIL 5 ROW	Bajaj spare parts
DK101635	COVER OIL COOLER 5 R	Bajaj spare parts
DK101636	LEVER ASSEMBLY	Bajaj spare parts
DK101698	WASHER GUARD PILLION	Bajaj spare parts
DK101710	GUARD PILLION	Bajaj spare parts
DK101717	GEAR 1ST DRIVEN	Bajaj spare parts
DK101718	GEAR 4TH DRIVEN	Bajaj spare parts
DK101719	GEAR 2ND DRIVEN	Bajaj spare parts
DK101720	GEAR 5TH DRIVEN (220)	Bajaj spare parts
DK101721	GEAR 5TH DRIVEN (180)	Bajaj spare parts
DK101722	SPRING SHIFT RETURN	Bajaj spare parts
DK101725	STOPPER DRUM	Bajaj spare parts

DK101729	WIRE SHIELD	Bajaj spare parts
DK101732	ASSEMBLY DRUM	Bajaj spare parts
DK101733	ASSEMBLY LEVER SHAFT	Bajaj spare parts
DK101738	DECAL COVER RH	Bajaj spare parts
DK101748	SHAFT ROCKER ARM INTAKE	Bajaj spare parts
DK101751	SHAFT ROCKER ARM EXHAUST	Bajaj spare parts
DK101755	ROCKER ARM ASSY.	Bajaj spare parts
DK101762	COVER LH RR MOONLIGHT	Bajaj spare parts
DK101770	STARTER MOTOR COVER	Bajaj spare parts
DK101774	ASSLY CYLINDER HEAD	Bajaj spare parts
DK101776	ASSY BODY BALANCER	Bajaj spare parts
DK101779	SILENCER COMPLETE WO CAT	Bajaj spare parts
DK101794	GASKET	Bajaj spare parts
DK101838	UNIT SAI	Bajaj spare parts
DK101851	GUARD PILLION	Bajaj spare parts
DK101853	SHIELD CAT	Bajaj spare parts
DK101856	COOLER ASSEMBLY OIL	Bajaj spare parts
DK101865	PIPE ASSEMBLY INLET OIL COOLER	Bajaj spare parts
DK101866	PIPE ASSEMBLY OUTLET OIL COOLER	Bajaj spare parts
DK101870	SILENCER ASSLY	Bajaj spare parts
DK101875	ASSLY SILENCER COMPLETE WITHOUT CAT	Bajaj spare parts
DK101892	ENGINE ASSEMBLY	Bajaj spare parts
DK101895	SILENCER ASSEMBLY	Bajaj spare parts
DK101898	ELEMENT ASSEMBLY FILTER AIR	Bajaj spare parts
DK101899	ELEMENT FILTER AIR	Bajaj spare parts
DK101930	BLOCK CYLINDER	Bajaj spare parts
DK101957	DRUM ASSEMBLY GEAR SHIFT	Bajaj spare parts
DK101972	CRANKSHAFT ASSEMBLY	Bajaj spare parts
DK101973	GUIDE CHAIN SLACK SIDE	Bajaj spare parts
DK101975	CAMSHAFT ASSEMBLY	Bajaj spare parts
DK101977	ENGINE ASSEMBLY	Bajaj spare parts
DK102000	HEAD CYLINDER-COVER ASSEMBLY	Bajaj spare parts
DK102001	PISTON ASSEMBLY	Bajaj spare parts
DK102019	SPROCKET CRANKSHAFT	Bajaj spare parts
DK102020	STOPPER BEARING	Bajaj spare parts
DK102021	SHAFT ROCKER ARM INTAKE	Bajaj spare parts
DK102022	SHAFT ROCKER ARM EXHAUST	Bajaj spare parts
DK102028	SPRING VALVE	Bajaj spare parts
DK102037	SILENCER ASSEMBLY	Bajaj spare parts
DK102054	SHIELD ASSEMBLY WIRE	Bajaj spare parts
DK111009	MOTOR STARTER	Bajaj spare parts
DK111011	CAP SPARK PLUG	Bajaj spare parts
DK111017	KIT BRUSH ASSEMBLY	Bajaj spare parts
DK111027	SPARK PLUG RG4HCC	Bajaj spare parts
DK111028	SPARK PLUG RG6HCC	Bajaj spare parts

DK111072	DC CDI UNIT	Bajaj spare parts
DK111073	DC CDI UNIT	Bajaj spare parts
DK111079	STATOR ASSEMBLY	Bajaj spare parts
DK111081	CDI NON TPS ASSEMBLY K3	Bajaj spare parts
DK111083	MAGNETO ASSEMBLY	Bajaj spare parts
DK111084	STATOR ASSEMBLY	Bajaj spare parts
DK121009	ELEMENT FILTER ASSLY	Bajaj spare parts
DK121015	RING O AIR CLEANERRI	Bajaj spare parts
DK121021	ACCELERATOR BODY ASS	Bajaj spare parts
DK121024	CLIP NUT M4 FOR IR SENSOR	Bajaj spare parts
DK121026	SCREW MUSHROOM HEAD (M4*0.7*15)	Bajaj spare parts
DK121038	FILTER AIR ASSY	Bajaj spare parts
DK121039	CONNECTING TUBE	Bajaj spare parts
DK121040	VACCUM PISTON KIT	Bajaj spare parts
DK121041	IDLING SCREW KIT	Bajaj spare parts
DK121043	RING O	Bajaj spare parts
DK121047	NEEDLE ASSLY	Bajaj spare parts
DK121048	SET ADJUSTER	Bajaj spare parts
DK121049	SET PLUNGER ASSLY	Bajaj spare parts
DK121051	JET PILOT (DIA 1*2*4)	Bajaj spare parts
DK121059	FLOAT NEEDLE	Bajaj spare parts
DK121063	JET PILOT	Bajaj spare parts
DK121069	ASSLY PISTON VALVE KIT	Bajaj spare parts
DK121070	JET KIT	Bajaj spare parts
DK121082	RUBBER INSULATOR	Bajaj spare parts
DK121086	ASSLY AIRFILTER_SAI	Bajaj spare parts
DK121091	HOSE SAI UNIT TO MANIFOLD	Bajaj spare parts
DK121092	CARBURETTOR ASSLY K3 EVAP	Bajaj spare parts
DK121115	SLEEVE MANIFOLD	Bajaj spare parts
DK121116	FILTER ASSEMBLY AIR	Bajaj spare parts
DK121119	BODY THROTTLE ASSEMBLY	Bajaj spare parts
DK121120	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
DK141005	HOSE FUEL R9 LONG	Bajaj spare parts
DK141013	ROTOR PETR TANK CAP	Bajaj spare parts
DK141014	CAP TANK FUEL TW	Bajaj spare parts
DK141015	TANK PAD	Bajaj spare parts
DK141017	DAMPER TANK MIDDLE	Bajaj spare parts
DK141025	PUMP FUEL NEW W/O 'T'	Bajaj spare parts
DK141026	PULSAR LOGOP TANK	Bajaj spare parts
DK141027	B' MONOGRAM P TANK	Bajaj spare parts
DK141028	'O' RING	Bajaj spare parts
DK141041	PIPE CLIP	Bajaj spare parts
DK141057	TUBE PURGE VALVE TO CARB	Bajaj spare parts
DK141082	PIPE CANISTER-CONNECTOR	Bajaj spare parts
DK141083	PIPE CONNECTOR-VALVE PURGE	Bajaj spare parts

DK141085	PIPE VALVE PURGE-BODY THROTTLE	Bajaj spare parts
DK151003	RIM WHEEL 2.5X17 RR	Bajaj spare parts
DK151005	COUPLING	Bajaj spare parts
DK151008	AXLE FRON	Bajaj spare parts
DK151009	AXLE REAR	Bajaj spare parts
DK151010	CHAIN O RING 104 LINK	Bajaj spare parts
DK151012	SEAL_OIL	Bajaj spare parts
DK151014	SPACER COUPLING	Bajaj spare parts
DK151015	SLEEVE	Bajaj spare parts
DK151022	COLLAR BEARING ASSLY	Bajaj spare parts
DK151024	DISC REAR	Bajaj spare parts
DK151026	VALVE TUBELESS TYRE	Bajaj spare parts
DK151027	DISC FRONT DIA 260	Bajaj spare parts
DK151028	SPACER ASY FRONT WH	Bajaj spare parts
DK151031	MASTER CYL REAR ASLY	Bajaj spare parts
DK151032	HOSE DISC BRAKE REAR	Bajaj spare parts
DK151033	RESERVOIR RR DISCBRA	Bajaj spare parts
DK151034	RESERVOIR TUBE RAER DISC	Bajaj spare parts
DK151036	CONNECTING LINK O	Bajaj spare parts
DK151038	RR BRAKE CALIPER PAD	Bajaj spare parts
DK151041	PAD SPRING REAR	Bajaj spare parts
DK151042	BOOT MASTER CYLINDE	Bajaj spare parts
DK151043	PUSH ROD ASSY	Bajaj spare parts
DK151045	CAP MASTER CYL REAR	Bajaj spare parts
DK151050	WHEEL 2.5 X 17 TUBELESS B	Bajaj spare parts
DK151052	BRCKT MTG BLACK CALI	Bajaj spare parts
DK151053	ASLY VEH SPEED SENSOR	Bajaj spare parts
DK151054	CALIPER ASSY BRAKE F	Bajaj spare parts
DK151057	HOSE ASSY	Bajaj spare parts
DK151059	CALIPER ASSY REAR	Bajaj spare parts
DK151060	SPROCKET 36T	Bajaj spare parts
DK151062	MASTER CYLINDER ASSY	Bajaj spare parts
DK151063	CLIP RESERVOR	Bajaj spare parts
DK151065	CIRCLIP	Bajaj spare parts
DK151067	BLEEDER SCREW	Bajaj spare parts
DK151068	SEAL	Bajaj spare parts
DK151069	BOLT BANJO	Bajaj spare parts
DK151072	DIAPHRAGM RESERVIOR KBX	Bajaj spare parts
DK151073	KIT R/MASTER CYL MAJOR	Bajaj spare parts
DK151074	KIT MINOR R/MASTER CYL	Bajaj spare parts
DK151081	SPACER I	Bajaj spare parts
DK151082	SPACER II	Bajaj spare parts
DK151083	CALIPER ASSLY RR FLOATING	Bajaj spare parts
DK151084	HOSE BRAKE REAR	Bajaj spare parts
DK151085	PAD BRAKE RE	Bajaj spare parts



DK151088	PISTON KIT	Bajaj spare parts
DK151089	SEAL KIT	Bajaj spare parts
DK151090	INSULATOR KIT	Bajaj spare parts
DK151092	PAD SPRING	Bajaj spare parts
DK151094	COUPLING RUBBER	Bajaj spare parts
DK151095	AXLE FRONT	Bajaj spare parts
DK151096	DISC FRONT BLACK	Bajaj spare parts
DK151097	DISC REAR BLACK	Bajaj spare parts
DK151101	BRAKE SYSTEM REAR	Bajaj spare parts
DK151103	CALIPER ASSEMBLY REAR	Bajaj spare parts
DK151109	DISC BRAKE DIA 280	Bajaj spare parts
DK151111	UNIT ABS	Bajaj spare parts
DK151113	CALIPER ASSEMBLY FRONT	Bajaj spare parts
DK151116	CYLINDER MASTER FRONT	Bajaj spare parts
DK151122	CALIPER ASSEMBLY REAR	Bajaj spare parts
DK151136	PAD SET BRAKE FRONT	Bajaj spare parts
DK161066	FAIRING ASSMBLY	Bajaj spare parts
DK161069	WINDSHIELD	Bajaj spare parts
DK161070	FAIRING AIR INTAKE LH	Bajaj spare parts
DK161071	FAIRING AIR INTAKE RH	Bajaj spare parts
DK161072	FAIRING UNDER COVER	Bajaj spare parts
DK161073	FAIRING BACK COVER A	Bajaj spare parts
DK161076	FAIRING MESH LH	Bajaj spare parts
DK161077	FAIRING MESH RH	Bajaj spare parts
DK161081	RUBBER GROMMET FAIRING	Bajaj spare parts
DK161082	SLEEVE FAIRING LOWER	Bajaj spare parts
DK161085	FENDER REAR	Bajaj spare parts
DK161086	FENDER REAR FRONT	Bajaj spare parts
DK161096	BRACKET ENG MTG FR	Bajaj spare parts
DK161098	BRACE FENDER FRONT	Bajaj spare parts
DK161122	STAND CENTER	Bajaj spare parts
DK161123	COVER SIDE MESH LH	Bajaj spare parts
DK161124	COVER SIDE MESH RH	Bajaj spare parts
DK161125	RUBBER MIRROR MOUNT	Bajaj spare parts
DK161126	DAMPER FAIRING	Bajaj spare parts
DK161137	HOLDER STEP LH	Bajaj spare parts
DK161138	HOLDER STEP RH	Bajaj spare parts
DK161147	GRAB HNDLE LH	Bajaj spare parts
DK161148	GRAB HANDLE RH	Bajaj spare parts
DK161151	SCREW CROSS RE M5	Bajaj spare parts
DK161152	BUSH FAIRING	Bajaj spare parts
DK161153	CLIP NUT M4	Bajaj spare parts
DK161161	BRACKET RH ENGINE RR	Bajaj spare parts
DK161163	BRACKET RR BRAKE SWI	Bajaj spare parts
DK161164	BKT REAR INDICATOR	Bajaj spare parts

DK161171	RUBBER FLAP LH	Bajaj spare parts
DK161172	RUBBER FLAP RH	Bajaj spare parts
DK161176	GUARD SARI	Bajaj spare parts
DK161185	GROMMET KIT SIDE	Bajaj spare parts
DK161186	OIL COOLER CAP BKT L	Bajaj spare parts
DK161187	OIL COOLER CAP BKT R	Bajaj spare parts
DK161188	OIL COOLER CAP LH	Bajaj spare parts
DK161189	OIL COOLER CAP RH	Bajaj spare parts
DK161198	MUD FLAP FRONT	Bajaj spare parts
DK161202	FRONT FENDER ASSY	Bajaj spare parts
DK161208	MONOGRAM B WINDSHILD	Bajaj spare parts
DK161209	TAPE I	Bajaj spare parts
DK161210	TAPE II	Bajaj spare parts
DK161212	SCREW MASHROOM HD	Bajaj spare parts
DK161217	GRAB HANDLE LH BLACK	Bajaj spare parts
DK161218	GRAB HANDLE RH BLACK	Bajaj spare parts
DK161225	DECAL P 220 C W RED	Bajaj spare parts
DK161226	DECAL P 220 L BLUE	Bajaj spare parts
DK161227	DECAL P 220 M SILVER	Bajaj spare parts
DK161228	DECAL P 220 M BLACK	Bajaj spare parts
DK161242	COWL SEAT RED PLSR 220F	Bajaj spare parts
DK161243	DECAL SEAT COWL BLUE	Bajaj spare parts
DK161244	COWL SEAT SILVER PLSR 220	Bajaj spare parts
DK161245	COWL SEAT BLUE PLSR 220F	Bajaj spare parts
DK161250	COVER CHAIN INTEGRAL	Bajaj spare parts
DK161255	COWL SEAT PLSR 220F	Bajaj spare parts
DK161256	SEAT COWL Decal P-200 SILVER	Bajaj spare parts
DK161257	DECAL PLSAR 220F SEAT COW	Bajaj spare parts
DK161258	DECAL PLSAR 220 SEAT COWL	Bajaj spare parts
DK161259	DECAL OIL COOLED SILVER	Bajaj spare parts
DK161260	DECAL OIL COOLED BLK	Bajaj spare parts
DK161263	DECAL OIL COOLED SILVER R	Bajaj spare parts
DK161264	DECAL OIL COOLED BLK RH	Bajaj spare parts
DK161308	HOLDER STEP-LH(MOONLIGHT)	Bajaj spare parts
DK161309	Holder Step-RH	Bajaj spare parts
DK161317	FAIRING STRUCTURE ASSY	Bajaj spare parts
DK161323	BRACKET SPEEDOMETER SUPPORT	Bajaj spare parts
DK161324	SLEEVE SPEEDOMETER SUPPORT	Bajaj spare parts
DK161338	FENDER REAR	Bajaj spare parts
DK161378	FAIRING DECAL UPPER EBONY BLACK LH	Bajaj spare parts
DK161379	FAIRING DECAL UPPER EBONY BLACK RH	Bajaj spare parts
DK161380	FAIRING DECAL LOWER 1 EBONY BLACK LH	Bajaj spare parts
DK161381	FAIRING DECAL LOWER 1 EBONY BLACK RH	Bajaj spare parts
DK161382	FAIRING DECAL LOWER 2 EBONY BLACK LH	Bajaj spare parts
DK161383	FAIRING DECAL LOWER 2 EBONY BLACK RH	Bajaj spare parts

DK161384	TANK DECAL UPPER EBONY BLACK LH	Bajaj spare parts
DK161385	TANK DECAL UPPER EBONY BLACK RH	Bajaj spare parts
DK161386	TANK DECAL LOWER EBONY BLACK LH	Bajaj spare parts
DK161387	TANK DECAL LOWER EBONY BLACK RH	Bajaj spare parts
DK161388	SEAT COWL DECAL EBONY BLACK LH	Bajaj spare parts
DK161389	SEAT COWL DECAL EBONY BLACK RH	Bajaj spare parts
DK161390	SEAT COWL DECAL SAFFIRE BLUE LH	Bajaj spare parts
DK161392	SEAT COWL DECAL COCKTAIL WINE RED LH	Bajaj spare parts
DK161393	SEAT COWL DECAL COCKTAIL WINE RED RH	Bajaj spare parts
DK161394	SEAT COWL DECAL METALLIC WHITE LH	Bajaj spare parts
DK161395	SEAT COWL DECAL METALLIC WHITE RH	Bajaj spare parts
DK161396	SEAT COWL DECAL EBONY BLACK LH	Bajaj spare parts
DK161397	SEAT COWL DECAL EBONY BLACK RH	Bajaj spare parts
DK161409	ASSLY FRAME K3 EVAP	Bajaj spare parts
DK161415	ASSLY ENGINE MTG BKT TOP LH	Bajaj spare parts
DK161416	ASSLY ENGINE MTG BKT TOP RH	Bajaj spare parts
DK161422	BRACKET SEAT LOCK- FRONT LOOSE	Bajaj spare parts
DK161423	BRACKET ENGINE ASSLY MTG TOP LH	Bajaj spare parts
DK161424	BRACKET ENGINE ASSLY MTG TOP RH	Bajaj spare parts
DK161436	BRACKET UNIT ABS	Bajaj spare parts
DK161437	HANGER ENGINE RH	Bajaj spare parts
DK161441	FRAME ASSEMBLY	Bajaj spare parts
DK161443	BRACKET LH BELLY	Bajaj spare parts
DK161444	BRACKET RH BELLY	Bajaj spare parts
DK161447	BRACKET BELLY PAN REAR RH	Bajaj spare parts
DK161454	FRAME ASSEMBLY	Bajaj spare parts
DK161455	BRACKET BATTERY	Bajaj spare parts
DK161470	BRACKET RELAY STARTER	Bajaj spare parts
DK161476	BRACKET LOCK SEAT	Bajaj spare parts
DK161483	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
DK161489	BELLY PAN MIDDLE	Bajaj spare parts
DK161495	HANGER ENGINE FRONT	Bajaj spare parts
DK161497	HANGER ASSEMBLY ENGINE FRONT LH	Bajaj spare parts
DK161498	HANGER ASSEMBLY ENGINE FRONT RH	Bajaj spare parts
DK161502	HANGER ENGINE RH	Bajaj spare parts
DK161504	BRACKET COIL IGNITION RH	Bajaj spare parts
DK161510	HANGER ENGINE LH	Bajaj spare parts
DK161513	BRACKET	Bajaj spare parts
DK161515	TAPE INSULATION RH	Bajaj spare parts
DK161518	BRACKET HOLDER MAGNET	Bajaj spare parts
DK161519	STAND SIDE	Bajaj spare parts
DK161530	STRUCTURE FAIRING	Bajaj spare parts
DK171003	SHAFT SWING ARM	Bajaj spare parts
DK171006	SLEEVE SWING ARM	Bajaj spare parts
DK171008	ASSLY SWING ARM	Bajaj spare parts

DK171011	ARM SWING BLACK	Bajaj spare parts
DK171014	REAR SHOCK ABS ASLY	Bajaj spare parts
DK171022	SHOCKABSORBER REAR	Bajaj spare parts
DK181004	TUBE OUTER LH	Bajaj spare parts
DK181005	TUBE OUTER RH	Bajaj spare parts
DK181006	BOLT M10X1.5X35	Bajaj spare parts
DK181007	WASHER COPPER	Bajaj spare parts
DK181008	BOLT FLANGEM8X1.25X	Bajaj spare parts
DK181009	CAP OIL LOCK	Bajaj spare parts
DK181010	SEAT PIPE	Bajaj spare parts
DK181011	SLIDE BUSH	Bajaj spare parts
DK181012	RING PISTON	Bajaj spare parts
DK181013	SPRING FRONT K	Bajaj spare parts
DK181014	MAIN SPRING	Bajaj spare parts
DK181015	WASHER	Bajaj spare parts
DK181017	GUIDE BUSH	Bajaj spare parts
DK181018	WASHER SEAL	Bajaj spare parts
DK181019	SEAL OIL	Bajaj spare parts
DK181020	SEAL OIL STOPPER	Bajaj spare parts
DK181021	SEAL DUST INNER	Bajaj spare parts
DK181022	BOLT K	Bajaj spare parts
DK181023	RING O	Bajaj spare parts
DK181024	BRACKET UNDER ASSY	Bajaj spare parts
DK181025	SPRING WASHER	Bajaj spare parts
DK181026	BOLT HEX M10X40L	Bajaj spare parts
DK181027	BRACKET UPPER	Bajaj spare parts
DK181028	HEX BOLT M10X1.5X40	Bajaj spare parts
DK181034	LOCK SET 4 IN 1	Bajaj spare parts
DK181036	PLUG HANDLE HOLDER	Bajaj spare parts
DK181037	CLAMP BRAKE HOSE	Bajaj spare parts
DK181043	HANDLE BAR WEIGHT	Bajaj spare parts
DK181045	FORK PIPE SPINNED	Bajaj spare parts
DK181048	CLAMP	Bajaj spare parts
DK181050	CAGE BEARING STEERIN	Bajaj spare parts
DK181051	CAGE BEARING STE BTM	Bajaj spare parts
DK181052	CLAMP RH FR. BR. SYSTEM	Bajaj spare parts
DK181053	FORK FRONT	Bajaj spare parts
DK181056	TUBE OUTER LH	Bajaj spare parts
DK181057	TUBE OUTER RH	Bajaj spare parts
DK181058	BOLT HANDLE BAR M8X40	Bajaj spare parts
DK181060	HOLDER HANDLE BLACK	Bajaj spare parts
DK181062	HOLDER HANDLE RH BLACK	Bajaj spare parts
DK181063	UPPER BRACKET BLACK	Bajaj spare parts
DK181068	LEG ASSY LH	Bajaj spare parts
DK181069	LEG ASSY RH	Bajaj spare parts

DK181070	FORK PIPE SPINNING	Bajaj spare parts
DK181072	FORK FRONT FORK COMPLETE	Bajaj spare parts
DK181073	SPRING MAIN	Bajaj spare parts
DK181074	BEADING FAIRING	Bajaj spare parts
DK181075	NUT STEERING	Bajaj spare parts
DK181076	CUP STEERING	Bajaj spare parts
DK181082	H.BAR TUBE ASSY LH	Bajaj spare parts
DK181083	BUSH SILENT	Bajaj spare parts
DK181086	HANDLE BAR TUBE ASSY RH	Bajaj spare parts
DK181087	FORK ASSY FRONT	Bajaj spare parts
DK181088	LEG ASSLY LH	Bajaj spare parts
DK181089	LEG ASSLY RH	Bajaj spare parts
DK181090	OUTER TUBE LH PC	Bajaj spare parts
DK181091	OUTER TUBE RH PC	Bajaj spare parts
DK181092	FORK PIPE SPINNING	Bajaj spare parts
DK181093	SPACER TUBE	Bajaj spare parts
DK181095	LOCK SET 3 IN 1	Bajaj spare parts
DK181096	LEVER HOLDER	Bajaj spare parts
DK181099	LOCK SET EVAP TWO TRACK KEY	Bajaj spare parts
DK181100	BRACKET UPPER	Bajaj spare parts
DK181102	HOLDER HANDLE LH	Bajaj spare parts
DK181104	HOLDER HANDLE RH	Bajaj spare parts
DK181107	CLAMP HOSE BRAKE	Bajaj spare parts
DK191011	CABLE CLUTCH	Bajaj spare parts
DK191012	LEVER BRAKE	Bajaj spare parts
DK191013	SPRING REAR BRAKE PE	Bajaj spare parts
DK191017	LEVER BRAKE ASSLY	Bajaj spare parts
DK191023	HOLDER ASSY LH	Bajaj spare parts
DK191034	HOLDER ASSY LEVER	Bajaj spare parts
DK191035	SPEEDOMETER 6 HOLES MTG	Bajaj spare parts
DK191036	SPEEDOMETER ASSY	Bajaj spare parts
DK191037	SPEEDOMETER ASSLY 220 S	Bajaj spare parts
DK191039	SPEEDOMETER ASSLY	Bajaj spare parts
DK191040	SPEEDOMETER	Bajaj spare parts
DK191042	ASSEMBLY PEDAL BRAKE	Bajaj spare parts
DK191045	SPEEDOMETER	Bajaj spare parts
DK191046	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
DK191047	SPEEDOMETER	Bajaj spare parts
DK191049	SPEEDOMETER	Bajaj spare parts
DK201001	REGULATOR 3 PHASE	Bajaj spare parts
DK201003	LAMP TAIL ASSEMBLY	Bajaj spare parts
DK201016	RELAY ST.70A FO	Bajaj spare parts
DK201023	FUSE ASSLY BLADE TY	Bajaj spare parts
DK201024	LAMP ASSLY RR	Bajaj spare parts
DK201028	CABLE BAT TO EARTH	Bajaj spare parts

DK201036	CAPACITOR	Bajaj spare parts
DK201037	HORN LH DIA 70	Bajaj spare parts
DK201038	HORN RH DIA 70	Bajaj spare parts
DK201043	BULB 12V 55W WHITE	Bajaj spare parts
DK201044	BULB 12V 5 WATT	Bajaj spare parts
DK201049	CLAMP-HARNESS WIRING	Bajaj spare parts
DK201050	BLINKER FRONT LH	Bajaj spare parts
DK201051	BLINKER FRONT RH	Bajaj spare parts
DK201056	LAMP HEAD ASSEMBLY	Bajaj spare parts
DK201064	SWITCH CL WITH DIODE	Bajaj spare parts
DK201065	TANK UNIT K3 LHS	Bajaj spare parts
DK201070	CONTROL SWITCH LH	Bajaj spare parts
DK201071	CONTROL SWITCH RH	Bajaj spare parts
DK201078	RALAY STARTER	Bajaj spare parts
DK201081	CABLE RELAY TO MOTOR	Bajaj spare parts
DK201083	CLUTCH SWITCH 6AMP	Bajaj spare parts
DK201084	BATTERY CABLE	Bajaj spare parts
DK201098	SPEED SENSOR	Bajaj spare parts
DK201116	SPEED SENSOR W/T SLEEVE	Bajaj spare parts
DK201117	HARNESS HEADLAMP	Bajaj spare parts
DK201119	HEAD LAMP ASSY	Bajaj spare parts
DK201121	FRONT REFLEX REFLECTOR LH ASSY	Bajaj spare parts
DK201137	SWITCH CLUTCH TR DIODE	Bajaj spare parts
DK201138	HARNESS WIRING-SINGLE PHASE	Bajaj spare parts
DK201139	REGULATOR ASSY-SINGLE PHASE	Bajaj spare parts
DK201140	SWITCH CONTROL LH	Bajaj spare parts
DK201141	SWITCH CONTROL RH	Bajaj spare parts
DK201142	FUSE 5A (BLADE TYPE)	Bajaj spare parts
DK201143	SCB HALL SENSOR ASSEMBLY	Bajaj spare parts
DK201145	CONTROL SWITCH RH	Bajaj spare parts
DK201149	MAIN WIRING HARNESS	Bajaj spare parts
DK201153	HARNESS MAIN WIRING F	Bajaj spare parts
DK201156	HARNESS WIRING	Bajaj spare parts
DK201159	HARNESS WIRING AHO BSIV	Bajaj spare parts
DK201160	REGULATOR ASSLY WITH RPM SENSOR	Bajaj spare parts
DK201161	SENSOR LEVEL FUEL	Bajaj spare parts
DK201162	SWITCH CONTROL LH	Bajaj spare parts
DK201163	SWITCH CONTROL RH	Bajaj spare parts
DK201164	SENSOR SPEED WHEEL	Bajaj spare parts
DK201166	HARNESS WIRING ABS	Bajaj spare parts
DK201178	CABLE HARNESS	Bajaj spare parts
DK201181	CABLE HARNESS	Bajaj spare parts
DK201183	BULB	Bajaj spare parts
DK201184	HARNESS WIRING	Bajaj spare parts
DK201188	UNIT TRANSIL	Bajaj spare parts

DK211001	SEAT ASSEMBLY FRONT	Bajaj spare parts
DK211004	SEAT ASSEMBLY REAR	Bajaj spare parts
DK211007	DAMPER SEAT FRONT	Bajaj spare parts
DK211008	LOCK ASSEMBLY SEAT	Bajaj spare parts
DK211009	DAMPER FOR SEAT	Bajaj spare parts
DK211012	SEAT ASSY COMP FRONT	Bajaj spare parts
DK211014	SEAT ASSY COMP REAR	Bajaj spare parts
DK221001	NUT MIRROR	Bajaj spare parts
DK221014	MIRROR LH LONG	Bajaj spare parts
DK221015	MIRROR RH LONG	Bajaj spare parts
DK221020	RUBBER BOOT LH LONG	Bajaj spare parts
DK221021	RUBBER BOOT RH (LONG)	Bajaj spare parts
DK221022	MIRROR BASE LH	Bajaj spare parts
DK221023	MIRROR BASE RH	Bajaj spare parts
DK221024	O RING	Bajaj spare parts
DK71032V	TANK FUEL 220 SF C WINE R	Bajaj spare parts
DK71034L	TANK FUEL 220 F M SI	Bajaj spare parts
DK71034M	TANK FUEL 220 SF MIDNIG	Bajaj spare parts
DK71035C	TANK FUEL 220 SF ORANGE M	Bajaj spare parts
DK71045F	PULSAR P TANK 220 F C W RED DUAL DECAL	Bajaj spare parts
DK71045G	PULSAR P TANK 220 F PL BLUE DUAL DECAL	Bajaj spare parts
DK71052V	TANK FUEL 220 S SMALL F	Bajaj spare parts
DK71054K	TANK FUEL 220 S SMALL F	Bajaj spare parts
DK71054L	TANK FUEL 220 S SMALL F	Bajaj spare parts
DK71054M	TANK FUEL 220 S SMALL F	Bajaj spare parts
DK73012V	COVER SIDE LH W RED	Bajaj spare parts
DK7301X3	COVER SIDE LH UG3 EB	Bajaj spare parts
DK73021C	COVER SIDE RH PLSR	Bajaj spare parts
DK73022V	COVER SIDE RH C W RE	Bajaj spare parts
DK7302X3	COVER SIDE RH UG3 EB	Bajaj spare parts
DK73032V	COWL SEAT CW RED	Bajaj spare parts
DK7303X3	COWL SEAT UG3 EB BL	Bajaj spare parts
DK7303X4	COWL SEAT UG3 FL RED	Bajaj spare parts
DK73042V	FENDER FR UG4 C WINE	Bajaj spare parts
DK73044K	FENDER FR UG4 PLASMA	Bajaj spare parts
DK73044M	FENDER FR UG4 MIDNIG	Bajaj spare parts
DK74012V	FAIRING PAINTED K3 C	Bajaj spare parts
DK74014K	FAIRING PAINTED K3 PLASMA	Bajaj spare parts
DK74014M	FAIRING 220F M BLACK	Bajaj spare parts
DK7402X3	FENDER FR K3 E BLK	Bajaj spare parts
DK902626	BOLT	Bajaj spare parts
DK990000	RING O	Bajaj spare parts
DL141035	BOLT SOCKET HEAD	Bajaj spare parts
DL151014	SPEEDOMETER GEAR-	Bajaj spare parts
DL161015	GROMMET	Bajaj spare parts

DL161017	DAMPER SIDE COVER	Bajaj spare parts
DL161018	COVER SIDE RH ASPIRE	Bajaj spare parts
DL161023	TRIM CASE CHAIN	Bajaj spare parts
DL161048	STAND SIDE	Bajaj spare parts
DL181009	SCREW M5 X L16	Bajaj spare parts
DL181010	"NUT, WELL, 5MM "	Bajaj spare parts
DL181080	SEAL OIL FORK DOUBLE GART	Bajaj spare parts
DL191012	HOLDER LEVER LH	Bajaj spare parts
DL191013	LEVER GRIP LH	Bajaj spare parts
DL191014	STUD LEVER HANDLE	Bajaj spare parts
DL191020	LAMP 12V 3W	Bajaj spare parts
DM101098	CUP STOPPER	Bajaj spare parts
DM101099	PLATE SPACER	Bajaj spare parts
DM101114	SPROCKET OUTPUT	Bajaj spare parts
DM101139	GASKET GEN COVER	Bajaj spare parts
DM101140	GASKET CLUTCH	Bajaj spare parts
DM121004	COVER SIDE AIR FILTER	Bajaj spare parts
DM121007	RING O AIR FILTER	Bajaj spare parts
DM121010	BAND - BATTERY	Bajaj spare parts
DM121014	TUBE - OIL DRAIN	Bajaj spare parts
DM151008	RIM 1.60 X 18 BOXER AR	Bajaj spare parts
DM151029	RIM 1.60 X 17 CT100	Bajaj spare parts
DM151032	AXLE M14 X 1.5	Bajaj spare parts
DM151033	PANEL BRAKE REAR	Bajaj spare parts
DM151317	ROD TORQUE	Bajaj spare parts
DM151320	WHEEL ALLOY FRONT	Bajaj spare parts
DM151324	ASSLY COUPLING 6 LUG	Bajaj spare parts
DM161009	FENDER - REAR :- FRONT	Bajaj spare parts
DM161158	FRAME ASSEMBLY	Bajaj spare parts
DM161163	LABEL VEHICLE EMISSION	Bajaj spare parts
DM161172	STAND CENTER	Bajaj spare parts
DM161182	FRAME ASSLY	Bajaj spare parts
DM161187	FRAME ASSLY	Bajaj spare parts
DM161192	BRACKET ENGINE HANGER LH	Bajaj spare parts
DM161193	BRACKET ENGINE HANGER RH	Bajaj spare parts
DM161195	BRACKET ENGINE MOUNTING FRONT	Bajaj spare parts
DM161206	HOLDER ASSEMBLY STEP PILLION RH	Bajaj spare parts
DM161210	DECAL COVER SIDE LH	Bajaj spare parts
DM161211	DECAL COVER SIDE RH	Bajaj spare parts
DM171022	SPACER	Bajaj spare parts
DM171025	SHOCK ABSORBER CT100	Bajaj spare parts
DM171027	REAR SHOCK ABSORBER	Bajaj spare parts
DM181008	SPRING - FRONT FORK :- TWO PITCH	Bajaj spare parts
DM181010	WASHER FORK SPRING	Bajaj spare parts
DM181036	PIPE INNER FORK BOXER	Bajaj spare parts



DM181038	COVER : COVER FORK LH	Bajaj spare parts
DM181039	COVER : COVER FORK RH	Bajaj spare parts
DM181042	HOLDER FORK UPPER ASSY	Bajaj spare parts
DM191002	CABLE STARTER BOXER AR	Bajaj spare parts
DM191005	CABLE ACC TPS BO	Bajaj spare parts
DM191009	INSTRUMENT CLUSTER BOXER	Bajaj spare parts
DM191010	"ROD - BRAKE FOR 130 DRUM,BOXER SWING AR	Bajaj spare parts
DM191011	CABLE INR BRAKE BOX	Bajaj spare parts
DM191014	BOOT FOR LEVER - LH	Bajaj spare parts
DM191017	CABLE CLUTCH BOXER	Bajaj spare parts
DM191025	CABLE CLUTCH	Bajaj spare parts
DM201022	LAMP HEAD BOXER	Bajaj spare parts
DM201026	BOOT	Bajaj spare parts
DM201027	BLINKER FR LH BOXER	Bajaj spare parts
DM201028	BLINKER FR RH BOXER	Bajaj spare parts
DM201029	BLINKER RR LH BOXER	Bajaj spare parts
DM201030	BLINKER RR RH BOXER	Bajaj spare parts
DM201032	HARNESS WIRING	Bajaj spare parts
DM201035	HARNESS WIRING	Bajaj spare parts
DM201036	SWITCH CONTROL ASSY RH	Bajaj spare parts
DM201037	HARNESS WIRING	Bajaj spare parts
DM201039	INDICATOR ASSY REAR LH	Bajaj spare parts
DM201040	INDICATOR ASSY REAR RH	Bajaj spare parts
DM201041	HARNESS WIRING	Bajaj spare parts
DM201043	HARNESS WIRING - AHO	Bajaj spare parts
DM201044	HARNESS WIRING	Bajaj spare parts
DM201050	HARNESS WIRING	Bajaj spare parts
DM211021	"SEAT ASY.COMP.	Bajaj spare parts
DM211024	ASSLY SEAT COMPLETE	Bajaj spare parts
DM221001	BAND FOR TOOL KIT	Bajaj spare parts
DM221008	GRIP : GRIP FRAME	Bajaj spare parts
DM221013	KIT -TOOL WITH VALUE ENGG.	Bajaj spare parts
DM221015	GRIP FRAME	Bajaj spare parts
DM221017	GUARD SARI	Bajaj spare parts
DM221019	GRIP FRAME	Bajaj spare parts
DM221020	GRIP FRAME	Bajaj spare parts
DP101076	RING SET PISTON WIND 125	Bajaj spare parts
DP101107	WHEEL CLUTCH WIND 125	Bajaj spare parts
DP101108	HUB CLUTCH	Bajaj spare parts
DP101109	PLATE FRICTION	Bajaj spare parts
DP101110	PLATE FRICTION	Bajaj spare parts
DP101111	PLATE CLUTCH	Bajaj spare parts
DP101114	SPRING	Bajaj spare parts
DP101140	GASKET	Bajaj spare parts
DP101145	STUD	Bajaj spare parts

DP101153	"WASHER (ID = 6.5, OD = 24, THK. = 2)"	Bajaj spare parts
DP101154	PLUG	Bajaj spare parts
DP101155	COLLAR	Bajaj spare parts
DP101165	"RING SNAP(OD = 15.8,	Bajaj spare parts
DP101168	RING O	Bajaj spare parts
DP101191	BOLT M8X1.25XLENGTH=15.5	Bajaj spare parts
DP101198	CLAMP ID 45 X W 10	Bajaj spare parts
DP101243	PLATE JUDDER SPRING	Bajaj spare parts
DP101269	ROD PUSH	Bajaj spare parts
DP101340	BOLT - SOCKET	Bajaj spare parts
DP101452	STRAINER OIL WITH STEEL M	Bajaj spare parts
DP121006	RING O	Bajaj spare parts
DP121018	CLAMP (ID = 15 MM)	Bajaj spare parts
DP121025	CLAMP	Bajaj spare parts
DP121028	CLAMP	Bajaj spare parts
DP121034	ELEMENT AIR FILTER	Bajaj spare parts
DP121051	VALVE PISTON	Bajaj spare parts
DP121055	HODER MAIN JET	Bajaj spare parts
DP121059	RING O	Bajaj spare parts
DP121065	HOSE - DRAIN	Bajaj spare parts
DP121070	JET PILOT	Bajaj spare parts
DP141020	PAD (SEATLAB)-RR SIDE OF PAINTED F. TANK	Bajaj spare parts
DP151027	DAMPER FOR COUPLING	Bajaj spare parts
DP161006	FENDER RR FR WIND125	Bajaj spare parts
DP161074	PLATE	Bajaj spare parts
DP161078	NUT - CLIP	Bajaj spare parts
DP161082	FENDER COMPLETE REAR	Bajaj spare parts
DP161094	BOLT STEPPED M6	Bajaj spare parts
DP161101	BRACKET RR NO PLATE	Bajaj spare parts
DP161102	LOCK ASY SEAT	Bajaj spare parts
DP161144	PLATE NUMBER FRONT	Bajaj spare parts
DP161145	PLATE NUMBER REAR	Bajaj spare parts
DP161163	WASHER REAR FOOT STEP	Bajaj spare parts
DP161168	DAMPER COVER SIDE LH	Bajaj spare parts
DP161170	STEP PILLION FOOTREST WIND 125	Bajaj spare parts
DP161192	PAD FOR AFIXING ON FENDER-REAR & COWLING	Bajaj spare parts
DP161260	FITMENT ON PIPE-SEAT	Bajaj spare parts
DP161272	BRACKET ASLY.FOR MTG.REAR NUM PLATE	Bajaj spare parts
DP171006	BUSHING RUBBER	Bajaj spare parts
DP181012	BRACKET COWLING SIDE	Bajaj spare parts
DP181021	PLATE BRACKET NUMBER	Bajaj spare parts
DP181038	COWLING	Bajaj spare parts
DP181040	COLLAR - COWLING	Bajaj spare parts
DP181041	DAMPER FOR MOUNTING COWLING	Bajaj spare parts
DP181063	WINDSHIELD WIND 125	Bajaj spare parts

DP201019	LENS LAMP TAIL WIND125	Bajaj spare parts
DP201030	LAMP TAIL PLATINA	Bajaj spare parts
DP201037	COLLAR	Bajaj spare parts
DP211009	DAMPER FOR SEAT	Bajaj spare parts
DP221001	GRIP FRAME	Bajaj spare parts
DP221011	BAND	Bajaj spare parts
DS101024	VALVE - EXHAUST	Bajaj spare parts
DS101026	COVER TAPPET	Bajaj spare parts
DS101036	CAM CHAIN	Bajaj spare parts
DS101059	SPRING KICK STARTER	Bajaj spare parts
DS101071	GAUGE OIL LEVEL	Bajaj spare parts
DS101072	GASKET COVER RH	Bajaj spare parts
DS101076	GASKET COVER MAGNETO	Bajaj spare parts
DS101084	GASKET COPPER	Bajaj spare parts
DS101096	CAP CAMSHAFT	Bajaj spare parts
DS101110	SPRING - VALVE :- INNER	Bajaj spare parts
DS101117	SPRING - KICK STARTER RATCHET	Bajaj spare parts
DS101123	SPRING TORSION LEVER CL.	Bajaj spare parts
DS101134	LEVER GEAR SHIFT	Bajaj spare parts
DS101154	KEY	Bajaj spare parts
DS101166	BUSH SILENT HEAD COVER	Bajaj spare parts
DS101191	ARM ROCKER WITH ROLLER DI	Bajaj spare parts
DS101197	SPROCKET DRIVE	Bajaj spare parts
DS101201	BUSHING PTFE	Bajaj spare parts
DS101215	CLIP WIRE	Bajaj spare parts
DS101234	SPRING PIPE BREATHER	Bajaj spare parts
DS101251	LEVER CHANGE	Bajaj spare parts
DS101252	DECAL COVER CL DIS	Bajaj spare parts
DS101261	TAPPET COVER ASSY	Bajaj spare parts
DS101274	COVER MAGNETO WITH GAUGE	Bajaj spare parts
DS101275	SPROCKET DRIVE CAM	Bajaj spare parts
DS101276	SPROCKET DRIVEN CAM	Bajaj spare parts
DS101277	TENSIONER ASSEMBLY	Bajaj spare parts
DS101319	CLUTCH CENTRE	Bajaj spare parts
DS101333	Rocker Arm Assly	Bajaj spare parts
DS101335	SHAFT ARM ROCKER INTAKE	Bajaj spare parts
DS101336	SHAFT ARM ROCKER EXHAUST	Bajaj spare parts
DS101351	WIRE SHIELD	Bajaj spare parts
DS101353	BOLT FLANGE M6	Bajaj spare parts
DS101355	BOLT M5 HEAD	Bajaj spare parts
DS101360	CYL.BLOCK ASSY VDSP1	Bajaj spare parts
DS101361	SET RING PISTON	Bajaj spare parts
DS101365	GEAR OIL PUMP DRIVEN	Bajaj spare parts
DS101366	WASHER WAVE	Bajaj spare parts
DS101402	CYL BL PISTON ASSY	Bajaj spare parts

DS109905	CAM CHAIN (94 LINKS)	Bajaj spare parts
DS111014	MOTOR STARTER DISC.	Bajaj spare parts
DS111016	STATOR ASSY DISCOVER	Bajaj spare parts
DS111017	ROTOR DISCOVER	Bajaj spare parts
DS111033	STATOR ASSY DISCOVER	Bajaj spare parts
DS111035	COIL H T LH	Bajaj spare parts
DS111040	BRUSH CARBON HOLDER	Bajaj spare parts
DS111049	STATOR ASSY COU NEU	Bajaj spare parts
DS111051	MOTOR STARTER	Bajaj spare parts
DS111056	ROTOR ASSY COMPLETE	Bajaj spare parts
DS121002	GEAR OIL PUMP DRIVEN	Bajaj spare parts
DS121004	MESH FILTER OIL PUMP	Bajaj spare parts
DS121005	CAP STRAINER	Bajaj spare parts
DS121012	INSULATOR CARBURETOR	Bajaj spare parts
DS121020	ELEMENT AIR FILTER	Bajaj spare parts
DS121022	CATRIDGE ASSY AIR FILTER	Bajaj spare parts
DS121060	JET NEEDLE	Bajaj spare parts
DS121068	JET MJ	Bajaj spare parts
DS121069	JET COMPLETE	Bajaj spare parts
DS121076	VALVE FLOAT	Bajaj spare parts
DS121080	FLOAT COMPLETE	Bajaj spare parts
DS121113	SET ADJUSTER DISCOVER	Bajaj spare parts
DS121115	PLUNGER ASSY	Bajaj spare parts
DS121116	DUCT.	Bajaj spare parts
DS121117	DRAIN TUBE FILTER AI	Bajaj spare parts
DS121126	PLUG	Bajaj spare parts
DS121137	KIT PUMP OIL	Bajaj spare parts
DS141009	CAP FUEL TANK	Bajaj spare parts
DS141012	GROMMET SIDE COVER	Bajaj spare parts
DS141013	TAPE SEAT	Bajaj spare parts
DS141014	TUBE FUEL DISCOVER	Bajaj spare parts
DS151003	RIM WHEEL 1.6 X 17 DRUM	Bajaj spare parts
DS151004	SPOKE INNER FR DISCOVER D	Bajaj spare parts
DS151005	SPOKE OUTER FR DISCOVER DISC	Bajaj spare parts
DS151009	SPOKE INNER RR DISCOVER	Bajaj spare parts
DS151010	SPOKE OUTER RR DISCOVER	Bajaj spare parts
DS151025	ROD TORQUE	Bajaj spare parts
DS151034	RIM WHEEL 2.15 X 17 DIS	Bajaj spare parts
DS151038	KIT GEAR SPEEDOMETER 21T	Bajaj spare parts
DS151042	SPACER	Bajaj spare parts
DS151046	RIM 1.85 X 17 REAR DISCOV	Bajaj spare parts
DS151056	COVER DUST FRONT	Bajaj spare parts
DS151057	DUST COVER REAR	Bajaj spare parts
DS151058	SPACER	Bajaj spare parts
DS151060	SPACER ASSY	Bajaj spare parts

DS151061	COLLAR ASSY	Bajaj spare parts
DS151067	DRUM REAR - 4 RUBBER	Bajaj spare parts
DS151068	COUPLING 4 RUBBER	Bajaj spare parts
DS151069	PANEL BRAKE RE	Bajaj spare parts
DS151073	STUD 4 RUBBER	Bajaj spare parts
DS151087	PANEL ASSY BRAKE COM	Bajaj spare parts
DS151089	CAM BRAKE ASSY FRONT	Bajaj spare parts
DS151090	INDICATOR WEAR	Bajaj spare parts
DS151091	WEAR INDICATOR	Bajaj spare parts
DS151092	LEVER BRAKE	Bajaj spare parts
DS151094	NUT	Bajaj spare parts
DS161035	NUT - CLIP :- M6	Bajaj spare parts
DS161061	FENDER RR FR DISCOVER	Bajaj spare parts
DS161062	FENDER RR DISCOVER	Bajaj spare parts
DS161065	COVER SIDE RH	Bajaj spare parts
DS161069	BRACKET SIDE COVER	Bajaj spare parts
DS161077	STAND SIDE	Bajaj spare parts
DS161082	GROMMET SIDE COVER	Bajaj spare parts
DS161108	SLEEVE FENDER FRONT	Bajaj spare parts
DS161112	SHAFT STAND	Bajaj spare parts
DS161113	CENTER STAND	Bajaj spare parts
DS161117	STAY STEP MAIN DISCOVER	Bajaj spare parts
DS161125	GUIDE CABLE	Bajaj spare parts
DS161132	HANDLE GRAB	Bajaj spare parts
DS161141	FLAP FRONT FENDER	Bajaj spare parts
DS161150	GEAR SHIFTER LABEL	Bajaj spare parts
DS161156	PLUG - SEAT LOCK CABLE	Bajaj spare parts
DS161166	TAPE II FRAME	Bajaj spare parts
DS161187	COLLAR FOR MUDCOVER	Bajaj spare parts
DS161188	GRAB HANDLE BLACK	Bajaj spare parts
DS161224	BOLT AIR CLEANER MTG	Bajaj spare parts
DS161287	BILT FLANGE M6	Bajaj spare parts
DS171002	ARM SWING DISCOVER	Bajaj spare parts
DS171007	CHAIN SLIDER	Bajaj spare parts
DS171013	SHAFT ARM SWING	Bajaj spare parts
DS171014	FLAP MUD	Bajaj spare parts
DS171015	CAP SWING ARM	Bajaj spare parts
DS171018	BRACKET MTG.MUDCOVER RH	Bajaj spare parts
DS181005	BRACKET UPPER FR FORK	Bajaj spare parts
DS181007	WASHER HANDLE UPPER	Bajaj spare parts
DS181008	DAMPER HANDLE U	Bajaj spare parts
DS181009	DAMPER HANDLE LOWER	Bajaj spare parts
DS181010	WASHER HANDLE LOWER	Bajaj spare parts
DS181012	BOLT K	Bajaj spare parts
DS181015	NUT CAP FORK	Bajaj spare parts

DS181016	WASHER PLAIN	Bajaj spare parts
DS181018	NUT FORK	Bajaj spare parts
DS181019	HOLDER HANDLE UPPER	Bajaj spare parts
DS181020	HOLDER ASSY FORK UNDER	Bajaj spare parts
DS181022	SWITCH IGNITION	Bajaj spare parts
DS181023	COWLING	Bajaj spare parts
DS181026	BRACKET NO.PLATE	Bajaj spare parts
DS181031	FLAP COWLING	Bajaj spare parts
DS181033	TUBE OUTER LH	Bajaj spare parts
DS181034	TUBE OUTER RH	Bajaj spare parts
DS181036	LOCK SET 3 IN 1 DISCOVER	Bajaj spare parts
DS181042	TUBE OUTER LH DRUM DISCOV	Bajaj spare parts
DS181043	TUBE OUTER RH DRUM DISC	Bajaj spare parts
DS181044	HANDLE BAR DISCOVER	Bajaj spare parts
DS181060	FOAM - SIDE FLAP	Bajaj spare parts
DS181062	BRACKET ASSY UPPER	Bajaj spare parts
DS181066	WINDSHIELD DISCOVER	Bajaj spare parts
DS181069	DECAL WINDSHIELD D	Bajaj spare parts
DS181070	BUSH GUIDE	Bajaj spare parts
DS181071	BUSH SLIDE	Bajaj spare parts
DS181072	WASHER GUIDE BUSH	Bajaj spare parts
DS181075	BOLT FORK	Bajaj spare parts
DS181077	CYL COMP FORK	Bajaj spare parts
DS181078	PIPE COMPLETE INNE	Bajaj spare parts
DS181083	PIPE INNER INCREASED	Bajaj spare parts
DS181084	SPRING FORK FRONT	Bajaj spare parts
DS181085	SEAT FORK PIPE	Bajaj spare parts
DS181117	FORK ASSLY FR BLK	Bajaj spare parts
DS191001	CABLE CLUTCH DISCOVER	Bajaj spare parts
DS191002	PEDAL BRAKE	Bajaj spare parts
DS191003	ROD BRAKE	Bajaj spare parts
DS191007	SPRING SWITCH BRAKE	Bajaj spare parts
DS191008	CABLE INNER SPEEDO	Bajaj spare parts
DS191009	CABLE SPEEDO DISCOVE	Bajaj spare parts
DS191010	CABLE INNER SPEEDOMETER D	Bajaj spare parts
DS191011	SPRING PEDAL BRAKE	Bajaj spare parts
DS191013	CABLE CHOKE DISCOVER	Bajaj spare parts
DS191015	GRIP HAND LH	Bajaj spare parts
DS191016	GRIP HAND RH VERRO	Bajaj spare parts
DS191018	BOOT LEVER RH	Bajaj spare parts
DS191020	PIPE THROTTLE RIDE CONTRO	Bajaj spare parts
DS191035	PACKING BRAKE ROD	Bajaj spare parts
DS191036	HOLDER ASSY LH KS	Bajaj spare parts
DS191037	HOLDER ASSY LH ES	Bajaj spare parts
DS191038	HOLDER ASSY RH	Bajaj spare parts

DS191039	INSTRUMENT CLUSTER PRICOL	Bajaj spare parts
DS191040	COVER METER	Bajaj spare parts
DS191041	INSTRUMENT CLUSTERPRI DIS	Bajaj spare parts
DS191052	LEVER BOOT LH CLU SW	Bajaj spare parts
DS191053	CABLE SPEEDOMETER	Bajaj spare parts
DS191054	CABLE BRAKE WITH INER	Bajaj spare parts
DS191055	CABLE INNER SPEEDO	Bajaj spare parts
DS201003	REGULATOR AC / DC	Bajaj spare parts
DS201009	LENS LAMP TAIL DISCOVER	Bajaj spare parts
DS201019	COLLAR NEW RHL	Bajaj spare parts
DS201025	DC FLASHER	Bajaj spare parts
DS201028	SWITCH CONTROL RH DI	Bajaj spare parts
DS201033	SWITCH CONTROL RH DISCOVE	Bajaj spare parts
DS201035	HEADLAMP WO BULB-RINDER -	Bajaj spare parts
DS201036	CLIP BULB HEAD LAMP	Bajaj spare parts
DS201048	RELAY STARTER	Bajaj spare parts
DS201055	GAUGE FUEL	Bajaj spare parts
DS201062	HARNESS WIRING	Bajaj spare parts
DS201064	HARNESS WIRING CL SW-FR B	Bajaj spare parts
DS201079	TANK UNIT O RING	Bajaj spare parts
DS201082	BATTERY 12 V,5 Ah	Bajaj spare parts
DS201085	FLEXI BAND-STRIP CLAMP(L	Bajaj spare parts
DS211004	DAMPER SEAT I	Bajaj spare parts
DS211005	DAMPER SEAT II	Bajaj spare parts
DS211006	LOCK SEAT	Bajaj spare parts
DS211007	DAMPER SEAT FRONT	Bajaj spare parts
DS211009	LOCK ASSY. SEAT	Bajaj spare parts
DS221001	PLUG	Bajaj spare parts
DS7302X3	FENDER FR BLACK DISCOVER	Bajaj spare parts
DS7401X3	FAIRING BLACK DISCOVER	Bajaj spare parts
DS74113F	FAIRING 3D RED W RED	Bajaj spare parts
DT111106	FRAME RUBER PAD LH	Bajaj spare parts
DT111107	FRAME RUBER PAD RH	Bajaj spare parts
DT111134	FRAME ASSLY - K10	Bajaj spare parts
DT111163	FRAME ASSLY (K7)	Bajaj spare parts
DT111209	FRAME ASSEMBLY	Bajaj spare parts
DT111214	FRAME ASSEMBLY	Bajaj spare parts
DT113001	HOLDER STEP RH	Bajaj spare parts
DT113002	HOLDER STEP LH	Bajaj spare parts
DT113006	STEP HOLDER- PILLION LH	Bajaj spare parts
DT113008	STEP HOLDER- PILLION RH	Bajaj spare parts
DT113014	LOCK PLATE LH	Bajaj spare parts
DT113015	LOCK PLATE RH	Bajaj spare parts
DT113027	BOLT BANKING	Bajaj spare parts
DT113028	ASSLY STEP MAIN LH	Bajaj spare parts

DT113029	ASSLY STEP MAIN RH	Bajaj spare parts
DT113034	SPRING TENSION	Bajaj spare parts
DT113035	TAPE HOLDER STEP LH	Bajaj spare parts
DT113036	HOLDER STEP RH - NON ABS K8	Bajaj spare parts
DT113202	BOLT SPL-STAND MTG	Bajaj spare parts
DT113204	ASSLY SIDE STAND	Bajaj spare parts
DT113205	BRACKET SIDE STAND.	Bajaj spare parts
DT113408	BOLT -ENGINE HANGER	Bajaj spare parts
DT113800	BRACKET ROLL OVER SENSOR LOOSE	Bajaj spare parts
DT113801	BRACKET STARTER RELAY MTG L	Bajaj spare parts
DT113802	BRACKET REGULATOR	Bajaj spare parts
DT113803	BRACKET HT COIL MOUNT LOOSE-1	Bajaj spare parts
DT113804	BRACKET HT COIL MOUNT LOOSE-2	Bajaj spare parts
DT113806	SLEEVE-SENSOR ROLL OVER	Bajaj spare parts
DT113807	BRACKET TAIL LAMP	Bajaj spare parts
DT113813	BRACKET REFLEX REFLECTOR	Bajaj spare parts
DT113815	BRACKET FAIRING MTG LOWER	Bajaj spare parts
DT113817	GROMMET BKT TAIL LAMP	Bajaj spare parts
DT113818	SCREW STEP M5	Bajaj spare parts
DT113819	SPACER BLINKER MTG	Bajaj spare parts
DT113824	SLEEVE TAIL LAMP MTG.	Bajaj spare parts
DT113825	BRACKET FUSE BOX MTG LOOSE	Bajaj spare parts
DT113826	BRACKET BATTERY TOP COVER	Bajaj spare parts
DT113827	COVER SEAL HEAT	Bajaj spare parts
DT113830	BRACKET FAIRING MTG LOWER RH	Bajaj spare parts
DT113833	BRACKET REGULATOR MTG LOOSE	Bajaj spare parts
DT113839	CAP LDPE FOR BKT SEAT MTG	Bajaj spare parts
DT113841	BRACKET CANISTER MTG	Bajaj spare parts
DT113842	COVER SEAL HEAT	Bajaj spare parts
DT113846	FRAME BEADING	Bajaj spare parts
DT113848	CAP SWING ARM PIVOT	Bajaj spare parts
DT113849	STRAP ECU HARNESS	Bajaj spare parts
DT113850	BRACKET FRONT ABS MTG LOOSE	Bajaj spare parts
DT113851	BRACKET FUSE BOX MTG LOOSE	Bajaj spare parts
DT113854	BRACKET FAIRING MTG LOOSE	Bajaj spare parts
DT113855	CLAMP HT COILS	Bajaj spare parts
DT113856	BKT FILTER MTG LH (4.3 LIT AIR FLTR)	Bajaj spare parts
DT113858	TAPE FRAME - K8	Bajaj spare parts
DT113860	BRACKET RELAY INTERLOCK	Bajaj spare parts
DT113862	BRACKET UNIT ABS	Bajaj spare parts
DT113864	BRACKET VALVE PURGE	Bajaj spare parts
DT113865	BRACKET RELAY STARTER	Bajaj spare parts
DT113869	BRACKET ECU	Bajaj spare parts
DT113870	PAD	Bajaj spare parts
DT113871	DAMPER	Bajaj spare parts



DT113872	DAMPER	Bajaj spare parts
DT121001	TUBE OUTER LH	Bajaj spare parts
DT121002	TUBE OUTER RH	Bajaj spare parts
DT121013	WASHER	Bajaj spare parts
DT121015	GUIDE BUSH	Bajaj spare parts
DT121016	WASHER SEAL	Bajaj spare parts
DT121020	FORK BOLT	Bajaj spare parts
DT121021	RING O	Bajaj spare parts
DT121030	UPPER BRACKET	Bajaj spare parts
DT121031	FORK TOP BOLT	Bajaj spare parts
DT121032	CAP STEERING TOP BOLT	Bajaj spare parts
DT121035	UNDER BRACKET ASSY COMP	Bajaj spare parts
DT121036	SPACER TUBE	Bajaj spare parts
DT121037	MAIN SPRING	Bajaj spare parts
DT121038	FRONT FORK ASSLY-K8 (ABS)	Bajaj spare parts
DT121039	SEAT PIPE	Bajaj spare parts
DT121040	OUTER TUBE RH PC (K8-ABS)	Bajaj spare parts
DT121047	RUBBER DAMPER FORK TOP CAP (K8)	Bajaj spare parts
DT121049	ASSLY FRONT FORK - K8 ABS	Bajaj spare parts
DT121050	LEG ASSLY LH	Bajaj spare parts
DT121051	LEG ASSLY RH	Bajaj spare parts
DT121052	TUBE OUTER LH PC	Bajaj spare parts
DT121053	TUBE OUTER RH PC	Bajaj spare parts
DT122015	PLATE SWING ARM	Bajaj spare parts
DT122017	SWING ARM ASSLY - K10	Bajaj spare parts
DT122019	SHOCKABSORBER REAR PDC	Bajaj spare parts
DT122029	ARM ASSEMBLY SWING	Bajaj spare parts
DT122032	SHOCKABSORBER REAR	Bajaj spare parts
DT131009	AXLE FRONT	Bajaj spare parts
DT131011	COLLAR	Bajaj spare parts
DT131017	COLLAR ASSLY FRONT WHEEL	Bajaj spare parts
DT131207	AXLE -REAR	Bajaj spare parts
DT131209	COUPLING ASSLY	Bajaj spare parts
DT131210	SLEEVE	Bajaj spare parts
DT131212	SPROCKET 45T (6 MTG)	Bajaj spare parts
DT131213	COUPLING 6 LUG	Bajaj spare parts
DT131214	SEAL OIL 52 DIA	Bajaj spare parts
DT131215	LOCK WASHER	Bajaj spare parts
DT131802	DISC -300 MM	Bajaj spare parts
DT131824	DISC BRAKE KIT REAR (K8)	Bajaj spare parts
DT131826	CALIPER ASSLY	Bajaj spare parts
DT131831	MASTER CYLINDER ASSY FRONT	Bajaj spare parts
DT131832	CLAMP BRAKE HOSE FRONT	Bajaj spare parts
DT131833	GUIDE DISC BRAKE KIT HOSE	Bajaj spare parts
DT131835	DISC BRAKE KIT ASSLY FRONT (K8) N/ABS	Bajaj spare parts

DT131836	MASTER CYLINDER ASSLY FRONT	Bajaj spare parts
DT131837	BRACKET HOSE CLAMP ABS	Bajaj spare parts
DT131849	CLAMP FOR ABS HOSE	Bajaj spare parts
DT131852	ASSLY ABS SYSTEM I CHANNEL K8	Bajaj spare parts
DT131853	ASSLY CALIPER K8	Bajaj spare parts
DT131857	SPEED SENSOR MOUNTING ENCLOSURE	Bajaj spare parts
DT131862	ABS UNIT 9.1 ML - WET	Bajaj spare parts
DT131866	REAR MASTER CYLINDER ASSLY	Bajaj spare parts
DT131867	SENSOR DISC FRONT K7	Bajaj spare parts
DT131872	BRACKET ABS BRAKE HOSE CLAMP	Bajaj spare parts
DT131875	CLAMP BRAKE HOSE - K8	Bajaj spare parts
DT131878	CLAMP W ABS HOSE-SPEED SENSOR	Bajaj spare parts
DT131891	UNIT ABS WET	Bajaj spare parts
DT151010	HANDLEBAR TUBE ASSY LH	Bajaj spare parts
DT151012	HANDLEBAR TUBE ASSY RH	Bajaj spare parts
DT151036	HANDLE HOLDER LH (K8)	Bajaj spare parts
DT151037	HANDLE HOLDER RH (K8)	Bajaj spare parts
DT151039	PLUG HANDLE HOLDER	Bajaj spare parts
DT151040	FORK PIPE SPINING	Bajaj spare parts
DT151042	FORK TOP BOLT	Bajaj spare parts
DT151043	CAP FORK TOP BOLT	Bajaj spare parts
DT151046	DAMPER STERRING TOP BOLT CAP(K8)	Bajaj spare parts
DT161000	BRAKE SHAFT ASSY	Bajaj spare parts
DT161001	BRAKE PEDAL	Bajaj spare parts
DT161004	BRAKE SWITCH SPRING	Bajaj spare parts
DT161005	HAND GRIP ASSY RH	Bajaj spare parts
DT161007	LEVER & SUPPORT HOLDER ASSY LH	Bajaj spare parts
DT161010	HOLDER ASLY LH SUPPORT LEVER	Bajaj spare parts
DT161011	BRAKE PEDAL - K8 ABS	Bajaj spare parts
DT161012	ASSLY BRAKE SHAFT	Bajaj spare parts
DT161013	PEDAL BRAKE	Bajaj spare parts
DT161203	CLUTCH CABLE (K8)	Bajaj spare parts
DT161204	THROTTLE CABLE (K8)	Bajaj spare parts
DT171001	FUEL TANK ASSLY	Bajaj spare parts
DT171022	DAMPER TANK COVER RESTING FR LH	Bajaj spare parts
DT171023	DAMPER TANK COVER RESTING FR RH	Bajaj spare parts
DT171024	DAMPER TNK COVR RESTING CENTL LH	Bajaj spare parts
DT171025	DAMPER TNK COVR RESTING CENTL RH	Bajaj spare parts
DT171026	DAMPER TANK COVER RESTING REAR	Bajaj spare parts
DT171030	FOAM TANK COVER	Bajaj spare parts
DT171042	TANK SIDE COVER ASSLY	Bajaj spare parts
DT171046	STEP BOLT FUEL PUMP MTG.	Bajaj spare parts
DT171047	NYLON WASHER FUEL PUMP MTG	Bajaj spare parts
DT171048	PLAIN WASHER FUEL PUMP MTG.	Bajaj spare parts
DT171052	GROMMET TANK COVER TOP	Bajaj spare parts

DT171053	GROMMET TANK SIDE COVER	Bajaj spare parts
DT171055	FOAM FUEL TANK	Bajaj spare parts
DT171061	DRAIN TUBE	Bajaj spare parts
DT171073	GROMMET TANK COVER ASSLY	Bajaj spare parts
DT171074	TUBE PURGE VALVE TO CONNECTOR K8	Bajaj spare parts
DT171075	SLEEVE TANK MTG FRONT	Bajaj spare parts
DT171076	"DAMPER TANK COVER MTG FR, LH"	Bajaj spare parts
DT171078	GROMMET TANK MTG FRONT -OBLONG	Bajaj spare parts
DT171080	COLLAR TANK COVER MTG	Bajaj spare parts
DT171082	BEADING TANK COVER	Bajaj spare parts
DT171087	ASSY TUBE PUMP TO FILTER (PHASE III)	Bajaj spare parts
DT171089	ASSY TUBE FILTER TO REGULATOR (PHASE III)	Bajaj spare parts
DT171092	ASSLY FUEL TANK PH III - K7 EVAP	Bajaj spare parts
DT171095	FUEL TANK ASSY NON EVAP PH-III	Bajaj spare parts
DT171107	TANK ASSEMBLY FUEL	Bajaj spare parts
DT171602	PIPE TANK-CONNECTOR	Bajaj spare parts
DT171611	PIPE CONNECTOR-VALVE PURGE	Bajaj spare parts
DT171612	PIPE VALVE PURGE-CONNECTOR	Bajaj spare parts
DT171613	PIPE CONNECTOR-CANISTER	Bajaj spare parts
DT171811	O RING FUEL PUMP	Bajaj spare parts
DT171814	INLINE FUEL FILTER	Bajaj spare parts
DT171821	CLAMP PUMP END PERMANENT	Bajaj spare parts
DT171822	CLAMP QUICK CONNECTOR END PERMT	Bajaj spare parts
DT171823	FUEL PUMP (W/O FLS)	Bajaj spare parts
DT171834	TUBE CANISTER TO PURGE VALVE	Bajaj spare parts
DT171839	PLATE PRESSURE K7 FUEL PUMP MTG PHASE II	Bajaj spare parts
DT171846	TUBE Y-CONNECTOR TO CANISTER-K8	Bajaj spare parts
DT171847	TUBE CONN. TO THROTTLE BODY-K8	Bajaj spare parts
DT171852	CLAMP EAR	Bajaj spare parts
DT181000	TUBE REAR HUGGER MTG (K8)	Bajaj spare parts
DT181001	COWL RADIATOR	Bajaj spare parts
DT181003	GROMMET BATTERY CASE	Bajaj spare parts
DT181004	SEAT COWL LH - K10	Bajaj spare parts
DT181005	SEAT COWL RH - K10	Bajaj spare parts
DT181007	UNDER TRAY FRONT - K10	Bajaj spare parts
DT181010	BOLT SOC-HEAD M5XL15 SPEEDO	Bajaj spare parts
DT181011	TAPE FRONT FAIRING	Bajaj spare parts
DT181013	DAMPER SIDE COVER	Bajaj spare parts
DT181018	RUBBER DAMPER SIDE FAIRING MESH	Bajaj spare parts
DT181022	BAND BATTERY CASE	Bajaj spare parts
DT181024	TAPE ANTI-SQUEAK SIDE FAIRING	Bajaj spare parts
DT181028	PLUG PUSH PULL COWL RADIATOR	Bajaj spare parts
DT181030	TAPE ANTI-ABRASIVE 3M - K8	Bajaj spare parts
DT181034	FOAM TANK COVER - K8	Bajaj spare parts
DT181039	TAPE INSULATION	Bajaj spare parts

DT181042	TAPE INSULATION II	Bajaj spare parts
DT181043	TAPE INSULATION III	Bajaj spare parts
DT181207	FLANGE SEAT COVER LH	Bajaj spare parts
DT181210	SEAT COWL CENTRAL TOP	Bajaj spare parts
DT181213	SIDE FAIRING LH	Bajaj spare parts
DT181214	SIDE FAIRING MESH LH	Bajaj spare parts
DT181215	SIDE FAIRING ENCLOSURE LH	Bajaj spare parts
DT181221	SIDE FAIRING MESH RH	Bajaj spare parts
DT181222	SIDE COVER LH	Bajaj spare parts
DT181223	SIDE COVER RH	Bajaj spare parts
DT181227	SLEEVE-BATTERY BOX	Bajaj spare parts
DT181228	SIDE FAIRING ENCLOSURE RH	Bajaj spare parts
DT181232	VISOR	Bajaj spare parts
DT181233	SPEEDO FLAP	Bajaj spare parts
DT181242	FAIRING STRUCTURE	Bajaj spare parts
DT181244	FAIRING STRUCTURE MIDDLE LH	Bajaj spare parts
DT181246	FAIRING STRUCTURE MIDDLE RH	Bajaj spare parts
DT181248	NUMBER PLATE MOU BRACKET	Bajaj spare parts
DT181254	GROMMET SIDE FAIRING	Bajaj spare parts
DT181255	DAMPER SPEEDO FLAP	Bajaj spare parts
DT181256	SEAT COWL CENTRAL BOTTOM	Bajaj spare parts
DT181260	GROMMET-BATTERY BOX	Bajaj spare parts
DT181261	FOAM BATTERY CASE (I)	Bajaj spare parts
DT181264	FOAM RH SEAT COWL	Bajaj spare parts
DT181265	GROMMET SIDE COVER	Bajaj spare parts
DT181267	OUTER MASK LH	Bajaj spare parts
DT181268	OUTER MASK RH	Bajaj spare parts
DT181273	STEP BOLT TANK COVER TOP	Bajaj spare parts
DT181274	COLLAR SIDE COVER	Bajaj spare parts
DT181275	FAIRING STRUCTURE MIDDLE	Bajaj spare parts
DT181284	PAD MIRROR MOUNTING	Bajaj spare parts
DT181285	COVER FAIRING MTG LOWER	Bajaj spare parts
DT181286	LOWER FAIRING LH (K8)	Bajaj spare parts
DT181291	BRACKET SIDE FAIRING FRONT LH	Bajaj spare parts
DT181292	BRACKET SIDE FAIRING FRONT RH	Bajaj spare parts
DT181293	BRACKET SIDE FAIRING REAR	Bajaj spare parts
DT181294	FAIRING STRUCTURE LOWER LH	Bajaj spare parts
DT181297	CAP CHAIN COVER	Bajaj spare parts
DT181299	PAD MIRROR BASE MTG.	Bajaj spare parts
DT181300	COVER SIDE LH - K10	Bajaj spare parts
DT181301	COVER SIDE RH - K10	Bajaj spare parts
DT181306	WINDSHIELD - K10	Bajaj spare parts
DT181307	BRACKET BELLY PAN MTG - K10	Bajaj spare parts
DT181308	CHAIN COVER ASSLY -K10	Bajaj spare parts
DT181310	HEX THRUST WASHER	Bajaj spare parts

DT181311	SPACER FAIRING STRUCTURE MTG.	Bajaj spare parts
DT181317	GROMMET BATTERY CASE-VERT ECU	Bajaj spare parts
DT181318	FOAM BATTERY CASE-VERT ECU	Bajaj spare parts
DT181319	FOAM BATTERY CASE I-VERT-ECU	Bajaj spare parts
DT181320	FOAM BATTERY CASE II-VERT-ECU	Bajaj spare parts
DT181321	PAD TANK COVER SITTING	Bajaj spare parts
DT181322	PLUG 1	Bajaj spare parts
DT181323	PLUG 2	Bajaj spare parts
DT181324	LOWER FAIRING RH	Bajaj spare parts
DT181325	LOWER FAIRING STRUCTURE RH	Bajaj spare parts
DT181326	FOAM SIDE FAIRING INNER	Bajaj spare parts
DT181347	TAPE INSULATION I	Bajaj spare parts
DT181407	BRACE FENDER (K8)	Bajaj spare parts
DT181408	FENDER FRONT ASSEMBLY(K8)	Bajaj spare parts
DT181411	SPACER FENDER FRONT (K8)	Bajaj spare parts
DT181414	ASSLY HUGGER REAR	Bajaj spare parts
DT181415	COVER TUBE HUGGER	Bajaj spare parts
DT181416	ASSLY REAR HUGGER COMP(K8)	Bajaj spare parts
DT181433	PLUG FRONT FENDER REAR	Bajaj spare parts
DT181434	CUP WASHER FRONT FENDER MTG	Bajaj spare parts
DT181435	GROMMET FRONT FENDER - K8	Bajaj spare parts
DT181437	BRACE FENDER (K8)	Bajaj spare parts
DT181439	SPACER FRONT FENDER - K8	Bajaj spare parts
DT191006	SEAT ASSLY FRONT 350	Bajaj spare parts
DT191009	SEAT ASSLY REAR 350	Bajaj spare parts
DT191012	DAMPER SEAT FRONT	Bajaj spare parts
DT191022	GROMMET REAR SEAT REAR	Bajaj spare parts
DT231000	BOX TOOLKIT (LOOSE)	Bajaj spare parts
DT231002	KIT TOOL - K8	Bajaj spare parts
DT231400	GRAB HANDLE LH	Bajaj spare parts
DT231401	GRAB HANDLE RH	Bajaj spare parts
DT231402	GRAB HANDLE LOWER LH	Bajaj spare parts
DT231403	GRAB HANDLE LOWER RH	Bajaj spare parts
DT231404	ASSLY GRAB HANDLE LH	Bajaj spare parts
DT231405	ASSLY GRAB HANDLE RH	Bajaj spare parts
DT231407	GRAB HANDLE LH - K10	Bajaj spare parts
DT231410	GRAB HANDLE RH - K10	Bajaj spare parts
DT231600	MIRROR ASSLY LH	Bajaj spare parts
DT231601	MIRROR ASSLY RH	Bajaj spare parts
DT231606	PLUG MIRROR MTG.	Bajaj spare parts
DT231607	BOLT MIRROR MTG LH THREAD	Bajaj spare parts
DT231608	BOLT MIRROR MTG RH THREAD	Bajaj spare parts
DT231609	BRACKET MIRROR MOUNTING LH	Bajaj spare parts
DT231610	BRACKET MIRROR MOUNTING RH	Bajaj spare parts
DT231611	MIRROR ASSLY LH - K8	Bajaj spare parts

DT231612	MIRROR ASSLY RH - K8	Bajaj spare parts
DT232601	LOCK SET 3 IN 1	Bajaj spare parts
DT232605	LOCK REAR SEAT - K8	Bajaj spare parts
DT232606	LOCK SET 3 IN 1 - EVAP E10	Bajaj spare parts
DT232804	RUBBER PAD NUMBER PLATE MTG.	Bajaj spare parts
DT232815	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
DT232816	BRACKET PLATE NUMBER REAR	Bajaj spare parts
DT233043	3D PULSAR DECAL K8 (SILVER)	Bajaj spare parts
DT233079	3D TANK DECAL	Bajaj spare parts
DT233082	DECAL TANK TOP COVER	Bajaj spare parts
DT233093	DECAL TANK TOP COVER	Bajaj spare parts
DT233095	3D TANK DECAL ROUSER (BLACK)	Bajaj spare parts
DT233096	3D TANK DECAL	Bajaj spare parts
DT233097	3D TANK DECAL (SILVER)	Bajaj spare parts
DT233100	DECAL FAIRING UPPER LH	Bajaj spare parts
DT233101	DECAL FAIRING UPPER RH	Bajaj spare parts
DT233102	DECAL FAIRING LOWER LH	Bajaj spare parts
DT233103	DECAL FAIRING LOWER RH	Bajaj spare parts
DT233104	DECAL SIDE FAIRING LOWER 2 LH	Bajaj spare parts
DT233105	DECAL SIDE FAIRING LOWER 2 RH	Bajaj spare parts
DT233106	DECAL SEAT COWL LH	Bajaj spare parts
DT233107	DECAL SEAT COWL RH	Bajaj spare parts
DT233108	FENDER DECAL LH	Bajaj spare parts
DT233109	FENDER DECAL RH	Bajaj spare parts
DT233110	DECAL SIDE FAIRING UPPER LH	Bajaj spare parts
DT233111	DECAL SIDE FAIRING UPPER RH	Bajaj spare parts
DT233112	DECAL FRONT FENDER ABS	Bajaj spare parts
DT233123	TANK 3D DECAL PULSE (BLACK)	Bajaj spare parts
DT233134	DECAL FAIRING LH RED-WHITE	Bajaj spare parts
DT233135	DECAL FAIRING RH RED-WHITE	Bajaj spare parts
DT233136	DECAL SIDE FAIRING UP LH RED-WH	Bajaj spare parts
DT233137	DECAL SIDE FAIRING UP RH RED-WH	Bajaj spare parts
DT233138	DECAL FLAP SIDE FAIRING LH	Bajaj spare parts
DT233139	DECAL FLAP SIDE FAIRING RH	Bajaj spare parts
DT233140	DECAL SIDE FAIRING LO LH RED-WH	Bajaj spare parts
DT233141	DECAL SIDE FAIRING LO RH RED-WH	Bajaj spare parts
DT233142	DECAL COVER TANK TOP LH RED-WH	Bajaj spare parts
DT233143	DECAL COVER TANK TOP RH RED-WH	Bajaj spare parts
DT233144	DECAL COWL SEAT LH RED-WHITE	Bajaj spare parts
DT233145	DECAL COWL SEAT RH RED-WHITE	Bajaj spare parts
DT233148	DECAL FAIRING LH BLUE-WHITE	Bajaj spare parts
DT233149	DECAL FAIRING RH BLUE-WHITE	Bajaj spare parts
DT233150	DECAL SIDE FAIRING UP LH BLUE-WH	Bajaj spare parts
DT233151	DECAL SIDE FAIRING UP RH BLUE-WH	Bajaj spare parts
DT233152	DECAL SIDE FAIRING LO LH BLUE-WH	Bajaj spare parts

DT233153	DECAL SIDE FAIRING LO RH BLUE-WH	Bajaj spare parts
DT233154	DECAL COVER TANK TOP LH BLUE-WH	Bajaj spare parts
DT233155	DECAL COVER TANK TOP RH BLUE-WH	Bajaj spare parts
DT233156	DECAL COWL SEAT LH BLUE-WHITE	Bajaj spare parts
DT233157	DECAL COWL SEAT RH BLUE-WHITE	Bajaj spare parts
DT233160	DECAL FAIRING LH BLACK-GRAY	Bajaj spare parts
DT233161	DECAL FAIRING RH BLACK-GRAY	Bajaj spare parts
DT233162	DECAL SIDE FAIRING UP LH BLK-GRY	Bajaj spare parts
DT233163	DECAL SIDE FAIRING UP RH BLK-GRY	Bajaj spare parts
DT233164	DECAL SIDE FAIRING LO LH BLK-GRY	Bajaj spare parts
DT233165	DECAL SIDE FAIRING LO RH BLK-GRY	Bajaj spare parts
DT233166	DECAL COVER TANK TOP LH BLK-GRAY	Bajaj spare parts
DT233167	DECAL COVER TANK TOP RH BLK-GRAY	Bajaj spare parts
DT233168	DECAL COWL SEAT LH BLACK-GRAY	Bajaj spare parts
DT233169	DECAL COWL SEAT RH BLACK-GRAY	Bajaj spare parts
DT233172	DECAL WHEEL REAR	Bajaj spare parts
DT233186	DECAL TANK 3D-GRAY	Bajaj spare parts
DT233192	DECAL TANK 3D ROUSER-GREY	Bajaj spare parts
DT233225	DECAL ABS LH	Bajaj spare parts
DT233226	DECAL ABS RH	Bajaj spare parts
DT233227	DECAL PULSAR	Bajaj spare parts
DT233243	DECAL WHEEL FRONT PEWTER GREY LH	Bajaj spare parts
DT233244	DECAL WHEEL FRONT PEWTER GREY RH	Bajaj spare parts
DT233245	DECAL WHEEL FRONT BURNT RED LH	Bajaj spare parts
DT233246	DECAL WHEEL FRONT BURNT RED RH	Bajaj spare parts
DT233247	DECAL WHEEL FR PEARL M WHITE LH	Bajaj spare parts
DT233248	DECAL WHEEL FR PEARL M WHITE RH	Bajaj spare parts
DT351001	STATOR ASSLY	Bajaj spare parts
DT351006	STATOR ASSLY	Bajaj spare parts
DT351008	STATOR ASSLY	Bajaj spare parts
DT351015	STATOR ASSEMBLY	Bajaj spare parts
DT351202	COIL HT1 WITH CAP	Bajaj spare parts
DT351204	COIL HT2 WITH CAP	Bajaj spare parts
DT351401	ECU SERIES FOR PRODUCTION	Bajaj spare parts
DT351411	ASSLY EPM44 (K8)	Bajaj spare parts
DT351800	SWITCH NEUTRAL + PICK UP COIL	Bajaj spare parts
DT351802	NEUTRAL INDICATION SWITCH	Bajaj spare parts
DT351803	SENSOR THROTTLE POSITION	Bajaj spare parts
DT351806	SENSOR ASSEMBLY PICK UP	Bajaj spare parts
DT401001	TAIL LAMP	Bajaj spare parts
DT401002	INDICATOR FRONT LH	Bajaj spare parts
DT401003	INDICATOR FRONT RH	Bajaj spare parts
DT401004	INDICATOR REAR LH	Bajaj spare parts
DT401005	INDICATOR REAR RH	Bajaj spare parts
DT401008	ASSLY PROJECTOR	Bajaj spare parts

DT401009	FRONT POSITION LAMP LH	Bajaj spare parts
DT401010	FRONT POSITION LAMP RH	Bajaj spare parts
DT401011	ASSLY HIGH BEAM PROJECTOR	Bajaj spare parts
DT401012	BULB H1155W SEALED COUPLER	Bajaj spare parts
DT401015	INDICATOR ASSY REAR LH	Bajaj spare parts
DT401016	INDICATOR ASSY REAR RH	Bajaj spare parts
DT401017	PIVOT SCREW M6	Bajaj spare parts
DT401018	ADJUSTING BOLT M8- VERTICAL ADJ	Bajaj spare parts
DT401019	ADJUSTING BOLT M10-HOR-ADJ	Bajaj spare parts
DT401020	HEAD LAMP ASSLY - K10	Bajaj spare parts
DT401021	TAIL LAMP ASSLY - K10	Bajaj spare parts
DT401024	12V H9 65W BULB	Bajaj spare parts
DT401403	CONTROL SWITCH LH	Bajaj spare parts
DT401404	CONTROL SWITCH RH	Bajaj spare parts
DT401407	SWITCH CONTROL RH	Bajaj spare parts
DT401408	CLUTCH SWITCH	Bajaj spare parts
DT402003	CAPACITOR ASSLY	Bajaj spare parts
DT402004	REGULATOR ASSY	Bajaj spare parts
DT402005	LIGHT CONTROL MODULE (LED)	Bajaj spare parts
DT402006	LIGHT CONTROL MODULE (BULB)	Bajaj spare parts
DT402008	LED FLASHER (K8)	Bajaj spare parts
DT402009	REGULATOR WITH INBUILT CAPACITOR-K8	Bajaj spare parts
DT402010	LIGHT CONTROL MODULE	Bajaj spare parts
DT402204	FUSE BOX ASSY/MINI FUSE	Bajaj spare parts
DT402212	MAIN WIRING HARNESS (K8)	Bajaj spare parts
DT402218	CABLE RELAY TO MOTOR (K8)	Bajaj spare parts
DT402219	EARTH CABLE (K8)	Bajaj spare parts
DT402220	MAIN WIRING HARNESS-K8 (ABS)	Bajaj spare parts
DT402223	EARTH CABLE	Bajaj spare parts
DT402226	FUSE 7.5A MINI	Bajaj spare parts
DT402227	FUSE 5A MINI	Bajaj spare parts
DT402231	HARNESS MAIN - K8 EVAP	Bajaj spare parts
DT402232	WIRING HARNESS-W/O LCM (K8-NON ABS)	Bajaj spare parts
DT402233	WIRING HARNESS-W/O LCM (K8-ABS)	Bajaj spare parts
DT402234	HARNESS PIGTAIL - MAGNETO TO RR	Bajaj spare parts
DT402239	HARNESS WITH EMP44 PH-III FUEL PUM	Bajaj spare parts
DT402241	WIRING HARNESS ABS K8 EVAP	Bajaj spare parts
DT402242	WIRING HARNESS NON ABS K8 EVAP	Bajaj spare parts
DT402243	HARNESS PH-III WITH EVAP AND EMP	Bajaj spare parts
DT402246	HARNESS WIRING ABS	Bajaj spare parts
DT402247	HARNESS WIRING	Bajaj spare parts
DT402256	HARNESS WIRING	Bajaj spare parts
DT402258	HARNESS WIRING	Bajaj spare parts
DT402266	HARNESS WIRING	Bajaj spare parts
DT402267	HARNESS WIRING	Bajaj spare parts



DT402271	HARNESS WIRING	Bajaj spare parts
DT402403	SPEEDOMETER ASSY	Bajaj spare parts
DT402404	SENSOR SPEED WHEEL (ABS)	Bajaj spare parts
DT402407	VEHICLE SPEED SENSOR	Bajaj spare parts
DT402408	SPEEDOMETE ASSY-K8 (ABS)	Bajaj spare parts
DT402409	SPEEDOMETER ASSLY - K10	Bajaj spare parts
DT402410	SPEEDOMETER ASSLY TANK - K10	Bajaj spare parts
DT402415	FOAM SPEEDOMTER - K8	Bajaj spare parts
DT402420	SPEEDOMETER ASSLY ABS	Bajaj spare parts
DT402421	SPEEDOMETER ASSLY NON ABS	Bajaj spare parts
DT402423	SPEEDOMETER	Bajaj spare parts
DT402426	INSTRUMENT CLUSTER	Bajaj spare parts
DT402600	FUEL LEVEL SENSOR	Bajaj spare parts
DT501020	ENGINE ASSEMBLY	Bajaj spare parts
DT501027	ENGINE ASSLY	Bajaj spare parts
DT501030	ENGINE ASSEMBLY	Bajaj spare parts
DT511027	CYLINDER HEAD COVER ASSLY	Bajaj spare parts
DT511032	HEAD CYLINDER-HOLDER CAMSHAFT	Bajaj spare parts
DT511033	HEAD CYLINDER ASSEMBLY	Bajaj spare parts
DT511097	HEAD CYLINDER COMPLETE	Bajaj spare parts
DT511239	ASSEMBLY CAMSHAFT	Bajaj spare parts
DT511244	ROLLER ASSLY_ CARBONITRIDE	Bajaj spare parts
DT511261	ASSLY ROCKER ARM INTAKE	Bajaj spare parts
DT511262	ASSLY ROCKER ARM EXHAUST	Bajaj spare parts
DT511270	VALVE EXHAUST	Bajaj spare parts
DT541018	BRACKET CLUTCH CABLE	Bajaj spare parts
DT541019	SHAFT CLUTCH RELEASE ASSLY	Bajaj spare parts
DT541202	COVER LH RR	Bajaj spare parts
DT541203	MAGNETO COVER ASSY CPL	Bajaj spare parts
DT541204	CLUTCH COVER WITH PLUG	Bajaj spare parts
DT541206	ASSLY MAGNETO COVER	Bajaj spare parts
DT541209	MAGNETO COVER WTH PLUG	Bajaj spare parts
DT541210	JET OIL STATOR	Bajaj spare parts
DT541212	CLUTCH COVER WITH PLUG	Bajaj spare parts
DT551400	CLUTCH ASSLY COMP	Bajaj spare parts
DT551401	CENTER CLUTCH	Bajaj spare parts
DT551402	PLATE CLUTCH PRESSURE	Bajaj spare parts
DT551403	SPRING CLUTCH	Bajaj spare parts
DT551408	CLUTCH PLATE	Bajaj spare parts
DT551409	CLUTCH ASSLY COMPLETE	Bajaj spare parts
DT551412	COLLAR	Bajaj spare parts
DT551413	BUSH BIMETALLIC	Bajaj spare parts
DT561201	ASSY LEVER COMP CHANGE	Bajaj spare parts
DT561205	DAMPER	Bajaj spare parts
DT561206	LEVER GEAR SHIFT ASSLY COMP	Bajaj spare parts

DT561408	CHANGE LEVER ASSY	Bajaj spare parts
DT561409	LEVER CHANGE ARM ASSY	Bajaj spare parts
DT561414	LEVER ASSEMBLY CHANGE	Bajaj spare parts
DT561416	ARM ASSEMBLY CHANGE	Bajaj spare parts
DT581016	DUCT DIRTY SIDE	Bajaj spare parts
DT581028	SEAL TOP COVER	Bajaj spare parts
DT581048	BREATHER TUBE ASSEMBLY	Bajaj spare parts
DT581049	BREATHER TUBE	Bajaj spare parts
DT581062	FILTER ELEMENT	Bajaj spare parts
DT581064	ASSLY AIR FILTER	Bajaj spare parts
DT581079	ASSLY AIR FILTER	Bajaj spare parts
DT581401	PIPE INTAKE	Bajaj spare parts
DT591072	BAND CLIP END CHAMBER	Bajaj spare parts
DT591116	ASSLY HEAT SHIELD	Bajaj spare parts
DT591118	GROMMET HEAT SHIELD	Bajaj spare parts
DT591131	CHAMBER LH	Bajaj spare parts
DT591132	CHAMBER RH	Bajaj spare parts
DT591133	CHAMBER END CAP	Bajaj spare parts
DT591156	INSERT	Bajaj spare parts
DT591230	ASSLY PIPE A EXHAUST	Bajaj spare parts
DT591238	MUFFLER ASSLY COMP	Bajaj spare parts
DT591340	ASSEMBLY MUFFLER	Bajaj spare parts
DT601210	TUBE DRAIN	Bajaj spare parts
DT601218	HOSE COOLANT(THERM TO T PIPE)	Bajaj spare parts
DT601219	PIPE COOLANT T ASSLY	Bajaj spare parts
DT601224	RADIATOR	Bajaj spare parts
DT601226	EXPANSION TANK	Bajaj spare parts
DT601228	TUBE CONNECTING	Bajaj spare parts
DT601229	RADIATOR ASSLY	Bajaj spare parts
DT601232	RADIATOR CORE	Bajaj spare parts
DT601237	RADIATOR ASSEMBLY	Bajaj spare parts
DT611202	ASSLY THROTTLE BODY	Bajaj spare parts
DT611203	CAP INJECTOR WITH ASSY QUICK	Bajaj spare parts
DT611208	INJECTOR CAP WITH QUICK CONNECTOR	Bajaj spare parts
DT611209	ASSLY THROTTLE BODY (PHASE III)	Bajaj spare parts
DT611210	ASSLY THROTTLE BODY_EVAP_PHASE-III	Bajaj spare parts
DU010142	DECAL ANTI SKID	Bajaj spare parts
DU010152	DECAL FAIRING LH E BLACK-BLUE	Bajaj spare parts
DU010153	DECAL FAIRING RH E BLACK-BLUE	Bajaj spare parts
DU010156	DECAL COVER SIDE LH E BLACK-BLUE	Bajaj spare parts
DU010157	DECAL COVER SIDE RH C BLACK-BLUE	Bajaj spare parts
DU010162	DECAL FAIRING LH E BLACK-RED	Bajaj spare parts
DU010163	DECAL FAIRING RH E BLACK-RED	Bajaj spare parts
DU010164	DECAL TANK LH EBONY BLACK-RED	Bajaj spare parts
DU010165	DECAL TANK RH EBONY BLACK-RED	Bajaj spare parts

DU010166	DECAL COVER SIDE LH E BLACK-RED	Bajaj spare parts
DU010167	DECAL COVER SIDE RH E BLACK-RED	Bajaj spare parts
DU010176	DECAL COVER SIDE LH M G YELLOW	Bajaj spare parts
DU010177	DECAL COVER SIDE RH M G YELLOW	Bajaj spare parts
DU010183	DECAL ANTI SKID	Bajaj spare parts
DU101005	CRANKSHAFT CT 100	Bajaj spare parts
DU101010	GASKET CENTRIFUGAL OIL FI	Bajaj spare parts
DU101038	GEAR SPUR KICK	Bajaj spare parts
DU101041	COVER CENTRIFUGAL OIL FIL	Bajaj spare parts
DU101045	SHAFT KICK	Bajaj spare parts
DU101050	LEVER KICK	Bajaj spare parts
DU101056	SPROCKET CAMSHAFT	Bajaj spare parts
DU101057	INSULATOR CARB. AND INTAK	Bajaj spare parts
DU101058	PIPEINTAKE	Bajaj spare parts
DU101060	ARM ROCKER ROLLER	Bajaj spare parts
DU101066	WASHER SPROCKET CAM	Bajaj spare parts
DU101067	COLLAR CAMSHAFT	Bajaj spare parts
DU101073	STOPPER DRUM GEAR SHIFT	Bajaj spare parts
DU101074	PLATE POSITION	Bajaj spare parts
DU101075	CRANKCASE RH CT 100	Bajaj spare parts
DU101080	GEAR 1ST DRIVEN	Bajaj spare parts
DU101081	DRUM CHANGE	Bajaj spare parts
DU101083	CAM DRUM CHANGE	Bajaj spare parts
DU101085	BUSHING	Bajaj spare parts
DU101103	BODY OIL FILTER GREY C	Bajaj spare parts
DU101109	COLLAR CLUTCH	Bajaj spare parts
DU101113	SPACER	Bajaj spare parts
DU101180	SHIELD TUBE EXHAUST	Bajaj spare parts
DU101185	LEVER CHANGE WITH DAMPER	Bajaj spare parts
DU101190	ARM ROCKER	Bajaj spare parts
DU101191	SHAFT ROCKER	Bajaj spare parts
DU101196	SILENCER W/OUT CAT	Bajaj spare parts
DU101206	NUT FLANGE	Bajaj spare parts
DU101208	HEAD CYLINDER	Bajaj spare parts
DU101210	COVER CLUTCH	Bajaj spare parts
DU101211	KEY WOODRUFF	Bajaj spare parts
DU101212	SPROCKET OUTPUT	Bajaj spare parts
DU101213	PLATE LOCK SPROCKET OUTP	Bajaj spare parts
DU101214	SHAFT OUTPUT	Bajaj spare parts
DU101216	CRANKCASE LHCT 100 CT 100	Bajaj spare parts
DU101218	CYL BL.ASSY CT100/Platina	Bajaj spare parts
DU101220	ENGINE ASSY NEW CT100	Bajaj spare parts
DU101223	PLUG DRAIN MAGNETIC	Bajaj spare parts
DU101225	BOLT FLANGED	Bajaj spare parts
DU101228	BOLT FLANGED	Bajaj spare parts

DU101232	DECAL CLUTCH COVER	Bajaj spare parts
DU101245	AEEMBLY ENGINE CT100 PHILIPPINES	Bajaj spare parts
DU101278	SHAFT INPUT CT100	Bajaj spare parts
DU101279	GEAR 2ND DRIVE CT100	Bajaj spare parts
DU101280	CRANKCASE LH CT100	Bajaj spare parts
DU101328	CYLINDER HEAD MACHINED CT 100 SAI	Bajaj spare parts
DU101359	ASSLY ENGINE CT100 SAI	Bajaj spare parts
DU101376	ASSLY-DRUM WITH HAMMER DRIVE SCREW	Bajaj spare parts
DU101400	SHAFT INPUT	Bajaj spare parts
DU101401	GEAR DRIVE SECOND	Bajaj spare parts
DU101406	SHAFT OUTPUT	Bajaj spare parts
DU111001	CDI ASSY WITH DAMPER FOR CT-100	Bajaj spare parts
DU111006	CDI CT100	Bajaj spare parts
DU121005	PIPE OIL	Bajaj spare parts
DU121008	DUCT AIR FILTER TO TO CAR	Bajaj spare parts
DU121009	CARBURETTOR CT 100	Bajaj spare parts
DU121013	JET MAIN	Bajaj spare parts
DU121015	FLOAT COMPLETE (LOCAL)	Bajaj spare parts
DU121017	VALVE THROTTLE	Bajaj spare parts
DU121018	NEEDLE JET	Bajaj spare parts
DU121021	SPRING - COMPRESSION	Bajaj spare parts
DU121028	SEAT JET NEEDLE	Bajaj spare parts
DU121033	CARBURETTOR ASLY.:- PB16 FOR PHILLIPINES	Bajaj spare parts
DU121052	RING SEAL AF CT100	Bajaj spare parts
DU121053	HOSE MANIFOLD CT100 SAI	Bajaj spare parts
DU121054	HOSE INTAKE SAI CT100	Bajaj spare parts
DU121056	ASSLY MANIFOLD CT 100 SAI	Bajaj spare parts
DU121057	TUBE METALLIC CT 100 SAI	Bajaj spare parts
DU121058	HOSE CONNECTOR CT 100 SAI	Bajaj spare parts
DU121059	GASKET FLANGE CT100 SAI	Bajaj spare parts
DU121060	ASSLY CARB CT100 EVAP	Bajaj spare parts
DU121063	CARBURETTOR ASSLY	Bajaj spare parts
DU121077	CARBURETTOR	Bajaj spare parts
DU121084	PLATE BREATHER	Bajaj spare parts
DU121085	FOAM BREATHER	Bajaj spare parts
DU141014	LAB SEAT	Bajaj spare parts
DU141027	COLLAR ASSY	Bajaj spare parts
DU141041	TUBE FUEL	Bajaj spare parts
DU141061	CAP ASSY FUEL TANK	Bajaj spare parts
DU141078	DECAL TANK LH BLUE (JT BL	Bajaj spare parts
DU141079	DECAL TANK RH BLUE (JT BL	Bajaj spare parts
DU141086	TANK DECAL-LH (STAR BLUE)	Bajaj spare parts
DU141087	TANK DECAL-RH (STAR BLUE)	Bajaj spare parts
DU141095	COCK FUEL ECO CT100	Bajaj spare parts
DU141228	COCK FUEL ASSEMBLY	Bajaj spare parts

DU141240	TANK DECAL UPPER LH EL BLUE	Bajaj spare parts
DU141241	TANK DECAL UPPER RH EL BLUE	Bajaj spare parts
DU141250	TANK DECAL UPPER LH	Bajaj spare parts
DU141258	CAP FUEL TANK EVAP	Bajaj spare parts
DU141271	TUBE PURGE VALVE TO CARBUERATTOR	Bajaj spare parts
DU141272	TUBE CANISTER DRAIN	Bajaj spare parts
DU141277	TUBE TANK TO T CONNECTOR	Bajaj spare parts
DU141278	TUBE INLINE CONNECTOR	Bajaj spare parts
DU141315	PAD TANK LH	Bajaj spare parts
DU141316	PAD TANK RH	Bajaj spare parts
DU141321	TAPE PAD TANK LH	Bajaj spare parts
DU141325	PIPE VALVE PURGE-CARBURETTOR	Bajaj spare parts
DU141326	TAPE PAD TANK RH	Bajaj spare parts
DU151005	COLLAR ASSY AXLE	Bajaj spare parts
DU151006	COLLAR	Bajaj spare parts
DU151009	DRUM BRAKE RR CT100	Bajaj spare parts
DU151010	COUPLING	Bajaj spare parts
DU151018	RIM 1.85 X 17 CT 100	Bajaj spare parts
DU151025	SPOKE INNER 3.5 DIA CT 100	Bajaj spare parts
DU151026	SPOKE OUTER 3.5 DIA CT 100	Bajaj spare parts
DU151029	AXLE M12 X 1.25	Bajaj spare parts
DU151031	NUT	Bajaj spare parts
DU151034	WHEEL REAR 1.6X17-110 DR SILVER	Bajaj spare parts
DU151037	PANEL ASSLY FRONT BRAKE	Bajaj spare parts
DU151038	DRUM REAR	Bajaj spare parts
DU151042	STAY PILLION RH B105D	Bajaj spare parts
DU151044	LEVER PANEL BRAKE FRONT	Bajaj spare parts
DU151046	LEVER PANEL BRAKE REAR	Bajaj spare parts
DU151047	ASSEMBLY PEDAL BRAKE	Bajaj spare parts
DU151055	CABLE PEDAL-UNIT DISTRIBUTOR	Bajaj spare parts
DU151056	CABLE UNIT DISTRIBUTOR-PANEL FR	Bajaj spare parts
DU151058	SPRING	Bajaj spare parts
DU151061	GROMMET	Bajaj spare parts
DU151067	COUPLING	Bajaj spare parts
DU151074	LEVER PANEL BRAKE REAR	Bajaj spare parts
DU151078	WHEEL REAR 1.85X17 DRUM	Bajaj spare parts
DU151086	SPROCKET	Bajaj spare parts
DU161008	FENDER RR CT100	Bajaj spare parts
DU161009	COVER SIDE LEFT	Bajaj spare parts
DU161010	COVER SIDE (R)	Bajaj spare parts
DU161011	COVER SEAT	Bajaj spare parts
DU161024	PLUG	Bajaj spare parts
DU161032	STAND CENTER	Bajaj spare parts
DU161065	NUT - CLIP :- M6	Bajaj spare parts
DU161093	BRACKET ENGINE FR LH	Bajaj spare parts

DU161094	BRACKET ENGINE FRRH	Bajaj spare parts
DU161096	GASKET COVER RH	Bajaj spare parts
DU161098	BRACE FOR FENDER-FR-RIV+ 8MM	Bajaj spare parts
DU161102	DAMPER	Bajaj spare parts
DU161119	SCREW-STEPPED M6 X 16	Bajaj spare parts
DU161125	CHASSIS CT100	Bajaj spare parts
DU161144	STAY LH CT 100	Bajaj spare parts
DU161162	COVER SEAT DECAL LH BLUE(	Bajaj spare parts
DU161176	COVER-SIDE DECAL LH (STAR BLUE)	Bajaj spare parts
DU161177	COVER-SIDE DECAL RH (STAR BLUE)	Bajaj spare parts
DU161178	COVER-SEAT DECAL LH (STAR BLUE)	Bajaj spare parts
DU161179	COVER-SEAT DECAL RH (STAR BLUE)	Bajaj spare parts
DU161196	TAPE - FRAME	Bajaj spare parts
DU161221	COVER SIDE DECAL LH FLAME RED	Bajaj spare parts
DU161223	COVER SIDE DECAL LH EL BLUE	Bajaj spare parts
DU161224	COVER SIDE DECAL RH EL BLUE	Bajaj spare parts
DU161226	COVER SEAT DECAL RH BLACK RED	Bajaj spare parts
DU161230	COVER SEAT DECAL RH EL BLUE	Bajaj spare parts
DU161232	COVER SIDE DECAL RH BLACK BLUE	Bajaj spare parts
DU161235	ASSLY PILLION STAY RH	Bajaj spare parts
DU161236	STAY PILLION RH	Bajaj spare parts
DU161239	COVER SIDE DECAL LH	Bajaj spare parts
DU161240	COVER SIDE DECAL RH	Bajaj spare parts
DU161241	COVER SIDE DECAL LH	Bajaj spare parts
DU161242	COVER SIDE DECAL RH	Bajaj spare parts
DU161243	COVER SIDE DECAL LH	Bajaj spare parts
DU161244	COVER SIDE DECAL RH	Bajaj spare parts
DU161245	COVER SIDE DECAL LH	Bajaj spare parts
DU161246	COVER SIDE DECAL RH	Bajaj spare parts
DU161247	COVER SEAT DECAL LH	Bajaj spare parts
DU161248	COVER SEAT DECAL RH	Bajaj spare parts
DU161249	COVER SEAT DECAL LH	Bajaj spare parts
DU161250	COVER SEAT DECAL RH	Bajaj spare parts
DU161251	COVER SEAT DECAL LH	Bajaj spare parts
DU161252	COVER SEAT DECAL RH	Bajaj spare parts
DU161253	COVER SEAT DECAL LH	Bajaj spare parts
DU161254	COVER SEAT DECAL RH	Bajaj spare parts
DU161265	FRAME ASSY	Bajaj spare parts
DU161266	ASSLY STAY PILLION LH	Bajaj spare parts
DU161267	STAY PILLION LH	Bajaj spare parts
DU161268	ASSLY STAY PILLION RH	Bajaj spare parts
DU161269	STAY PILLION RH	Bajaj spare parts
DU161271	STAY PILLION RH	Bajaj spare parts
DU161281	GUIDE CABLE	Bajaj spare parts
DU161283	FRAME ASSLY	Bajaj spare parts

DU161286	DECAL COVER SIDE LH BLACK RED	Bajaj spare parts
DU161287	DECAL COVER SIDE RH BLACK RED	Bajaj spare parts
DU161288	DECAL COVER SIDE LH FLAME RED	Bajaj spare parts
DU161289	DECAL COVER SIDE RH FLAME RED	Bajaj spare parts
DU161292	DECAL COVER SIDE LH BLACK BLUE	Bajaj spare parts
DU161293	DECAL COVER SIDE RH BLACK BLUE	Bajaj spare parts
DU161307	FRAME ASSEMBLY	Bajaj spare parts
DU161311	BRACKET BOX FUSE	Bajaj spare parts
DU161317	DECAL COWL SEAT RH BLACK RED	Bajaj spare parts
DU161324	FRAME ASSEMBLY	Bajaj spare parts
DU161325	HOLDER ASSEMBLY STEP RIDER	Bajaj spare parts
DU161326	COVER LINK CBS	Bajaj spare parts
DU161329	HOOK	Bajaj spare parts
DU161346	PLUG	Bajaj spare parts
DU161358	FRAME ASSEMBLY	Bajaj spare parts
DU161364	FENDER REAR FRONT	Bajaj spare parts
DU161367	FRAME ASSEMBLY	Bajaj spare parts
DU161372	HOLDER STEP PILLION RH	Bajaj spare parts
DU161373	GUIDE CABLE	Bajaj spare parts
DU161377	BRACKET FAIRING LOWER	Bajaj spare parts
DU161384	BRACKET PLATE NUMBER REAR	Bajaj spare parts
DU161391	HOOK	Bajaj spare parts
DU161394	BRACE ASSEMBLY	Bajaj spare parts
DU161412	FLAP SPEEDOMETER	Bajaj spare parts
DU161444	BELLY PAN	Bajaj spare parts
DU161454	FRAME ASSEMBLY	Bajaj spare parts
DU161462	BRACKET ENGINE FRONT	Bajaj spare parts
DU161463	BRACKET BELLY PAN	Bajaj spare parts
DU171018	ARM COMPLETE - SWING	Bajaj spare parts
DU171037	SHOCKABSORBER REAR	Bajaj spare parts
DU171043	ARM ASSEMBLY SWING	Bajaj spare parts
DU181021	HANDLE BAR CT 100	Bajaj spare parts
DU181030	COWLING	Bajaj spare parts
DU181031	WIND SHIELD CT 100	Bajaj spare parts
DU181032	LOCK SET CT 100	Bajaj spare parts
DU181047	BRACKET COWLING UPPER	Bajaj spare parts
DU181067	FORK FRONT CT 100	Bajaj spare parts
DU181070	FLAP COWLING	Bajaj spare parts
DU181071	COWLING DECAL-LH BLUE (JT BLK)	Bajaj spare parts
DU181072	COWLING DECAL-RH BLUE	Bajaj spare parts
DU181077	FAIRING LH GREY CT 100	Bajaj spare parts
DU181081	COWLING DECAL-LH (STAR BLUE)	Bajaj spare parts
DU181082	COWLING DECAL-RH (STAR BLUE)	Bajaj spare parts
DU181090	COWLING DECAL-RH BLACK RED	Bajaj spare parts
DU181091	COWLING DECAL-LH FLAME RED	Bajaj spare parts

DU181092	COWLING DECAL RH FLAME RED	Bajaj spare parts
DU181093	COWLING DECAL-LH EL BLUE	Bajaj spare parts
DU181094	COWLING DECAL-RH EL BLUE	Bajaj spare parts
DU181096	COWLING DECAL LH BLACK BLUE	Bajaj spare parts
DU181097	COWLING DECAL RH BLACK BLUE	Bajaj spare parts
DU181099	LEG ASSLY LH	Bajaj spare parts
DU181101	TUBE OUTER LH	Bajaj spare parts
DU181102	TUBE OUTER RH	Bajaj spare parts
DU181107	HANDLE BAR	Bajaj spare parts
DU181108	OIL SEAL - DIA 30 SFN	Bajaj spare parts
DU181111	LOCK SET	Bajaj spare parts
DU181114	HANDLEBAR	Bajaj spare parts
DU181125	FORK FRONT	Bajaj spare parts
DU181144	BELLOW FORK FRONT	Bajaj spare parts
DU181155	HANDLEBAR	Bajaj spare parts
DU181156	SET LOCK	Bajaj spare parts
DU181157	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
DU181159	BRACKET ASSEMBLY FAIRING LOWER	Bajaj spare parts
DU181174	STRUCTURE FLAP SPEEDOMETER	Bajaj spare parts
DU181175	STRUCTURE INDICATOR FRONT	Bajaj spare parts
DU181180	FORK FRONT	Bajaj spare parts
DU191003	GRIP ASSY RH	Bajaj spare parts
DU191005	CABLE ACC BOX/CT	Bajaj spare parts
DU191006	CABLE CLUTCH CT 100	Bajaj spare parts
DU191008	CABLE INNER BRAKE CT 100	Bajaj spare parts
DU191009	GRIP LH	Bajaj spare parts
DU191013	CABLE SPEEDOMETER CT 100	Bajaj spare parts
DU191022	COVER METER UPPER	Bajaj spare parts
DU191023	COVER METER LOWER	Bajaj spare parts
DU191024	CASE INNERWHITE	Bajaj spare parts
DU191025	INSTRUMENT CLUSTERFOR CT	Bajaj spare parts
DU191030	ROD BRAKE	Bajaj spare parts
DU191031	SWITCH CONTROL RH CT 1	Bajaj spare parts
DU191033	LEVER SWITCH LH	Bajaj spare parts
DU191034	SWITCH ASSY CONTROL	Bajaj spare parts
DU191035	LEVER LH	Bajaj spare parts
DU191041	CABLE BRAKE INER	Bajaj spare parts
DU191044	ASSLY SWITCH CONTROL LH	Bajaj spare parts
DU191045	ASSLY SWITCH CONTROL RH	Bajaj spare parts
DU191046	CABLE BRAKE WITHOUT ADJUSTER	Bajaj spare parts
DU191047	CABLE CLUTCH WITHOUT ADJUSTER	Bajaj spare parts
DU191048	CABLE THROTTLE	Bajaj spare parts
DU191050	ASSLY LEVER BRAKE TUBULAR	Bajaj spare parts
DU191056	SWITCH CONTROL RH	Bajaj spare parts
DU191058	CABLE THROTTLE	Bajaj spare parts



DU191059	CABLE CLUTCH	Bajaj spare parts
DU191060	CABLE BRAKE	Bajaj spare parts
DU191062	CABLE BRAKE	Bajaj spare parts
DU191063	SPEEDOMETER	Bajaj spare parts
DU191070	SPEEDOMETER	Bajaj spare parts
DU191072	PEDAL ASSEMBLY BRAKE	Bajaj spare parts
DU191076	SPEEDOMETER	Bajaj spare parts
DU191077	CABLE PEDAL-UNIT DISTRIBUTOR	Bajaj spare parts
DU201008	BLINKER FR LH CT 100	Bajaj spare parts
DU201010	BLINKER FR RH CT 100	Bajaj spare parts
DU201012	BLINKER RR LH CT 100	Bajaj spare parts
DU201014	BLINKER RR RH CT 100	Bajaj spare parts
DU201016	LENS BLINKER CT 100	Bajaj spare parts
DU201018	SWITCH CONTROL RH	Bajaj spare parts
DU201023	LAMP TAIL CT 100	Bajaj spare parts
DU201029	SCREW SPECIAL	Bajaj spare parts
DU201046	PLUNGER-SPRING CONTR SWIT	Bajaj spare parts
DU201047	LAMP HEAD CT 100	Bajaj spare parts
DU201057	HOUSING HEAD LAMP ROUND	Bajaj spare parts
DU201060	COLLAR HEAD LIGHT	Bajaj spare parts
DU201061	HARNESS WIRING CT 100	Bajaj spare parts
DU201062	REGULATOR RECTIFIER UNIT	Bajaj spare parts
DU201063	CAPACITOR ELECTROLYTIC	Bajaj spare parts
DU201066	LENS LAMP TAIL CT 100	Bajaj spare parts
DU201083	HEAD LIGHT LENS H	Bajaj spare parts
DU201099	HARNESS WIRING CT 100	Bajaj spare parts
DU201101	LAMP HEAD CT 100 TZ	Bajaj spare parts
DU201104	HARNESS WIRING	Bajaj spare parts
DU201108	LAMP ASSY HEAD LENS REFLE	Bajaj spare parts
DU201110	CAP DUST FOR HS1 LAMP	Bajaj spare parts
DU201118	HARNESS WIRING-AHO	Bajaj spare parts
DU201119	HARNESS WIRING ES	Bajaj spare parts
DU201121	HARNESS WIRING	Bajaj spare parts
DU201123	INDICATOR FRONT LH	Bajaj spare parts
DU201124	INDICATOR FRONT RH	Bajaj spare parts
DU201125	INDICATOR REAR LH	Bajaj spare parts
DU201126	INDICATOR REAR RH	Bajaj spare parts
DU201127	HARNESS WIRING	Bajaj spare parts
DU201132	HARNESS WIRING	Bajaj spare parts
DU201137	HARNESS WIRING	Bajaj spare parts
DU201144	HARNESS WIRING	Bajaj spare parts
DU201147	SWITCH BRAKE-SPRING	Bajaj spare parts
DU201154	HARNESS WIRING	Bajaj spare parts
DU201156	HARNESS WIRING	Bajaj spare parts
DU201158	HARNESS WIRING	Bajaj spare parts

DU201160	HARNESS WIRING	Bajaj spare parts
DU201176	HARNESS WIRING	Bajaj spare parts
DU201222	HARNESS WIRING	Bajaj spare parts
DU211001	SEAT ASSY CT 100	Bajaj spare parts
DU211004	SEAT ASSEMBLY	Bajaj spare parts
DU221001	GRIP FRAME DIE CAST	Bajaj spare parts
DU221002	GUARD-SARI	Bajaj spare parts
DU221004	GRIP FRAME TUBULAR	Bajaj spare parts
DU221005	PLUG FOR TUBE DIA. 17.46 MM X THK 1.6 MM	Bajaj spare parts
DU221015	GUARD SARI	Bajaj spare parts
DU221017	GRIP FRAME - TUBULAR BLACK	Bajaj spare parts
DU221021	ASSEMBLY HOLDER STEP RIDER	Bajaj spare parts
DU221028	MIRROR LH	Bajaj spare parts
DU221029	MIRROR RH	Bajaj spare parts
DU221030	GUARD LEG	Bajaj spare parts
DU221041	GUARD LEG LH	Bajaj spare parts
DU221042	GUARD LEG RH	Bajaj spare parts
DU70013N	CRANKCASE CASE RH GREY CT	Bajaj spare parts
DU70023N	HEAD CYLINDER GREY CT 100	Bajaj spare parts
DU730722	FENDER FR JET BLACK CT 100	Bajaj spare parts
DU73073E	FRONT FENDER PAINTED ELECTRON BLUE	Bajaj spare parts
DU7307X4	FRONT FENDER PAINTED (NEW) FLAME RED	Bajaj spare parts
DU74013H	FAIRING BLACK/ BLUE CT 10	Bajaj spare parts
DU74013J	FAIRING BLACK/ RED CT 100	Bajaj spare parts
DU74013L	FAIRINGBLACK/ GREY CT 100	Bajaj spare parts
DU7402X4	FAIRING FL RED CT100	Bajaj spare parts
DV101034	ROD TIE	Bajaj spare parts
DV101035	SHIELD TUBE EXHAUST	Bajaj spare parts
DV101040	LEVER CHANGE	Bajaj spare parts
DV101042	GASKET COVER MAGNETO	Bajaj spare parts
DV101044	SPRING RETURN GEAR SHIFT	Bajaj spare parts
DV101045	SPRING STOPPER DRUM GEAR	Bajaj spare parts
DV101048	SPROCKET OUTPUT 14T	Bajaj spare parts
DV101052	LEVER GEAR SHIFT	Bajaj spare parts
DV101056	SHIELD MUFFLER RR AVENGER	Bajaj spare parts
DV101057	SHIELD MUFFLER FR AVENGER	Bajaj spare parts
DV101059	TUBE DRAIN (AIR FILTER)	Bajaj spare parts
DV111005	STATOR ASSYAVENGER	Bajaj spare parts
DV121005	TUBE BREATHER	Bajaj spare parts
DV151005	CAUPLING	Bajaj spare parts
DV151007	COLLAR ASSLY	Bajaj spare parts
DV161033	STAND CENTRE	Bajaj spare parts
DV161036	BATTERY BAND	Bajaj spare parts
DV161045	GUARD STEP LH	Bajaj spare parts
DV161046	HOLDER STEP LH	Bajaj spare parts

DV161047	RUBBER STEP MAIN	Bajaj spare parts
DV161050	RUBBER STEP STOPPER	Bajaj spare parts
DV161053	GUARD - LH FOR CHAIN	Bajaj spare parts
DV161060	SPRING MAIN STAND	Bajaj spare parts
DV171001	SHOCK ABSORBER RR AVENGER	Bajaj spare parts
DV181001	FORK FRONT AVENGER	Bajaj spare parts
DV181002	HANDLE BAR AVENGER	Bajaj spare parts
DV181003	WEIGHT HANDLE BAR END	Bajaj spare parts
DV181008	BRACKET SPEEDOMETER	Bajaj spare parts
DV181009	GROMMET SPEEDO MTG.	Bajaj spare parts
DV181010	COLLAR SPEEDO MTG.	Bajaj spare parts
DV181011	ASSLY LEG LH	Bajaj spare parts
DV181013	FORK PIPE AVENGER	Bajaj spare parts
DV181016	LOCK SET 5 IN 1 AV 110 SE	Bajaj spare parts
DV191001	CABLE BRAKE RR AVENGER	Bajaj spare parts
DV191002	CABLE CLUTCH AVENGER	Bajaj spare parts
DV191004	CABLE ACCELER AVENG	Bajaj spare parts
DV191007	LEVER BRAKE FRONT	Bajaj spare parts
DV191008	INSTRU CLUSTER AVENGR	Bajaj spare parts
DV201006	CABLE EARTH AVENGER	Bajaj spare parts
DV201010	LAMP HEAD AVENGER	Bajaj spare parts
DV201011	LAMP TAIL AVENGER	Bajaj spare parts
DV201014	BLINKER RR LH AVENGER	Bajaj spare parts
DV201015	BLINKER RR RH AVENGER	Bajaj spare parts
DV201016	RELAY STARTER	Bajaj spare parts
DV201025	HARNESS WIRING KILL SWIT	Bajaj spare parts
DV221001	EMBLEM BACK REST	Bajaj spare parts
DV73012V	COVER SIDE LH C WINE RED	Bajaj spare parts
DV73022V	COVER SIDE RH C. WINE RED	Bajaj spare parts
DX101030	BRACKET CLUTCH CABLE	Bajaj spare parts
DX101035	LEVER CLUTCH DISCOVER	Bajaj spare parts
DX101045	GEAR TRANSMI SPUR 2ND I/	Bajaj spare parts
DX101046	SHAFT OUTPUT TRANSMISSION	Bajaj spare parts
DX101047	GEAR PRIMARY DRIVE HELICA	Bajaj spare parts
DX101048	GEAR 3RD DRIVE	Bajaj spare parts
DX101049	GEAR 4TH DRIVE	Bajaj spare parts
DX101050	GEAR 3RD DRIVEN	Bajaj spare parts
DX101051	GEAR 4TH DRIVEN	Bajaj spare parts
DX101052	SPROCKET OUTPUT	Bajaj spare parts
DX101053	BODY CENTRIFUGAL O F	Bajaj spare parts
DX101054	HOUSING CLUTCH	Bajaj spare parts
DX101055	CLUTCH ASSY DISCOVER	Bajaj spare parts
DX101064	CYL BLOCK ASSY.CT110	Bajaj spare parts
DX101068	GC Lever Bolt	Bajaj spare parts
DX101074	SCREW PAN CROSS M6 PRECOATED	Bajaj spare parts

DX111005	ROTOR ASSEMBLY	Bajaj spare parts
DX121005	FILTER AIR COVER.	Bajaj spare parts
DX121007	CATRIDGE AIR FILTER	Bajaj spare parts
DX121010	FILTER AIR ELEMENT	Bajaj spare parts
DX121011	ARRESTER COMPLETE FLAME.	Bajaj spare parts
DX121015	CARBURETTOR DISCOVER	Bajaj spare parts
DX151007	COUPLING AASEMBLY	Bajaj spare parts
DX151008	COUPLING	Bajaj spare parts
DX151009	SLEEVE	Bajaj spare parts
DX151010	BOLT D	Bajaj spare parts
DX151012	COLLAR ASSEMBLY	Bajaj spare parts
DX151015	WASHER PLAIN	Bajaj spare parts
DX151016	AXLE	Bajaj spare parts
DX151018	WASHER PLAIN	Bajaj spare parts
DX151020	WHEEL 1.85 X 17 DC 4 RUBB	Bajaj spare parts
DX151022	COLLAR	Bajaj spare parts
DX151081	DRIVE CHAIN CONNE.	Bajaj spare parts
DX161032	BASE BATTERY	Bajaj spare parts
DX161044	BAND BATTERY 5AH	Bajaj spare parts
DX161045	BATTERY ARRESTER	Bajaj spare parts
DX161052	BEADING CHAIN CASE	Bajaj spare parts
DX161056	RUBBER STEP PILLION	Bajaj spare parts
DX161065	BRACE FENDER	Bajaj spare parts
DX161066	PAD BRACE FENDER	Bajaj spare parts
DX161067	PLATE LOCK PILLION STEP	Bajaj spare parts
DX171001	ARM SWING DISCOVER	Bajaj spare parts
DX171004	SHOCK ABSORBER RR DIS.	Bajaj spare parts
DX171007	SHOCK ABSORBER REAR	Bajaj spare parts
DX181008	FORK PIPE SPINNING DISCOV	Bajaj spare parts
DX181010	SPRING FORK FRONT DISCOVE	Bajaj spare parts
DX191001	PIPE THROTTLE	Bajaj spare parts
DX191003	CABLE ACCELETOR DIS	Bajaj spare parts
DX191004	CABLE CLUTCH	Bajaj spare parts
DX191006	CABLE BRAKE FR DISCOVER	Bajaj spare parts
DX191009	LEVER ASSEMBLY RH	Bajaj spare parts
DY111010	COLLAR	Bajaj spare parts
DY111031	FRAME ASSLY	Bajaj spare parts
DY111036	FRAME ASSEMBLY	Bajaj spare parts
DY111042	FRAME ASSEMBLY	Bajaj spare parts
DY111054	FRAME ASSEMBLY	Bajaj spare parts
DY111058	FRAME ASSEMBLY	Bajaj spare parts
DY111073	BRACKET CABLE BRAKE LOWER	Bajaj spare parts
DY111074	BRACKET BELLY PAN UPPER	Bajaj spare parts
DY111095	FRAME ASSEMBLY	Bajaj spare parts
DY111108	FRAME ASSEMBLY	Bajaj spare parts

DY113000	ASSLY MAIN STEP LH	Bajaj spare parts
DY113001	MAIN STEP LH	Bajaj spare parts
DY113002	ASSLY MAIN STEP RH	Bajaj spare parts
DY113004	STEP ASSLY MAIN RH	Bajaj spare parts
DY113006	HOLDER ASSEMBLY STEP PILLION RH	Bajaj spare parts
DY113007	HOLDER STEP PILLION RH	Bajaj spare parts
DY113008	STEP ASSEMBLY REAR LH	Bajaj spare parts
DY113009	STEP ASSEMBLY REAR RH	Bajaj spare parts
DY113014	STEP REAR RH	Bajaj spare parts
DY113017	STEP ASSEMBLY RIDER RH	Bajaj spare parts
DY113019	STAY RH	Bajaj spare parts
DY113021	STEP ASSEMBLY RIDER LH	Bajaj spare parts
DY113200	STAND SIDE	Bajaj spare parts
DY113203	STAND SIDE	Bajaj spare parts
DY113206	STAND CENTER	Bajaj spare parts
DY113400	BRACKET ENGINE MTG FRONT	Bajaj spare parts
DY113406	HANGER ENGINE UPPER	Bajaj spare parts
DY113407	BRACKET ASSEMBLY ENGINE FRONT	Bajaj spare parts
DY113409	HANGER ASSEMBLY ENGINE UPPER RH	Bajaj spare parts
DY113411	HANGER ASSEMBLY ENGINE UPPER RH	Bajaj spare parts
DY113803	CLAMP ASSEMBLY BATTERY	Bajaj spare parts
DY113806	HOOK	Bajaj spare parts
DY113814	HOOK	Bajaj spare parts
DY121000	FORK ASSLY	Bajaj spare parts
DY121007	BRACKET UPPER	Bajaj spare parts
DY121014	FRAME LAMP HEAD	Bajaj spare parts
DY121015	FORK FRONT	Bajaj spare parts
DY121018	ASSEMBLY BRACKET UNDER	Bajaj spare parts
DY121020	FORK FRONT	Bajaj spare parts
DY121032	BRACKET CABLE BRAKE	Bajaj spare parts
DY122001	ARM ASSLY SWING	Bajaj spare parts
DY122002	ADJUSTER ASSLY CHAIN LH	Bajaj spare parts
DY122004	ADJUSTER ASSLY CHAIN RH	Bajaj spare parts
DY122015	ARM ASSEMBLY SWING	Bajaj spare parts
DY122020	ARM ASSEMBLY SWING	Bajaj spare parts
DY122021	SHOCKABSORBER REAR	Bajaj spare parts
DY122045	ROD ASSEMBLY TORQUE	Bajaj spare parts
DY122049	ROD ASSEMBLY TORQUE	Bajaj spare parts
DY122050	ARM ASSEMBLY SWING	Bajaj spare parts
DY131008	CLAMP HOSE BRAKE	Bajaj spare parts
DY131206	COLLAR	Bajaj spare parts
DY151006	HANDLEBAR	Bajaj spare parts
DY161002	ASSLY LEVER BRAKE TUBULAR	Bajaj spare parts
DY161003	ROD BRAKE	Bajaj spare parts
DY161004	ASSEMBLY PEDAL BRAKE	Bajaj spare parts

DY161007	ASSEMBLY PEDAL BRAKE	Bajaj spare parts
DY161021	ROD BRAKE	Bajaj spare parts
DY161024	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
DY161025	ROD BRAKE	Bajaj spare parts
DY161200	CABLE THROTTLE	Bajaj spare parts
DY161201	CABLE CLUTCH	Bajaj spare parts
DY161202	CABLE BRAKE	Bajaj spare parts
DY161205	CABLE CHOKE	Bajaj spare parts
DY161206	CABLE THROTTLE	Bajaj spare parts
DY161209	CABLE BRAKE FRONT	Bajaj spare parts
DY161210	CABLE CLUTCH	Bajaj spare parts
DY161212	CABLE BRAKE FRONT	Bajaj spare parts
DY161213	CABLE PEDAL BRAKE-PANEL FRONT	Bajaj spare parts
DY161215	CABLE ACCELERATOR	Bajaj spare parts
DY161218	CABLE PEDAL-CYLINDER MASTER	Bajaj spare parts
DY171035	PAD ASSEMBLY TANK LH	Bajaj spare parts
DY171036	PAD ASSEMBLY TANK RH	Bajaj spare parts
DY171037	TAPE TANK	Bajaj spare parts
DY171602	PIPE FUEL	Bajaj spare parts
DY171603	PIPE FUEL	Bajaj spare parts
DY171604	PIPE FUEL	Bajaj spare parts
DY171605	PIPE FUEL	Bajaj spare parts
DY171802	PLATE PRESSURE	Bajaj spare parts
DY181200	CASE ASSY CHAIN UPPER COMP	Bajaj spare parts
DY181214	FLAP SPEEDOMETER	Bajaj spare parts
DY181219	COVER LINK CBS	Bajaj spare parts
DY181221	FLAP SPEEDOMETER	Bajaj spare parts
DY181226	BELLY PAN	Bajaj spare parts
DY181233	BRACKET LAMP HEAD UPPER	Bajaj spare parts
DY181234	BRACKET LAMP HEAD LOWER	Bajaj spare parts
DY181251	BRACKET ASSEMBLY	Bajaj spare parts
DY181408	FLAP FENDER FRONT LOWER	Bajaj spare parts
DY181412	FENDER FRONT	Bajaj spare parts
DY181420	BRACE ASSEMBLY FENDER	Bajaj spare parts
DY191003	SEAT ASSEMBLY	Bajaj spare parts
DY191005	SEAT ASSEMBLY	Bajaj spare parts
DY191014	SEAT ASSEMBLY	Bajaj spare parts
DY231203	GUARD LEG LH	Bajaj spare parts
DY231204	GUARD SAREE	Bajaj spare parts
DY231205	GUARD LEG RH	Bajaj spare parts
DY231212	TRIM GUARD LEG	Bajaj spare parts
DY231215	COLLAR	Bajaj spare parts
DY231404	HOLDER LAMP TAIL	Bajaj spare parts
DY231406	BRACKET INDICATOR	Bajaj spare parts
DY231408	TRIM FRAME GRIP LH	Bajaj spare parts

DY231409	TRIM FRAME GRIP RH	Bajaj spare parts
DY232600	SET LOCK	Bajaj spare parts
DY232800	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
DY233002	DECAL COVER SIDE RH BLACK RED	Bajaj spare parts
DY233007	DECAL COVER SIDE LH BLACK BLUE	Bajaj spare parts
DY233008	DECAL COVER SIDE RH BLACK BLUE	Bajaj spare parts
DY233073	DECAL COVER SIDE LH E BLACK BLUE	Bajaj spare parts
DY233074	DECAL COVER SIDE RH E BLACK BLUE	Bajaj spare parts
DY233075	DECAL COVER SIDE LH FL BR RED	Bajaj spare parts
DY233076	DECAL COVER SIDE RH FL BR RED	Bajaj spare parts
DY233077	DECAL COVER SIDE LH E BLACK RED	Bajaj spare parts
DY233078	DECAL COVER SIDE RH E BLACK RED	Bajaj spare parts
DY233079	DECAL COVER SIDE RH MATTE GREEN	Bajaj spare parts
DY233080	DECAL COVER SIDE LH MATTE GREEN	Bajaj spare parts
DY233085	DECAL COVER SIDE E BLK S GREY LH	Bajaj spare parts
DY233086	DECAL COVER SIDE E BLK S GREY RH	Bajaj spare parts
DY233095	DECAL COVER SIDE E BLACK BLUE LH	Bajaj spare parts
DY233096	DECAL COVER SIDE E BLACK BLUE LH	Bajaj spare parts
DY233107	DECAL COVER SIDE E BLACK RED LH	Bajaj spare parts
DY233108	DECAL COVER SIDE E BLACK RED RH	Bajaj spare parts
DY233113	DECAL COVER SIDE E BLK GREEN LH	Bajaj spare parts
DY233114	DECAL COVER SIDE E BLK GREEN RH	Bajaj spare parts
DY351004	ASSLY STATOR B105A	Bajaj spare parts
DY351201	COIL HT WITH CABLE B105A	Bajaj spare parts
DY351204	CDI	Bajaj spare parts
DY351206	COIL ASSEMBLY IGNITION LH	Bajaj spare parts
DY351400	ECU EMS ASSEMBLY	Bajaj spare parts
DY351405	ECU EMS ASSEMBLY	Bajaj spare parts
DY351409	ECU EMS ASSEMBLY	Bajaj spare parts
DY351413	ECU EMS ASSEMBLY	Bajaj spare parts
DY351417	ECU EMS ASSEMBLY	Bajaj spare parts
DY351424	ECU EMS ASSEMBLY	Bajaj spare parts
DY351445	ECU EMS ASSEMBLY	Bajaj spare parts
DY351800	SENSOR TEMPERATURE-PRESSURE	Bajaj spare parts
DY401001	LAMP ASSY TAIL	Bajaj spare parts
DY401002	LAMP HEAD	Bajaj spare parts
DY401003	LAMP DRL	Bajaj spare parts
DY401004	LAMP TAIL	Bajaj spare parts
DY401400	SPRING RE BRK SWITCH	Bajaj spare parts
DY401801	PAD BATTERY	Bajaj spare parts
DY401805	CASE BATTERY	Bajaj spare parts
DY402200	HARNESS WIRING	Bajaj spare parts
DY402202	CABLE EARTH	Bajaj spare parts
DY402204	HARNESS WIRING	Bajaj spare parts
DY402211	HARNESS WIRING	Bajaj spare parts

DY402213	BOOT	Bajaj spare parts
DY402214	HARNESS WIRING	Bajaj spare parts
DY402216	HARNESS WIRING	Bajaj spare parts
DY402219	HARNESS WIRING	Bajaj spare parts
DY402222	HARNESS WIRING	Bajaj spare parts
DY402225	HARNESS WIRING	Bajaj spare parts
DY402229	HARNESS WIRING	Bajaj spare parts
DY402400	SPEEDOMETER ASSLY	Bajaj spare parts
DY402401	SPEEDOMETER	Bajaj spare parts
DY402402	SPEEDOMETER	Bajaj spare parts
DY402600	GAUGE FUEL	Bajaj spare parts
DY403400	BRACKET ASSEMBLY SOCKET CHARGER	Bajaj spare parts
DY403402	WASHER	Bajaj spare parts
DY501020	ENGINE ASSEMBLY	Bajaj spare parts
DY501025	ENGINE ASSEMBLY	Bajaj spare parts
DY511023	HEAD CYLINDER	Bajaj spare parts
DY511200	VALVE INTAKE B105A	Bajaj spare parts
DY511201	VALVE EXHAUST B105A	Bajaj spare parts
DY511202	RETAINER VALVE B105A	Bajaj spare parts
DY511204	ASSLY CAMSHAFT B105A	Bajaj spare parts
DY511208	CHAIN	Bajaj spare parts
DY521200	ASSLY PISTON B105A	Bajaj spare parts
DY531008	CRANKSHAFT ASSEMBLY	Bajaj spare parts
DY541202	ASSEMBLY COVER LH RR	Bajaj spare parts
DY541204	COVER ASSEMBLY REAR LH	Bajaj spare parts
DY541213	SHAFT ASSEMBLY CLUTCH	Bajaj spare parts
DY541214	SPRING TORSION	Bajaj spare parts
DY541215	BRACKET CABLE CLUTCH	Bajaj spare parts
DY551400	CLUTCH ASSLY	Bajaj spare parts
DY551406	CLUTCH ASSEMBLY	Bajaj spare parts
DY561400	LEVER GEAR SHIFT ASSEMBLY	Bajaj spare parts
DY581002	COVER AIR FILTER B105A	Bajaj spare parts
DY581003	TUBE CONNECTING B105A	Bajaj spare parts
DY581005	SPACER BATTERY 3A	Bajaj spare parts
DY581009	TUBE BREATHER B105A	Bajaj spare parts
DY581010	TUBE DRAIN B105A	Bajaj spare parts
DY581016	FILTER ASSEMBLY AIR	Bajaj spare parts
DY581020	FILTER ASSEMBLY AIR	Bajaj spare parts
DY581021	TUBE CONNECTING	Bajaj spare parts
DY581025	FILTER ASSEMBLY AIR	Bajaj spare parts
DY581027	FILTER ASSEMBLY AIR	Bajaj spare parts
DY581046	FILTER ASSEMBLY AIR	Bajaj spare parts
DY581049	PIPE BREATHER	Bajaj spare parts
DY581051	SPACER BATTERY	Bajaj spare parts
DY581056	FILTER ASSEMBLY AIR	Bajaj spare parts



DY581058	PIPE BREATHER	Bajaj spare parts
DY581062	FILTER ASSEMBLY AIR	Bajaj spare parts
DY581065	FILTER ASSEMBLY AIR	Bajaj spare parts
DY581200	ASSEMBLY CARBURETTOR	Bajaj spare parts
DY581212	CARBURETTOR	Bajaj spare parts
DY581215	CARBURETTOR	Bajaj spare parts
DY581236	CARBURETTOR	Bajaj spare parts
DY581410	PIPE INTAKE	Bajaj spare parts
DY581412	CLAMP	Bajaj spare parts
DY581415	PIPE INTAKE	Bajaj spare parts
DY582200	UNIT SAI	Bajaj spare parts
DY582401	HOSE CONNECTOR B105A SAI	Bajaj spare parts
DY582402	HOSE INTAKE B105A SAI	Bajaj spare parts
DY582403	HOSE MANIFOLD B105A SAI	Bajaj spare parts
DY591020	ASSLY SILENCER	Bajaj spare parts
DY591027	ASSEMBLY SILENCER	Bajaj spare parts
DY591072	SHIELD CATALYST	Bajaj spare parts
DY591073	SHIELD MUFFLER	Bajaj spare parts
DY591076	ASSEMBLY SILENCER	Bajaj spare parts
DY591077	SILENCER ASSEMBLY	Bajaj spare parts
DY611202	MOTOR STEPPER	Bajaj spare parts
DY621202	LEVER ASSEMBLY KICK	Bajaj spare parts
DZ101001	COVER CHAIN ENGINE	Bajaj spare parts
DZ101031	COVER SILENCER RR	Bajaj spare parts
DZ101034	TUBE RUBBER	Bajaj spare parts
DZ101044	SHIELD CAT COVER	Bajaj spare parts
DZ101047	CLUTCH COVER/GRAPHIC	Bajaj spare parts
DZ101051	SILENCER ASSLY WI	Bajaj spare parts
DZ101075	CAMSHAFT ASSEMBLY	Bajaj spare parts
DZ101096	DECAL LABEL-CLUTCH COVER	Bajaj spare parts
DZ111002	CDI INTELLIGENT PLATINA	Bajaj spare parts
DZ111003	TPS SENSOR	Bajaj spare parts
DZ111012	H T COIL WITH CAP	Bajaj spare parts
DZ121003	DUCT AIR FILTER TO TO CAR	Bajaj spare parts
DZ121006	CARBURETTOR PLATINA	Bajaj spare parts
DZ121011	VALVE THROTTLE/PISTON VALVE	Bajaj spare parts
DZ121015	KIT SCREW AIR CONTROL PL	Bajaj spare parts
DZ121018	KIT HOLDER JET PLATINA	Bajaj spare parts
DZ121024	REGULATOR LPG	Bajaj spare parts
DZ121041	TUBE BREATHER II	Bajaj spare parts
DZ121047	TUBE BREATHER CARB.	Bajaj spare parts
DZ121048	TUBE OVERFLOW CARB.	Bajaj spare parts
DZ141040	COCK FUEL ASSLY FUEL	Bajaj spare parts
DZ141075	GASKET 4 HOLE WITH F	Bajaj spare parts
DZ141076	CAP FUEL TANK	Bajaj spare parts

DZ151002	SLEEVE	Bajaj spare parts
DZ151003	COLLAR	Bajaj spare parts
DZ151011	COUPLING	Bajaj spare parts
DZ151012	AXLE	Bajaj spare parts
DZ151014	AXLE PLATINA	Bajaj spare parts
DZ151025	PANEL ASSEMBLY COMPLETE	Bajaj spare parts
DZ151027	PANEL FRONT BRAKE	Bajaj spare parts
DZ151030	PANEL FRONT BRAKE	Bajaj spare parts
DZ151032	COLLAR ASSLY	Bajaj spare parts
DZ151037	SPACER	Bajaj spare parts
DZ151044	PANEL ASSLY BRA	Bajaj spare parts
DZ151045	PANEL REAR BRAKE DIA	Bajaj spare parts
DZ161041	COVER SIDE LEFT	Bajaj spare parts
DZ161042	COVER SIDE RIGHT	Bajaj spare parts
DZ161055	LABEL- INSTRUCTION	Bajaj spare parts
DZ161141	CAP FOR PIPE SEAT	Bajaj spare parts
DZ161265	BRACKET NUMBER PLATE MTG	Bajaj spare parts
DZ171007	SHAFT ARM SWING	Bajaj spare parts
DZ171009	DAMPER SWING ARM	Bajaj spare parts
DZ171014	ARM SWING	Bajaj spare parts
DZ171016	SHOCK ABSORBER REAR	Bajaj spare parts
DZ181001	FLAP COWLING	Bajaj spare parts
DZ181002	BRACKET SIGNALFR	Bajaj spare parts
DZ181003	BRACKET COWLING	Bajaj spare parts
DZ181004	LOCK SET 3 IN 1 PLATINA	Bajaj spare parts
DZ181007	HOLDER FU ASY ST CUM	Bajaj spare parts
DZ181012	BRCKT K SIDE	Bajaj spare parts
DZ181057	LOCK KEY SET ASSY	Bajaj spare parts
DZ181063	BRACKET - SIGNAL - FRONT	Bajaj spare parts
DZ191001	ROD BRAKE	Bajaj spare parts
DZ191004	LEVER BRAKE TUBLAR	Bajaj spare parts
DZ191005	INSTRUMENT CLUSTER	Bajaj spare parts
DZ191008	COVER METER UPPER	Bajaj spare parts
DZ191009	MACHINE SPEEDOMETER	Bajaj spare parts
DZ191010	GAUGE FUEL	Bajaj spare parts
DZ191013	CABLE BRAKE INER	Bajaj spare parts
DZ191014	CABLE SPEEDO PLATINA	Bajaj spare parts
DZ191016	CABLE ACCELERATER	Bajaj spare parts
DZ191017	CABLE STARTER PLATIN	Bajaj spare parts
DZ191019	CABLE INNER SPEEDO	Bajaj spare parts
DZ191024	MACHINE SPEEDOMETER	Bajaj spare parts
DZ191035	CABLE THROTTLE	Bajaj spare parts
DZ201001	HARNESS WIRING PLATINA	Bajaj spare parts
DZ201002	TANK UNIT PLATINA	Bajaj spare parts
DZ201005	BLINKER FR LH PLATINA	Bajaj spare parts

DZ201006	BLINKER FR RH PLATINA	Bajaj spare parts
DZ201007	BLINKER RR LH PLATINA	Bajaj spare parts
DZ201008	BLINKER RR RH PLATINA	Bajaj spare parts
DZ201011	BLINKER FR LH PLATINA	Bajaj spare parts
DZ201012	BLINKER FR RH PLATINA	Bajaj spare parts
DZ201015	COLLAR ASSY	Bajaj spare parts
DZ201016	LIGHT ASSLY TAIL	Bajaj spare parts
DZ201019	TANK UNIT OCTAGONAL	Bajaj spare parts
DZ201038	DC HORN	Bajaj spare parts
DZ201039	HARNESS WIRING PL 100	Bajaj spare parts
DZ201044	SWITCH CONTROL RH	Bajaj spare parts
DZ221003	GUARD - LEG	Bajaj spare parts
DZ221011	GUARD - LEG	Bajaj spare parts
DZ73033E	SEAT COWL ELE BLUE PLATINA	Bajaj spare parts
DZ73033F	SEAT COWL FL RED PLATINA	Bajaj spare parts
DZ73042V	FENDER FR CW RED	Bajaj spare parts
DZ73043E	FENDER FR ELE BLUE PLATINA	Bajaj spare parts
DZ73133W	SEAT COWL BLACK PLATINA	Bajaj spare parts
DZ73134G	SEAT COWL BL MAROON PLATINA	Bajaj spare parts
DZ74012V	FAIRING RED PLATINA	Bajaj spare parts
DZ74013E	FAIRING ELE BLUE PLATINA	Bajaj spare parts
DZ74013F	FAIRING FL RED PLATINA	Bajaj spare parts
DZ74013W	FAIRING BLK/CHROM PLATINA	Bajaj spare parts
DZ74014G	FAIRING BLK DAC MARO	Bajaj spare parts
DZ74032V	FAIRING CW RED PLATINA	Bajaj spare parts
DZ74033W	FAIRING BLACK PLATINA	Bajaj spare parts
DZ74034G	FAIRING BL MAROON PLATINA	Bajaj spare parts
EC131821	CONNECTOR 2 WAY HEX	Bajaj spare parts
EC131835	CLIP HOSE	Bajaj spare parts
EC202206	MOTOR WATER TANK	Bajaj spare parts
EC401030	HEAD LAMP BULB 60/55W (H4)	Bajaj spare parts
EC541004	ADAPTER- OIL FILTER	Bajaj spare parts
EC561023	SPRING GEAR SWITCH	Bajaj spare parts
EC561247	SPRING REVERSE LOCK	Bajaj spare parts
EE521220	PIN PISTON	Bajaj spare parts
EE531028	BOLT CONNECTING ROD	Bajaj spare parts
EE531030	BEARING BIG END	Bajaj spare parts
FA101334	GEAR OIL PUMP DRIVE	Bajaj spare parts
FD101078	SCREW PAN CROSS PRECOATE	Bajaj spare parts
FD181012	NUT CAP SPECIAL	Bajaj spare parts
FD181019	WASHER PLAIN	Bajaj spare parts
FD181030	HOLDER HANDLE UPPER	Bajaj spare parts
FD181031	HOLDER ASSY HANDLE LOWE	Bajaj spare parts
FD211006	GROMMET - SEAT	Bajaj spare parts
FD221019	BOLT SPECIAL	Bajaj spare parts

GF101086	BOLT SPECIAL HEAD CO	Bajaj spare parts
GF101087	RUBBER MOUNTING	Bajaj spare parts
GF101127	WASHER SPECIAL HEAD COVER MOUNTING	Bajaj spare parts
GF101139	GROMMET	Bajaj spare parts
GF101169	VALVE KIT	Bajaj spare parts
GF111112	GROMMET	Bajaj spare parts
GF121014	ELEMENT AIR FILTER	Bajaj spare parts
GF121041	PUMP FUEL ELECTRIC	Bajaj spare parts
GF121045	FLOAT KIT CARBURATTO	Bajaj spare parts
GF121053	SOLENOID CHOKE ASSY	Bajaj spare parts
GF141020	HOLDER FILTER FUEL	Bajaj spare parts
GF141027	FILTER FUEL	Bajaj spare parts
GF151019	GEAR SPEEDOMTR	Bajaj spare parts
GF161131	FOAM STRIP	Bajaj spare parts
GF161143	SPRING PILLION FOOTR	Bajaj spare parts
GF161156	BOLT(STEP) - M6 X 1 - OLIVE	Bajaj spare parts
GF161168	PAD FOAM FOR ELECT UNITS	Bajaj spare parts
GF201053	FUSE 10 AMP	Bajaj spare parts
GH201012	LAMP 12V 10W AMBER	Bajaj spare parts
GL113002	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
GL113013	STEP PILLION LH	Bajaj spare parts
GL113027	SPRING FOOTREST LADIES	Bajaj spare parts
GL113032	RUBBER PILLION FOOT PEG LH	Bajaj spare parts
GL113033	RUBBER PILLION FOOT PEG RH	Bajaj spare parts
GL113035	LOCK PLATE LH	Bajaj spare parts
GL113036	LOCK PLATE RH	Bajaj spare parts
GL113044	FOOTREST SIDE	Bajaj spare parts
GL113046	DAMPER STEP	Bajaj spare parts
GL113052	PIN	Bajaj spare parts
GL113053	DAMPER	Bajaj spare parts
GL113069	STEP LH	Bajaj spare parts
GL113071	STEP RH	Bajaj spare parts
GL113213	COVER SIDE STAND SPRING	Bajaj spare parts
GL113216	DAMPER	Bajaj spare parts
GL113219	PLATE STAND SIDE	Bajaj spare parts
GL113809	BRACKET CABLE HOLDING	Bajaj spare parts
GL113811	SLEEVE CC UNIT MTG	Bajaj spare parts
GL113812	GROMMET CC UNIT MTG	Bajaj spare parts
GL113817	HOOK CABLE OFFSET STEERING COLUMN	Bajaj spare parts
GL113835	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
GL113836	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
GL113837	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
GL113841	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
GL113845	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
GL113851	PAD I BATTERY	Bajaj spare parts

GL113853	PAD II BATTERY	Bajaj spare parts
GL113854	PAD III BATTERY	Bajaj spare parts
GL113856	BRACKET CHARGER	Bajaj spare parts
GL113862	CAP	Bajaj spare parts
GL113866	BRACKET UNIT ANTENNA	Bajaj spare parts
GL113868	BRACKET HARNESS FRONT	Bajaj spare parts
GL113879	PAD	Bajaj spare parts
GL113881	DAMPER	Bajaj spare parts
GL113882	DAMPER	Bajaj spare parts
GL113883	BRACKET BATTERY UPPER FRONT	Bajaj spare parts
GL113884	BRACKET BATTERY UPPER REAR	Bajaj spare parts
GL113885	BRACKET ASSEMBLY MCU	Bajaj spare parts
GL113898	HOOK ASSEMBLY	Bajaj spare parts
GL113910	BRACKET SCU	Bajaj spare parts
GL113912	SUPPORT BRACKET LH	Bajaj spare parts
GL113913	SUPPORT BRACKET RH	Bajaj spare parts
GL121069	RACE BEARING UPPER	Bajaj spare parts
GL121071	CAP STEERING	Bajaj spare parts
GL121075	NUT LOCK	Bajaj spare parts
GL121107	NUT STEERING	Bajaj spare parts
GL121115	BEARING RACE LOWER	Bajaj spare parts
GL121118	SEAL DUST	Bajaj spare parts
GL121121	BEARING CONE LOWER O-SUSP	Bajaj spare parts
GL121129	ASSLY CAGE BEARING LOWER	Bajaj spare parts
GL121138	GUIDE BRAKE HOSE	Bajaj spare parts
GL122058	BRACKET CABLE BRAKE	Bajaj spare parts
GL131064	CAP WHEEL-FRONT	Bajaj spare parts
GL131067	SEAL OIL-CASE GEAR METER	Bajaj spare parts
GL131218	SPACER CAM BRAKE LEVER	Bajaj spare parts
GL131236	CAP WHEEL REAR	Bajaj spare parts
GL131603	SPRING	Bajaj spare parts
GL131804	DISC BRAKE DIA 200	Bajaj spare parts
GL131807	HOSE BRAKE FRONT	Bajaj spare parts
GL131813	CALIPER ASSLY FRONT-SINGLE POT	Bajaj spare parts
GL131816	ASSLY MASTER CYLINDER	Bajaj spare parts
GL131829	SET SHOE BRAKE	Bajaj spare parts
GL151001	ADAPTER LH	Bajaj spare parts
GL151009	ADAPTER RH	Bajaj spare parts
GL151028	SCREW LEVER PIVOT	Bajaj spare parts
GL151044	HANDLEBAR ASSLY-ABS	Bajaj spare parts
GL151046	GRIP ASSEMBLY-LH	Bajaj spare parts
GL151051	DECAL GRIP	Bajaj spare parts
GL161042	SPRING COMPRESSION	Bajaj spare parts
GL161043	PIN PARKING BRAKE	Bajaj spare parts
GL161044	BRACKET SPRING LEVER PARKING	Bajaj spare parts

GL161053	ASSEMBLY LEVER-HOLDER RH	Bajaj spare parts
GL161054	LEVER HOLDER RH	Bajaj spare parts
GL161055	LEVER RH	Bajaj spare parts
GL161065	BRACKET STOPPER PARKING BRAKE	Bajaj spare parts
GL161076	SPRING BRAKE PEDAL	Bajaj spare parts
GL161091	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
GL161092	HOLDER LEVER LH	Bajaj spare parts
GL161220	CABLE BRAKE	Bajaj spare parts
GL161224	CABLE LOCK SEAT	Bajaj spare parts
GL171031	VALVE ONE WAY	Bajaj spare parts
GL171036	CONNECTOR FOR BREATHER AND VAPOR TUBE	Bajaj spare parts
GL171072	ROUND CANISTER	Bajaj spare parts
GL181043	CLIP SNAP	Bajaj spare parts
GL181057	SEAL GLOVE BOX LID	Bajaj spare parts
GL181060	GROMMET PLUG	Bajaj spare parts
GL181076	TRIM ASSLY BOX GLOVE LH TAN	Bajaj spare parts
GL181079	ASSLY COLLAR TRIM GLOVE BOX RH	Bajaj spare parts
GL181093	BEADING LH	Bajaj spare parts
GL181094	BEADING RH	Bajaj spare parts
GL181099	WASHER NY NO PLATE MTG 1	Bajaj spare parts
GL181102	COLLAR	Bajaj spare parts
GL181119	GRILL ASSLY SHIELD UPPER	Bajaj spare parts
GL181128	GRILL ASSEMBLY PANEL REAR	Bajaj spare parts
GL181134	DAMPER RH	Bajaj spare parts
GL181135	COLLAR	Bajaj spare parts
GL181142	TRIM ASSEMBLY BOX GLOVE LH BLACK	Bajaj spare parts
GL181145	TRIM ASSEMBLY BOX GLOVE RH BLACK	Bajaj spare parts
GL181155	TAPE TRIM SHIELD UPPER	Bajaj spare parts
GL181253	PIECE GLOVE BOX ADD ON II	Bajaj spare parts
GL181263	BEAD FRONT SHIELD	Bajaj spare parts
GL181268	GLOVE BOX FOAM LH	Bajaj spare parts
GL181269	GLOVE BOX FOAM RH	Bajaj spare parts
GL181270	DAMPER LID COVER	Bajaj spare parts
GL181288	PAD GLOVE BOX	Bajaj spare parts
GL181292	TAPE-DUAL LOCK 33 X 17	Bajaj spare parts
GL181293	HOLDER FUSE-SPARE	Bajaj spare parts
GL181310	COVER BRACKET BATTERY LH	Bajaj spare parts
GL181311	COVER BRACKET BATTERY RH	Bajaj spare parts
GL181323	COVER BATTERY LH	Bajaj spare parts
GL181324	COVER BATTERY RH	Bajaj spare parts
GL181327	SHROUD FAN UPPER	Bajaj spare parts
GL181331	COVER SOLENOID BOX GLOVE	Bajaj spare parts
GL181338	COVER BATTERY REAR	Bajaj spare parts
GL181339	COVER BATTERY LOWER	Bajaj spare parts
GL181381	BRACKET COVER TERMINAL MCU	Bajaj spare parts

GL181432	SLEEVE	Bajaj spare parts
GL181441	FENDER HUGGER ASSEMBLY	Bajaj spare parts
GL181469	COLLAR	Bajaj spare parts
GL181626	FLOORBOARD	Bajaj spare parts
GL181630	FOAM COVER BATTERY	Bajaj spare parts
GL181632	COVER BATTERY	Bajaj spare parts
GL181633	MAT	Bajaj spare parts
GL181638	COVER FLOORBOARD LOWER	Bajaj spare parts
GL181642	FLAP FLOORBOARD	Bajaj spare parts
GL181803	BOX HELMET	Bajaj spare parts
GL181817	TAPE DUAL LOCK 10X10	Bajaj spare parts
GL181826	CAP	Bajaj spare parts
GL181835	TRIM BOX HELMET	Bajaj spare parts
GL181931	BRACKET HARNESS	Bajaj spare parts
GL191009	PIN -DIA. 8XL83.8XCL8.8XBLKXSTEP	Bajaj spare parts
GL191038	ROD SPRING SUPPORT	Bajaj spare parts
GL191052	SPRING	Bajaj spare parts
GL191056	DAMPER HINGE	Bajaj spare parts
GL191065	DAMPER	Bajaj spare parts
GL191079	DAMPER BATTERY	Bajaj spare parts
GL191128	DAMPER	Bajaj spare parts
GL191130	DAMPER	Bajaj spare parts
GL231010	BAG CABLE CHARGER	Bajaj spare parts
GL231013	KEY ALLEN 8	Bajaj spare parts
GL231410	TAPE DUAL LOCK	Bajaj spare parts
GL231610	MIRROR ASSEMBLY LH	Bajaj spare parts
GL231611	MIRROR ASSEMBLY RH	Bajaj spare parts
GL232804	TAPE	Bajaj spare parts
GL233000	EMBLEM	Bajaj spare parts
GL233007	DECAL FRONT	Bajaj spare parts
GL233008	DECAL REAR	Bajaj spare parts
GL233012	DECAL LID INDIGO METALLIC	Bajaj spare parts
GL233013	DECAL LID PROCELAIN WHITE	Bajaj spare parts
GL233015	DECAL LID HAZELNUT	Bajaj spare parts
GL233016	DECAL LID COARSE GREY	Bajaj spare parts
GL233030	LABEL INSTRUCTION	Bajaj spare parts
GL233054	DECAL MIRACLE GR LH	Bajaj spare parts
GL233055	DECAL MIRACLE GR RH	Bajaj spare parts
GL233057	DECAL DEX GR LH	Bajaj spare parts
GL233058	DECAL DEX GR RH	Bajaj spare parts
GL233059	DECAL YULU WHITE LH	Bajaj spare parts
GL233060	DECAL YULU WHITE RH	Bajaj spare parts
GL233061	DECAL YULU BLUE LH	Bajaj spare parts
GL233062	DECAL YULU BLUE RH	Bajaj spare parts
GL233067	DECAL YULU	Bajaj spare parts

GL233068	DECAL YULU	Bajaj spare parts
GL234000	LABEL INSTRUCTION	Bajaj spare parts
GL301020	ASSEMBLY MCU	Bajaj spare parts
GL301025	GROMMET	Bajaj spare parts
GL301039	ASSEMBLY MCU	Bajaj spare parts
GL301203	MOTOR DRIVE	Bajaj spare parts
GL301235	SEAL OIL	Bajaj spare parts
GL301248	SEAL	Bajaj spare parts
GL301249	SEAL	Bajaj spare parts
GL401019	REFLECTOR REFLEX	Bajaj spare parts
GL401030	LAMP HEAD	Bajaj spare parts
GL401033	CHARGER BATTERY	Bajaj spare parts
GL401035	LAMP BOX HELMET	Bajaj spare parts
GL401042	MOULD FOR H105 HELMET BOX LAMP HOUSING	Bajaj spare parts
GL401043	MOULD FOR H105 HELMET BOX LAMP LENS	Bajaj spare parts
GL401046	INDICATOR FRONT LH SILVER	Bajaj spare parts
GL401047	INDICATOR FRONT RH SILVER	Bajaj spare parts
GL401427	LOCK SEAT	Bajaj spare parts
GL401428	LOCK BOX GLOVE	Bajaj spare parts
GL401432	SWITCH BRAKE RH	Bajaj spare parts
GL401433	MAGNET SWITCH AUTO CANCEL	Bajaj spare parts
GL401440	SWITCH LOCK STEERING	Bajaj spare parts
GL401443	SWITCH ASSEMBLY STAND CENTER	Bajaj spare parts
GL401803	CONVERTER DC-DC	Bajaj spare parts
GL401805	BOX CONNECTIVITY	Bajaj spare parts
GL401811	PLUG	Bajaj spare parts
GL401812	PAD	Bajaj spare parts
GL401814	TAPE	Bajaj spare parts
GL401857	COVER FAN	Bajaj spare parts
GL401869	BATTERY ASSEMBLY	Bajaj spare parts
GL401880	BATTERY ASSEMBLY	Bajaj spare parts
GL401889	CHARGER BATTERY	Bajaj spare parts
GL402210	FUSE BOX BLADE TYPE SPARE FUSE	Bajaj spare parts
GL402239	CLIP	Bajaj spare parts
GL402242	PAD SUPPORT-CABLE TIE	Bajaj spare parts
GL402245	HARNESS WIRING	Bajaj spare parts
GL402247	CABLE MOTOR -BOX JUNCTION	Bajaj spare parts
GL402256	CABLE CHARGER AC	Bajaj spare parts
GL402257	CABLE MAINS AC	Bajaj spare parts
GL402293	CABLE BATTERY	Bajaj spare parts
GL402316	CABLE CHARGER AC	Bajaj spare parts
GL402333	HARNESS WIRING	Bajaj spare parts
GL403001	CONTROLLER MOTOR	Bajaj spare parts
GL403002	RELAY FAN	Bajaj spare parts
GL403220	UNIT TELEMATIC	Bajaj spare parts



GL403265	ASSEMBLY VCU	Bajaj spare parts
GL403401	BOX SOCKET MAINS	Bajaj spare parts
GL403606	UNIT ASSEMBLY ANTENNA	Bajaj spare parts
GL403608	DAMPER UNIT ANTENNA	Bajaj spare parts
GL404021	HARNESS WIRING	Bajaj spare parts
GL404027	CABLE BATTERY	Bajaj spare parts
GL405133	BATTERY ASSEMBLY	Bajaj spare parts
GL405219	CONVERTER DC-DC	Bajaj spare parts
GL541117	BUSH SILENT	Bajaj spare parts
GL541287	SEAL OP SHAFT	Bajaj spare parts
GL541305	COVER MOTOR	Bajaj spare parts
GL551052	SHAFT OUTPUT	Bajaj spare parts
GL561004	WASHER PLAIN	Bajaj spare parts
GL561006	WASHER PLAIN(12.2X1X20)	Bajaj spare parts
GL561049	SPRING TORSION	Bajaj spare parts
GL581479	CLAMP 42	Bajaj spare parts
GL601443	FAN ASSEMBLY LOWER	Bajaj spare parts
GL621414	ONE WAY CLUTCH 10 ROL D103	Bajaj spare parts
HA201007	SOLENOID PETR	Bajaj spare parts
JA113011	BOLT FLANGE M8	Bajaj spare parts
JA113201	SHAFT STAND	Bajaj spare parts
JA113202	STAND SIDE	Bajaj spare parts
JA113402	ENGINE MTG BKT FRONT	Bajaj spare parts
JA113403	BOLT FLANGE M10X110	Bajaj spare parts
JA113404	BOLT FLANGE M8X75	Bajaj spare parts
JA113802	SLEEVE A/F MTG	Bajaj spare parts
JA121003	SHAFT SWING ARM	Bajaj spare parts
JA121005	BOLT STEP TRQ ROD	Bajaj spare parts
JA131202	COLLER	Bajaj spare parts
JA131205	PANEL REAR BRAKE	Bajaj spare parts
JA131206	SPROCKET HUB (42T)	Bajaj spare parts
JA131601	PANEL ASSY REAR	Bajaj spare parts
JA131602	LEVER BRAKE	Bajaj spare parts
JA131603	DRUM FRONT	Bajaj spare parts
JA131604	PANEL ASSY BR COMP F	Bajaj spare parts
JA131605	PANEL FRONT BRAKE	Bajaj spare parts
JA131606	BUSHING	Bajaj spare parts
JA131607	LEVER BRAKE CAM	Bajaj spare parts
JA151013	FORK PIPE SPINNING	Bajaj spare parts
JA161003	PAD BRAKE LEVER	Bajaj spare parts
JA171801	TUBE FUEL	Bajaj spare parts
JA231201	HOOK LEG GUARD	Bajaj spare parts
JA351012	STATOR ASSYDC SYSTE	Bajaj spare parts
JA351015	ROTOR ASSY .WITH CL	Bajaj spare parts
JA351200	CDI ASSEMBLY	Bajaj spare parts

JA351209	SPARK PLUG	Bajaj spare parts
JA351600	MOTOR STARTER	Bajaj spare parts
JA351602	RING O SPIGOT	Bajaj spare parts
JA351606	RING SEALING	Bajaj spare parts
JA351608	POSITIVE BRUSH HOLDE	Bajaj spare parts
JA351609	NEGATIVE BRUSH HOLDE	Bajaj spare parts
JA351610	POSITIVE TERMINAL	Bajaj spare parts
JA351619	TERMINAL ASSY VE	Bajaj spare parts
JA351624	SPRING BRUSH	Bajaj spare parts
JA351626	SEAL YOKE	Bajaj spare parts
JA351627	RING O SPIGOT	Bajaj spare parts
JA401800	CASE BATTERY 5 AH	Bajaj spare parts
JA401801	BATTERY BAND 5 AH	Bajaj spare parts
JA402202	CABLE BAT TO EARTH	Bajaj spare parts
JA511005	BOLT FLANGE M6X1X98	Bajaj spare parts
JA511006	GASKET HEAD CYLINDER	Bajaj spare parts
JA511008	BOLT HEAD MOUNTING	Bajaj spare parts
JA511011	HOSE CCASE BREATHER	Bajaj spare parts
JA511012	RING O HEAD COVER	Bajaj spare parts
JA511028	STUD M8X1.25X45L	Bajaj spare parts
JA511029	CLAMP BREATHER TUBE	Bajaj spare parts
JA511202	SPRING VALVE	Bajaj spare parts
JA511204	ARM ROCKER	Bajaj spare parts
JA511210	SHAFT ROCKER ARM	Bajaj spare parts
JA511211	SHAFT ROCKER ARM EX	Bajaj spare parts
JA511216	SPACER CAM SPROCKET	Bajaj spare parts
JA511217	SPROCKET CAMSHAFT 3	Bajaj spare parts
JA521015	DAMPER CYLINDER BLOC	Bajaj spare parts
JA521017	CHAIN TENSIONER BLAC	Bajaj spare parts
JA521207	PISTON RINGS SET	Bajaj spare parts
JA521210	PISTON ASSY	Bajaj spare parts
JA531000	CRANK SHAFT ASSY	Bajaj spare parts
JA531011	CAM CHAIN 92 LINKS	Bajaj spare parts
JA531012	SPRING	Bajaj spare parts
JA531015	PINC/S PLUNGER	Bajaj spare parts
JA541005	BUSH BENDIX	Bajaj spare parts
JA541010	STOPPER PLATE INPUT	Bajaj spare parts
JA541011	NEEDLE ROLLER BEARIN	Bajaj spare parts
JA541012	GUIDE KICK	Bajaj spare parts
JA541016	GASKET CASE PUMP OIL	Bajaj spare parts
JA541018	GEAR DRIVEN SHAFT OI	Bajaj spare parts
JA541019	MESH FILTER PUMP OIL	Bajaj spare parts
JA541020	RING OFILTER OIL PUM	Bajaj spare parts
JA541021	CAP STRAINER	Bajaj spare parts
JA541027	DAMPERCRANKSHAFT	Bajaj spare parts

JA541028	LOCK PLATE	Bajaj spare parts
JA541034	STOPPER GEAR STARTER	Bajaj spare parts
JA541036	PLUG OIL CONTROL	Bajaj spare parts
JA541044	BOLT FLANGE M6X1X40L	Bajaj spare parts
JA541048	STRAINER CAP WITH O-RING	Bajaj spare parts
JA541205	GASKET MAGNETO COVER	Bajaj spare parts
JA541211	CAP OIL FILLER	Bajaj spare parts
JA541212	GASKET CLUTCH COVER	Bajaj spare parts
JA541225	RING O CAP OIL FILLE	Bajaj spare parts
JA541233	CAP TDC FINDER	Bajaj spare parts
JA541235	BOLT FLANGE M6X1X85L	Bajaj spare parts
JA541236	PLAIN WASHER	Bajaj spare parts
JA541237	SPRING TORSION CL. COVER	Bajaj spare parts
JA551002	SPLINE WASHER	Bajaj spare parts
JA551004	WASHER THRUST 2ND DR	Bajaj spare parts
JA551007	BUSH 1ST DRIVEN	Bajaj spare parts
JA551008	WASHER THRUST 12.2X	Bajaj spare parts
JA551009	COLLAR SPROCKET DRIV	Bajaj spare parts
JA551206	GEAR 1ST DRIVEN	Bajaj spare parts
JA551405	CLUTCH HOLDER	Bajaj spare parts
JA551406	COLLAR CLUTCH	Bajaj spare parts
JA551410	SPRING CLUTCH DAM	Bajaj spare parts
JA551411	SPRING CLUTCH DAMPER	Bajaj spare parts
JA551414	WHEEL CLUTCH	Bajaj spare parts
JA551415	HUB CLUTCH	Bajaj spare parts
JA551416	WASHER BELVILLE	Bajaj spare parts
JA551417	PLATE FRICTION REDUC	Bajaj spare parts
JA551419	PLATE CLUTCH	Bajaj spare parts
JA551420	WASHER PLAIN	Bajaj spare parts
JA551421	PLATE JUDDER	Bajaj spare parts
JA551422	SPRING JUDDER	Bajaj spare parts
JA561002	CAM DRUM CHANGE	Bajaj spare parts
JA561207	INHIBITOR COMP GEAR	Bajaj spare parts
JA561208	SPRING INHIBITOR	Bajaj spare parts
JA561209	STEP WASHER	Bajaj spare parts
JA561211	BOLT FLANGE M6X1X22L	Bajaj spare parts
JA561400	LEVER COMP GEAR SHIF	Bajaj spare parts
JA561401	LEVER COMPLETE CHANG	Bajaj spare parts
JA581005	ELEMENT ASSEMBLY FILTER AIR	Bajaj spare parts
JA581006	ELEMENT AIR FILTER	Bajaj spare parts
JA581009	FLAME ARRESTOR	Bajaj spare parts
JA581011	RING O CARTRIDGE	Bajaj spare parts
JA581012	TUBE DRAIN	Bajaj spare parts
JA581013	CARTRIDGE COVER ASSL	Bajaj spare parts
JA581209	CARBURETTOR VM 16	Bajaj spare parts

JA581221	NEEDLE VALVE ASSEMBL	Bajaj spare parts
JA581222	NEEDLE JET	Bajaj spare parts
JA581223	MIXING CAP ASSLY	Bajaj spare parts
JA581226	JET NEEDLE	Bajaj spare parts
JA581228	SPRING	Bajaj spare parts
JA581229	PISTON VALVE ASSY	Bajaj spare parts
JA581231	JET HOLDER	Bajaj spare parts
JA581232	RING OFCB	Bajaj spare parts
JA581233	SCREW	Bajaj spare parts
JA581238	RING OTPS	Bajaj spare parts
JA581239	SOLENOID CHOKE ASSLY	Bajaj spare parts
JA581240	RING O SOLENOID FIXI	Bajaj spare parts
JA581242	SCREW AIR KIT	Bajaj spare parts
JA581243	IDLING SCREW KIT	Bajaj spare parts
JA581244	JET KIT	Bajaj spare parts
JA581268	FLOAT ASSEMBLY	Bajaj spare parts
JA581285	SPRING COMPR	Bajaj spare parts
JA581299	TUBE AIR VENT	Bajaj spare parts
JA581311	SCREW AIR KIT	Bajaj spare parts
JA581312	IDLING SCREW KIT	Bajaj spare parts
JA581313	JET KIT	Bajaj spare parts
JA581314	DRAIN SCREW	Bajaj spare parts
JA581406	BOLT FLANGE M6X1X25L	Bajaj spare parts
JA581407	CLAMP (39 MM)	Bajaj spare parts
JA621001	SHAFT KICK	Bajaj spare parts
JA621003	GEAR SPUR KICK START	Bajaj spare parts
JA621006	WASHER THRUSTR	Bajaj spare parts
JA621201	LEVER ASSLY. KICK	Bajaj spare parts
JA621206	BOLT SPECIAL M8*30	Bajaj spare parts
JA621402	WASHERTHK 0.4	Bajaj spare parts
JA621403	BODY STARTER ASSEMBL	Bajaj spare parts
JA621406	DRIVE ASSEMBLY	Bajaj spare parts
JA621411	BUSH SPRING STAR CLU	Bajaj spare parts
JA621414	BODY STARTER ASSEMBLY	Bajaj spare parts
JB111033	PLUG REAR PIPE	Bajaj spare parts
JB111043	FRAME ASSY COMPLETE	Bajaj spare parts
JB113005	PLAIN WASHER	Bajaj spare parts
JB113007	PLAIN WASHER	Bajaj spare parts
JB122003	CHAIN SLIDER	Bajaj spare parts
JB122007	ARM SWING	Bajaj spare parts
JB122009	DOMPED CAP NUT	Bajaj spare parts
JB122010	WASHER PLAIN	Bajaj spare parts
JB122011	PLAIN WASHER	Bajaj spare parts
JB122016	BOLT FLANGE M10	Bajaj spare parts
JB131008	RINGSPEED SENSOR	Bajaj spare parts

JB131017	AXLE FR EXCEED DTSI	Bajaj spare parts
JB131018	WASHER PLAIN	Bajaj spare parts
JB131022	SPACER ASSEMBLY	Bajaj spare parts
JB131201	WHEEL REAR1.6X17 SL	Bajaj spare parts
JB131222	RIM WHEEL 1.6X17110	Bajaj spare parts
JB131223	BRAKE CAM	Bajaj spare parts
JB131601	BRAKE PANEL FRONT	Bajaj spare parts
JB131605	LEVER BRAKE	Bajaj spare parts
JB141001	DRIVE CHAIN CONNE LI	Bajaj spare parts
JB151003	HOLDER K UPPER	Bajaj spare parts
JB151012	GROMMET FAIRING	Bajaj spare parts
JB151013	SLEEVE FEARING MOU	Bajaj spare parts
JB151020	HOOK SPEEDO CABLE	Bajaj spare parts
JB151025	TUBE INNER FORK	Bajaj spare parts
JB161001	LEVER ASSY LH (ES)	Bajaj spare parts
JB161002	PIN BRAKE ROD	Bajaj spare parts
JB161203	CABLE ACCELERATOR	Bajaj spare parts
JB181211	WIND SHIELD	Bajaj spare parts
JB181212	FLAP SPEEDOMETER	Bajaj spare parts
JB181218	CAP CHAIN CASE	Bajaj spare parts
JB181220	BOLT FLANGE M6X1PX62L	Bajaj spare parts
JB181221	BOLT FLANGE	Bajaj spare parts
JB181223	BEADING SPEEDO FLAP	Bajaj spare parts
JB181403	FLAP FRONT FENDER	Bajaj spare parts
JB181406	FENDER REAR REAR	Bajaj spare parts
JB181416	BRACE FENDER	Bajaj spare parts
JB181417	FRONT FENDER (EXPORT)	Bajaj spare parts
JB181421	BRACE FENDER DISC	Bajaj spare parts
JB231208	BOLT STEP	Bajaj spare parts
JB232600	LOCK SET 3 IN 1	Bajaj spare parts
JB232826	SUB ASSY FR NO.PLATE	Bajaj spare parts
JB351014	ROTOR ASSY	Bajaj spare parts
JB351017	ROTOR ASSEMBLY(KICK START	Bajaj spare parts
JB351022	STATOR ASSY DISCO M	Bajaj spare parts
JB351029	STATOR ASSEMBLY	Bajaj spare parts
JB351030	STATOR ASSLY	Bajaj spare parts
JB351034	ROTOR ASSEMBLY	Bajaj spare parts
JB351201	CDI ASSLY D100 UG	Bajaj spare parts
JB351800	SENSOR THROTTLE POSITION	Bajaj spare parts
JB401001	LAMP TAIL ASSY	Bajaj spare parts
JB401011	LAMP HEAD ASSEMBLY	Bajaj spare parts
JB401012	FOAM TAIL LAMP	Bajaj spare parts
JB401400	SWITCH CONTROL LH	Bajaj spare parts
JB401401	SWITCH CONTROL RH SS	Bajaj spare parts
JB401402	IGNITION SWITCH ASSL	Bajaj spare parts

JB401409	CLUTCH SWITCH6AMP	Bajaj spare parts
JB402000	REGULATOR DC ASSLY	Bajaj spare parts
JB402002	CAPACITOR + BKT	Bajaj spare parts
JB402202	GROMMET ETS	Bajaj spare parts
JB402401	VEHICLE SPEED SENSOR	Bajaj spare parts
JB501017	ENGINE ASSLY	Bajaj spare parts
JB511011	BOLT HEAD MOUNTING	Bajaj spare parts
JB511015	BOLT FLANGE M8X1.25	Bajaj spare parts
JB511018	SLEEVE SPARK PLUG	Bajaj spare parts
JB511019	GASKET CYL HEAD DIS 94	Bajaj spare parts
JB511039	HEAD CYLINDER	Bajaj spare parts
JB511206	CAMSHAFT COMP DISCO M 94	Bajaj spare parts
JB521200	PISTON ASSY	Bajaj spare parts
JB531005	CHAIN CAM 90L	Bajaj spare parts
JB531012	BIG END ROLLER BRG	Bajaj spare parts
JB531018	CRANK SHAFT ASSLY	Bajaj spare parts
JB531021	PLUNGER OIL CRANKSHAFT	Bajaj spare parts
JB531023	CRANKSHAFT ASSLY	Bajaj spare parts
JB541201	JET CLUTCH COVER DISCO M	Bajaj spare parts
JB541212	ASSLY COVER CLUTCH D100 UG	Bajaj spare parts
JB541218	COVER REAR ASSLY	Bajaj spare parts
JB541224	GASKET COVER MAGNETO	Bajaj spare parts
JB551000	SPROCKET DRIVE 14 T	Bajaj spare parts
JB551400	CLUTCH ASSLY COMPLETE	Bajaj spare parts
JB551404	CLUTCH PLATE ASSEMBLY	Bajaj spare parts
JB551406	HOLDER	Bajaj spare parts
JB551408	WHEEL CLUTCH	Bajaj spare parts
JB551410	ASSLY CLUTCH COMP MODIFIED	Bajaj spare parts
JB551411	HUB CLUTCH MODIFIED	Bajaj spare parts
JB561000	FORKSHIFT INPUT DISCO M	Bajaj spare parts
JB561001	FORKSHIFT OUTPUT	Bajaj spare parts
JB571000	PUMP OIL ASSLY	Bajaj spare parts
JB571004	GEAR OIL PUMP DRIVEN	Bajaj spare parts
JB571005	ASSLY OIL PUMP D100 UG	Bajaj spare parts
JB571006	GEAR OIL PUMP D100 UG	Bajaj spare parts
JB581003	DUCT AIR FILTER	Bajaj spare parts
JB581005	ELEMENT AIR FILTER	Bajaj spare parts
JB581011	CAP AIR FILTER	Bajaj spare parts
JB581013	CATRIDGE ASSEMBLY	Bajaj spare parts
JB581020	CONNECTING TUBE PTE	Bajaj spare parts
JB581021	AIR FILT DISCO M	Bajaj spare parts
JB581035	CARTRIDGE COVER PULSAR 135	Bajaj spare parts
JB581036	ASSLY AIR FILTER	Bajaj spare parts
JB581037	TUBE BREATHER	Bajaj spare parts
JB581041	COVER ASSLY FILTER AIR	Bajaj spare parts

JB581058	FILTER ASSEMBLY AIR	Bajaj spare parts
JB581200	CARBURETTOR ASSLY	Bajaj spare parts
JB581202	ACCELERATOR POSIN SE	Bajaj spare parts
JB581204	RING O TPS	Bajaj spare parts
JB581208	CARB ASSY PLATI UG	Bajaj spare parts
JB581229	VALVE COMP FLOAT (PIN)	Bajaj spare parts
JB581230	FLOAT COMP PTE16 XCD125 C	Bajaj spare parts
JB581237	ADJUSTER CABLE	Bajaj spare parts
JB581247	RING O SOLENOID	Bajaj spare parts
JB581248	SCREW TPS & SOLENOID	Bajaj spare parts
JB581255	AUTOCHOKE SOLENOID DISCOM	Bajaj spare parts
JB581256	ARM PIN FLOAT	Bajaj spare parts
JB581257	TUBE OVER FLOW	Bajaj spare parts
JB581258	TUBE AIR VENT	Bajaj spare parts
JB581259	CLIP	Bajaj spare parts
JB581260	DRAIN SCREW	Bajaj spare parts
JB581271	INSULATOR DISCO M	Bajaj spare parts
JB581272	SEAL O RING INSULATOR	Bajaj spare parts
JB581276	JET NEEDLE DISCO M	Bajaj spare parts
JB581278	CARB.ASLY PTE 16 DISCO M	Bajaj spare parts
JB581284	ASSLY CARBURETOR D100 UG	Bajaj spare parts
JB581289	CARBURETTOR	Bajaj spare parts
JB581291	CARBURETTOR	Bajaj spare parts
JB581411	INSULATOR MANIFOLD	Bajaj spare parts
JB582400	HOSE MANIFOLD SAI	Bajaj spare parts
JB591051	SILENCER ASY W/O SHIELD	Bajaj spare parts
JB591059	DAMPER SHIELD MUFFLER DISCO-M	Bajaj spare parts
JB591068	WASHER NYLON SHIELD SILENCER	Bajaj spare parts
JB591080	SHIELD MUFFLER	Bajaj spare parts
JB591098	SENSOR OXYGEN	Bajaj spare parts
JB621001	SHAFT ASSLY. KICK	Bajaj spare parts
JB621003	GEAR STARTER PINION ASSLY	Bajaj spare parts
JB71013Q	TANK FUEL KG2 SILVER	Bajaj spare parts
JB74013A	FAIRING LB BLUE XCD	Bajaj spare parts
JC101001	CRANKSHAFT ASSY COM	Bajaj spare parts
JC101029	CRANKCASE RH JC	Bajaj spare parts
JC101033	COVER LH RR JC	Bajaj spare parts
JC101034	TENSIONER ASSEMBLY	Bajaj spare parts
JC101035	CAM CHAIN 98 LINKS	Bajaj spare parts
JC101036	HEAD CYL WITH COVER	Bajaj spare parts
JC101037	CYL BLOCK ASSY Avenger	Bajaj spare parts
JC101038	GUIDE CHAIN KIT	Bajaj spare parts
JC101040	DECAL COVER CL	Bajaj spare parts
JC101045	CRANKCASE LH	Bajaj spare parts
JC101085	BEARING BALL 6002/C3	Bajaj spare parts

JC101086	BEARING BALL RS1/C3H	Bajaj spare parts
JC101112	GEAR STARTER CLUTCH (55T)	Bajaj spare parts
JC101114	GEAR STARTER CL	Bajaj spare parts
JC101145	ASSLY GEAR ST COUNTER	Bajaj spare parts
JC111003	COIL H T LH WITH CA	Bajaj spare parts
JC111004	COIL H T RH WITH CAP	Bajaj spare parts
JC111007	MOTOR STARTER BLACK	Bajaj spare parts
JC111010	YOKE ASSEMBLY (JC)	Bajaj spare parts
JC111022	COIL H.T. LH	Bajaj spare parts
JC111023	COIL H T RH	Bajaj spare parts
JC111026	STATOR ASSY 18 POLE	Bajaj spare parts
JC111028	ROTOR ASSY	Bajaj spare parts
JC120001	INTAKE PIPE	Bajaj spare parts
JC120002	TUBE CONNECTING	Bajaj spare parts
JC120003	CARBURETOR INSULATOR	Bajaj spare parts
JC120005	CARBURETOR ASSEMBLY	Bajaj spare parts
JC120009	JET NEEDLE JN	Bajaj spare parts
JC120010	NEEDLE JET NJ	Bajaj spare parts
JC120017	MANIFOLD BS32	Bajaj spare parts
JC120018	RUBBER INSULATOR BS32	Bajaj spare parts
JC120023	BS32 CARB INSULATOR WITH CLAMPS	Bajaj spare parts
JC120024	BS32 CARB ASSEMBLY	Bajaj spare parts
JC120026	AUTOCHOKE SOLENOID	Bajaj spare parts
JC141015	GROMMET	Bajaj spare parts
JC141016	COLLAR TANK COVER	Bajaj spare parts
JC141017	GROMMET II TANK COVE	Bajaj spare parts
JC141018	DECAL LH OIL COOLED	Bajaj spare parts
JC141028	FUEL PIPE-PETROL WITH ETHANOL	Bajaj spare parts
JC141034	SPRING DRAIN PIPE	Bajaj spare parts
JC141035	DECAL PULSAR TANK LH	Bajaj spare parts
JC141036	DECAL PULSAR TANK RH	Bajaj spare parts
JC141037	DECAL LH TANK GRAY	Bajaj spare parts
JC141038	DECAL RH TANK GRAY CHROME	Bajaj spare parts
JC141039	DECL LH TANK BLK CHR	Bajaj spare parts
JC141040	DECL RH TANK BLK CHR	Bajaj spare parts
JC141049	TANK MONOGRAM LH GRY	Bajaj spare parts
JC141050	TANK MONOGRAM RH GRY	Bajaj spare parts
JC141051	TANK MONOGRAM LH	Bajaj spare parts
JC141052	TANK MONOGRAM RH BLK	Bajaj spare parts
JC141055	FOAM STRIP 15 X 25	Bajaj spare parts
JC151002	PANEL REAR BRAKE	Bajaj spare parts
JC151004	CAM BRAKE ASSLY	Bajaj spare parts
JC151006	INDICATOR WEAR	Bajaj spare parts
JC151007	LEVER CAM BRAKE	Bajaj spare parts
JC151008	ROD TOURQUE	Bajaj spare parts



JC151010	RIM WHEEL 2.5X17RR B	Bajaj spare parts
JC151012	SPECIAL WASHER PANEL RR	Bajaj spare parts
JC151013	RIM WHEEL 1.85X17FR	Bajaj spare parts
JC151016	COUPLING	Bajaj spare parts
JC151019	VEHICLE SPEED SENSOR	Bajaj spare parts
JC151020	CASE METER HOUSING	Bajaj spare parts
JC161002	HOLDER STEP RH	Bajaj spare parts
JC161017	STAND SIDE	Bajaj spare parts
JC161019	SEAT COWL DECAL LH 2	Bajaj spare parts
JC161023	LABEL INSTRUCTION	Bajaj spare parts
JC171003	SHOCK ABSORBER REAR	Bajaj spare parts
JC171004	ASSLY SWING ARM	Bajaj spare parts
JC181005	HANDLE BAR	Bajaj spare parts
JC181006	COVER TRAIL 'B'	Bajaj spare parts
JC181007	COVER CUSHION	Bajaj spare parts
JC181020	SPRING WASHER	Bajaj spare parts
JC181021	FORK PIPE SPINNED	Bajaj spare parts
JC181022	COVER TRAIL B	Bajaj spare parts
JC181023	COVER CUSHION	Bajaj spare parts
JC181024	LAMP SHADE ASSY	Bajaj spare parts
JC181025	BKT PLATE NUMBER FR	Bajaj spare parts
JC181026	BKT MTG NO PLATE	Bajaj spare parts
JC181027	PLATE NUMBER FR	Bajaj spare parts
JC181029	LOCK SET 4 IN 1	Bajaj spare parts
JC191001	BRAKE LEVER	Bajaj spare parts
JC191002	ROD BRAKE	Bajaj spare parts
JC191004	CABLE CLUTCH	Bajaj spare parts
JC191006	PIN BRAKE REAR	Bajaj spare parts
JC191008	SPRING BRAKE ROD	Bajaj spare parts
JC191009	BOLT BRAKE PEDAL	Bajaj spare parts
JC191010	SPRING PEDAL BRAKE	Bajaj spare parts
JC191011	PIN BRAKE	Bajaj spare parts
JC191018	ELECTRONC SPEED SEAL CP	Bajaj spare parts
JC191019	CABLE ACCELERATER	Bajaj spare parts
JC201004	REAR BRAKE SWITCH AS	Bajaj spare parts
JC201005	SWITCH REED	Bajaj spare parts
JC201006	MAGNET REAR BRAKE S	Bajaj spare parts
JC201008	LAMP HEAD ASSEMBLY	Bajaj spare parts
JC201009	BULB WHITE OUTPUT	Bajaj spare parts
JC201016	SWITCHBODY CONTROL	Bajaj spare parts
JC201017	SWITCH CONTROL LH	Bajaj spare parts
JC201018	SWITCH CONTROL RH	Bajaj spare parts
JC201021	HALL SENSOR	Bajaj spare parts
JC201025	RALAY STARTER	Bajaj spare parts
JC201027	CABLE MOTOR TO RELAY	Bajaj spare parts

JC201036	SIDE REFLEX REFLECTOR(AMBER)	Bajaj spare parts
JC201037	HARNESS WIRING (BS 32)	Bajaj spare parts
JC201039	STAND SIDE SWITCH ASSY	Bajaj spare parts
JC201040	DC BCU WITH SEALED C	Bajaj spare parts
JC201041	HARNESS WIRING	Bajaj spare parts
JC201043	VEHICLE SPEED SENSOR	Bajaj spare parts
JC201045	IGNITION SWITCH	Bajaj spare parts
JC201049	SPEED SENSOR SLEEVE	Bajaj spare parts
JC201050	KIT HARDWARE SPD SENSR	Bajaj spare parts
JC201051	HEAD LAMP ASSY(EUROPEAN MARKET)	Bajaj spare parts
JC72014L	FLAP TANK LH MISTY GREY S	Bajaj spare parts
JC72014M	FLAP TANK LH MIDNIGHT BLA	Bajaj spare parts
JC72024L	FLAP TANK RH MISTY GREY S	Bajaj spare parts
JC72024M	FLAP TANK RH MID BLACK	Bajaj spare parts
JD111001	FRAME SPRINT	Bajaj spare parts
JD111011	NUT CLIP COVER SIDE	Bajaj spare parts
JD111012	BKT SIDE COVER LOCK	Bajaj spare parts
JD111052	GROMMET TANK MTG	Bajaj spare parts
JD111070	FRAME ASSLY	Bajaj spare parts
JD111082	FRAME ASSLY	Bajaj spare parts
JD111093	BRACKET ASSLY STEP HOLDER MTG.	Bajaj spare parts
JD111101	HOOK	Bajaj spare parts
JD111106	FRAME ASSLY	Bajaj spare parts
JD113002	HOLDER STEP LH	Bajaj spare parts
JD113003	HOLDER STEP RH	Bajaj spare parts
JD113024	PLATE LOCK RIDER STEP	Bajaj spare parts
JD113025	DAMPER FOOT REST	Bajaj spare parts
JD113026	HOLDER STEP LH PULSAR	Bajaj spare parts
JD113027	HOLDER STEP RH PULSAR	Bajaj spare parts
JD113031	MAIN STEP LH PUL	Bajaj spare parts
JD113032	MAIN STEP RH PUL	Bajaj spare parts
JD113035	HOLDER STEP LH	Bajaj spare parts
JD113036	HOLDER STEP RH	Bajaj spare parts
JD113200	STAND SIDE	Bajaj spare parts
JD113201	BKT MTG STAND SIDE	Bajaj spare parts
JD113207	STAND CENTER	Bajaj spare parts
JD113208	STAND SIDE	Bajaj spare parts
JD113400	BRACKET ENGINE HANGER	Bajaj spare parts
JD113401	BRACKET ENGINE MTG FRONT	Bajaj spare parts
JD113402	ASSLY HANGER ENGINE	Bajaj spare parts
JD113800	BRKT REAR NO PLATE	Bajaj spare parts
JD113801	BRACKET REAR BLINKER MTG	Bajaj spare parts
JD113802	BRACKET REFLECTOR MTG	Bajaj spare parts
JD113805	FOAM	Bajaj spare parts
JD113807	BRACKET RIDER SEAT MTG	Bajaj spare parts

JD113809	BRACKET REAR NO. PLATE MTG.	Bajaj spare parts
JD113810	BRACKET REFLEX REFLECTOR MTG.	Bajaj spare parts
JD113813	FOAM STRIP (50X15X4)	Bajaj spare parts
JD113814	GROMMET SAI UNIT	Bajaj spare parts
JD113815	SLEEVE SAI UNIT	Bajaj spare parts
JD113816	SPACER	Bajaj spare parts
JD113818	BRACKET BOX FUSE MTG	Bajaj spare parts
JD121002	PIPE SEAT WITH RING	Bajaj spare parts
JD122002	SHAFT SWING ARM	Bajaj spare parts
JD122003	SHOCK ABSORBER REAR	Bajaj spare parts
JD122004	ROD TORQUE	Bajaj spare parts
JD122009	ARM SWING	Bajaj spare parts
JD122013	CHAIN SLIDER	Bajaj spare parts
JD122020	ARM ASSEMBLY SWING	Bajaj spare parts
JD131210	COLLAR ASSY	Bajaj spare parts
JD131212	SLEEVE	Bajaj spare parts
JD131213	AXLE REAR	Bajaj spare parts
JD131215	COLLAR ASSEMBLY	Bajaj spare parts
JD131217	COLLAR	Bajaj spare parts
JD131218	AXLE M14X1.5XL 276 X OLIVE GREEN	Bajaj spare parts
JD131601	LEVER CAM BRAKE	Bajaj spare parts
JD131807	DISC BRAKE KIT FRONT	Bajaj spare parts
JD131808	HOSE ASSY	Bajaj spare parts
JD131809	CLAMP HOSE	Bajaj spare parts
JD131810	DISC BRAKE	Bajaj spare parts
JD131811	BOLT SPECIAL M8	Bajaj spare parts
JD131813	CALIPER ASSLY BLACK	Bajaj spare parts
JD131816	DISC BRAKE FRONT	Bajaj spare parts
JD131820	CABLE BRAKE LEVER-MASTR CYL.	Bajaj spare parts
JD131822	LEVER CAM BRAKE REAR	Bajaj spare parts
JD141003	CHAIN LINK LOCK SET	Bajaj spare parts
JD151000	FRONT FORK ASSY DISC	Bajaj spare parts
JD151003	TUBE OUTER LH	Bajaj spare parts
JD151004	TUBE OUTER RH	Bajaj spare parts
JD151006	LAMP SHADE ASSY	Bajaj spare parts
JD151015	UPPER BRACKET	Bajaj spare parts
JD151016	HOLDER HANDLE LH	Bajaj spare parts
JD151017	HOLDER HANDLE RH	Bajaj spare parts
JD151020	HANDLE BAR TUBE RH	Bajaj spare parts
JD151023	BKT MTG BLINKER FR LH	Bajaj spare parts
JD151024	BKT MTG BLINKER FR RH	Bajaj spare parts
JD151026	FORK PIPE SPINNING	Bajaj spare parts
JD151027	TUBE SPACER	Bajaj spare parts
JD151028	FORK BOLT	Bajaj spare parts
JD151029	UNDER BRKT.ASSLY H/FORK	Bajaj spare parts

JD151032	PLUG HANDLE HOLDER	Bajaj spare parts
JD151036	WASHER CUP	Bajaj spare parts
JD151037	BKT HEADLAMP MTG LH	Bajaj spare parts
JD151038	BKT MTG RH HEADLAMP	Bajaj spare parts
JD151045	HANDLE BAR TUBE ASSY LH	Bajaj spare parts
JD151048	HANDLE BAR TUBE ASSY RH	Bajaj spare parts
JD151051	HOLDER HANDLE LH - BL	Bajaj spare parts
JD151052	HOLDER HANDLE RH - BL	Bajaj spare parts
JD151054	UPPER BRACKET - BLACK	Bajaj spare parts
JD161001	BRAKE PEDAL	Bajaj spare parts
JD161002	SPRING BRAKE PEDAL	Bajaj spare parts
JD161003	ROD BRAKE	Bajaj spare parts
JD161004	SPRING BRAKE SWITCH	Bajaj spare parts
JD161006	SLEEVE SPRING RETURN B	Bajaj spare parts
JD161007	LEVER BRAKE PEDALCBS	Bajaj spare parts
JD161008	LINK EQUILIZER	Bajaj spare parts
JD161011	ROD BRAKE-CBS	Bajaj spare parts
JD161012	PEDAL ASSLY BRAKE	Bajaj spare parts
JD161013	LINK SECONDARY ASSEMBLY	Bajaj spare parts
JD161014	BRACKET SWITCH BRAKE REAR	Bajaj spare parts
JD161015	PIVOT PEDAL BRAKE	Bajaj spare parts
JD161016	SPRING SWITCH BRAKE REAR	Bajaj spare parts
JD161019	DAMPER PEDAL BRAKE	Bajaj spare parts
JD161200	CABLE ACCELERATOR	Bajaj spare parts
JD161201	CLUTCH CABLE	Bajaj spare parts
JD161202	CABLE THROTTLE	Bajaj spare parts
JD161203	CABLE CLUTCH	Bajaj spare parts
JD161204	CABLE THROTTLE	Bajaj spare parts
JD171016	SCREW ROUND HEAD	Bajaj spare parts
JD171018	TAPE DUAL LOCK 10X20	Bajaj spare parts
JD171038	TAPE SEAT	Bajaj spare parts
JD171049	DUEL LOCK TANK SPOILER UPPER	Bajaj spare parts
JD171050	DUEL LOCK TANK SPOILER UPPER RH	Bajaj spare parts
JD171059	EVAP CAP RUBBER BUSH SEALING	Bajaj spare parts
JD171063	TUBE PURGE VALVE TO CARBURATOR	Bajaj spare parts
JD171064	TUBE Y CONNECTOR TO CANISTER	Bajaj spare parts
JD171084	TUBE CONNECTOR T- BODY THROTTLE	Bajaj spare parts
JD171600	FUEL TANK CAP	Bajaj spare parts
JD171602	TAP FUEL ( IRAN EXPORT)	Bajaj spare parts
JD171605	TUBE CANISTER TO PURGE VALVE	Bajaj spare parts
JD171607	TUBE TANK TO Y CONN	Bajaj spare parts
JD171800	PIPE FUEL	Bajaj spare parts
JD171801	SOCKET HEAD BOLT M6X1X17	Bajaj spare parts
JD171807	TUBE INLINE CONNECTOR TO PURGE VALVE	Bajaj spare parts
JD181000	FLAP LH	Bajaj spare parts

JD181001	FLAP RH	Bajaj spare parts
JD181002	STRIP FOAM	Bajaj spare parts
JD181003	FENDER REAR FRONT ASSLY	Bajaj spare parts
JD181006	TUBE MTG RR HUGGER	Bajaj spare parts
JD181007	TUBE HUGGER MTG EXP	Bajaj spare parts
JD181200	COVER LH SIDE	Bajaj spare parts
JD181201	COVER RH SIDE	Bajaj spare parts
JD181203	SEAT COWL ASSY	Bajaj spare parts
JD181208	COWLING LH	Bajaj spare parts
JD181209	COWLING RH	Bajaj spare parts
JD181210	WIND SHIELD	Bajaj spare parts
JD181211	FLAP SPEEDOMETER	Bajaj spare parts
JD181212	MASK	Bajaj spare parts
JD181221	BKT SPEEDO COVER	Bajaj spare parts
JD181224	COVER SIDE UPPER LH	Bajaj spare parts
JD181228	COVER HARNESS LH	Bajaj spare parts
JD181229	COVER HARNESS RH	Bajaj spare parts
JD181230	FOAM	Bajaj spare parts
JD181232	COVER CHAIN INNER	Bajaj spare parts
JD181233	CHAIN COVER ASSLY	Bajaj spare parts
JD181234	NAIL PLASTIC	Bajaj spare parts
JD181240	WINDSHIELD	Bajaj spare parts
JD181241	FOAM -WINDSHIELD	Bajaj spare parts
JD181244	COVER -PAN BELLY-LH	Bajaj spare parts
JD181245	COVER -PAN BELLY-RH	Bajaj spare parts
JD181246	BRACKET -PAN BELLY MTG-LH	Bajaj spare parts
JD181247	BRACKET -PAN BELLY MTG-RH	Bajaj spare parts
JD181255	COVER LEVER BRAKE	Bajaj spare parts
JD181401	BRACE FENDER	Bajaj spare parts
JD181402	FLAP FRONT FENDER	Bajaj spare parts
JD181405	SLEEVE HUUGER MTG FRONT	Bajaj spare parts
JD181408	HUGGER REAR	Bajaj spare parts
JD181409	FLAP MUD REAR	Bajaj spare parts
JD181412	FENDER REAR EVAP	Bajaj spare parts
JD191003	SEAT ASSY REAR	Bajaj spare parts
JD191004	REAR SEAT BASE	Bajaj spare parts
JD191006	DAMPER ROUND	Bajaj spare parts
JD191007	GROMMET RIDER SEAT	Bajaj spare parts
JD191008	COLLAR RIDER SEAT	Bajaj spare parts
JD191012	SEAT ASSY	Bajaj spare parts
JD191018	SEAT ASSLY	Bajaj spare parts
JD191021	DAMPER	Bajaj spare parts
JD231200	LEG GUARD KIT	Bajaj spare parts
JD231201	GUARD LEG	Bajaj spare parts
JD231203	FOOTREST LADIES	Bajaj spare parts

JD231204	GUARD SARI	Bajaj spare parts
JD231402	GRAB HANDLE LH FOAM	Bajaj spare parts
JD231403	GRAB HANDLE RH	Bajaj spare parts
JD231408	GRAB HANDLE LH WITH FOAM(BL)	Bajaj spare parts
JD231409	GRAB HANDLE RH WITH FOAM(BL)	Bajaj spare parts
JD231600	MIRROR ASSY LH	Bajaj spare parts
JD231601	MIRROR RH	Bajaj spare parts
JD232602	SET LOCK	Bajaj spare parts
JD232800	FRONT NUMBER PLATE ASSY	Bajaj spare parts
JD232801	BKT MTG NO PLATE	Bajaj spare parts
JD232804	RUBBER BUSH RR BLNK LH	Bajaj spare parts
JD232805	RUBBER BUSH RR BLNK RH	Bajaj spare parts
JD233012	DECAL TANK BL PLSR 135	Bajaj spare parts
JD233014	DECAL SEAT COWL BL PLSR 1	Bajaj spare parts
JD233016	DECAL 4 VALVE BLACK LH	Bajaj spare parts
JD233017	DECAL 4 VALVE BLACK RH	Bajaj spare parts
JD233150	DECAL TANK 3D EBONY BLACK	Bajaj spare parts
JD233168	DECAL SIDE COVER LH EBONY BLACK	Bajaj spare parts
JD233169	DECAL SIDE COVER RH EBONY BLACK	Bajaj spare parts
JD233188	DECAL SIDE COVER LH RO BL	Bajaj spare parts
JD233189	DECAL SIDE COVER RH RO BL	Bajaj spare parts
JD233224	DECAL COVER SIDE LH FLAME RED	Bajaj spare parts
JD233225	DECAL COVER SIDE RH FLAME RED	Bajaj spare parts
JD233226	DECAL PAN BELLY LH EBONY BLACK	Bajaj spare parts
JD233227	DECAL PAN BELLY RH EBONY BLACK	Bajaj spare parts
JD233228	DECAL PAN BELLY LH ROYAL BLUE	Bajaj spare parts
JD233229	DECAL PAN BELLY RH ROYAL BLUE	Bajaj spare parts
JD233230	DECAL PAN BELLY LH FLAME RED	Bajaj spare parts
JD233231	DECAL PAN BELLY RH FLAME RED	Bajaj spare parts
JD233246	DECAL COVER SIDE LH BLACK CHROME	Bajaj spare parts
JD233247	DECAL COVER SIDE RH BLACK CHROME	Bajaj spare parts
JD233262	DECAL COVER SIDE LH BLUE CHROME	Bajaj spare parts
JD233263	DECAL COVER SIDE RH BLUE CHROME	Bajaj spare parts
JD233278	DECAL COVER SIDE LH PASSION RED	Bajaj spare parts
JD233279	DECAL COVER SIDE RH PASSION RED	Bajaj spare parts
JD233300	DECAL COVER SIDE LH PASSION RED	Bajaj spare parts
JD233301	DECAL COVER SIDE RH PASSION RED	Bajaj spare parts
JD233302	DECAL COVER SIDE LH PEARL WHITE	Bajaj spare parts
JD233303	DECAL COVER SIDE RH PEARL WHITE	Bajaj spare parts
JD233304	DECAL COVER SIDE LH SPARK BLACK	Bajaj spare parts
JD233305	DECAL COVER SIDE RH SPARK BLACK	Bajaj spare parts
JD233306	DECAL COVER SIDE LH BRGHT YELLOW	Bajaj spare parts
JD233307	DECAL COVER SIDE RH BRGHT YELLOW	Bajaj spare parts
JD233323	DECAL COVER SIDE LH CW RED	Bajaj spare parts
JD233324	DECAL COVER SIDE RH CW RED	Bajaj spare parts

JD233339	DECAL COVER SIDE LH S BLUE	Bajaj spare parts
JD233340	DECAL COVER SIDE RH S BLUE	Bajaj spare parts
JD233348	DECAL ANTI SKID	Bajaj spare parts
JD233349	DECAL COVER SIDE LH PASSION RED	Bajaj spare parts
JD233350	DECAL COVER SIDE RH PASSION RED	Bajaj spare parts
JD233351	DECAL COVER SIDE LH WHITE	Bajaj spare parts
JD233352	DECAL COVER SIDE RH WHITE	Bajaj spare parts
JD233353	DECAL COVER SIDE LH BLACK	Bajaj spare parts
JD233354	DECAL COVER SIDE RH BLACK	Bajaj spare parts
JD233355	DECAL COVER SIDE LH YELLOW	Bajaj spare parts
JD233356	DECAL COVER SIDE RH YELLOW	Bajaj spare parts
JD351002	ROTOR XCD 135 SS	Bajaj spare parts
JD351206	GROMMET SPARK PLUG	Bajaj spare parts
JD351207	SPARK PLUG CAP	Bajaj spare parts
JD351800	THROT POSITI SENSOR	Bajaj spare parts
JD401000	LAMP HEAD ASSEMBLY	Bajaj spare parts
JD401003	BLINKER RR LH	Bajaj spare parts
JD401004	BLINKER RR RH CL LENS	Bajaj spare parts
JD401007	LAMP NO. PLATE REAR	Bajaj spare parts
JD401008	LED TAIL LAMP ASSEMBLY	Bajaj spare parts
JD401023	COVER-REAR NUMBER PLATE LAMP	Bajaj spare parts
JD401024	LAMP HEAD ASSEMBLY	Bajaj spare parts
JD401025	HL HARNESS WITH CAP	Bajaj spare parts
JD401032	BULB 12V 5W E-MARKED	Bajaj spare parts
JD401400	SWITCH CONTROL RH	Bajaj spare parts
JD401806	TUBE DRAIN 530 MM	Bajaj spare parts
JD402202	HARNESS WIRING(REAR)	Bajaj spare parts
JD402212	BAND (LENGTH 200 MM)	Bajaj spare parts
JD402214	HARNESS FR	Bajaj spare parts
JD402215	BAND	Bajaj spare parts
JD402216	BAND 300MM	Bajaj spare parts
JD402217	CABLE TIES FOR HARNESS 200MM	Bajaj spare parts
JD402219	HARNESS WIRING REAR	Bajaj spare parts
JD402231	HARNESS WIRING REAR	Bajaj spare parts
JD402232	HARNESS WIRING REAR	Bajaj spare parts
JD402233	HARNESS WIRING REAR BS-IV	Bajaj spare parts
JD402234	HARNESS WIRING FRONT	Bajaj spare parts
JD402235	HARNESS WIRING	Bajaj spare parts
JD402237	HARNESS WIRING FRONT	Bajaj spare parts
JD402239	HARNESS WIRING	Bajaj spare parts
JD402240	HARNESS WIRING FRONT	Bajaj spare parts
JD402402	COVER TOP SPEEDOMETER	Bajaj spare parts
JD402404	SPEEDOMETER PULSAR 135 LS	Bajaj spare parts
JD402405	SPEEDOMETER ASSLY	Bajaj spare parts
JD402406	SPEEDOMETER ASSLY	Bajaj spare parts

JD402407	SPEEDOMETER	Bajaj spare parts
JD402601	TFR TANK UNIT	Bajaj spare parts
JD402602	GAUGE FUEL	Bajaj spare parts
JD511004	SLEEVE SPARK PLUG	Bajaj spare parts
JD511008	GASKET CYLINDER HEAD	Bajaj spare parts
JD511010	GASKET HEAD COVER	Bajaj spare parts
JD511201	VALVE INTAKE	Bajaj spare parts
JD511202	VALVE EXHAUST	Bajaj spare parts
JD511205	RETAINER VALVE SPRING	Bajaj spare parts
JD511207	ARM ROCKER	Bajaj spare parts
JD511209	SHAFT ARM ROCKER	Bajaj spare parts
JD511211	CAM SHAFT COMP.	Bajaj spare parts
JD521002	GASKET CYL. BLOCK	Bajaj spare parts
JD531004	SPACER CR SHAFT CL S	Bajaj spare parts
JD541000	DAMPER CRANK SHAFT	Bajaj spare parts
JD541202	BRACKET HOOK MOUNTING	Bajaj spare parts
JD551208	BUSH 2ND DRIVEN	Bajaj spare parts
JD551400	SPACER CLUTCH ASSEMBLY(17	Bajaj spare parts
JD561001	DRUM COMP GEAR SHIFT	Bajaj spare parts
JD561004	FORK GEAR SHIFT OUTP	Bajaj spare parts
JD561005	FORK GEAR SHIFT INPUT	Bajaj spare parts
JD561006	SHAFT GEAR K SHIF	Bajaj spare parts
JD561011	BOLT SPECIAL DRUM CHANGE	Bajaj spare parts
JD561203	INHIBITOR COMP. GEAR SHIF	Bajaj spare parts
JD561204	SPRING INHIBITOR	Bajaj spare parts
JD561411	LEVER CHANGE ARM	Bajaj spare parts
JD561413	ROD TIE	Bajaj spare parts
JD561414	LEVER COMPLETE C	Bajaj spare parts
JD561415	LEVER COMPLETE CHANGE	Bajaj spare parts
JD561416	WASHER NYLON	Bajaj spare parts
JD561417	BOOT CHANGE ARM	Bajaj spare parts
JD561418	BOOT CHANGE LEVER	Bajaj spare parts
JD561421	LEVER -GEAR CHANGE	Bajaj spare parts
JD561423	ARM -LEVER CHANGE GEAR	Bajaj spare parts
JD581001	DUCT AIR INTAKE	Bajaj spare parts
JD581005	FILTER AIR	Bajaj spare parts
JD581011	CLIP SEPARATOR	Bajaj spare parts
JD581012	VALVE PURGE	Bajaj spare parts
JD581202	THROTTLE POSITION SENSOR	Bajaj spare parts
JD591026	SHIELD MUFFLER	Bajaj spare parts
JD591055	GASKET	Bajaj spare parts
JD591056	SILENCER WITHOUT SHIELD	Bajaj spare parts
JD621001	SHAFT KICK	Bajaj spare parts
JD710123	TANK FUEL PULSAR 135 LS	Bajaj spare parts
JD71034M	TANK FUEL M BL PLSR 135	Bajaj spare parts



JD72024M	FENDER FR MID BLACK	Bajaj spare parts
JD73014M	COWLING LH MID BLK	Bajaj spare parts
JD73014R	COWL SEAT LH PASS RED	Bajaj spare parts
JD73015L	COWLING LH WITH ECAL	Bajaj spare parts
JD73024M	COWLING RH MID BLK	Bajaj spare parts
JD73024R	COWL SEAT RH PASS RED	Bajaj spare parts
JD73025G	COWLING RH PLASMA BLUE	Bajaj spare parts
JD73025L	COWLING RH	Bajaj spare parts
JD74014M	SPOILER LH MID BLACK	Bajaj spare parts
JD74024M	SPOILER RH MID BLACK	Bajaj spare parts
JD74024R	SPOILER RH TANK PASS RE	Bajaj spare parts
JD74025L	TANK SPOILER RH P RED WTH DUL DEC SCH	Bajaj spare parts
JD74034M	SPOILER CENTRAL MID BLACK	Bajaj spare parts
JD74034R	SPOILER CENTRL TANK PASS	Bajaj spare parts
JE233002	DECAL COVER CLUTCH	Bajaj spare parts
JE351002	ROTOR ASSY W/O CLUTCH XC	Bajaj spare parts
JE351004	ROTOR ASSLY-12 POLE D102C	Bajaj spare parts
JE351005	STATOR ASSLY-12 POLE D102C	Bajaj spare parts
JE351009	STATOR ASSLY 12POLE K11	Bajaj spare parts
JE351011	ROTOR ASSLY K15	Bajaj spare parts
JE351013	STATOR ASSLY K15	Bajaj spare parts
JE351016	ROTOR ASSLY WITH CLUTCH	Bajaj spare parts
JE351018	ROTOR ASSLY WITH CLUTCH K11	Bajaj spare parts
JE351025	STATOR ASSLY K16C	Bajaj spare parts
JE351031	STATOR ASSLY	Bajaj spare parts
JE351033	STATOR ASSLY	Bajaj spare parts
JE351035	ASSEMBLY ROTOR	Bajaj spare parts
JE351046	ROTOR ASSEMBLY	Bajaj spare parts
JE351047	STATOR ASSEMBLY	Bajaj spare parts
JE351052	STATOR ASSEMBLY	Bajaj spare parts
JE351054	STATOR ASSEMBLY	Bajaj spare parts
JE351060	ASSEMBLY ROTOR	Bajaj spare parts
JE351067	ASSEMBLY ROTOR	Bajaj spare parts
JE351200	DC CDI UNIT	Bajaj spare parts
JE351203	COIL H.T. WITH CABL	Bajaj spare parts
JE351204	COIL H.T. WITH CAB	Bajaj spare parts
JE351206	CDI	Bajaj spare parts
JE351207	CDI D102C TX	Bajaj spare parts
JE351208	CDI DC WITH DAMPER	Bajaj spare parts
JE351212	CAP SPARK (120 DEG) K11	Bajaj spare parts
JE351232	CDI ASSLY WITH DAMPER K16B	Bajaj spare parts
JE351236	HT COIL 1 K16B	Bajaj spare parts
JE351238	HT COIL 2 K16B	Bajaj spare parts
JE351243	CDI NON TPS ASSLY K16B	Bajaj spare parts
JE351246	ASSLY CDI D109	Bajaj spare parts

JE351250	H T COIL 1 K16B FI	Bajaj spare parts
JE351252	H T COIL 2 K16B FI	Bajaj spare parts
JE351256	COIL HT WITH CABLE-RH	Bajaj spare parts
JE351257	CDI ASSLY	Bajaj spare parts
JE351266	CDI ASSEMBLY	Bajaj spare parts
JE351400	OIL PRESSURE SWITCH K11	Bajaj spare parts
JE351401	ENGINE TEMP SENSOR_K11 UG	Bajaj spare parts
JE351403	SENSOR -TEMPERATURE-ENGINE	Bajaj spare parts
JE351407	SENSOR TEMPERATURE ENGINE	Bajaj spare parts
JE351408	ECU EMS ASSEMBLY	Bajaj spare parts
JE351421	ECU EMS ASSEMBLY	Bajaj spare parts
JE351438	ECU EMS ASSEMBLY	Bajaj spare parts
JE351600	STARTER MOTOR D102A	Bajaj spare parts
JE501006	ENGINE ASSLY DIS 102	Bajaj spare parts
JE501017	ENGINE ASSELY D102C TX	Bajaj spare parts
JE501019	ASSLY ENGINE K15	Bajaj spare parts
JE501049	ASSLY ENGINE D109	Bajaj spare parts
JE501053	ENGINE ASSLY	Bajaj spare parts
JE501061	ENGINE ASSEMBLY	Bajaj spare parts
JE501071	ENGINE ASSEMBLY	Bajaj spare parts
JE501076	ENGINE ASSEMBLY	Bajaj spare parts
JE501079	ENGINE ASSEMBLY	Bajaj spare parts
JE501085	ENGINE ASSEMBLY	Bajaj spare parts
JE501094	ENGINE ASSEMBLY	Bajaj spare parts
JE501119	ENGINE ASSEMBLY	Bajaj spare parts
JE511015	GASKET BREATHER P145 UG	Bajaj spare parts
JE511022	GASKET METALLIC HEAD COVER	Bajaj spare parts
JE511024	HEAD CYLINDER MACHINED K11	Bajaj spare parts
JE511038	GASKET COVER CYLINDER HEAD K11	Bajaj spare parts
JE511040	GASKET BREATHER HEAD COVER K11	Bajaj spare parts
JE511047	BOLT CYLINDER HEAD K11	Bajaj spare parts
JE511049	BEARING CAM SHAFT	Bajaj spare parts
JE511052	NOZZLE HEAD - K11	Bajaj spare parts
JE511053	ASSLY BOLT HEAD COVER D102A	Bajaj spare parts
JE511060	CIRCLIP INTERNAL K11	Bajaj spare parts
JE511067	GASKET SAI FLANGE	Bajaj spare parts
JE511076	PLATE CYLINDER HEAD D106A	Bajaj spare parts
JE511078	GASKET SAI FLANGE K11	Bajaj spare parts
JE511085	GASKET CYLINDER HEAD K11 UG	Bajaj spare parts
JE511086	ASSLY CYLINDER HEAD K11 UG	Bajaj spare parts
JE511087	HEAD CYLINDER MACHINED K11 UG	Bajaj spare parts
JE511127	HEAD CYLINDER	Bajaj spare parts
JE511140	HEAD CYLINDER	Bajaj spare parts
JE511153	SPRING VALVE	Bajaj spare parts
JE511156	COVER ASSEMBLY HEAD CYLINDER	Bajaj spare parts

JE511158	GASKET COVER HEAD CYLINDER	Bajaj spare parts
JE511170	GASKET HEAD CYLINDER	Bajaj spare parts
JE511200	VALVE INTAKE P-145	Bajaj spare parts
JE511201	VALVE EXHAUST P-145 UG	Bajaj spare parts
JE511202	VALVE SEAT INTAKE P145 UG	Bajaj spare parts
JE511203	VALVE SEAT EXHAUST P-145 UG	Bajaj spare parts
JE511204	ARM ROCKER WITH ROLLER	Bajaj spare parts
JE511206	CAMSHAFT ASSY DIS 102	Bajaj spare parts
JE511208	VALVE INTAKE -K11	Bajaj spare parts
JE511209	VALVE EXHAUST -K11	Bajaj spare parts
JE511212	ASSLY INTAKE ROCKER ARM-K11	Bajaj spare parts
JE511213	ASSLY EX ROCKER ARM-K11	Bajaj spare parts
JE511216	SPRING VALVE -K11	Bajaj spare parts
JE511221	SHAFT ROCKER K11	Bajaj spare parts
JE511225	SHAFT ROCKER EXHAUST K11	Bajaj spare parts
JE511230	CAM CHAIN 94 LINKS	Bajaj spare parts
JE511233	CAM CHAIN K11(SILENT)	Bajaj spare parts
JE511234	SPROCKET CAM SHAFT K11	Bajaj spare parts
JE511236	CAM CHAIN SILENT D106A	Bajaj spare parts
JE511237	CAM SPROCKET SILENT CHAIN D106A	Bajaj spare parts
JE511239	ASSLY CAMSHAFT D106A	Bajaj spare parts
JE511240	SPRING VALVE D106A	Bajaj spare parts
JE511241	SPACER CAM K11 (SILENT CHAIN)	Bajaj spare parts
JE511243	ASSEMBLY CAMSHAFT K11	Bajaj spare parts
JE511245	Camshaft Assly	Bajaj spare parts
JE511251	CAMSHAFT ASSLY	Bajaj spare parts
JE511253	CAMSHAFT ASSEMBLY	Bajaj spare parts
JE511255	VALVE INTAKE	Bajaj spare parts
JE511256	ROCKER ARM ASSEMBLY INTAKE	Bajaj spare parts
JE511258	ROCKER ARM ASSEMBLY EXHAUST	Bajaj spare parts
JE511261	VALVE EXHAUST	Bajaj spare parts
JE511262	SEAT SPRING VALVE	Bajaj spare parts
JE511265	CAMSHAFT ASSEMBLY	Bajaj spare parts
JE511267	VALVE INTAKE	Bajaj spare parts
JE511268	VALVE EXHAUST	Bajaj spare parts
JE511269	ROCKER ARM ASSEMBLY	Bajaj spare parts
JE511271	SPROCKET CAMSHAFT	Bajaj spare parts
JE511275	VALVE INTAKE	Bajaj spare parts
JE521011	GUIDE CAMCHAIN (TIGHT SIDE)	Bajaj spare parts
JE521016	TENSIONER CHAIN D102C	Bajaj spare parts
JE521019	GUIDE CAM CHAIN TIGHT D102C	Bajaj spare parts
JE521021	CHAIN GUIDE TIGHT SIDE K11	Bajaj spare parts
JE521025	GUIDE TIGHT SIDE SILENT CHAIN	Bajaj spare parts
JE521030	GASKET CYLINDER BLOCK K11 UG	Bajaj spare parts
JE521033	GASKET BLOCK CYLINDER	Bajaj spare parts

JE521206	ASSLY PISTON P145 UG	Bajaj spare parts
JE521208	PISTON ASSEMBLY D102C	Bajaj spare parts
JE521210	ASSLY PISTON K11	Bajaj spare parts
JE521215	ASSLY PISTON K11 UG	Bajaj spare parts
JE531000	CRANK SHAFT ASSLY	Bajaj spare parts
JE531001	BALL BEARING 22X56X16	Bajaj spare parts
JE531003	ASSLY CRANK SHAFT P145 UG	Bajaj spare parts
JE531008	CRANKSHAFT ASSY DIS 10	Bajaj spare parts
JE531025	CRANKSHAFT ASSLY K11	Bajaj spare parts
JE531033	SPROCKET CRANK SHAFT	Bajaj spare parts
JE531040	CRANKSHAFT ASSLY K11 UG	Bajaj spare parts
JE531045	GEAR PRIMARY DRIVE K11 UG	Bajaj spare parts
JE531047	CRANKSHAFT ASSLY	Bajaj spare parts
JE531052	CRANKSHAFT ASSLY	Bajaj spare parts
JE531054	CRANKSHAFT ASSEMBLY	Bajaj spare parts
JE531200	BALANCER INTEGRAL K11	Bajaj spare parts
JE531201	ASSLY INTEGRAL BALANCER	Bajaj spare parts
JE531202	ASSLY INTEGRAL BALANCER K11 UG	Bajaj spare parts
JE531206	BALANCER ASSEMBLY	Bajaj spare parts
JE541001	CRANKCASE MAG SIDE	Bajaj spare parts
JE541003	CRANKCASE CLUTCH SIDE	Bajaj spare parts
JE541008	SPRING RETURN KICK STR.	Bajaj spare parts
JE541018	CRANKCASE RH (D102A)	Bajaj spare parts
JE541026	CRANKCASE ASSLY RH D102A	Bajaj spare parts
JE541028	PIN K11	Bajaj spare parts
JE541030	GUIDE CAM CHAIN SLACK SIDE	Bajaj spare parts
JE541038	DAMPER CRANKSHAFT D106A	Bajaj spare parts
JE541039	CRANKCASE LH D106A	Bajaj spare parts
JE541040	ASSLY CRANKCASE LH D106A	Bajaj spare parts
JE541042	BOLT STATOR MTG D106A	Bajaj spare parts
JE541048	DAMPER CRANKSHAFT K11	Bajaj spare parts
JE541051	NOZZLE OIL JET K11	Bajaj spare parts
JE541052	JET CRANKCASE LH K16B	Bajaj spare parts
JE541060	CRANKCASE CLUTCH SIDE K11 UG	Bajaj spare parts
JE541061	ASSLY CRANKCASE LH K11 UG	Bajaj spare parts
JE541062	CRANKCASE MAGNETO SIDE K11 UG	Bajaj spare parts
JE541063	GASKET CRANKCASE K11 UG	Bajaj spare parts
JE541074	CRANKCASE LH	Bajaj spare parts
JE541080	CRANKCASE LH	Bajaj spare parts
JE541082	CRANKCASE LH	Bajaj spare parts
JE541085	CRANKCASE ASSEMBLY LH	Bajaj spare parts
JE541207	COVER LH RR	Bajaj spare parts
JE541209	DAMPER	Bajaj spare parts
JE541210	DAMPER	Bajaj spare parts
JE541211	DECAL CLUTCH COVER	Bajaj spare parts

JE541212	DECAL MAGNETO COVER	Bajaj spare parts
JE541213	PLAIN WASHER	Bajaj spare parts
JE541214	SPRING TORSION CLUTCH LEVER	Bajaj spare parts
JE541218	CAP FILTER M LIGHT SILV.	Bajaj spare parts
JE541228	ASSLY COVER RR K11	Bajaj spare parts
JE541230	LABEL MAGNETO COVER D102C	Bajaj spare parts
JE541231	LABEL CLUTCH COVER D102C	Bajaj spare parts
JE541233	ASSLY MAG COVER-D100 UG	Bajaj spare parts
JE541240	GASKET MAGNETO COVER K11	Bajaj spare parts
JE541241	GASKET CLUTCH COVER K11	Bajaj spare parts
JE541242	SEAL OIL CRANKSHAFT K11	Bajaj spare parts
JE541243	BRACKET HARNESS K11	Bajaj spare parts
JE541244	BRACKET CLUTCH CABLE K11	Bajaj spare parts
JE541245	JET CLUTCH COVER K11	Bajaj spare parts
JE541247	ASSELY COVER LH RR	Bajaj spare parts
JE541249	PLATE POSITION K11	Bajaj spare parts
JE541264	ASSLY MAG COVER D106A	Bajaj spare parts
JE541266	CAP OIL FILTER D106A	Bajaj spare parts
JE541267	LABEL CLUTCH COVER K11	Bajaj spare parts
JE541271	SHAFT CLUTCH RELEASE ASSEMBLY K11	Bajaj spare parts
JE541287	LABEL GEAR SHIFT	Bajaj spare parts
JE541288	SHAFT ASSLY CLUTCH	Bajaj spare parts
JE541291	BRACKET CABLE CLUTCH	Bajaj spare parts
JE541311	BRACKET HARNESS	Bajaj spare parts
JE541312	GASKET COVER MAGNETO	Bajaj spare parts
JE551001	SHAFT INPUT	Bajaj spare parts
JE551007	SHAFT OUTPUT	Bajaj spare parts
JE551015	SHAFT INPUT	Bajaj spare parts
JE551200	GEAR 2ND DRIVE	Bajaj spare parts
JE551201	GEAR 3RD DRIVE K11	Bajaj spare parts
JE551202	GEAR 4TH DRIVE	Bajaj spare parts
JE551203	GEAR 5TH DRIVE	Bajaj spare parts
JE551204	GEAR 1ST DRIVEN	Bajaj spare parts
JE551205	GEAR 2ND DRIVEN	Bajaj spare parts
JE551206	GEAR 3RD DRIVEN K11	Bajaj spare parts
JE551207	GEAR 4TH DRIVEN	Bajaj spare parts
JE551208	GEAR 5TH DRIVEN	Bajaj spare parts
JE551211	WASHER 1MM K11	Bajaj spare parts
JE551212	BUSH 1ST GEAR DRIVEN	Bajaj spare parts
JE551213	BALANCER DRIVE GEAR K11	Bajaj spare parts
JE551214	BALANCER DRIVEN GEAR K11	Bajaj spare parts
JE551215	GEAR 1ST DRIVEN K11	Bajaj spare parts
JE551216	GEAR 4TH DRIVEN K11	Bajaj spare parts
JE551400	CLUTCH ASSLY COMP	Bajaj spare parts
JE551401	ROD PUSH	Bajaj spare parts

JE551403	HUB CLUTCH FCC	Bajaj spare parts
JE551404	SPRING CLUTCH FCC	Bajaj spare parts
JE551405	PLATE CLUTCH LIFTER FCC	Bajaj spare parts
JE551407	CLUTCH ASSLY - MAKINO	Bajaj spare parts
JE551408	ROD PUSH K11	Bajaj spare parts
JE551409	WASHER BELLEVILLE D102C	Bajaj spare parts
JE551411	ASSLY CLUTCH - D106A	Bajaj spare parts
JE551413	HUB CLUTCH FCC	Bajaj spare parts
JE551414	WHEEL CLUTCH	Bajaj spare parts
JE551415	LIFTER PLATE CLUTCH	Bajaj spare parts
JE551428	ASSEMBLY CLUTCH	Bajaj spare parts
JE551434	CLUTCH ASSLY	Bajaj spare parts
JE551435	HOUSING ASSLY CLUTCH	Bajaj spare parts
JE551437	PLATE ASSLY CLUTCH	Bajaj spare parts
JE551438	HUB CLUTCH	Bajaj spare parts
JE551439	WHEEL CLUTCH	Bajaj spare parts
JE551452	CLUTCH ASSEMBLY	Bajaj spare parts
JE561001	DRUM COMP GEAR SHIFT DISCO-H	Bajaj spare parts
JE561003	DRUM COMP GEAR SHIFT	Bajaj spare parts
JE561004	SHAFT GEAR FORK SHIFT OUTPUT K11	Bajaj spare parts
JE561005	CAM DRUM CHANGE K11	Bajaj spare parts
JE561006	DRUM COMP GEAR SHIFT K11	Bajaj spare parts
JE561200	SPRING GEAR SHIFT RETURN K11	Bajaj spare parts
JE571003	ASSLY OIL PUMP BODY K11	Bajaj spare parts
JE571004	GEAR OIL PUMP BODY K11	Bajaj spare parts
JE571007	ELEMENT OIL FILTER K11	Bajaj spare parts
JE571008	GEAR OIL PUMP K11 UG	Bajaj spare parts
JE571009	OIL PUMP ASSY COMP	Bajaj spare parts
JE571014	PUMP OIL	Bajaj spare parts
JE571213	ASSLY PRESSURE RELIEF VALVE K11 UG	Bajaj spare parts
JE571215	ASSLY 3 LAYER OIL COOLER K11 UG	Bajaj spare parts
JE571216	ASSLY PIPE OUTLET 3 LAYER OIL COOLER	Bajaj spare parts
JE571219	ASSLY PIPE INLET 3 LAYER OIL COOLER K	Bajaj spare parts
JE571224	BRACKET UPPER OILCOOLER K11 UG	Bajaj spare parts
JE571225	BRACKET LOWER OIL COOLER K11 UG	Bajaj spare parts
JE571227	SLEEVE BKT OIL COOLER K11 UG	Bajaj spare parts
JE571239	CLAMP COOLER OIL	Bajaj spare parts
JE571240	BRACKET COOLER OIL	Bajaj spare parts
JE581000	TUBE CONNECTING	Bajaj spare parts
JE581004	ASSLY AIR FILTER K11	Bajaj spare parts
JE581009	TUBE CONNECTING K11	Bajaj spare parts
JE581010	DUCT ENTRY AIR FILTER K11	Bajaj spare parts
JE581011	TUBE BREATHER K11	Bajaj spare parts
JE581014	ELEMENT AIRFILTER K11	Bajaj spare parts
JE581018	TUBE CONNECTING K15	Bajaj spare parts

JE581025	ASSLY DUCT INTAKE D106A	Bajaj spare parts
JE581027	HOSE PIPE A/F TO SILENCER UNIT	Bajaj spare parts
JE581035	HOSE CONNECTOR D106C SAI	Bajaj spare parts
JE581037	HOSE CONNECTOR SAI	Bajaj spare parts
JE581038	TUBE OUTLET SAI-P135	Bajaj spare parts
JE581039	BAND CLIP SAI HOSE OUTLET TUBE	Bajaj spare parts
JE581041	HOSE INTAKE SILENCER UNIT TO SAI	Bajaj spare parts
JE581045	SEAL BOTTOM COVER K11	Bajaj spare parts
JE581046	SCOOP SHROUD K11	Bajaj spare parts
JE581047	ASSLY SHROUD K11	Bajaj spare parts
JE581051	ARRESTER FLAME K11	Bajaj spare parts
JE581053	TUBE OUTLET SAI K11	Bajaj spare parts
JE581054	HOSE INTAKE SAI K11	Bajaj spare parts
JE581055	HOSE PIPE SAI INLET K11	Bajaj spare parts
JE581056	ASSLY AIR FILTER K15	Bajaj spare parts
JE581060	HOSE CONNECTOR SAI K11	Bajaj spare parts
JE581068	CLAMP CONNECTING TUBE K11	Bajaj spare parts
JE581075	ASSLY AIR FILTER SECONDARY K11	Bajaj spare parts
JE581076	FOAM ELEMENT SECONDORY AIR FILTER K11	Bajaj spare parts
JE581080	ASSLY AIR FILTER K11 UG	Bajaj spare parts
JE581081	SCOOP SHROUD K11 UG	Bajaj spare parts
JE581084	DUCT ENTRY AIR FILTER K16C	Bajaj spare parts
JE581093	TUBE BREATHER	Bajaj spare parts
JE581094	FILTER ASSLY AIR	Bajaj spare parts
JE581095	TUBE CONNECTING FI	Bajaj spare parts
JE581099	FILTER ASSEMBLY AIR	Bajaj spare parts
JE581107	TUBE SAI OUTLET	Bajaj spare parts
JE581118	FILTER ASSEMBLY AIR	Bajaj spare parts
JE581125	FILTER ASSEMBLY AIR	Bajaj spare parts
JE581130	PIPE BREATHER	Bajaj spare parts
JE581142	FILTER ASSEMBLY AIR	Bajaj spare parts
JE581161	FILTER ASSEMBLY AIR	Bajaj spare parts
JE581200	CARBURETTOR BS26	Bajaj spare parts
JE581213	DIAPHRAGM PISTON BS26	Bajaj spare parts
JE581215	SEAL ORING AUTOCHOKE	Bajaj spare parts
JE581218	SCREW DRAIN BS26	Bajaj spare parts
JE581220	SCREW TPS BS26	Bajaj spare parts
JE581221	AUTOCHOKE BS26	Bajaj spare parts
JE581223	PIPE OVER FLOW BS26	Bajaj spare parts
JE581224	PIPE AIR VENT BS26	Bajaj spare parts
JE581225	SEAL ORING TPS BS26	Bajaj spare parts
JE581230	CARBURETTOR BS26 WITH FLASH TPS	Bajaj spare parts
JE581231	CARBURETOR ASSY DIS 10	Bajaj spare parts
JE581233	ASSLY CARBURETTOR K11	Bajaj spare parts
JE581237	ASSLY REED SWITCH	Bajaj spare parts

JE581238	ASSLY CARB D125 T	Bajaj spare parts
JE581239	THROTTLE CABLE BRACKET K11	Bajaj spare parts
JE581245	ASSLY CARBURETTOR K11	Bajaj spare parts
JE581247	CARBURETTOR	Bajaj spare parts
JE581249	ASSLY CARBURETTOR K16B UG EVAP	Bajaj spare parts
JE581251	ASSLY CARBURETTOR D109	Bajaj spare parts
JE581254	CARBURETTOR ASSLY	Bajaj spare parts
JE581255	CARBURETTOR ASSLY	Bajaj spare parts
JE581257	CARBURETTOR ASSLY	Bajaj spare parts
JE581258	CARBURETTOR ASSLY	Bajaj spare parts
JE581261	NEEDLE VALVE ASSEMBLY	Bajaj spare parts
JE581262	CARBURETTOR	Bajaj spare parts
JE581400	MANIFOLD INTAKE	Bajaj spare parts
JE581401	SLEEVE CARBURETTOR	Bajaj spare parts
JE581406	MANIFOLD INTAKE K11	Bajaj spare parts
JE581407	SLEEVE CARBURETTOR K11	Bajaj spare parts
JE581409	PIPE INTAKE K15	Bajaj spare parts
JE581412	HOSE PIPE INTAKE MANIFOLD	Bajaj spare parts
JE581416	NIPPLE CONNECTOR MANIFOLD SAI	Bajaj spare parts
JE581417	ASSLY INTAKE MANIFOLD P135	Bajaj spare parts
JE581423	ASSLY MANIFOLD SAI K11	Bajaj spare parts
JE581426	INSULATOR MANIFOLD K16B	Bajaj spare parts
JE581428	CLAMP SLEEVE CARBURETTOR K16B UG	Bajaj spare parts
JE581429	PIPE INTAKE	Bajaj spare parts
JE581435	PIPE INTAKE	Bajaj spare parts
JE581437	MANIFOLD INTAKE	Bajaj spare parts
JE581438	INSULATOR	Bajaj spare parts
JE581442	SLEEVE MANIFOLD	Bajaj spare parts
JE581445	PIPE INTAKE	Bajaj spare parts
JE581453	BRACKET CABLE THROTTLE	Bajaj spare parts
JE582402	TUBE SAI OUTLET	Bajaj spare parts
JE582602	RING O SAI FILTER D106A	Bajaj spare parts
JE582603	FOAM SAI FILTER D106A	Bajaj spare parts
JE582604	ASSLY SAI FILTER D106A	Bajaj spare parts
JE582606	SEAL SAI FILTER K11	Bajaj spare parts
JE591002	GASKET EXHAUST	Bajaj spare parts
JE591005	ASSLY PIPE A K11	Bajaj spare parts
JE591012	ASSLY MUFFLER K11	Bajaj spare parts
JE591046	HEAT SHIELD K11	Bajaj spare parts
JE591048	MUFFLER ASSLY COMPLETE K11	Bajaj spare parts
JE591075	ASSEMBLY SILENCER D106A	Bajaj spare parts
JE591172	ASSLY PIPE A K16C WO CAT	Bajaj spare parts
JE591179	ASSLY PIPE A K11 UG	Bajaj spare parts
JE591195	SHIELD MUFFLER	Bajaj spare parts
JE591201	SHIELD MUFFLER	Bajaj spare parts



JE591280	GASKET EXHAUST	Bajaj spare parts
JE591283	PIPE ASSEMBLY A	Bajaj spare parts
JE591299	ASSEMBLY MUFFLER	Bajaj spare parts
JE591300	MUFFLER ASSEMBLY	Bajaj spare parts
JE591320	SHIELD MUFFLER	Bajaj spare parts
JE591333	PIPE ASSEMBLY A	Bajaj spare parts
JE591358	SHIELD MUFFLER	Bajaj spare parts
JE591368	PIPE ASSEMBLY A	Bajaj spare parts
JE611000	INJECTOR ASSEMBLY	Bajaj spare parts
JE611003	ASSLY CONECTR-TUB-CAP INJECTR	Bajaj spare parts
JE611004	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
JE611200	BODY ASSLY THROTTLE	Bajaj spare parts
JE611203	BODY ASSLY THROTTLE	Bajaj spare parts
JE611205	BODY ASSLY THROTTLE	Bajaj spare parts
JE611208	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JE611212	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JE611213	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
JE621001	SHAFT KICK	Bajaj spare parts
JE621002	SHAFT KICK K11	Bajaj spare parts
JE621003	SPRING K11	Bajaj spare parts
JE621004	SLEEVE K11	Bajaj spare parts
JE621008	GEAR ASSEMBLY PINION KICK	Bajaj spare parts
JE621200	KICK LEVER	Bajaj spare parts
JE621203	ASSLY KICK LEVER K11	Bajaj spare parts
JE621206	LEVER ASSLY KICK	Bajaj spare parts
JE621402	STARTER DRIVE ASSLY K11	Bajaj spare parts
JE621403	NEEDLE ROLLER BEARING	Bajaj spare parts
JE621404	ASSLY GEAR STARTER CLUTCH	Bajaj spare parts
JE621405	STOPPER GEAR STARTER K11	Bajaj spare parts
JE621406	GEAR STARTER CLUTCH D106A	Bajaj spare parts
JE621408	GEAR DRIVE STARTER CLUTCH	Bajaj spare parts
JE621409	GEAR ASSLY STARTER CLUTCH	Bajaj spare parts
JE621411	BEARING NEEDLE	Bajaj spare parts
JE621412	GEAR ASSEMBLY CLUTCH STARTER	Bajaj spare parts
JE621414	GEAR DRIVE STARTER CLUTCH	Bajaj spare parts
JE621415	STOPPER GEAR STARTER	Bajaj spare parts
JF111000	FRAME ASSLY	Bajaj spare parts
JF111051	FRAME ASSY COMP (K11)	Bajaj spare parts
JF111052	BOLT ENGINE MTG	Bajaj spare parts
JF111136	FRAME ASSLY COMP (K16B)	Bajaj spare parts
JF111173	FRAME ASSLY - K11 UG	Bajaj spare parts
JF111179	GROMMET FRAME-K10	Bajaj spare parts
JF111183	FRAME ASSLY -K11-UG FI	Bajaj spare parts
JF111192	FRAME ASSEMBLY	Bajaj spare parts
JF111280	FRAME ASSEMBLY	Bajaj spare parts

JF111283	FRAME ASSEMBLY	Bajaj spare parts
JF111351	FRAME ASSEMBLY	Bajaj spare parts
JF111361	FRAME ASSEMBLY	Bajaj spare parts
JF113003	HOLDER STEP LH - K10	Bajaj spare parts
JF113007	DAMPER FOOTREST (K11)	Bajaj spare parts
JF113008	LOCK PLATE FOOTREST (K11)	Bajaj spare parts
JF113009	STEP ASSY RH (K11)	Bajaj spare parts
JF113012	SPRING TORSION - K10	Bajaj spare parts
JF113014	BRACKET RESERVOIR MTG -K10	Bajaj spare parts
JF113015	STEP HOLDER RH -K10 (2CH ABS)	Bajaj spare parts
JF113019	TAPE ANTI-ABRASION STEP HOLDR RH	Bajaj spare parts
JF113024	PAD STEP	Bajaj spare parts
JF113036	BRACKET RESERVOIR	Bajaj spare parts
JF113037	BRACKET SWITCH BRAKE REAR	Bajaj spare parts
JF113048	BRACKET ASSEMBLY	Bajaj spare parts
JF113202	STAND CENTRAL (K11)	Bajaj spare parts
JF113204	ASSLY SIDE STAND - K10	Bajaj spare parts
JF113205	BUSH SIDE STAND MTG	Bajaj spare parts
JF113208	BRACKET HOLDER MAGNET	Bajaj spare parts
JF113209	BRACKET STAND SIDE	Bajaj spare parts
JF113210	SPRING TENSION-COVER	Bajaj spare parts
JF113212	STAND ASSEMBLY SIDE	Bajaj spare parts
JF113408	SPACER ASSLY - K11	Bajaj spare parts
JF113412	BOLT ENGINE MONTING REAR M10X110	Bajaj spare parts
JF113414	ENGINE HANGER LH (TUBULAR) -K10	Bajaj spare parts
JF113415	ENGINE HANGER RH (TUBULAR) -K10	Bajaj spare parts
JF113418	ENGINE STAY LH -K11 UG	Bajaj spare parts
JF113419	ENGINE STAY RH -K11 UG	Bajaj spare parts
JF113422	SPACER	Bajaj spare parts
JF113423	WASHER	Bajaj spare parts
JF113424	BRACKET ENGINE MIDDLE REAR	Bajaj spare parts
JF113808	HOOK DRAIN TUBE (K11)	Bajaj spare parts
JF113809	BKT SIDE COVER MTG - K11	Bajaj spare parts
JF113814	BRACKET REGULATOR LOOSE - K11	Bajaj spare parts
JF113815	BRACKET SAI MTG LOOSE - K11	Bajaj spare parts
JF113816	HORN MTG BKT - K10	Bajaj spare parts
JF113817	BKT SEAT LOCK MTG - K10	Bajaj spare parts
JF113818	BKT RR FENDER MIDDLE MTG - K10	Bajaj spare parts
JF113820	CLAMP BRAKE HOSE K16B	Bajaj spare parts
JF113821	BRACKET CANISTER MTG- K10	Bajaj spare parts
JF113822	STUD HORN MOUNTING BRACKET	Bajaj spare parts
JF113823	BRACKET HT COIL MTG LOOSE K16B	Bajaj spare parts
JF113828	CLIP NUT M8 - K10	Bajaj spare parts
JF113831	BRACKET ROLL OVER SENSOR-K10	Bajaj spare parts
JF113832	HORN MTG BKT - K11 UG	Bajaj spare parts

JF113834	HEAT SHEATH- K16B UG	Bajaj spare parts
JF113838	BRACKET PURGE VALVE MTG - K16B	Bajaj spare parts
JF113841	CAP ENGINE STAY	Bajaj spare parts
JF113842	BRACKET ROLL OVER SENSOR MTG	Bajaj spare parts
JF113843	BRACKET HARNESS HOLDING	Bajaj spare parts
JF113844	BRACKET FLASHER INTERLOCK RELAY	Bajaj spare parts
JF113845	BRACKET COVER SIDE TANK	Bajaj spare parts
JF113846	BRACKET GUIDE HOSE ABS	Bajaj spare parts
JF113848	BRACKET RADIATOR LH	Bajaj spare parts
JF113849	BRACKET RADIATOR RH	Bajaj spare parts
JF113850	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
JF113851	CLAMP HOSE	Bajaj spare parts
JF113852	BRACKET UNIT ABS	Bajaj spare parts
JF113853	BRACKET VALVE PURGE	Bajaj spare parts
JF113854	BRACKET ABS	Bajaj spare parts
JF113855	BRACKET COVER SWITCH STAND SIDE	Bajaj spare parts
JF113857	BRACKET RELAY STARTER	Bajaj spare parts
JF113859	BRACKET VALVE PURGE-RELAY INTERLOCK	Bajaj spare parts
JF113861	BRACKET HORN	Bajaj spare parts
JF113869	HOLDER ECU	Bajaj spare parts
JF113871	INSULATOR FRAME	Bajaj spare parts
JF113876	BRACKET COVER SIDE	Bajaj spare parts
JF113877	BRACKET RELAY INTERLOCK	Bajaj spare parts
JF113879	DAMPER	Bajaj spare parts
JF113880	DAMPER	Bajaj spare parts
JF113887	BRACKET ASSEMBLY COVER TANK SIDE	Bajaj spare parts
JF113893	BRACKET RELAY INTERLOCK	Bajaj spare parts
JF113903	BRACKET ASSEMBLY LATCH SEAT	Bajaj spare parts
JF113910	CLAMP	Bajaj spare parts
JF113912	BRACKET ASSEMBLY UNIT SAI	Bajaj spare parts
JF113929	BRACKET ECU	Bajaj spare parts
JF121004	UNDER BRACKET ASSY COMP	Bajaj spare parts
JF121005	WHEEL CLAMP LH - K10	Bajaj spare parts
JF121006	WHEEL CLAMP RH - K10	Bajaj spare parts
JF121016	FORK OUTER TUBE - K10	Bajaj spare parts
JF121018	FORK ASSLY FRONT_GDC - K10	Bajaj spare parts
JF121020	UNDER BKT ASSLY COMP_GDC - K10	Bajaj spare parts
JF121022	LEG ASSLY LH_GDC - K10	Bajaj spare parts
JF121023	LEG ASSLY RH_GDC - K10	Bajaj spare parts
JF121029	FRONT FORK ASSLY - K10	Bajaj spare parts
JF121030	UPPER BRACKET-K10B	Bajaj spare parts
JF121033	ASSLY UNDER BKT COMP - K10	Bajaj spare parts
JF121034	LEG ASSLY LH - K10	Bajaj spare parts
JF121035	LEG ASSLY RH - K10	Bajaj spare parts
JF121036	FORK TUBE INNER - K10	Bajaj spare parts

JF121037	SPRING MAIN - K10	Bajaj spare parts
JF121038	TUBE SPACER - K10	Bajaj spare parts
JF121046	FORK ASSLY FRONT-ABS	Bajaj spare parts
JF121047	ASSLY UNDER BRACKET COMP-ABS	Bajaj spare parts
JF121049	SPACER SENSOR SPEED	Bajaj spare parts
JF121050	FORK FRONT	Bajaj spare parts
JF121051	FORK FRONT	Bajaj spare parts
JF121052	LEG ASSEMBLY LH	Bajaj spare parts
JF121053	LEG ASSEMBLY RH	Bajaj spare parts
JF121054	TUBE FORK OUTER LH	Bajaj spare parts
JF121055	TUBE FORK OUTER RH	Bajaj spare parts
JF121063	COVER TUBE FORK	Bajaj spare parts
JF121068	FORK FRONT	Bajaj spare parts
JF121069	BRACKET ASSEMBLY UNDER	Bajaj spare parts
JF121075	CLAMP HOSE	Bajaj spare parts
JF121093	BRACKET ASSEMBLY UNDER	Bajaj spare parts
JF121098	HOOK	Bajaj spare parts
JF122000	SHOCK ABSORBER REAR (K11)	Bajaj spare parts
JF122005	ASSLY SWING ARM	Bajaj spare parts
JF122006	CHAIN SLIDER (K11)	Bajaj spare parts
JF122013	SHOCKABSORBER MONO - K10	Bajaj spare parts
JF122014	CHAIN ADJUSTER - K10	Bajaj spare parts
JF122015	STUD CHAIN ADJUSTER - K10	Bajaj spare parts
JF122016	CHAIN SLIDER - K10	Bajaj spare parts
JF122028	BRACKET CHAIN COVER MIDDLE-K10	Bajaj spare parts
JF122049	ADJUSTER CHAIN	Bajaj spare parts
JF122069	SHOCKABSORBER REAR	Bajaj spare parts
JF122072	ARM ASSEMBLY SWING	Bajaj spare parts
JF122090	BRACKET SLIDER CHAIN	Bajaj spare parts
JF122104	CAP TUBE ARM SWING	Bajaj spare parts
JF122105	SLIDER CHAIN	Bajaj spare parts
JF122115	ADJUSTER CHAIN	Bajaj spare parts
JF122120	SHOCKABSORBER REAR	Bajaj spare parts
JF122128	ARM ASSEMBLY SWING	Bajaj spare parts
JF122134	SHOCKABSORBER REAR	Bajaj spare parts
JF122141	ARM ASSEMBLY SWING	Bajaj spare parts
JF131008	AXLE FRONT	Bajaj spare parts
JF131011	WHEEL FRONT 1.85X17 TL	Bajaj spare parts
JF131012	WHEEL FRONT 3.00 X 17 - K10	Bajaj spare parts
JF131016	SPACER FR WHEEL-K11	Bajaj spare parts
JF131018	ASSLY COLLAR FR WHEEL-K11	Bajaj spare parts
JF131020	COLLAR FR WHEEL - K16B ABS	Bajaj spare parts
JF131022	ASSLY COLLAR-FR WHEEL K16B	Bajaj spare parts
JF131024	AXLE-FRONT-M14X1.5XL214.5XBRIGHT	Bajaj spare parts
JF131026	WHEEL MT 3.00X17	Bajaj spare parts

JF131062	SPACER	Bajaj spare parts
JF131206	WHEEL REAR 2.15X17 (K11).	Bajaj spare parts
JF131209	SPACER PANNEL SIDE (K11)	Bajaj spare parts
JF131210	AXLE REAR	Bajaj spare parts
JF131212	SLEEVE	Bajaj spare parts
JF131217	WHEEL REAR 4.00 X 17 - K10	Bajaj spare parts
JF131233	WHEEL REAR MT 2.50X17	Bajaj spare parts
JF131236	AXLE-M14X1.5XL 310XOLIVE GREEN	Bajaj spare parts
JF131261	COUPLING	Bajaj spare parts
JF131600	CAM LEVER (K11)	Bajaj spare parts
JF131601	PANEL ASSLY (K11)	Bajaj spare parts
JF131800	DISC FRONT	Bajaj spare parts
JF131802	BRAKE HOSE	Bajaj spare parts
JF131803	DISC BRAKE KIT FRONT (K11)	Bajaj spare parts
JF131806	INTEGRAL CALIPER ASSLY (K11)	Bajaj spare parts
JF131807	MASTER CYLINDER ASSLY - K11	Bajaj spare parts
JF131814	MASTER CYL ASSLY REAR - K10	Bajaj spare parts
JF131816	ASSLY MASTER CYL FRONT - K10	Bajaj spare parts
JF131817	DISC FRONT DIA 320 - K10	Bajaj spare parts
JF131829	BRACKET HOSE CLAMP I - K10	Bajaj spare parts
JF131833	DISC FRONT DIA 260-K16B	Bajaj spare parts
JF131834	CALIPER ASSY BRAKE FRONT	Bajaj spare parts
JF131837	CYLINDER ASSEMBLY MASTER FRONT	Bajaj spare parts
JF131840	ABS UNIT -WET K10 2CH	Bajaj spare parts
JF131846	DISC FR DIA 300 NON ABS-K10	Bajaj spare parts
JF131848	BRACKET HOSE CLAMP -FENDER K10	Bajaj spare parts
JF131851	BRACKET BRAKE SWITCH REAR	Bajaj spare parts
JF131852	BRACKET ABS BRAKE HOSE CLAMP FR	Bajaj spare parts
JF131853	BRACKET HOSE CLAMP - ABS	Bajaj spare parts
JF131854	CLAMP W ABS HOSE-SPEED SENSOR	Bajaj spare parts
JF131855	BRACKET BRAKE FRT HOSE CLAMP BTM	Bajaj spare parts
JF131857	CALIPER ASSLY FRONT	Bajaj spare parts
JF131858	CALIPER ASSLY REAR	Bajaj spare parts
JF131859	CALIPER ASSLY FRONT	Bajaj spare parts
JF131860	CALIPER ASSLY REAR	Bajaj spare parts
JF131861	DISC DIA 230 REAR	Bajaj spare parts
JF131863	COVER CALIPER FRONT ABS	Bajaj spare parts
JF131864	COVER CALIPER FRONT	Bajaj spare parts
JF131871	CLIP SEPARATOR	Bajaj spare parts
JF131876	DISC BRAKE DIA 320	Bajaj spare parts
JF131878	HOSE BRAKE REAR	Bajaj spare parts
JF131888	CYLINDER MASTER ASSEMBLY REAR	Bajaj spare parts
JF131889	CYLINDER MASTER ASSEMBLY FRONT	Bajaj spare parts
JF131896	CLAMP HOSE BRAKE	Bajaj spare parts
JF131897	BRACKET ASSEMBLY HOSE	Bajaj spare parts

JF131900	KIT DISC BRAKE FRONT - K16B	Bajaj spare parts
JF131901	HOSE ASSLY FRONT BRAKE	Bajaj spare parts
JF131902	UNIT ABS WET	Bajaj spare parts
JF131906	CALIPER ASSEMBLY REAR	Bajaj spare parts
JF131907	CLAMP HOSE BRAKE	Bajaj spare parts
JF131912	UNIT ABS WET	Bajaj spare parts
JF131916	ROD BRAKE	Bajaj spare parts
JF131933	CYLINDER ASSEMBLY MASTER FRONT	Bajaj spare parts
JF131942	CLAMP ASSEMBLY	Bajaj spare parts
JF131951	UNIT ABS WET	Bajaj spare parts
JF131965	PAD	Bajaj spare parts
JF131975	GUIDE HOSE	Bajaj spare parts
JF141000	CHAIN O RING TYPE (K11)	Bajaj spare parts
JF141001	CHAIN DRIVE - K10	Bajaj spare parts
JF151018	FORK FRONT ASSLY(K11)	Bajaj spare parts
JF151019	BRACKET UPPER(K11)	Bajaj spare parts
JF151025	HANDLE HOLDER LH(K11)	Bajaj spare parts
JF151027	HANDLE HOLDER RH(K11)	Bajaj spare parts
JF151031	TUBE OUTER LH (K11)	Bajaj spare parts
JF151032	TUBE OUTER RH (K11)	Bajaj spare parts
JF151033	FORK PIPE SPINNING (K11)	Bajaj spare parts
JF151034	SPRING MAIN (K11)	Bajaj spare parts
JF151035	SEAT PIPE K11	Bajaj spare parts
JF151036	SPACER TUBE K11	Bajaj spare parts
JF151040	BRACKET UPPER - K10	Bajaj spare parts
JF151041	HANDLE BAR - K10	Bajaj spare parts
JF151042	HANDLE HOLDER UPPER - K10	Bajaj spare parts
JF151043	SPACER HANDLE HOLDER - K10	Bajaj spare parts
JF151044	DAMPER HANDLE HOLDER MTG-K10	Bajaj spare parts
JF151045	HANDLE HOLDER BOTTOM-K10	Bajaj spare parts
JF151046	HANDLE BAR DAMPER -K10	Bajaj spare parts
JF151047	WASHER CUP	Bajaj spare parts
JF151048	TAPE ANTI-ABRASIVE FR FORK	Bajaj spare parts
JF151051	ASSLY GRIP HANDLE RH	Bajaj spare parts
JF151054	DAMPER	Bajaj spare parts
JF151055	SPACER	Bajaj spare parts
JF161001	BRAKE PEDAL ASSLY-K11	Bajaj spare parts
JF161002	LEVER AND SUPPORT HOLDER ASSLY	Bajaj spare parts
JF161004	BRAKE RETURN SPRING - K10	Bajaj spare parts
JF161006	BRAKE PEDAL-K10 (2CH ABS)	Bajaj spare parts
JF161007	DAMPER BRAKE PEDAL - K10	Bajaj spare parts
JF161008	ASSLY -LEVER AND SPRT HOLDR	Bajaj spare parts
JF161009	ASSEMBLY PEDAL BRAKE	Bajaj spare parts
JF161013	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JF161014	HOLDER LEVER LH	Bajaj spare parts

JF161015	PEDAL ASSEMBLY BRAKE	Bajaj spare parts
JF161022	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JF161023	HOLDER LEVER LH	Bajaj spare parts
JF161024	BOOT LINK EQUALIZER	Bajaj spare parts
JF161027	PEDAL ASSEMBLY BRAKE	Bajaj spare parts
JF161028	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JF161032	DAMPER	Bajaj spare parts
JF161034	SLEEVE	Bajaj spare parts
JF161201	CABLE CLUTCH (K11)	Bajaj spare parts
JF161202	CABLE THROTTLE (K11)	Bajaj spare parts
JF161203	CABLE THROTTLE - K15	Bajaj spare parts
JF161204	CABLE CLUTCH - K10	Bajaj spare parts
JF161205	CABLE THROTTLE - K10	Bajaj spare parts
JF161206	THROTTLE CABLE (K16B)	Bajaj spare parts
JF161207	BRACKET -CABLE CLUTCH	Bajaj spare parts
JF161208	COLLAR-T-CABLE CLUTCH	Bajaj spare parts
JF161210	CABLE THROTTLE	Bajaj spare parts
JF161214	CABLE BRAKE	Bajaj spare parts
JF161216	CABLE THROTTLE	Bajaj spare parts
JF161220	CABLE THROTTLE	Bajaj spare parts
JF171001	ASSY TANK CENTRAL COVER (K11)	Bajaj spare parts
JF171004	BRACKET SIDE COVER MTG RH	Bajaj spare parts
JF171009	BKT SIDE COVER MTG LH - K11	Bajaj spare parts
JF171018	TANK TOP COVER - K10	Bajaj spare parts
JF171019	TANK CAP COVER - K10	Bajaj spare parts
JF171020	TANK SIDE COVER LH - K10	Bajaj spare parts
JF171021	TANK SIDE COVER RH - K10	Bajaj spare parts
JF171022	TANK CENTRAL COVER - K10	Bajaj spare parts
JF171023	TANK DAMPER TOP FRONT LH - K10	Bajaj spare parts
JF171024	TANK DAMPER TOP FRONT RH - K10	Bajaj spare parts
JF171025	TANK DAMPER TOP CENTRAL LH - K10	Bajaj spare parts
JF171026	TANK DAMPER TOP CENTRAL RH - K10	Bajaj spare parts
JF171028	BRACKET TANK COVER REAR - K10	Bajaj spare parts
JF171029	BEADING FUEL TANK - K10	Bajaj spare parts
JF171033	TANK ASSLY EVAP - K10	Bajaj spare parts
JF171035	BRACKET TANK SIDE COVER LH - K10	Bajaj spare parts
JF171036	BRACKET TANK SIDE COVER RH - K10	Bajaj spare parts
JF171037	BOLT SPCL TANK COVER MTG - K10	Bajaj spare parts
JF171043	BRACKET SECONDARY SPEEDO-K10	Bajaj spare parts
JF171047	GROMMET COVER -TANK	Bajaj spare parts
JF171048	COLLAR COVER -TANK	Bajaj spare parts
JF171051	ASSLY TUBE-CONNECTOR	Bajaj spare parts
JF171053	TUBE DRAIN	Bajaj spare parts
JF171054	DAMPER COVER-TANK-SIDE	Bajaj spare parts
JF171055	SLEEVE TANK MTG FRONT	Bajaj spare parts

JF171056	FOAM FUEL TANK	Bajaj spare parts
JF171057	PAD TANK COVER TOP	Bajaj spare parts
JF171058	TAPE ANTI ABRASIVE	Bajaj spare parts
JF171061	TANK ASSEMBLY	Bajaj spare parts
JF171064	BAND CABLE	Bajaj spare parts
JF171065	GROMMET	Bajaj spare parts
JF171066	COLLAR	Bajaj spare parts
JF171067	COLLAR	Bajaj spare parts
JF171068	GROMMET	Bajaj spare parts
JF171069	GROMMET	Bajaj spare parts
JF171072	TANK ASSLY FUEL	Bajaj spare parts
JF171073	TANK ASSLY FUEL	Bajaj spare parts
JF171083	BRACKET COVER TANK REAR	Bajaj spare parts
JF171087	BRACKET SPEEDOMETER	Bajaj spare parts
JF171093	DECAL DOME TANK	Bajaj spare parts
JF171094	DECAL DOME TANK CHARCOAL	Bajaj spare parts
JF171105	DECAL DOME TANK RACING RED	Bajaj spare parts
JF171603	TUBE TANK TO Y CONNECTOR - K10	Bajaj spare parts
JF171604	TUBE Y CONR TO CANISTER - K10	Bajaj spare parts
JF171605	TUBE PURGE VALVE TO CONNECOR - K10	Bajaj spare parts
JF171606	TUBE CONTR TO THROTTLE BODY - K10	Bajaj spare parts
JF171607	TUBE CONNECTOR TO PLUG - K10	Bajaj spare parts
JF171608	CAP TANK SINGLE TRACK KEY	Bajaj spare parts
JF171610	TUBE CONN TO PURGE VALVE-K16B	Bajaj spare parts
JF171613	TUBE CANISTER DRAIN	Bajaj spare parts
JF171619	PIPE CONNECTOR-BODY THROTTLE	Bajaj spare parts
JF171623	PIPE CANISTER-CONNECTOR	Bajaj spare parts
JF171624	PIPE CONNECTOR-VALVE PURGE	Bajaj spare parts
JF171625	PIPE VALVE PURGE-CONNECTOR	Bajaj spare parts
JF171641	PIPE FUEL	Bajaj spare parts
JF171650	PIPE FUEL	Bajaj spare parts
JF171657	PIPE FUEL	Bajaj spare parts
JF171800	TUBE FUEL - CARB	Bajaj spare parts
JF171802	ASSLY FUEL PUMP- K10	Bajaj spare parts
JF171804	TUBE CANISTER TO CONNECTOR	Bajaj spare parts
JF171805	TUBE PURGE VALVE TO CARB-K16B EVAP	Bajaj spare parts
JF171806	TUBE TANK TO Y-CONNECTOR-K16B EVAP	Bajaj spare parts
JF171807	TUBE CANISTER DRAIN -K16B	Bajaj spare parts
JF171811	PUMP FUEL	Bajaj spare parts
JF181001	SEAT COWL ASSY	Bajaj spare parts
JF181005	TUBE REAR HUGGER MTG (K11)	Bajaj spare parts
JF181210	LAMP SHADE ASSY(K11)	Bajaj spare parts
JF181211	CHAIN COVER ASSY (K11)	Bajaj spare parts
JF181216	SHROUD LH (K11)	Bajaj spare parts
JF181217	SHROUD RH (K11)	Bajaj spare parts



JF181241	SHROUD LH - K10	Bajaj spare parts
JF181244	SHROUD RH - K10	Bajaj spare parts
JF181253	ASSLY BATTERY CASE	Bajaj spare parts
JF181254	FOAM BATTERY CASE BOTTOM	Bajaj spare parts
JF181255	SHROUD LH (K16B)	Bajaj spare parts
JF181256	SHROUD RH (K16B)	Bajaj spare parts
JF181257	SHROUD CENTRE - K10	Bajaj spare parts
JF181262	SHROUD MTG BKT RH - K10	Bajaj spare parts
JF181265	BACK COVER CUM SPEEDO FLAP - K10	Bajaj spare parts
JF181266	MASK CARRIER - K10	Bajaj spare parts
JF181267	SIDE MASK LH - K10	Bajaj spare parts
JF181268	SIDE MASK RH - K10	Bajaj spare parts
JF181269	BRACKET SPEEDO MTG UPPER - K10	Bajaj spare parts
JF181270	BKT MASK CARRIER MTG LOWER - K10	Bajaj spare parts
JF181271	BRACKET NUMBER PLATE MTG - K10	Bajaj spare parts
JF181272	BATTERY CASE EPM 44	Bajaj spare parts
JF181275	DECAL MASK LH (K10)	Bajaj spare parts
JF181276	DECAL MASK RH (K10)	Bajaj spare parts
JF181277	WELL-NUT FOR MASK (K10)	Bajaj spare parts
JF181278	COLLAR	Bajaj spare parts
JF181282	BRACKET BKT ECU MTG LOWER-K10	Bajaj spare parts
JF181283	TUBE FORK COVER - K10	Bajaj spare parts
JF181284	COVER TRAIL - K10	Bajaj spare parts
JF181285	COVER CUSHION - K10	Bajaj spare parts
JF181286	BELLY PAN LH - K11 UG	Bajaj spare parts
JF181287	COWL OIL COOLER - K16B	Bajaj spare parts
JF181288	BELLY PAN RH -K11	Bajaj spare parts
JF181289	BRACKET BELLY PAN LH - K11	Bajaj spare parts
JF181290	BRACKET BELLY PAN RH - K11	Bajaj spare parts
JF181307	BRACKET REAR NO PLATE - K10	Bajaj spare parts
JF181308	RUBBER BATTERY CASE -K10	Bajaj spare parts
JF181309	BRACKET BELLY PAN	Bajaj spare parts
JF181311	BELLY PAN LH - K10	Bajaj spare parts
JF181312	BELLY PAN RH - K10	Bajaj spare parts
JF181313	BELLY PAN CENTER - K10	Bajaj spare parts
JF181314	ASSLY BELLY PAN - K10	Bajaj spare parts
JF181316	COLLAR -COVER CHAIN MOUNTING	Bajaj spare parts
JF181317	ASSLY UNDER TRAY FRONT	Bajaj spare parts
JF181320	COVER FRAME FRONT	Bajaj spare parts
JF181322	COVER ABS PAD	Bajaj spare parts
JF181323	FOAM BELLY PAN	Bajaj spare parts
JF181324	FOAM BELLY PAN	Bajaj spare parts
JF181328	COVER BRACKET RADIATOR	Bajaj spare parts
JF181329	FOAM BELLY PAN	Bajaj spare parts
JF181331	BRACKET BELLY PAN LH	Bajaj spare parts

JF181332	BRACKET BELLY PAN RH	Bajaj spare parts
JF181334	COVER SIDE LH	Bajaj spare parts
JF181335	COVER SIDE RH	Bajaj spare parts
JF181340	COVER ASSEMBLY CHAIN	Bajaj spare parts
JF181346	COVER FRAME FRONT	Bajaj spare parts
JF181348	CAP	Bajaj spare parts
JF181349	FOAM	Bajaj spare parts
JF181351	BELLY PAN MIDDLE	Bajaj spare parts
JF181352	STRUCTURE BELLY PAN LH	Bajaj spare parts
JF181353	STRUCTURE BELLY PAN RH	Bajaj spare parts
JF181354	BRACKET ASSEMBLY BELLY PAN FRONT	Bajaj spare parts
JF181355	BRACKET BELLY PAN REAR	Bajaj spare parts
JF181361	FOAM	Bajaj spare parts
JF181362	FOAM	Bajaj spare parts
JF181377	COVER ASSEMBLY CHAIN	Bajaj spare parts
JF181401	FENDER FRONT	Bajaj spare parts
JF181402	FENDER BRACE	Bajaj spare parts
JF181403	MUDFLAP -FRONT	Bajaj spare parts
JF181409	ASSLY HUGGER REAR (K11)	Bajaj spare parts
JF181420	FENDER REAR - K10	Bajaj spare parts
JF181421	UNDER TRAY FENDER REAR - K10	Bajaj spare parts
JF181422	REINFORCEMENT REAR FENDER - K10	Bajaj spare parts
JF181423	FLAP FENDER FRONT	Bajaj spare parts
JF181424	FLAP REAR FENDER - K10	Bajaj spare parts
JF181426	FLAP FENDER REAR	Bajaj spare parts
JF181429	FENDER BRACE - K10	Bajaj spare parts
JF181432	SLEEVE BRACE FENDER - K10	Bajaj spare parts
JF181433	SLEEVE FENDER MOUNTING - K10	Bajaj spare parts
JF181434	FLAP MUD FRONT FENDER-K10	Bajaj spare parts
JF181435	FENDER FR. MUD PROTECTOR-K16B	Bajaj spare parts
JF181464	FENDER HUGGER ASSEMBLY	Bajaj spare parts
JF181466	TUBE HUGGER	Bajaj spare parts
JF181467	COVER TUBE HUGGER I	Bajaj spare parts
JF181468	COVER TUBE HUGGER II	Bajaj spare parts
JF181471	PROTECTOR FORK LH	Bajaj spare parts
JF181472	PROTECTOR FORK RH	Bajaj spare parts
JF181473	COLLAR	Bajaj spare parts
JF181480	FLAP FENDER FRONT	Bajaj spare parts
JF181481	PROTECTOR FORK LH	Bajaj spare parts
JF181482	PROTECTOR FORK RH	Bajaj spare parts
JF181497	PROTECTOR FORK LH	Bajaj spare parts
JF181498	PROTECTOR FORK RH	Bajaj spare parts
JF181504	FLAP FENDER FRONT	Bajaj spare parts
JF181702	BELLY PAN LH	Bajaj spare parts
JF181703	BELLY PAN RH	Bajaj spare parts

JF181704	BELLY PAN ASSEMBY MIDDLE	Bajaj spare parts
JF181735	COVER LEVER BRAKE	Bajaj spare parts
JF181737	PLUG	Bajaj spare parts
JF181743	BRACKET BELLY PAN FRONT	Bajaj spare parts
JF181744	BRACKET BELLY PAN REAR	Bajaj spare parts
JF181759	STRUCTURE FAIRING	Bajaj spare parts
JF181783	BRACKET ASSEMBLY BELLY PAN FRONT	Bajaj spare parts
JF181784	BELLY PAN MIDDLE	Bajaj spare parts
JF191009	SEAT ASSLY FRONT - K10	Bajaj spare parts
JF191012	SEAT ASSLY REAR - K10	Bajaj spare parts
JF191016	GROMMET	Bajaj spare parts
JF191017	GROMMET	Bajaj spare parts
JF191018	DAMPER	Bajaj spare parts
JF231000	TOOLKIT	Bajaj spare parts
JF231010	TOOLKIT	Bajaj spare parts
JF231035	TOOLKIT	Bajaj spare parts
JF231201	GUARD LEG LH	Bajaj spare parts
JF231202	GUARD LEG RH	Bajaj spare parts
JF231203	GUARD SAREE (K11)	Bajaj spare parts
JF231207	GROMMET SAREE GUARD - K11	Bajaj spare parts
JF231208	GUARD SARI - K10	Bajaj spare parts
JF231209	GUARD LEG LH - K10	Bajaj spare parts
JF231210	GUARD LEG RH - K10	Bajaj spare parts
JF231211	PLUG SARI GUARD - K10	Bajaj spare parts
JF231214	GUARD LEG LH -K11 UG	Bajaj spare parts
JF231215	GUARD LEG RH - K11UG	Bajaj spare parts
JF231216	GUARD LEG LH - K10	Bajaj spare parts
JF231217	GUARD LEG RH - K10	Bajaj spare parts
JF231218	Guard Leg LH	Bajaj spare parts
JF231219	BUSH	Bajaj spare parts
JF231226	GUARD SAREE	Bajaj spare parts
JF231229	GUARD HAND LH UPPER	Bajaj spare parts
JF231232	GUARD HAND RH UPPER	Bajaj spare parts
JF231235	GUARD SADDLE LH	Bajaj spare parts
JF231236	GUARD SADDLE RH	Bajaj spare parts
JF231237	GUARD LEG LH	Bajaj spare parts
JF231238	GUARD LEG RH	Bajaj spare parts
JF231239	GUARD LEG LH	Bajaj spare parts
JF231240	GUARD LEG RH	Bajaj spare parts
JF231242	BRACKET GUARD HAND LH	Bajaj spare parts
JF231243	BRACKET GUARD HAND RH	Bajaj spare parts
JF231244	CLAMP GUARD HAND LH	Bajaj spare parts
JF231245	CLAMP GUARD HAND RH	Bajaj spare parts
JF231246	BRACKET LOWER LH	Bajaj spare parts
JF231247	BRACKET LOWER RH	Bajaj spare parts

JF231249	GUARD SAREE	Bajaj spare parts
JF231250	GUARD LEG LH	Bajaj spare parts
JF231251	GUARD LEG RH	Bajaj spare parts
JF231261	SPACER	Bajaj spare parts
JF231413	STRAP FRONT LH	Bajaj spare parts
JF231414	STRAP FRONT RH	Bajaj spare parts
JF231415	STRAP REAR	Bajaj spare parts
JF231417	BRACKET SOCKET CHARGER USB	Bajaj spare parts
JF231420	BASE ASSEMBLY BACKREST	Bajaj spare parts
JF231425	SPACER	Bajaj spare parts
JF231426	SPACER BRACKET	Bajaj spare parts
JF231608	MIRROR LH	Bajaj spare parts
JF231609	MIRROR RH	Bajaj spare parts
JF231612	MIRROR LH	Bajaj spare parts
JF231613	MIRROR RH	Bajaj spare parts
JF232000	WINDSHIELD	Bajaj spare parts
JF232001	CARRIER WINDSHIELD	Bajaj spare parts
JF232002	CARRIER UNIT NAVIGATION	Bajaj spare parts
JF232003	SPACER	Bajaj spare parts
JF232603	LOCK SET 3 IN 1 (K16B)	Bajaj spare parts
JF232606	LOCK SET 3-IN-1 (K11)	Bajaj spare parts
JF232607	LOCK SET 3-IN-1 ROUSER NS 150	Bajaj spare parts
JF232611	LOCK SET 3 IN 1 - K10	Bajaj spare parts
JF232612	SET LOCK	Bajaj spare parts
JF232615	SET LOCK	Bajaj spare parts
JF232616	SET LOCK	Bajaj spare parts
JF232618	SET LOCK	Bajaj spare parts
JF232632	SET LOCK	Bajaj spare parts
JF232805	BRACKET PLATE NUMBER REAR	Bajaj spare parts
JF232806	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JF232807	BRACKET PLATE NUMBER REAR	Bajaj spare parts
JF232808	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JF232828	BRACKET PLATE NUMBER INNER FRONT	Bajaj spare parts
JF232829	BRACKET PLATE NUMBER OUTER FRONT	Bajaj spare parts
JF232830	BRACKET REFLECTOR REFLEX REAR	Bajaj spare parts
JF233018	SEAT COWL DECAL UPPER	Bajaj spare parts
JF233021	SEAT COWL DECAL AS 150	Bajaj spare parts
JF233023	FENDER DECAL LH	Bajaj spare parts
JF233024	FENDER DECAL RH	Bajaj spare parts
JF233025	FENDER DECAL LH	Bajaj spare parts
JF233026	FENDER DECAL RH	Bajaj spare parts
JF233036	LABEL GEAR SHIFT 6 SPEED	Bajaj spare parts
JF233037	LABEL TYRE PRESSURE - K10	Bajaj spare parts
JF233049	DECAL TANK UPPER RH RED	Bajaj spare parts
JF233069	DECAL SIDE COVER LH BLUE	Bajaj spare parts

JF233072	DECAL SIDE COVER RH BLUE	Bajaj spare parts
JF233088	DECAL FENDER LH RED	Bajaj spare parts
JF233091	DECAL FENDER RH RED	Bajaj spare parts
JF233099	DECAL COWL SEAT BOTTOM 3D	Bajaj spare parts
JF233108	DECAL FENDER FRONT LH - NON ABS	Bajaj spare parts
JF233109	DECAL FENDER FRONT RH - NON ABS	Bajaj spare parts
JF233110	DECAL FENDER FRONT LH - NON ABS	Bajaj spare parts
JF233111	DECAL FENDER FRONT RH - NON ABS	Bajaj spare parts
JF233112	DECAL FENDER FRONT LH - NON ABS	Bajaj spare parts
JF233113	DECAL FENDER FRONT RH - NON ABS	Bajaj spare parts
JF233118	DECAL TANK 3D-DOMINAR	Bajaj spare parts
JF233124	DECAL SHROUD-OIL COOLED	Bajaj spare parts
JF233133	DECAL COVER SIDE LH-BLUE	Bajaj spare parts
JF233139	DECAL COVER TANK LH-160	Bajaj spare parts
JF233140	DECAL COVER TANK RH-160	Bajaj spare parts
JF233154	DECAL COVER SIDE LH GREY-BLACK	Bajaj spare parts
JF233155	DECAL COVER SIDE RH GREY-BLACK	Bajaj spare parts
JF233189	DECAL FENDER RH G GREEN	Bajaj spare parts
JF233193	DECAL COWL SEAT RH	Bajaj spare parts
JF233198	DECAL 3D	Bajaj spare parts
JF233199	DECAL 3D COWL SEAT	Bajaj spare parts
JF233218	DECAL COVER MAGNETO	Bajaj spare parts
JF233219	DECAL COVER CLUTCH	Bajaj spare parts
JF233222	DECAL FENDER FRONT LH G GREEN	Bajaj spare parts
JF233223	DECAL BELLY PAN RH G GREEN	Bajaj spare parts
JF233230	DECAL COWL SEAT UPPER LH BLACK	Bajaj spare parts
JF233231	DECAL COWL SEAT UPPER RH BLACK	Bajaj spare parts
JF233234	DECAL RING COVER MAGNETO	Bajaj spare parts
JF233235	DECAL RING COVER CLUTCH	Bajaj spare parts
JF233237	DECAL BELLY PAN LH CHARCOAL	Bajaj spare parts
JF233238	DECAL BELLY PAN RH CHARCOAL	Bajaj spare parts
JF233244	DECAL 3D COWL SEAT	Bajaj spare parts
JF233245	DECAL COVER CLUTCH	Bajaj spare parts
JF233253	DECAL COVER SIDE LH BLUE BLACK	Bajaj spare parts
JF233254	DECAL COVER SIDE LH GREY BLACK	Bajaj spare parts
JF233256	DECAL BELLY PAN LH RACING RED	Bajaj spare parts
JF233257	DECAL BELLY PAN RH RACING RED	Bajaj spare parts
JF233286	DECAL COVER TANK LOWER LH	Bajaj spare parts
JF233287	DECAL COVER TANK LOWER RH	Bajaj spare parts
JF233288	EMBLEM FUEL INJECTION LH	Bajaj spare parts
JF233289	EMBLEM FUEL INJECTION RH	Bajaj spare parts
JF233296	DECAL COWL SEAT MIDDLE FL YELLOW	Bajaj spare parts
JF233297	DECAL COWL SEAT MIDDLE BURNT RED	Bajaj spare parts
JF233299	DECAL COWL SEAT MIDDLE PL BLUE	Bajaj spare parts
JF233300	DECAL FENDER FRONT LH	Bajaj spare parts

JF233301	DECAL FENDER FRONT RH	Bajaj spare parts
JF233308	DECAL 3D TANK	Bajaj spare parts
JF233309	DECAL COVER CLUTCH	Bajaj spare parts
JF233310	DECAL COVER MAGNETO	Bajaj spare parts
JF233313	DECAL BELLY PAN LH BURNT RED	Bajaj spare parts
JF233314	DECAL BELLY PAN RH BURNT RED	Bajaj spare parts
JF233325	DECAL COVER SIDE LWR LH F ORANGE	Bajaj spare parts
JF233326	DECAL COVER SIDE LWR RH F ORANGE	Bajaj spare parts
JF233328	DECAL COVER SIDE LWR LH BURNT RED	Bajaj spare parts
JF233329	DECAL COVER SIDE LWR RH BURNT RED	Bajaj spare parts
JF233330	DECAL COVER SIDE LWR LH PTR GREY	Bajaj spare parts
JF233331	DECAL COVER SIDE LWR LH B BLUE	Bajaj spare parts
JF233332	DECAL COVER SIDE LWR RH B BLUE	Bajaj spare parts
JF233333	DECAL COVER SIDE LWR RH PTR GREY	Bajaj spare parts
JF233342	DECAL COVER SIDE LOWER LH P GREY	Bajaj spare parts
JF233343	DECAL COVER SIDE LOWER RH P GREY	Bajaj spare parts
JF233344	DECAL COVER SIDE LWR LH M WHITE	Bajaj spare parts
JF233345	DECAL COVER SIDE LWR RH M WHITE	Bajaj spare parts
JF233349	DECAL BELLY PAN LH PEWTER GREY	Bajaj spare parts
JF233350	DECAL BELLY PAN RH PEWTER GREY	Bajaj spare parts
JF233362	DECAL WINDSHIELD LH	Bajaj spare parts
JF233363	DECAL WINDSHIELD RH	Bajaj spare parts
JF233378	DECAL BELLY PAN LH FIERY ORANGE	Bajaj spare parts
JF233379	DECAL BELLY PAN RH FIERY ORANGE	Bajaj spare parts
JF233380	DECAL BELLY PAN LH BEACH BLUE	Bajaj spare parts
JF233381	DECAL BELLY PAN RH BEACH BLUE	Bajaj spare parts
JF233389	DECAL COVER TANK LOWER LH	Bajaj spare parts
JF233390	DECAL COVER TANK LOWER RH	Bajaj spare parts
JF233396	DECAL WINDSHIELD LH CHARCOAL BLK	Bajaj spare parts
JF233397	DECAL WINDSHIELD RH CHARCOAL BLK	Bajaj spare parts
JF233398	DECAL WINDSHIELD LH RACING RED	Bajaj spare parts
JF233399	DECAL WINDSHIELD RH RACING RED	Bajaj spare parts
JF233418	DECAL BELLY PAN RACING RED LH	Bajaj spare parts
JF233419	DECAL BELLY PAN RACING RED RH	Bajaj spare parts
JF233432	DECAL FAIRING RACING RED LH	Bajaj spare parts
JF233433	DECAL FAIRING RACING RED RH	Bajaj spare parts
JF233457	DECAL WHEEL FRONT PEWTER GREY LH	Bajaj spare parts
JF233458	DECAL WHEEL FRONT PEWTER GREY RH	Bajaj spare parts
JF233459	DECAL BELLY PAN PEWTER GREY LH	Bajaj spare parts
JF233460	DECAL BELLY PAN PEWTER GREY RH	Bajaj spare parts
JF233461	DECAL BELLY PAN S BLACK LH	Bajaj spare parts
JF233462	DECAL BELLY PAN S BLACK RH	Bajaj spare parts
JF233463	DECAL COWL SEAT S BLK SILVER LH	Bajaj spare parts
JF233464	DECAL COWL SEAT S BLK SILVER RH	Bajaj spare parts
JF233465	DECAL COVER TANK UPR S SILVER LH	Bajaj spare parts

JF233466	DECAL COVER TANK UPR S SILVER RH	Bajaj spare parts
JF233467	DECAL COVER TANK S BLACK LH	Bajaj spare parts
JF233468	DECAL COVER TANK S BLACK RH	Bajaj spare parts
JF233469	DECAL FAIRING SPARKLING BLACK LH	Bajaj spare parts
JF233470	DECAL FAIRING SPARKLING BLACK RH	Bajaj spare parts
JF233471	DECAL WHEEL SPARKLING BLACK LH	Bajaj spare parts
JF233472	DECAL WHEEL SPARKLING BLACK RH	Bajaj spare parts
JF233473	DECAL DOME TANK SPARKLING BLACK	Bajaj spare parts
JF233474	DECAL BELLY PAN C R-P SILVER LH	Bajaj spare parts
JF233475	DECAL BELLY PAN C R-P SILVER RH	Bajaj spare parts
JF233476	DECAL COWL SEAT C R-P SILVER LH	Bajaj spare parts
JF233477	DECAL COWL SEAT C R-P SILVER RH	Bajaj spare parts
JF233478	DECAL COVER TANK UPR C R-P SL LH	Bajaj spare parts
JF233479	DECAL COVER TANK UPR C R-P SL RH	Bajaj spare parts
JF233480	DECAL COVER TANK C R-P SILVER LH	Bajaj spare parts
JF233481	DECAL COVER TANK C R-P SILVER RH	Bajaj spare parts
JF233482	DECAL FAIRING C R-P SILVER LH	Bajaj spare parts
JF233483	DECAL FAIRING C R-P SILVER RH	Bajaj spare parts
JF233484	DECAL WHEEL C R-P SILVER LH	Bajaj spare parts
JF233485	DECAL WHEEL C R-P SILVER RH	Bajaj spare parts
JF233486	DECAL COWL SEAT R R-P SILVER LH	Bajaj spare parts
JF233487	DECAL COWL SEAT R R-P SILVER RH	Bajaj spare parts
JF233488	DECAL COVER TANK UPR R R-P SL LH	Bajaj spare parts
JF233489	DECAL COVER TANK UPR R R-P SL RH	Bajaj spare parts
JF233490	DECAL COVER TANK R R-P SILVER LH	Bajaj spare parts
JF233491	DECAL COVER TANK R R-P SILVER RH	Bajaj spare parts
JF233492	DECAL WHEEL R R-P SILVER LH	Bajaj spare parts
JF233493	DECAL WHEEL R R-P SILVER RH	Bajaj spare parts
JF233494	DECAL DOME TANK C R-P SILVER	Bajaj spare parts
JF233496	DECAL WHEEL C R MATTE BLACK LH	Bajaj spare parts
JF233497	DECAL WHEEL C R MATTE BLACK RH	Bajaj spare parts
JF233498	DECAL WHEEL S BLACK M BLACK LH	Bajaj spare parts
JF233499	DECAL WHEEL S BLACK M BLACK RH	Bajaj spare parts
JF233500	DECAL WHEEL R RED MATTE BLACK LH	Bajaj spare parts
JF233501	DECAL WHEEL R RED MATTE BLACK RH	Bajaj spare parts
JF233560	DECAL COVER CLUTCH	Bajaj spare parts
JF233565	DECAL COVER MAGNETO	Bajaj spare parts
JF233603	DECAL WHEEL LH	Bajaj spare parts
JF233604	DECAL WHEEL RH	Bajaj spare parts
JF233611	DECAL PULSAR	Bajaj spare parts
JF351011	STATOR ASSLY COMPLETE	Bajaj spare parts
JF351013	ROTOR ASSLY WITHOUT CLUTCH	Bajaj spare parts
JF351014	BODY CLUTCH STARTER	Bajaj spare parts
JF351016	STATOR ASSLY	Bajaj spare parts
JF351022	STATOR ASSEMBLY	Bajaj spare parts

JF351206	GROMMET SPARK PLUG	Bajaj spare parts
JF351208	KIT HT COIL 1 WITH CAP	Bajaj spare parts
JF351210	KIT HT COIL 2 WITH CAP	Bajaj spare parts
JF351212	SPARK PLUG CAP	Bajaj spare parts
JF351213	COIL ASSEMBLY IGNITION LH	Bajaj spare parts
JF351216	COIL IGNITION	Bajaj spare parts
JF351219	COIL ASSEMBLY IGNITION	Bajaj spare parts
JF351404	EPM44 MTB SERIES_NON CAN	Bajaj spare parts
JF351427	ECU EMS ASSEMBLY	Bajaj spare parts
JF351430	ECU EMS ASSEMBLY	Bajaj spare parts
JF351439	ECU EMS ASSEMBLY	Bajaj spare parts
JF351600	STARTER MOTOR	Bajaj spare parts
JF351801	PIGTAIL OIL PRESS SW & TEMP SENSOR	Bajaj spare parts
JF351804	SENSOR ASSEMBLY PICK UP	Bajaj spare parts
JF351805	SENSOR ASSEMBLY PICK UP	Bajaj spare parts
JF401013	LAMP NO PLATE ILLUMINATION	Bajaj spare parts
JF401016	LAMP REAR NUMBER PLATE ILLUM	Bajaj spare parts
JF401017	HEAD LAMP ASSLY (K11)	Bajaj spare parts
JF401021	REFLECTOR REFLEX FRONT	Bajaj spare parts
JF401022	LAMP TAIL	Bajaj spare parts
JF401030	REFLECTOR REFLEX LH	Bajaj spare parts
JF401031	REFLECTOR REFLEX RH	Bajaj spare parts
JF401400	CONTROL SWITCH LH	Bajaj spare parts
JF401401	CONTROL SWITCH RH	Bajaj spare parts
JF401405	SIDE STAND SWITCH - K10	Bajaj spare parts
JF401408	SWITCH CONTROL LH - K10	Bajaj spare parts
JF401410	SWITCH CONTROL LH	Bajaj spare parts
JF401411	SWITCH CONTROL RH	Bajaj spare parts
JF401413	SWITCH CONTROL LH	Bajaj spare parts
JF401414	SWITCH CONTROL RH	Bajaj spare parts
JF401415	SWITCH STAND SIDE	Bajaj spare parts
JF401416	SWITCH CONTROL LH	Bajaj spare parts
JF401417	SWITCH CONTROL RH	Bajaj spare parts
JF401421	SWITCH CONTROL RH	Bajaj spare parts
JF401600	HORN K16B UG	Bajaj spare parts
JF401601	HORN	Bajaj spare parts
JF401802	BATTERY BAND	Bajaj spare parts
JF401808	4AH VRLA DRY ONLY ACID BOTTLE	Bajaj spare parts
JF401809	LID CAP BATTERY-4 AH	Bajaj spare parts
JF402000	REGULATOR ASSLY	Bajaj spare parts
JF402004	REGULATOR ASSLY	Bajaj spare parts
JF402006	UNIT REGULATOR	Bajaj spare parts
JF402201	EARTH CABLE-BATTERY TO EARTH	Bajaj spare parts
JF402203	HARNESS WIRING (K11)	Bajaj spare parts
JF402209	HARNESS WIRING- K16B	Bajaj spare parts



JF402211	CABLE EARTH - K10	Bajaj spare parts
JF402212	CABLE STARTER RELAY TO MOTOR-K10	Bajaj spare parts
JF402216	HARNESS WIRING AHO-K16B	Bajaj spare parts
JF402217	WIRING HARNESS W/O LCM-K16B	Bajaj spare parts
JF402223	HARNESS WIRING K11 AHO WVTA	Bajaj spare parts
JF402227	HARNESS WIRING- K11 (NON TPS)	Bajaj spare parts
JF402231	HARNESS WIRING-K11 AHO (NON-TPS)	Bajaj spare parts
JF402234	MAGNETO PIGTAIL TO RR - K10	Bajaj spare parts
JF402235	WIRING HARNESS NON ABS	Bajaj spare parts
JF402237	WIRING HARNESS K11UG FI	Bajaj spare parts
JF402238	HARNESS WIRING K11 UG FI ABS	Bajaj spare parts
JF402242	CABLE EARTH BATTERY	Bajaj spare parts
JF402243	CABLE EARTH ENGINE	Bajaj spare parts
JF402245	HARNESS WIRING ABS	Bajaj spare parts
JF402247	HARNESS WIRING	Bajaj spare parts
JF402248	HARNESS WIRING	Bajaj spare parts
JF402249	HARNESS WIRING	Bajaj spare parts
JF402250	HARNESS WIRING ABS	Bajaj spare parts
JF402252	HARNESS WIRING ABS	Bajaj spare parts
JF402264	HARNESS WIRING	Bajaj spare parts
JF402270	CABLE BATTERY NEGATIVE	Bajaj spare parts
JF402272	CABLE PUMP FUEL	Bajaj spare parts
JF402276	HARNESS WIRING	Bajaj spare parts
JF402280	HARNESS WIRING	Bajaj spare parts
JF402286	HARNESS WIRING	Bajaj spare parts
JF402293	HARNESS WIRING	Bajaj spare parts
JF402301	HARNESS WIRING	Bajaj spare parts
JF402328	HARNESS WIRING	Bajaj spare parts
JF402330	HARNESS WIRING	Bajaj spare parts
JF402332	CABLE BATTERY NEGATIVE	Bajaj spare parts
JF402359	HARNESS WIRING	Bajaj spare parts
JF402363	HARNESS WIRING	Bajaj spare parts
JF402364	HARNESS WIRING	Bajaj spare parts
JF402400	SPEEDOMETER ASSY	Bajaj spare parts
JF402404	SPEED SENSOR (K16B)	Bajaj spare parts
JF402405	ASSLY SPEED SENSOR - K16B	Bajaj spare parts
JF402406	SPEEDOMETER ASSLY - K10	Bajaj spare parts
JF402407	SPEEDOMETER TANK ASSLY - K10	Bajaj spare parts
JF402408	SPEEDOMETER ABS-K11	Bajaj spare parts
JF402409	SPEEDO METER ASSLY NON ABS	Bajaj spare parts
JF402410	SPEEDO METER ASSLY TANK NON ABS	Bajaj spare parts
JF402411	SPEEDOMETER ASSLY FOR K11&K16B UG FI	Bajaj spare parts
JF402412	SPEEDOMETER ASSLY FOR K11&K16B UG FI-	Bajaj spare parts
JF402413	SENSOR SPEED-VEHICLE	Bajaj spare parts
JF402415	FOAM	Bajaj spare parts

JF402416	SPEEDOMETER	Bajaj spare parts
JF402417	SPEEDOMETER	Bajaj spare parts
JF402418	SPEEDOMETER	Bajaj spare parts
JF402422	SPEEDOMETER	Bajaj spare parts
JF402426	SPEEDOMETER	Bajaj spare parts
JF402428	SPEEDOMETER	Bajaj spare parts
JF402429	INSTRUMENT CLUSTER	Bajaj spare parts
JF402441	INSTRUMENT CLUSTER	Bajaj spare parts
JF402602	CONSOLE TELL TALE	Bajaj spare parts
JF403000	RELAY INTERLOCK	Bajaj spare parts
JF403400	SOCKET CHARGER	Bajaj spare parts
JF501011	ASSLY ENGINE_400CS	Bajaj spare parts
JF501015	ENGINE ASSLY	Bajaj spare parts
JF501021	ENGINE ASSEMBLY	Bajaj spare parts
JF501025	ENGINE ASSEMBLY	Bajaj spare parts
JF501063	ENGINE ASSEMBLY	Bajaj spare parts
JF511040	BREATHER GASKET	Bajaj spare parts
JF511041	HEAD COVER ASSLY	Bajaj spare parts
JF511042	ROCKER SHAFT	Bajaj spare parts
JF511046	HEAD COVER GASKET	Bajaj spare parts
JF511049	GASKET CYLINDER HEAD	Bajaj spare parts
JF511050	CAM GALLERY PLUG	Bajaj spare parts
JF511052	SLEEVE SPARK PLUG	Bajaj spare parts
JF511058	HEAD CYLINDER-HOLDER CAMSHAFT	Bajaj spare parts
JF511099	PIPE UNIT SAI	Bajaj spare parts
JF511104	BRACKET	Bajaj spare parts
JF511204	VALVE INTAKE	Bajaj spare parts
JF511207	PLATE STOPPER ROCKER ARM	Bajaj spare parts
JF511208	VALVE EXHAUST	Bajaj spare parts
JF511214	RETAINER VALVE SPRING	Bajaj spare parts
JF511215	SEAT VALVE SPRING	Bajaj spare parts
JF511217	VALVE SPRING	Bajaj spare parts
JF511222	ASSLY CAMSHAFT	Bajaj spare parts
JF511223	CHAIN SILENT	Bajaj spare parts
JF511228	ASSLY CAMSHAFT	Bajaj spare parts
JF511233	ASSLY ROCKER ARM INTAKE	Bajaj spare parts
JF511234	ASSLY ROCKER ARM EXHAUST	Bajaj spare parts
JF511235	SPROCKET CAMSHAFT	Bajaj spare parts
JF511240	CAMSHAFT COLLAR	Bajaj spare parts
JF511248	COLLAR DECOMP	Bajaj spare parts
JF511249	TENSIONER ASSLY	Bajaj spare parts
JF511250	SPRING VALVE	Bajaj spare parts
JF511251	SEAT SPRING VALVE	Bajaj spare parts
JF511253	CAMSHAFT ASSLY INTAKE	Bajaj spare parts
JF511254	CAMSHAFT INTAKE	Bajaj spare parts

JF511255	CAMSHAFT ASSLY EXHAUST	Bajaj spare parts
JF511257	SEAT SPRING VALVE	Bajaj spare parts
JF511258	CAMSHAFT ASSEMBLY INTAKE	Bajaj spare parts
JF511260	CAMSHAFT ASSEMBLY EXHAUST	Bajaj spare parts
JF521009	BLOCK CYLINDER	Bajaj spare parts
JF521200	PISTON ASSEMBLY	Bajaj spare parts
JF521210	PISTON ASSLY	Bajaj spare parts
JF521216	PISTON ASSLY	Bajaj spare parts
JF521300	CIRCLIP PISTON PIN	Bajaj spare parts
JF531007	CONROD ASSLY COMPL	Bajaj spare parts
JF531014	BOLT (JF CON ROD)	Bajaj spare parts
JF531017	SPROCKET CRANKSHAFT	Bajaj spare parts
JF531019	CRANKSHAFT ASSEMBLY	Bajaj spare parts
JF531020	CRANKSHAFT ASSLY COMP	Bajaj spare parts
JF531021	BALANCER DRIVE GEAR	Bajaj spare parts
JF531206	SPRING	Bajaj spare parts
JF531213	SCISSOR GEAR ASSLY	Bajaj spare parts
JF531214	BALANCER ASSEMBLY	Bajaj spare parts
JF541016	NOZZLE	Bajaj spare parts
JF541017	BRACKET	Bajaj spare parts
JF541204	BRACKET CLUTCH CABLE	Bajaj spare parts
JF541208	SHAFT CLUTCH RELEASE ASSLY	Bajaj spare parts
JF541210	SPRING CLUTCH LEVER	Bajaj spare parts
JF541211	LABEL COVER	Bajaj spare parts
JF541212	LABEL BAJAJ	Bajaj spare parts
JF551411	GEAR PRIMARY DRIVEN ASSLY	Bajaj spare parts
JF551412	CLUTCH OUTER COMP.	Bajaj spare parts
JF551419	CLUTCH ASSLY	Bajaj spare parts
JF551420	PLATE ASSLY CLUTCH	Bajaj spare parts
JF551422	CLUTCH ASSEMBLY	Bajaj spare parts
JF551500	ASSLY CLUTCH	Bajaj spare parts
JF561000	DRUM GEAR SHIFT	Bajaj spare parts
JF561001	SHAFT OUTPUT FORK SHIFT	Bajaj spare parts
JF561204	ARM CHANGE ARM WITH BALL JOINT	Bajaj spare parts
JF561205	ASSLY SHIFT LEVER- BALL JOINT	Bajaj spare parts
JF561208	LEVER ASSEMBLY CHANGE	Bajaj spare parts
JF561408	CHANGE ARM ASSLY - K10	Bajaj spare parts
JF561410	LEVER CHANGE ASSLY- K10	Bajaj spare parts
JF561415	ARM CHANGE BALL JOINT ASSLY	Bajaj spare parts
JF561416	LEVER SHIFT BALL JOINT ASSLY	Bajaj spare parts
JF561418	ROD TIE NUT ASSLY BJ	Bajaj spare parts
JF561422	ARM CHANGE	Bajaj spare parts
JF561424	LEVER ASSEMBLY CHANGE	Bajaj spare parts
JF561426	ARM ASSEMBLY CHANGE	Bajaj spare parts
JF581022	ENTRY DUCT	Bajaj spare parts

JF581026	CLAMP BREATHER PIPE	Bajaj spare parts
JF581029	FILTER ASSLY AIR	Bajaj spare parts
JF581031	TUBE BREATHER	Bajaj spare parts
JF581035	FILTER ASSEMBLY AIR	Bajaj spare parts
JF581066	FILTER ASSEMBLY AIR	Bajaj spare parts
JF581209	CLAMP CONNECTING SIDE	Bajaj spare parts
JF581408	PIPE INTAKE	Bajaj spare parts
JF582200	UNIT SAI	Bajaj spare parts
JF582400	PIPE UNIT SAI	Bajaj spare parts
JF591033	SHIELD	Bajaj spare parts
JF591053	CAP	Bajaj spare parts
JF591065	MUFFLER ASSLY COMPLETE	Bajaj spare parts
JF591099	ASSEMBLY MUFFLER	Bajaj spare parts
JF591116	PIPE A ASSLY	Bajaj spare parts
JF591120	END CAHMBER ASSLY COMPLETE	Bajaj spare parts
JF591134	GASKET	Bajaj spare parts
JF591135	CLAMP	Bajaj spare parts
JF591182	MUFFLER ASSEMBLY	Bajaj spare parts
JF591211	CAP END	Bajaj spare parts
JF591213	PIPE ASSEMBLY COMPLETE	Bajaj spare parts
JF591222	SHIELD MUFFLER	Bajaj spare parts
JF591241	ASSEMBLY PIPE	Bajaj spare parts
JF591242	GASKET EXHAUST	Bajaj spare parts
JF591245	SHIELD	Bajaj spare parts
JF591304	PIPE ASSEMBLY	Bajaj spare parts
JF591334	COLLAR	Bajaj spare parts
JF591339	PIPE ASSEMBLY	Bajaj spare parts
JF591342	PIPE ASSEMBLY	Bajaj spare parts
JF591362	PIPE ASSEMBLY	Bajaj spare parts
JF591363	PIPE ASSEMBLY A	Bajaj spare parts
JF601201	ASSLY RADIATOR	Bajaj spare parts
JF601202	HOSE RADIATOR TO PIPE T	Bajaj spare parts
JF601203	HOSE RADIATOR TO THERMOSTAT	Bajaj spare parts
JF601205	RADIATOR CORE	Bajaj spare parts
JF601210	PIPE THERMOSTAT-JOINT T	Bajaj spare parts
JF601211	JOINT ASSEMBLY T	Bajaj spare parts
JF601213	PIPE CONNECTOR-RADIATOR	Bajaj spare parts
JF601215	RADIATOR	Bajaj spare parts
JF601219	TANK ASSEMBLY EXPANSION	Bajaj spare parts
JF601220	PIPE TANK EXPANSION	Bajaj spare parts
JF601400	ASSLY FAN SHROUD	Bajaj spare parts
JF611201	INJECTOR CAP WITH QUICK CONNCTOR	Bajaj spare parts
JF611202	ASSLY THROTTLE BODY_PHASE-III	Bajaj spare parts
JF611203	ASSLY THROTTLE BODY_EVAP_PHASE-III	Bajaj spare parts
JF611206	BODY THROTTLE ASSEMBLY	Bajaj spare parts

JF611207	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
JF990409	UNIT ABS WET	Bajaj spare parts
JF990410	BRACKET SLIDER CHAIN	Bajaj spare parts
JG111139	HOOK BRACKET ABS HOSE	Bajaj spare parts
JG111147	FRAME ASSLY KT03	Bajaj spare parts
JG111151	BRACKET ASSY DC FLASHER MTG	Bajaj spare parts
JG111154	FRAME ASSEMBLY	Bajaj spare parts
JG111319	SPACER	Bajaj spare parts
JG113001	HOLDER STEP LH	Bajaj spare parts
JG113005	MAIN STEP LH	Bajaj spare parts
JG113007	SPRING TORSION	Bajaj spare parts
JG113010	DAMPER CHANGE LEVER	Bajaj spare parts
JG113020	PILLION STEP LH	Bajaj spare parts
JG113024	HOLDER STEP RH	Bajaj spare parts
JG113029	PILLION STEP RH	Bajaj spare parts
JG113031	IGUS BUSH-CHANGE LEVER	Bajaj spare parts
JG113034	LOCK PLATE 1	Bajaj spare parts
JG113035	LOCK PLATE 2	Bajaj spare parts
JG113043	PIN FOOTREST PIVOT	Bajaj spare parts
JG113050	ASSEMBLY TIE ROD	Bajaj spare parts
JG113052	BOLT	Bajaj spare parts
JG113060	SPACER CHANGE LEVER	Bajaj spare parts
JG113061	BEARING CHANGE LEVER	Bajaj spare parts
JG113062	WASHER CHANGE LEVER	Bajaj spare parts
JG113063	BOLT CHANGE LEVER	Bajaj spare parts
JG113068	BOLT CHANGE LEVER	Bajaj spare parts
JG113078	COVER DUST TIE ROD	Bajaj spare parts
JG113081	HOLDER STEP PILLION LH	Bajaj spare parts
JG113083	HOLDER STEP PILLION RH	Bajaj spare parts
JG113084	HOLDER STEP RIDER LH	Bajaj spare parts
JG113085	HOLDER STEP RIDER RH	Bajaj spare parts
JG113086	GUARD HEEL RIDER LH	Bajaj spare parts
JG113087	GUARD HEEL RIDER RH	Bajaj spare parts
JG113088	GUARD HEEL PILLION LH	Bajaj spare parts
JG113089	GUARD HEEL PILLION RH	Bajaj spare parts
JG113090	STEP RIDER LH	Bajaj spare parts
JG113091	DAMPER STEP RH	Bajaj spare parts
JG113092	STEP RIDER RH	Bajaj spare parts
JG113096	BRACKET STEP RIDER	Bajaj spare parts
JG113097	PLATE STEP RIDER	Bajaj spare parts
JG113098	BRACKET STEP PILLION	Bajaj spare parts
JG113101	DAMPER STEP LH	Bajaj spare parts
JG113102	GUIDE CHAIN	Bajaj spare parts
JG113103	SPACER GUIDE CHAIN	Bajaj spare parts
JG113104	SPACER	Bajaj spare parts

JG113203	SIDE STAND	Bajaj spare parts
JG113204	PLATE -SIDE STAND	Bajaj spare parts
JG113207	BOLT	Bajaj spare parts
JG113210	GUARD SIDE STAND SWITCH	Bajaj spare parts
JG113212	STAND ASSEMBLY SIDE	Bajaj spare parts
JG113213	PLATE STAND SIDE	Bajaj spare parts
JG113215	BRACKET HOLDER MAGNET	Bajaj spare parts
JG113216	BRACKET HOLDER MAGNET	Bajaj spare parts
JG113221	STAND ASSEMBLY SIDE	Bajaj spare parts
JG113400	ENGINE STAY LH	Bajaj spare parts
JG113401	ENGINE STAY RH	Bajaj spare parts
JG113403	BOLT FLANGE M10X110	Bajaj spare parts
JG113404	CLIP NUT	Bajaj spare parts
JG113406	BOLT ENGINE HANGER	Bajaj spare parts
JG113407	BOLT FLANGE M8	Bajaj spare parts
JG113800	DUMBLE SPACERS	Bajaj spare parts
JG113802	SPACER-CHAIN TENSIONER MTG	Bajaj spare parts
JG113804	BKT RAD MTG LH ON ENG HANGER	Bajaj spare parts
JG113805	BKT RAD MTG RH ON ENG HANGER	Bajaj spare parts
JG113806	GROMMET EXPANSION TANK	Bajaj spare parts
JG113808	BKT LOCATOR-LH RIDER SEAT	Bajaj spare parts
JG113809	BET LOCATOR-RH RIDER SEAT	Bajaj spare parts
JG113813	BKT SIDE STAND SWITCH CABLE	Bajaj spare parts
JG113814	FRONT GUIDE BKT FOR RR HOSE	Bajaj spare parts
JG113815	REAR GUIDE BKT FOR RR HOSE	Bajaj spare parts
JG113816	BKT FOR TUBE DRAIN	Bajaj spare parts
JG113820	HARNESS PROCTECTOR SHEATHE	Bajaj spare parts
JG113822	BRACKET ABS MOUNTING	Bajaj spare parts
JG113824	BRACKET RESREVOIR MOUNTING	Bajaj spare parts
JG113825	BRACKET REGULATOR MTG ADDON	Bajaj spare parts
JG113826	CLAMP FOR ABS HOSE	Bajaj spare parts
JG113827	BRACKET BATTERY MTG	Bajaj spare parts
JG113828	HOSE CLAMP	Bajaj spare parts
JG113831	HOSE CLAMP	Bajaj spare parts
JG113832	SLEEVE FOR ABS HOSE CLAMP	Bajaj spare parts
JG113836	CLAMP HOSE	Bajaj spare parts
JG113837	BOLT SILENCER MTG	Bajaj spare parts
JG113839	BRACKET TUBE DRAIN	Bajaj spare parts
JG113841	EN: TAPE ANTIABRASIVE	Bajaj spare parts
JG113844	CAP FORGING PIVOT LH	Bajaj spare parts
JG113846	D WASHER CHAIN SLIDER	Bajaj spare parts
JG113847	BRACKET LOOSE PURGE VALVE	Bajaj spare parts
JG113848	BRACKET CANISTER MTG LOOSE	Bajaj spare parts
JG113849	BRACKET RESERVOIR MTG	Bajaj spare parts
JG113850	BRACKET SIDE REFLECTOR	Bajaj spare parts

JG113851	RUBBER BATTERY PAD	Bajaj spare parts
JG113852	LOCATOR CAP CANISTER	Bajaj spare parts
JG113854	BRACKET CANISTER HOSE ROUTING	Bajaj spare parts
JG113855	COLLAR ID 6 X OD 8 X 7L	Bajaj spare parts
JG113856	BRACKET ECU BOTTOM	Bajaj spare parts
JG113857	HOSE CLAMP	Bajaj spare parts
JG113858	CLAMP FOR BRAKE HOSE	Bajaj spare parts
JG113864	HOLDER CANISTER	Bajaj spare parts
JG113866	DAMPER TANK	Bajaj spare parts
JG113867	BRACKET SPIDER LH	Bajaj spare parts
JG113868	BRACKET SPIDER RH	Bajaj spare parts
JG113869	BRACKET CROSS FRONT	Bajaj spare parts
JG113870	BRACKET CROSS REAR	Bajaj spare parts
JG113873	BRACKET ASSEMBLY MUFFLER	Bajaj spare parts
JG113875	BRACKET CARRIER LH	Bajaj spare parts
JG113876	BRACKET CARRIER RH	Bajaj spare parts
JG113877	GUIDE CABLE CLUTCH	Bajaj spare parts
JG113878	BRACKET RADIATOR LH	Bajaj spare parts
JG113879	BRACKET RADIATOR RH	Bajaj spare parts
JG113881	BRACKET HOLDER THERMOSTAT	Bajaj spare parts
JG113882	GUIDE CABLE CLUTCH	Bajaj spare parts
JG113883	PROTECTOR	Bajaj spare parts
JG113888	SHIELD HEAT	Bajaj spare parts
JG121011	INNER DUST SEAL	Bajaj spare parts
JG121012	FORK TOP BOLT	Bajaj spare parts
JG121013	OIL SEAL	Bajaj spare parts
JG121015	PLUG STEERING TUBE	Bajaj spare parts
JG121016	ASSLY LEG LH	Bajaj spare parts
JG121017	LEG ASSY RH	Bajaj spare parts
JG121018	FORK PIPE SUB ASSY LH	Bajaj spare parts
JG121019	FORK PIPE SUB ASSY RH	Bajaj spare parts
JG121023	SHOCKABSORBER MONOSHOX	Bajaj spare parts
JG121024	FORK INDIAN SETTING	Bajaj spare parts
JG121026	LEG ASSLY RH	Bajaj spare parts
JG121028	FORK FRONT DUST COVER	Bajaj spare parts
JG121033	ASSLY MAIN SPRING & WASHER	Bajaj spare parts
JG121038	AXLE CLAMP & FORK PIPE ASSY LH	Bajaj spare parts
JG121041	ASSLY FORK LEG LH	Bajaj spare parts
JG121042	ASSLY FORK LEG RH	Bajaj spare parts
JG121069	FORK FRONT	Bajaj spare parts
JG121071	LEG ASSEMBLY LH	Bajaj spare parts
JG121072	LEG ASSEMBLY RH	Bajaj spare parts
JG121083	LEG ASSEMBLY LH	Bajaj spare parts
JG121084	LEG ASSEMBLY RH	Bajaj spare parts
JG121095	CARTRIDGE SPLIT LH	Bajaj spare parts

JG121096	CARTRIDGE SPLIT RH	Bajaj spare parts
JG121100	LEG ASSEMBLY LH	Bajaj spare parts
JG121101	LEG ASSEMBLY RH	Bajaj spare parts
JG122004	CLAMP HOSE	Bajaj spare parts
JG122005	CHAIN SLIDER	Bajaj spare parts
JG122007	CHAIN ADJUSTER RH	Bajaj spare parts
JG122009	IGUS BUSH	Bajaj spare parts
JG122010	COLLAR	Bajaj spare parts
JG122011	END BUSH-COLLAR	Bajaj spare parts
JG122012	OIL SEAL	Bajaj spare parts
JG122015	CHAIN GUIDE	Bajaj spare parts
JG122016	SHAFT SWING ARM	Bajaj spare parts
JG122026	STOP DISC 22.2X31.7X1	Bajaj spare parts
JG122028	EXTRUDED WASHER	Bajaj spare parts
JG122032	WASHER HEXAGONAL THRUST	Bajaj spare parts
JG122033	WASHER THREADED-SWING ARM STACK	Bajaj spare parts
JG122034	TUBE FOR CHAIN GUIDE	Bajaj spare parts
JG122036	CHAIN SLIDERCHAIN SLIDER	Bajaj spare parts
JG122037	SLEEVE	Bajaj spare parts
JG122038	SHOCKABSORBER MONO INDIAN	Bajaj spare parts
JG122039	CHAIN SLIDER	Bajaj spare parts
JG122042	SWING ARM_MY14_DELINK	Bajaj spare parts
JG122043	ASSLY SWING ARM COMP	Bajaj spare parts
JG122044	ASSLY SWING ARM COMP	Bajaj spare parts
JG122047	SHOCKABSORBER REAR	Bajaj spare parts
JG122048	ARM SWING	Bajaj spare parts
JG122052	SHOCKABSORBER REAR	Bajaj spare parts
JG122054	SHOCKABSORBER REAR	Bajaj spare parts
JG122055	SHOCKABSORBER REAR	Bajaj spare parts
JG122059	SHOCKABSORBER REAR	Bajaj spare parts
JG122064	SHOCKABSORBER REAR	Bajaj spare parts
JG122066	SHOCKABSORBER REAR	Bajaj spare parts
JG131001	SPACER	Bajaj spare parts
JG131002	SPACER FRONT WHEEL	Bajaj spare parts
JG131003	FRONT AXLE	Bajaj spare parts
JG131007	FLANGE BOLT M8	Bajaj spare parts
JG131008	TYRE TUBELESS (SIZE 110/70-R17)	Bajaj spare parts
JG131020	COLLAR CH 0.7_0.9	Bajaj spare parts
JG131028	COLLAR MY17	Bajaj spare parts
JG131029	SPACER FRONT WHEEL	Bajaj spare parts
JG131030	AXLE FRONT MY17	Bajaj spare parts
JG131031	BOLT - AXLE FRONT MY17	Bajaj spare parts
JG131063	SPACER ASSEMBLY	Bajaj spare parts
JG131065	DISC SENSOR SPEED	Bajaj spare parts
JG131078	SPOKE	Bajaj spare parts



JG131087	SPOKE	Bajaj spare parts
JG131088	NIPPLE SPOKE	Bajaj spare parts
JG131205	COLLAR BEARING ASSLY	Bajaj spare parts
JG131209	SPACER FOR COUPLING	Bajaj spare parts
JG131211	SPACER	Bajaj spare parts
JG131217	STUD M10X1.25P FOUR RUBBER	Bajaj spare parts
JG131218	SLEEVE	Bajaj spare parts
JG131219	COUPLING RUBBER	Bajaj spare parts
JG131220	SCREW FOR ABS	Bajaj spare parts
JG131221	TYRE TUBELESS (SIZE 150/60-R17)	Bajaj spare parts
JG131224	AXLE REAR KT03	Bajaj spare parts
JG131228	BOLT D	Bajaj spare parts
JG131235	COUPLING ASSLY DUKE 390	Bajaj spare parts
JG131236	SPROCKET 45 T	Bajaj spare parts
JG131238	COUPLING ASSLY 46T SPROCKET	Bajaj spare parts
JG131265	SPACER ASSEMBLY	Bajaj spare parts
JG131283	SPOKE	Bajaj spare parts
JG131284	SPOKE	Bajaj spare parts
JG131801	DISC FRONT	Bajaj spare parts
JG131802	DISC MTG BOLT	Bajaj spare parts
JG131804	CALIPER ASY BRAKE FRONT	Bajaj spare parts
JG131805	HOSE ASSY	Bajaj spare parts
JG131807	HOSE DISC BRAKE REAR	Bajaj spare parts
JG131808	ASSY MASTER CYLINDER	Bajaj spare parts
JG131809	DISC REAR	Bajaj spare parts
JG131811	BLEEDER SCREW	Bajaj spare parts
JG131813	SPRING	Bajaj spare parts
JG131814	PIN CLIP	Bajaj spare parts
JG131815	ASSY- FLOATING CALIPER-RR	Bajaj spare parts
JG131819	BKT CALIPER MTG FLOATING	Bajaj spare parts
JG131821	RESERVOIR REAR BRAKE	Bajaj spare parts
JG131822	TUBE RESERVOIR	Bajaj spare parts
JG131826	MASTER CYLINDER FRONT	Bajaj spare parts
JG131830	PIN PAD	Bajaj spare parts
JG131840	ASSLY MASTER CYLINDER FRONT	Bajaj spare parts
JG131844	CLAMP BRAKE HOSE REA	Bajaj spare parts
JG131846	DISC BRAKE KIT REAR	Bajaj spare parts
JG131848	CYLINDER MASTER DIA 13	Bajaj spare parts
JG131850	CLIP SEPARATOR	Bajaj spare parts
JG131856	CYLINDER MASTER REAR	Bajaj spare parts
JG131857	CLIP SEPARATOR	Bajaj spare parts
JG131859	UNIT ABS WET	Bajaj spare parts
JG131861	UNIT ABS WET	Bajaj spare parts
JG131865	DISC BRAKE DIA 320	Bajaj spare parts
JG131866	DISC BRAKE DIA 230	Bajaj spare parts

JG131874	UNIT ABS WET	Bajaj spare parts
JG141000	CHAIN	Bajaj spare parts
JG141001	CHAIN 520 H O RINGS	Bajaj spare parts
JG141002	SPROCKET 46 T	Bajaj spare parts
JG141003	CHAIN	Bajaj spare parts
JG141006	SPROCKET	Bajaj spare parts
JG151002	TRIPLE CLAMP- UPPER	Bajaj spare parts
JG151012	COLLAR	Bajaj spare parts
JG151013	CUP WASHER	Bajaj spare parts
JG151014	HANDLE HOLDER BOTTOM	Bajaj spare parts
JG151020	TOP HANDLE HOLDER	Bajaj spare parts
JG151021	SPACER TUBE	Bajaj spare parts
JG151022	THROTTLE PIPE	Bajaj spare parts
JG151023	GRIP ASSY RH	Bajaj spare parts
JG151026	NUT -STEERING	Bajaj spare parts
JG151027	HAND GRIP LH	Bajaj spare parts
JG151029	BOLT FOR HANDLE HOLDER	Bajaj spare parts
JG151031	HANDLE BAR	Bajaj spare parts
JG151035	ASSEMBLE HANDLE BAR DUKE390	Bajaj spare parts
JG151036	GRIP ASSLY DUKE390 RH	Bajaj spare parts
JG151037	THROTTLE PIPE	Bajaj spare parts
JG151038	GRIP ASSLY DUKE 125_200 RH	Bajaj spare parts
JG151043	HOLDER HANDLEBAR TOP	Bajaj spare parts
JG151044	HOLDER HANDLEBAR BOTTOM	Bajaj spare parts
JG151045	HANDLEBAR	Bajaj spare parts
JG151046	BRACKET UPPER	Bajaj spare parts
JG151048	GUIDE CABLE LH	Bajaj spare parts
JG151049	GUIDE CABLE RH	Bajaj spare parts
JG151054	HANDLEBAR	Bajaj spare parts
JG151056	PLUG	Bajaj spare parts
JG151058	COLLAR	Bajaj spare parts
JG151063	HANDLEBAR	Bajaj spare parts
JG161001	SPRING BRAKE PEDAL	Bajaj spare parts
JG161008	LEVER -CLUTCH	Bajaj spare parts
JG161009	LEVER & SUPPORT HOLDER ASSY LH	Bajaj spare parts
JG161010	LEVER BRAKE FRONT	Bajaj spare parts
JG161014	ASSLY BRAKE LEVER	Bajaj spare parts
JG161015	ASSLY CHANGE LEVER	Bajaj spare parts
JG161019	PAD PEDAL BRAKE	Bajaj spare parts
JG161200	CABLE ACCELATOR	Bajaj spare parts
JG161201	CABLE CLUTCH	Bajaj spare parts
JG161205	CABLE CLUTCH	Bajaj spare parts
JG161206	CABLE CLUTCH	Bajaj spare parts
JG171003	PLATE PUMP FUEL	Bajaj spare parts
JG171005	FUEL TANK COVER LH	Bajaj spare parts

JG171006	FUEL TANK COVER RH	Bajaj spare parts
JG171012	CAP TANK	Bajaj spare parts
JG171018	GASKET-FUELPUMP MOUNTING	Bajaj spare parts
JG171020	SLEEVE TANK MOUNTING	Bajaj spare parts
JG171022	GROMMET-TANK MUT REAR	Bajaj spare parts
JG171023	SCREW SEAT HOOKING	Bajaj spare parts
JG171024	GROMMET TOP COVER	Bajaj spare parts
JG171025	TUBE DRAIN CUP CAP	Bajaj spare parts
JG171026	BRACKET ECU MOUNTING	Bajaj spare parts
JG171027	DAMPER TANK RESTING	Bajaj spare parts
JG171029	SPRING BAND CLAMP 11.5 x 8.4	Bajaj spare parts
JG171030	CLAMP	Bajaj spare parts
JG171031	CLIP NUT M5	Bajaj spare parts
JG171033	TANK RUBBER PAD SMALL LH	Bajaj spare parts
JG171034	TANK RUBBER PAD LARGE LH	Bajaj spare parts
JG171035	TANK RUBBER PAD SMALL RH	Bajaj spare parts
JG171036	TANK RUBBER PAD LARGE RH	Bajaj spare parts
JG171037	LUG DRAIN PIPE RETURN	Bajaj spare parts
JG171039	D WASHER	Bajaj spare parts
JG171040	DAMPER ECU	Bajaj spare parts
JG171044	CAP FUEL TANK	Bajaj spare parts
JG171046	DAMPER ASSLY ECU	Bajaj spare parts
JG171047	TAPE DUAL	Bajaj spare parts
JG171048	DUEL LOCK	Bajaj spare parts
JG171053	PLUG TANK CAP	Bajaj spare parts
JG171054	GASKET CUP CAP	Bajaj spare parts
JG171055	TANK CUP CAP	Bajaj spare parts
JG171056	FUEL TANK	Bajaj spare parts
JG171059	BOLT SOCKET HEAD	Bajaj spare parts
JG171060	TANK (US HOMOLOGATION)	Bajaj spare parts
JG171061	CUP CAP	Bajaj spare parts
JG171062	GASKET CUP CAP (US HOMOLOGATION)	Bajaj spare parts
JG171065	TUBE CUP CAP TO CANISTER	Bajaj spare parts
JG171066	TUBE CANISTER TO PURGE VALVE	Bajaj spare parts
JG171067	TUBE PURGE VALVE TO INJECTOR	Bajaj spare parts
JG171074	ASSY ECU DAMPER NEW	Bajaj spare parts
JG171075	DUAL TAPE	Bajaj spare parts
JG171077	ASSEMBLY ECU MTG BKT	Bajaj spare parts
JG171085	TUBE CONNECTOR TO INJ BODY	Bajaj spare parts
JG171086	CONNECTOR TUBE EVAP	Bajaj spare parts
JG171136	CUP CAP	Bajaj spare parts
JG171137	GASKET	Bajaj spare parts
JG171139	BRACKET TANK FRONT	Bajaj spare parts
JG171140	BRACKET TANK REAR	Bajaj spare parts
JG171141	FLANGE PUMP FUEL	Bajaj spare parts

JG171142	DAMPER	Bajaj spare parts
JG171144	COVER CAP TANK	Bajaj spare parts
JG171147	PIPE DRAIN	Bajaj spare parts
JG171148	BRACKET COVER TANK FRONT	Bajaj spare parts
JG171149	GROMMET	Bajaj spare parts
JG171150	BRACKET SENSOR	Bajaj spare parts
JG171151	BRACKET SPOILER TANK	Bajaj spare parts
JG171152	COLLAR	Bajaj spare parts
JG171153	COLLAR	Bajaj spare parts
JG171157	TAPE	Bajaj spare parts
JG171158	BRACKET SENSOR LEAN ANGLE	Bajaj spare parts
JG171601	VALVE PURGE	Bajaj spare parts
JG171602	CAP TANK	Bajaj spare parts
JG171603	TUBE TANK TO CONNECTOR	Bajaj spare parts
JG171604	TUBE CONNECTOR TO CANISTER	Bajaj spare parts
JG171611	CANISTER	Bajaj spare parts
JG171614	PIPE VALVE PURGE-BODY THROTTLE	Bajaj spare parts
JG171615	PIPE CANISTER-CONNECTOR	Bajaj spare parts
JG171616	PIPE TANK-CONNECTOR	Bajaj spare parts
JG171617	PIPE CANISTER-CONNECTOR	Bajaj spare parts
JG171618	PIPE DRAIN	Bajaj spare parts
JG171619	PIPE CONNECTOR-VALVE PURGE	Bajaj spare parts
JG171622	PIPE FUEL	Bajaj spare parts
JG171800	FUEL PUMP MODULE	Bajaj spare parts
JG171802	FINE FUEL FILTER	Bajaj spare parts
JG171803	HOSE - FUEL PUMP - I	Bajaj spare parts
JG171816	PUMP FUEL	Bajaj spare parts
JG171817	PIPE FILTER FUEL-PUMP FUEL I	Bajaj spare parts
JG171818	PIPE FUEL	Bajaj spare parts
JG171819	PIPE FUEL	Bajaj spare parts
JG171820	SLEEVE	Bajaj spare parts
JG171822	PIPE FUEL	Bajaj spare parts
JG171823	PLATE PUMP FUEL	Bajaj spare parts
JG171824	PIPE FUEL	Bajaj spare parts
JG181001	PIN	Bajaj spare parts
JG181205	SEAT COWL LOWER LH	Bajaj spare parts
JG181206	SEAT COWL LOWER RH	Bajaj spare parts
JG181210	CHAIN COVER	Bajaj spare parts
JG181211	BELLY PAN	Bajaj spare parts
JG181219	BRIDGE BKT FRONT-BELLY PAN	Bajaj spare parts
JG181220	BKT FRONT MTG -LH-BELLY PAN	Bajaj spare parts
JG181221	BKT REAR MTG-BELLY PAN	Bajaj spare parts
JG181225	FAIRING BACK COVER	Bajaj spare parts
JG181226	CARRIER	Bajaj spare parts
JG181227	DASHBOARD	Bajaj spare parts

JG181228	SIDE MASK LH	Bajaj spare parts
JG181230	WIND SCREEN	Bajaj spare parts
JG181231	BKT FRONT MTG-RH-BELLY PAN	Bajaj spare parts
JG181232	SCREW SELF TAP-DIA	Bajaj spare parts
JG181233	SCREW SELF TAPPING-DIA 6-INNER	Bajaj spare parts
JG181234	MESH BELLY-PAN	Bajaj spare parts
JG181235	WASHER SPECIAL	Bajaj spare parts
JG181236	WELL NUT - M5 X 16 L	Bajaj spare parts
JG181238	GROMMET DASHBOARD	Bajaj spare parts
JG181239	COLLAR BUSHING	Bajaj spare parts
JG181240	D - WASHER	Bajaj spare parts
JG181242	GROMMET PIVOT BOLT	Bajaj spare parts
JG181243	SECURING CLIP-PIV BOLT	Bajaj spare parts
JG181245	MASK CARRIER PIVOT BKT	Bajaj spare parts
JG181249	BKT FOR HARNESS ROUTING	Bajaj spare parts
JG181250	STEP BOLT	Bajaj spare parts
JG181251	SCREW ROUND HEAD	Bajaj spare parts
JG181252	BOLT FLANGE M6X1X90L	Bajaj spare parts
JG181253	BKT CETRL MTG BELLYPAN-PDC CR CS	Bajaj spare parts
JG181254	BKT RR MTG-BELLYPAN - PDC CR CS	Bajaj spare parts
JG181255	STEP BOLT	Bajaj spare parts
JG181257	BRACKET MOLEX COUPLER MTG	Bajaj spare parts
JG181258	RUBBER STRAP FOR MOLEX COUPLER	Bajaj spare parts
JG181259	RIVET SNAP	Bajaj spare parts
JG181267	REAR FENDER	Bajaj spare parts
JG181273	BOLT CHAIN CASE MTG	Bajaj spare parts
JG181274	STRAP CANISTER	Bajaj spare parts
JG181280	FORK PROTECTOR LH	Bajaj spare parts
JG181281	FLAP PROTECTOR SHOCKER	Bajaj spare parts
JG181282	FORK PROTECTOR RH	Bajaj spare parts
JG181287	SLEEVE CHAIN COVER MY15	Bajaj spare parts
JG181288	BRACKET BELLY PAN FRONT	Bajaj spare parts
JG181296	SPOILER TANK OUTER LH	Bajaj spare parts
JG181297	SPOILER TANK OUTER RH	Bajaj spare parts
JG181298	COVER RADIATOR LH	Bajaj spare parts
JG181299	COVER RADIATOR RH	Bajaj spare parts
JG181300	BELLY PAN	Bajaj spare parts
JG181301	TRAY UNDER	Bajaj spare parts
JG181303	CARRIER MASK LH	Bajaj spare parts
JG181304	CARRIER MASK RH	Bajaj spare parts
JG181305	COVER CABLE CARRIER MASK	Bajaj spare parts
JG181306	COVER MASK MIDDLE	Bajaj spare parts
JG181307	CAP CARRIER MASK	Bajaj spare parts
JG181308	COWL SEAT LOWER LH	Bajaj spare parts
JG181309	COWL SEAT UPPER	Bajaj spare parts

JG181310	COVER SOCKET	Bajaj spare parts
JG181311	COVER MASK LH	Bajaj spare parts
JG181312	COVER MASK RH	Bajaj spare parts
JG181313	COWL SEAT LOWER RH	Bajaj spare parts
JG181314	HOLDER RELAY	Bajaj spare parts
JG181315	HOLDER PLATE NUMBER REAR	Bajaj spare parts
JG181316	FLAP LAMP HEAD LH	Bajaj spare parts
JG181317	FLAP LAMP HEAD RH	Bajaj spare parts
JG181320	COVER	Bajaj spare parts
JG181321	COWL RADIATOR	Bajaj spare parts
JG181324	COLLAR CARRIER MASK	Bajaj spare parts
JG181325	HOLDER SPEEDOMETER	Bajaj spare parts
JG181326	HOLDER INDICATOR LH	Bajaj spare parts
JG181338	CAP CARRIER MASK LH	Bajaj spare parts
JG181339	CAP CARRIER MASK RH	Bajaj spare parts
JG181340	HOLDER INDICATOR RH	Bajaj spare parts
JG181341	COVER LOCK IGNITION	Bajaj spare parts
JG181342	SPOILER TANK INNER LH	Bajaj spare parts
JG181343	SPOILER TANK INNER RH	Bajaj spare parts
JG181344	GROMMET	Bajaj spare parts
JG181345	COLLAR	Bajaj spare parts
JG181346	PIN QUICK RELEASE	Bajaj spare parts
JG181347	HOLDER CABLE	Bajaj spare parts
JG181348	DAMPER	Bajaj spare parts
JG181349	DAMPER	Bajaj spare parts
JG181350	BRACKET BELLY PAN FRONT	Bajaj spare parts
JG181351	BRACKET BELLY PAN REAR	Bajaj spare parts
JG181356	GROMMET	Bajaj spare parts
JG181357	COVER BELLY PAN	Bajaj spare parts
JG181358	SLEEVE	Bajaj spare parts
JG181361	DAMPER	Bajaj spare parts
JG181362	COVER RELAY STARTER	Bajaj spare parts
JG181364	CARRIER MASK LH	Bajaj spare parts
JG181365	CARRIER MASK RH	Bajaj spare parts
JG181366	COVER BOTTOM	Bajaj spare parts
JG181373	HOLDER CABLE	Bajaj spare parts
JG181374	NUT SQUARE-M5X0.8XHT 4.5XCL 4XBR	Bajaj spare parts
JG181375	COWL ASSEMBLY SEAT LOWER LH	Bajaj spare parts
JG181376	COWL ASSEMBLY SEAT LOWER RH	Bajaj spare parts
JG181380	NUT RIVET	Bajaj spare parts
JG181387	COVER SENSOR LEAN ANGLE LOWER	Bajaj spare parts
JG181388	COVER SENSOR LEAN ANGLE UPPER	Bajaj spare parts
JG181400	FRONT FENDER	Bajaj spare parts
JG181403	Fender Rear	Bajaj spare parts
JG181406	FRONT HUGGER RR WHEEL	Bajaj spare parts

JG181408	WASHER FRONT-FENDER-MTG	Bajaj spare parts
JG181416	REAR FENDER EXT.	Bajaj spare parts
JG181417	REFLEX REFLECTOR MTG	Bajaj spare parts
JG181428	REAR FENDER REAR INDIA	Bajaj spare parts
JG181429	UNDER TRAY	Bajaj spare parts
JG181435	FENDER FRONT	Bajaj spare parts
JG181437	FLAP FENDER FRONT	Bajaj spare parts
JG181438	FLAP FENDER REAR	Bajaj spare parts
JG181439	PROTECTOR FORK LH	Bajaj spare parts
JG181440	PROTECTOR FORK RH	Bajaj spare parts
JG181441	HOLDER REFLECTOR REFLEX LH	Bajaj spare parts
JG181442	HOLDER REFLECTOR REFLEX RH	Bajaj spare parts
JG181444	EXTENSION FENDER REAR	Bajaj spare parts
JG181445	FENDER FRONT	Bajaj spare parts
JG181708	COLLAR	Bajaj spare parts
JG181713	FLAP LAMP HEAD LH	Bajaj spare parts
JG181714	FLAP LAMP HEAD RH	Bajaj spare parts
JG184000	WINDSHIELD	Bajaj spare parts
JG184002	SUPPORT WINDSHIELD	Bajaj spare parts
JG191000	SEAT ASSY FRONT	Bajaj spare parts
JG191003	SEAT ASSY REAR	Bajaj spare parts
JG191006	DAMPER SEAT	Bajaj spare parts
JG191008	COLLAR -SEAT	Bajaj spare parts
JG191009	BOLT FLANGE - M6	Bajaj spare parts
JG191017	SEAT ASSLY FRONT	Bajaj spare parts
JG191024	SEAT ASSEMBLY RIDER	Bajaj spare parts
JG191028	SEAT ASSEMBLY PILLION	Bajaj spare parts
JG231002	TOOL BAG	Bajaj spare parts
JG231003	SPARK PLUG SPANNER	Bajaj spare parts
JG231020	TOOLKIT	Bajaj spare parts
JG231021	BAG TOOL	Bajaj spare parts
JG231209	GUARD LEG LH	Bajaj spare parts
JG231210	GUARD LEG RH	Bajaj spare parts
JG231212	GUARD HAND LH	Bajaj spare parts
JG231213	GUARD HAND RH	Bajaj spare parts
JG231214	SLEEVE HAND GAURD	Bajaj spare parts
JG231215	CLAMP HAND GAURD LH	Bajaj spare parts
JG231216	CLAMP HAND GAURD RH	Bajaj spare parts
JG231219	FOAM HAND GAURD	Bajaj spare parts
JG231221	SPACER HAND GUARD	Bajaj spare parts
JG231222	GUARD LEG LH	Bajaj spare parts
JG231223	GUARD LEG RH	Bajaj spare parts
JG231226	GUARD SAREE LH	Bajaj spare parts
JG231227	HOLDER GUARD SAREE II	Bajaj spare parts
JG231231	CLAMP REAR	Bajaj spare parts

JG231232	SPACER	Bajaj spare parts
JG231237	HOLDER ASSEMBLY GUARD SAREE	Bajaj spare parts
JG231239	BRACKET GUARD SAREE	Bajaj spare parts
JG231404	GRAB LH WITH FOAM	Bajaj spare parts
JG231405	GRAB RH WITH FOAM	Bajaj spare parts
JG231406	BOLT SOCKET M8 X 1.25 X27	Bajaj spare parts
JG231408	GRAB HANDLE LH	Bajaj spare parts
JG231409	GRAB HANDLE RH	Bajaj spare parts
JG231411	COLLAR	Bajaj spare parts
JG231413	PLUG	Bajaj spare parts
JG231414	PAD	Bajaj spare parts
JG231600	MIRROR LH	Bajaj spare parts
JG231601	MIRROR RH	Bajaj spare parts
JG231604	MIRROR LH	Bajaj spare parts
JG231605	MIRROR RH	Bajaj spare parts
JG232601	LOCK ASSY SEAT REAR	Bajaj spare parts
JG232602	SIDE LOCK	Bajaj spare parts
JG232603	BRACKET SEAT LOCK BARREL	Bajaj spare parts
JG232604	LOCK SET THREE IN ONE	Bajaj spare parts
JG232605	TWO TRACK KEY	Bajaj spare parts
JG232606	SEAT LOCK CABLE	Bajaj spare parts
JG232608	LOCK SET DUKE 390 USA	Bajaj spare parts
JG232609	SET LOCK	Bajaj spare parts
JG232614	LATCH ASSEMBLY SEAT	Bajaj spare parts
JG232809	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JG232810	BRACKET PLATE NUMBER REAR	Bajaj spare parts
JG232815	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JG233008	BELL PAN LH DECAL	Bajaj spare parts
JG233009	BELL PAN RH DECAL	Bajaj spare parts
JG233012	LABEL ATTENTION	Bajaj spare parts
JG233044	DECL BELY PAN LH WH	Bajaj spare parts
JG233045	DECL BELLY PAN RH WH	Bajaj spare parts
JG233048	DECAL MASK LH_390_MY13	Bajaj spare parts
JG233049	DECAL MASK RH_390_MY13	Bajaj spare parts
JG233052	DECAL BELLY PAN LH_390_MY13	Bajaj spare parts
JG233053	DECAL BELLY PAN RH_390_MY13	Bajaj spare parts
JG233054	DECAL SEAT COWL LH_390_MY13	Bajaj spare parts
JG233055	DECAL SEAT COWL RH_390_MY13	Bajaj spare parts
JG233069	DECAL BELLY PAN LH BL	Bajaj spare parts
JG233070	DECAL BELLY PAN RH BL	Bajaj spare parts
JG233071	DECAL SEAT COWL LH BL	Bajaj spare parts
JG233072	DECAL SEAT COWL RH BL	Bajaj spare parts
JG233080	EN: TAPE ANTIABRASIVE	Bajaj spare parts
JG233082	DECAL SET TANK COVER LH & RH	Bajaj spare parts
JG233083	DECAL SET DUKE 390 MY 13	Bajaj spare parts



JG233084	DECAL SEAT COWL_LH_ORANGE_MY13	Bajaj spare parts
JG233085	DECAL SEAT COWL_RH_ORANGE_MY13	Bajaj spare parts
JG233086	DECAL SEAT COWL_LH_BLACK_MY13	Bajaj spare parts
JG233088	DECAL SEAT COWL_LH_WHITE_MY13	Bajaj spare parts
JG233089	DECAL SEAT COWL_RH_WHITE_MY13	Bajaj spare parts
JG233111	DEC MASK LH BLACK	Bajaj spare parts
JG233112	DEC MASK RH BLACK	Bajaj spare parts
JG233113	DEC BELLY PAN LH BLACK	Bajaj spare parts
JG233114	DEC BELLY PAN RH BLACK	Bajaj spare parts
JG233115	DEC UP SEAT COWL LH BLACK	Bajaj spare parts
JG233116	DECAL UP seat cow RH BLACK	Bajaj spare parts
JG233117	DECAL SET TANK CVR DUKE390 BLACK MY14	Bajaj spare parts
JG233118	DECAL SET	Bajaj spare parts
JG233145	DECAL TANK COVER LH DUKE250 BLACK	Bajaj spare parts
JG233146	DECAL TANK COVER RH DUKE250 BLACK	Bajaj spare parts
JG233166	EMBLEM KTM	Bajaj spare parts
JG233171	DECAL SPOILER TANK LH WHITE	Bajaj spare parts
JG233172	DECAL SPOILER TANK RH WHITE	Bajaj spare parts
JG233173	DECAL COWL SEAT UPPER LH WHITE	Bajaj spare parts
JG233174	DECAL COWL SEAT UPPER RH WHITE	Bajaj spare parts
JG233175	DECAL SPOILER TANK LH ORANGE	Bajaj spare parts
JG233176	DECAL SPOILER TANK RH ORANGE	Bajaj spare parts
JG233177	DECAL COWL SEAT UPPER LH ORANGE	Bajaj spare parts
JG233178	DECAL COWL SEAT UPPER RH ORANGE	Bajaj spare parts
JG233183	DECAL COWL SEAT UPPER LH BLACK	Bajaj spare parts
JG233184	DECAL COWL SEAT UPPER RH BLACK	Bajaj spare parts
JG233185	DECAL COWL SEAT UPPER LH ORANGE	Bajaj spare parts
JG233186	DECAL COWL SEAT UPPER RH ORANGE	Bajaj spare parts
JG233187	DECAL SPOILER TANK LH BLACK	Bajaj spare parts
JG233188	DECAL SPOILER TANK RH BLACK	Bajaj spare parts
JG233189	DECAL SPOILER TANK LH ORANGE	Bajaj spare parts
JG233190	DECAL SPOILER TANK RH ORANGE	Bajaj spare parts
JG233236	DECAL FENDER LH ORANGE	Bajaj spare parts
JG233237	DECAL FENDER RH ORANGE	Bajaj spare parts
JG233238	DECAL FENDER LH BLUE	Bajaj spare parts
JG233239	DECAL FENDER RH BLUE	Bajaj spare parts
JG233254	DECAL FENDER LH ORANGE BLUE	Bajaj spare parts
JG233255	DECAL FENDER RH ORANGE BLUE	Bajaj spare parts
JG233256	DECAL FENDER RH LIQUID METAL ORG	Bajaj spare parts
JG233257	DECAL FENDER LH LIQUID METAL ORG	Bajaj spare parts
JG351002	GEAR INDICATOR SWITCH	Bajaj spare parts
JG351005	STATOR ASSY	Bajaj spare parts
JG351014	GROMMET N	Bajaj spare parts
JG351019	BODY STARTER CLUTCH	Bajaj spare parts
JG351020	ROTOR ASSY.W/O CLUTCH ASSY	Bajaj spare parts

JG351021	ROTOR CPL.	Bajaj spare parts
JG351201	SPARK PLUG CAP	Bajaj spare parts
JG351202	GROMMET SPARK PLUG	Bajaj spare parts
JG351203	IGNITION COIL WITH CABLE	Bajaj spare parts
JG351208	GROMMET SPARK PLUG CAP	Bajaj spare parts
JG351209	PLUG SPARK M12 (BOSCH-VR5NE)	Bajaj spare parts
JG351400	COOLANT WATER TEMP SENSOR	Bajaj spare parts
JG351402	ENGINE CONTROL UNIT	Bajaj spare parts
JG351600	STARTER MOTOR ASSY 350W BLK	Bajaj spare parts
JG351804	SENSOR THROTTLE POSITION	Bajaj spare parts
JG351805	SENSOR TMAP	Bajaj spare parts
JG351806	GEAR IND SWITCH AND PICK UP COIL	Bajaj spare parts
JG351811	SENSOR LEAN ANGLE	Bajaj spare parts
JG401001	TAIL LAMP ASSEMBLY	Bajaj spare parts
JG401004	INDICATOR ASSLY FR LH	Bajaj spare parts
JG401006	NUMBER PLATE ILL-LAMP	Bajaj spare parts
JG401027	HEAD LIGHT DUST CAP	Bajaj spare parts
JG401036	REFLECTOR REFLEX	Bajaj spare parts
JG401037	REFLECTOR REFLEX REAR SIDE	Bajaj spare parts
JG401038	REFLECTOR FRONT SIDE	Bajaj spare parts
JG401041	ASSLY HEAD LAMP	Bajaj spare parts
JG401044	HEAD LAMP CONTROL UNIT	Bajaj spare parts
JG401045	LAMP HEAD	Bajaj spare parts
JG401046	INDICATOR REAR LH	Bajaj spare parts
JG401048	INDICATOR REAR RH	Bajaj spare parts
JG401049	LAMP HEAD	Bajaj spare parts
JG401050	LAMP TAIL	Bajaj spare parts
JG401051	INDICATOR FRONT LH	Bajaj spare parts
JG401052	INDICATOR FRONT RH	Bajaj spare parts
JG401053	INDICATOR REAR LH	Bajaj spare parts
JG401054	INDICATOR REAR RH	Bajaj spare parts
JG401400	REAR BRAKE PRESSURE SWITCH	Bajaj spare parts
JG401401	IGNITION SWITCH	Bajaj spare parts
JG401402	SWITCH SIDE STAND	Bajaj spare parts
JG401405	TERMINATION UNIT	Bajaj spare parts
JG401406	SWITCH CONTROL LH	Bajaj spare parts
JG401411	MAGNET HOLDER	Bajaj spare parts
JG401416	SWITCH CLUTCH (VB)	Bajaj spare parts
JG401417	CONTROL SWITCH RH	Bajaj spare parts
JG401418	SWITCH CONTROL RH DOMESTIC MY15	Bajaj spare parts
JG401424	SWITCH CONTROL LH	Bajaj spare parts
JG401425	SWITCH CONTROL RH	Bajaj spare parts
JG401426	SWITCH CLUTCH	Bajaj spare parts
JG401427	SWITCH CONTROL LH	Bajaj spare parts
JG401428	SWITCH CONTROL RH	Bajaj spare parts

JG401601	HORN 82 DIA	Bajaj spare parts
JG401604	HORN	Bajaj spare parts
JG401607	HORN	Bajaj spare parts
JG401801	BATTERY BAND	Bajaj spare parts
JG401808	FOAM BATTERY BKT 35X15X3	Bajaj spare parts
JG401811	BAND BATTERY	Bajaj spare parts
JG401812	CASE BATTERY	Bajaj spare parts
JG402002	DC FLASHER	Bajaj spare parts
JG402003	REGULATOR 3 PHASE-SHUNT	Bajaj spare parts
JG402005	UNIT CAN TERMINATION	Bajaj spare parts
JG402203	CABLE ASSY BATTERY TO GROUND	Bajaj spare parts
JG402228	FUSE 10A	Bajaj spare parts
JG402229	FUSE 15A	Bajaj spare parts
JG402230	FUSE 30A	Bajaj spare parts
JG402234	FUSE 25A (MINI FUSE)	Bajaj spare parts
JG402235	EARTH CABLE 1	Bajaj spare parts
JG402236	CABLE RELAY TO MOTOR	Bajaj spare parts
JG402237	CABLE EARTH 2	Bajaj spare parts
JG402238	HARNESS	Bajaj spare parts
JG402239	HARNESS WIRING US MARKET	Bajaj spare parts
JG402242	CABLE TIE ORANGE 100 L	Bajaj spare parts
JG402244	CABLE TIE ORANGE 150 L	Bajaj spare parts
JG402245	CABLE TIE ORANGE 200 L	Bajaj spare parts
JG402247	HARNESS KT03 CHINA	Bajaj spare parts
JG402250	HARNESS DUKE 390 DOMESTIC	Bajaj spare parts
JG402253	HARNESS DUKE DOMESTIC	Bajaj spare parts
JG402261	HARNESS WIRING REAR	Bajaj spare parts
JG402262	SOCKET CHARGER	Bajaj spare parts
JG402269	CABLE EARTH	Bajaj spare parts
JG402270	CABLE RELAY-MOTOR STARTER	Bajaj spare parts
JG402271	HARNESS WIRING FRONT	Bajaj spare parts
JG402273	HARNESS WIRING FRONT	Bajaj spare parts
JG402274	HARNESS WIRING REAR	Bajaj spare parts
JG402284	FUSE 20A	Bajaj spare parts
JG402298	HARNESS WIRING FRONT	Bajaj spare parts
JG402299	HARNESS WIRING REAR	Bajaj spare parts
JG402400	VEHICLE SPEED SENSOR.	Bajaj spare parts
JG402401	DIGITAL SP.METER ASSY	Bajaj spare parts
JG402405	SPEEDOMETER WITH ABS	Bajaj spare parts
JG402408	SPEEDOMETER ASSLY	Bajaj spare parts
JG402412	SPEEDOMETER	Bajaj spare parts
JG402413	SPEEDOMETER	Bajaj spare parts
JG403003	DAMPER RELAY STARTER	Bajaj spare parts
JG403200	SENSOR ROLL OVER	Bajaj spare parts
JG403603	CLAMP SENSOR CABLE HOLDING	Bajaj spare parts

JG501008	HEX BOLT WITH FLANGE	Bajaj spare parts
JG509003	WASHER PLAIN	Bajaj spare parts
JG511010	O2 SENSOR	Bajaj spare parts
JG511016	PLUG	Bajaj spare parts
JG511021	WASHER	Bajaj spare parts
JG511022	BOLT SPECIAL	Bajaj spare parts
JG511028	GASKET CYLINDER HEAD	Bajaj spare parts
JG511029	RUBBER GASKET	Bajaj spare parts
JG511030	COVER CYLINDER HEAD	Bajaj spare parts
JG511042	SEAT VALVE SPRING (BAL)	Bajaj spare parts
JG511046	STUD (M8*1.25)	Bajaj spare parts
JG511050	CYLINDER HEAD WITH CAMHOLDER	Bajaj spare parts
JG511054	O-RING_PIPE COOLANT	Bajaj spare parts
JG511211	TENSIONER ASSLY_G2	Bajaj spare parts
JG511243	ROCKER ARM SHAFT	Bajaj spare parts
JG511247	TIMING CHAIN	Bajaj spare parts
JG511249	CAMSHAFT HOLDER	Bajaj spare parts
JG511250	GUIDE CHAIN TOP	Bajaj spare parts
JG511253	VALVE GUIDE_G2	Bajaj spare parts
JG511255	VALVE SPRING (BAL)_G2	Bajaj spare parts
JG511257	VALVE INTAKE VALVE	Bajaj spare parts
JG511258	VALVE EXHAUST VALVE	Bajaj spare parts
JG511259	RETAINER VALVE SPRING	Bajaj spare parts
JG511261	BALL BEARING_G2	Bajaj spare parts
JG511262	SPACER CAMSHAFT_G2	Bajaj spare parts
JG511269	SPECIAL SCREW CAMSHAFT	Bajaj spare parts
JG511270	BOLT FLANGED M6X1X6L-SPECIAL	Bajaj spare parts
JG511276	SPROCKET CAMSHAFT	Bajaj spare parts
JG511281	CAMSHAFT ASSLY INTAKE	Bajaj spare parts
JG511283	CAMSHAFT ASSLY EXHAUST	Bajaj spare parts
JG521008	GASKET CYLINDER BLOCK	Bajaj spare parts
JG521010	CYLINDER BLOCK	Bajaj spare parts
JG521200	PISTON ASSEMBLY	Bajaj spare parts
JG531007	BOLT CONNECTING ROD	Bajaj spare parts
JG531027	SPROCKET CRANKSHAFT 17T	Bajaj spare parts
JG531031	SPACER CRANKSHAFT	Bajaj spare parts
JG531035	CONNECTING ROD ASSY CPL	Bajaj spare parts
JG531039	BELEVILLE WASHER	Bajaj spare parts
JG531040	NUT BALANCER DRIVE LOCK	Bajaj spare parts
JG531041	BALANCER DRIVE GEAR	Bajaj spare parts
JG531043	CRANKSHAFT ASSY CPL	Bajaj spare parts
JG531207	GEAR BALANCER DRIVEN	Bajaj spare parts
JG531211	SLEEVE BALANCER DRIVEN	Bajaj spare parts
JG531212	O RING BALANCER DRIVEN	Bajaj spare parts
JG531215	WASHER (2.5MM)	Bajaj spare parts

JG531220	BALANCER BEARING	Bajaj spare parts
JG531228	SLEEVE BALANCER DRIVEN	Bajaj spare parts
JG531229	O RING BALANCER DRIVEN	Bajaj spare parts
JG541015	NEEDLE BEARING HK 1514 RS	Bajaj spare parts
JG541020	JET OIL CRANKCASE RH	Bajaj spare parts
JG541021	OIL NOZZLE	Bajaj spare parts
JG541041	GASKET CRANKCASE	Bajaj spare parts
JG541043	RETAINER GEAR STARTER	Bajaj spare parts
JG541044	BRACKET HARNESS LOWER_G2	Bajaj spare parts
JG541045	INPUT SHAFT BEARING STOPPER	Bajaj spare parts
JG541046	BALANCER BEARING STOPPER	Bajaj spare parts
JG541047	GUIDE CHAIN (SLACKSIDE)	Bajaj spare parts
JG541048	GUIDE CHAIN (TIGHT SIDE)	Bajaj spare parts
JG541058	CHAIN GUARD	Bajaj spare parts
JG541059	PLATE STOPPER BEARING	Bajaj spare parts
JG541061	PIPE BREATHER	Bajaj spare parts
JG541063	BRACKET HARNESS UPPER_G2	Bajaj spare parts
JG541068	HEX FLANGE HEAD BOLT M10	Bajaj spare parts
JG541074	OIL NOZZLE	Bajaj spare parts
JG541207	COVER LH RR_G2	Bajaj spare parts
JG541211	GASKET COVER MAGNETO	Bajaj spare parts
JG541221	GASKET CLUTCH COVER	Bajaj spare parts
JG541223	BRACKET HARNESS_G2	Bajaj spare parts
JG541224	GASKET MAGNETO COVER	Bajaj spare parts
JG541230	CAP OIL FILLING	Bajaj spare parts
JG541231	PLATE -POSITION	Bajaj spare parts
JG541232	PLUG INCL. O-RING	Bajaj spare parts
JG541235	ASSLY CLUTCH COVER	Bajaj spare parts
JG541236	CLUTCH COVER WITH PLUG	Bajaj spare parts
JG551000	BUSH IST DRIVEN	Bajaj spare parts
JG551010	COLLAR SPROCKET	Bajaj spare parts
JG551013	BUSH 6TH DRIVE	Bajaj spare parts
JG551015	SHAFT CLUTCH RELEASE ASSY	Bajaj spare parts
JG551017	SPRING (LEVER CLUTCH)	Bajaj spare parts
JG551019	PLATE DRIVE SPROCKET	Bajaj spare parts
JG551020	WASHER SPLINED O/P SHAFT	Bajaj spare parts
JG551021	WASHER PLAIN O/P SHAFT	Bajaj spare parts
JG551022	WASHER PLAIN 2ND GEAR	Bajaj spare parts
JG551025	SHAFT OUTPUT ASSY WITH PLUG	Bajaj spare parts
JG551026	SHAFT OUTPUT T/M ASSY	Bajaj spare parts
JG551027	SHAFT INPUT T/M COMP	Bajaj spare parts
JG551028	SHAFT INPUT T/M ASSEMBLY	Bajaj spare parts
JG551031	COLLAR SPROCKET	Bajaj spare parts
JG551213	GEAR 6TH DRIVE	Bajaj spare parts
JG551214	GEAR DRIVE MULTIPLE 3&4	Bajaj spare parts

JG551215	GEAR 4TH DRIVEN	Bajaj spare parts
JG551216	GEAR PRIMARY DRIVE 22T	Bajaj spare parts
JG551220	GEAR 5TH DRIVE (G2)	Bajaj spare parts
JG551222	GEAR 5TH DRIVEN (G2)	Bajaj spare parts
JG551223	GEAR 3RD DRIVEN (G2)	Bajaj spare parts
JG551224	GEAR 6TH DRIVEN (G2)	Bajaj spare parts
JG551225	GEAR 1ST DRIVEN (G2)	Bajaj spare parts
JG551227	GEAR 2ND DRIVE	Bajaj spare parts
JG551228	GEAR 2ND DRIVEN	Bajaj spare parts
JG551423	CLUTCH LIFTER BEARING	Bajaj spare parts
JG551427	COLLARED BUSH_G2	Bajaj spare parts
JG551428	WASHER CLUTCH_G2	Bajaj spare parts
JG551432	OUTER CLUTCH HOUSING_G2	Bajaj spare parts
JG551433	CLUTCH CENTER_G2	Bajaj spare parts
JG551443	CLUTCH HOLDER	Bajaj spare parts
JG551447	PRESSURE PLATE	Bajaj spare parts
JG551448	FRICITION DISK A	Bajaj spare parts
JG551449	PLATE= WH CLUTCH	Bajaj spare parts
JG551450	SPRING	Bajaj spare parts
JG551451	BOLT SH 6*22	Bajaj spare parts
JG551455	DISC C-CLUTCH FRICTION	Bajaj spare parts
JG551457	HOUSING CLUTCH ASSLY COM.	Bajaj spare parts
JG551458	CLUTCH ASSLY COMPLETE	Bajaj spare parts
JG561008	GEAR INDICATOR PIN	Bajaj spare parts
JG561009	STOPPER DRUM COMP	Bajaj spare parts
JG561010	SPACER-GUIDE GEAR SHIFT	Bajaj spare parts
JG561011	DRUM COMPLETE GEAR SHIFT	Bajaj spare parts
JG561012	FORK GEAR SHIFT INPUT	Bajaj spare parts
JG561013	FORK GEAR SHIFT OUTPUT	Bajaj spare parts
JG561016	SHAFT GEAR SHIFT FORK_G2	Bajaj spare parts
JG561017	DRUM COMPLETE GEAR SHIFT	Bajaj spare parts
JG561200	LEVER GEAR SHIFT ASSY COMP.	Bajaj spare parts
JG561204	BOLT STOPPER DRUM	Bajaj spare parts
JG561205	WASHER DRUM STOPPER	Bajaj spare parts
JG561215	COMPRESSION SPRING	Bajaj spare parts
JG561216	WASHER 14X30X1.5	Bajaj spare parts
JG561217	BUSH-TORSION SPRING	Bajaj spare parts
JG561218	TORSION SPRING	Bajaj spare parts
JG561222	GUIDE GEAR SHIFT	Bajaj spare parts
JG561225	SHIFT RAIL GR SHIFT FORK	Bajaj spare parts
JG561226	SPRING STOPPER DRUM	Bajaj spare parts
JG561232	TORSION SPRING	Bajaj spare parts
JG561233	LEVER ASSEMBLY CHANGE	Bajaj spare parts
JG561235	SPRING	Bajaj spare parts
JG561236	ROD ASSEMBLY TIE	Bajaj spare parts

JG561240	DAMPER	Bajaj spare parts
JG571014	OIL FILTER	Bajaj spare parts
JG571015	CAP OIL FILTER	Bajaj spare parts
JG571016	O-RING	Bajaj spare parts
JG571018	GEAR OIL PUMP DRIVE	Bajaj spare parts
JG571024	MESH OIL FILTER ASSY_G2	Bajaj spare parts
JG581004	FILTER ELEMENT	Bajaj spare parts
JG581014	SILENT BLOCK(M6)	Bajaj spare parts
JG581015	INSERT (M6*1)	Bajaj spare parts
JG581033	DUCT AIR_G2	Bajaj spare parts
JG581036	BREATHER TUBE_G2	Bajaj spare parts
JG581037	TUBE DRAIN ASSLY_G2	Bajaj spare parts
JG581055	CLAMP	Bajaj spare parts
JG581056	CLAMP (BREATHER TUBE)	Bajaj spare parts
JG581058	SILENT BLOCK_AIRFILTER	Bajaj spare parts
JG581060	TUBE DRAIN	Bajaj spare parts
JG581061	CLAMP (DRAIN TUBE)	Bajaj spare parts
JG581065	AIR FILTER ASSLY INJECTION MOULDING	Bajaj spare parts
JG581073	TUBE DRAIN_INJ_MOULD AIR FILTER	Bajaj spare parts
JG581075	INSERT AIR FILTER	Bajaj spare parts
JG581076	CLAMP	Bajaj spare parts
JG581081	ASSEY TOP COVER DUKE	Bajaj spare parts
JG581086	DUCT INTAKE	Bajaj spare parts
JG581088	FILTER ASSEMBLY AIR	Bajaj spare parts
JG581092	FILTER ASSEMBLY AIR	Bajaj spare parts
JG581407	O-RING PIPE INTAKE_G2	Bajaj spare parts
JG581408	PIPE INTAKE_G2	Bajaj spare parts
JG581416	INJECTOR CAP	Bajaj spare parts
JG581419	BRACKET THROTTLE CABLE	Bajaj spare parts
JG581421	IDLE ADJUSTER	Bajaj spare parts
JG581423	FIXING SCREW	Bajaj spare parts
JG581424	FIXING SCREW	Bajaj spare parts
JG581437	FIXING SCREW	Bajaj spare parts
JG581442	CLAMP INTAKE PIPE	Bajaj spare parts
JG581444	CONNECTING TUBE	Bajaj spare parts
JG591038	BAND CLIP	Bajaj spare parts
JG591039	GASKET MUFFLER PIPE	Bajaj spare parts
JG591053	DAMPER SILENCER MOUNTING	Bajaj spare parts
JG591055	PIPE SILENCER MOUNTING	Bajaj spare parts
JG591064	HEAT SHIELD ASSLY_G2	Bajaj spare parts
JG591068	RUBBER BUSH_G2	Bajaj spare parts
JG591070	EXHAUST PIPE GASKET	Bajaj spare parts
JG591088	CLIP NUT M6	Bajaj spare parts
JG591096	BUSH SILENCER MOUNTING	Bajaj spare parts
JG591097	DAMPER SILENCER MOUNTING	Bajaj spare parts

JG591100	DAMPER SILENCER MOU LOWER	Bajaj spare parts
JG591109	PIPE A ASSY	Bajaj spare parts
JG591111	BUSH O2 SENSOR	Bajaj spare parts
JG591120	MUFFLER Y	Bajaj spare parts
JG591136	SHIELD ASSEMBLY MUFFLER	Bajaj spare parts
JG591143	CLAMP	Bajaj spare parts
JG601005	DOME NUT	Bajaj spare parts
JG601007	SPECIAL SHAFT SEAL RING	Bajaj spare parts
JG601011	COVER WATER PUMP	Bajaj spare parts
JG601012	O-RING (WATER PUMP COVER)	Bajaj spare parts
JG601013	WATER PUMP ROTOR_G2	Bajaj spare parts
JG601014	THERMOSTAT ASSY.	Bajaj spare parts
JG601016	CLAMP_G2	Bajaj spare parts
JG601018	"COOLANT HOSE THERMOSTAT TO ""T"""	Bajaj spare parts
JG601024	COVER WATER PUMP	Bajaj spare parts
JG601200	RADIATOR ASSLY WITH COLING FAN	Bajaj spare parts
JG601204	RADIATOR	Bajaj spare parts
JG601208	EXPANSION TANK	Bajaj spare parts
JG601209	CLAMP RADIATOR PIPE DIA 19.8	Bajaj spare parts
JG601210	CLAMP RADIATOR PIPE DIA 25.2	Bajaj spare parts
JG601211	CAP EXPANSION TANK	Bajaj spare parts
JG601213	TUBE DRAIN-EXPANSION TANK	Bajaj spare parts
JG601215	TUBE CONNECTING-RAD TO EXP.	Bajaj spare parts
JG601218	COOLANT HOSE RADIATOR	Bajaj spare parts
JG601220	RADIATOR HOSE	Bajaj spare parts
JG601221	O-RING COOLANT PIPE	Bajaj spare parts
JG601223	COOLANT HOSE ENG THERMOSTAT	Bajaj spare parts
JG601229	PRESSURE CAP RADIATOR	Bajaj spare parts
JG601230	EXPANSION TANK O RING	Bajaj spare parts
JG601234	CLAMP DIA 23	Bajaj spare parts
JG601235	PRESSURE CAP RADIATOR	Bajaj spare parts
JG601238	HOSE ENG.TO THERMOSTAT	Bajaj spare parts
JG601239	ASSLY COOLANT PIPE T	Bajaj spare parts
JG601243	TANK ASSEMBLY EXPANSION	Bajaj spare parts
JG601245	PIPE DRAIN	Bajaj spare parts
JG601247	PIPE TANK EXPANSION-RADIATOR	Bajaj spare parts
JG601249	RADIATOR	Bajaj spare parts
JG601250	FAN RADIATOR	Bajaj spare parts
JG601251	PIPE RADIATOR-CONNECTOR	Bajaj spare parts
JG601252	PIPE THERMOSTAT-RADIATOR	Bajaj spare parts
JG601256	CAP	Bajaj spare parts
JG601257	STRAP-CLIP SWIVEL	Bajaj spare parts
JG611004	FUEL INJECTOR	Bajaj spare parts
JG611006	CLAMP F. INJECTOR	Bajaj spare parts
JG611007	FUEL INJECTOR	Bajaj spare parts



JG611010	INJECTOR CAP	Bajaj spare parts
JG611200	ASSLY. THROTTLE BODY	Bajaj spare parts
JG611206	MOTOR STEPPER (IACV)	Bajaj spare parts
JG611209	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JG611210	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JG611212	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JG611213	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JG621412	GEAR STARTER COUNTER 1	Bajaj spare parts
JG621413	GEAR STARTER COUNTER 2 ASSY	Bajaj spare parts
JG621417	ASSLY GEAR STARTER CLUTCH	Bajaj spare parts
JG71014M	KTM FRONT FENDER	Bajaj spare parts
JG72024W	KTM FUEL TANK CVRLH	Bajaj spare parts
JG72025C	KTM FUEL TANK COVUP	Bajaj spare parts
JG72025S	KTM FUEL TANK COV	Bajaj spare parts
JG72034W	KTM FUEL TANK CVRRH	Bajaj spare parts
JG72044W	KTM SEAT COWL UP	Bajaj spare parts
JG72054W	KTM SEAT COWL UP	Bajaj spare parts
JG73015C	SIDE MASK LH W-ORANGE	Bajaj spare parts
JG73015S	KTM SIDE MASK LH	Bajaj spare parts
JG73025C	KTM SIDE MASK RH	Bajaj spare parts
JG73025S	KTM SIDE MASK RH	Bajaj spare parts
JG74035C	KTM SEAT COWL RH ORANGE	Bajaj spare parts
JH111000	FRAME ASSLY	Bajaj spare parts
JH111018	HOOK CLUTCH CABLE	Bajaj spare parts
JH111131	FRAME ASSLY	Bajaj spare parts
JH111171	BRACKET COVER CBS REAR	Bajaj spare parts
JH113004	PILLION STEP HOLDER LH	Bajaj spare parts
JH113005	PILLION STEP HOLDER RH	Bajaj spare parts
JH113006	RUBBER MAIN STEP	Bajaj spare parts
JH113008	BRACKET STAY MAIN STEP RH	Bajaj spare parts
JH113009	ASSLY PILLION STEP LH	Bajaj spare parts
JH113010	RUBBER PILLION STEP	Bajaj spare parts
JH113011	ASSLY PILLION STEP RH	Bajaj spare parts
JH113012	WASHER NYLON	Bajaj spare parts
JH113016	STAY MAIN STEP LH	Bajaj spare parts
JH113019	HOLDER PILLION STEP LH	Bajaj spare parts
JH113020	HOLDER PILLION STEP RH	Bajaj spare parts
JH113021	RUBBER PILLION STEP	Bajaj spare parts
JH113022	ASSLY PILLION STEP LH	Bajaj spare parts
JH113023	ASSLY PILLION STEP RH	Bajaj spare parts
JH113030	BAR PILLION STEP LH	Bajaj spare parts
JH113200	STAND SIDE	Bajaj spare parts
JH113201	STAND CENTER	Bajaj spare parts
JH113202	STAND SIDE	Bajaj spare parts
JH113203	DAMPER KICK STOPPER	Bajaj spare parts

JH113205	STAND SIDE	Bajaj spare parts
JH113207	STAND SIDE	Bajaj spare parts
JH113400	BRACKET ENG MTG FRONT LH	Bajaj spare parts
JH113401	BRACKET ENG MTG FRONT RH	Bajaj spare parts
JH113402	BRACKET ENG MTG TOP	Bajaj spare parts
JH113403	BRACKET ENG MTG REAR	Bajaj spare parts
JH113410	BRACKET ENG MTG TOP WITH HOOK	Bajaj spare parts
JH113414	BRACKET ASSY ENG MTG REAR	Bajaj spare parts
JH113415	ASSY BRACKET ENGINE MOUNTING TOP	Bajaj spare parts
JH113416	ASSLY ENGINE MOUNTING TOP	Bajaj spare parts
JH113800	CAP SWING ARM PIVOT	Bajaj spare parts
JH113802	CLAMP FOR PIPE	Bajaj spare parts
JH113805	STRAP FOR HARNESS	Bajaj spare parts
JH113810	TAPE ANTIABRASIVE	Bajaj spare parts
JH113828	HOOK CABLE THROTTLE	Bajaj spare parts
JH121005	FORK PIPE SPINNING	Bajaj spare parts
JH121006	UNDER BRACKET ASSY COMP	Bajaj spare parts
JH121009	ASSLY FRONT FORK DISC	Bajaj spare parts
JH121010	LEG ASSY LH	Bajaj spare parts
JH121011	LEG ASSY RH	Bajaj spare parts
JH121012	TUBE OUTER LH DISC	Bajaj spare parts
JH121013	TUBE OUTER RH DISC	Bajaj spare parts
JH121014	COVER DUST FORK LH	Bajaj spare parts
JH121016	FORK BOLT	Bajaj spare parts
JH121019	COVER DUST FORK RH	Bajaj spare parts
JH121022	HOOK FOR BR HOSE PIPE MTG	Bajaj spare parts
JH121032	SPRING MAIN	Bajaj spare parts
JH121033	SPACER TUBE	Bajaj spare parts
JH121038	ASSLY FRONT FORK DISC	Bajaj spare parts
JH121039	TUBE OUTER LH	Bajaj spare parts
JH121040	TUBE OUTER RH	Bajaj spare parts
JH121041	FORK PIPE SPINNING	Bajaj spare parts
JH121042	BELLOW	Bajaj spare parts
JH121043	ASSLY UNDER BRACKET COMP	Bajaj spare parts
JH121047	LEG ASSLY LH	Bajaj spare parts
JH121048	LEG ASSLY RH	Bajaj spare parts
JH121050	FORK ASSLY DRUM	Bajaj spare parts
JH121053	TUBE OUTER LH	Bajaj spare parts
JH121054	TUBE OUTER RH	Bajaj spare parts
JH121056	SPRING MAIN	Bajaj spare parts
JH121079	HOOK -BRAKE HOSE ROUTING	Bajaj spare parts
JH122003	SHOCKABSORBER REAR	Bajaj spare parts
JH122004	SHAFT SWING ARM	Bajaj spare parts
JH122009	SEAL DUST	Bajaj spare parts
JH122011	ASSLY SWING ARM	Bajaj spare parts

JH122012	SLEEVE	Bajaj spare parts
JH122013	BEARING NEEDLE	Bajaj spare parts
JH122014	CHAIN SLIDER	Bajaj spare parts
JH122015	SHOCKABSORBER REAR	Bajaj spare parts
JH122027	SWING ARM ASSLY	Bajaj spare parts
JH122029	ARM ASSEMBLY SWING	Bajaj spare parts
JH131001	WHEEL FRONT DISC 1.85X18-TL	Bajaj spare parts
JH131011	AXLE FRONT	Bajaj spare parts
JH131014	SENSOR DISC FRONT	Bajaj spare parts
JH131025	WHEEL FRONT DISC 1.4X18	Bajaj spare parts
JH131031	WHEEL FRONT DRUM 1.4X18	Bajaj spare parts
JH131201	WHEEL REAR 2.5X16-TUBELESS	Bajaj spare parts
JH131203	SLEEVE	Bajaj spare parts
JH131204	COLLAR	Bajaj spare parts
JH131218	WHEEL REAR 2.15X16	Bajaj spare parts
JH131233	COLLAR	Bajaj spare parts
JH131238	COLLAR	Bajaj spare parts
JH131600	ASSLY CASE METER	Bajaj spare parts
JH131800	DISC BRAKE SYSTEM	Bajaj spare parts
JH131801	ASSLY HOSE	Bajaj spare parts
JH131802	ASSLY BRAKE PANEL REAR	Bajaj spare parts
JH131803	LEVER CAM BRAKE	Bajaj spare parts
JH131820	ASSLY BRAKE PANEL FR 130 DR	Bajaj spare parts
JH131822	DISC FRONT 240MM	Bajaj spare parts
JH131825	ASSLY HOSE MASTER CYLINDER TO ABS UNI	Bajaj spare parts
JH131826	ASSLY HOSE ABS UNIT TO CALLIPER BODY	Bajaj spare parts
JH131832	DISC BRAKE SYSTEM	Bajaj spare parts
JH131833	HOSE ASSLY	Bajaj spare parts
JH131835	ASSLY CALLIPER	Bajaj spare parts
JH131850	Cyl.Asly Master Fr.	Bajaj spare parts
JH131855	MASTER CYLINDER FRONT	Bajaj spare parts
JH131864	PANEL REAR BRAKE-ABS	Bajaj spare parts
JH131866	PIPE -CALIPER TO ABS UNIT	Bajaj spare parts
JH131867	PIPE -ABS TO MASTER CYLINDER	Bajaj spare parts
JH131869	CALIPER ASSLY-FRONT	Bajaj spare parts
JH131871	LEVER -CAM-BRAKE	Bajaj spare parts
JH131880	LEVER BRAKE FRONT	Bajaj spare parts
JH131883	LEVER BRAKE CAM	Bajaj spare parts
JH131884	CLIP HARNESS SPEED SENSOR	Bajaj spare parts
JH131885	DISC BRAKE 240 DIA	Bajaj spare parts
JH131886	CALIPER ASSEMBLY	Bajaj spare parts
JH131887	DISC BRAKE 200 DIA	Bajaj spare parts
JH131890	BOOT UNIT CBS	Bajaj spare parts
JH151001	HANDLE BAR	Bajaj spare parts
JH151002	GRIP HANDLE LH	Bajaj spare parts

JH151003	ASSLY GRIP RH	Bajaj spare parts
JH151005	ASSLY UPPER BRACKET	Bajaj spare parts
JH151006	HOLDER FORK UPPER	Bajaj spare parts
JH151007	HOLDER HANDLE LOWER	Bajaj spare parts
JH151009	HANDLE HOLDER UPPER	Bajaj spare parts
JH151018	CAP STEERING	Bajaj spare parts
JH151021	HANDLE HOLDER LOWER	Bajaj spare parts
JH151026	ASSLY UPPER BRACKET	Bajaj spare parts
JH151030	ASSLY UPR BKT COMPLT EVAP	Bajaj spare parts
JH151041	WEIGHT HANDLEBAR END	Bajaj spare parts
JH161002	PAD BRAKE PEDAL	Bajaj spare parts
JH161004	BRAKE ROD	Bajaj spare parts
JH161017	ROD BRAKE-CBS	Bajaj spare parts
JH161025	NUT ADJUSTER	Bajaj spare parts
JH161031	LEVER BRAKE FRONT	Bajaj spare parts
JH161032	LEVER MAIN BRAKE FRONT	Bajaj spare parts
JH161035	ASSLY FORCE DISTRIBUTION	Bajaj spare parts
JH161038	SLEEVE PIVOT BRAKE PEDAL CBS	Bajaj spare parts
JH161041	ROD BRAKE	Bajaj spare parts
JH161200	CABLE ACCELERATOR	Bajaj spare parts
JH161202	CABLE CHOKE	Bajaj spare parts
JH161203	SEAT LOCK ASSY COMP	Bajaj spare parts
JH161204	CABLE SEAT LOCK	Bajaj spare parts
JH161209	CABLE ACCELERATOR	Bajaj spare parts
JH161210	CABLE CHOKE	Bajaj spare parts
JH161211	CABLE THROTTLE	Bajaj spare parts
JH161215	CABLE BRAKE LEVER-MASTR CYLINDER	Bajaj spare parts
JH161216	CABLE CHOKE	Bajaj spare parts
JH171008	SEAT TAPE	Bajaj spare parts
JH171014	COVER FUEL TANK FRONT	Bajaj spare parts
JH171016	DAMPER TANK MTG FRONT	Bajaj spare parts
JH171017	O RING FUEL GAUGE	Bajaj spare parts
JH171018	TUBE TANK TO T CONNECTOR	Bajaj spare parts
JH171019	TUBE DRAIN	Bajaj spare parts
JH171020	TUBE Y CONNECTOR TO CANISTER	Bajaj spare parts
JH171021	TUBE CANISTER TO PURGE VALVE	Bajaj spare parts
JH171022	TUBE PURGE VALVE TO CARBURETOR	Bajaj spare parts
JH171023	TUBE T TO Y CONNECTOR	Bajaj spare parts
JH171024	TUBE CANISTER BREATHER	Bajaj spare parts
JH171025	TUBE CANISTER DRAIN	Bajaj spare parts
JH171033	CAP FUEL TANK	Bajaj spare parts
JH171038	VALVE PURGE	Bajaj spare parts
JH171045	BEADING TANK	Bajaj spare parts
JH171047	CABLE TIE FIXED LENGHT	Bajaj spare parts
JH171048	GROMMET PURGE VALVE	Bajaj spare parts

JH171049	O RING	Bajaj spare parts
JH171072	TUBE PURGE PORT TO PURGE VALVE	Bajaj spare parts
JH171074	TUBE Y CONNECTOR TO THROTTLE BODY	Bajaj spare parts
JH171078	COVER -TANK FUEL-FRONT	Bajaj spare parts
JH171090	TUBE BREATHER CANISTER CONNECTOR	Bajaj spare parts
JH171092	TUBE VALVE PURGE-CONNECTOR Y	Bajaj spare parts
JH171601	TUBE -CANISTER DRAIN	Bajaj spare parts
JH171602	CLAMP -CANISTER BREATHER	Bajaj spare parts
JH171800	ASSLY FUEL COCK	Bajaj spare parts
JH171801	PIPE FUEL	Bajaj spare parts
JH171802	FUEL PUMP ASSLY	Bajaj spare parts
JH171803	O RING FUEL PUMP MTG	Bajaj spare parts
JH171804	PLATE PRESSURE	Bajaj spare parts
JH181200	ASSLY CHAIN CASE UPPER	Bajaj spare parts
JH181207	FAIRING MOUNTING STRUCTURE	Bajaj spare parts
JH181210	FAIRING ASSLY	Bajaj spare parts
JH181215	WINDSHIELD	Bajaj spare parts
JH181216	COVER LH SIDE	Bajaj spare parts
JH181217	COVER RH SIDE	Bajaj spare parts
JH181220	COVER SEAT COWL LH	Bajaj spare parts
JH181221	COVER SEAT COWL RH	Bajaj spare parts
JH181223	HEAD LAMP BEZEL	Bajaj spare parts
JH181228	BRACKET SEAT COWL MTG REAR	Bajaj spare parts
JH181229	ASSLY SEAT COWL	Bajaj spare parts
JH181231	COVER CARB LH	Bajaj spare parts
JH181232	COVER CARB RH	Bajaj spare parts
JH181233	BRACKET HEADLAMP MTG LOWER	Bajaj spare parts
JH181234	GROMMET TAIL LAMP MTG	Bajaj spare parts
JH181238	COVER BACK FAIRING LH	Bajaj spare parts
JH181239	COVER BACK FAIRING RH	Bajaj spare parts
JH181241	GROMMET FAIRING MTG	Bajaj spare parts
JH181242	COLLAR FAIRING MTG	Bajaj spare parts
JH181243	PAD PILLION SEAT COVER	Bajaj spare parts
JH181244	SLEEVE SEAT	Bajaj spare parts
JH181246	CHAIN COVER	Bajaj spare parts
JH181253	BEADING RUBBER	Bajaj spare parts
JH181255	WASHER RETAINING	Bajaj spare parts
JH181259	PLUG FAIRING SRTUCTURE	Bajaj spare parts
JH181262	SLEEVE FOR FAIRING MTG	Bajaj spare parts
JH181263	COLLAR FOR WINDSHIELD MTG	Bajaj spare parts
JH181265	ASSLY CARB COVER LH	Bajaj spare parts
JH181271	FOAM FAIRING 20X20X6	Bajaj spare parts
JH181293	SLEEVE CARB COVER	Bajaj spare parts
JH181299	COVER DISC	Bajaj spare parts
JH181305	COVER DISC	Bajaj spare parts

JH181306	BRACKET COVER DISC MOUNTING	Bajaj spare parts
JH181307	COVER PEDAL BRAKE CBS	Bajaj spare parts
JH181308	COVER LEVER BRAKE CBS	Bajaj spare parts
JH181400	FENDER FRONT	Bajaj spare parts
JH181403	FENDER REAR	Bajaj spare parts
JH181404	REINFORCEMENT BKT REAR FENDER	Bajaj spare parts
JH181405	CAP TOOL KIT	Bajaj spare parts
JH181408	FENDER BRACE FRONT DISC	Bajaj spare parts
JH181426	GROMMET UNDER TRAY	Bajaj spare parts
JH181430	FENDER REAR -WVTA	Bajaj spare parts
JH191000	SEAT ASSY COMP	Bajaj spare parts
JH191003	REINFORCEMENT PILLION SEAT COVER	Bajaj spare parts
JH191014	SEAT ASSLY	Bajaj spare parts
JH231201	KIT HARDWARE	Bajaj spare parts
JH231202	GUARD SAREE	Bajaj spare parts
JH231204	CAP LEG GUARD	Bajaj spare parts
JH231210	ASSLY LEG GUARD LH	Bajaj spare parts
JH231211	ASSLY LEG GUARD RH	Bajaj spare parts
JH231404	GRAB HANDLE SECONDARY	Bajaj spare parts
JH231409	KIT SECONDARY GRAB	Bajaj spare parts
JH231422	CAP BACKREST	Bajaj spare parts
JH231600	MIRROR ASSY LH	Bajaj spare parts
JH231601	MIRROR ASSY RH	Bajaj spare parts
JH232601	ASSLY LOCK SET	Bajaj spare parts
JH232602	ASSLY LOCK SET - NON EVAP	Bajaj spare parts
JH232604	ASSEMBLY LOCK SET-EVAP	Bajaj spare parts
JH232606	ASSEMBLY LOCK SET	Bajaj spare parts
JH232612	SET LOCK	Bajaj spare parts
JH232616	SET LOCK	Bajaj spare parts
JH232800	BRACKET NO. PLATE MTG	Bajaj spare parts
JH232807	BRACKET -NUMBER PLATE MTG-RR-TOP	Bajaj spare parts
JH232808	BRACKET -NUMBER PLATE MTG-RR-BTM	Bajaj spare parts
JH232809	BRACKET-NUMBER PLATE MTG-FRONT	Bajaj spare parts
JH233014	DECAL KIT TANK - BL	Bajaj spare parts
JH233015	DECAL SIDE COVER LH - BL	Bajaj spare parts
JH233016	DECAL SIDE COVER RH - BL	Bajaj spare parts
JH233018	DECAL 3D- TANK	Bajaj spare parts
JH233019	DECAL 3D- SIDE COVER	Bajaj spare parts
JH233020	DECAL- PILLION SEAT COVER	Bajaj spare parts
JH233021	DECAL KIT TANK-WH	Bajaj spare parts
JH233025	DECAL SIDE COVER LH-WH	Bajaj spare parts
JH233026	DECAL SIDE COVER RH-WH	Bajaj spare parts
JH233028	DECAL TANK KIT	Bajaj spare parts
JH233032	DECAL SIDE COVER LH	Bajaj spare parts
JH233033	DECAL SIDE COVER RH	Bajaj spare parts

JH233049	DECAL 3D - COVER SIDE-EBONY BL	Bajaj spare parts
JH233051	DECAL 3D - COVER SIDE-RED	Bajaj spare parts
JH233052	DECAL KIT TANK-BLUE	Bajaj spare parts
JH233056	DECAL SIDE COVER LH-BLUE	Bajaj spare parts
JH233057	DECAL SIDE COVER RH-BLUE	Bajaj spare parts
JH233059	DECAL WHEEL	Bajaj spare parts
JH233060	KIT DECAL TANK FLAME RED	Bajaj spare parts
JH233064	DECAL COVER SIDE LH FLAME RED	Bajaj spare parts
JH233065	DECAL COVER SIDE RH FLAME RED	Bajaj spare parts
JH233066	DECAL 3D COVER SIDE FLAME RED	Bajaj spare parts
JH233067	KIT DECAL TANK EBONY BLACK	Bajaj spare parts
JH233071	DECAL COVER SIDE LH EB BLACK	Bajaj spare parts
JH233072	DECAL COVER SIDE RH EB BLACK	Bajaj spare parts
JH233073	DECAL 3D COVER SIDE EB BLACK	Bajaj spare parts
JH233074	KIT DECAL TANK SAF BLUE	Bajaj spare parts
JH233078	DECAL COVER SIDE LH SAF BLUE	Bajaj spare parts
JH233079	DECAL COVER SIDE RH SAF BLUE	Bajaj spare parts
JH233080	DECAL 3D COVER SIDE SAF BLUE	Bajaj spare parts
JH233096	DECAL COVER SIDE LH EBONY BLACK	Bajaj spare parts
JH233097	DECAL COVER SIDE RH EBONY BLACK	Bajaj spare parts
JH233105	DECAL COVER SIDE LH CW RED	Bajaj spare parts
JH233106	DECAL COVER SIDE RH CW RED	Bajaj spare parts
JH233109	DECAL COVER SIDE LH MD BLUE	Bajaj spare parts
JH233110	DECAL COVER SIDE RH MD BLUE	Bajaj spare parts
JH233118	EMBLEM V15 EBONY BLACK	Bajaj spare parts
JH233119	EMBLEM V15 MD BLUE	Bajaj spare parts
JH351005	ASSLY STATOR C101	Bajaj spare parts
JH351007	ASSLY STATOR C101B	Bajaj spare parts
JH351017	ASSLY ROTOR WO CLUTCH C101D FI	Bajaj spare parts
JH351028	STATOR ASSEMBLY	Bajaj spare parts
JH351033	ASSEMBLY ROTOR	Bajaj spare parts
JH351200	CDI C101	Bajaj spare parts
JH351201	KIT H.T. COIL C101	Bajaj spare parts
JH351203	H.T. COIL 1_C101	Bajaj spare parts
JH351205	H.T. COIL 2_C101	Bajaj spare parts
JH351207	CDI C101B	Bajaj spare parts
JH351211	HT COIL WITH CABLE LH C101E	Bajaj spare parts
JH351213	HT COIL WITH CABLE RH C101E	Bajaj spare parts
JH351219	CDI	Bajaj spare parts
JH351222	CDI	Bajaj spare parts
JH351600	ASSLY STARTER MOTOR C101	Bajaj spare parts
JH351601	MOTOR ASSLY STARTER	Bajaj spare parts
JH351602	MOTOR ASSEMBLY STARTER	Bajaj spare parts
JH351603	MOTOR STARTER	Bajaj spare parts
JH401000	INDICATOR REAR LH	Bajaj spare parts

JH401001	INDICATOR REAR RH	Bajaj spare parts
JH401003	TAIL LAMP	Bajaj spare parts
JH401006	INDICATOR FRONT LH	Bajaj spare parts
JH401007	INDICATOR FRONT RH	Bajaj spare parts
JH401008	ASSLY HEAD LAMP	Bajaj spare parts
JH401017	INDICATOR FRONT LH	Bajaj spare parts
JH401018	INDICATOR FRONT RH	Bajaj spare parts
JH401019	HEAD LAMP ASSLY	Bajaj spare parts
JH401031	REFLECTOR SIDE	Bajaj spare parts
JH401400	SWITCH CONTROL LH	Bajaj spare parts
JH401401	SWITCH CONTROL RH	Bajaj spare parts
JH401402	SWITCH CONTROL RH	Bajaj spare parts
JH401413	SWITCH SIDE STAND	Bajaj spare parts
JH401414	SWITCH CONTORL LH	Bajaj spare parts
JH402002	REGULATOR	Bajaj spare parts
JH402003	REGULATOR	Bajaj spare parts
JH402200	HARNESS WIRING	Bajaj spare parts
JH402201	CABLE ASSLY BATTERY TO EARTH	Bajaj spare parts
JH402202	CABLE ASSLY ST MOTOR TO ST RELAY	Bajaj spare parts
JH402203	HARNESS WIRING ABS	Bajaj spare parts
JH402207	HARNESS WIRING C101B	Bajaj spare parts
JH402211	HARNESS WIRING	Bajaj spare parts
JH402219	HARNESS WIRING	Bajaj spare parts
JH402222	HARNESS PIGTAIL FUEL PUMP	Bajaj spare parts
JH402227	HARNESS WIRING	Bajaj spare parts
JH402228	HARNESS WIRNG FI	Bajaj spare parts
JH402240	HARNESS WIRING	Bajaj spare parts
JH402400	SPEEDOMETER	Bajaj spare parts
JH402401	ASSLY SPEEDOMETER ABS	Bajaj spare parts
JH402404	SPEEDOMETER	Bajaj spare parts
JH402410	SPEEDOMETER ASSLY	Bajaj spare parts
JH402413	SPEEDOMETER ASSLY	Bajaj spare parts
JH402416	GROMMET CABLE SENSOR SPEED	Bajaj spare parts
JH402600	GAUGE FUEL TANK	Bajaj spare parts
JH402601	GAUGE FUEL TANK	Bajaj spare parts
JH501001	ASSLY ENGINE C101	Bajaj spare parts
JH501003	ASSLY ENGINE C101B	Bajaj spare parts
JH501022	ENGINE ASSLY FI	Bajaj spare parts
JH501029	ENGINE ASSLY	Bajaj spare parts
JH501030	ENGINE ASSLY	Bajaj spare parts
JH501031	ENGINE ASSLY	Bajaj spare parts
JH511011	CYLINDER HEAD WITH HEAD COVER C101	Bajaj spare parts
JH511014	NIPPLE BREATHER HEAD COVER C101	Bajaj spare parts
JH511016	GASKET CYLINDER HEAD C101	Bajaj spare parts
JH511017	CAMSHAFT CAP C101	Bajaj spare parts



JH511028	PLUG 1/4 TAPPERED C101	Bajaj spare parts
JH511044	GASKET HEAD C101B	Bajaj spare parts
JH511045	RING O OHC COVER C101B	Bajaj spare parts
JH511047	GASKET BREATHER PLATE C101B	Bajaj spare parts
JH511050	O RING TAPPET COVER C101B	Bajaj spare parts
JH511087	HEAD CYLINDER COVER ASSLY	Bajaj spare parts
JH511202	VALVE INTAKE C101	Bajaj spare parts
JH511203	VALVE EXHAUST C101	Bajaj spare parts
JH511207	ASSLY ROCKER ARM C101	Bajaj spare parts
JH511210	ASSLY ROCKER ARM C101B	Bajaj spare parts
JH511212	SHAFT ROCKER ARM	Bajaj spare parts
JH511225	CAMSHAFT ASSLY	Bajaj spare parts
JH521001	GASKET CYLINDER BLOCK C101	Bajaj spare parts
JH521005	CHAIN TENSIONER C101	Bajaj spare parts
JH521007	GASKET BLOCK CYLINDER	Bajaj spare parts
JH521207	ASSLY PISTON C101B	Bajaj spare parts
JH531000	ASSLY CRANKSHAFT C101	Bajaj spare parts
JH531003	PIN CRANK C101	Bajaj spare parts
JH531007	ASSLY CRANKSHAFT C101B	Bajaj spare parts
JH541008	ASSLY CRANKCASE RH_C101	Bajaj spare parts
JH541009	ASSLY CRANKCASE RH	Bajaj spare parts
JH541015	GASKET CRANKCASE C101	Bajaj spare parts
JH541016	JET CRANKCASE C101	Bajaj spare parts
JH541021	BRACKET GEAR STOPPER C101D	Bajaj spare parts
JH541202	ASSLY MAGNETO COVER C101	Bajaj spare parts
JH541205	ASSLY COVER LH RR C101	Bajaj spare parts
JH541207	BRACKET STATOR HARNESS C101	Bajaj spare parts
JH541209	BRACKET CLUTCH CABLE C101	Bajaj spare parts
JH541210	SPRING CLUTCH RELEASE SHAFT C101	Bajaj spare parts
JH541211	LABEL GEAR SHIFT C101	Bajaj spare parts
JH541212	ASSLY CLUTCH RELEASE SHAFT C101	Bajaj spare parts
JH541215	LABEL CLUTCH COVER_C101	Bajaj spare parts
JH541216	LABEL MAGNETO COVER_C101	Bajaj spare parts
JH541217	ASSLY CAP OIL FILTER_C101	Bajaj spare parts
JH541220	ASSLY MAGNETO COVER C101D	Bajaj spare parts
JH541241	COVER ASSLY REAR LH	Bajaj spare parts
JH551001	SHAFT OUTPUT C101	Bajaj spare parts
JH551002	COLLAR SPROCKET DRIVE C101	Bajaj spare parts
JH551202	LOCK PLATE OUTPUT SPROCKET C101	Bajaj spare parts
JH551203	WASHER GEAR 3RD DRIVEN	Bajaj spare parts
JH551204	GEAR 2ND DRIVEN C101	Bajaj spare parts
JH551205	BUSH 2ND DRIVEN C101	Bajaj spare parts
JH551206	GEAR 5TH DRIVEN C101	Bajaj spare parts
JH551213	GEAR FIRST DRIVEN	Bajaj spare parts
JH551400	ASSLY CLUTCH HTTS C101	Bajaj spare parts

JH551401	ASSLY CLUTCH PLATE C101	Bajaj spare parts
JH551404	HUB CLUTCH C101HUB CLUTCH C101	Bajaj spare parts
JH551411	CLUTCH ASSLY COMPLETE	Bajaj spare parts
JH551412	PLATE ASSLY CLUTCH	Bajaj spare parts
JH551413	HUB CLUTCH	Bajaj spare parts
JH551416	CLUTCH ASSLY	Bajaj spare parts
JH551418	SPRING COMPRESSION CLUTCH	Bajaj spare parts
JH551419	PLATE CLUTCH	Bajaj spare parts
JH551421	PLATE CLUTCH	Bajaj spare parts
JH561000	FORK GEAR SHIFT 5TH DRIVEN C101	Bajaj spare parts
JH561007	DRUM ASSEMBLY GEAR SHIFT	Bajaj spare parts
JH561200	INHIBITOR GEARSHIFT C101	Bajaj spare parts
JH561212	LEVER ASSLY GEAR CHANGE	Bajaj spare parts
JH561213	ARM LEVER CHANGE	Bajaj spare parts
JH561402	ASSLY GEAR SHFT LEVER C101	Bajaj spare parts
JH561404	RUBBER DAMPER GSL_C101	Bajaj spare parts
JH561409	ROD TIE	Bajaj spare parts
JH581000	ASSLY AIR FILTER C101	Bajaj spare parts
JH581003	ELEMENT AIR FILTER C101	Bajaj spare parts
JH581004	DUCT INTAKE C101	Bajaj spare parts
JH581005	TUBE CONNECTING C101	Bajaj spare parts
JH581007	TUBE BREATHER C101	Bajaj spare parts
JH581008	ASSLY CASE AIR FILTER C101	Bajaj spare parts
JH581011	ARRESTER FLAME C101	Bajaj spare parts
JH581012	ASSLY COVER AIR FILTER C101	Bajaj spare parts
JH581015	TUBE DRAIN C101	Bajaj spare parts
JH581018	ASSLY AIR FILTER C101B PB20	Bajaj spare parts
JH581027	TUBE CONNECTING C101B PB20	Bajaj spare parts
JH581030	TUBE BREATHER C101B	Bajaj spare parts
JH581200	ASSLY CARBURATOR C101	Bajaj spare parts
JH581201	SLEEVE CARBURATOR C101	Bajaj spare parts
JH581202	CLAMP CARB SLEEVE DIA 44	Bajaj spare parts
JH581206	ASSLY CARBURATOR C101A EVAP	Bajaj spare parts
JH581207	ASSLY CARBURATOR C101B PTE20	Bajaj spare parts
JH581218	GASKET CHAMBER FLOAT	Bajaj spare parts
JH581223	GASKET TOP	Bajaj spare parts
JH581231	CARBURETTOR	Bajaj spare parts
JH581232	SLEEVE MANIFOLD	Bajaj spare parts
JH581233	CARBURETTOR	Bajaj spare parts
JH581401	ASSLY INTAKE MANIFOLD C101 SAI	Bajaj spare parts
JH581410	ASSLY INTAKE MANIFIOLD C101B PTE20	Bajaj spare parts
JH581413	INSULATOR HEAD SIDE	Bajaj spare parts
JH582200	ASSLY SAI UNIT C101	Bajaj spare parts
JH582400	HOSE INTAKE SAI C101	Bajaj spare parts
JH582402	TUBE SAI TO CYLINDER HEAD C101	Bajaj spare parts

JH582405	HOSE SAI INTAKE MANIFOLD WO ABS	Bajaj spare parts
JH582408	HOSE UNIT BREATHER-FILTER AIR	Bajaj spare parts
JH582409	HOSE UNIT BREATHER-COVER HEAD	Bajaj spare parts
JH582411	HOSE UNIT BREATHER-COVER OHC	Bajaj spare parts
JH582601	PLATE SUPPORTING SAI C101	Bajaj spare parts
JH582602	FOAM ELEMENT SAI C101	Bajaj spare parts
JH591034	SHIELD MUFFLER C101	Bajaj spare parts
JH591062	ASSLY SILENCER	Bajaj spare parts
JH611001	CAP INJECTOR	Bajaj spare parts
JH611200	ASSLY THROTTLE BODY C101D	Bajaj spare parts
JH621400	GEAR STARTER CLUTCH C101	Bajaj spare parts
JH621403	GEAR STARTER CLUTCH ASSLY	Bajaj spare parts
JH621407	GEAR DRIVE STARTER CLUTCH	Bajaj spare parts
JH990400	SEAT ASSLY VALVE - MINDA	Bajaj spare parts
JH990401	SEAT ASSLY VALVE - PAVNA	Bajaj spare parts
JK111086	FRAME ASSEMBLY	Bajaj spare parts
JK111091	HOOK	Bajaj spare parts
JK111092	GUIDE CABLE	Bajaj spare parts
JK111095	FRAME ASSEMBLY	Bajaj spare parts
JK111108	FRAME ASSEMBLY	Bajaj spare parts
JK111147	FRAME ASSEMBLY	Bajaj spare parts
JK113006	STAY LEFT	Bajaj spare parts
JK113007	STAY RIGHT	Bajaj spare parts
JK113008	STEP RUBBER PILLION	Bajaj spare parts
JK113015	STEP RIDER LH	Bajaj spare parts
JK113016	STEP ASSLY RIDER RH	Bajaj spare parts
JK113017	STEP RIDER RH	Bajaj spare parts
JK113024	STEP ASSEMBLY RIDER LH	Bajaj spare parts
JK113025	STEP RIDER LH	Bajaj spare parts
JK113406	HANGER ENGINE	Bajaj spare parts
JK113407	ASSEMBLY BRACKET ENGINE FRONT LH	Bajaj spare parts
JK113410	ASSEMBLY BRACKET ENGINE FRONT RH	Bajaj spare parts
JK113415	HANGER ASSEMBLY ENGINE RH	Bajaj spare parts
JK113802	GROMMET	Bajaj spare parts
JK113803	COLLAR	Bajaj spare parts
JK113804	CAP	Bajaj spare parts
JK113818	BRACKET UNIT ABS	Bajaj spare parts
JK113820	BRACKET UNIT ABS	Bajaj spare parts
JK113829	HOOK	Bajaj spare parts
JK121000	FORK FR 130 DR	Bajaj spare parts
JK121007	BUSH GUIDE	Bajaj spare parts
JK121008	SPACER TUBE	Bajaj spare parts
JK121009	WASHER GUIDE BUSH	Bajaj spare parts
JK121012	PIPE LEFT FORK OUTER	Bajaj spare parts
JK121013	PIPE RIGHT FORK OUTF	Bajaj spare parts

JK121014	FORK FRONT	Bajaj spare parts
JK121024	FORK ASSEMBLY FRONT	Bajaj spare parts
JK121025	LEG ASSEMBLY LH	Bajaj spare parts
JK121026	FORK FRONT	Bajaj spare parts
JK121027	LEG ASSEMBLY RH	Bajaj spare parts
JK121028	LEG ASSLY LH	Bajaj spare parts
JK121029	TUBE OUTER LH	Bajaj spare parts
JK121030	LEG ASSLY RH	Bajaj spare parts
JK121031	TUBE OUTER RH	Bajaj spare parts
JK121036	BRACKET ASSEMBLY-CLAMP HOSE	Bajaj spare parts
JK121040	BRACKET ASSEMBLY-CLAMP HOSE	Bajaj spare parts
JK121042	FORK FRONT	Bajaj spare parts
JK122002	ADJUSTER CHAIN LH	Bajaj spare parts
JK122004	ADJUSTER CHAIN RH	Bajaj spare parts
JK122006	SHAFT SWING ARM	Bajaj spare parts
JK122007	NUT DOMED CAP	Bajaj spare parts
JK122008	NUT HEX NYLOC	Bajaj spare parts
JK122009	WASHER SPRING	Bajaj spare parts
JK122010	NUT HEXAGONM12 X 1.	Bajaj spare parts
JK122011	ROD TORQUE	Bajaj spare parts
JK122012	ASSEMBLY ARM SWING	Bajaj spare parts
JK122021	SHOCKABSORBER REAR	Bajaj spare parts
JK122030	ARM ASSEMBLY SWING	Bajaj spare parts
JK131003	SPACER	Bajaj spare parts
JK131015	AXLE FRONT	Bajaj spare parts
JK131016	STOPPER BUSHING	Bajaj spare parts
JK131023	AXLE	Bajaj spare parts
JK131024	LEVER BRAKE CAM	Bajaj spare parts
JK131025	CAM BRAKE	Bajaj spare parts
JK131026	WHEEL 1.4X17 (DIA 110 DRUM)	Bajaj spare parts
JK131030	WHEEL FRONT 1.4X17 DISC	Bajaj spare parts
JK131031	CASE ASSY METER GEAR	Bajaj spare parts
JK131037	WHEEL FR 1.4X17 DIA 110 BLK	Bajaj spare parts
JK131042	CLAMP HOSE BRAKE	Bajaj spare parts
JK131044	WHEEL FRONT MT 1.85X17	Bajaj spare parts
JK131051	WHEEL FRONT MT 1.85X17 DRUM	Bajaj spare parts
JK131063	DISC SENSOR SPEED FRONT	Bajaj spare parts
JK131201	AXLE REAR M12X1.25	Bajaj spare parts
JK131202	SLEEVE	Bajaj spare parts
JK131204	COLLAR	Bajaj spare parts
JK131218	COLLAR	Bajaj spare parts
JK131219	SPACER	Bajaj spare parts
JK131228	WHEEL REAR 1.85X17	Bajaj spare parts
JK131235	DISC SENSOR SPEED REAR	Bajaj spare parts
JK131604	PANEL FRONT BRAKE	Bajaj spare parts

JK131605	COLLAR ASSEMBLY	Bajaj spare parts
JK131606	COLLAR	Bajaj spare parts
JK131806	PANEL FRONT BRAKE	Bajaj spare parts
JK131807	COLLER AXLE ASSLY	Bajaj spare parts
JK131813	BRAKE SYSTEM FRONT	Bajaj spare parts
JK131814	CALIPER ASSEMBLY FRONT	Bajaj spare parts
JK131815	DISC BRAKE DIA 240	Bajaj spare parts
JK131825	PANEL BRAKE REAR	Bajaj spare parts
JK131833	UNIT ABS WET	Bajaj spare parts
JK131835	ROD BRAKE	Bajaj spare parts
JK131840	UNIT ABS	Bajaj spare parts
JK131844	CAM ASSEMBLY BRAKE	Bajaj spare parts
JK131849	HOOK	Bajaj spare parts
JK151018	GRIP LH	Bajaj spare parts
JK151019	GRIP ASSEMBLY RH	Bajaj spare parts
JK161001	ROD BRAKE	Bajaj spare parts
JK161002	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JK161003	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JK161004	ASSEMBLY LEVER-HOLDER RH	Bajaj spare parts
JK161200	CABLE ACCELERATOR	Bajaj spare parts
JK161202	CABLE BRAKE FRONT	Bajaj spare parts
JK161205	CABLE THROTTLE	Bajaj spare parts
JK161207	CABLE CLUTCH	Bajaj spare parts
JK161208	CABLE PEDAL-CYLINDER MASTER	Bajaj spare parts
JK161215	CABLE BRAKE FRONT	Bajaj spare parts
JK171050	PIPE VALVE PURGE-CARBURETTOR	Bajaj spare parts
JK171056	PIPE VALVE PURGE-CARBURETTOR	Bajaj spare parts
JK171058	PIPE FUEL	Bajaj spare parts
JK171064	PAD ASSEMBLY TANK	Bajaj spare parts
JK181001	WINDSHIELD	Bajaj spare parts
JK181246	BRACKET ASSLY FAIRING UPPER	Bajaj spare parts
JK181247	FLAP SPEEDOMETER	Bajaj spare parts
JK181257	FOAM	Bajaj spare parts
JK181259	TAPE	Bajaj spare parts
JK181260	BRACKET FORK	Bajaj spare parts
JK181263	BRACKET	Bajaj spare parts
JK181267	FLAP SPEEDOMETER	Bajaj spare parts
JK181272	WINDSHIELD	Bajaj spare parts
JK181275	EXTENSION FLAP SPEEDOMETER LH	Bajaj spare parts
JK181276	EXTENSION FLAP SPEEDOMETER RH	Bajaj spare parts
JK181277	BRACKET FAIRING LOWER	Bajaj spare parts
JK181278	BRACKET FAIRING UPPER	Bajaj spare parts
JK181279	BRACKET INDICATOR FRONT	Bajaj spare parts
JK181291	BRACKET ASSEMBLY-CLAMP HOSE	Bajaj spare parts
JK181302	CLAMP ASSEMBLY	Bajaj spare parts

JK181304	COVER SWITCH STAND SIDE	Bajaj spare parts
JK181412	TAPE	Bajaj spare parts
JK181413	FENDER HUGGER	Bajaj spare parts
JK181416	BRACE ASSEMBLY FRONT-GUIDE CABLE	Bajaj spare parts
JK181426	BRACE ASSEMBLY FENDER FRONT	Bajaj spare parts
JK191003	SEAT ASSEMBLY	Bajaj spare parts
JK191005	DAMPER SEAT	Bajaj spare parts
JK191006	SEAT ASSEMBLY	Bajaj spare parts
JK231203	GUARD SAREE	Bajaj spare parts
JK231204	BOLT HX SOKET M10	Bajaj spare parts
JK231206	GUARD ASSEMBLY SAREE	Bajaj spare parts
JK231207	GUARD LEG RH	Bajaj spare parts
JK231208	GUARD LEG LH	Bajaj spare parts
JK231209	GUARD HAND LH	Bajaj spare parts
JK231210	GUARD HAND RH	Bajaj spare parts
JK231214	GUARD HAND RH	Bajaj spare parts
JK231400	GRIP FRAME	Bajaj spare parts
JK231600	MIRROR LH	Bajaj spare parts
JK231601	MIRROR RH	Bajaj spare parts
JK232600	LOCK SET 3 IN 1	Bajaj spare parts
JK232603	SET LOCK	Bajaj spare parts
JK233051	DECAL COVER SIDE LH BLACK BLUE	Bajaj spare parts
JK233052	DECAL COVER SIDE RH BLACK BLUE	Bajaj spare parts
JK233066	DECAL COVER SIDE LH BLACK GREY	Bajaj spare parts
JK233067	DECAL COVER SIDE RH BLACK GREY	Bajaj spare parts
JK233081	DECAL COVER SIDE LH C W RED	Bajaj spare parts
JK233082	DECAL COVER SIDE RH C W RED	Bajaj spare parts
JK233094	DECAL COVER SIDE LH E BLUE	Bajaj spare parts
JK233095	DECAL COVER SIDE RH E BLUE	Bajaj spare parts
JK233110	DECAL COVER SIDE LH BLUE	Bajaj spare parts
JK233111	DECAL COVER SIDE RH BLUE	Bajaj spare parts
JK233118	EMBLEM PLATINA	Bajaj spare parts
JK233127	DECAL COVER SIDE LH RED	Bajaj spare parts
JK233128	DECAL COVER SIDE RH RED	Bajaj spare parts
JK233144	DECAL COVER SIDE LH C W RED	Bajaj spare parts
JK233145	DECAL COVER SIDE RH C W RED	Bajaj spare parts
JK233153	DECAL WHEEL BLUE	Bajaj spare parts
JK233154	DECAL WHEEL RED	Bajaj spare parts
JK233155	DECAL WHEEL C W RED	Bajaj spare parts
JK233157	DECAL ANTI SKID	Bajaj spare parts
JK233209	DECAL COVER SIDE LH C BLACK	Bajaj spare parts
JK233210	DECAL COVER SIDE RH C BLACK	Bajaj spare parts
JK233251	DECAL COVER SIDE LH S BEACH BLUE	Bajaj spare parts
JK233252	DECAL COVER SIDE RH S BEACH BLUE	Bajaj spare parts
JK233265	DECAL COVER SIDE LH V MATTE RED	Bajaj spare parts

JK233266	DECAL COVER SIDE RH V MATTE RED	Bajaj spare parts
JK233282	DECAL WHEEL LH	Bajaj spare parts
JK233283	DECAL WHEEL RH	Bajaj spare parts
JK233296	DECAL WHEEL E BLACK G P GRAY	Bajaj spare parts
JK233307	DECAL COVER SIDE E B G P GRAY LH	Bajaj spare parts
JK233308	DECAL COVER SIDE E B G P GRAY RH	Bajaj spare parts
JK233323	DECAL COVER SIDE EBONY BLACK RH	Bajaj spare parts
JK233330	DECAL COVER SIDE GLOSS P G LH	Bajaj spare parts
JK233331	DECAL COVER SIDE GLOSS P G RH	Bajaj spare parts
JK233338	DECAL COVER SIDE COCKTAIL W R LH	Bajaj spare parts
JK233362	DECAL WHEEL BRASS GOLD LH	Bajaj spare parts
JK233363	DECAL WHEEL BRASS GOLD RH	Bajaj spare parts
JK233374	DECAL COVER SIDE DARK M B LH	Bajaj spare parts
JK233375	DECAL COVER SIDE DARK M B RH	Bajaj spare parts
JK351001	STATOR ASSY	Bajaj spare parts
JK351005	STATOR ASSY PLATINA UG	Bajaj spare parts
JK351201	COIL H T PRIMARY	Bajaj spare parts
JK351202	COIL H.T. WITH CABLE	Bajaj spare parts
JK351600	RALAY STARTER	Bajaj spare parts
JK401001	LAMP HEAD ASSEMBLY	Bajaj spare parts
JK401007	BLINKER RR LH AMBR LENS	Bajaj spare parts
JK401008	BLINKER RR RH AMBR LENS	Bajaj spare parts
JK401009	BLINKER FR LH AMBR LENS	Bajaj spare parts
JK401010	BLINKER FR RH AMBR LENS	Bajaj spare parts
JK401023	LAMP ASSLY HEAD	Bajaj spare parts
JK401024	BULB LAMP HEAD	Bajaj spare parts
JK401025	LAMP ASSLY-DRL	Bajaj spare parts
JK401027	LAMP TAIL	Bajaj spare parts
JK401028	INDICATOR FRONT LH	Bajaj spare parts
JK401029	INDICATOR FRONT RH	Bajaj spare parts
JK401402	CONTROL SWITCH RH(KS)	Bajaj spare parts
JK401410	SWITCH CONTROL LH	Bajaj spare parts
JK401412	SWITCH STAND SIDE	Bajaj spare parts
JK401415	SWITCH ASSEMBLY STAND SIDE	Bajaj spare parts
JK401801	FOAM BATTERY BAND	Bajaj spare parts
JK402000	REGULATOR DC	Bajaj spare parts
JK402200	HARNESS WIRING P	Bajaj spare parts
JK402205	CABLE RELAY TO MOTO	Bajaj spare parts
JK402209	HARNESS WIRING (SS_125)	Bajaj spare parts
JK402213	HARNESS WIRING	Bajaj spare parts
JK402214	HARNESS WIRING	Bajaj spare parts
JK402227	HARNESS WIRING	Bajaj spare parts
JK402231	HARNESS WIRING	Bajaj spare parts
JK402232	CABLE EARTH	Bajaj spare parts
JK402235	HARNESS WIRING	Bajaj spare parts

JK402239	HARNESS WIRING	Bajaj spare parts
JK402241	HARNESS WIRING	Bajaj spare parts
JK402242	HARNESS WIRING	Bajaj spare parts
JK402243	HARNESS WIRING	Bajaj spare parts
JK402244	HARNESS WIRING	Bajaj spare parts
JK402249	HARNESS WIRING	Bajaj spare parts
JK402276	HARNESS WIRING	Bajaj spare parts
JK402280	HARNESS WIRING	Bajaj spare parts
JK402402	MACHINE SPPEDOMETER MINDA	Bajaj spare parts
JK402403	MACHINE SPPEDOMETER PRICO	Bajaj spare parts
JK402406	DIAL FUEL GAUGE	Bajaj spare parts
JK402409	ADAPTER F G DIAL	Bajaj spare parts
JK402410	CASE WHITE SPEDOMETER	Bajaj spare parts
JK402411	SPEEDOMETER	Bajaj spare parts
JK402413	SPEEDOMETER	Bajaj spare parts
JK402414	SPEEDOMETER	Bajaj spare parts
JK402415	SPEEDOMETER	Bajaj spare parts
JK402417	SPEEDOMETER	Bajaj spare parts
JK402420	INSTRUMENT CLUSTER	Bajaj spare parts
JK403600	SENSOR ASSEMBLY SPEED	Bajaj spare parts
JK403601	SENSOR ASSEMBLY SPEED	Bajaj spare parts
JK403603	HOUSING SENSOR SPEED	Bajaj spare parts
JK403604	SENSOR LEVEL FUEL	Bajaj spare parts
JK511002	CLAMP HOSE BREATHER	Bajaj spare parts
JK531000	CRANK SHAFT	Bajaj spare parts
JK541212	DAMPER COVER CLUTCH	Bajaj spare parts
JK541213	DAMPER MAGNETO COVER_PL_BM	Bajaj spare parts
JK541214	DECAL COVER MAGNETO	Bajaj spare parts
JK551402	COMPRESSION SPRING	Bajaj spare parts
JK561206	ASSEMBLY LEVER CHANGE	Bajaj spare parts
JK561208	ARM LEVER CHANGE	Bajaj spare parts
JK581201	CARBURETTOR VM16 PL UG	Bajaj spare parts
JK73043F	FENDER FR FLAME RED	Bajaj spare parts
JK73044C	FENDER FR BLACK	Bajaj spare parts
JK990400	TAPE	Bajaj spare parts
JL111054	ENGINE MTG BOLT FRONT	Bajaj spare parts
JL111078	BRACKET HORN MTG LH	Bajaj spare parts
JL111081	BRACKET LOOSE H.T.COIL 1	Bajaj spare parts
JL111082	BRACKET LOOSE H.T.COIL 2	Bajaj spare parts
JL111092	BRACKET RADIATOR LOWER MTG LH	Bajaj spare parts
JL111093	BRACKET RADIATOR RH	Bajaj spare parts
JL111102	BRACKET SIDE COVER MTG	Bajaj spare parts
JL111103	CAP TUBE END	Bajaj spare parts
JL111106	FRAME ASSLY COMPLETE	Bajaj spare parts
JL111152	EDGE CAP BKT SIDE COVER MTG.	Bajaj spare parts



JL111183	FRAME ASSLY COMP (K16)	Bajaj spare parts
JL111221	FRAME ASSLY - K14 EURO IV	Bajaj spare parts
JL111233	ASSLY FRAME -K4 EVAP	Bajaj spare parts
JL111246	FRAME ASSEMBLY	Bajaj spare parts
JL111254	BRACKET HORN	Bajaj spare parts
JL113000	STEP ASSLY MAIN LH	Bajaj spare parts
JL113006	RUBBER MAIN STEP	Bajaj spare parts
JL113007	STEP ASSY MAIN RH	Bajaj spare parts
JL113012	SPRING TORSION	Bajaj spare parts
JL113013	STEP HOLDER- PILLION LH	Bajaj spare parts
JL113014	STEP PILLION ASSY COMPLETE LH	Bajaj spare parts
JL113015	STEP HOLDER - PILLION RH	Bajaj spare parts
JL113016	STEP PILLION ASSY COMPLETE RH	Bajaj spare parts
JL113027	FLAP PILLON HOLDER RH	Bajaj spare parts
JL113028	RUBBER PAD FOOTREST	Bajaj spare parts
JL113033	BRACKET REAR BRAKE SWITCH	Bajaj spare parts
JL113034	HOLDER STEP LH	Bajaj spare parts
JL113035	BOLT -BANKING	Bajaj spare parts
JL113036	RUBBER PILLON STEP	Bajaj spare parts
JL113037	PIN FOOT STEP	Bajaj spare parts
JL113038	STEP BOLT-SPL	Bajaj spare parts
JL113042	TAPE STEP HOLDER LH	Bajaj spare parts
JL113043	TAPE STEP HOLDER RH	Bajaj spare parts
JL113056	PIN FOOT STEP	Bajaj spare parts
JL113057	STEP HOLDER LH (K16A)	Bajaj spare parts
JL113059	TAPE HOLDER STEP LH	Bajaj spare parts
JL113201	STAND SIDE	Bajaj spare parts
JL113202	BRACKET STAND SIDE_OKAYFERN	Bajaj spare parts
JL113206	SPRING MAIN STAND WITH COVER	Bajaj spare parts
JL113207	SPRING MAIN STAND	Bajaj spare parts
JL113209	SPRING SIDE STAND	Bajaj spare parts
JL113210	BUSH MAIN STAND LH	Bajaj spare parts
JL113212	COVER SPRING MAIN STAND	Bajaj spare parts
JL113215	CENTER STAND	Bajaj spare parts
JL113223	BUSH ANC HORPIN	Bajaj spare parts
JL113400	ENGINE STAY LH	Bajaj spare parts
JL113401	ENGINE STAY RH	Bajaj spare parts
JL113800	BRACKET REAR BLINKER MTG	Bajaj spare parts
JL113803	BRACKET -REFLECTOR REFLEX MTG	Bajaj spare parts
JL113809	GROMMET AIR FILTER RESTING	Bajaj spare parts
JL113810	BRACKET NUMBER PLATE	Bajaj spare parts
JL113811	GROMMET -ILLUMINATION BKT	Bajaj spare parts
JL113812	SLEEVE -ILLUMINATION BKT	Bajaj spare parts
JL113818	COVER SIDE STAND SWITCH(K14)	Bajaj spare parts
JL113821	SPACER BLINKER MTG (K14)	Bajaj spare parts

JL113822	BRACKET NUMBER PLATE ILLU	Bajaj spare parts
JL113824	BRACKET RELAY MTG (LOOSE	Bajaj spare parts
JL113825	BAND BATTERY CASE-VERT ECU	Bajaj spare parts
JL113827	BRACKET SAI UNIT MTG-LOOSE	Bajaj spare parts
JL113828	CLAMP SAI HOSE MTG	Bajaj spare parts
JL113829	BRACKET HORN MTG	Bajaj spare parts
JL113830	BRACKET CANISTER MTG (K14)	Bajaj spare parts
JL113832	BRACKET TANK SIDE COVER MTG.	Bajaj spare parts
JL113833	BKT SPEEDO CABLE ROUTING	Bajaj spare parts
JL113834	BRACKET HOSE CLAMP	Bajaj spare parts
JL113835	CLAMP BRAKE HOSE K16A	Bajaj spare parts
JL113836	BRACKET CDI MTG LOOSE K-16A	Bajaj spare parts
JL113837	BKT FRONT BRAKE HOSE CLAMP ON UNDER	Bajaj spare parts
JL113839	BRACKET BRAKE HOSE CLAMP	Bajaj spare parts
JL113841	CLAMP TIE CABLE	Bajaj spare parts
JL113844	BRACKET UNIT SAI	Bajaj spare parts
JL121001	MAIN SPRING	Bajaj spare parts
JL121005	FORK ASSLY ABS -K16A	Bajaj spare parts
JL121006	ASSLY LEG RH-K16A ABS	Bajaj spare parts
JL121007	ASSLY LEG LH-K16A ABS	Bajaj spare parts
JL121008	FORK PIPE INNER -K16A ABS	Bajaj spare parts
JL121032	FORK FRONT	Bajaj spare parts
JL122001	ADJUSTER CHAIN LH	Bajaj spare parts
JL122002	CAP SWING ARM TUBE	Bajaj spare parts
JL122003	SLIDER CHAIN	Bajaj spare parts
JL122004	SPACER CHAIN ADJUSTER	Bajaj spare parts
JL122006	SHOCKABSORBER MONO	Bajaj spare parts
JL122008	SPACER CENTRAL SWING ARM	Bajaj spare parts
JL122009	ADJUSTER CHAIN RH	Bajaj spare parts
JL122013	ASSLY SWING ARM-DISC	Bajaj spare parts
JL122026	SHAFT SWING ARM ASSLY	Bajaj spare parts
JL122032	TAPE	Bajaj spare parts
JL122037	SHOCKABSORBER REAR	Bajaj spare parts
JL131000	COLLAR	Bajaj spare parts
JL131001	AXLE	Bajaj spare parts
JL131004	WHEEL 2.5X17 DIE CAST	Bajaj spare parts
JL131005	DISC FRONT	Bajaj spare parts
JL131034	AXLE DIA 15	Bajaj spare parts
JL131203	AXLE REAR	Bajaj spare parts
JL131209	WHEEL 3.5 X 17	Bajaj spare parts
JL131211	SPACER FOR COUPLING	Bajaj spare parts
JL131216	COLLAR BEARING ASSY	Bajaj spare parts
JL131218	DISC -REAR	Bajaj spare parts
JL131220	HOSE -RESEVOIR	Bajaj spare parts
JL131225	COUPLING -6 LUG	Bajaj spare parts

JL131226	WASHER -COUPLING (6 PETAL)	Bajaj spare parts
JL131232	DAMPER -COUPLING	Bajaj spare parts
JL131801	DISC BRAKE KIT REAR	Bajaj spare parts
JL131802	HOSE ASSLY	Bajaj spare parts
JL131803	HOSE DISC BRAKE REAR	Bajaj spare parts
JL131804	CALIPER ASSY BRAKE FRONT	Bajaj spare parts
JL131805	PAD	Bajaj spare parts
JL131806	SCREW BLEEDER	Bajaj spare parts
JL131807	BOOT	Bajaj spare parts
JL131809	PIN CLIP	Bajaj spare parts
JL131810	BRAKE ROD	Bajaj spare parts
JL131811	BRACKET -HOSE CLAMP	Bajaj spare parts
JL131812	BRACKET HOSE CLAMP TOP	Bajaj spare parts
JL131813	BRACKET MTG RESEVOIR	Bajaj spare parts
JL131825	PAD SPRING	Bajaj spare parts
JL131832	BRAKE PAD SET	Bajaj spare parts
JL131834	CALIPER ASSLY	Bajaj spare parts
JL131841	BRACKET RESORVIOR MTG	Bajaj spare parts
JL131877	CLAMP HOSE RESERVOIR	Bajaj spare parts
JL131878	BRACKET -RESERVOIR CAP	Bajaj spare parts
JL131907	BRAKE HOSE REAR	Bajaj spare parts
JL131918	MASTER CYLINDER ASSY FRONT	Bajaj spare parts
JL131920	KIT DISC BRAKE FRONT - K16	Bajaj spare parts
JL131928	ASSY BRAKE SHAFT-K16A(1CH ABS)	Bajaj spare parts
JL131929	UNIT ABS WET -K16A	Bajaj spare parts
JL131930	DISC REAR DIA 230MM	Bajaj spare parts
JL131931	CYLINDER ASSLY MASTER BRAKE RR	Bajaj spare parts
JL131940	UNIT ABS WET	Bajaj spare parts
JL131945	BRACKET CLAMP HOSE	Bajaj spare parts
JL131951	CALIPER ASSEMBLY FRONT	Bajaj spare parts
JL131960	CALIPER ASSEMBLY FRONT	Bajaj spare parts
JL131961	CLAMP ASSEMBLY	Bajaj spare parts
JL131974	UNIT ABS WET	Bajaj spare parts
JL131992	BRACKET HOSE BRAKE REAR	Bajaj spare parts
JL131993	UNIT ABS WET	Bajaj spare parts
JL131994	CYLINDER ASSEMBLY MASTER FRONT	Bajaj spare parts
JL141000	CHAIN O RING TYPE	Bajaj spare parts
JL141002	CHAIN DRIVE X-RING - 108LINK	Bajaj spare parts
JL151002	TUBE OUTER LH	Bajaj spare parts
JL151003	TUBE OUTER RH	Bajaj spare parts
JL151004	FORK PIPE SPINNING	Bajaj spare parts
JL151021	HANDLE	Bajaj spare parts
JL151023	LOCK SET 3 IN 1	Bajaj spare parts
JL151024	FORK ASSLY-FRONT	Bajaj spare parts
JL151026	HOLDER HANDLE LH	Bajaj spare parts

JL151028	PLUG HANDLE HOLDER	Bajaj spare parts
JL151030	HOLDER HANDLE RH	Bajaj spare parts
JL151032	UPPER BRACKET	Bajaj spare parts
JL151034	HANDLEBAR TUBE ASSY RH	Bajaj spare parts
JL151035	HANDLEBAR WEIGHT	Bajaj spare parts
JL151036	STEERING TOP BOLT	Bajaj spare parts
JL151037	UNDER BKT ASSY COMPLETE	Bajaj spare parts
JL151038	'O' RING	Bajaj spare parts
JL151053	HOOK CLUTCH CABLE	Bajaj spare parts
JL151054	HOOK THROTTLE CABLE	Bajaj spare parts
JL161001	BRAKE PEDAL	Bajaj spare parts
JL161003	HANDLE GRIP LH	Bajaj spare parts
JL161005	SHAFT ASSY BRAKE LEVER	Bajaj spare parts
JL161006	SPRING REAR BRAKE SWITCH	Bajaj spare parts
JL161008	GRIP HAND ASSY RH	Bajaj spare parts
JL161010	SHAFT ASSY BRAKE LEVER-DISC	Bajaj spare parts
JL161011	LEVER & SUPPORT HOLDER ASSY	Bajaj spare parts
JL161012	LEVER -CLUTCH	Bajaj spare parts
JL161013	LEVER & SUPPORT HOLDER ASSY	Bajaj spare parts
JL161014	SUPPORT HOLDER LH	Bajaj spare parts
JL161015	LEVER AND SUPPORT HOLDER ASSY	Bajaj spare parts
JL161016	LEVER & SUPPORT HOLDER ASSY (K14)	Bajaj spare parts
JL161017	PEDAL BRAKE	Bajaj spare parts
JL161200	CABLE CLUTCH	Bajaj spare parts
JL161201	CABLE THROTTLE	Bajaj spare parts
JL161205	THROTTLE CABLE (K14)	Bajaj spare parts
JL161206	THROTTLE CABLE (K16A)	Bajaj spare parts
JL161207	CABLE CLUTCH K16A	Bajaj spare parts
JL171018	GROMMET TANK MTG FRONT	Bajaj spare parts
JL171019	SLEEVE TANK MTG FRONT	Bajaj spare parts
JL171020	GROMMET TANK MTG REAR	Bajaj spare parts
JL171022	BRACKET SIDE COVER MTG LH	Bajaj spare parts
JL171024	DAMPER STRUCTURE MTG	Bajaj spare parts
JL171025	SLEEVE STRUCTURE MTG	Bajaj spare parts
JL171028	DAMPER TANK COVER RESTING FR LH	Bajaj spare parts
JL171029	DAMPER TANK COVER RESTING FR RH	Bajaj spare parts
JL171030	DAMPER TNK COVR RESTING CENTL LH	Bajaj spare parts
JL171031	DAMPER TNK COVR RESTING CENTL RH	Bajaj spare parts
JL171032	DAMPER TANK COVER RESTING REAR	Bajaj spare parts
JL171035	TUBE FUEL (TANK)	Bajaj spare parts
JL171036	TUBE FUEL (CARBURETTOR)	Bajaj spare parts
JL171037	BREATHING TUBE	Bajaj spare parts
JL171038	BEADING TANK LH	Bajaj spare parts
JL171040	SLEEVE (STRUCTURE)	Bajaj spare parts
JL171044	TANK ASSLY	Bajaj spare parts

JL171045	TANK COVER SIDE LH	Bajaj spare parts
JL171046	TANK COVER SIDE RH	Bajaj spare parts
JL171048	COVER CENTRAL TANK	Bajaj spare parts
JL171049	DAMPER RING	Bajaj spare parts
JL171057	DAMPER -TANK SIDECOVER	Bajaj spare parts
JL171060	O RING-FOR KNOB	Bajaj spare parts
JL171061	GRILL-TANK SIDE COVER LH	Bajaj spare parts
JL171062	GRILL -TANK SIDE COVER RH	Bajaj spare parts
JL171063	PIPE DRAIN	Bajaj spare parts
JL171070	TANK COVER GROMMET	Bajaj spare parts
JL171071	TANK COVER MTG SLEEVE	Bajaj spare parts
JL171073	DAMPER TANK CVR RESTIG RR	Bajaj spare parts
JL171078	PAD TANK COVER	Bajaj spare parts
JL171081	TANK ASSY-(GAGE TOP MTG)	Bajaj spare parts
JL171085	SPRING FUEL TUBE	Bajaj spare parts
JL171096	GASKET FUEL COCK	Bajaj spare parts
JL171099	BRACKET SIDE COVER MTG RH (K14)	Bajaj spare parts
JL171101	CLAMP BAND SPRING 9.5X8.4	Bajaj spare parts
JL171102	CLAMP BAND SPRING 12.5X8	Bajaj spare parts
JL171111	TANK ASSEMBLY FUEL	Bajaj spare parts
JL171600	CAP TANK	Bajaj spare parts
JL171607	TUBE PURGE VALVE TO CARB	Bajaj spare parts
JL171610	PIPE CONNECTOR-CANISTER	Bajaj spare parts
JL171616	PIPE CONNECTOR-PLUG	Bajaj spare parts
JL171617	PIPE CONNECTOR-VALVE PURGE	Bajaj spare parts
JL171618	PIPE VALVE PURGE-CONNECTOR	Bajaj spare parts
JL171619	PIPE CONNECTOR-CANISTER	Bajaj spare parts
JL171625	PIPE FUEL	Bajaj spare parts
JL171626	PIPE FUEL	Bajaj spare parts
JL171627	PIPE FUEL	Bajaj spare parts
JL171628	PIPE FUEL	Bajaj spare parts
JL171800	TAP FUEL ASSLY	Bajaj spare parts
JL171801	KNOB FUEL TAP	Bajaj spare parts
JL171802	FILTER INLINE	Bajaj spare parts
JL171803	PIN SNAP FOR KNOB	Bajaj spare parts
JL171805	STEP BOLT FUEL PUMP MTG	Bajaj spare parts
JL171810	FUEL TANK ASSLY FUEL COCK EVAP	Bajaj spare parts
JL171823	ADD-ON BKT LH TANK TOP COVER	Bajaj spare parts
JL171824	ADD-ON BKT RH TANK TOP COVER	Bajaj spare parts
JL171825	SUB-ASSLY TANK TOP COVER (K16)	Bajaj spare parts
JL171830	ASSY TUBE FL PP TO FL FLTR WITH QC	Bajaj spare parts
JL171832	ASSY TUBE FL FLTR TO RR WITH QC	Bajaj spare parts
JL171836	TUBE TANK TO Y CONNECTOR-K14 (BRAZIL)	Bajaj spare parts
JL171837	TUBE Y CONNECTOR TO CANISTER -K14	Bajaj spare parts
JL171839	TUBE CANISTER TO PURGE VALVE-K14	Bajaj spare parts

JL171841	TANK ASSEMBLY FUEL	Bajaj spare parts
JL171852	FUEL PUMP ASSY-(PH-III)	Bajaj spare parts
JL171854	HOSE PURGE VALVE TO CONNECTOR	Bajaj spare parts
JL171856	ASSLY FUEL PUMP PHASE III - K14	Bajaj spare parts
JL171858	PLATE PRESSURE	Bajaj spare parts
JL171867	PIPE FUEL	Bajaj spare parts
JL181005	SEAT COWL ASSY	Bajaj spare parts
JL181006	TUBE REAR HUGGER MTG	Bajaj spare parts
JL181008	WINDSHIELD ASSLY	Bajaj spare parts
JL181012	SEAT COWL ASSLY (K16)	Bajaj spare parts
JL181017	SHROUD ASSLY LH	Bajaj spare parts
JL181019	SHROUD ASSLY RH	Bajaj spare parts
JL181024	BOLT SOCKET HEAD M5XL16XTAPER	Bajaj spare parts
JL181025	BOLT SOCKET HEAD M4XL10XTAPER	Bajaj spare parts
JL181026	CLIP NUT -M5	Bajaj spare parts
JL181027	CLIP NUT M6	Bajaj spare parts
JL181028	BOLT CLIP	Bajaj spare parts
JL181029	GROMMET FAIRING K16	Bajaj spare parts
JL181200	COVER SIDE LH	Bajaj spare parts
JL181201	COVER SIDE RH	Bajaj spare parts
JL181203	FAIRING	Bajaj spare parts
JL181205	COVER ASSLY CHAIN	Bajaj spare parts
JL181209	FENDER REAR FRONT	Bajaj spare parts
JL181211	COVER SIDE ASSY LH	Bajaj spare parts
JL181212	COVER SIDE ASSY RH	Bajaj spare parts
JL181214	SEAT COWL CENTRAL INNER	Bajaj spare parts
JL181218	BATTERY CASE	Bajaj spare parts
JL181219	GROMMET -1 SEAT COWL	Bajaj spare parts
JL181220	GROMMET -2 SEAT COWL	Bajaj spare parts
JL181221	FOAM-REAR FENDER FRONT	Bajaj spare parts
JL181224	GROMMET I	Bajaj spare parts
JL181225	GROMMET II	Bajaj spare parts
JL181226	SHROUD ASSY LH	Bajaj spare parts
JL181229	SHROUD ASSY RH	Bajaj spare parts
JL181231	SHROUD OUTER RH	Bajaj spare parts
JL181232	SHROUD MTG BKT RH	Bajaj spare parts
JL181233	SIDE MASK LH	Bajaj spare parts
JL181234	SIDE MASK RH	Bajaj spare parts
JL181235	LAMP SHADE ASSY	Bajaj spare parts
JL181236	BRACKET LOWER MTG	Bajaj spare parts
JL181237	BRACKET UPPER MTG	Bajaj spare parts
JL181241	FLAP SPEEDO	Bajaj spare parts
JL181245	GROMMET NO. PLATE MTG	Bajaj spare parts
JL181246	COLLAR NUMBER PLATE MOUNTING	Bajaj spare parts
JL181247	GROMMET WIND SCREEN	Bajaj spare parts

JL181249	DAMPER HEAD LAMP	Bajaj spare parts
JL181253	CHAIN COVER SIDE RH	Bajaj spare parts
JL181255	COVER SIDE ASSY LH-FI	Bajaj spare parts
JL181256	GROMMET FOR RADIATOR COWL	Bajaj spare parts
JL181257	COLLAR FAIRING	Bajaj spare parts
JL181258	ASSLY BATTERY CASE	Bajaj spare parts
JL181259	FOAM STRIP 25X13X3	Bajaj spare parts
JL181260	FOAM STRIP 18X15X3	Bajaj spare parts
JL181263	FOAM STRIP 10X10X7	Bajaj spare parts
JL181264	SLEEVE BATTERY BOX	Bajaj spare parts
JL181283	BRACKET WIND SHIELD	Bajaj spare parts
JL181284	STEP BOLT	Bajaj spare parts
JL181288	SCREW STEPPED M6 X 14	Bajaj spare parts
JL181293	GROMMET SIDE COVER MTG	Bajaj spare parts
JL181297	COLLAR	Bajaj spare parts
JL181304	GROMMET DASHBOARD K16	Bajaj spare parts
JL181305	BELLY PAN LH	Bajaj spare parts
JL181306	BELLY PAN RH	Bajaj spare parts
JL181307	BRACKET BELLY PAN	Bajaj spare parts
JL181325	PLUG	Bajaj spare parts
JL181336	FOAM	Bajaj spare parts
JL181401	FENDER FRONT	Bajaj spare parts
JL181402	BRACKET BRACE FENDER	Bajaj spare parts
JL181405	MUDFLAP -FRONT	Bajaj spare parts
JL181407	COVER 1-HUGGER REAR	Bajaj spare parts
JL181408	COVER 2-HUGGER REAR	Bajaj spare parts
JL181409	ASSEMBLY HUGGER REAR	Bajaj spare parts
JL181410	COLLAR HUGGER REAR	Bajaj spare parts
JL181411	CUP WASHER FRONT FENDER MTG.	Bajaj spare parts
JL181416	FAIRING STRUCTURE (K16)	Bajaj spare parts
JL181417	MASK (K16)	Bajaj spare parts
JL181418	SIDE MASK LH (K16)	Bajaj spare parts
JL181420	SIDE FAIRING FRONT LH (K16)	Bajaj spare parts
JL181421	SIDE FAIRING FRONT RH (K16)	Bajaj spare parts
JL181424	SIDE FAIRING INNER LH (K16)	Bajaj spare parts
JL181425	SIDE FAIRING INNER RH (K16)	Bajaj spare parts
JL181426	WINDSHIELD (K16)	Bajaj spare parts
JL181427	SPEEDO FLAP (K16)	Bajaj spare parts
JL181432	FAIRING MTG BKT MIDDLE (K16)	Bajaj spare parts
JL181433	FENDER REAR (K16)	Bajaj spare parts
JL181436	UNDER TRAY (K16)	Bajaj spare parts
JL181437	FLAP CANOPY SPEEDO K16	Bajaj spare parts
JL181440	RADIATOR SHROUD CENTRAL (K16)	Bajaj spare parts
JL181447	BRACKET BLINKER MTG LH (K16)	Bajaj spare parts
JL181448	BRACKET BLINKER MTG RH (K16)	Bajaj spare parts

JL181449	BRACKET FAIRING MTG LH (K16)	Bajaj spare parts
JL181450	BRACKET FAIRING MTG RH (K16)	Bajaj spare parts
JL181453	COLLAR WIND SHIELD	Bajaj spare parts
JL181455	SQUARE INSERT M4 (10X10X4.9 THK)	Bajaj spare parts
JL181456	BRACKET SIDE FAIRING FR MTG LH	Bajaj spare parts
JL181457	BRACKET SIDE FAIRING FR MTG RH	Bajaj spare parts
JL181464	FENDER BRACE -K16A (SOFT MTG)	Bajaj spare parts
JL181465	FENDER FR K16 SOFT	Bajaj spare parts
JL181468	COLLAR FRONT FENDER SOFT MTG	Bajaj spare parts
JL191001	SEAT ASSY COMP FRONT	Bajaj spare parts
JL191004	SEAT ASSY COMP REAR	Bajaj spare parts
JL191007	DAMPER SEAT	Bajaj spare parts
JL191008	SEAT TAPE LH	Bajaj spare parts
JL191009	SEAT TAPE RH	Bajaj spare parts
JL191017	SEAT DAMPER FRONT	Bajaj spare parts
JL231003	TOOL KIT-BAND	Bajaj spare parts
JL231004	TOOL KIT	Bajaj spare parts
JL231201	GUARD LEG	Bajaj spare parts
JL231202	GUARD SAREE	Bajaj spare parts
JL231203	GUARD LEG GUARD RH	Bajaj spare parts
JL231204	LADIES FOOTREST	Bajaj spare parts
JL231206	BOLT -SPECIAL M10	Bajaj spare parts
JL231209	PLUG SAREE GAURD	Bajaj spare parts
JL231211	SAREE GUARD (K16)	Bajaj spare parts
JL231212	CAP REAR FENDER K16A	Bajaj spare parts
JL231213	GUARD LEG LH	Bajaj spare parts
JL231214	GUARD LEG RH	Bajaj spare parts
JL231400	GRAB HANDLE LH	Bajaj spare parts
JL231401	GRAB HANDLE RH	Bajaj spare parts
JL231404	GRAB HANDLE ASSY LH	Bajaj spare parts
JL231405	GRAB HANDLE ASSY RH	Bajaj spare parts
JL231600	MIRROR ASSY LH	Bajaj spare parts
JL231601	MIRROR ASSY RH	Bajaj spare parts
JL232603	LOCK SET FOR EXPORT	Bajaj spare parts
JL232604	COVER SEAT LOCK ASSY	Bajaj spare parts
JL232605	LOCK SET 3 IN 1-K14-E10 (EVAP)	Bajaj spare parts
JL232805	BRACKET NUMBER PLATE	Bajaj spare parts
JL232806	PLATE NUMBER-FRONT	Bajaj spare parts
JL232808	BRACKET -RR NUMBER PLATE MTG	Bajaj spare parts
JL232810	BRACKET FRONT NUMBER PLATE MTG	Bajaj spare parts
JL232811	BRACKET RE NUMBER PLATE MTG	Bajaj spare parts
JL232824	BRACKET NUMBER PLATE MTG ABS	Bajaj spare parts
JL232830	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JL232831	BRACKET PLATE NUMBER REAR	Bajaj spare parts
JL232857	BRACKET PLATE NUMBER FRONT	Bajaj spare parts



JL233000	DECAL FAIRING LH	Bajaj spare parts
JL233001	DECAL FAIRING RH	Bajaj spare parts
JL233002	B LOGO DECAL FORNT	Bajaj spare parts
JL233003	DECAL 3D TANK LH	Bajaj spare parts
JL233004	3D DECAL TANK RH	Bajaj spare parts
JL233005	DECAL SIDE COVER 4 VALVE	Bajaj spare parts
JL233006	DECAL SEAT COWL 200 NS	Bajaj spare parts
JL233015	GEAR SHIFT LABELGEAR SHIFT LABEL	Bajaj spare parts
JL233016	KIT 3D DECAL TANK SET PUSLE	Bajaj spare parts
JL233017	3D TANK DECAL SET ROUSER	Bajaj spare parts
JL233019	LABEL TYRE INFO	Bajaj spare parts
JL233020	LABEL TYRE PRESSURE	Bajaj spare parts
JL233027	SPOILER DECAL UPPER LH	Bajaj spare parts
JL233028	SPOILER DECAL UPPER RH	Bajaj spare parts
JL233029	SPOILER DECAL LOWER LH	Bajaj spare parts
JL233030	SPOILER DECAL LOWER RH	Bajaj spare parts
JL233035	FENDER DECAL LH	Bajaj spare parts
JL233036	FENDER DECAL RH	Bajaj spare parts
JL233041	DECAL FRONT 3D BLACK	Bajaj spare parts
JL233044	SPOILER DECAL UPPER LH	Bajaj spare parts
JL233045	SPOILER DECAL UPPER RH	Bajaj spare parts
JL233046	SPOILER DECAL LOWER LH	Bajaj spare parts
JL233047	SPOILER DECAL LOWER RH	Bajaj spare parts
JL233052	FENDER DECAL LH	Bajaj spare parts
JL233053	FENDER DECAL RH	Bajaj spare parts
JL233060	SPOILER DECAL UPPER LH	Bajaj spare parts
JL233061	SPOILER DECAL UPPER RH	Bajaj spare parts
JL233062	SPOILER DECAL LOWER LH	Bajaj spare parts
JL233063	SPOILER DECAL LOWER RH	Bajaj spare parts
JL233076	LABEL STATUTORY	Bajaj spare parts
JL233131	DECAL SIDE COVER FI LH	Bajaj spare parts
JL233153	DECAL ADVENTURE SPORTS I	Bajaj spare parts
JL233155	SEAT COWL DECAL AS 200	Bajaj spare parts
JL233185	3D DECAL TANK	Bajaj spare parts
JL233186	TANK LOWER DECAL LH	Bajaj spare parts
JL233187	TANK LOWER DECAL RH	Bajaj spare parts
JL233188	SPOILER UPPER DECAL LH	Bajaj spare parts
JL233189	SPOILER UPPER DECAL LH	Bajaj spare parts
JL233211	3D TANK DECAL (SHADED)	Bajaj spare parts
JL233239	3D TANK DECAL SHADED (SILVER)	Bajaj spare parts
JL233241	3D TANK DECAL PULSE (SHADED)	Bajaj spare parts
JL233249	DECAL SIDE COVER LH RED-BLACK	Bajaj spare parts
JL233250	DECAL SIDE COVER RH RED-BLACK	Bajaj spare parts
JL233255	DECAL WHEEL FRONT RED-BLACK	Bajaj spare parts
JL233256	DECAL WHEEL REAR RED-BLACK	Bajaj spare parts

JL233263	DECAL SIDE COVER LH WHITE-GRAY	Bajaj spare parts
JL233264	DECAL SIDE COVER RH WHITE-GRAY	Bajaj spare parts
JL233269	DECAL WHEEL FRONT WHITE-GRAY	Bajaj spare parts
JL233270	DECAL WHEEL REAR WHITE-GRAY	Bajaj spare parts
JL233281	DECAL WHEEL FRONT BLUE-BLACK	Bajaj spare parts
JL233282	DECAL WHEEL REAR BLUE-BLACK	Bajaj spare parts
JL233292	DECAL SIDE COVER LH BLACK-GRAY	Bajaj spare parts
JL233293	DECAL SIDE COVER RH BLACK-GRAY	Bajaj spare parts
JL233298	DECAL WHEEL I BLACK-GRAY	Bajaj spare parts
JL233299	DECAL WHEEL II BLACK-GRAY	Bajaj spare parts
JL233302	DECAL COVER TANK TOP LH YLW-GRAY	Bajaj spare parts
JL233303	DECAL COVER TANK TOP RH YLW-GRAY	Bajaj spare parts
JL233305	DECAL SIDE COVER RH YELLOW-GRAY	Bajaj spare parts
JL233308	DECAL FENDER FRONT LH YELLOW-GRY	Bajaj spare parts
JL233310	DECAL WHEEL I YELLOW-GRAY	Bajaj spare parts
JL233311	DECAL WHEEL II YELLOW-GRAY	Bajaj spare parts
JL233314	DECAL TANK 3D PULSE-GREY	Bajaj spare parts
JL233315	DECAL TANK 3D ROUSER-GREY	Bajaj spare parts
JL233316	DECAL TANK 3D PULSAR-GREY	Bajaj spare parts
JL233318	DECAL ABS FENDER FRONT	Bajaj spare parts
JL233319	DECAL COVER SIDE LH RED-GREY	Bajaj spare parts
JL233320	DECAL COVER SIDE RH RED-GREY	Bajaj spare parts
JL233321	DECAL COVER SIDE LH WHITE-GREY	Bajaj spare parts
JL233322	DECAL COVER SIDE RH WHITE-GREY	Bajaj spare parts
JL233323	DECAL COVER SIDE LH BLACK-GREY	Bajaj spare parts
JL233325	DECAL COVER SIDE LH YELLOW-GREY	Bajaj spare parts
JL233333	DECAL COVER SIDE LH RED GREY	Bajaj spare parts
JL233334	DECAL COVER SIDE LH WHITE GREY	Bajaj spare parts
JL233339	DECAL COVER SIDE LOWER LH	Bajaj spare parts
JL233340	DECAL COVER SIDE LOWER RH	Bajaj spare parts
JL233347	DECAL COVER CLUTCH	Bajaj spare parts
JL233378	DECAL BELLY PAN PEWTER GREY LH	Bajaj spare parts
JL233379	DECAL BELLY PAN PEWTER GREY RH	Bajaj spare parts
JL233381	DECAL WHEEL FR PEARL M WHITE LH	Bajaj spare parts
JL233382	DECAL WHEEL FR PEARL M WHITE RH	Bajaj spare parts
JL233383	DECAL WHEEL FRONT PLASMA BLUE LH	Bajaj spare parts
JL233384	DECAL WHEEL FRONT PLASMA BLUE RH	Bajaj spare parts
JL233385	DECAL WHEEL FRONT BURNT RED LH	Bajaj spare parts
JL233386	DECAL WHEEL FRONT BURNT RED RH	Bajaj spare parts
JL351003	STATOR ASSLY COMPL	Bajaj spare parts
JL351009	ROTOR ASSLY WITHOUT CLUTCH	Bajaj spare parts
JL351032	STATOR ASSLY	Bajaj spare parts
JL351038	STATOR ASSLY	Bajaj spare parts
JL351040	STATOR ASSLY	Bajaj spare parts
JL351059	STATOR ASSEMBLY	Bajaj spare parts

JL351061	ASSEMBLY ROTOR	Bajaj spare parts
JL351200	DC CDI WITH SEALED COUPLER	Bajaj spare parts
JL351201	IGNITION COIL WITH CABLE LH	Bajaj spare parts
JL351202	IGNITION COIL WITH CABLE RH	Bajaj spare parts
JL351211	GROMMET SPARK PLUG	Bajaj spare parts
JL351218	Spark Plug	Bajaj spare parts
JL351219	KIT HT COIL	Bajaj spare parts
JL351223	COIL HT 1	Bajaj spare parts
JL351225	COIL HT 2	Bajaj spare parts
JL351230	COIL HT 1	Bajaj spare parts
JL351232	COIL HT 2	Bajaj spare parts
JL351235	COIL HT 1	Bajaj spare parts
JL351237	COIL HT 2	Bajaj spare parts
JL351240	HT COIL	Bajaj spare parts
JL351241	DI ASSLY WITH DAMPER	Bajaj spare parts
JL351246	CDI NON TPS ASSLY	Bajaj spare parts
JL351252	HT COIL 2	Bajaj spare parts
JL351600	STARTER MOTOR	Bajaj spare parts
JL351800	NEUTRAL INDICATION SWITCH	Bajaj spare parts
JL351802	NEUTRAL SWITCH	Bajaj spare parts
JL351806	SWITCH NEUTRAL	Bajaj spare parts
JL351808	SWITCH NEUTRAL	Bajaj spare parts
JL351811	SENSOR OIL PRESSURE	Bajaj spare parts
JL401002	LAMP TAIL ASSY	Bajaj spare parts
JL401003	INDICATOR ASSY RR LH	Bajaj spare parts
JL401004	INDICATOR ASSY RR RH	Bajaj spare parts
JL401006	INDICATOR ASSY FR RH	Bajaj spare parts
JL401012	HEAD LAMP ASSY (55/60W)	Bajaj spare parts
JL401016	COVER ILLUMINATION LAMP	Bajaj spare parts
JL401017	HEAD LAMP ASSY-K16	Bajaj spare parts
JL401018	LAMP HEAD ASSLY	Bajaj spare parts
JL401400	SWITCH CONTROL LH	Bajaj spare parts
JL401401	SWITCH CONTROL RH	Bajaj spare parts
JL401402	SWITCH SIDE STAND	Bajaj spare parts
JL401403	SWITCH IGNITION	Bajaj spare parts
JL401405	CONTROL SWITCH RH (EXPORT)	Bajaj spare parts
JL401406	BRAKE SWITCH-REAR	Bajaj spare parts
JL401408	SIDE STAND SWITCH-FI	Bajaj spare parts
JL401409	CONTROL SWITCH LH (K16)	Bajaj spare parts
JL401410	CONTROL SWITCH RH (K16)	Bajaj spare parts
JL401411	CLUTCH SWITCH	Bajaj spare parts
JL401412	SWITCH CONTROL RH-AHO K16	Bajaj spare parts
JL401600	HORN LH	Bajaj spare parts
JL401602	HORN DIA 82	Bajaj spare parts
JL401801	BAND BATTERY	Bajaj spare parts

JL401803	FOAM BOTTOM BATTERY 6 & 8AH	Bajaj spare parts
JL401804	FOAM SIDE BATTERY 8AH	Bajaj spare parts
JL401805	BATTERY LID CAP	Bajaj spare parts
JL402001	REGULATOR ASSY	Bajaj spare parts
JL402002	REGULATOR 3 PHASE KHI	Bajaj spare parts
JL402003	REGULATOR ASSLY-K14	Bajaj spare parts
JL402004	LIGHT CONTROL MODULE (BULB)	Bajaj spare parts
JL402005	CONTROLLER LCM FI	Bajaj spare parts
JL402007	REGULATOR ASSY K4 AND K16A	Bajaj spare parts
JL402008	LIGHT CONTROL MODULE	Bajaj spare parts
JL402201	CABLE ASSY RELAY TO MOTOR	Bajaj spare parts
JL402202	CABLE EARTH	Bajaj spare parts
JL402203	HARNESS WIRING	Bajaj spare parts
JL402204	DAMPER FOR FUSE BOX	Bajaj spare parts
JL402207	FUSE BOX ASSY WITH FUSE	Bajaj spare parts
JL402208	FUSE - 20A (BLADE TYPE)	Bajaj spare parts
JL402209	HARNESS WIRING (FI)	Bajaj spare parts
JL402210	MAIN HARNESS (EXPORT)	Bajaj spare parts
JL402213	MAIN WIRING HARNESS	Bajaj spare parts
JL402214	CABLE RELAY TO MOTOR	Bajaj spare parts
JL402215	CABLE EARTH	Bajaj spare parts
JL402218	WIRING HARNESS (K14)	Bajaj spare parts
JL402219	PIGTAIL OIL PRESSURE SWITCH	Bajaj spare parts
JL402220	MAIN WIRING HARNESS (K16)	Bajaj spare parts
JL402221	MAIN WIRING HARNESS (PHILIPPIN)	Bajaj spare parts
JL402223	EARTH CABLE (K16)	Bajaj spare parts
JL402226	WIRING HARNESS - PHASE II (K14)	Bajaj spare parts
JL402228	WIRING HARNESS W/O LCM-K16	Bajaj spare parts
JL402229	WIRING HARNESS W/O HLCU (K4)	Bajaj spare parts
JL402230	WIRING HARNESS -K4 (NON TPS)	Bajaj spare parts
JL402232	HARNESS WIRING ABS -K14	Bajaj spare parts
JL402234	WIRING HARNESS -K14 (EPM44)	Bajaj spare parts
JL402235	WIRING HARNESS -K4 ABS	Bajaj spare parts
JL402237	HARNESS K16A - AHO	Bajaj spare parts
JL402240	PIG TAIL FUEL PUMP PH III (K14)	Bajaj spare parts
JL402242	HARNESS WIRING K16A UG	Bajaj spare parts
JL402245	HARNESS WIRING UG AHO	Bajaj spare parts
JL402246	HARNESS WIRING ABS	Bajaj spare parts
JL402247	HARNESS WIRING	Bajaj spare parts
JL402252	HARNESS WIRING	Bajaj spare parts
JL402255	HARNESS WIRING	Bajaj spare parts
JL402272	HARNESS WIRING	Bajaj spare parts
JL402275	HARNESS WIRING	Bajaj spare parts
JL402290	HARNESS WIRING	Bajaj spare parts
JL402400	SPEEDOMETER ASSLY	Bajaj spare parts

JL402403	SPEEDOMETER PIGTAIL HARNESS	Bajaj spare parts
JL402405	SPEEDOMETER	Bajaj spare parts
JL402406	SPEEDOMETER ASSLY (EXPORT)	Bajaj spare parts
JL402407	SPEEDOMETER ASSY (K14)	Bajaj spare parts
JL402409	SPEEDOMETER ABS-K4	Bajaj spare parts
JL402412	SPEEDOMETER ASSLY	Bajaj spare parts
JL402414	SPEEDOMETER	Bajaj spare parts
JL402415	SPEEDOMETER	Bajaj spare parts
JL402421	INSTRUMENT CLUSTER	Bajaj spare parts
JL402600	SENSOR FUEL LEVEL	Bajaj spare parts
JL402602	FUEL LEVEL SENSOR(JNS)	Bajaj spare parts
JL403000	INTERLOCK RELAY	Bajaj spare parts
JL403001	RELAY AUX1DIODE	Bajaj spare parts
JL403200	TERMINATION UNIT	Bajaj spare parts
JL403201	UNIT TERMINATION	Bajaj spare parts
JL403600	HOLDER MAGNET	Bajaj spare parts
JL501040	ASSLY ENGINE_K16	Bajaj spare parts
JL501063	ENGINE ASSLY_BSIV	Bajaj spare parts
JL501078	ENGINE ASSLY	Bajaj spare parts
JL501089	ENGINE ASSEMBLY	Bajaj spare parts
JL511001	GASKET HEAD COVER(RUBBER)	Bajaj spare parts
JL511002	COVER CYLINDER HEAD	Bajaj spare parts
JL511009	M6 STUD BOLT	Bajaj spare parts
JL511010	VALVE INTAKE	Bajaj spare parts
JL511011	VALVE EXHAUST	Bajaj spare parts
JL511016	INSULATOR RUBBER	Bajaj spare parts
JL511022	GASKET CYLINDER HEAD	Bajaj spare parts
JL511029	COVER THERMOSTAT	Bajaj spare parts
JL511041	COVER CYLINDER HEAD	Bajaj spare parts
JL511042	Gasket Head Cov.	Bajaj spare parts
JL511045	HEAD CYLINDER COMP	Bajaj spare parts
JL511053	ASSEMBLY CYL. HEAD K4 SAI	Bajaj spare parts
JL511056	GASKET COPPERFORK4SAI	Bajaj spare parts
JL511058	HOSE SAI UNIT TO EXHAUST PORT	Bajaj spare parts
JL511059	ASSLY PIPE SAI WITH ADAPTOR	Bajaj spare parts
JL511061	BRACKET FOR SAI PIPE	Bajaj spare parts
JL511080	HEAD CYLINDER	Bajaj spare parts
JL511112	SLEEVE SPARK PLUG	Bajaj spare parts
JL511114	SHAFT ROCKER ARM	Bajaj spare parts
JL511115	PLATE STOPPER	Bajaj spare parts
JL511205	ROCKER ARM SHAFT	Bajaj spare parts
JL511219	SLEEVE SPARK PLUG	Bajaj spare parts
JL511220	SPROCKET CAMSHAFT SILENT CHAIN	Bajaj spare parts
JL511221	SPACER CAMSHAFT SILENT CHAIN	Bajaj spare parts
JL511222	CHAIN SILENT	Bajaj spare parts

JL511227	SCREW TAPPET	Bajaj spare parts
JL511231	SPROCKET CAMSHAFT	Bajaj spare parts
JL511241	CAMSHAFT ASSLY	Bajaj spare parts
JL511249	SHAFT ROCKER ARM	Bajaj spare parts
JL511250	SPACER CAMSHAFT	Bajaj spare parts
JL511254	PLATE STOPPER ROCKER SHAFT	Bajaj spare parts
JL511271	CAMSHAFT ASSEMBLY	Bajaj spare parts
JL521002	GASKET CYLINDER BLOCK	Bajaj spare parts
JL521004	CYLINDER BLOCK WITH NIPPLE	Bajaj spare parts
JL521200	PISTON ASSLY COMPL	Bajaj spare parts
JL531004	CHAIN GUIDE SLACK SILENT	Bajaj spare parts
JL531005	CHAIN GUIDE TIGHT SILENT	Bajaj spare parts
JL531203	SLEEVE BALANCER DRIVEN	Bajaj spare parts
JL531205	ASSLY BALANCER INTEGRAL	Bajaj spare parts
JL531223	SPRING COMPRESSION	Bajaj spare parts
JL541008	PIPE BREATHER CRANKCASE	Bajaj spare parts
JL541030	ASSLY CRANKCASE LH	Bajaj spare parts
JL541203	COVER LH RR	Bajaj spare parts
JL541207	GASKET CLUTCH COVER	Bajaj spare parts
JL541208	GASKET MAGNETO COVER	Bajaj spare parts
JL541218	JET OIL COVER CLUTCH	Bajaj spare parts
JL541222	DECAL TRIPLE SPARK	Bajaj spare parts
JL541223	DECAL B-BAJAJ	Bajaj spare parts
JL541225	COVER MAGNETO	Bajaj spare parts
JL541227	WINDOW OIL GAUGE	Bajaj spare parts
JL541230	DAMPER CLUTCH COVER	Bajaj spare parts
JL541231	PLATE DAMPER CLUTCH COVER	Bajaj spare parts
JL541236	MAGNETO COVER	Bajaj spare parts
JL541238	LABEL TRIPLE SPARK LH SIDE	Bajaj spare parts
JL541239	BRACKET CLUTCH CABLE	Bajaj spare parts
JL541243	MAGNETO COVER ASSLY	Bajaj spare parts
JL541244	MAGNETO COVER ASSLY	Bajaj spare parts
JL541245	CAP TDC FINDER	Bajaj spare parts
JL541246	BRACKET CLUTCH CABLE	Bajaj spare parts
JL541255	BRACKET CABLE CLUTCH	Bajaj spare parts
JL541274	COVER ASSEMBLY MAGNETO	Bajaj spare parts
JL541277	GASKET COVER CLUTCH	Bajaj spare parts
JL551217	BUSH 1ST DRIVEN	Bajaj spare parts
JL551218	BUSH 2ND DRIVEN	Bajaj spare parts
JL551407	SPRING BELLVILLE	Bajaj spare parts
JL551410	SHAFT CLUTCH ASSEMBLY RELEASE	Bajaj spare parts
JL561205	ASSLY LEVER SHIFT BALL JOINT	Bajaj spare parts
JL561206	ASSLY ARM CHANGE BALL JOINT	Bajaj spare parts
JL561222	LEVER ASSEMBLY CHANGE	Bajaj spare parts
JL561400	ASSLY LEVER COMP CHANGE	Bajaj spare parts

JL561401	LEVER COMPLETE CHANGE	Bajaj spare parts
JL561404	ASSLY LEVER CHANGE ARM	Bajaj spare parts
JL561405	ROD TIE	Bajaj spare parts
JL561407	BOOT -CHANGE ARM	Bajaj spare parts
JL561408	BOOT -CHANGE LEVER	Bajaj spare parts
JL561409	BOLT GEAR CHANGE LEVER	Bajaj spare parts
JL561410	WASHER - STEEL	Bajaj spare parts
JL561414	ARM ASSEMBLY CHANGE	Bajaj spare parts
JL571001	CAP OIL FILTER	Bajaj spare parts
JL571203	COOLER OIL	Bajaj spare parts
JL571207	COVER COOLER OIL	Bajaj spare parts
JL571208	PIPE ASSEMBLY COOLER OIL INLET	Bajaj spare parts
JL571214	PIPE ASSEMBLY COOLER OIL OUTLET	Bajaj spare parts
JL581000	AIR FILTER ASSLY	Bajaj spare parts
JL581007	ENTRY DUCT	Bajaj spare parts
JL581009	FILTER ELEMENT	Bajaj spare parts
JL581010	TUBE CONNECTING	Bajaj spare parts
JL581015	TUBE DRAIN ASSLY	Bajaj spare parts
JL581016	TUBE BREATHER ASSLY	Bajaj spare parts
JL581025	SEAL TOP COVER	Bajaj spare parts
JL581027	CLAMP CONNECTING TUBE	Bajaj spare parts
JL581039	PIPE INTAKE	Bajaj spare parts
JL581042	ASSEMBLY DRAIN TUBE	Bajaj spare parts
JL581043	DRAIN TUBE	Bajaj spare parts
JL581046	TUBE CONNECTING	Bajaj spare parts
JL581050	ASSLY AIRFILTER K4 SAI	Bajaj spare parts
JL581055	TUBE DRAIN	Bajaj spare parts
JL581063	CLAMP SAI	Bajaj spare parts
JL581065	CLAMP HOSE SAI	Bajaj spare parts
JL581066	CLAMP SAI PIPE	Bajaj spare parts
JL581093	VALVE REED ASSLY	Bajaj spare parts
JL581098	FILTER ASSLY AIR	Bajaj spare parts
JL581106	TUBE BREATHER	Bajaj spare parts
JL581201	CARBURETTOR WITH REED SWITCH	Bajaj spare parts
JL581202	THROTTLE CABLE BRACKET	Bajaj spare parts
JL581203	GROMMET THROTTLE BRACKET	Bajaj spare parts
JL581204	LEVER CHOKE	Bajaj spare parts
JL581205	TUBE DRAIN CARB	Bajaj spare parts
JL581206	TUBE BREATHER CARB	Bajaj spare parts
JL581212	CARBURETTOR ASSLY	Bajaj spare parts
JL581215	CARBURETTOR ASSLY_EVAP_NON_TPS	Bajaj spare parts
JL581217	CARBURETTOR WITHOUT EVAP AND TPS	Bajaj spare parts
JL581300	CLAMP INSULATOR TO HEAD	Bajaj spare parts
JL582400	HOSE SAI UNIT TO AIRFILTER	Bajaj spare parts
JL582402	HOSE SAI UNIT TO INTAKE MANIFOLD	Bajaj spare parts

JL582404	HOSE UNIT SAI-MANIFOLD INTAKE	Bajaj spare parts
JL591045	SPACER PIPE A PROTO 1	Bajaj spare parts
JL591048	PIPE EXHAUST	Bajaj spare parts
JL591052	SILENCER ASSY	Bajaj spare parts
JL591075	HEAT SHIELD	Bajaj spare parts
JL591086	BOLT STEPPED	Bajaj spare parts
JL591144	SHIELD CATALYTIC CONVERTER	Bajaj spare parts
JL591148	BOLT HEXAGONAL FLANGE	Bajaj spare parts
JL591149	TRUSS SCREW (HEAD BLACK)	Bajaj spare parts
JL591156	SLEEVE TOP	Bajaj spare parts
JL591157	SLEEVE BOTTOM	Bajaj spare parts
JL591165	DAMPER SILENCER MOUNT	Bajaj spare parts
JL591178	ASSLY PIPE A EXHAUST	Bajaj spare parts
JL591196	ASSLY MUFFLER COMP	Bajaj spare parts
JL591226	PIPE EXHAUST A ASSLY	Bajaj spare parts
JL591240	ASSLY MUFFLER	Bajaj spare parts
JL591324	PIPE ASSEMBLY A	Bajaj spare parts
JL591342	ASSEMBLY MUFFLER	Bajaj spare parts
JL591388	PIPE ASSEMBLY A	Bajaj spare parts
JL591392	SHIELD MUFFLER	Bajaj spare parts
JL601000	HOSE THERMOSTAT TO RADIATOR	Bajaj spare parts
JL601001	HOSE BY PASS TO PUMP	Bajaj spare parts
JL601005	COVER WATER PUMP	Bajaj spare parts
JL601008	WATER PUMP COVER	Bajaj spare parts
JL601010	WATER SEAL_DOUBLE LIP	Bajaj spare parts
JL601200	RADIATOR	Bajaj spare parts
JL601209	TANK EXPANSION	Bajaj spare parts
JL601210	COWL RADIATOR	Bajaj spare parts
JL601212	CLAMP RADIATOR DIA 19	Bajaj spare parts
JL601213	HOSE -EXPANSION TANK	Bajaj spare parts
JL601214	HOSE -EXPANSION TANK TOP	Bajaj spare parts
JL601215	CLAMP -EXPANSION TANK	Bajaj spare parts
JL601216	DAMPER RUBBER MTG RADIATOR	Bajaj spare parts
JL601217	HOSE EXPANSION TANK BREATHER	Bajaj spare parts
JL601219	HOSE COOLANT	Bajaj spare parts
JL601220	HOSE COOLANT (RAD TO CO PUMP)	Bajaj spare parts
JL601221	CLAMP COOLANT PIPE	Bajaj spare parts
JL601222	HOSE THERMOSTAT TO RADIATOR	Bajaj spare parts
JL601223	HOSE RADIATOR TO PIPE T	Bajaj spare parts
JL601225	SEAL THERMOSTAT	Bajaj spare parts
JL601227	PIPE BREATHER	Bajaj spare parts
JL601228	PIPE COOLANT "T" ASSLY"	Bajaj spare parts
JL601231	SLEEVE COWL MOUNTING	Bajaj spare parts
JL601234	RADIATOR CORE	Bajaj spare parts
JL601235	EXPANSION TANK ASSLY	Bajaj spare parts



JL601237	THERMOSTAT	Bajaj spare parts
JL601251	RADIATOR ASSEMBLY	Bajaj spare parts
JL611000	INJECTOR CAP O RING	Bajaj spare parts
JL611001	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
JL611205	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JL75015U	FENDER FR WTH	Bajaj spare parts
JL7501X3	FENDER FR WTH GUIDE N FLAP	Bajaj spare parts
JL76015L	SIDE MASK LH -JL RED	Bajaj spare parts
JL76015P	SIDE MASK LH BLUE	Bajaj spare parts
JL76025L	SIDE MASK RH - JL	Bajaj spare parts
JL76025Q	SIDE MASK RH YELLOW	Bajaj spare parts
JL78015M	SEAT COWL ASSY RED COLOR	Bajaj spare parts
JM100003	LEVER CHANGE ARM COM	Bajaj spare parts
JM100012	CRANKCASE LH JM	Bajaj spare parts
JM100020	PIPE INLET OIL COOL	Bajaj spare parts
JM100021	PIPE OIL COOLER ASSY	Bajaj spare parts
JM100039	COVER LH RR	Bajaj spare parts
JM100040	DAMPER C COVER LH RR	Bajaj spare parts
JM100041	PLATE DAM COV LH RR	Bajaj spare parts
JM100043	CYL BL PISTON ASSY	Bajaj spare parts
JM100045	BOLT FLANGE M6 X 28	Bajaj spare parts
JM101008	CRANKSHAFT ASSEMBLY	Bajaj spare parts
JM101016	INTAKE MANIFOLD JM(150)	Bajaj spare parts
JM101017	TUBE CONNECTING	Bajaj spare parts
JM101022	SHIELD EXHAUST FRONT	Bajaj spare parts
JM101027	SHIELD EXHAUST REAR	Bajaj spare parts
JM111014	CDI UNIT (EDGE FIRING)	Bajaj spare parts
JM120008	KIT MAIN JET & NEEDL	Bajaj spare parts
JM141002	COVER TANK	Bajaj spare parts
JM141009	FUEL PIPE-PETROL WITH ETHANOL	Bajaj spare parts
JM151001	SPROCKET 38T O RING	Bajaj spare parts
JM151005	AXLE REAR	Bajaj spare parts
JM161002	BRACKET FRONT LH	Bajaj spare parts
JM161003	BRACKET FRONT RH	Bajaj spare parts
JM161006	BRACKET ENGINE HD RH	Bajaj spare parts
JM161017	GUARD FRONT	Bajaj spare parts
JM161020	COLLAR OIL COOLER MT	Bajaj spare parts
JM161023	BRACKET ASSY COMP	Bajaj spare parts
JM161026	FRAME WITH BEARING R	Bajaj spare parts
JM161027	DECAL OIL COOLED B B	Bajaj spare parts
JM161037	HOLDER STEP FR RH ASLY.	Bajaj spare parts
JM161038	.COMP STAY RH	Bajaj spare parts
JM171003	ADJUSTER CHAIN	Bajaj spare parts
JM171004	CAP CHAIN ADJUSTER	Bajaj spare parts
JM181001	BOLTWIND SHIELD	Bajaj spare parts

JM181003	LOCK KIT	Bajaj spare parts
JM181004	WIND SHIELD WITH GRO	Bajaj spare parts
JM181008	HANDLE BAR	Bajaj spare parts
JM181010	CLAMP	Bajaj spare parts
JM181011	CLAMP	Bajaj spare parts
JM191005	CABLE BRAKE RR	Bajaj spare parts
JM191006	SPRING BRAKE SWITCH	Bajaj spare parts
JM191007	CABLE ASSY. SPEEDO	Bajaj spare parts
JM191008	CABLE INNER SPEEDOME	Bajaj spare parts
JM191010	LEVER BOOT	Bajaj spare parts
JM191011	LEVER BRAKE	Bajaj spare parts
JM191012	SPRING	Bajaj spare parts
JM191013	REAR BRAKE CABLE	Bajaj spare parts
JM191014	SPRING BRAKE SWITCH	Bajaj spare parts
JM191015	GUARD BRAKE PEDAL	Bajaj spare parts
JM201002	HORN AVENGER 200	Bajaj spare parts
JM201003	SWITCH CONTROL LH	Bajaj spare parts
JM201004	TANK UNIT	Bajaj spare parts
JM201011	HARNESS WIRINGST.RE	Bajaj spare parts
JM201012	CABLE MOTOR TO RELAY	Bajaj spare parts
JM201015	CABLE BATTERY	Bajaj spare parts
JM201016	COUPLER KIT	Bajaj spare parts
JM201028	LIGHT ASY SIGL RE-LH	Bajaj spare parts
JM201029	LIGHT ASY SIGL RE-RH	Bajaj spare parts
JM201030	BLINKER FR.LH	Bajaj spare parts
JM201031	BLINKER FR.RH	Bajaj spare parts
JM201032	ADAPTOR VENT PLUG WITH TUBE	Bajaj spare parts
JM221001	MIRROR ASSY LH	Bajaj spare parts
JM221002	MIRROR ASSY RH	Bajaj spare parts
JM221003	TOOL KIT	Bajaj spare parts
JM710123	FUEL TANK AVENGER PRIMER PAINTED	Bajaj spare parts
JM71014K	TANK FUEL WITH DECAL	Bajaj spare parts
JM71014L	TANK FUEL DECAL SILVER	Bajaj spare parts
JM71014M	TANK FUEL WITH DECAL	Bajaj spare parts
JM73014L	COVER SIDE LH JM M G SILV	Bajaj spare parts
JM73014M	CVR SIDE LEFT WITH DCL	Bajaj spare parts
JM73024K	CVR SIDE RIGHT WITH DCL	Bajaj spare parts
JM73024M	CVR SIDE RIGHT WITH DCL	Bajaj spare parts
JM74014K	FENDER REAR	Bajaj spare parts
JM74014L	FENDER FR MG SILVER	Bajaj spare parts
JN113200	DAMPER CENTER STAND	Bajaj spare parts
JN122000	SHOCK ABSORBER REAR	Bajaj spare parts
JN122006	ARM SWING DIS 135 UG	Bajaj spare parts
JN131006	WHEEL 1.6 X 17	Bajaj spare parts
JN131203	COUPLING	Bajaj spare parts

JN131211	AXLE REAR	Bajaj spare parts
JN131800	HOSE BRAKE KIT	Bajaj spare parts
JN131804	CLAMP HOSE PIPE UPPE	Bajaj spare parts
JN131806	CALIPER ASY BRAKE FR	Bajaj spare parts
JN131807	BRAKE DISC	Bajaj spare parts
JN141002	LOCK DRIVE CHAIN CON	Bajaj spare parts
JN151011	HOLDER K UPPER	Bajaj spare parts
JN171000	DAMPER REAR	Bajaj spare parts
JN181000	COWLING	Bajaj spare parts
JN181001	WINDSHIELD	Bajaj spare parts
JN181002	FLAP COWLING	Bajaj spare parts
JN181003	BRACKET FAIRING TOP	Bajaj spare parts
JN181004	BKT COWLING	Bajaj spare parts
JN181005	BRACKET HEAD LAMP MT	Bajaj spare parts
JN181006	NUT WELL	Bajaj spare parts
JN181010	BUSH 1 WINDSHIELD M	Bajaj spare parts
JN181011	BUSH 2 WINDSHIELD M	Bajaj spare parts
JN181014	FOAM SPEEDO FLAP	Bajaj spare parts
JN181017	BRACKET FLAP SUPP LH	Bajaj spare parts
JN181018	BRACKET FLAP SUPP RH	Bajaj spare parts
JN181019	FOAM FAIRING I	Bajaj spare parts
JN181020	FOAM FAIRING II	Bajaj spare parts
JN181021	BOLT FLANGED M6 X 14 L	Bajaj spare parts
JN181023	H LAMP MTG BRIDGE LH	Bajaj spare parts
JN181024	H LAMP MTG BRIDGE RH	Bajaj spare parts
JN181029	FOAM SPEEDO	Bajaj spare parts
JN181031	FOAM FAIRING	Bajaj spare parts
JN181033	BOLT FLANGED M5	Bajaj spare parts
JN181200	COVER CHAIN	Bajaj spare parts
JN181206	COVER DISC	Bajaj spare parts
JN181211	CLIP NUT - M6	Bajaj spare parts
JN181406	BEAD SPEEDO FLAP	Bajaj spare parts
JN191000	SEAT ASSY COMP	Bajaj spare parts
JN231202	LEG GUARD KIT	Bajaj spare parts
JN232600	LOCK SET 3/1SLD COU	Bajaj spare parts
JN232801	BRACKET PLATE NUMBER	Bajaj spare parts
JN351600	MOTOR STARTER	Bajaj spare parts
JN351604	STARTER RELAY-GROMMET	Bajaj spare parts
JN401008	LAMP ASSY HEAD	Bajaj spare parts
JN401400	SWITCH ASSY IIGNITIO	Bajaj spare parts
JN402000	RR UNIT WITH CAPACIT	Bajaj spare parts
JN402200	HARNESS WIRING	Bajaj spare parts
JN402203	HARNESS WIRING DIS U	Bajaj spare parts
JN402207	HARNESS RUBBER BOOT	Bajaj spare parts
JN402210	HARNESS WIRINGSOLTY	Bajaj spare parts

JN402405	TOP COV SPEEDO W/TACHO	Bajaj spare parts
JN402600	TFR TANK UNITDISCOV	Bajaj spare parts
JN511006	HEAD CYL DIS 13	Bajaj spare parts
JN511202	CAM SHAFT ASSLY	Bajaj spare parts
JN521001	CYL BL.ASSY DISCOVER-135	Bajaj spare parts
JN551400	SPRINGCLUTCH CAPACI	Bajaj spare parts
JN551408	SPRING ANTI JUDDER	Bajaj spare parts
JN551409	WASHER ANTI JUDDER	Bajaj spare parts
JN551410	PLATE FRICTION DIS-135	Bajaj spare parts
JN551416	CLUTCH PLATE ASSLY	Bajaj spare parts
JN571001	CAP STRAINER	Bajaj spare parts
JN581207	IDLING SCREW KIT	Bajaj spare parts
JN581208	JET HOLDER KIT	Bajaj spare parts
JN581212	CHOKE PLUNGER HOUSIN	Bajaj spare parts
JN581215	JET NEEDLE NJNFA	Bajaj spare parts
JN581216	CARBURETTOR ASSLY.	Bajaj spare parts
JN581217	JET HOLDER KIT	Bajaj spare parts
JN73013B	FAIRING BLACK BLUE D	Bajaj spare parts
JP111067	BRACKET SPIDER LH	Bajaj spare parts
JP111068	BRACKET SPIDER RH	Bajaj spare parts
JP111069	BRACKET BRIDGE LOOSE	Bajaj spare parts
JP111070	DAMPER RUBBER M8	Bajaj spare parts
JP113004	STEP HOLDER RIDER LH	Bajaj spare parts
JP113005	STEP HOLDER RIDER RH	Bajaj spare parts
JP113006	STEP HOLDER PILLION LH	Bajaj spare parts
JP113007	STEP HOLDER PILLION RH	Bajaj spare parts
JP113012	HEEL GUARD REAR LH	Bajaj spare parts
JP113013	HEEL GUARD REAR RH	Bajaj spare parts
JP113014	BRACKET BRIDGE PILLION STEP	Bajaj spare parts
JP113015	PIN DOWEL	Bajaj spare parts
JP113017	PLATE LOCK PILLION STEP TOP	Bajaj spare parts
JP113018	PLATE LOCK PILLION STEP BOTTOM	Bajaj spare parts
JP113019	PIN FOOTREST PIVOT BLACK	Bajaj spare parts
JP113021	STEP RIDER RH	Bajaj spare parts
JP113022	STEP PILLION LH	Bajaj spare parts
JP113023	STEP PILLION RH	Bajaj spare parts
JP113025	PAD STEP	Bajaj spare parts
JP113027	ASSLY STEP RIDER LH	Bajaj spare parts
JP113028	ASSLY STEP RIDER RH	Bajaj spare parts
JP113029	STEP ASSEMBLY PILLION LH	Bajaj spare parts
JP113030	ASSLY STEP PILLION RH	Bajaj spare parts
JP113035	SPRING TORSION	Bajaj spare parts
JP113037	HOLDER STEP RIDER LH	Bajaj spare parts
JP113038	HOLDER STEP RIDER RH	Bajaj spare parts
JP113041	HOLDER STEP PILLION LH	Bajaj spare parts

JP113042	HOLDER STEP PILLION RH	Bajaj spare parts
JP113201	PLATE SIDE STAND	Bajaj spare parts
JP113203	STAND ASSEMBLY SIDE	Bajaj spare parts
JP113204	PLATE STAND SIDE	Bajaj spare parts
JP113205	GUARD SWITCH STAND SIDE	Bajaj spare parts
JP113229	PLATE STAND SIDE	Bajaj spare parts
JP113402	ENGINE HANGER LH KT21/KT22	Bajaj spare parts
JP113403	ENGINE HANGER RH KT21/KT22	Bajaj spare parts
JP113800	BRACKET RADIATOR MTG RH	Bajaj spare parts
JP113801	BRACKET SEAT MOUNT LOOSE	Bajaj spare parts
JP113802	BRACKET PURGE VALVE LOOSE KT22	Bajaj spare parts
JP113803	BRACKET ECU MTG TOP	Bajaj spare parts
JP113804	BRACKET ABS MTG LOOSE	Bajaj spare parts
JP113809	BRACKET RESERVOIR MTG	Bajaj spare parts
JP113810	BRACKET SILENCER MOUNTING	Bajaj spare parts
JP113811	BRACKET REAR HOSE GUIDE I	Bajaj spare parts
JP113812	BRACKET REAR HOSE GUIDE II	Bajaj spare parts
JP113814	DAMPER WITH STUD	Bajaj spare parts
JP113815	GROMMET CLUTCH CABLE GUIDE	Bajaj spare parts
JP113816	BRACKET RADIATOR MTG LOOSE	Bajaj spare parts
JP113822	SPACER PIVOT FORGING LH	Bajaj spare parts
JP113823	RUBBER CLUTCH CABLE GUIDE	Bajaj spare parts
JP113826	PAD RESTING ECU MY17	Bajaj spare parts
JP113827	BRACKET CLUTCH CABLE GUIDE LOOSE	Bajaj spare parts
JP113828	GUIDE CLUTCH CABLE	Bajaj spare parts
JP113830	Bkt-No.Plate	Bajaj spare parts
JP113831	Sleeve - No. Plate	Bajaj spare parts
JP113832	COLLAR TFT SPEEDO SMALL	Bajaj spare parts
JP113833	SLEEVE CLUTCH CABLE GUIDE	Bajaj spare parts
JP113835	SLEEVE COVER IGNITION COIL	Bajaj spare parts
JP113837	NUT SOCKET-M10X1.25XHT. 24XBRT	Bajaj spare parts
JP113838	DAMPER BRACKET ECU MTG	Bajaj spare parts
JP113840	SHIELD	Bajaj spare parts
JP113841	PROTECTOR	Bajaj spare parts
JP113849	BRACKET VALVE PURGE	Bajaj spare parts
JP113852	PLUG BLACK	Bajaj spare parts
JP113853	PLUG ORANGE	Bajaj spare parts
JP113859	BRACKET VALVE PURGE	Bajaj spare parts
JP121014	ASSEMBLY LEG LH 125 NHD	Bajaj spare parts
JP121015	ASSEMBLY LEG RH 125 NHD	Bajaj spare parts
JP121022	TUBE OUTER HD	Bajaj spare parts
JP121024	TUBE INNER DIA 43	Bajaj spare parts
JP121028	CARTRIDGE SPLIT COMP.CPL KT20 H.D.	Bajaj spare parts
JP121034	CARTRIDGE SPLIT REB.CPL KT20 H.D.	Bajaj spare parts
JP121037	ASSLY FORK PIPE LH	Bajaj spare parts

JP121038	ASSLY FORK PIPE RH	Bajaj spare parts
JP121040	GUIDE BUSH UPPER	Bajaj spare parts
JP121041	GUIDE BUSH LOWER	Bajaj spare parts
JP121043	CARTRIDGE SPLIT COMP.CPL KT22 H.D.	Bajaj spare parts
JP121044	CARTRIDGE SPLIT REB.CPL KT22 H.D.	Bajaj spare parts
JP121045	OIL PACKED FOR SINGLE LEG	Bajaj spare parts
JP121046	ASSLY LOWER TRIPLE CLAMP GDC	Bajaj spare parts
JP121047	BOLT FORK	Bajaj spare parts
JP121048	DECAL FORK FRONT WP	Bajaj spare parts
JP121049	LEG ASSLY LH	Bajaj spare parts
JP121050	LEG ASSLY RH	Bajaj spare parts
JP121068	RING O	Bajaj spare parts
JP121070	FORK FRONT	Bajaj spare parts
JP121074	LEG ASSEMBLY LH	Bajaj spare parts
JP121075	LEG ASSEMBLY RH	Bajaj spare parts
JP121092	LEG ASSEMBLY LH	Bajaj spare parts
JP121093	LEG ASSEMBLY RH	Bajaj spare parts
JP121098	FORK FRONT	Bajaj spare parts
JP121103	FORK FRONT	Bajaj spare parts
JP121111	FORK FRONT	Bajaj spare parts
JP121118	TAPE	Bajaj spare parts
JP122001	SHOCKABSORBER MONO DUKE 200 NHD	Bajaj spare parts
JP122002	SHOCKABSORBER MONO DUKE 390 NHD MY17	Bajaj spare parts
JP122005	SHOCKABSORBER MONO KT22 HD	Bajaj spare parts
JP122016	SHOCKABSORBER REAR	Bajaj spare parts
JP122018	SHOCKABSORBER REAR	Bajaj spare parts
JP122022	SHOCKABSORBER REAR	Bajaj spare parts
JP122023	SHOCKABSORBER REAR	Bajaj spare parts
JP122032	SHOCKABSORBER REAR	Bajaj spare parts
JP122066	CLAMP HOSE	Bajaj spare parts
JP131009	FRONT AXLE KT22	Bajaj spare parts
JP131205	SPROCKET 44 T	Bajaj spare parts
JP131802	ASSLY MASTER CYLINDER	Bajaj spare parts
JP131806	UNIT ABS WET KT19	Bajaj spare parts
JP131807	UNIT ABS WET KT22	Bajaj spare parts
JP131811	UNIT ABS DRY KT19	Bajaj spare parts
JP131817	DISC 320MM 110PCD	Bajaj spare parts
JP131818	DISC 300MM 110PCD	Bajaj spare parts
JP131823	BRACKET CAP RESERVOIR	Bajaj spare parts
JP131850	UNIT ABS WET	Bajaj spare parts
JP131854	UNIT ABS WET	Bajaj spare parts
JP131858	UNIT ABS WET	Bajaj spare parts
JP131859	UNIT ABS WET	Bajaj spare parts
JP131861	DISC BRAKE DIA 300	Bajaj spare parts
JP131879	GROMMET	Bajaj spare parts

JP131909	CLAMP HOSE	Bajaj spare parts
JP151004	Handle Bar	Bajaj spare parts
JP151005	HANDLEBAR	Bajaj spare parts
JP151009	SPACER TUBE MY17	Bajaj spare parts
JP151010	UPPER TRIPLE CLAMP GDC	Bajaj spare parts
JP151011	LOWER TRIPLE CLAMP GDC	Bajaj spare parts
JP151012	SPACER HANDLEBAR KT19-20	Bajaj spare parts
JP151013	HOLDER HANDLEBAR CUM TFT SPEEDO	Bajaj spare parts
JP151015	HANDLE HOLDER BOTTOM	Bajaj spare parts
JP151016	HANDLE HOLDER TOP	Bajaj spare parts
JP151031	HANDLEBAR	Bajaj spare parts
JP161001	ASSLY BRAKE LEVER MY17	Bajaj spare parts
JP161004	ASSLY HOLDER LH NON ADJUSTABLE	Bajaj spare parts
JP161005	ASSLY LEVER AND HOLDER LH	Bajaj spare parts
JP161007	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JP161008	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JP161009	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JP161010	SLEEVE	Bajaj spare parts
JP161200	CLUTCH CABLE DUKE 125/200	Bajaj spare parts
JP161202	CABLE THROTTLE 125	Bajaj spare parts
JP171005	ASSLY QC AND HOSE FUEL FILTER TO REGU	Bajaj spare parts
JP171008	ASSLY QC AND HOSE PUMP TO FUEL FILTER	Bajaj spare parts
JP171026	TUBE TANK TO Y CONNECTOR	Bajaj spare parts
JP171027	DAMPER TANK MTG REAR	Bajaj spare parts
JP171030	GROMMET LATCH MTG BKT	Bajaj spare parts
JP171031	PLATE PRESSURE FUEL PUMP	Bajaj spare parts
JP171038	TUBE 'Y' CONNECTOR TO CANISTER	Bajaj spare parts
JP171039	TUBE CANISTER TO PURGE VALVE	Bajaj spare parts
JP171040	TUBE PURGE VALVE TO CONNECTOR	Bajaj spare parts
JP171043	BRACKET EXPANSION TANK LOOSE	Bajaj spare parts
JP171044	BRACKET CANISTER LOOSE	Bajaj spare parts
JP171051	GROMMET	Bajaj spare parts
JP171053	SLEEVE EXPANSION TANK MTG	Bajaj spare parts
JP171056	SLEEVE TANK MTG	Bajaj spare parts
JP171057	SLEEVE TANK MTG FRONT	Bajaj spare parts
JP171060	TUBE CONNECTOR TO THROTTLE BODY ETB	Bajaj spare parts
JP171062	TUBE CANISTER DRAIN	Bajaj spare parts
JP171074	PIPE CANISTER-VALVE PURGE	Bajaj spare parts
JP171075	PIPE VALVE PURGE-BODY THROTTLE	Bajaj spare parts
JP171088	TANK ASSEMBLY FUEL	Bajaj spare parts
JP171604	TUBE CONNECTOR TO THROTTLE BODY MTB	Bajaj spare parts
JP171610	PIPE CONNECTOR-VALVE PURGE	Bajaj spare parts
JP171612	PIPE VALVE PURGE-BODY THROTTLE	Bajaj spare parts
JP171807	PLUG EVAP DRAIN	Bajaj spare parts
JP171808	CAP PLUG EVAP DRAIN	Bajaj spare parts

JP171809	GASKET O RING PLUG EVAP DRAIN	Bajaj spare parts
JP171811	PIPE PUMP FUEL-FILTER I	Bajaj spare parts
JP171812	PIPE PUMP FUEL-FILTER II	Bajaj spare parts
JP171813	PLATE PUMP FUEL	Bajaj spare parts
JP171814	PUMP FUEL	Bajaj spare parts
JP171816	PIPE FILTER FUEL-INJECTOR	Bajaj spare parts
JP171818	PUMP FUEL	Bajaj spare parts
JP181000	TUBE ASSEMBLY HUGGER REAR	Bajaj spare parts
JP181001	PANEL ELECTRIC MTG	Bajaj spare parts
JP181002	UNDER TRAY FRONT	Bajaj spare parts
JP181004	SEAT COWL LOWER LH	Bajaj spare parts
JP181005	SEAT COWL LOWER RH	Bajaj spare parts
JP181006	SEAT COWL UPPER LH	Bajaj spare parts
JP181007	SEAT COWL UPPER RH	Bajaj spare parts
JP181013	GROMMET UNDER TRAY	Bajaj spare parts
JP181014	COLLAR TAIL LAMP MOUNTING	Bajaj spare parts
JP181015	TAPE COVER TANK LH	Bajaj spare parts
JP181016	TAPE COVER TANK RH	Bajaj spare parts
JP181017	SPRING	Bajaj spare parts
JP181200	BELLY PAN DUKE 125/200	Bajaj spare parts
JP181201	BELLY PAN DUKE 390	Bajaj spare parts
JP181202	COVER RADIATOR LH	Bajaj spare parts
JP181203	COVER RADIATOR RH	Bajaj spare parts
JP181205	BATTERY BOX	Bajaj spare parts
JP181206	TANK COVER LH	Bajaj spare parts
JP181207	TANK COVER RH	Bajaj spare parts
JP181209	BRACKET BELLY PAN FRONT KT22	Bajaj spare parts
JP181210	BRACKET BELLY PAN FRONT REAR KT22	Bajaj spare parts
JP181218	TANK SPOILER INNER RH	Bajaj spare parts
JP181219	TANK SPOILER INNER LH	Bajaj spare parts
JP181220	IGNITION SWITCH COVER	Bajaj spare parts
JP181226	GROMMET EXPANSION TANK MTG	Bajaj spare parts
JP181227	GROMMET SPOILER MTG	Bajaj spare parts
JP181228	CHAIN CHAIN COVER ASSLY	Bajaj spare parts
JP181229	GROMMET IGNITION SWITCH COVER	Bajaj spare parts
JP181231	BUSH BELLY PAN MTG	Bajaj spare parts
JP181232	SLEEVE RADIATOR	Bajaj spare parts
JP181233	SPACER RADIATOR SHROUD	Bajaj spare parts
JP181234	Grommet Ign.CVR	Bajaj spare parts
JP181236	CAP RADIATOR SHROUD	Bajaj spare parts
JP181239	COVER ASSEMBLY SWITCH IGNITION	Bajaj spare parts
JP181240	DASHBOARD LCD SPEEDOMETER	Bajaj spare parts
JP181241	FAIRING BACK COVER	Bajaj spare parts
JP181242	FAIRING BACK COVER BULB HL	Bajaj spare parts
JP181243	BACK COVER TFT HOLDER	Bajaj spare parts



JP181247	SLEEVE RESERVOIR MOUNTING	Bajaj spare parts
JP181248	INSERT BRACKET SPEEDO HOLDER	Bajaj spare parts
JP181249	SPEEDOMETER HOLDER BACKCOVER	Bajaj spare parts
JP181250	BRACKET SPEEDOMETER HOLDER	Bajaj spare parts
JP181254	SIDE MASK LH FRONT FAIRING LED	Bajaj spare parts
JP181255	SIDE MASK RH FRONT FAIRING LED	Bajaj spare parts
JP181256	HOLDER HEADLAMP LED	Bajaj spare parts
JP181258	ASSLY LED HL ADJUSTMENT MECHANISM TOP	Bajaj spare parts
JP181259	ASSLY LED HL ADJUSTMENT MECHANISM BOT	Bajaj spare parts
JP181260	HOLDER LED HL ADJUSTMENT MECHANISM	Bajaj spare parts
JP181261	GROMMET HL COVER TOP	Bajaj spare parts
JP181262	GROMMET HL COVER BOTTOM	Bajaj spare parts
JP181263	GROMMET RUBBER 2 FRONT FAIRING	Bajaj spare parts
JP181278	SLEEVE SPOILER INNER RR MTG	Bajaj spare parts
JP181279	GROMMET FRONT FAIRING ASSY	Bajaj spare parts
JP181280	COLLAR HEAD LAMP HOLDER MTG	Bajaj spare parts
JP181281	SIDE MASK LH FRONT FAIRING BULB HL	Bajaj spare parts
JP181282	SIDE MASK RH FRONT FAIRING BULB HL	Bajaj spare parts
JP181283	ADAPTER BLINKER USA LH	Bajaj spare parts
JP181284	MIDDLE MASK BULB HL	Bajaj spare parts
JP181286	BRACKET TFT COVER BACK	Bajaj spare parts
JP181287	BRACKET BELLY PAN REAR	Bajaj spare parts
JP181288	COVER IGNITION COIL	Bajaj spare parts
JP181291	GROMMET NUMBER PLATE MTG	Bajaj spare parts
JP181296	GROMMET SPOILER TANK	Bajaj spare parts
JP181297	BOX BATTERY	Bajaj spare parts
JP181299	GUARD LH	Bajaj spare parts
JP181315	COVER ECU	Bajaj spare parts
JP181316	SPACER	Bajaj spare parts
JP181326	BELLY PAN	Bajaj spare parts
JP181329	BRACKET BELLY PAN LH	Bajaj spare parts
JP181330	BRACKET BELLY PAN RH	Bajaj spare parts
JP181342	BELLY PAN	Bajaj spare parts
JP181357	STRUCTURE BELLY PAN	Bajaj spare parts
JP181373	SHROUD RADIATOR LH	Bajaj spare parts
JP181374	SHROUD RADIATOR RH	Bajaj spare parts
JP181379	BRACKET HOLDER SPEEDOMETER	Bajaj spare parts
JP181380	COLLAR	Bajaj spare parts
JP181383	CONNECTOR SHROUD RADIATOR	Bajaj spare parts
JP181400	FENDER FRONT	Bajaj spare parts
JP181402	FLAP FENDER FRONT	Bajaj spare parts
JP181404	FLAP PROTECTOR	Bajaj spare parts
JP181407	BRACKET REFLEX REFLECTOR	Bajaj spare parts
JP181408	WASHER EXTRUDED	Bajaj spare parts
JP181413	GROMMET	Bajaj spare parts

JP181415	FLAP FENDER FRONT	Bajaj spare parts
JP181417	PROTECTOR FORK LH	Bajaj spare parts
JP181418	PROTECTOR FORK RH	Bajaj spare parts
JP181419	PROTECTOR FORK OUTER LH	Bajaj spare parts
JP181420	PROTECTOR FORK OUTER RH	Bajaj spare parts
JP191000	SEAT ASSLY FRONT	Bajaj spare parts
JP191001	SEAT ASSLY REAR	Bajaj spare parts
JP191007	SEAT DAMPER REAR	Bajaj spare parts
JP191009	DAMPER SEAT	Bajaj spare parts
JP191010	GROMMET RIDER SEAT	Bajaj spare parts
JP191012	ASSLY BUSH DAMPER SEAT	Bajaj spare parts
JP191021	SEAT ASSEMBLY FRONT	Bajaj spare parts
JP191022	SEAT ASSEMBLY REAR	Bajaj spare parts
JP231200	LEG GUARD RH KT19-KT22	Bajaj spare parts
JP231202	GUARD LEG LH	Bajaj spare parts
JP231203	GUARD LEG RH	Bajaj spare parts
JP231209	GUARD LEG LH	Bajaj spare parts
JP231210	GUARD LEG RH	Bajaj spare parts
JP231211	GUARD LEG LH	Bajaj spare parts
JP231212	GUARD LEG RH	Bajaj spare parts
JP231213	GUARD ASSEMBLY LEG LH	Bajaj spare parts
JP231400	GRAB HANDLE LH	Bajaj spare parts
JP231401	GRAB HANDLE RH	Bajaj spare parts
JP231409	GRAB HANDLE LH	Bajaj spare parts
JP231410	GRAB HANDLE RH	Bajaj spare parts
JP231600	MIRROR LH	Bajaj spare parts
JP231601	MIRROR RH	Bajaj spare parts
JP232600	BRACKET SEAT LOCK	Bajaj spare parts
JP232601	SEAT LOCK	Bajaj spare parts
JP232602	SEAT LOCK CABLE	Bajaj spare parts
JP232802	CAP RUBBER REAR NUMBER PLATE	Bajaj spare parts
JP232804	LEO BUSH RR NO PLATE STRUCTURE	Bajaj spare parts
JP232805	BRACKET NUMBER PLATE DOMESTIC	Bajaj spare parts
JP232808	HOLDER NUMBER PLATE	Bajaj spare parts
JP232811	STRUCTURE ASSLY PLATE NUMBER	Bajaj spare parts
JP232812	BRACKET PLATE NUMBER REAR	Bajaj spare parts
JP232824	STRUCTURE ASSEMBLY PLATE NUMBER	Bajaj spare parts
JP232825	COVER STRUCTURE	Bajaj spare parts
JP232827	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JP232830	BRACKET PLATE NUMBER REAR	Bajaj spare parts
JP232831	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JP233006	DECAL SET WHITE KT21	Bajaj spare parts
JP233007	DECAL SET ORANGE KT21	Bajaj spare parts
JP233008	DECAL SET ORANGE KT22	Bajaj spare parts
JP233009	DECAL SET WHITE KT22	Bajaj spare parts

JP233010	DECAL TANK CENTER MY17	Bajaj spare parts
JP233011	DECAL RADIATOR COVER LH MY17	Bajaj spare parts
JP233012	DECAL RADIATOR COVER RH MY17	Bajaj spare parts
JP233013	DECAL WHEEL RIM FRONT LH KT 19/20/21	Bajaj spare parts
JP233014	DECAL WHEEL RIM FRONT RH KT 19/20/21	Bajaj spare parts
JP233015	DECAL WHEEL RIM FRONT LH KT22	Bajaj spare parts
JP233016	DECAL WHEEL RIM FRONT RH KT22	Bajaj spare parts
JP233025	DECAL TANK SPOILER LH WHITE KT21	Bajaj spare parts
JP233026	DECAL TANK SPOILER RH WHITE KT21	Bajaj spare parts
JP233027	DECAL TANK SPOILER LH ORNGE KT21	Bajaj spare parts
JP233028	DECAL TANK SPOILER RH ORNGE KT21	Bajaj spare parts
JP233029	DECAL TANK SPOILER LH WHITE KT22	Bajaj spare parts
JP233030	DECAL TANK SPOILER RH WHITE KT22	Bajaj spare parts
JP233031	DECAL TANK SPOILER LH ORNGE KT22	Bajaj spare parts
JP233032	DECAL TANK SPOILER RH ORNGE KT22	Bajaj spare parts
JP233035	DECAL WHEEL RIM REAR LH KT19/20/21	Bajaj spare parts
JP233036	DECAL WHEEL RIM REAR RH KT19/20/21	Bajaj spare parts
JP233039	DECAL WHEEL RIM REAR LH KT22	Bajaj spare parts
JP233040	DECAL WHEEL RIM REAR RH KT22	Bajaj spare parts
JP233041	DECAL SEAT COWL LH KT21	Bajaj spare parts
JP233042	DECAL SEAT COWL RH KT21	Bajaj spare parts
JP233043	DECAL SEAT COWL LH KT22	Bajaj spare parts
JP233044	DECAL SEAT COWL RH KT22	Bajaj spare parts
JP233090	LABEL WARNING	Bajaj spare parts
JP233094	DECAL COWL SEAT LH	Bajaj spare parts
JP233095	DECAL COWL SEAT RH	Bajaj spare parts
JP233096	DECAL TANK LH BLACK	Bajaj spare parts
JP233097	DECAL TANK RH BLACK	Bajaj spare parts
JP233098	DECAL TANK LH ORANGE	Bajaj spare parts
JP233099	DECAL TANK RH ORANGE	Bajaj spare parts
JP233100	DECAL TANK LH WHITE	Bajaj spare parts
JP233101	DECAL TANK RH WHITE	Bajaj spare parts
JP233102	DECAL BELLY PAN LH	Bajaj spare parts
JP233103	DECAL BELLY PAN RH	Bajaj spare parts
JP233115	DECAL FAIRING LH SILVER	Bajaj spare parts
JP233116	DECAL FAIRING RH SILVER	Bajaj spare parts
JP233117	DECAL TANK LH SILVER	Bajaj spare parts
JP233118	DECAL TANK RH SILVER	Bajaj spare parts
JP233119	DECAL COWL SEAT LH SILVER	Bajaj spare parts
JP233120	DECAL COWL SEAT RH SILVER	Bajaj spare parts
JP233121	DECAL WHEEL SILVER	Bajaj spare parts
JP233122	EMBLEM KTM LH	Bajaj spare parts
JP233123	EMBLEM KTM RH	Bajaj spare parts
JP233124	DECAL FAIRING LH BLACK	Bajaj spare parts
JP233125	DECAL FAIRING RH BLACK	Bajaj spare parts

JP233126	DECAL TANK LH BLACK	Bajaj spare parts
JP233127	DECAL TANK RH BLACK	Bajaj spare parts
JP233128	DECAL COWL SEAT LH BLACK	Bajaj spare parts
JP233129	DECAL COWL SEAT RH BLACK	Bajaj spare parts
JP233130	DECAL WHEEL BLACK	Bajaj spare parts
JP233134	DECAL FAIRING LH SILVER	Bajaj spare parts
JP233135	DECAL FAIRING RH SILVER	Bajaj spare parts
JP233136	DECAL TANK LH SILVER	Bajaj spare parts
JP233137	DECAL TANK RH SILVER	Bajaj spare parts
JP233138	DECAL FAIRING LH BLACK	Bajaj spare parts
JP233139	DECAL FAIRING RH BLACK	Bajaj spare parts
JP233140	DECAL TANK LH BLACK	Bajaj spare parts
JP233141	DECAL TANK RH BLACK	Bajaj spare parts
JP233145	DECAL FAIRING LH SILVER	Bajaj spare parts
JP233146	DECAL FAIRING RH SILVER	Bajaj spare parts
JP233147	DECAL TANK LH SILVER	Bajaj spare parts
JP233148	DECAL TANK RH SILVER	Bajaj spare parts
JP233149	DECAL COWL SEAT LH WHITE	Bajaj spare parts
JP233150	DECAL COWL SEAT RH WHITE	Bajaj spare parts
JP233153	DECAL TANK LH WHITE	Bajaj spare parts
JP233154	DECAL TANK RH WHITE	Bajaj spare parts
JP233159	DECAL FAIRING LH ORANGE	Bajaj spare parts
JP233160	DECAL FAIRING RH ORANGE	Bajaj spare parts
JP233161	DECAL TANK LH ORANGE	Bajaj spare parts
JP233162	DECAL TANK RH ORANGE	Bajaj spare parts
JP233163	DECAL COWL SEAT LH ORANGE	Bajaj spare parts
JP233164	DECAL COWL SEAT RH ORANGE	Bajaj spare parts
JP233165	DECAL TANK LH WHITE	Bajaj spare parts
JP233166	DECAL TANK RH WHITE	Bajaj spare parts
JP233169	DECAL WHEEL FRONT LH BLACK	Bajaj spare parts
JP233170	DECAL WHEEL FRONT RH BLACK	Bajaj spare parts
JP233171	DECAL WHEEL REAR RH BLACK	Bajaj spare parts
JP233172	DECAL WHEEL FRONT LH ORANGE	Bajaj spare parts
JP233173	DECAL WHEEL FRONT RH ORANGE	Bajaj spare parts
JP233174	DECAL WHEEL REAR RH ORANGE	Bajaj spare parts
JP233196	DECAL COWL SEAT LH	Bajaj spare parts
JP233197	DECAL COWL SEAT RH	Bajaj spare parts
JP233198	DECAL TANK LH ORANGE	Bajaj spare parts
JP233199	DECAL TANK RH ORANGE	Bajaj spare parts
JP233200	DECAL TANK LH WHITE	Bajaj spare parts
JP233201	DECAL TANK RH WHITE	Bajaj spare parts
JP233222	DECAL TANK LH WHITE	Bajaj spare parts
JP233223	DECAL TANK RH WHITE	Bajaj spare parts
JP233224	DECAL COWL SEAT LH	Bajaj spare parts
JP233225	DECAL COWL SEAT RH	Bajaj spare parts

JP233226	DECAL TANK GREY LH	Bajaj spare parts
JP233227	DECAL TANK GREY RH	Bajaj spare parts
JP233228	DECAL COWL SEAT LH	Bajaj spare parts
JP233229	DECAL COWL SEAT RH	Bajaj spare parts
JP233230	DECAL TANK LH BLACK	Bajaj spare parts
JP233231	DECAL TANK RH BLACK	Bajaj spare parts
JP233232	DECAL TANK GREY LH	Bajaj spare parts
JP233233	DECAL TANK GREY RH	Bajaj spare parts
JP233234	DECAL COWL SEAT LH ORANGE	Bajaj spare parts
JP233235	DECAL COWL SEAT RH ORANGE	Bajaj spare parts
JP233295	DECAL TANK BLACK LH	Bajaj spare parts
JP233296	DECAL TANK BLACK RH	Bajaj spare parts
JP234002	LABEL BOX FUSE	Bajaj spare parts
JP351005	SENSOR ASSEMBLY PICK UP	Bajaj spare parts
JP351007	STATOR ASSY	Bajaj spare parts
JP351010	SENSOR ASSEMBLY PICK UP	Bajaj spare parts
JP351019	STATOR ASSEMBLY	Bajaj spare parts
JP351020	ROTOR ASSEMBLY	Bajaj spare parts
JP351023	STATOR ASSEMBLY	Bajaj spare parts
JP351026	ASSEMBLY ROTOR	Bajaj spare parts
JP351203	COIL ASSEMBLY IGNITION	Bajaj spare parts
JP351204	COIL ASSEMBLY IGNITION	Bajaj spare parts
JP351209	GROMMET PLUG SPARK	Bajaj spare parts
JP351439	ECU	Bajaj spare parts
JP351463	ECU EMS	Bajaj spare parts
JP351464	ECU EMS	Bajaj spare parts
JP351600	MOTOR STARTER	Bajaj spare parts
JP351800	SENSOR AIR INTAKE TEMP	Bajaj spare parts
JP351801	SENSOR PRESSURE	Bajaj spare parts
JP351803	SENSOR LEVER GEAR SHIFT	Bajaj spare parts
JP401000	LAMP HEAD MY17	Bajaj spare parts
JP401001	LAMP TAIL MY17	Bajaj spare parts
JP401003	BULB HEAD LAMP	Bajaj spare parts
JP401004	GROMMET ROUND	Bajaj spare parts
JP401005	GROMMET SQUARE	Bajaj spare parts
JP401006	NYLON WASHER SQUARE	Bajaj spare parts
JP401007	SPACER GROMMET ROUND	Bajaj spare parts
JP401018	INDICATOR FRONT LH	Bajaj spare parts
JP401019	INDICATOR FRONT RH	Bajaj spare parts
JP401021	GROMMET TAIL LAMP RH	Bajaj spare parts
JP401029	ASSLY INDICATOR FRONT LH	Bajaj spare parts
JP401032	LAMP HEAD	Bajaj spare parts
JP401034	BUSH AIMING	Bajaj spare parts
JP401039	LAMP HEAD	Bajaj spare parts
JP401041	BULB	Bajaj spare parts

JP401401	CONTROL SWITCH - LH	Bajaj spare parts
JP401402	SWITCH CONTROL RH KT19	Bajaj spare parts
JP401406	SWITCH CONTROL LH	Bajaj spare parts
JP401411	SWITCH CONTROL RH	Bajaj spare parts
JP401412	SWITCH CONTROL RH	Bajaj spare parts
JP401414	SWITCH STAND SIDE	Bajaj spare parts
JP401418	LOCATOR SWITCH	Bajaj spare parts
JP401419	LOCATOR SWITCH	Bajaj spare parts
JP401434	HOLDER MAGNET	Bajaj spare parts
JP401435	SWITCH STAND SIDE	Bajaj spare parts
JP401600	HORN KT22	Bajaj spare parts
JP401800	BAND BATTERY I	Bajaj spare parts
JP401801	BAND BATTERY II	Bajaj spare parts
JP401802	BRACKET BATTERY BAND I	Bajaj spare parts
JP402000	REGULATOR 3 PHASE	Bajaj spare parts
JP402002	REGULATOR	Bajaj spare parts
JP402200	HARNESS WIRING	Bajaj spare parts
JP402201	HARNESS WIRING NON ABS DUKE-200	Bajaj spare parts
JP402202	CABLE EARTH MY17	Bajaj spare parts
JP402203	CABLE RELAY TO MOTOR MY17	Bajaj spare parts
JP402204	HARNESS WIRING DUKE 125	Bajaj spare parts
JP402205	HARNESS WIRING DUKE 250	Bajaj spare parts
JP402217	PIGTAIL INTAKE AIR TEMPERATURE SENSOR	Bajaj spare parts
JP402218	PIGTAIL OIL PRESSURE SWITCH MY17	Bajaj spare parts
JP402221	CABLE EARTH ABS	Bajaj spare parts
JP402224	HARNESS WIRING	Bajaj spare parts
JP402237	HARNESS WIRING	Bajaj spare parts
JP402238	HARNESS WIRING	Bajaj spare parts
JP402250	HARNESS WIRING	Bajaj spare parts
JP402262	HARNESS WIRING	Bajaj spare parts
JP402263	HARNESS WIRING	Bajaj spare parts
JP402267	CABLE RELAY-MOTOR STARTER	Bajaj spare parts
JP402285	HARNESS WIRING	Bajaj spare parts
JP402367	HARNESS WIRING	Bajaj spare parts
JP402400	"SPEEDOMETER WITH TFT,CAN,ABS"	Bajaj spare parts
JP402401	"SPEEDOMETER LCD,CAN,NON-ABS"	Bajaj spare parts
JP402402	"SPEEDOMETER LCD,CAN,ABS"	Bajaj spare parts
JP402403	SPEEDOMETER	Bajaj spare parts
JP402408	SPEEDOMETER	Bajaj spare parts
JP402409	SPEEDOMETER	Bajaj spare parts
JP402410	SPEEDOMETER	Bajaj spare parts
JP402416	SPEEDOMETER	Bajaj spare parts
JP402424	SPEEDOMETER	Bajaj spare parts
JP403000	STARTER RELAY	Bajaj spare parts
JP403002	DAMPER RELAY STARTER	Bajaj spare parts

JP501002	ENGINE ASSLY	Bajaj spare parts
JP501035	ENGINE ASSLY	Bajaj spare parts
JP511001	Breather Pipe	Bajaj spare parts
JP511016	PIPE BREATHER	Bajaj spare parts
JP511062	HEAD CYLINDER-HOLDER CAMSHAFT	Bajaj spare parts
JP511208	CAMSHAFT ASSEMBLY INTAKE	Bajaj spare parts
JP511209	CAMSHAFT ASSEMBLY EXHAUST	Bajaj spare parts
JP511213	CAMSHAFT ASSLY INTAKE	Bajaj spare parts
JP511214	CAMSHAFT ASSLY EXHAUST	Bajaj spare parts
JP511228	VALVE EXHAUST	Bajaj spare parts
JP511229	VALVE EXHAUST	Bajaj spare parts
JP511230	VALVE EXHAUST	Bajaj spare parts
JP511248	SEAT SPRING VALVE	Bajaj spare parts
JP511249	SPRING VALVE	Bajaj spare parts
JP531025	ASSEMBLY CRANKSHAFT	Bajaj spare parts
JP531206	BALANCER ASSEMBLY	Bajaj spare parts
JP541208	GASKET MAGNETO COVER	Bajaj spare parts
JP541219	CLUTCH COVER WITH PLUG	Bajaj spare parts
JP541231	COVER ASSEMBLY CLUTCH	Bajaj spare parts
JP541233	COVER ASSEMBLY MAGNETO	Bajaj spare parts
JP541244	SHAFT ASSEMBLY CLUTCH	Bajaj spare parts
JP551011	COLLAR	Bajaj spare parts
JP551012	WASHER -ID 16XOD 26XTHK 1	Bajaj spare parts
JP551224	GEAR THIRD DRIVEN	Bajaj spare parts
JP551225	GEAR FIFTH DRIVEN	Bajaj spare parts
JP551226	GEAR SIXTH DRIVEN	Bajaj spare parts
JP561003	FORK GEAR SHIFT OUTPUT	Bajaj spare parts
JP561200	ASSEMBLY LEVER GEAR SHIFT	Bajaj spare parts
JP561203	GUIDE GEAR SHIFT	Bajaj spare parts
JP561400	CHANGE ARM	Bajaj spare parts
JP561402	ASSLY CHANGE LEVER	Bajaj spare parts
JP561403	ASSLY TIE ROD	Bajaj spare parts
JP581001	DUCT DIRTY SIDE	Bajaj spare parts
JP581002	AIR FILTER ASSLY CPL	Bajaj spare parts
JP581003	FILTER ELEMENT	Bajaj spare parts
JP581004	BREATHER TUBE ASSEMBLY	Bajaj spare parts
JP581008	CAP TOP COVER	Bajaj spare parts
JP581009	SEAL CAP TOP COVER	Bajaj spare parts
JP581012	GROMMET DUCT DIRTY SIDE	Bajaj spare parts
JP581013	BREATHER TUBE	Bajaj spare parts
JP581014	TUBE OIL RETURN	Bajaj spare parts
JP581015	ASSLY OIL RETURN TUBE	Bajaj spare parts
JP581018	TUBE DRAIN	Bajaj spare parts
JP581019	RUBBER DAMPER	Bajaj spare parts
JP581020	BRACKET DUCT DIRTY SIDE	Bajaj spare parts

JP581021	TUBE CONNECTING	Bajaj spare parts
JP581023	TUBE CONNECTING	Bajaj spare parts
JP581027	BREATHER TUBE	Bajaj spare parts
JP581028	ASSLY AIR FILTER DUKE	Bajaj spare parts
JP581030	ASSLY BREATHER TUBE	Bajaj spare parts
JP581031	RUBBER FLAP	Bajaj spare parts
JP581035	SENSOR COVER	Bajaj spare parts
JP581036	DUAL LOCK 3M - SIZE 10X15	Bajaj spare parts
JP581037	FLAP-RUBBER-RH	Bajaj spare parts
JP581055	DUCT INTAKE	Bajaj spare parts
JP581059	FILTER ASSEMBLY AIR	Bajaj spare parts
JP581061	FILTER ASSEMBLY AIR	Bajaj spare parts
JP591010	PIPE ASSEMBLY A	Bajaj spare parts
JP591012	CLAMP	Bajaj spare parts
JP591013	CLAMP	Bajaj spare parts
JP591028	MUFFLER ASSEMBLY SECONDARY	Bajaj spare parts
JP591031	PIPE ASSEMBLY B	Bajaj spare parts
JP591033	GASKET MUFFLER SECONDARY	Bajaj spare parts
JP591040	PIPE ASSEMBLY A	Bajaj spare parts
JP591042	GASKET MUFFLER PRIMARY	Bajaj spare parts
JP591043	PROTECTOR MUFFLER INNER MIDDLE	Bajaj spare parts
JP591044	PROTECTOR MUFFLER INNER REAR	Bajaj spare parts
JP591045	PROTECTOR ASSEMBLY MUFFLER OUTER	Bajaj spare parts
JP591051	FLANGE EXHAUST	Bajaj spare parts
JP591065	SENSOR OXYGEN	Bajaj spare parts
JP591081	PROTECTOR ASSEMBLY MUFFLER	Bajaj spare parts
JP591082	PROTECTOR MUFFLER INNER FRONT	Bajaj spare parts
JP591085	SILENCER ASSEMBLY	Bajaj spare parts
JP591086	PIPE ASSEMBLY A	Bajaj spare parts
JP591094	PROTECTOR ASSEMBLY MUFFLER	Bajaj spare parts
JP591095	PROTECTOR MUFFLER INNER	Bajaj spare parts
JP591105	PROTECTOR ASSEMBLY MUFFLER OUTER	Bajaj spare parts
JP591106	GASKET EXHAUST	Bajaj spare parts
JP591109	PIPE ASSEMBLY A	Bajaj spare parts
JP591114	SENSOR OXYGEN	Bajaj spare parts
JP591117	SHIELD ASSEMBLY MUFFLER	Bajaj spare parts
JP591122	ASSEMBLY MUFFLER	Bajaj spare parts
JP591132	PIPE ASSEMBLY A	Bajaj spare parts
JP591214	PIPE ASSEMBLY A	Bajaj spare parts
JP591216	PIPE ASSEMBLY A	Bajaj spare parts
JP591293	PIPE ASSEMBLY A	Bajaj spare parts
JP591294	PIPE ASSEMBLY A	Bajaj spare parts
JP591301	PIPE ASSEMBLY A	Bajaj spare parts
JP591320	SHIELD ASSEMBLY MUFFLER	Bajaj spare parts
JP601202	RADIATOR	Bajaj spare parts



JP601204	ASSLY EXPANSION TANK	Bajaj spare parts
JP601205	TANK EXPANSION	Bajaj spare parts
JP601206	TUBE RADIATOR TO EXPANSION TANK	Bajaj spare parts
JP601209	RADIATOR	Bajaj spare parts
JP601210	HOSE COOLANT ENG-THERM	Bajaj spare parts
JP601211	HOSE COOLANT THERM-PIPE T	Bajaj spare parts
JP601212	HOSE COOLANT THERM-RAD	Bajaj spare parts
JP601214	HOSE ENG TO THERMOSTAT	Bajaj spare parts
JP601216	HOSE RADIATOR TO THERMOSTAT	Bajaj spare parts
JP601217	RUBBER DAMPER RADIATOR MOUNTING	Bajaj spare parts
JP601218	CLIP NUT M6 BLACK	Bajaj spare parts
JP601224	PIPE THERMOSTAT-CONNECTOR	Bajaj spare parts
JP601229	PIPE THERMOSTAT-JOINT T	Bajaj spare parts
JP601234	RADIATOR ASSEMBLY	Bajaj spare parts
JP601235	FAN RADIATOR	Bajaj spare parts
JP601238	RADIATOR	Bajaj spare parts
JP601240	FAN RADIATOR	Bajaj spare parts
JP601242	PIPE TANK EXPANSION-RADIATOR	Bajaj spare parts
JP601244	RADIATOR ASSEMBLY	Bajaj spare parts
JP601245	RADIATOR ASSEMBLY	Bajaj spare parts
JP601246	RADIATOR ASSEMBLY	Bajaj spare parts
JP601247	SHROUD	Bajaj spare parts
JP611000	ASSLY INJECTOR CAP WITH QC	Bajaj spare parts
JP611200	ASSLY INJECTOR CAP WITH QC	Bajaj spare parts
JP611201	ASSLY ETB DIA 46	Bajaj spare parts
JP611206	ASSLY INJECTOR CAP WITH QC KT21	Bajaj spare parts
JP611207	ASSLY THROTTLE BODY DIA.33	Bajaj spare parts
JP611208	ASSEMBLY THROTTLE BODY DIA.38	Bajaj spare parts
JP611209	ASSLY THROTTLE BODY DIA.38 KT21	Bajaj spare parts
JP611210	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JP611211	CABLE BRACKET	Bajaj spare parts
JP611212	NOZZLE EVAP	Bajaj spare parts
JP611213	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JP611217	BODY THROTTLE ASSLY-ELECTRONIC	Bajaj spare parts
JP611219	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JP611220	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JP611222	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JP611223	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JR111040	FRAME ASSEMBLY	Bajaj spare parts
JR113056	BRACKET SWITCH BRAKE	Bajaj spare parts
JR113063	PLATE HOLDER STEP RH	Bajaj spare parts
JR113064	BRACKET ASSEMBLY LH	Bajaj spare parts
JR113066	BRACKET ASSEMBLY RH	Bajaj spare parts
JR113069	DAMPER STEP	Bajaj spare parts
JR113075	SPACER	Bajaj spare parts

JR113091	PAD STEP	Bajaj spare parts
JR113108	PLATE HOLDER STEP RH	Bajaj spare parts
JR113109	FOOTREST SIDE	Bajaj spare parts
JR113126	SPRING COMPRESSION	Bajaj spare parts
JR113214	STAND ASSEMBLY MAIN	Bajaj spare parts
JR113215	STAND CENTER	Bajaj spare parts
JR113216	STAND SIDE	Bajaj spare parts
JR113220	BRACKET HOLDER MAGNET	Bajaj spare parts
JR113227	SPRING TENSION	Bajaj spare parts
JR113234	SLEEVE	Bajaj spare parts
JR113406	BRACKET HANGER ENGINE FRONT LH	Bajaj spare parts
JR113407	BRACKET HANGER ENGINE FRONT RH	Bajaj spare parts
JR113425	HANGER ASSEMBLY ENGINE LH	Bajaj spare parts
JR113426	HANGER ASSEMBLY ENGINE RH	Bajaj spare parts
JR113800	BRACKET UNIT ABS	Bajaj spare parts
JR113805	BRACKET SEAT REAR	Bajaj spare parts
JR113810	HANGER ENGINE LH	Bajaj spare parts
JR113811	HANGER ENGINE RH	Bajaj spare parts
JR113822	CASE BATTERY	Bajaj spare parts
JR113824	STRAP BATTERY	Bajaj spare parts
JR113825	HOLDER ECU	Bajaj spare parts
JR113826	STRAP BATTERY	Bajaj spare parts
JR113829	BRACKET LH	Bajaj spare parts
JR113830	BRACKET RH	Bajaj spare parts
JR113836	GROMMET	Bajaj spare parts
JR113840	HANGER ENGINE LH	Bajaj spare parts
JR113841	HANGER ENGINE RH	Bajaj spare parts
JR113844	STRAP BATTERY	Bajaj spare parts
JR113847	CASE ASSEMBLY BATTERY	Bajaj spare parts
JR113848	BRACKET ASSEMBLY LH	Bajaj spare parts
JR113849	BRACKET ASSEMBLY RH	Bajaj spare parts
JR113850	BRACKET MUFFLER LH	Bajaj spare parts
JR113851	BRACKET MUFFLER RH	Bajaj spare parts
JR113852	HOOK ASSEMBLY	Bajaj spare parts
JR113855	BRACKET ASSEMBLY COOLER OIL	Bajaj spare parts
JR113858	BRACKET SENSOR ROLL OVER	Bajaj spare parts
JR113859	CASE UNIT ABS	Bajaj spare parts
JR113865	BRACKET	Bajaj spare parts
JR113872	BRACKET COWL SEAT MIDDLE	Bajaj spare parts
JR113874	BUSH SILENT	Bajaj spare parts
JR113875	BRACKET LH	Bajaj spare parts
JR113876	BRACKET RH	Bajaj spare parts
JR113878	BEADING	Bajaj spare parts
JR113879	CLAMP	Bajaj spare parts
JR113880	BRACKET CAN UNIT TERMINATION	Bajaj spare parts

JR113890	BRACKET ASSEMBLY UNIT ABS	Bajaj spare parts
JR113892	CASE UNIT ABS	Bajaj spare parts
JR113893	CLAMP HOSE	Bajaj spare parts
JR113896	HOLDER HOSE	Bajaj spare parts
JR113900	HOLDER ECU	Bajaj spare parts
JR113906	BRACKET HANGER ENGINE RH	Bajaj spare parts
JR113907	HOLDER ECU	Bajaj spare parts
JR113908	CASE UNIT ABS	Bajaj spare parts
JR113924	DEFLECTOR LH	Bajaj spare parts
JR113925	DEFLECTOR RH	Bajaj spare parts
JR113926	COVER FILTER AIR	Bajaj spare parts
JR113939	BRACKET ASSEMBLY ECU	Bajaj spare parts
JR113941	BRACKET RESERVOIR	Bajaj spare parts
JR121005	FORK FRONT	Bajaj spare parts
JR121008	BRACKET ASSEMBLY UNDER	Bajaj spare parts
JR121017	FORK FRONT	Bajaj spare parts
JR121042	LEG ASSEMBLY LH	Bajaj spare parts
JR121043	LEG ASSEMBLY RH	Bajaj spare parts
JR121046	BRACKET ASSEMBLY UNDER	Bajaj spare parts
JR121068	TUBE	Bajaj spare parts
JR121069	TUBE	Bajaj spare parts
JR121077	CUSHION	Bajaj spare parts
JR121080	CUSHION	Bajaj spare parts
JR121084	FORK FRONT	Bajaj spare parts
JR121087	BRACKET ASSEMBLY UNDER	Bajaj spare parts
JR121092	RING	Bajaj spare parts
JR121105	PROTECTOR FORK LH	Bajaj spare parts
JR121106	PROTECTOR FORK RH	Bajaj spare parts
JR122004	ARM ASSEMBLY SWING	Bajaj spare parts
JR122008	ARM ASSEMBLY SWING	Bajaj spare parts
JR122010	SHOCKABSORBER	Bajaj spare parts
JR122040	BOLT FLANGED M14X1.5	Bajaj spare parts
JR122041	SPACER	Bajaj spare parts
JR122042	SPACER	Bajaj spare parts
JR122044	ADJUSTER CHAIN	Bajaj spare parts
JR122049	SLIDER CHAIN	Bajaj spare parts
JR122066	ADJUSTER CHAIN RH	Bajaj spare parts
JR122068	SLEEVE	Bajaj spare parts
JR122075	SLIDER CHAIN	Bajaj spare parts
JR122092	SLIDER CHAIN	Bajaj spare parts
JR122101	ARM ASSEMBLY SWING	Bajaj spare parts
JR122111	SPACER	Bajaj spare parts
JR122130	DAMPER	Bajaj spare parts
JR131013	DISC BRAKE DIA 280	Bajaj spare parts
JR131026	DISC BRAKE DIA 280	Bajaj spare parts

JR131041	DISC SENSOR SPEED	Bajaj spare parts
JR131058	DISC SENSOR SPEED	Bajaj spare parts
JR131062	COLLAR	Bajaj spare parts
JR131083	DISC SENSOR SPEED	Bajaj spare parts
JR131221	SCREW BUTTON HEAD-M5X0.8XL28XBLACK	Bajaj spare parts
JR131237	COUPLING	Bajaj spare parts
JR131238	SLEEVE	Bajaj spare parts
JR131245	COUPLING	Bajaj spare parts
JR131259	SPACER ASSEMBLY	Bajaj spare parts
JR131261	SPACER	Bajaj spare parts
JR131267	COLLAR	Bajaj spare parts
JR131801	DISC BRAKE DIA 260	Bajaj spare parts
JR131807	CALIPER ASSEMBLY FRONT	Bajaj spare parts
JR131809	UNIT ABS	Bajaj spare parts
JR131825	CALIPER ASSEMBLY FRONT	Bajaj spare parts
JR131827	PAD SET BRAKE FRONT	Bajaj spare parts
JR131829	CALIPER ASSEMBLY REAR	Bajaj spare parts
JR131830	CYLINDER MASTER REAR	Bajaj spare parts
JR131838	ROD BRAKE	Bajaj spare parts
JR131839	BRACKET SWITCH BRAKE	Bajaj spare parts
JR131851	CLAMP ASSEMBLY	Bajaj spare parts
JR131852	HOOK	Bajaj spare parts
JR131854	UNIT ABS WET	Bajaj spare parts
JR131868	CYLINDER ASSEMBLY MASTER FRONT	Bajaj spare parts
JR131877	CALIPER ASSEMBLY FRONT	Bajaj spare parts
JR131878	BRACKET ASSEMBLY	Bajaj spare parts
JR131882	CYLINDER ASSEMBLY MASTER FRONT	Bajaj spare parts
JR131883	CALIPER ASSEMBLY REAR	Bajaj spare parts
JR131896	UNIT ABS	Bajaj spare parts
JR131897	CYLINDER ASSEMBLY MASTER FRONT	Bajaj spare parts
JR131898	UNIT ABS WET	Bajaj spare parts
JR131910	STRAP	Bajaj spare parts
JR131913	CYLINDER MASTER REAR	Bajaj spare parts
JR131936	UNIT ABS WET	Bajaj spare parts
JR131938	UNIT ABS WET	Bajaj spare parts
JR151044	ASSEMBLY TUBE HANDLEBAR RH	Bajaj spare parts
JR151046	ASSEMBLY TUBE HANDLEBAR LH	Bajaj spare parts
JR161006	PEDAL BRAKE	Bajaj spare parts
JR161007	SHAFT ASSEMBLY BRAKE	Bajaj spare parts
JR161012	PEDAL ASSEMBLY BRAKE	Bajaj spare parts
JR161035	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JR161036	PEDAL ASSEMBLY BRAKE	Bajaj spare parts
JR161043	PEDAL ASSEMBLY BRAKE	Bajaj spare parts
JR161204	CABLE CLUTCH	Bajaj spare parts
JR161206	CABLE CLUTCH	Bajaj spare parts

JR161210	CABLE THROTTLE	Bajaj spare parts
JR161218	CABLE CLUTCH	Bajaj spare parts
JR161227	CABLE CLUTCH	Bajaj spare parts
JR161228	CABLE THROTTLE	Bajaj spare parts
JR171009	DAMPER TANK RESTING FRONT	Bajaj spare parts
JR171092	COVER TANK MIDDLE	Bajaj spare parts
JR171105	BUSH	Bajaj spare parts
JR171109	TAPE SEAT	Bajaj spare parts
JR171122	STRAP	Bajaj spare parts
JR171144	DAMPER TANK RH	Bajaj spare parts
JR171620	CANISTER	Bajaj spare parts
JR171621	VALVE PURGE	Bajaj spare parts
JR171803	PIPE FUEL	Bajaj spare parts
JR171804	PIPE CANISTER-CONNECTOR	Bajaj spare parts
JR171805	PIPE VALVE PURGE-BODY THROTTLE	Bajaj spare parts
JR171807	PIPE CONNECTOR-VALVE PURGE	Bajaj spare parts
JR171815	PIPE DRAIN	Bajaj spare parts
JR171816	PIPE DRAIN	Bajaj spare parts
JR171820	PLATE PRESSURE	Bajaj spare parts
JR171823	PIPE FUEL	Bajaj spare parts
JR181004	TRAY UNDER FRONT	Bajaj spare parts
JR181010	COWL SEAT MIDDLE	Bajaj spare parts
JR181013	BRACKET LAMP TAIL	Bajaj spare parts
JR181014	CLAMP	Bajaj spare parts
JR181015	GRILL FLAP TANK LH	Bajaj spare parts
JR181016	GRILL FLAP TANK RH	Bajaj spare parts
JR181017	GRILL COVER SIDE REAR LH	Bajaj spare parts
JR181018	GRILL COVER SIDE REAR RH	Bajaj spare parts
JR181024	STRAP	Bajaj spare parts
JR181025	GRILL FLAP TANK LH	Bajaj spare parts
JR181026	GRILL FLAP TANK RH	Bajaj spare parts
JR181030	TAPE	Bajaj spare parts
JR181036	PLUG COVER TANK LH	Bajaj spare parts
JR181037	PLUG COVER TANK RH	Bajaj spare parts
JR181234	BRACKET TOP	Bajaj spare parts
JR181239	COVER ASSEMBLY CHAIN	Bajaj spare parts
JR181240	FLAP SPEEDOMETER	Bajaj spare parts
JR181249	WINDSHIELD	Bajaj spare parts
JR181273	CARRIER MASK	Bajaj spare parts
JR181280	BELLY PAN TOP LH	Bajaj spare parts
JR181281	BELLY PAN TOP RH	Bajaj spare parts
JR181295	WINDSHIELD	Bajaj spare parts
JR181296	BELLY PAN LH	Bajaj spare parts
JR181297	BELLY PAN RH	Bajaj spare parts
JR181299	BELLY PAN MIDDLE	Bajaj spare parts

JR181307	BRACKET ASSEMBLY BELLY PAN FRONT	Bajaj spare parts
JR181309	BRACKET BELLY PAN REAR LH	Bajaj spare parts
JR181310	BRACKET BELLY PAN REAR RH	Bajaj spare parts
JR181334	BRACKET COVER SIDE LH	Bajaj spare parts
JR181335	BRACKET COVER SIDE RH	Bajaj spare parts
JR181336	FLAP SPEEDOMETER MIDDLE	Bajaj spare parts
JR181338	STRUCTURE LAMP HEAD REAR	Bajaj spare parts
JR181342	STRUCTURE LAMP HEAD FRONT	Bajaj spare parts
JR181349	BRACKET ASSEMBLY SPEEDOMETER	Bajaj spare parts
JR181356	FLAP SPEEDOMETER	Bajaj spare parts
JR181357	COVER FLAP SPEEDOMETER FRONT	Bajaj spare parts
JR181359	BRACKET UPPER LH	Bajaj spare parts
JR181360	BRACKET UPPER RH	Bajaj spare parts
JR181366	GROMMET	Bajaj spare parts
JR181369	FAIRING REAR LH	Bajaj spare parts
JR181371	FAIRING REAR RH	Bajaj spare parts
JR181375	PAD	Bajaj spare parts
JR181378	BRACKET MIDDLE LH	Bajaj spare parts
JR181379	BRACKET MIDDLE RH	Bajaj spare parts
JR181384	FLAP COVER TANK	Bajaj spare parts
JR181387	GROMMET	Bajaj spare parts
JR181397	DAMPER	Bajaj spare parts
JR181399	GROMMET	Bajaj spare parts
JR181407	FENDER REAR	Bajaj spare parts
JR181413	TRAY UNDER FRONT	Bajaj spare parts
JR181424	FENDER HUGGER ASSEMBLY	Bajaj spare parts
JR181425	ARRESTER CASE CHAIN	Bajaj spare parts
JR181431	FLAP FENDER FRONT	Bajaj spare parts
JR181438	FENDER FRONT BOTTOM	Bajaj spare parts
JR181439	FLAP FENDER FRONT	Bajaj spare parts
JR181441	REINFORCEMENT FENDER LH	Bajaj spare parts
JR181458	REINFORCEMENT FENDER RH	Bajaj spare parts
JR181461	BRACKET	Bajaj spare parts
JR181463	BRACE ASSEMBLY FENDER	Bajaj spare parts
JR181465	BRACE ASSEMBLY FENDER	Bajaj spare parts
JR181702	BRACKET BELLY PAN REAR LH	Bajaj spare parts
JR181703	BRACKET BELLY PAN REAR RH	Bajaj spare parts
JR181704	BRACKET ASSEMBLY BELLY PAN FRONT	Bajaj spare parts
JR181715	PIN QUICK RELEASE	Bajaj spare parts
JR181717	BEADING	Bajaj spare parts
JR181718	COVER SIDE INNER FRONT LH	Bajaj spare parts
JR181719	COVER SIDE INNER FRONT RH	Bajaj spare parts
JR181738	FLAP TANK MIDDLE	Bajaj spare parts
JR181758	BRACKET BELLY PAN LH	Bajaj spare parts
JR181759	BRACKET BELLY PAN REAR LH	Bajaj spare parts

JR181768	CAP	Bajaj spare parts
JR181769	STRUCTURE FAIRING	Bajaj spare parts
JR181772	GROMMET	Bajaj spare parts
JR181773	STRUCTURE SPEEDOMETER	Bajaj spare parts
JR181774	BRACKET FAIRING FRONT LH	Bajaj spare parts
JR181775	BRACKET FAIRING FRONT RH	Bajaj spare parts
JR181776	BRACKET FAIRING SIDE BOTTOM	Bajaj spare parts
JR181777	BRACKET FAIRING SIDE LH	Bajaj spare parts
JR181778	BRACKET FAIRING SIDE RH	Bajaj spare parts
JR181779	BRACKET FLAP COVER MIDDLE LH	Bajaj spare parts
JR181780	BRACKET FLAP COVER MIDDLE RH	Bajaj spare parts
JR181781	GROMMET	Bajaj spare parts
JR181783	COLLAR	Bajaj spare parts
JR181784	BEADING	Bajaj spare parts
JR181787	BRACKET CABLE SPEEDOMETER	Bajaj spare parts
JR181799	PACKING RH	Bajaj spare parts
JR181904	FAIRING REAR LH	Bajaj spare parts
JR181905	STRUCTURE FAIRING	Bajaj spare parts
JR181907	FAIRING REAR RH	Bajaj spare parts
JR181908	CARRIER MASK	Bajaj spare parts
JR181914	BEADING	Bajaj spare parts
JR181915	BEADING	Bajaj spare parts
JR181917	PACKING LH	Bajaj spare parts
JR181928	BRACKET FLAP SPEEDOMETER	Bajaj spare parts
JR181939	COVER ASSEMBLY MESH LH	Bajaj spare parts
JR181940	COVER ASSEMBLY MESH RH	Bajaj spare parts
JR181941	COVER ASSEMBLY CHAIN	Bajaj spare parts
JR181964	COVER CARRIER MASK	Bajaj spare parts
JR181965	TAPE	Bajaj spare parts
JR181966	CARRIER MASK ASSEMBLY	Bajaj spare parts
JR181971	TAPE COVER CARRIER MASK	Bajaj spare parts
JR183577	COVER ASSEMBLY CHAIN	Bajaj spare parts
JR183591	NUT CLIP M6X1	Bajaj spare parts
JR191011	SEAT ASSEMBLY	Bajaj spare parts
JR191014	SEAT ASSEMBLY FRONT	Bajaj spare parts
JR191017	SEAT ASSEMBLY REAR	Bajaj spare parts
JR191021	DAMPER	Bajaj spare parts
JR191025	SEAT ASSEMBLY FRONT	Bajaj spare parts
JR191028	SEAT ASSEMBLY REAR	Bajaj spare parts
JR231010	STRAP	Bajaj spare parts
JR231201	GUARD LEG RH	Bajaj spare parts
JR231202	GUARD LEG LH	Bajaj spare parts
JR231203	GUARD LEG RH	Bajaj spare parts
JR231204	GUARD SAREE	Bajaj spare parts
JR231216	GUARD SAREE	Bajaj spare parts

JR231600	MIRROR LH	Bajaj spare parts
JR231601	MIRROR RH	Bajaj spare parts
JR231602	MIRROR LH	Bajaj spare parts
JR231603	MIRROR RH	Bajaj spare parts
JR231605	HOLDER MIRROR	Bajaj spare parts
JR231612	MIRROR LH	Bajaj spare parts
JR231613	MIRROR RH	Bajaj spare parts
JR232605	SET LOCK	Bajaj spare parts
JR232607	LATCH ASSEMBLY SEAT	Bajaj spare parts
JR232611	BRACKET LOCK SEAT	Bajaj spare parts
JR232613	CABLE LATCH SEAT	Bajaj spare parts
JR232614	SET LOCK	Bajaj spare parts
JR232616	LATCH ASSEMBLY SEAT	Bajaj spare parts
JR232806	HOLDER INDICATOR	Bajaj spare parts
JR232808	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JR232809	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JR232817	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JR233020	DECAL FENDER M T GREY LH	Bajaj spare parts
JR233021	DECAL FENDER M T GREY RH	Bajaj spare parts
JR233022	DECAL FENDER M T GREY MIDDLE	Bajaj spare parts
JR233030	DECAL TANK FLAP LWR M T GREY LH	Bajaj spare parts
JR233031	DECAL TANK FLAP LWR M T GREY RH	Bajaj spare parts
JR233032	DECAL BELLY PAN M T GREY LH	Bajaj spare parts
JR233033	DECAL BELLY PAN M T GREY RH	Bajaj spare parts
JR233034	DECAL WHEEL M T GREY LH	Bajaj spare parts
JR233035	DECAL WHEEL M T GREY RH	Bajaj spare parts
JR233056	DECAL FENDER M V RED MIDDLE	Bajaj spare parts
JR233064	DECAL TANK FLAP LWR M V RED LH	Bajaj spare parts
JR233065	DECAL TANK FLAP LWR M V RED RH	Bajaj spare parts
JR233066	DECAL BELLY PAN M V RED LH	Bajaj spare parts
JR233067	DECAL BELLY PAN M V RED RH	Bajaj spare parts
JR233068	DECAL WHEEL M V RED LH	Bajaj spare parts
JR233069	DECAL WHEEL M V RED RH	Bajaj spare parts
JR233074	DECAL FENDER M YELLOW MIDDLE	Bajaj spare parts
JR233084	DECAL BELLY PAN M YELLOW LH	Bajaj spare parts
JR233085	DECAL BELLY PAN M YELLOW RH	Bajaj spare parts
JR233086	DECAL WHEEL M YELLOW LH	Bajaj spare parts
JR233087	DECAL WHEEL M YELLOW RH	Bajaj spare parts
JR233088	DECAL PULSAR	Bajaj spare parts
JR233099	DECAL SHROUD TANK M T GREY LH	Bajaj spare parts
JR233100	DECAL SHROUD TANK M T GREY RH	Bajaj spare parts
JR233111	DECAL SHROUD TANK M V RED LH	Bajaj spare parts
JR233112	DECAL SHROUD TANK M V RED RH	Bajaj spare parts
JR233123	DECAL SHROUD TANK M YELLOW LH	Bajaj spare parts
JR233124	DECAL SHROUD TANK M YELLOW RH	Bajaj spare parts



JR233240	DECAL COVER MAGNETO	Bajaj spare parts
JR233241	DECAL COVER CLUTCH	Bajaj spare parts
JR233275	DECAL FENDER C BLUE G MIDDLE	Bajaj spare parts
JR233285	DECAL BELLY PAN C BLUE GLOSSY LH	Bajaj spare parts
JR233286	DECAL BELLY PAN C BLUE GLOSSY RH	Bajaj spare parts
JR233287	DECAL WHEEL C BLUE GLOSSY LH	Bajaj spare parts
JR233288	DECAL WHEEL C BLUE GLOSSY RH	Bajaj spare parts
JR233303	DECAL SHROUD TANK C BLUE G LH	Bajaj spare parts
JR233304	DECAL SHROUD TANK C BLUE G RH	Bajaj spare parts
JR233306	DECAL PULSAR	Bajaj spare parts
JR233310	DECAL FLAP TANK LWR B BLACK G LH	Bajaj spare parts
JR233311	DECAL FLAP TANK LWR B BLACK G RH	Bajaj spare parts
JR233312	DECAL F250 B BLACK GLOSSY LH	Bajaj spare parts
JR233313	DECAL F250 B BLACK GLOSSY RH	Bajaj spare parts
JR233319	DECAL BELLY PAN B BLACK G LH	Bajaj spare parts
JR233320	DECAL BELLY PAN B BLACK G RH	Bajaj spare parts
JR233321	DECAL WHEEL B BLACK GLOSSY LH	Bajaj spare parts
JR233322	DECAL WHEEL B BLACK GLOSSY RH	Bajaj spare parts
JR233323	DECAL FAIRING FR UPR B BLK G LH	Bajaj spare parts
JR233324	DECAL FAIRING FR UPR B BLK G RH	Bajaj spare parts
JR233325	DECAL FAIRING FR LWR B BLK G LH	Bajaj spare parts
JR233326	DECAL FAIRING FR LWR B BLK G RH	Bajaj spare parts
JR233327	DECAL N250 B BLACK GLOSSY LH	Bajaj spare parts
JR233328	DECAL N250 B BLACK GLOSSY RH	Bajaj spare parts
JR233329	DECAL FAIRING FRONT B BLACK G LH	Bajaj spare parts
JR233330	DECAL FAIRING FRONT B BLACK G RH	Bajaj spare parts
JR233342	DECAL SHROUD TANK B BLACK G LH	Bajaj spare parts
JR233343	DECAL SHROUD TANK B BLACK G RH	Bajaj spare parts
JR233350	DECAL CARRIER MASK	Bajaj spare parts
JR233366	DECAL N160 B BLACK GLOSSY LH	Bajaj spare parts
JR233367	DECAL N160 B BLACK GLOSSY RH	Bajaj spare parts
JR233370	DECAL FENDER B BLACK G MIDDLE	Bajaj spare parts
JR233380	DECAL BELLY PAN B BLACK G LH	Bajaj spare parts
JR233381	DECAL BELLY PAN B BLACK G RH	Bajaj spare parts
JR233382	DECAL WHEEL B BLACK GLOSSY LH	Bajaj spare parts
JR233383	DECAL WHEEL B BLACK GLOSSY RH	Bajaj spare parts
JR233386	DECAL SHROUD TANK B BLACK G LH	Bajaj spare parts
JR233387	DECAL SHROUD TANK B BLACK G RH	Bajaj spare parts
JR233397	DECAL N160 B BLACK GLOSSY LH	Bajaj spare parts
JR233398	DECAL N160 B BLACK GLOSSY RH	Bajaj spare parts
JR233424	DECAL WHEEL G TECHNO BLACK LH	Bajaj spare parts
JR233425	DECAL WHEEL G TECHNO BLACK RH	Bajaj spare parts
JR233426	DECAL WHEEL RACING RED LH	Bajaj spare parts
JR233427	DECAL WHEEL RACING RED RH	Bajaj spare parts
JR233428	DECAL WHEEL SPORT YELLOW LH	Bajaj spare parts

JR233429	DECAL WHEEL SPORT YELLOW RH	Bajaj spare parts
JR233430	DECAL WHEEL C BLUE GLOSSY LH	Bajaj spare parts
JR233431	DECAL WHEEL C BLUE GLOSSY RH	Bajaj spare parts
JR233432	DECAL COVER MAGNETO	Bajaj spare parts
JR233446	DECAL ABS RH	Bajaj spare parts
JR233487	DECAL ABS LH	Bajaj spare parts
JR233496	DECAL COVER CLUTCH	Bajaj spare parts
JR233497	DECAL COVER SIDE OUTER LH	Bajaj spare parts
JR233498	DECAL COVER SIDE OUTER RH	Bajaj spare parts
JR233501	DECAL P150 RACING RUSH RED LH	Bajaj spare parts
JR233502	DECAL P150 RACING RUSH RED RH	Bajaj spare parts
JR233513	DECAL BELLY PAN RACING RED LH	Bajaj spare parts
JR233514	DECAL BELLY PAN RACING RED RH	Bajaj spare parts
JR233515	DECAL WHEEL RACING RUSH RED LH	Bajaj spare parts
JR233516	DECAL WHEEL RACING RUSH RED RH	Bajaj spare parts
JR233521	DECAL P150 CARIBBEAN I BLUE LH	Bajaj spare parts
JR233522	DECAL P150 CARIBBEAN I BLUE RH	Bajaj spare parts
JR233533	DECAL BELLY PAN C INDIGO BLUE LH	Bajaj spare parts
JR233534	DECAL BELLY PAN C INDIGO BLUE RH	Bajaj spare parts
JR233535	DECAL WHEEL C INDIGO BLUE LH	Bajaj spare parts
JR233536	DECAL WHEEL C INDIGO BLUE RH	Bajaj spare parts
JR233541	DECAL P150 E CHARCOAL BLACK LH	Bajaj spare parts
JR233542	DECAL P150 E CHARCOAL BLACK RH	Bajaj spare parts
JR233557	DECAL BELLY PAN EBONY C BLACK LH	Bajaj spare parts
JR233558	DECAL BELLY PAN EBONY C BLACK RH	Bajaj spare parts
JR233569	DECAL P150 E BLK C WHITE LH	Bajaj spare parts
JR233570	DECAL P150 E BLK C WHITE RH	Bajaj spare parts
JR233573	DECAL BELLY PAN E BLK C WHITE LH	Bajaj spare parts
JR233574	DECAL BELLY PAN E BLK C WHITE RH	Bajaj spare parts
JR233575	DECAL WHEEL E BLK C WHITE LH	Bajaj spare parts
JR233576	DECAL WHEEL E BLK C WHITE RH	Bajaj spare parts
JR233579	DECAL P150 E BLK C BLUE LH	Bajaj spare parts
JR233580	DECAL P150 E BLK C BLUE RH	Bajaj spare parts
JR233585	DECAL BELLY PAN E BLK C BLUE LH	Bajaj spare parts
JR233586	DECAL BELLY PAN E BLK C BLUE RH	Bajaj spare parts
JR233587	DECAL WHEEL E BLK C BLUE LH	Bajaj spare parts
JR233588	DECAL WHEEL E BLK C BLUE RH	Bajaj spare parts
JR233622	DECAL WHEEL RACING RUSH RED LH	Bajaj spare parts
JR233623	DECAL WHEEL RACING RUSH RED RH	Bajaj spare parts
JR233624	DECAL WHEEL C INDIGO BLUE LH	Bajaj spare parts
JR233625	DECAL WHEEL C INDIGO BLUE RH	Bajaj spare parts
JR233626	DECAL WHEEL E BLK C WHITE LH	Bajaj spare parts
JR233627	DECAL WHEEL E BLK C WHITE RH	Bajaj spare parts
JR233628	DECAL WHEEL E BLK C BLUE LH	Bajaj spare parts
JR233629	DECAL WHEEL E BLK C BLUE RH	Bajaj spare parts

JR351433	ECU EMS	Bajaj spare parts
JR401008	LAMP TAIL	Bajaj spare parts
JR401010	INDICATOR FRONT RH	Bajaj spare parts
JR401011	INDICATOR FRONT LH	Bajaj spare parts
JR401012	INDICATOR REAR RH	Bajaj spare parts
JR401013	INDICATOR REAR LH	Bajaj spare parts
JR401017	LAMP HEAD	Bajaj spare parts
JR401018	LAMP HEAD	Bajaj spare parts
JR401019	LAMP PLATE NUMBER	Bajaj spare parts
JR401020	LAMP POSITION	Bajaj spare parts
JR401026	INDICATOR REAR LH	Bajaj spare parts
JR401027	INDICATOR REAR RH	Bajaj spare parts
JR401028	INDICATOR FRONT LH	Bajaj spare parts
JR401030	CABLE INDICATOR FRONT LH	Bajaj spare parts
JR401031	CABLE INDICATOR FRONT RH	Bajaj spare parts
JR401032	LAMP DRL	Bajaj spare parts
JR401033	LAMP HEAD	Bajaj spare parts
JR401035	LAMP HEAD	Bajaj spare parts
JR401400	SWITCH CONTROL LH	Bajaj spare parts
JR401401	SWITCH CONTROL RH	Bajaj spare parts
JR401410	SWITCH CONTROL LH	Bajaj spare parts
JR401411	SWITCH CONTROL RH	Bajaj spare parts
JR401420	SWITCH CONTROL LH	Bajaj spare parts
JR401422	SWITCH CONTROL RH	Bajaj spare parts
JR401426	SWITCH CONTROL RH	Bajaj spare parts
JR401428	SWITCH CONTROL RH	Bajaj spare parts
JR401430	SWITCH CONTROL RH	Bajaj spare parts
JR401602	HORN	Bajaj spare parts
JR401605	HORN	Bajaj spare parts
JR402008	UNIT REGULATOR	Bajaj spare parts
JR402207	HARNESS MAIN WIRING K17	Bajaj spare parts
JR402209	HARNESS WIRING	Bajaj spare parts
JR402210	CABLE STARTER RELAY-MOTOR	Bajaj spare parts
JR402212	HARNESS WIRING	Bajaj spare parts
JR402213	CABLE EARTH	Bajaj spare parts
JR402219	CABLE RELAY-MOTOR STARTER	Bajaj spare parts
JR402220	CABLE EARTH	Bajaj spare parts
JR402227	HARNESS WIRING	Bajaj spare parts
JR402230	CABLE SPEEDOMETER	Bajaj spare parts
JR402247	HARNESS WIRING	Bajaj spare parts
JR402249	HARNESS WIRING	Bajaj spare parts
JR402262	HARNESS WIRING	Bajaj spare parts
JR402267	HARNESS WIRING	Bajaj spare parts
JR402269	HARNESS WIRING	Bajaj spare parts
JR402270	HARNESS WIRING	Bajaj spare parts

JR402411	SPEEDOMETER	Bajaj spare parts
JR402432	INSTRUMENT CLUSTER	Bajaj spare parts
JR402600	GAUGE FUEL LEVEL K17A	Bajaj spare parts
JR403200	UNIT TERMINATION	Bajaj spare parts
JR403401	SOCKET CHARGER	Bajaj spare parts
JR403608	SENSOR SPEED WHEEL	Bajaj spare parts
JR561202	LEVER ASSEMBLY CHANGE	Bajaj spare parts
JR561402	LEVER ASSEMBLY CHANGE	Bajaj spare parts
JR561404	ARM ASSEMBLY CHANGE	Bajaj spare parts
JR561408	ARM ASSEMBLY CHANGE	Bajaj spare parts
JR561410	ARM ASSEMBLY CHANGE	Bajaj spare parts
JR561412	LEVER ASSEMBLY CHANGE	Bajaj spare parts
JS113801	BUSH LPR VANAZ	Bajaj spare parts
JS113802	WASHER LPR VANAZ	Bajaj spare parts
JS172014	FLANGE SCREW	Bajaj spare parts
JS172015	DIAPHRAGM SUB ASSLY.	Bajaj spare parts
JS172018	Plug	Bajaj spare parts
JS172019	FLANGE SCREW	Bajaj spare parts
JS172020	SCREW IDLE	Bajaj spare parts
JS172023	DIAPHRAGM	Bajaj spare parts
JS172026	BREATHER -I	Bajaj spare parts
JS172027	SPRING	Bajaj spare parts
JS172028	CONNECTER INLET	Bajaj spare parts
JS172030	SCREW FLOW CONTROL	Bajaj spare parts
JS172031	BREATHER II	Bajaj spare parts
JS172032	BODY FLOW CONTROL	Bajaj spare parts
JS172033	Clamp	Bajaj spare parts
JS172035	GUIDE SPRING	Bajaj spare parts
JS172036	LEVER REGULATOR LPG	Bajaj spare parts
JS172037	SEAT	Bajaj spare parts
JS581223	HOSE REG. TO MIXER	Bajaj spare parts
JT231602	MIRROR LH CPL. W. FLASHER	Bajaj spare parts
JU111017	BRACKET HORN	Bajaj spare parts
JU111100	FRAME ASSLY KT01 AND KT02	Bajaj spare parts
JU113019	HOLDER STEP RIDER RH	Bajaj spare parts
JU113021	HOLDER STEP PILLION RH	Bajaj spare parts
JU113023	HOLDER STEP RIDER LH	Bajaj spare parts
JU113025	HOLDER STEP PILLION LH	Bajaj spare parts
JU113026	HOLDER STEP RIDER LH	Bajaj spare parts
JU113027	HOLDER STEP RIDER RH	Bajaj spare parts
JU113028	HOLDER STEP PILLION LH	Bajaj spare parts
JU113029	HOLDER STEP PILLION RH	Bajaj spare parts
JU113030	STAY MUFFLER	Bajaj spare parts
JU113037	PIN	Bajaj spare parts
JU113044	PLATE LOCK UPPER	Bajaj spare parts

JU113045	PLATE LOCK LOWER	Bajaj spare parts
JU113047	HOLDER STEP PILLION LH	Bajaj spare parts
JU113048	HOLDER STEP PILLION RH	Bajaj spare parts
JU113049	HOLDER STEP PILLION LH	Bajaj spare parts
JU113050	HOLDER STEP PILLION RH	Bajaj spare parts
JU113200	SPRING SIDE STAND WITH COVER	Bajaj spare parts
JU113801	GROMMET RAD COWL	Bajaj spare parts
JU113804	BRACKET PURGE VALVE	Bajaj spare parts
JU113809	BRACKET -RADIATOR-LH	Bajaj spare parts
JU113810	BRACKET -RADIATOR-RH	Bajaj spare parts
JU113812	BRACKET -ABS MOUNTING	Bajaj spare parts
JU113813	BRACKET SPIDER-LH	Bajaj spare parts
JU113814	BRACKET SPIDER-RH	Bajaj spare parts
JU113816	BUSH	Bajaj spare parts
JU113818	BRACKET TANK REAR MIDDLE	Bajaj spare parts
JU113820	BASE BATTERY	Bajaj spare parts
JU113822	BRACKET MOUNT UNIT ELECTRICAL	Bajaj spare parts
JU113834	SPACER	Bajaj spare parts
JU113842	BRACKET COVER SIDE LH	Bajaj spare parts
JU113843	BRACKET COVER SIDE RH	Bajaj spare parts
JU113845	BRACKET COUPLER	Bajaj spare parts
JU113848	PLATE CLAMP HOSE BRAKE	Bajaj spare parts
JU121002	LEG ASSLY. LH	Bajaj spare parts
JU121003	LEG ASSLY. RH	Bajaj spare parts
JU121007	TUBE INNER ASSY RH	Bajaj spare parts
JU121009	CIRCLIP	Bajaj spare parts
JU121017	MAIN SPRING & WASHER	Bajaj spare parts
JU121018	CAP SCREW ASSLY	Bajaj spare parts
JU121019	PISTON ROD ASSLY	Bajaj spare parts
JU121025	FORK FRONT	Bajaj spare parts
JU121037	ASSLY OUTER TUBE	Bajaj spare parts
JU121048	FORK ASSEMBLY FRONT	Bajaj spare parts
JU121050	ASSEMBLY LEG LH	Bajaj spare parts
JU121051	ASSEMBLY LEG RH	Bajaj spare parts
JU121052	PIPE ASSLY FORK LH	Bajaj spare parts
JU121054	ASSLY CLAMP TRIPLE LOWER	Bajaj spare parts
JU121058	BRACKET ASSEMBLY UNDER	Bajaj spare parts
JU121060	BRACKET UPPER	Bajaj spare parts
JU121071	HOLDER HANDLE UPPER	Bajaj spare parts
JU121076	FORK FRONT	Bajaj spare parts
JU121077	BRACKET ASSEMBLY UNDER	Bajaj spare parts
JU121079	LEG ASSEMBLY LH	Bajaj spare parts
JU121080	LEG ASSEMBLY RH	Bajaj spare parts
JU121086	FORK FRONT	Bajaj spare parts
JU121087	LEG ASSEMBLY LH	Bajaj spare parts

JU121088	LEG ASSEMBLY RH	Bajaj spare parts
JU121091	LEG ASSEMBLY LH	Bajaj spare parts
JU121092	LEG ASSEMBLY RH	Bajaj spare parts
JU121118	FORK FRONT	Bajaj spare parts
JU121123	FORK FRONT	Bajaj spare parts
JU122009	SHOCKABSORBER WITH DUST COVER	Bajaj spare parts
JU122022	CUP	Bajaj spare parts
JU122023	SHOCKABSORBER REAR	Bajaj spare parts
JU122025	SHOCKABSORBER REAR	Bajaj spare parts
JU122026	INSERT	Bajaj spare parts
JU122027	SHOCKABSORBER REAR	Bajaj spare parts
JU122035	ARM SWING	Bajaj spare parts
JU122041	SHOCKABSORBER REAR	Bajaj spare parts
JU131004	SPACER FOR CALIPER	Bajaj spare parts
JU131027	SPOKE-FRONT	Bajaj spare parts
JU131028	NIPPLE-SPOKE	Bajaj spare parts
JU131029	COLLAR-WHEEL-FRONT	Bajaj spare parts
JU131205	LABEL INSTRUCTION	Bajaj spare parts
JU131206	COUPLING ASSEMBLY	Bajaj spare parts
JU131216	COUPLING ASSLY 6 LUG_MY14	Bajaj spare parts
JU131222	DAMPER COUPLING	Bajaj spare parts
JU131223	COUPLING ASSLY_DUKE_200_MY15	Bajaj spare parts
JU131235	SPOKE-REAR 1	Bajaj spare parts
JU131236	SPOKE-REAR 2	Bajaj spare parts
JU131239	SPACER-WHEEL-REAR	Bajaj spare parts
JU131241	COLLAR-BEARING	Bajaj spare parts
JU131242	CARRIER SPROCKET REAR	Bajaj spare parts
JU131253	COUPLING ASSEMBLY	Bajaj spare parts
JU131258	TYRE 150/60 R17	Bajaj spare parts
JU131260	SPACER ASSEMBLY	Bajaj spare parts
JU131801	SENSOR DISC FRONT	Bajaj spare parts
JU131802	SENSOR DISC REAR	Bajaj spare parts
JU131807	BRAKE HOSE FR ABS TO CALIPER	Bajaj spare parts
JU131808	BRAKE HOSE RR ABS TO CALIPER	Bajaj spare parts
JU131809	BRAKE HOSE ABS TO MASTER CY.FR	Bajaj spare parts
JU131810	BRAKE HOSE ABS TO MASTER CY.RR	Bajaj spare parts
JU131815	KIT MAJOR FRONT	Bajaj spare parts
JU131816	KIT MINOR FRONT	Bajaj spare parts
JU131840	SENSOR-ABS-DIS-REAR	Bajaj spare parts
JU131852	HOLDER HOSE BRAKE	Bajaj spare parts
JU131853	CLAMP SEPERATOR	Bajaj spare parts
JU131854	CLAMP SEPERATOR	Bajaj spare parts
JU131856	CYLINDER MASTER FRONT	Bajaj spare parts
JU131861	CYLINDER MASTER REAR	Bajaj spare parts
JU131865	BRACKET CLAMP HOSE	Bajaj spare parts

JU131870	UNIT ABS WET	Bajaj spare parts
JU131875	DISC BRAKE DIA 320	Bajaj spare parts
JU141001	CHAIN 110 LINK	Bajaj spare parts
JU141002	SPROCKET 42 TEETH	Bajaj spare parts
JU141006	CHAIN 520 X RING 110 LINK	Bajaj spare parts
JU141007	SPROCKET 42 T 6 LUG	Bajaj spare parts
JU141008	SPROCKET 42T SPOT FACING	Bajaj spare parts
JU151011	GRIP LH	Bajaj spare parts
JU151013	CLAMP TRIPPLE UPPER	Bajaj spare parts
JU151015	CLAMP TRIPPLE LOWER	Bajaj spare parts
JU151019	HOLDER HANDLE BOTTOM	Bajaj spare parts
JU151020	HANDLEBAR	Bajaj spare parts
JU151021	ROD HANDLEBAR	Bajaj spare parts
JU151023	WEIGHT HANDLEBAR	Bajaj spare parts
JU151026	HANDLEBAR	Bajaj spare parts
JU151032	PIPE THROTTLE	Bajaj spare parts
JU151033	GRIP ASSEMBLY RH	Bajaj spare parts
JU161002	RETURN SPRING BRAKE PEDAL	Bajaj spare parts
JU161005	PIN BRAKE LEVER	Bajaj spare parts
JU161006	ASSLY BRAKE LEVER	Bajaj spare parts
JU161007	ASSLY CHANGE LEVER	Bajaj spare parts
JU161010	PEDAL ASSEMBLY BRAKE	Bajaj spare parts
JU161019	HOLDER HOSE BRAKE	Bajaj spare parts
JU161021	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JU161022	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JU161026	PEDAL ASSEMBLY BRAKE	Bajaj spare parts
JU161200	BOLT M6 X 10 PRECOATED	Bajaj spare parts
JU161201	CABLE CLUTCH	Bajaj spare parts
JU161203	CABLE CLUTCH	Bajaj spare parts
JU161206	CABLE LOCK SEAT	Bajaj spare parts
JU161214	CABLE CLUTCH	Bajaj spare parts
JU161215	CABLE CLUTCH	Bajaj spare parts
JU171001	GASKET F. FUEL PUMP	Bajaj spare parts
JU171010	FUEL TANK EVAP HDPE	Bajaj spare parts
JU171026	INSERT	Bajaj spare parts
JU171038	PLATE PUMP FUEL	Bajaj spare parts
JU171039	COVER SIDE RH	Bajaj spare parts
JU171040	COVER SIDE LH	Bajaj spare parts
JU171041	COVER TOP	Bajaj spare parts
JU171043	RACK TANK	Bajaj spare parts
JU171048	CONNECTOR QUICK	Bajaj spare parts
JU171049	PLATE PUMP FUEL	Bajaj spare parts
JU171050	CLAMP EAR	Bajaj spare parts
JU171051	GROMMET	Bajaj spare parts
JU171054	TANK ASSEMBLY FUEL	Bajaj spare parts

JU171078	PIPE FILTER FUEL-INJECTOR	Bajaj spare parts
JU171603	TUBE CANISTER TO CONNECTOR	Bajaj spare parts
JU171604	TUBE CONNECTOR TO PURGE VALVE	Bajaj spare parts
JU171605	TUBE PURGEVALVE TO THROTTLE BODY	Bajaj spare parts
JU171606	VALVE PURGE	Bajaj spare parts
JU171609	CANISTER	Bajaj spare parts
JU171610	DAMPER CANISTER	Bajaj spare parts
JU171611	CAP CANISTER	Bajaj spare parts
JU171612	PIPE VALVE PURGE-BODY THROTTLE	Bajaj spare parts
JU171617	PIPE VALVE PURGE-BODY THROTTLE	Bajaj spare parts
JU171803	PUMP -FUEL-MODULE	Bajaj spare parts
JU171807	TUBE FUEL PUMP TO FUEL FILTER	Bajaj spare parts
JU171808	TUBE FUEL FILTER TO REGULATOR	Bajaj spare parts
JU171809	TUBE FUEL FILTER TO INJECTOR	Bajaj spare parts
JU171817	PIPE DRAIN	Bajaj spare parts
JU171818	PIPE TANK EXPANSION-CONNECTOR	Bajaj spare parts
JU171819	PIPE CONNECTOR	Bajaj spare parts
JU171820	PIPE TANK-CONNECTOR	Bajaj spare parts
JU171821	PIPE CANISTER-CONNECTOR	Bajaj spare parts
JU171822	PIPE DRAIN	Bajaj spare parts
JU171823	PIPE CANISTER-VALVE PURGE	Bajaj spare parts
JU181000	TUBE REAR HUGGER MOUNTING	Bajaj spare parts
JU181004	TRAY UNDER	Bajaj spare parts
JU181005	COWL SEAT LH	Bajaj spare parts
JU181006	COWL SEAT RH	Bajaj spare parts
JU181007	HOLDER FENDER REAR	Bajaj spare parts
JU181008	BRACE FENDER REAR	Bajaj spare parts
JU181009	CAP	Bajaj spare parts
JU181014	CAP	Bajaj spare parts
JU181015	PAD	Bajaj spare parts
JU181200	RADIATOR PROTECTOR L/S	Bajaj spare parts
JU181201	RADIATOR PROTECTOR R/S	Bajaj spare parts
JU181217	COVER CHAIN INNER	Bajaj spare parts
JU181218	COVER CHAIN OUTER	Bajaj spare parts
JU181219	GUARD SPLASH	Bajaj spare parts
JU181224	BUSH COVER-TANK-MIDDLE	Bajaj spare parts
JU181225	GROMMET IGNITION LOCK	Bajaj spare parts
JU181228	GROMMET-SEAT COWL	Bajaj spare parts
JU181234	BUSH IGNITION COIL COVER	Bajaj spare parts
JU181242	COVER SENSOR ROLL OVER	Bajaj spare parts
JU181243	HOLDER LAMP HEAD FRONT	Bajaj spare parts
JU181244	HOLDER LAMP HEAD REAR	Bajaj spare parts
JU181245	COVER COIL IGNITION	Bajaj spare parts
JU181246	COVER SENSOR OXYGEN	Bajaj spare parts
JU181248	HOLDER SPEEDOMETER	Bajaj spare parts



JU181251	COVER ABS	Bajaj spare parts
JU181255	BRACKET BELLY PAN FRONT	Bajaj spare parts
JU181256	COLLAR	Bajaj spare parts
JU181259	BELLY PAN ASSEMBLY	Bajaj spare parts
JU181267	COLLAR	Bajaj spare parts
JU181269	SPACER	Bajaj spare parts
JU181270	GROMMET	Bajaj spare parts
JU181275	PROTECTOR SHOCKABSORBER	Bajaj spare parts
JU181277	PROTECTOR HARNESS	Bajaj spare parts
JU181278	GROMMET	Bajaj spare parts
JU181280	COVER BATTERY	Bajaj spare parts
JU181281	CLAMP	Bajaj spare parts
JU181291	COVER RADIATOR LH	Bajaj spare parts
JU181292	COVER RADIATOR RH	Bajaj spare parts
JU181298	COVER RADIATOR LH	Bajaj spare parts
JU181299	COVER RADIATOR RH	Bajaj spare parts
JU181339	BELLY PAN ASSEMBLY	Bajaj spare parts
JU181340	BRACKET BELLY PAN	Bajaj spare parts
JU181342	CAP	Bajaj spare parts
JU181343	HOLDER LAMP HEAD FRONT	Bajaj spare parts
JU181347	HOLDER LAMP HEAD REAR	Bajaj spare parts
JU181348	GUIDE CABLE	Bajaj spare parts
JU181408	GROMMET REAR NO PLATE	Bajaj spare parts
JU181409	PLATE REAR NUMBER	Bajaj spare parts
JU181410	BRACKET REAR NUMBER PLATE	Bajaj spare parts
JU181411	SLEEVE REAR NUMBER PLATE	Bajaj spare parts
JU181412	DUEL LOCK REAR NO PLATE	Bajaj spare parts
JU181415	MUDFLAP FRONT FENDER	Bajaj spare parts
JU181431	FENDER FRONT	Bajaj spare parts
JU181432	BRACE FENDER FRONT LH	Bajaj spare parts
JU181433	BRACE FENDER FRONT RH	Bajaj spare parts
JU181434	FENDER REAR	Bajaj spare parts
JU181435	COVER INDICATOR	Bajaj spare parts
JU181437	COLLAR	Bajaj spare parts
JU181440	FLAP FENDER FRONT	Bajaj spare parts
JU181441	PANEL PLATE NUMBER	Bajaj spare parts
JU181442	STRUCTURE INDICATOR LH	Bajaj spare parts
JU181443	STRUCTURE INDICATOR RH	Bajaj spare parts
JU181445	COVER STRUCTURE INDICATOR LH	Bajaj spare parts
JU181446	COVER STRUCTURE INDICATOR RH	Bajaj spare parts
JU181455	FENDER HUGGER	Bajaj spare parts
JU191000	SEAT ASSLY REAR	Bajaj spare parts
JU191001	SEAT ASSLY FRONT	Bajaj spare parts
JU191018	SEAT ASSEMBLY RIDER	Bajaj spare parts
JU191022	SEAT ASSEMBLY PILLION	Bajaj spare parts

JU191029	SEAT ASSEMBLY RIDER	Bajaj spare parts
JU191030	BRACKET SEAT PILLION	Bajaj spare parts
JU191031	COVER LH	Bajaj spare parts
JU191032	COVER RH	Bajaj spare parts
JU191034	SEAT ASSEMBLY	Bajaj spare parts
JU231009	TOOLKIT	Bajaj spare parts
JU231200	LEG GUARD LH	Bajaj spare parts
JU231201	LEG GUARD RH	Bajaj spare parts
JU231203	BOLT LEG GUARD	Bajaj spare parts
JU231204	SAREE GUARD	Bajaj spare parts
JU231205	NUT LEG GUARD	Bajaj spare parts
JU231206	BOLT M8 PRECOATED	Bajaj spare parts
JU231207	NUT NYLOC M8X1.25	Bajaj spare parts
JU231210	GUARD SAREE UPPER	Bajaj spare parts
JU231212	GUARD LEG RH	Bajaj spare parts
JU231214	GUARD SAREE LOWER	Bajaj spare parts
JU231216	PAD GUARD SAREE	Bajaj spare parts
JU231404	GRAB HANDLE	Bajaj spare parts
JU231603	MIRROR RH	Bajaj spare parts
JU231604	MIRROR LH	Bajaj spare parts
JU232602	SET KEY	Bajaj spare parts
JU232606	SET LOCK	Bajaj spare parts
JU232609	LATCH ASSEMBLY SEAT	Bajaj spare parts
JU232800	NUMBER PLATE FRONT	Bajaj spare parts
JU232805	BRACKET FRONT NUMBER PLATE MTG	Bajaj spare parts
JU232814	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JU232817	GROMMET	Bajaj spare parts
JU232820	BRACKET REFLECTOR REFLEX REAR	Bajaj spare parts
JU232823	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JU233001	DECAL SET TANK COVER LH & RH	Bajaj spare parts
JU233023	DECAL SET DUKE _200	Bajaj spare parts
JU233027	DECAL SET TANK WHITE_MY1	Bajaj spare parts
JU233032	DECAL SET TANK COVER	Bajaj spare parts
JU233066	DECAL TANK LOGO	Bajaj spare parts
JU233067	DECAL COWL SEAT LH	Bajaj spare parts
JU233068	DECAL COWL SEAT RH	Bajaj spare parts
JU233070	DECAL COVER TANK LH BLACK	Bajaj spare parts
JU233071	DECAL COVER TANK RH BLACK	Bajaj spare parts
JU233072	DECAL MASK LH BLACK	Bajaj spare parts
JU233073	DECAL MASK RH BLACK	Bajaj spare parts
JU233074	DECAL BELLY PAN LH BLACK	Bajaj spare parts
JU233075	DECAL BELLY PAN RH BLACK	Bajaj spare parts
JU233077	DECAL COVER TANK LH ORANGE	Bajaj spare parts
JU233078	DECAL COVER TANK RH ORANGE	Bajaj spare parts
JU233079	DECAL MASK LH ORANGE	Bajaj spare parts

JU233080	DECAL MASK RH ORANGE	Bajaj spare parts
JU233081	DECAL BELLY PAN LH ORANGE	Bajaj spare parts
JU233082	DECAL BELLY PAN RH ORANGE	Bajaj spare parts
JU233084	DECAL COVER TANK LH WHITE	Bajaj spare parts
JU233085	DECAL COVER TANK RH WHITE	Bajaj spare parts
JU233086	DECAL MASK LH WHITE	Bajaj spare parts
JU233087	DECAL MASK RH WHITE	Bajaj spare parts
JU233088	DECAL BELLY PAN LH WHITE	Bajaj spare parts
JU233089	DECAL BELLY PAN RH WHITE	Bajaj spare parts
JU233102	DECAL TANK LOGO BLACK	Bajaj spare parts
JU233120	EMBLEM HUSQVARNA	Bajaj spare parts
JU233123	DECAL SVARTPILEN LH	Bajaj spare parts
JU233124	DECAL SVARTPILEN RH	Bajaj spare parts
JU233132	DECAL COVER SIDE FRONT LH	Bajaj spare parts
JU233133	DECAL COVER SIDE FRONT RH	Bajaj spare parts
JU233137	DECAL COWL SEAT LH	Bajaj spare parts
JU233138	DECAL COWL SEAT RH	Bajaj spare parts
JU233147	DECAL COVER SIDE LH	Bajaj spare parts
JU233148	DECAL COVER SIDE RH	Bajaj spare parts
JU233149	DECAL VITPILEN LH	Bajaj spare parts
JU233150	DECAL VITPILEN RH	Bajaj spare parts
JU233151	EMBLEM HUSQVARNA	Bajaj spare parts
JU233156	DECAL COWL SEAT LH	Bajaj spare parts
JU233157	DECAL COWL SEAT RH	Bajaj spare parts
JU233172	DECAL 3D	Bajaj spare parts
JU351001	STATOR ASSLY	Bajaj spare parts
JU351003	STATOR ASSEMBLY	Bajaj spare parts
JU351004	ROTOR ASSEMBLY	Bajaj spare parts
JU351439	COVER ECU	Bajaj spare parts
JU351600	MOTOR STARTER	Bajaj spare parts
JU401000	LAMP SIGNAL FRONT LH DUKE190	Bajaj spare parts
JU401004	HEAD LAMP CONTROL UNIT-NON ABS	Bajaj spare parts
JU401006	LAMP TAIL	Bajaj spare parts
JU401015	STRUCTURE LAMP HEAD	Bajaj spare parts
JU401016	INDICATOR LH	Bajaj spare parts
JU401017	INDICATOR RH	Bajaj spare parts
JU401024	REFLECTOR REFLEX	Bajaj spare parts
JU401025	LAMP HEAD	Bajaj spare parts
JU401028	LAMP PLATE NUMBER	Bajaj spare parts
JU401400	SWITCH CONTROL RH DOMESTIC	Bajaj spare parts
JU401404	SWITCH CONTROL LH	Bajaj spare parts
JU401405	SWITCH CONTROL LH	Bajaj spare parts
JU401407	SWITCH BRAKE	Bajaj spare parts
JU401409	SWITCH CONTROL RH	Bajaj spare parts
JU401410	SWITCH CONTROL RH	Bajaj spare parts

JU401411	SWITCH CONTROL RH	Bajaj spare parts
JU401412	SWITCH CLUTCH	Bajaj spare parts
JU401602	HORN	Bajaj spare parts
JU401603	HORN	Bajaj spare parts
JU401803	8AH VRLA BATTERY WITHOUT ACID BOTTLE	Bajaj spare parts
JU402001	REGULATOR	Bajaj spare parts
JU402201	CABLE ASSY EARTH 1	Bajaj spare parts
JU402202	WIRING HARNESS DOMESTIC	Bajaj spare parts
JU402223	HARNESS DUKE 200 MY14	Bajaj spare parts
JU402226	HARNESS DUKE 200 DOMESTIC	Bajaj spare parts
JU402227	HARNESS DUKE 200 ARGENTINA	Bajaj spare parts
JU402229	HARNESS DUKE 200 CHINA NON ABS	Bajaj spare parts
JU402239	HARNESS WIRING	Bajaj spare parts
JU402253	HARNESS WIRING	Bajaj spare parts
JU402255	HARNESS WIRING	Bajaj spare parts
JU402263	CABLE HARNESS	Bajaj spare parts
JU402268	CABLE EARTH	Bajaj spare parts
JU402272	HARNESS WIRING	Bajaj spare parts
JU402405	SPEEDO LCD DISPLAY	Bajaj spare parts
JU402408	COLLAR	Bajaj spare parts
JU403606	STRAP CABLE	Bajaj spare parts
JU511038	COVER CYLINDER HEAD	Bajaj spare parts
JU511039	RUBBER GASKET	Bajaj spare parts
JU511049	HEAD CYLINDER-HOLDER CAMSHAFT	Bajaj spare parts
JU511055	GASKET HEAD CYLINDER	Bajaj spare parts
JU511204	ROCKER ARM (FINGER TYPE)	Bajaj spare parts
JU511205	VALVE INTAKE_G2	Bajaj spare parts
JU511206	VALVE EXHAUST_G2	Bajaj spare parts
JU511214	VALVE STEM SEAL	Bajaj spare parts
JU511216	CAMSHAFT EXHAUST	Bajaj spare parts
JU511218	ASSLY CAMSHAFT EXHAUST	Bajaj spare parts
JU511219	ASSLY CAMSHAFT INTAKE	Bajaj spare parts
JU511221	ASSLY CAMSHAFT EXHAUST	Bajaj spare parts
JU511223	CAMSHAFT SPROCKET	Bajaj spare parts
JU511225	VALVE EXHAUST	Bajaj spare parts
JU511226	RETAINER SPRING VALVE	Bajaj spare parts
JU511229	TENSIONER CHAIN	Bajaj spare parts
JU521005	CYL. BLOCK COMP (3.5MM THK)	Bajaj spare parts
JU521210	PISTON PIN_G2	Bajaj spare parts
JU521212	RING SNAP	Bajaj spare parts
JU531011	CIRCLIP	Bajaj spare parts
JU531021	BUSH BIG END	Bajaj spare parts
JU531027	CRANKSHAFT ASSY COMP	Bajaj spare parts
JU531204	BALANCER ASSY_G2	Bajaj spare parts
JU541005	BREATHER PLATE	Bajaj spare parts

JU541018	BRACKET HARNESS UPPER	Bajaj spare parts
JU541023	CRANKCASE LH-PLUG	Bajaj spare parts
JU541025	CRANKCASE LH	Bajaj spare parts
JU541201	ASSLY COVER MAGNETO	Bajaj spare parts
JU541218	COVER MAGNETO-PLUG	Bajaj spare parts
JU541219	COVER ASSLY MAGNETO	Bajaj spare parts
JU541229	COVER SENSOR	Bajaj spare parts
JU541233	COVER ASSEMBLY MAGNETO	Bajaj spare parts
JU551003	SHAFT OUTPUT-PLUG	Bajaj spare parts
JU551201	GEAR DRIVEN SECOND	Bajaj spare parts
JU551202	GEAR DRIVEN FIFTH	Bajaj spare parts
JU551401	ROD PUSH_G2 (FINAL)	Bajaj spare parts
JU551402	CLUTCH SPRING	Bajaj spare parts
JU551406	CLUTCH CENTER_G2	Bajaj spare parts
JU551408	CLUTCH PLATE ASSY_G2	Bajaj spare parts
JU551412	HOUSING CLUTCH ASSLY COMP	Bajaj spare parts
JU551413	CLUTCH ASSLY COMPLETE	Bajaj spare parts
JU561200	ROD ASSEMBLY TIE	Bajaj spare parts
JU561201	ROD ASSEMBLY TIE	Bajaj spare parts
JU561202	RING SNAP	Bajaj spare parts
JU561204	SPRING TORSION	Bajaj spare parts
JU561400	LEVER CHANGE ARM COMP	Bajaj spare parts
JU561401	ASSEMBLY TIE ROD	Bajaj spare parts
JU561412	LEVER ASSEMBLY CHANGE	Bajaj spare parts
JU561419	LEVER ASSEMBLY CHANGE	Bajaj spare parts
JU571000	ASSEMBLY OIL PUMP	Bajaj spare parts
JU581006	CLAMP CONNECTING TUBE	Bajaj spare parts
JU581014	CLAMP	Bajaj spare parts
JU581024	FILTER ASSLY AIR	Bajaj spare parts
JU581025	DUCT INTAKE	Bajaj spare parts
JU581035	DUCT INTAKE	Bajaj spare parts
JU581039	FILTER ASSEMBLY AIR	Bajaj spare parts
JU581404	THROTTLE BODY ASSY COMP G2	Bajaj spare parts
JU581413	PIPE INTAKE	Bajaj spare parts
JU591019	EXHAUST PIPE A ASSY_G2	Bajaj spare parts
JU591070	SILENCER SUB ASSLY	Bajaj spare parts
JU591081	BAND CLIP	Bajaj spare parts
JU591084	SILENCER SUB ASSLY	Bajaj spare parts
JU591091	ASSLY PIPE A	Bajaj spare parts
JU591107	SILENCER SUB ASSLY	Bajaj spare parts
JU591111	SILENCER SUB ASSLY	Bajaj spare parts
JU591144	SLEEVE	Bajaj spare parts
JU591145	DAMPER	Bajaj spare parts
JU591160	DAMPER	Bajaj spare parts
JU591162	WASHER SPECIAL	Bajaj spare parts

JU591168	ASSEMBLY MUFFLER	Bajaj spare parts
JU591175	ASSEMBLY MUFFLER	Bajaj spare parts
JU591178	SHIELD ASSEMBLY	Bajaj spare parts
JU591184	SHIELD ASSEMBLY	Bajaj spare parts
JU601200	COWL RADIATOR	Bajaj spare parts
JU601213	RADIATOR	Bajaj spare parts
JU601215	ASSLY RADIATOR	Bajaj spare parts
JU601217	TANK EXPANSION	Bajaj spare parts
JU601229	PIPE TANK EXPANSION-RADIATOR	Bajaj spare parts
JU611002	CAP INJECTOR	Bajaj spare parts
JU611206	THROTTLE BODY ASSLY_EVAP	Bajaj spare parts
JU611210	BODY ASSLY THROTTLE - EVAP	Bajaj spare parts
JU611219	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JU611220	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JU611221	CAP INJECTOR	Bajaj spare parts
JU611222	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JU611223	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JU990400	UNIT ABS WET	Bajaj spare parts
JU990401	GUIDE ASSEMBLY CABLE	Bajaj spare parts
JV113405	BRACKET ENGINE MTG TOP LH	Bajaj spare parts
JV113406	BRACKET ENGINE MTG TOP RH	Bajaj spare parts
JV161014	SPRING	Bajaj spare parts
JV171001	DAMPER TANK REAR	Bajaj spare parts
JV171079	TUBE BREATHER INLET	Bajaj spare parts
JV181206	COVER COVER - LH	Bajaj spare parts
JV181207	COVER RH SIDE	Bajaj spare parts
JV181408	FENDER REAR (COMBINED)	Bajaj spare parts
JV181410	FLAP FENDER REAR	Bajaj spare parts
JV231210	GUARD SAREE	Bajaj spare parts
JV233100	DECAL COVER SIDE LH ELE BLUE	Bajaj spare parts
JV233102	DECAL COVER SIDE LH EBONY BLACK	Bajaj spare parts
JV233104	DECAL COVER SIDE LH PASN RED	Bajaj spare parts
JV351008	STATOR ASSLY B108A	Bajaj spare parts
JV351204	COIL H. T. WITH CABLE	Bajaj spare parts
JV351205	H.T.COIL WITH CABLE & CAP	Bajaj spare parts
JV351211	CDI B108A	Bajaj spare parts
JV351213	CDI	Bajaj spare parts
JV351215	CDI	Bajaj spare parts
JV351600	STARTER MOTOR SILVER COLOUR	Bajaj spare parts
JV401602	DC HORN	Bajaj spare parts
JV401801	CASE BATTERY	Bajaj spare parts
JV401802	BATTERY BAND	Bajaj spare parts
JV402204	CABLE ST RELAY TO MOTOR	Bajaj spare parts
JV402205	CABLE ASSY BATTERY TO EAR	Bajaj spare parts
JV402213	HARNESS WIRING SS	Bajaj spare parts

JV402215	HARNESS WIRING	Bajaj spare parts
JV402406	SPEEDOMETER ASSLY	Bajaj spare parts
JV501008	ENGINE ASSLY	Bajaj spare parts
JV511007	CAMSHAFT COMPLETE	Bajaj spare parts
JV511011	PLATE CYLINDER HEAD	Bajaj spare parts
JV511012	GASKET HEAD COVER	Bajaj spare parts
JV511013	CYLINDER HEAD COVER	Bajaj spare parts
JV511200	VALVE INTAKE BM108A	Bajaj spare parts
JV511201	VALVE EXHAUST B108A	Bajaj spare parts
JV521003	CHAIN TENSIONER(SILVER)	Bajaj spare parts
JV531004	CRANKSHAFT ASSLY	Bajaj spare parts
JV531007	CRANKSHAFT ASSEMBLY	Bajaj spare parts
JV541006	CAP STRAINER	Bajaj spare parts
JV541007	BOLT FLANGE M6X1X35L	Bajaj spare parts
JV541205	CAP OIL FILTER	Bajaj spare parts
JV541207	CAP TDC FINDER	Bajaj spare parts
JV541208	SHAFT CLUTCH RELEASE ASSY	Bajaj spare parts
JV541209	BRACKET CABLE CLUTCH	Bajaj spare parts
JV541212	COVER LH RR SELF START	Bajaj spare parts
JV541225	LABEL COVER CLUCTH	Bajaj spare parts
JV551000	SPROCKET OUTPUT (15T)	Bajaj spare parts
JV581013	ASSLY AIRFILTER B108A	Bajaj spare parts
JV581014	TUBE CONNECTING B108A	Bajaj spare parts
JV581202	ASSLY CARBURETTOR B108A	Bajaj spare parts
JV581204	CARBURETTOR ASSLY	Bajaj spare parts
JV581404	INSULATOR PIPE INTAKE	Bajaj spare parts
JV582400	HOSE SAI INTAKE	Bajaj spare parts
JV582401	HOSE SAI OUTLET	Bajaj spare parts
JV582402	HOSE SAI MANIFOLD	Bajaj spare parts
JW122003	ARM SWING	Bajaj spare parts
JW131601	LEVER BRAKE	Bajaj spare parts
JW131800	DISC BRAKE SYSTEM	Bajaj spare parts
JW131801	CALIPER ASSY BRAKE F	Bajaj spare parts
JW131805	HOSE ASSY	Bajaj spare parts
JW131806	DISC BRAKE	Bajaj spare parts
JW131807	BRAKE PAD SET	Bajaj spare parts
JW131809	KIT CALIPER MINI	Bajaj spare parts
JW131810	KIT ANCHOR PIN	Bajaj spare parts
JW151001	HOLDER K UPPER	Bajaj spare parts
JW151021	TUBE OUTER LH DISC	Bajaj spare parts
JW151023	CYLINDER K	Bajaj spare parts
JW151024	SEAT PIPE	Bajaj spare parts
JW161017	GROMMET COVER SIDE R	Bajaj spare parts
JW171006	NUT CLIP M6	Bajaj spare parts
JW171007	DUAL LOCK TAPE 15X 20	Bajaj spare parts

JW171014	GROMMET SPOILER CENT	Bajaj spare parts
JW171015	COLLAR SPOILER CENTR	Bajaj spare parts
JW171016	SCREW ROUND HEAD	Bajaj spare parts
JW171017	DAMPER REAR	Bajaj spare parts
JW171026	PIPE DRAIN	Bajaj spare parts
JW181219	DUAL TAPE COWL SEAT	Bajaj spare parts
JW181228	BOLT FLANGE M6	Bajaj spare parts
JW181229	WASHER PLAIN	Bajaj spare parts
JW181236	CLIP NUT M5	Bajaj spare parts
JW181241	COVER DISC	Bajaj spare parts
JW232601	LOCK SET 3 IN 1	Bajaj spare parts
JW351400	SENSOR THERMAL GASKET	Bajaj spare parts
JW401001	LAMP HEAD ASSEMBLY	Bajaj spare parts
JW401010	CAP TAIL LAMP	Bajaj spare parts
JW401011	LAMP NUMBER PLATE	Bajaj spare parts
JW401600	HORN DC	Bajaj spare parts
JW402001	DC REGULATOR/CAPCTOR	Bajaj spare parts
JW402202	CABLE RELAY TO ST MT	Bajaj spare parts
JW511201	CAM SHAFT ASSLY	Bajaj spare parts
JW521000	CYL BLOCK ASSY XCD135	Bajaj spare parts
JW541000	BRACKET CLUTCH CABLE	Bajaj spare parts
JW541005	SHAFT CLUTCH RELEASE	Bajaj spare parts
JW541006	CRANKCASE MAGNETO AS	Bajaj spare parts
JW541010	CRANKCASE MAG KS	Bajaj spare parts
JW551401	SPRING COMPRESSION	Bajaj spare parts
JW551402	CLUTCH PLATE ASSLY	Bajaj spare parts
JW561000	DRUM COMP. GEAR SHIFT	Bajaj spare parts
JW561206	SPRING EXTENSION	Bajaj spare parts
JW561208	SPRING GEAR SHIFT RETURN	Bajaj spare parts
JW581206	JET MAIN VM17 XCD13	Bajaj spare parts
JW581208	NEEDLE JETVM17 XCD1	Bajaj spare parts
JW581211	PISTON VALVE ASSLY	Bajaj spare parts
JW591028	TRUSS SCREW M5X0.8	Bajaj spare parts
JW591030	GROMMET SHIELD	Bajaj spare parts
JX111024	HOLDER CABLE REAR	Bajaj spare parts
JX113001	HOLDER STEP RIDER LH	Bajaj spare parts
JX113002	STEP RIDER LH	Bajaj spare parts
JX113003	SCREW M10X45	Bajaj spare parts
JX113004	STEP RIDER RH	Bajaj spare parts
JX113005	HOLDER ASSEMBLY STEP PILLION LH	Bajaj spare parts
JX113006	SCREW	Bajaj spare parts
JX113007	SCREW	Bajaj spare parts
JX113008	SCREW M6X16	Bajaj spare parts
JX113009	HOLDER ASSEMBLY STEP PILLION RH	Bajaj spare parts
JX113010	COLLAR	Bajaj spare parts



JX113013	WASHER	Bajaj spare parts
JX113014	SPRING	Bajaj spare parts
JX113015	SPACER	Bajaj spare parts
JX113016	SWITCH BRAKE REAR	Bajaj spare parts
JX113017	COLLAR	Bajaj spare parts
JX113019	HOLDER RESERVIOR	Bajaj spare parts
JX113020	CIRCLIP	Bajaj spare parts
JX113026	GROMMET	Bajaj spare parts
JX113211	STAND SIDE	Bajaj spare parts
JX113212	BEARING	Bajaj spare parts
JX113213	DAMPER	Bajaj spare parts
JX113214	SPACER	Bajaj spare parts
JX113215	SEAL	Bajaj spare parts
JX113800	SET LOCK	Bajaj spare parts
JX113805	BOLT EJOT	Bajaj spare parts
JX113807	COLLAR	Bajaj spare parts
JX113812	HOSE FUEL	Bajaj spare parts
JX113823	LOCKING PLATE	Bajaj spare parts
JX113826	CLAMP STD DN32	Bajaj spare parts
JX113827	WASHER M6	Bajaj spare parts
JX113830	BUSH SILENT	Bajaj spare parts
JX113833	SCREW M5X12	Bajaj spare parts
JX113836	REGULATOR	Bajaj spare parts
JX113840	SPACER	Bajaj spare parts
JX113843	WASHER	Bajaj spare parts
JX113847	HOLDER STEP RIDER LH	Bajaj spare parts
JX113849	SCREW M6X10	Bajaj spare parts
JX113854	WASHER	Bajaj spare parts
JX113856	SPACER	Bajaj spare parts
JX113859	DISC BRAKE DIA 240	Bajaj spare parts
JX113861	SCREW	Bajaj spare parts
JX113862	BUSH	Bajaj spare parts
JX113863	COLLAR	Bajaj spare parts
JX113864	SCREW	Bajaj spare parts
JX113872	SPRING BAND CLAMP STD DN38	Bajaj spare parts
JX113874	CLAMP 25-40 SGT 4	Bajaj spare parts
JX113875	SCREW	Bajaj spare parts
JX113876	SCREW	Bajaj spare parts
JX113880	SCREW M6X18	Bajaj spare parts
JX113881	SCREW TIE CABLE	Bajaj spare parts
JX113884	BUSH	Bajaj spare parts
JX121000	FORK FRONT	Bajaj spare parts
JX121005	LEG FORK RH	Bajaj spare parts
JX121006	LEG FORK LH	Bajaj spare parts
JX121008	SCREW	Bajaj spare parts

JX121012	GREASE	Bajaj spare parts
JX121013	OIL FORK	Bajaj spare parts
JX122049	GUARD SLIDER CHAIN	Bajaj spare parts
JX122050	MONOSHOCK DUKE 790 L-PART	Bajaj spare parts
JX122053	SCREW M5X10	Bajaj spare parts
JX122056	GUARD SLIDER CHAIN	Bajaj spare parts
JX122057	DISC BRAKE DIA 300	Bajaj spare parts
JX122059	BUSH	Bajaj spare parts
JX122061	BUSH	Bajaj spare parts
JX122067	BEARING BUSH	Bajaj spare parts
JX131009	WHEEL ASSEMBLY FRONT	Bajaj spare parts
JX131011	DISC BRAKE DIA 300	Bajaj spare parts
JX131014	CARRIER MASK RH	Bajaj spare parts
JX131019	CARRIER ASSEMBLY MASK	Bajaj spare parts
JX131201	WHEEL ASSEMBLY REAR	Bajaj spare parts
JX131224	VALVE TYRE TUBELESS	Bajaj spare parts
JX131226	COUPLING	Bajaj spare parts
JX131227	SPROCKET	Bajaj spare parts
JX131228	FENDER REAR	Bajaj spare parts
JX131229	SCREW M8X18	Bajaj spare parts
JX131230	SCREW	Bajaj spare parts
JX131231	HOLDER REFLECTOR LH	Bajaj spare parts
JX131232	DISC BRAKE DIA 240	Bajaj spare parts
JX131233	TUBE ASSEMBLY	Bajaj spare parts
JX131235	BEARING BALL	Bajaj spare parts
JX131804	FUSE 30A	Bajaj spare parts
JX131822	CYLINDER ASSEMBLY MASTER FRONT	Bajaj spare parts
JX131831	HORN	Bajaj spare parts
JX131837	BATTERY	Bajaj spare parts
JX131851	COVER RELAY STARTER	Bajaj spare parts
JX131868	HOSE CYLINDER MASTER FR-UNIT ABS	Bajaj spare parts
JX131872	LEVER ASSEMBLY BRAKE	Bajaj spare parts
JX131878	INDICATOR FRONT RH	Bajaj spare parts
JX131885	HARNESS WIRING	Bajaj spare parts
JX131886	TYRE SPEED SENSOR	Bajaj spare parts
JX131887	COVER LOCK IGNITION	Bajaj spare parts
JX131889	DAMPER BLOCK	Bajaj spare parts
JX131890	RESERVOIR	Bajaj spare parts
JX131891	CLAMP	Bajaj spare parts
JX131892	HOSE RESERVOIR	Bajaj spare parts
JX131893	CYLINDER MASTER REAR	Bajaj spare parts
JX131901	SET RETAINER SPRING REAR	Bajaj spare parts
JX141000	CHAIN	Bajaj spare parts
JX141001	TENSIONER CHAIN	Bajaj spare parts
JX151002	BRACKET UNDER	Bajaj spare parts

JX151005	BRACKET UPPER	Bajaj spare parts
JX151021	HOLDER HANDLE LOWER	Bajaj spare parts
JX151022	HOLDER HANDLE UPPER	Bajaj spare parts
JX151023	HANDLEBAR	Bajaj spare parts
JX151052	GRIP LH	Bajaj spare parts
JX151053	WEIGHT HANDLEBAR	Bajaj spare parts
JX151058	MEMBER FRAME REAR RH	Bajaj spare parts
JX151076	Holder Ballhead	Bajaj spare parts
JX151079	SCREW M12X40	Bajaj spare parts
JX151084	GRIP RH	Bajaj spare parts
JX151085	SENSOR THROTTLE	Bajaj spare parts
JX151086	SET SCREW	Bajaj spare parts
JX151088	SWITCH CLUTCH	Bajaj spare parts
JX151089	SET SCREW	Bajaj spare parts
JX161001	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JX161004	DAMPER PEDAL BRAKE	Bajaj spare parts
JX161008	BOLT SWIVEL	Bajaj spare parts
JX161010	ROD PRESSURE	Bajaj spare parts
JX161011	SCREW	Bajaj spare parts
JX161200	CABLE STARTER	Bajaj spare parts
JX161201	CABLE STARTER-BATTERY	Bajaj spare parts
JX161204	CABLE CLUTCH	Bajaj spare parts
JX161206	CABLE STARTER-FRAME	Bajaj spare parts
JX171018	TANK FUEL	Bajaj spare parts
JX171028	FOAM LH	Bajaj spare parts
JX171031	CAP TANK FUEL	Bajaj spare parts
JX171811	GASKET	Bajaj spare parts
JX171812	PUMP FUEL	Bajaj spare parts
JX171817	CONNECTOR PUMP FUEL	Bajaj spare parts
JX181001	COMPENSATING RESERVOIR	Bajaj spare parts
JX181209	SENSOR TEMPERATURE	Bajaj spare parts
JX181228	CARRIER ASSEMBLY MASK	Bajaj spare parts
JX181229	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JX181230	COVER MASK MIDDLE	Bajaj spare parts
JX181231	CARRIER MASK LH	Bajaj spare parts
JX181232	CARRIER MASK RH	Bajaj spare parts
JX181233	FAIRING RH	Bajaj spare parts
JX181234	GUARD CHAIN	Bajaj spare parts
JX181235	COVER LH	Bajaj spare parts
JX181238	SCREW M6X12	Bajaj spare parts
JX181245	GUIDE CABLE RH	Bajaj spare parts
JX181248	BAND	Bajaj spare parts
JX181249	HOLDER PLATE NUMBER RH	Bajaj spare parts
JX181253	WASHER	Bajaj spare parts
JX181254	SCREW M5X13	Bajaj spare parts

JX181255	SCREW M8X25	Bajaj spare parts
JX181256	COVER TANK	Bajaj spare parts
JX181414	FENDER FRONT REAR	Bajaj spare parts
JX181418	SCREW	Bajaj spare parts
JX181419	FENDER FRONT	Bajaj spare parts
JX191004	SEAT ASSEMBLY FRONT	Bajaj spare parts
JX191005	SEAT ASSEMBLY REAR	Bajaj spare parts
JX191006	HOLDER HANDLE LOWER	Bajaj spare parts
JX231014	ELBOW CONNECTOR	Bajaj spare parts
JX231015	SCREW M8X30	Bajaj spare parts
JX231200	GUARD SAREE	Bajaj spare parts
JX231201	GUARD LEG LH	Bajaj spare parts
JX231202	GUARD LEG RH	Bajaj spare parts
JX231403	GRAB HANDLE	Bajaj spare parts
JX231603	MIRROR LH	Bajaj spare parts
JX231604	MIRROR RH	Bajaj spare parts
JX232605	SET LOCK	Bajaj spare parts
JX232607	KEY KEY	Bajaj spare parts
JX232608	LATCH ASSEMBLY SEAT	Bajaj spare parts
JX232800	HOLDER PLATE NUMBER LH	Bajaj spare parts
JX232801	HOLDER PLATE NUMBER RH	Bajaj spare parts
JX232802	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JX232804	BRACKET PLATE NUMBER REAR	Bajaj spare parts
JX351003	ROTOR CPL.	Bajaj spare parts
JX351004	STATOR	Bajaj spare parts
JX351010	DEEP GROOVE BALL BEARING 6001.2RSR C3	Bajaj spare parts
JX351203	SPARK PLUG NGK LMAR9AI-10	Bajaj spare parts
JX351204	COIL STICK	Bajaj spare parts
JX351206	SPECIAL SCREW M12X1.5 WS15	Bajaj spare parts
JX351415	CONTROL UNIT	Bajaj spare parts
JX351602	MOTOR STARTER	Bajaj spare parts
JX351603	RELAY STARTER	Bajaj spare parts
JX351800	SENSOR INDICATOR GEAR	Bajaj spare parts
JX351803	COVER RH	Bajaj spare parts
JX351804	SENSOR PICK UP	Bajaj spare parts
JX351805	WASHER	Bajaj spare parts
JX401026	INDICATOR FRONT LH	Bajaj spare parts
JX401027	INDICATOR FRONT RH	Bajaj spare parts
JX401028	HARNES WIRING REAR	Bajaj spare parts
JX401029	COLLAR	Bajaj spare parts
JX401030	PUMP FUEL	Bajaj spare parts
JX401031	LAMP TAIL	Bajaj spare parts
JX401409	OIL PRESSURE SWITCH "BITRON"	Bajaj spare parts
JX401410	GROMMET	Bajaj spare parts
JX401411	SPACER EXHAUST	Bajaj spare parts

JX401412	STAND SIDE	Bajaj spare parts
JX401413	CIRCLIP	Bajaj spare parts
JX401415	SWITCH BRAKE FRONT	Bajaj spare parts
JX402004	REGULATOR	Bajaj spare parts
JX402217	HARNESS WIRING	Bajaj spare parts
JX402218	RELAY	Bajaj spare parts
JX402222	CLAMP TIE CABLE	Bajaj spare parts
JX402224	DISC SPPED SENSOR	Bajaj spare parts
JX402403	SPEEDOMETER RH	Bajaj spare parts
JX403600	CLAMP SEPARATOR	Bajaj spare parts
JX403602	SENSOR ABS	Bajaj spare parts
JX403603	GASKET SENSOR LEVEL FUEL	Bajaj spare parts
JX403604	SCREW	Bajaj spare parts
JX403605	SENSOR OXYGEN	Bajaj spare parts
JX403606	SENSOR OXYGEN	Bajaj spare parts
JX501004	HH COLLAR SCREW M8X65 TX40	Bajaj spare parts
JX501009	DOWEL SLEEVE 6X8X11.5	Bajaj spare parts
JX501010	HH COLLAR SCREW M6X35 TX30	Bajaj spare parts
JX501012	THREADED PLUG M24X1.5 PA 6.6	Bajaj spare parts
JX501013	O-RING 24.00X2.50 VITON	Bajaj spare parts
JX511031	GUIDE VALVE	Bajaj spare parts
JX511035	VALVE EXHAUST	Bajaj spare parts
JX511036	INTAKE VALVE	Bajaj spare parts
JX511040	SEAL STEM VALVE	Bajaj spare parts
JX511041	ROCKER ARM	Bajaj spare parts
JX511042	SHAFT ROCKER ARM	Bajaj spare parts
JX511044	VALVE COVER	Bajaj spare parts
JX511045	CYLINDER HEAD GASKET	Bajaj spare parts
JX511046	WATER CONNECTION	Bajaj spare parts
JX511049	RUBBER GASKET FOR SCREW	Bajaj spare parts
JX511050	SPARK PLUG SHAFT GASKET	Bajaj spare parts
JX511054	"O-RING 12,00X3,0 VITON 75"	Bajaj spare parts
JX511056	DOWEL	Bajaj spare parts
JX511057	BOLT	Bajaj spare parts
JX511058	WASHER 19X10.5X2.5	Bajaj spare parts
JX511062	VALVE MECHANISM COVER SCREW	Bajaj spare parts
JX511063	VALVE COVER SCREW	Bajaj spare parts
JX511064	HOSE CLAMP GEMI 66	Bajaj spare parts
JX511070	DECOUPLING ELEMENT	Bajaj spare parts
JX511261	CAMSHAFT INTAKE	Bajaj spare parts
JX511262	CAMSHAFT EXHAUST	Bajaj spare parts
JX511263	BLEEDER CENTRIFUGE	Bajaj spare parts
JX511264	GUIDE CHAIN SLACK SIDE	Bajaj spare parts
JX511265	SLIDE BARS	Bajaj spare parts
JX511266	"SLIDE BARS, TOP CPL."	Bajaj spare parts

JX511267	TENSIONER CHAIN	Bajaj spare parts
JX511268	CHAIN	Bajaj spare parts
JX511272	RING O	Bajaj spare parts
JX511273	PLUG TENSIONER CHAIN	Bajaj spare parts
JX511274	RING O	Bajaj spare parts
JX511275	RING O	Bajaj spare parts
JX511276	PLUG	Bajaj spare parts
JX511278	VALVE COVER GASKET	Bajaj spare parts
JX521200	PISTON ASSEMBLY	Bajaj spare parts
JX521201	CIRCLIP	Bajaj spare parts
JX521202	SET RING PISTON	Bajaj spare parts
JX531027	BEARING SHELL	Bajaj spare parts
JX531028	BEARING SHELL	Bajaj spare parts
JX531029	BOLT	Bajaj spare parts
JX531030	BEARING MAIN	Bajaj spare parts
JX531031	BEARING MAIN	Bajaj spare parts
JX531032	BEARING MAIN	Bajaj spare parts
JX531033	BEARING MAIN	Bajaj spare parts
JX531206	BALANCER ASSEMBLY	Bajaj spare parts
JX531207	SHAFT BALANCER	Bajaj spare parts
JX531208	SHELL BEARING	Bajaj spare parts
JX531210	WASHER	Bajaj spare parts
JX531211	BEARING NEEDLE ROLLER	Bajaj spare parts
JX541037	CRANKCASE ASSEMBLY	Bajaj spare parts
JX541039	GASKET PAN OIL	Bajaj spare parts
JX541041	OIL-WATER-HEATER EXCHANGER	Bajaj spare parts
JX541042	GASKET	Bajaj spare parts
JX541043	OIL PAN	Bajaj spare parts
JX541049	GASKET	Bajaj spare parts
JX541200	GASKET COVER MAGNETO	Bajaj spare parts
JX541201	CAP FILLER OIL	Bajaj spare parts
JX541204	CLUTCH COVER GASKET	Bajaj spare parts
JX541205	SPRING	Bajaj spare parts
JX541207	GENERATOR COVER	Bajaj spare parts
JX541208	SCREW	Bajaj spare parts
JX541209	SEAL	Bajaj spare parts
JX541212	"O-RING 19,00X3,00 NBR"	Bajaj spare parts
JX551037	CLUTCH RELEASE SHAFT	Bajaj spare parts
JX551043	RADIAL SHAFT SEAL 32X47X7BSL VITON	Bajaj spare parts
JX551044	"O-RING 25,12X1,78 NBR70"	Bajaj spare parts
JX551045	SPACER SLEEVE DRIVE END	Bajaj spare parts
JX551046	FRONT SPROCKET 16 TEETH DAMPED	Bajaj spare parts
JX551047	SPROCKET NUT M20X1.5	Bajaj spare parts
JX551071	SHAFT OUTPUT	Bajaj spare parts
JX551200	TORQUE LIMITER 10/55 CPL.	Bajaj spare parts

JX551201	IDLER GEAR 26 TEETH	Bajaj spare parts
JX551440	PULL ROD	Bajaj spare parts
JX551442	SHAFT ASSEMBLY CLUTCH	Bajaj spare parts
JX551444	WASHER 26X47X3	Bajaj spare parts
JX551445	"HEX NUT M20X1., H=6MM"	Bajaj spare parts
JX551446	THRUST WASHER 20X32X2	Bajaj spare parts
JX551449	SCREW	Bajaj spare parts
JX551450	PLATE STOPPER	Bajaj spare parts
JX551451	SPRING	Bajaj spare parts
JX551452	COVER SPRING	Bajaj spare parts
JX551453	PLATE PRESSURE	Bajaj spare parts
JX551454	PLATE ASSEMBLY CLUTCH	Bajaj spare parts
JX551455	WASHER BELLEVILLE	Bajaj spare parts
JX551456	BEARING BALL	Bajaj spare parts
JX551457	CLUTCH CENTER	Bajaj spare parts
JX551458	WASHER	Bajaj spare parts
JX551459	HOUSING CLUTCH	Bajaj spare parts
JX551460	BEARING NEEDLE	Bajaj spare parts
JX561036	LOCKING PLATE	Bajaj spare parts
JX561038	SHIFT FORK 1.-4. GEAR	Bajaj spare parts
JX561040	LEVER DETENT	Bajaj spare parts
JX561045	SCREW	Bajaj spare parts
JX561046	HH COLLAR SCREW M6X15 TX30	Bajaj spare parts
JX561056	PAIR NORDLOCK WASHER M6	Bajaj spare parts
JX561204	SHIFT LOCKER CPL.	Bajaj spare parts
JX561205	SHIFT SHAFT CPL.	Bajaj spare parts
JX561206	GEAR LEVER KPL. BLACK	Bajaj spare parts
JX561207	SHIFTER ROD CPL.	Bajaj spare parts
JX561208	DAMPER LEVER GEAR SHIFT	Bajaj spare parts
JX561209	LEVER GEAR SHIFT	Bajaj spare parts
JX571036	OIL FILTER COVER	Bajaj spare parts
JX571037	FILTER OIL	Bajaj spare parts
JX571038	STRAINER OIL	Bajaj spare parts
JX571039	PIPE ASSEMBLY OIL	Bajaj spare parts
JX571048	"O-RING 14,00X2,00"	Bajaj spare parts
JX571050	RING O	Bajaj spare parts
JX571051	RING O	Bajaj spare parts
JX581007	INTAKE SLEEVE	Bajaj spare parts
JX581009	BOX FILTER AIR	Bajaj spare parts
JX581012	CALIPER ASSEMBLY REAR	Bajaj spare parts
JX581013	ELEMENT FILTER AIR	Bajaj spare parts
JX581014	HOLDER ELEMENT FILTER AIR I	Bajaj spare parts
JX581015	HOLDER ELEMENT FILTER AIR II	Bajaj spare parts
JX581018	LID COVER FILTER AIR	Bajaj spare parts
JX581021	CLAMP	Bajaj spare parts

JX591002	SCREW	Bajaj spare parts
JX591003	SHIELD MUFFLER	Bajaj spare parts
JX591004	GROMMET	Bajaj spare parts
JX591006	SPACER	Bajaj spare parts
JX591007	BOLT PIVOT	Bajaj spare parts
JX591009	SCREW	Bajaj spare parts
JX591011	SEAL	Bajaj spare parts
JX591013	WHEEL ASSEMBLY REAR	Bajaj spare parts
JX591016	BEARING BALL	Bajaj spare parts
JX591018	PIPE A	Bajaj spare parts
JX601013	WATER PUMP WHEEL CPL.	Bajaj spare parts
JX601014	GASKET COVER PUMP WATER	Bajaj spare parts
JX601015	WATER PUMP COVER	Bajaj spare parts
JX601016	UNIT THERMOSTAT	Bajaj spare parts
JX601018	DOUBLE-D WASHER 16X1 SST	Bajaj spare parts
JX601019	HH COLLAR SCREW M6X13 TX30	Bajaj spare parts
JX601020	RADIAL SHAFT SEAL 34.5X15X9 DUO	Bajaj spare parts
JX601021	"O-RING 9X1,5 V80 SH"	Bajaj spare parts
JX601022	BOLT EJOT	Bajaj spare parts
JX601023	SEAL	Bajaj spare parts
JX601224	MOLDED HOSE RADIATOR	Bajaj spare parts
JX601225	MOLDED HOSE RADIATOR	Bajaj spare parts
JX601228	RADIATOR ASSEMBLY	Bajaj spare parts
JX601229	CAP RADIATOR	Bajaj spare parts
JX601231	COVER FAN RADIATOR	Bajaj spare parts
JX611000	INJECTOR FUEL	Bajaj spare parts
JX611200	THROTTLE BODY	Bajaj spare parts
JX611204	SENSOR MAP	Bajaj spare parts
JX621200	LEVER ASSEMBLY BRAKE	Bajaj spare parts
JX621203	SPRING	Bajaj spare parts
JX621205	SCREW	Bajaj spare parts
JX621400	FREE WHEEL GEAR CPL.	Bajaj spare parts
JX621401	SHIM	Bajaj spare parts
JX621402	SHIM	Bajaj spare parts
JX621403	SHIM	Bajaj spare parts
JX621404	SHIM	Bajaj spare parts
JX621405	SHIM	Bajaj spare parts
JX621406	SHIM	Bajaj spare parts
JX621407	SHIM	Bajaj spare parts
JX621408	SHIM	Bajaj spare parts
JX621409	SHIM	Bajaj spare parts
JX621410	SHIM	Bajaj spare parts
JX621411	SHIM	Bajaj spare parts
JX621412	SHIM	Bajaj spare parts
JX621413	SHIM	Bajaj spare parts



JX621414	SHIM	Bajaj spare parts
JX621415	SHIM	Bajaj spare parts
JX621416	SHIM	Bajaj spare parts
JX621417	SHIM	Bajaj spare parts
JX621418	SHIM	Bajaj spare parts
JX621419	SHIM	Bajaj spare parts
JX621420	SHIM	Bajaj spare parts
JX621421	SHIM	Bajaj spare parts
JX621422	SHIM	Bajaj spare parts
JX621423	SHIM	Bajaj spare parts
JY111155	FRAME ASSLY KT04 KT05	Bajaj spare parts
JY111203	BRACKET SPIDER LH	Bajaj spare parts
JY111204	BRACKET SPIDER RH	Bajaj spare parts
JY113004	HOLDER STEP LH	Bajaj spare parts
JY113005	HOLDER STEP RH	Bajaj spare parts
JY113006	HOLDER STEP PILLION LH	Bajaj spare parts
JY113007	HOLDER STEP PILLION RH	Bajaj spare parts
JY113008	ASSLY TIE ROD	Bajaj spare parts
JY113015	WASHER CHANGE LEVER	Bajaj spare parts
JY113018	PIN FOOTPEG PIVOT	Bajaj spare parts
JY113020	PLATE LOCK UPPER	Bajaj spare parts
JY113021	PLATE LOCK LOWER	Bajaj spare parts
JY113024	ASSLY CHANGE LEVER KT04	Bajaj spare parts
JY113025	BOLT CHANGE LEVER	Bajaj spare parts
JY113049	BRACKET HOSE I	Bajaj spare parts
JY113050	BRACKET HOSE II	Bajaj spare parts
JY113054	GUARD HEEL LH	Bajaj spare parts
JY113055	GUARD HEEL RH	Bajaj spare parts
JY113056	BRACKET HOSE	Bajaj spare parts
JY113057	GUARD HEEL LH	Bajaj spare parts
JY113058	GUARD HEEL RH	Bajaj spare parts
JY113205	PLATE STAND SIDE	Bajaj spare parts
JY113209	STAND SIDE	Bajaj spare parts
JY113210	SHIELD SWITCH STAND SIDE	Bajaj spare parts
JY113212	STAND SIDE	Bajaj spare parts
JY113216	SHIELD SWITCH STAND SIDE	Bajaj spare parts
JY113217	STAND SIDE	Bajaj spare parts
JY113400	ENGINE HANGER LH	Bajaj spare parts
JY113401	ENGINE HANGER RH	Bajaj spare parts
JY113800	BRACKET RADIATOR MTG LH	Bajaj spare parts
JY113801	BRACKET RADIATOR MTG RH	Bajaj spare parts
JY113804	BRACKET REGULATOR SINK MTG	Bajaj spare parts
JY113805	BASE BATTERY	Bajaj spare parts
JY113806	BRACKET ECU MTG LH	Bajaj spare parts
JY113807	BRACKET ECU MTG RH	Bajaj spare parts

JY113808	BRIDGE BRACKET SEAT MTG	Bajaj spare parts
JY113809	BRACKET RADIATOR MOUNTING LH	Bajaj spare parts
JY113812	BRACKET RADIATOR MTG RH	Bajaj spare parts
JY113813	BUSH RADIATOR MTG	Bajaj spare parts
JY113819	BRACKET LOOSE SIDE FAIRING MTG LH	Bajaj spare parts
JY113821	BOLT SOCKET SPECIAL HEAD	Bajaj spare parts
JY113822	GROMMET BATTERY BOX	Bajaj spare parts
JY113824	BRACKET CABLE LID LOCK	Bajaj spare parts
JY113825	SLEEVE UNDER TRAY	Bajaj spare parts
JY113826	COLLAR UNDER TRAY	Bajaj spare parts
JY113827	BRACKET HOSE CLAMP 1	Bajaj spare parts
JY113828	BRACKET HOSE CLAMP 2	Bajaj spare parts
JY113831	BRACKET RADIATOR MTG LOOSE 1	Bajaj spare parts
JY113832	BRACKET RADIATOR MTG LOOSE 2	Bajaj spare parts
JY113834	RUBBER PAD GRAB LH TOP	Bajaj spare parts
JY113835	RUBBER PAD GRAB RH TOP	Bajaj spare parts
JY113836	RUBBER DAMPER	Bajaj spare parts
JY113837	GROMMET FOR CABLE	Bajaj spare parts
JY113838	RUBBER PAD GRAB LH BOTTOM	Bajaj spare parts
JY113839	RUBBER PAD GRAB RH BOTTOM	Bajaj spare parts
JY113842	CONNECTOR Y SHAPE	Bajaj spare parts
JY113844	CLAMP BRAKE HOSE	Bajaj spare parts
JY113845	RUBBER HEAT SHIELD	Bajaj spare parts
JY113846	CAP FORGING PIVOT LH KT04	Bajaj spare parts
JY113847	CAP FRAME END	Bajaj spare parts
JY113848	CABLE TIE FOR CLUTCH CABLE	Bajaj spare parts
JY113849	BRACKET CANISTER MTG LOOSE	Bajaj spare parts
JY113850	BRACKET CANISTER MTG LOOSE 2	Bajaj spare parts
JY113851	PAD RUBBER CANISTER MTG BKT	Bajaj spare parts
JY113853	RUBBER STRAP	Bajaj spare parts
JY113854	BRACKET SIDE REFLECTOR FR LH	Bajaj spare parts
JY113855	BRACKET SIDE REFLECTOR FR RH	Bajaj spare parts
JY113856	ASSLY ECU RUBBER DAMPER	Bajaj spare parts
JY113857	STRAP CANISTER	Bajaj spare parts
JY113858	PAD UNDER TRAY BOTTOM	Bajaj spare parts
JY113862	"RUBBER STRAP FR, BRAKE HOSE"	Bajaj spare parts
JY113863	RUBBER FRONT BRAKE HOSE	Bajaj spare parts
JY113864	BRACKET ECU MTG TOP C SAMPLE	Bajaj spare parts
JY113865	BRACKET SILENCER MTG	Bajaj spare parts
JY113870	COVER BRACKET SIDE FAIRING MTG LH I	Bajaj spare parts
JY113871	COVER BRACKET SIDE FAIRING MTG LH II	Bajaj spare parts
JY113872	PAD RESTING ECU C SAMPLE LH	Bajaj spare parts
JY113873	PAD RESTING ECU C SAMPLE RH	Bajaj spare parts
JY113874	DAMPER ECU C SAMPLE MTG TOP	Bajaj spare parts
JY113876	BRACKET RESERVOIR MTG MY16	Bajaj spare parts

JY113877	DAMPER ECU LOCATOR	Bajaj spare parts
JY113879	BRACKET RADIATOR MTG RH	Bajaj spare parts
JY113880	BRACKET UNIT ABS	Bajaj spare parts
JY113882	GUARD CAT	Bajaj spare parts
JY113883	SHIELD	Bajaj spare parts
JY113885	BRACKET MUFFLER	Bajaj spare parts
JY113886	BRACKET CANISTER	Bajaj spare parts
JY113889	COLLAR	Bajaj spare parts
JY113890	DAMPER	Bajaj spare parts
JY113891	BRACKET FRAME FRONT MIDDLE	Bajaj spare parts
JY113892	BRACKET REFLECTOR REFLEX LH	Bajaj spare parts
JY113893	BRACKET REFLECTOR REFLEX RH	Bajaj spare parts
JY113899	PIN	Bajaj spare parts
JY113900	PIN	Bajaj spare parts
JY113901	HOLDER COUPLER	Bajaj spare parts
JY113910	FOAM LH	Bajaj spare parts
JY113911	FOAM RH	Bajaj spare parts
JY113912	DAMPER	Bajaj spare parts
JY113916	BRACKET RADIATOR LH	Bajaj spare parts
JY113917	BRACKET RADIATOR RH	Bajaj spare parts
JY113919	PIN QUICK RELEASE	Bajaj spare parts
JY113921	BRACKET FAIRING SIDE LH	Bajaj spare parts
JY113922	BRACKET FAIRING SIDE RH	Bajaj spare parts
JY113923	BRACKET FAIRING SIDE MIDDLE	Bajaj spare parts
JY113925	STRAP CANISTER	Bajaj spare parts
JY113926	GROMMET	Bajaj spare parts
JY113927	CLAMP	Bajaj spare parts
JY113930	GROMMET	Bajaj spare parts
JY113931	PLUG	Bajaj spare parts
JY113932	PLATE CLAMP	Bajaj spare parts
JY113933	CAP	Bajaj spare parts
JY121007	LEG ASSY LH	Bajaj spare parts
JY121009	FORK ASSLY DOMESTIC	Bajaj spare parts
JY121010	ASSEMBLY UNDER BRACKET	Bajaj spare parts
JY121011	BOLT SOCKET M8X1.25X30L BLK	Bajaj spare parts
JY121014	ASSEY PISTON ROD	Bajaj spare parts
JY121016	FORK ASSLY FRONT KT05 DOM	Bajaj spare parts
JY121017	FORK ASSLY FRONT KT06	Bajaj spare parts
JY121020	LEG ASSLY LH KT06	Bajaj spare parts
JY121021	LEG ASSLY RH KT06	Bajaj spare parts
JY121029	ASSLY MAIN SPRING AND WASHER	Bajaj spare parts
JY121030	ASSLY PISTON ROD	Bajaj spare parts
JY121033	LEG ASSY LH	Bajaj spare parts
JY121034	LEG ASSY RH	Bajaj spare parts
JY121036	ASSLY MAIN SPRING AND WASHER	Bajaj spare parts

JY121037	ASSLY PISTON ROD	Bajaj spare parts
JY121040	LEG ASSY LH	Bajaj spare parts
JY121041	LEG ASSY RH	Bajaj spare parts
JY121054	FORK PIPE ASSEMBLY RH	Bajaj spare parts
JY121066	AXLE CLAMP AND FORK PIPE LH	Bajaj spare parts
JY121067	AXLE CLAMP AND FORK PIPE RH	Bajaj spare parts
JY121068	AXLE CLAMP LH	Bajaj spare parts
JY121069	AXLE CLAMP RH	Bajaj spare parts
JY121076	LEG ASSLY LH -HEAVY DUTY	Bajaj spare parts
JY121077	LEG ASSLY RH -HEAVY DUTY	Bajaj spare parts
JY121083	LEG ASSLY LH	Bajaj spare parts
JY121092	BRACKET ASSEMBLY UNDER	Bajaj spare parts
JY121118	FORK FRONT	Bajaj spare parts
JY122004	SLEEVE CHAIN SLIDER	Bajaj spare parts
JY122005	SHOCKABSORBER MONO DOMESTIC	Bajaj spare parts
JY122006	SHOCKABSORBER MONO KT05 DOM	Bajaj spare parts
JY122007	SHOCKABSORBER MONO KT06	Bajaj spare parts
JY122019	SHOCKABSORBER MONO	Bajaj spare parts
JY122020	SHOCKABSORBER MONO RC390 HD	Bajaj spare parts
JY122026	SHOCKABSORBER REAR	Bajaj spare parts
JY122027	SHOCKABSORBER REAR	Bajaj spare parts
JY122029	SHOCKABSORBER REAR	Bajaj spare parts
JY122030	SHOCKABSORBER REAR	Bajaj spare parts
JY122037	BRACKET COVER CHAIN	Bajaj spare parts
JY131025	DISC SENSOR SPEED FRONT	Bajaj spare parts
JY131030	SEAL OIL	Bajaj spare parts
JY131201	DAMPER 6 RUBBER	Bajaj spare parts
JY131203	COUPLIN ASSY	Bajaj spare parts
JY131800	DISC FRONT	Bajaj spare parts
JY131802	ANTILOCK BRAKING SYSTEM_WET	Bajaj spare parts
JY131805	TUBE RESERVOIR	Bajaj spare parts
JY131811	ASSLY REAR MASTER CYLINDER	Bajaj spare parts
JY131812	ASSLY MASTER CYL FRONT KT04	Bajaj spare parts
JY131813	CLAMP BRAKE HOSE KT04	Bajaj spare parts
JY131816	ABS UNIT 9.1 WET	Bajaj spare parts
JY131817	CLAMP BRAKE HOSE REAR	Bajaj spare parts
JY131823	PAD SET -SINTERED	Bajaj spare parts
JY131824	BRACKET FR. BRAKE HOSE MTG I	Bajaj spare parts
JY131825	BRACKET FR. BRAKE HOSE MTG II	Bajaj spare parts
JY131826	BRACKET FR. BRAKE HOSE MTG III	Bajaj spare parts
JY131829	ASSLY MASTER CYLINDER FR MY16	Bajaj spare parts
JY131834	UNIT ABS WET_9.1 MB_CAN	Bajaj spare parts
JY131842	MASTER CYLINDER ADJUSTABLE LEVER	Bajaj spare parts
JY131844	ASSLY MASTER CYLINDER	Bajaj spare parts
JY131875	UNIT ABS WET	Bajaj spare parts

JY131880	DISC BRAKE DIA 320	Bajaj spare parts
JY131881	DISC BRAKE DIA 230	Bajaj spare parts
JY131888	CYLINDER ASSEMBLY MASTER REAR	Bajaj spare parts
JY131901	UNIT ABS WET	Bajaj spare parts
JY131905	UNIT ABS WET	Bajaj spare parts
JY131918	CLAMP HOSE BRAKE REAR	Bajaj spare parts
JY131919	CLIP SEPARATOR	Bajaj spare parts
JY131921	CALIPER ASSEMBLY FRONT	Bajaj spare parts
JY131922	CALIPER ASSEMBLY FRONT	Bajaj spare parts
JY131923	CALIPER ASSEMBLY REAR	Bajaj spare parts
JY141004	SPROCKET DRIVEN	Bajaj spare parts
JY151002	TUBE HANDLEBAR LH	Bajaj spare parts
JY151003	TUBE HANDLEBAR RH	Bajaj spare parts
JY151007	HANDLE BAR TUBE LH	Bajaj spare parts
JY151008	HANDLE BAR TUBE RH	Bajaj spare parts
JY151010	LOWER TRIPLE CLAMP	Bajaj spare parts
JY151011	BOLT STEERING TOP	Bajaj spare parts
JY151012	GRIP HAND LH KT04	Bajaj spare parts
JY151014	GRIP ASSLY RH KT04	Bajaj spare parts
JY151015	GRIP HAND LH KT06	Bajaj spare parts
JY151017	GRIP ASSEMBLY RH KT06	Bajaj spare parts
JY151018	CLAMP UPPER TRIPLE	Bajaj spare parts
JY151019	TUBE HANDLE BAR LH	Bajaj spare parts
JY151020	TUBE HANDLE BAR RH	Bajaj spare parts
JY151021	TUBE HANDLE BAR LH	Bajaj spare parts
JY151022	TUBE HANDLE BAR RH	Bajaj spare parts
JY151023	HANDLEBAR TUBE LH KT06 MY16	Bajaj spare parts
JY151024	HANDLEBAR TUBE RH KT06 MY16	Bajaj spare parts
JY151028	HANDLEBAR END WEIGHT KT06	Bajaj spare parts
JY151036	ASSLY GRIP HANDLEBAR RH	Bajaj spare parts
JY151040	HOLDER HANDLE LH	Bajaj spare parts
JY151041	HOLDER HANDLE RH	Bajaj spare parts
JY151042	BRACKET UPPER	Bajaj spare parts
JY151045	TUBE HANDLEBAR LH	Bajaj spare parts
JY151046	TUBE HANDLEBAR LH	Bajaj spare parts
JY151047	TUBE HANDLEBAR RH	Bajaj spare parts
JY151059	GRIP LH	Bajaj spare parts
JY151063	GRIP LH	Bajaj spare parts
JY151065	GRIP ASSEMBLY RH	Bajaj spare parts
JY151067	GRIP ASSEMBLY RH	Bajaj spare parts
JY161000	LEVER & SUPPORT HOLDER ASSY LH	Bajaj spare parts
JY161002	HOLDER ASSLY LH RC390	Bajaj spare parts
JY161003	LEVER CLUTCH ADJUSTABLE	Bajaj spare parts
JY161006	HOLDER ASSLY LH RC 200	Bajaj spare parts
JY161007	CLUTCH LEVER NON ADJUSTABLE	Bajaj spare parts

JY161008	ASSLY CLUTCH LEVER ADJUSTABLE	Bajaj spare parts
JY161023	BOOT CLUTCH LEVER_ADJUSTABLE	Bajaj spare parts
JY161025	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JY161026	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JY161027	PEDAL ASSEMBLY BRAKE	Bajaj spare parts
JY161029	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JY161200	CABLE CLUTCH_DUKE 375	Bajaj spare parts
JY161201	CABLE ACCELERATOR	Bajaj spare parts
JY161202	CLUTCH CABLE	Bajaj spare parts
JY161204	CABLE ACCELERATOR	Bajaj spare parts
JY161205	CABLE CLUTCH KT06	Bajaj spare parts
JY161206	CABLE CLUTCH	Bajaj spare parts
JY161209	ACCELERATOR CABLE MY17	Bajaj spare parts
JY171002	TANK COVER TOP	Bajaj spare parts
JY171006	BRACKET TANK MTG REAR	Bajaj spare parts
JY171007	PAD RUBBER NEW ECU MY16	Bajaj spare parts
JY171037	GROMMET TANK COVER MTG	Bajaj spare parts
JY171040	DAMPER TANK TOP LH	Bajaj spare parts
JY171041	DAMPER TANK TOP RH	Bajaj spare parts
JY171042	DAMPER TANK FRONT LH	Bajaj spare parts
JY171043	DAMPER TANK FRONT RH	Bajaj spare parts
JY171044	DAMPER TANK REAR LH	Bajaj spare parts
JY171045	DAMPER TANK REAR RH	Bajaj spare parts
JY171066	TUBE TANK TO CANISTER (US)	Bajaj spare parts
JY171067	TUBE CANISTER TO PURGE VALVE	Bajaj spare parts
JY171069	SPRING BAND CLAMP 15X10	Bajaj spare parts
JY171070	SPRING BAND CLAMP 10.5 X 8.4	Bajaj spare parts
JY171072	TANK CANISTER	Bajaj spare parts
JY171077	CANISTER	Bajaj spare parts
JY171088	SEAT TAPE	Bajaj spare parts
JY171089	TUBE CONNECTOR TO INJECTOR	Bajaj spare parts
JY171090	SPRING BAND CLAMP 13X12	Bajaj spare parts
JY171093	CAP FUEL TANK	Bajaj spare parts
JY171095	TUBE DRAIN	Bajaj spare parts
JY171096	DRAIN TUBE	Bajaj spare parts
JY171097	ASSLY FUEL TANK PHASE II	Bajaj spare parts
JY171108	TANK ASSLY US PH3	Bajaj spare parts
JY171125	ASSLY FUEL TANK	Bajaj spare parts
JY171146	RING O	Bajaj spare parts
JY171160	TANK ASSEMBLY FUEL	Bajaj spare parts
JY171180	PLATE PUMP FUEL	Bajaj spare parts
JY171182	CAP	Bajaj spare parts
JY171183	BEADING	Bajaj spare parts
JY171185	TANK ASSEMBLY FUEL	Bajaj spare parts
JY171194	TAPE	Bajaj spare parts

JY171195	TAPE	Bajaj spare parts
JY171602	TUBE CANISTER TO PURGE VALVE	Bajaj spare parts
JY171603	CANISTER TO TUBE CONNECTOR	Bajaj spare parts
JY171604	TUBE CONNECTOR TO ETB	Bajaj spare parts
JY171605	TUBE DRAIN	Bajaj spare parts
JY171606	TUBE PURGE VALVE TO CONNECTOR	Bajaj spare parts
JY171614	PIPE FUEL	Bajaj spare parts
JY171616	PIPE FUEL	Bajaj spare parts
JY171617	PIPE DRAIN	Bajaj spare parts
JY171618	PIPE DRAIN	Bajaj spare parts
JY171619	PIPE DRAIN	Bajaj spare parts
JY171800	FUEL PUMP MODULE	Bajaj spare parts
JY171812	HOSE FUEL PUMP TO FILTER	Bajaj spare parts
JY171815	BOLT STEP FUEL PUMP MTG	Bajaj spare parts
JY171816	ASSLY FUEL PUMP KT04	Bajaj spare parts
JY171817	ASSLY FUEL PUMP KT06	Bajaj spare parts
JY171823	TUBE CONNECTOR TO CANISTER	Bajaj spare parts
JY171824	TUBE CONNECTOR TO PLUG	Bajaj spare parts
JY171825	PLUG FUEL DRAIN	Bajaj spare parts
JY171829	ASSLY HOSE PUMP TO FUEL FILTER WITH Q	Bajaj spare parts
JY171831	ASSLY HOSE FUEL FILTER	Bajaj spare parts
JY171837	PRESSURE PLATE FUEL PUMP MTG PH3	Bajaj spare parts
JY171838	TUBE ETB TO CONNECTOR	Bajaj spare parts
JY171850	PUMP FUEL	Bajaj spare parts
JY171855	PIPE FUEL	Bajaj spare parts
JY171856	PIPE FUEL	Bajaj spare parts
JY171857	PIPE FILTER FUEL-BODY THROTTLE	Bajaj spare parts
JY171859	PIPE FUEL	Bajaj spare parts
JY171860	PIPE FUEL	Bajaj spare parts
JY171861	PUMP FUEL	Bajaj spare parts
JY171862	PUMP FUEL	Bajaj spare parts
JY181000	TUBE REAR HUGGER	Bajaj spare parts
JY181201	BELLY PAN	Bajaj spare parts
JY181202	BELLY PAN RC390 MY16	Bajaj spare parts
JY181204	PAD RUBBER SIDEMASK LH FR	Bajaj spare parts
JY181205	PAD RUBBER SIDEMASK RH FR	Bajaj spare parts
JY181207	BRACKET DRAIN TUBE HOLDING	Bajaj spare parts
JY181209	PAD RUBBER SIDEMASK LH RR	Bajaj spare parts
JY181210	PAD RUBBER SIDEMASK RH RR	Bajaj spare parts
JY181211	UNDER TRAY BOTTOM	Bajaj spare parts
JY181213	UNDER TRAY FRONT	Bajaj spare parts
JY181214	BATTERY MTG CASE	Bajaj spare parts
JY181215	LID BATTERY	Bajaj spare parts
JY181216	PANEL ELEC. COMPONENT MTG	Bajaj spare parts
JY181217	BKT BELLY PAN TOP MTG	Bajaj spare parts

JY181218	BKT BELLYPAN MIDDLE MTG	Bajaj spare parts
JY181219	BKT BELLYPAN REAR MTG	Bajaj spare parts
JY181220	FAIRING INNER LH	Bajaj spare parts
JY181221	FAIRING INNER RH	Bajaj spare parts
JY181222	FAIRING OUTER LH	Bajaj spare parts
JY181223	FAIRING OUTER RH	Bajaj spare parts
JY181226	CHAIN COVER CUM HUGGER 1	Bajaj spare parts
JY181228	BELLY PAN LH	Bajaj spare parts
JY181229	BELLY PAN RH	Bajaj spare parts
JY181232	COVER NUMBER PLATE STRUCTURE	Bajaj spare parts
JY181233	BOX UTILITY	Bajaj spare parts
JY181234	BRACKET BELLY PAN RR RC390 MY16	Bajaj spare parts
JY181235	RADIATOR SHROUD LOWER	Bajaj spare parts
JY181236	BRACKET FRONT BELLY PAN	Bajaj spare parts
JY181238	BRACKET REAR BELLY PAN	Bajaj spare parts
JY181240	SLEEVE CHAIN COVER MTG	Bajaj spare parts
JY181241	VISOR	Bajaj spare parts
JY181243	SIDEMASK RH	Bajaj spare parts
JY181244	FAIRING STRUCTURE LH	Bajaj spare parts
JY181245	FAIRING STRUCTURE RH	Bajaj spare parts
JY181246	STRUCTURE PROJECTOR HEAD LAMP MTG	Bajaj spare parts
JY181247	DASHBOARD	Bajaj spare parts
JY181248	COLLAR BELLY PAN RH MTG	Bajaj spare parts
JY181253	ASSLY SIDE FAIRING RH	Bajaj spare parts
JY181254	BRACKET BLINKER CABLE HOLDING	Bajaj spare parts
JY181255	WASHER END CAP	Bajaj spare parts
JY181256	SHROUD RADIATOR	Bajaj spare parts
JY181258	SLEEVE FOR CHAIN COVER	Bajaj spare parts
JY181262	COVER COUPLER PROTECTION	Bajaj spare parts
JY181263	COVER IGNITION SWITCH	Bajaj spare parts
JY181264	STEP BOLT M6 X 16	Bajaj spare parts
JY181265	BOLT SPECIAL HEAD M6X42L	Bajaj spare parts
JY181266	COVER BLINKER FR LH	Bajaj spare parts
JY181267	COVER BLINKER FR RH	Bajaj spare parts
JY181268	PANEL BLINKER MTG FR LH	Bajaj spare parts
JY181269	PANEL BLINKER MTG FR RH	Bajaj spare parts
JY181270	BOLT M8 X 20L	Bajaj spare parts
JY181272	COVER POSITION LAMP	Bajaj spare parts
JY181276	COVER HT COIL	Bajaj spare parts
JY181278	BRACKET BELLY PAN REAR	Bajaj spare parts
JY181279	SCREW SELF TAPPING (DIA 5) BLK	Bajaj spare parts
JY181282	RUBBER PAD LH	Bajaj spare parts
JY181283	RUBBER PAD RH	Bajaj spare parts
JY181284	WASHER NYLON	Bajaj spare parts
JY181285	BOLT SOCKET SPECIAL HEAD M6X1PX10L	Bajaj spare parts



JY181288	SCREW SELF TAP DIA 6 X 30L BLK	Bajaj spare parts
JY181289	SLEEVE BATTERY MTG CASE	Bajaj spare parts
JY181292	BOLT STEP M6	Bajaj spare parts
JY181297	SCREW SELF TAPING DIA 5XL18 BLK	Bajaj spare parts
JY181298	WASHER SIDE FAIRING	Bajaj spare parts
JY181299	COVER FAIRING COUPLER	Bajaj spare parts
JY181300	HUGGER ENVELOPE	Bajaj spare parts
JY181306	BRACKET CANISTER MTG MY16	Bajaj spare parts
JY181309	BELLY PAN CENTRAL	Bajaj spare parts
JY181310	GROMMET BELLY PAN CENTRAL	Bajaj spare parts
JY181312	SLEEVE	Bajaj spare parts
JY181314	RUBBER BAND	Bajaj spare parts
JY181315	CANISTER RUBBER DAMPER	Bajaj spare parts
JY181316	FLAP PROTECTOR SHOCKER	Bajaj spare parts
JY181327	BRACKET DRAIN TUBE	Bajaj spare parts
JY181350	COVER TANK	Bajaj spare parts
JY181353	COWL SEAT TOP	Bajaj spare parts
JY181356	BELLY PAN MIDDLE	Bajaj spare parts
JY181358	TRAY UNDER	Bajaj spare parts
JY181359	SHROUD RADIATOR	Bajaj spare parts
JY181371	BELLY PAN	Bajaj spare parts
JY181372	BELLY PAN FRONT	Bajaj spare parts
JY181374	BELLY PAN	Bajaj spare parts
JY181377	BRACKET BELLY PAN UPPER	Bajaj spare parts
JY181378	BRACKET BELLY PAN LOWER	Bajaj spare parts
JY181379	BRACKET BELLY PAN FRONT	Bajaj spare parts
JY181380	BRACKET BELLY PAN REAR	Bajaj spare parts
JY181381	COVER ECU	Bajaj spare parts
JY181382	CARRIER COVER TANK	Bajaj spare parts
JY181384	COVER LOCK SEAT	Bajaj spare parts
JY181385	COVER REAR	Bajaj spare parts
JY181387	STRUCTURE FAIRING LH	Bajaj spare parts
JY181388	STRUCTURE FAIRING RH	Bajaj spare parts
JY181392	FLAP SPEEDOMETER LH	Bajaj spare parts
JY181393	FLAP SPEEDOMETER RH	Bajaj spare parts
JY181399	BRACKET ASSY BELLY PAN MIDDLE	Bajaj spare parts
JY181400	ASSLY FRONT FENDER	Bajaj spare parts
JY181401	FRONT FENDER FRONT	Bajaj spare parts
JY181402	FRONT FENDER REAR	Bajaj spare parts
JY181404	CUP WASHER FRONT FENDER MTG BLK	Bajaj spare parts
JY181405	COVER MUD REAR	Bajaj spare parts
JY181408	FRONT FENDER REAR DOMESTIC	Bajaj spare parts
JY181410	MUDFLAP FRONT FENDER	Bajaj spare parts
JY181419	FENDER FRONT	Bajaj spare parts
JY181421	FENDER FRONT REAR	Bajaj spare parts

JY181423	FENDER HUGGER FRONT	Bajaj spare parts
JY181424	PROTECTOR FORK INNER LH	Bajaj spare parts
JY181425	PROTECTOR FORK INNER RH	Bajaj spare parts
JY181700	COVER CATALYST	Bajaj spare parts
JY181701	FLAP COWL SEAT LH	Bajaj spare parts
JY181702	FLAP COWL SEAT RH	Bajaj spare parts
JY181705	BRACKET ASSY BELLY PAN MIDDLE	Bajaj spare parts
JY181707	BRACKET ASSEMBLY FAIRING MIDDLE	Bajaj spare parts
JY181709	PIN SPIGOT	Bajaj spare parts
JY181710	DAMPER WINDSHIELD LH	Bajaj spare parts
JY181714	DAMPER	Bajaj spare parts
JY181719	COVER SWITCH IGNITION	Bajaj spare parts
JY181721	COVER BRACKET TANK	Bajaj spare parts
JY181722	COVER CATALYST	Bajaj spare parts
JY181724	COVER ASSEMBLY CHAIN	Bajaj spare parts
JY181729	DAMPER WINDSHIELD RH	Bajaj spare parts
JY181738	BEADING	Bajaj spare parts
JY181739	PROTECTOR SHOCKABSORBER	Bajaj spare parts
JY181740	COLLAR	Bajaj spare parts
JY181741	BEADING LAMP HEAD	Bajaj spare parts
JY181742	COLLAR	Bajaj spare parts
JY181753	BEADING	Bajaj spare parts
JY181760	DAMPER	Bajaj spare parts
JY181761	BEADING RH	Bajaj spare parts
JY181762	COVER COIL IGNITION	Bajaj spare parts
JY181763	GROMMET	Bajaj spare parts
JY181764	BRACKET SPEEDOMETER	Bajaj spare parts
JY181768	BRACKET BELLY PAN REAR RH	Bajaj spare parts
JY181794	CONNECTOR SHROUD RADIATOR	Bajaj spare parts
JY181795	CONNECTOR SHROUD RADIATOR	Bajaj spare parts
JY184000	WINDSHIELD	Bajaj spare parts
JY184001	WINDSHIELD	Bajaj spare parts
JY191000	SEAT ASSLY FRONT	Bajaj spare parts
JY191007	GROMMET PILLION SEAT	Bajaj spare parts
JY191008	DAMPER SEAT	Bajaj spare parts
JY191010	SEAT ASSLY REAR DOMESTIC	Bajaj spare parts
JY191012	ASSLY SEAT DOM MY16	Bajaj spare parts
JY191018	SEAT ASSEMBLY FRONT	Bajaj spare parts
JY191025	SEAT ASSEMBLY PILLION	Bajaj spare parts
JY191032	DAMPER	Bajaj spare parts
JY191034	SEAT ASSEMBLY FRONT	Bajaj spare parts
JY191035	SEAT ASSEMBLY PILLION	Bajaj spare parts
JY231000	TOOL KIT RC	Bajaj spare parts
JY231009	BAND	Bajaj spare parts
JY231200	SAREE GAURD	Bajaj spare parts

JY231401	GRAB ASSLY RC	Bajaj spare parts
JY231402	SLEEVE PLATE HAND GUARD	Bajaj spare parts
JY231606	MIRROR ASSLY LH	Bajaj spare parts
JY231607	MIRROR ASSLY RH	Bajaj spare parts
JY231610	MIRROR RC LH	Bajaj spare parts
JY231611	MIRROR RH	Bajaj spare parts
JY231616	MIRROR WITHOUT BLINKER LH	Bajaj spare parts
JY231617	MIRROR WITHOUT BLINKER RH	Bajaj spare parts
JY231620	MIRROR LH	Bajaj spare parts
JY231621	MIRROR RH	Bajaj spare parts
JY232603	ASSLY BATTERY LEAD LOCK	Bajaj spare parts
JY232604	ASSLY SEAT LOCK FRONT	Bajaj spare parts
JY232605	SEAT LOCK CABLE	Bajaj spare parts
JY232607	LOCK SET THREE IN ONE	Bajaj spare parts
JY232613	LATCH ASSEMBLY SEAT	Bajaj spare parts
JY232803	GROMMET NUMBER PLATE STRUCTURE	Bajaj spare parts
JY232804	BRACKET NUMBER PLATE DOMESTIC	Bajaj spare parts
JY232806	BRACKET REFLEX REFLECTOR MTG	Bajaj spare parts
JY232807	BRACKET FRONT NUMBER PLATE MTG	Bajaj spare parts
JY232808	RUBBER PAD NUMBER PLATE MTG BKT	Bajaj spare parts
JY232814	STRUCTURE ASSLY PLATE NUMBER	Bajaj spare parts
JY232815	BRACKET PLATE NUMBER REAR	Bajaj spare parts
JY232819	COVER STRUCTURE PLATE NUMBER TOP	Bajaj spare parts
JY232820	COVER STRUCTURE PLATE NUMBER BTM	Bajaj spare parts
JY232821	STRUCTURE ASSEMBLY PLATE NUMBER	Bajaj spare parts
JY232824	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
JY232826	BRACKET PLATE NUMBER REAR	Bajaj spare parts
JY232829	HOLDER PLATE NUMBER FRONT	Bajaj spare parts
JY233000	DECAL BELLY PAN LH	Bajaj spare parts
JY233001	DECAL BELLY PAN RH	Bajaj spare parts
JY233004	DECAL SIDE FAIRING LH UPPER RC200	Bajaj spare parts
JY233005	DECAL SIDE FAIRING RH UPPER RC200	Bajaj spare parts
JY233006	DECAL SIDE FAIRING LH LOWER	Bajaj spare parts
JY233007	DECAL SIDE FAIRING RH LOWER	Bajaj spare parts
JY233008	DECAL TANK COVER LH	Bajaj spare parts
JY233009	DECAL TANK COVER RH	Bajaj spare parts
JY233010	DECAL TANK COVER TOP	Bajaj spare parts
JY233011	DECAL BELLY PAN LH	Bajaj spare parts
JY233012	DECAL BELLY PAN RH	Bajaj spare parts
JY233013	DECAL SIDE FAIRING LH	Bajaj spare parts
JY233014	DECAL SIDE FAIRING RH	Bajaj spare parts
JY233015	DECAL SET RC200	Bajaj spare parts
JY233017	DECAL TANK COVER LH	Bajaj spare parts
JY233018	DECAL TANK COFER RH	Bajaj spare parts
JY233019	DECAL SET RC125	Bajaj spare parts

JY233020	DECAL SET RC390	Bajaj spare parts
JY233041	TAPE ANTIABRASIVE	Bajaj spare parts
JY233083	DECAL OUTER SPOILER RC200 LH	Bajaj spare parts
JY233084	DECAL OUTER SPOILER RC200 RH	Bajaj spare parts
JY233093	DECAL UNDER TRAY RC200 LH	Bajaj spare parts
JY233094	DECAL UNDER TRAY RC200 RH	Bajaj spare parts
JY233095	DECAL TANK LOGO KT04/10 MY17	Bajaj spare parts
JY233096	DECAL SET RC125 MY 17	Bajaj spare parts
JY233102	DECAL INNER SPOILER LH KT06 MY17	Bajaj spare parts
JY233103	DECAL INNER SPOILER RH KT06 MY17	Bajaj spare parts
JY233104	DECAL OUTER SPOILER RC390 LH MY17	Bajaj spare parts
JY233105	DECAL OUTER SPOILER RC390 RH MY17	Bajaj spare parts
JY233106	DECAL BELLY PAN LH KT06 MY17	Bajaj spare parts
JY233107	DECAL BELLY PAN RH KT06 MY17	Bajaj spare parts
JY233108	DECAL TANK UPPER LH KT06 MY17	Bajaj spare parts
JY233109	DECAL TANK UPPER RH KT06 MY17	Bajaj spare parts
JY233110	DECAL TANK LOWER LH KT06 MY17	Bajaj spare parts
JY233111	DECAL TANK LOWER RH KT06 MY17	Bajaj spare parts
JY233114	DECAL UNDER TRAY RC390 LH	Bajaj spare parts
JY233115	DECAL UNDER TRAY RC390 RH	Bajaj spare parts
JY233116	DECAL TANK LOGO KT06 MY17	Bajaj spare parts
JY233118	DECAL SET 390	Bajaj spare parts
JY233120	DECAL BELLY PAN RH KT10 MY17	Bajaj spare parts
JY233123	DECAL SPOILER INNER LH	Bajaj spare parts
JY233124	DECAL SPOILER INNER RH	Bajaj spare parts
JY233125	DECAL BELLY PAN LH	Bajaj spare parts
JY233126	DECAL BELLY PAN RH	Bajaj spare parts
JY233127	DECAL TANK LOWER LH	Bajaj spare parts
JY233128	DECAL TANK LOWER RH	Bajaj spare parts
JY233129	DECAL TANK UPPER LH	Bajaj spare parts
JY233130	DECAL TANK UPPER RH	Bajaj spare parts
JY233131	DECAL TANK LOGO	Bajaj spare parts
JY233133	DECAL FAIRING OUTER LOWER LH	Bajaj spare parts
JY233134	DECAL FAIRING OUTER LOWER RH	Bajaj spare parts
JY233135	DECAL FAIRING OUTER UPPER LH	Bajaj spare parts
JY233136	DECAL FAIRING OUTER UPPER RH	Bajaj spare parts
JY233137	DECAL FAIRING OUTER UPPER LH	Bajaj spare parts
JY233138	DECAL FAIRING OUTER UPPER RH	Bajaj spare parts
JY233139	DECAL FAIRING SIDE LH	Bajaj spare parts
JY233140	DECAL FAIRING SIDE RH	Bajaj spare parts
JY233141	DECAL COVER TANK LH	Bajaj spare parts
JY233142	DECAL COVER TANK RH	Bajaj spare parts
JY233143	DECAL BELLY PAN LH	Bajaj spare parts
JY233144	DECAL BELLY PAN RH	Bajaj spare parts
JY233145	DECAL COVER TANK TOP	Bajaj spare parts

JY233155	DECAL FAIRING UPPER LH BLACK	Bajaj spare parts
JY233156	DECAL FAIRING UPPER RH BLACK	Bajaj spare parts
JY233157	DECAL FAIRING LOWER LH BLACK	Bajaj spare parts
JY233158	DECAL FAIRING LOWER RH BLACK	Bajaj spare parts
JY233159	DECAL SPOILER TANK LH BLACK	Bajaj spare parts
JY233160	DECAL SPOILER TANK RH BLACK	Bajaj spare parts
JY233161	DECAL BELLY PAN LH BLACK	Bajaj spare parts
JY233162	DECAL BELLY PAN RH BLACK	Bajaj spare parts
JY233163	DECAL TANK UPPER LH BLACK	Bajaj spare parts
JY233164	DECAL TANK UPPER RH BLACK	Bajaj spare parts
JY233165	DECAL TANK LOWER LH BLACK	Bajaj spare parts
JY233166	DECAL TANK LOWER RH BLACK	Bajaj spare parts
JY233167	EMBLEM RC	Bajaj spare parts
JY233172	DECAL TANK LH WHITE	Bajaj spare parts
JY233173	DECAL TANK RH WHITE	Bajaj spare parts
JY233174	DECAL COVER TANK INNER LH WHITE	Bajaj spare parts
JY233175	DECAL COVER TANK INNER RH WHITE	Bajaj spare parts
JY233176	DECAL COVER TANK OUTER LH WHITE	Bajaj spare parts
JY233177	DECAL COVER TANK OUTER RH WHITE	Bajaj spare parts
JY233178	DECAL BELLY PAN LH WHITE	Bajaj spare parts
JY233179	DECAL BELLY PAN RH WHITE	Bajaj spare parts
JY233180	DECAL COWL SEAT LH WHITE	Bajaj spare parts
JY233181	DECAL COWL SEAT RH WHITE	Bajaj spare parts
JY233184	DECAL TANK LH ORANGE	Bajaj spare parts
JY233185	DECAL TANK RH ORANGE	Bajaj spare parts
JY233186	DECAL COVER TANK INNER LH ORANGE	Bajaj spare parts
JY233187	DECAL COVER TANK INNER RH ORANGE	Bajaj spare parts
JY233188	DECAL COVER TANK OUTER LH ORANGE	Bajaj spare parts
JY233189	DECAL COVER TANK OUTER RH ORANGE	Bajaj spare parts
JY233190	DECAL BELLY PAN LH ORANGE	Bajaj spare parts
JY233191	DECAL BELLY PAN RH ORANGE	Bajaj spare parts
JY233192	DECAL COWL SEAT LH ORANGE	Bajaj spare parts
JY233193	DECAL COWL SEAT RH ORANGE	Bajaj spare parts
JY233194	DECAL COVER TANK OUT L LR ORANGE	Bajaj spare parts
JY233195	DECAL COVER TANK OUT R LR ORANGE	Bajaj spare parts
JY233196	DECAL COVER TANK OUT L LR WHITE	Bajaj spare parts
JY233197	DECAL COVER TANK OUT R LR WHITE	Bajaj spare parts
JY233198	EMBLEM RC	Bajaj spare parts
JY233199	DECAL FENDER FRONT LH BLACK	Bajaj spare parts
JY233201	DECAL TANK LH BLACK	Bajaj spare parts
JY233202	DECAL TANK RH BLACK	Bajaj spare parts
JY233203	DECAL FAIRING SIDE INNER LH BLK	Bajaj spare parts
JY233204	DECAL FAIRING SIDE INNER RH BLK	Bajaj spare parts
JY233205	DECAL FAIRING SIDE UPPER LH BLK	Bajaj spare parts
JY233206	DECAL FAIRING SIDE UPPER RH BLK	Bajaj spare parts

JY233207	DECAL FAIRING SIDE LOWER LH BLK	Bajaj spare parts
JY233208	DECAL FAIRING SIDE LOWER RH BLK	Bajaj spare parts
JY233209	DECAL BELLY PAN LH BLACK	Bajaj spare parts
JY233210	DECAL BELLY PAN RH BLACK	Bajaj spare parts
JY233211	DECAL COWL SEAT LH BLACK	Bajaj spare parts
JY233212	DECAL COWL SEAT RH BLACK	Bajaj spare parts
JY233213	DECAL FENDER FRONT LH BLACK	Bajaj spare parts
JY233214	DECAL FENDER FRONT RH BLACK	Bajaj spare parts
JY233215	DECAL TANK LH BLACK	Bajaj spare parts
JY233216	DECAL TANK RH BLACK	Bajaj spare parts
JY233217	DECAL FAIRING SIDE INNER LH BLK	Bajaj spare parts
JY233218	DECAL FAIRING SIDE INNER RH BLK	Bajaj spare parts
JY233219	DECAL FAIRING SIDE UPPER LH BLK	Bajaj spare parts
JY233220	DECAL FAIRING SIDE UPPER RH BLK	Bajaj spare parts
JY233221	DECAL FAIRING SIDE LOWER LH BLK	Bajaj spare parts
JY233222	DECAL FAIRING SIDE LOWER RH BLK	Bajaj spare parts
JY233223	DECAL BELLY PAN LH BLACK	Bajaj spare parts
JY233224	DECAL BELLY PAN RH BLACK	Bajaj spare parts
JY233225	DECAL COWL SEAT LH BLACK	Bajaj spare parts
JY233226	DECAL COWL SEAT RH BLACK	Bajaj spare parts
JY233227	DECAL FENDER FRONT LH WHITE	Bajaj spare parts
JY233228	DECAL FENDER FRONT RH WHITE	Bajaj spare parts
JY233229	DECAL TANK LH WHITE	Bajaj spare parts
JY233230	DECAL TANK RH WHITE	Bajaj spare parts
JY233231	DECAL FAIRING SIDE INNER LH WHT	Bajaj spare parts
JY233232	DECAL FAIRING SIDE INNER RH WHT	Bajaj spare parts
JY233233	DECAL FAIRING SIDE UPPER LH WHT	Bajaj spare parts
JY233234	DECAL FAIRING SIDE UPPER RH WHT	Bajaj spare parts
JY233235	DECAL FAIRING SIDE LOWER LH WHT	Bajaj spare parts
JY233236	DECAL FAIRING SIDE LOWER RH WHT	Bajaj spare parts
JY233237	DECAL BELLY PAN LH WHITE	Bajaj spare parts
JY233238	DECAL BELLY PAN RH WHITE	Bajaj spare parts
JY233239	DECAL COWL SEAT LH WHITE	Bajaj spare parts
JY233240	DECAL COWL SEAT RH WHITE	Bajaj spare parts
JY233251	DECAL FAIRING SIDE UPPER LH	Bajaj spare parts
JY233252	DECAL FAIRING SIDE UPPER RH	Bajaj spare parts
JY233257	DECAL COWL SEAT LH	Bajaj spare parts
JY233258	DECAL COWL SEAT RH	Bajaj spare parts
JY233259	DECAL TANK LH	Bajaj spare parts
JY233260	DECAL TANK RH	Bajaj spare parts
JY233261	DECAL FAIRING SIDE INNER LH	Bajaj spare parts
JY233262	DECAL FAIRING SIDE INNER RH	Bajaj spare parts
JY233263	DECAL FAIRING SIDE UPPER LH	Bajaj spare parts
JY233264	DECAL FAIRING SIDE UPPER RH	Bajaj spare parts
JY233265	DECAL FAIRING SIDE LOWER LH	Bajaj spare parts

JY233266	DECAL FAIRING SIDE LOWER RH	Bajaj spare parts
JY233267	EMBLEM RC	Bajaj spare parts
JY233268	DECAL FENDER FRONT RH	Bajaj spare parts
JY233269	DECAL FENDER FRONT LH	Bajaj spare parts
JY233275	DECAL FAIRING SIDE INR LH BLACK	Bajaj spare parts
JY233276	DECAL FAIRING SIDE INR RH BLACK	Bajaj spare parts
JY233279	DECAL RC BLACK	Bajaj spare parts
JY233286	DECAL FAIRING SIDE INR LH ORANGE	Bajaj spare parts
JY233287	DECAL FAIRING SIDE INR RH ORANGE	Bajaj spare parts
JY233294	DECAL RC ORANGE	Bajaj spare parts
JY233299	DECAL FAIRING SIDE INNER LH GREY	Bajaj spare parts
JY233300	DECAL FAIRING SIDE INNER RH GREY	Bajaj spare parts
JY233313	DECAL WHEEL	Bajaj spare parts
JY233341	DECAL FAIRING SIDE OUTER LH SLVR	Bajaj spare parts
JY233342	DECAL FAIRING SIDE OUTER RH SLVR	Bajaj spare parts
JY233352	DECAL FAIRING SIDE OUTER LH BLK	Bajaj spare parts
JY233353	DECAL FAIRING SIDE OUTER RH BLK	Bajaj spare parts
JY233363	DECAL FAIRING SIDE OUTER LH WH	Bajaj spare parts
JY233364	DECAL FAIRING SIDE OUTER RH WH	Bajaj spare parts
JY233374	DECAL FAIRING SIDE OUTER LH BLK	Bajaj spare parts
JY233375	DECAL FAIRING SIDE OUTER RH BLK	Bajaj spare parts
JY233425	DECAL KTM	Bajaj spare parts
JY233435	DECAL FAIRING SIDE OUTER LH	Bajaj spare parts
JY233436	DECAL FAIRING SIDE OUTER RH	Bajaj spare parts
JY233449	DECAL TANK BLACK	Bajaj spare parts
JY233462	DECAL FAIRING SIDE OUTER LH	Bajaj spare parts
JY233463	DECAL FAIRING SIDE OUTER RH	Bajaj spare parts
JY233478	DECAL KTM BLACK	Bajaj spare parts
JY234003	LABEL BOX FUSE	Bajaj spare parts
JY351006	MAGNETO ASSY COMPLETE	Bajaj spare parts
JY351007	STATOR ASSY	Bajaj spare parts
JY351008	STATOR ASSY	Bajaj spare parts
JY351011	ROTOR ASSY WITH CLUTCH ASSY	Bajaj spare parts
JY351015	STATOR ASSEMBLY	Bajaj spare parts
JY351019	ROTOR ASSLY W/O CLUTCH ASSLY	Bajaj spare parts
JY351023	STATOR ASSLY	Bajaj spare parts
JY351025	ROTOR ASSLY WITHOUT CLUTCH	Bajaj spare parts
JY351029	STATOR ASSLY	Bajaj spare parts
JY351032	STATOR ASSLY	Bajaj spare parts
JY351034	STATOR ASSLY	Bajaj spare parts
JY351036	STATOR ASSLY	Bajaj spare parts
JY351037	MAGNETO ASSEMBLY	Bajaj spare parts
JY351038	STATOR ASSEMBLY	Bajaj spare parts
JY351200	CAP SPARK PLUG	Bajaj spare parts
JY351203	GROMMET SPARK PLUG CAP	Bajaj spare parts

JY351205	SPARK PLUG	Bajaj spare parts
JY351206	PLUG SPARK	Bajaj spare parts
JY351400	ASSLY ENGINE CONTROL UNIT	Bajaj spare parts
JY351417	ENGINE CONTROL UNIT MY16	Bajaj spare parts
JY351604	STARTER MOTOR ASSY	Bajaj spare parts
JY351607	STARTER MOTOR ASSLY	Bajaj spare parts
JY351608	MOTOR STARTER	Bajaj spare parts
JY351800	SENSOR ASSEMBLY PICK UP	Bajaj spare parts
JY351801	GEAR INDICATION SENSOR	Bajaj spare parts
JY401002	LAMP TAIL	Bajaj spare parts
JY401006	POSITION LAMP	Bajaj spare parts
JY401007	INDICATOR ASSY FR LH	Bajaj spare parts
JY401008	INDICATOR ASSY FR RH	Bajaj spare parts
JY401014	ASSLY LOW BEAM PROJECTOR	Bajaj spare parts
JY401015	ASSLY HIGH BEAM PROJECTOR	Bajaj spare parts
JY401018	ASSLY HEADLAMP COMPLETE	Bajaj spare parts
JY401019	SCREW PROJECTOR MTG	Bajaj spare parts
JY401020	SCREW 1 ADJUSTING PROJ MTG	Bajaj spare parts
JY401022	ASSLY HIGH BEAM PROJECTOR USA	Bajaj spare parts
JY401023	ASSLY HEADLAMP COMP USA	Bajaj spare parts
JY401024	INDICATOR ASSY RR LH	Bajaj spare parts
JY401025	INDICATOR ASSY RR RH	Bajaj spare parts
JY401026	REFLECTOR SIDE FRONT	Bajaj spare parts
JY401027	LAMP TAIL USA	Bajaj spare parts
JY401035	LAMP HEAD	Bajaj spare parts
JY401036	LAMP HEAD	Bajaj spare parts
JY401037	LAMP TAIL	Bajaj spare parts
JY401038	INDICATOR FRONT LH	Bajaj spare parts
JY401039	INDICATOR FRONT RH	Bajaj spare parts
JY401042	REFLECTOR REFLEX	Bajaj spare parts
JY401402	SWITCH CONTROL LH	Bajaj spare parts
JY401403	SWITCH CONTROL RH	Bajaj spare parts
JY401404	SWITCH CLUTCH	Bajaj spare parts
JY401405	SWITCH CONTROL RH DOMESTIC	Bajaj spare parts
JY401407	SWITCH CONTROL RH RC KT06 -MY16	Bajaj spare parts
JY401408	SWITCH SIDE STAND MY16	Bajaj spare parts
JY401410	RESISTOR UNIT	Bajaj spare parts
JY401415	HOLDER MAGNET	Bajaj spare parts
JY401418	SWITCH CONTROL LH	Bajaj spare parts
JY401421	SWITCH CONTROL RH	Bajaj spare parts
JY401423	SWITCH CONTROL RH	Bajaj spare parts
JY401425	SWITCH CLUTCH	Bajaj spare parts
JY401600	HORN	Bajaj spare parts
JY401801	BAND BATTERY	Bajaj spare parts
JY401804	CASE BATTERY	Bajaj spare parts



JY401805	BAND BATTERY	Bajaj spare parts
JY402000	REGULATOR ASSLY WITH CAPACITOR	Bajaj spare parts
JY402203	HARNESS WIRING KT04	Bajaj spare parts
JY402204	RUBBER DAMPER FUSE BOX (10+3)	Bajaj spare parts
JY402205	CABLE BATTERY TO EARTH	Bajaj spare parts
JY402207	HARNESS MAIN 390 FF USA	Bajaj spare parts
JY402209	HARNESS WIRING KT05 DOMESTIC	Bajaj spare parts
JY402210	CABLE RELAY TO MOTOR	Bajaj spare parts
JY402213	HARNESS WIRING MAIN MY16	Bajaj spare parts
JY402217	HARNESS MAIN RC 200 NON ABS	Bajaj spare parts
JY402218	HARNESS MAIN RC 200 NON ABS DOM	Bajaj spare parts
JY402229	EARTH CABLE RC MY16	Bajaj spare parts
JY402235	PIGTAIL PH-3 FUEL PUMP	Bajaj spare parts
JY402237	PIG TAIL BLINKER USA	Bajaj spare parts
JY402246	PIGTAIL COOLANT TEMP SENSOR RC MY16	Bajaj spare parts
JY402251	CAP HARNESS ECU	Bajaj spare parts
JY402258	HARNESS WIRING	Bajaj spare parts
JY402259	HARNESS WIRING	Bajaj spare parts
JY402260	HARNESS WIRING	Bajaj spare parts
JY402267	HARNESS WIRING	Bajaj spare parts
JY402268	CABLE EARTH	Bajaj spare parts
JY402269	CABLE RELAY-MOTOR STARTER	Bajaj spare parts
JY402270	HARNESS WIRING	Bajaj spare parts
JY402271	CLIP	Bajaj spare parts
JY402273	HARNESS WIRING	Bajaj spare parts
JY402279	HARNESS WIRING	Bajaj spare parts
JY402283	HARNESS WIRING	Bajaj spare parts
JY402401	SPEEDOMETER	Bajaj spare parts
JY402403	SPEEDOMETER KT06 USA	Bajaj spare parts
JY402404	SPEEDOMETER ASSLY RC-MY17	Bajaj spare parts
JY402405	SPEEDOMETER RC 200 NON ABS	Bajaj spare parts
JY402412	SPEEDOMETER	Bajaj spare parts
JY402415	SPEEDOMETER	Bajaj spare parts
JY402426	INSTRUMENT CLUSTER	Bajaj spare parts
JY403202	UNIT TERMINATION	Bajaj spare parts
JY403601	ASSLY WHEEL SPEED SENSOR FR	Bajaj spare parts
JY403604	SENSOR ROLL OVER MY16	Bajaj spare parts
JY501057	ENGINE ASSLY	Bajaj spare parts
JY511048	CYLINDER HEAD COVER	Bajaj spare parts
JY511058	GUIDE CHAIN TOP	Bajaj spare parts
JY511059	GASKET BREATHER	Bajaj spare parts
JY511060	PLATE BREATHER	Bajaj spare parts
JY511068	SLEEVE SPARK PLUG	Bajaj spare parts
JY511071	NOZZLE BREATHER	Bajaj spare parts
JY511073	PLUG	Bajaj spare parts

JY511074	GASKET SLEEVE SPARK PLUG	Bajaj spare parts
JY511127	COVER CYLINDER HEAD	Bajaj spare parts
JY511128	GASKET RUBBER - D	Bajaj spare parts
JY511137	HEAD CYLINDER WITH CAMHOLDER	Bajaj spare parts
JY511139	GASKET HEAD CYLINDER	Bajaj spare parts
JY511141	COVER HEAD CYLINDER	Bajaj spare parts
JY511142	PIPE BREATHER	Bajaj spare parts
JY511144	HEAD CYLINDER-HOLDER CAMSHAFT	Bajaj spare parts
JY511149	GASKET HEAD CYLINDER	Bajaj spare parts
JY511212	ROCKER ARM DECOMP	Bajaj spare parts
JY511214	SPRING DECOMP	Bajaj spare parts
JY511215	PIN DECOMP	Bajaj spare parts
JY511217	PIN PIVOT DECOMP	Bajaj spare parts
JY511219	SPROCKET CAMSHAFT	Bajaj spare parts
JY511220	CHAIN TIMING	Bajaj spare parts
JY511221	VALVE INTAKE	Bajaj spare parts
JY511222	VALVE EXHAUST	Bajaj spare parts
JY511223	SEAT VALVE SPRING	Bajaj spare parts
JY511224	VALVE SPRING OUTER	Bajaj spare parts
JY511225	RETAINER VALVE SPRING	Bajaj spare parts
JY511226	ROCKER ARM SHAFT	Bajaj spare parts
JY511227	GUIDE CHAIN SLACK SIDE	Bajaj spare parts
JY511229	GUIDE CHAIN TIGHT SIDE	Bajaj spare parts
JY511231	SHIM	Bajaj spare parts
JY511234	CAMSHAFT EXHAUST ASSLY	Bajaj spare parts
JY511236	VALVE SPRING INNER	Bajaj spare parts
JY511238	TENSIONER ASSLY	Bajaj spare parts
JY511248	INTAKE VALVE	Bajaj spare parts
JY511249	EXHAUST VALVE	Bajaj spare parts
JY511259	RETAINER SPRING DECOMP	Bajaj spare parts
JY511270	CAM SHAFT EXHAUST	Bajaj spare parts
JY511271	SPROCKET CAMSHAFT	Bajaj spare parts
JY511274	CAMSHAFT INTAKE ASSY	Bajaj spare parts
JY511276	CAMSHAFT EXHAUST ASSY	Bajaj spare parts
JY521006	GASKET CYLINDER BLOCK	Bajaj spare parts
JY521012	CYLINDER BLOCK KT10	Bajaj spare parts
JY521021	BLOCK CYLINDER	Bajaj spare parts
JY521214	PISTON ASSLY CPL	Bajaj spare parts
JY521220	RING SNAP	Bajaj spare parts
JY521223	PISTON ASSLY CPL	Bajaj spare parts
JY521226	PISTON ASSLY-KT10	Bajaj spare parts
JY521236	CIRCLIP	Bajaj spare parts
JY531005	BOLT CON ROD	Bajaj spare parts
JY531006	BUSH BIMETALLIC	Bajaj spare parts
JY531008	WASHER PLAIN	Bajaj spare parts

JY531021	CRANKSHAFT ASSLY COMP	Bajaj spare parts
JY531024	CONROD ASSLY	Bajaj spare parts
JY531026	SPROCKET CRANKSHAFT(18T)	Bajaj spare parts
JY531033	CONROD ASSY	Bajaj spare parts
JY531036	CONROD ASSLY WITH BUSH	Bajaj spare parts
JY531045	CONROD ASSEMBLY	Bajaj spare parts
JY531060	CRANKSHAFT ASSLY COMPLETE	Bajaj spare parts
JY531061	CRANKSHAFT ASSEMBLY	Bajaj spare parts
JY531063	ASSLY CONROD	Bajaj spare parts
JY531213	BALANCER ASSLY	Bajaj spare parts
JY531221	BALANCER SHAFT	Bajaj spare parts
JY541009	BOLT SPECIAL PIVOT GUIDE CHAIN	Bajaj spare parts
JY541016	PLATE HARNESS	Bajaj spare parts
JY541024	JET EVACUATION OIL	Bajaj spare parts
JY541029	OIL NOZZLE HEAD	Bajaj spare parts
JY541031	CHAIN GUARD	Bajaj spare parts
JY541034	BUSH STARTER SHAFT	Bajaj spare parts
JY541036	CRANKCASE ASSY RH	Bajaj spare parts
JY541038	BUSH	Bajaj spare parts
JY541039	SPRING	Bajaj spare parts
JY541040	RETAINER GEAR STARTER	Bajaj spare parts
JY541042	BRACKET HARNESS	Bajaj spare parts
JY541047	STOPPER I/P SHAFT BEARING	Bajaj spare parts
JY541050	JET OIL	Bajaj spare parts
JY541051	JET EVAC	Bajaj spare parts
JY541052	JET TRANS	Bajaj spare parts
JY541053	BRACKET HARNESS GI SWITCH	Bajaj spare parts
JY541058	OIL SEAL	Bajaj spare parts
JY541068	CRANKCASE LH	Bajaj spare parts
JY541071	PLATE HARNESS 2	Bajaj spare parts
JY541077	PIPE BREATHER	Bajaj spare parts
JY541078	ASSLY CRANKCASE RH	Bajaj spare parts
JY541080	PLATE HARNESS	Bajaj spare parts
JY541081	BRACKET HARNESS	Bajaj spare parts
JY541082	BRACKET HARNESS GI SWITCH	Bajaj spare parts
JY541083	CRANKCASE ASSLY RH	Bajaj spare parts
JY541084	CRANKCASE RH	Bajaj spare parts
JY541206	CAP CRANK CENTRE	Bajaj spare parts
JY541208	BRACKET HARNESS MAGNETO	Bajaj spare parts
JY541209	BRACKET CLUTCH CABLE	Bajaj spare parts
JY541213	CLUTCH COVER ASSLY COMP	Bajaj spare parts
JY541214	GASKET MAGNETO COVER	Bajaj spare parts
JY541217	SHAFT CLUTCH RELEASE ASSLY	Bajaj spare parts
JY541218	COVER MAGNETO	Bajaj spare parts
JY541219	MAGNETO COVER ASSY CPL	Bajaj spare parts

JY541220	PLATE OIL SEAL	Bajaj spare parts
JY541221	SPRING LEVER CLUTCH	Bajaj spare parts
JY541222	PLATE HARNESS MAGNETO	Bajaj spare parts
JY541225	GASKET CLUTCH COVER	Bajaj spare parts
JY541227	COVER LH RR	Bajaj spare parts
JY541231	JET STATOR	Bajaj spare parts
JY541236	CLUTCH COVER ASSY COMP	Bajaj spare parts
JY541238	MAGNETO COVER WITH PLUG	Bajaj spare parts
JY541240	MAGNETO COVER ASSY CPL	Bajaj spare parts
JY541244	Magneto Cover	Bajaj spare parts
JY541245	CLUTCH COVER with stopper	Bajaj spare parts
JY541251	SHAFT CLUTCH RELEASE ASSY	Bajaj spare parts
JY541253	BRACKET CLUTCH CABLE	Bajaj spare parts
JY541254	CLUTCH COVER ASSLY	Bajaj spare parts
JY541255	JET OIL	Bajaj spare parts
JY541258	COVER ASSEMBLY MAGNETO	Bajaj spare parts
JY541267	CLUTCH COVER WITH PLUG	Bajaj spare parts
JY541276	GASKET MAGNETO COVER	Bajaj spare parts
JY541284	COVER ASSLY MAGNETO	Bajaj spare parts
JY541286	COVER ASSLY MAGNETO	Bajaj spare parts
JY541294	COVER ASSEMBLY MAGNETO	Bajaj spare parts
JY551005	WASHER THRUST 3RD DRIVEN	Bajaj spare parts
JY551006	BUSH 2ND DRIVEN	Bajaj spare parts
JY551008	SHAFT OUTPUT ASSLY WITH PLUG	Bajaj spare parts
JY551010	BUSH V DRIVE	Bajaj spare parts
JY551015	COLLAR SPROCKET	Bajaj spare parts
JY551018	O RING SPROCKET COLLAR	Bajaj spare parts
JY551019	WASHER PLAIN	Bajaj spare parts
JY551021	BUSH VI DRIVE	Bajaj spare parts
JY551022	SHAFT INPUT	Bajaj spare parts
JY551023	SHAFT I/P TRANSM ASSLY	Bajaj spare parts
JY551024	SHAFT O/P TRANSM ASSLY	Bajaj spare parts
JY551027	BUSH 3RD DRIVEN	Bajaj spare parts
JY551029	SPROCKET DRIVE	Bajaj spare parts
JY551030	PLATE SPROCKET DRIVE	Bajaj spare parts
JY551205	BUSH 1 ST DRIVEN	Bajaj spare parts
JY551212	GEAR PRIMARY DRIVE	Bajaj spare parts
JY551214	CIRCLIP EXTERNAL I/P SHAFT	Bajaj spare parts
JY551215	WASHER THRUST 2D DRIVE	Bajaj spare parts
JY551217	WASHER THRUST 1ST DRIVEN	Bajaj spare parts
JY551218	CIRCLIP EXTERNAL O/P SHAFT	Bajaj spare parts
JY551220	GEAR BALANCER DRIVE	Bajaj spare parts
JY551221	GEAR STARTER CLUTCH	Bajaj spare parts
JY551225	GEAR STARTER COUNTER 2	Bajaj spare parts
JY551226	GEAR STARTER COUNTER 1 ASSLY	Bajaj spare parts

JY551228	GEAR 2ND DRIVE	Bajaj spare parts
JY551229	GEAR 3RD-4TH DRIVE	Bajaj spare parts
JY551230	GEAR 5TH DRIVE	Bajaj spare parts
JY551231	GEAR 6TH DRIVE	Bajaj spare parts
JY551232	GEAR 1ST DRIVEN	Bajaj spare parts
JY551233	GEAR 2ND DRIVEN	Bajaj spare parts
JY551234	GEAR 3RD DRIVEN	Bajaj spare parts
JY551235	GEAR 4TH DRIVEN	Bajaj spare parts
JY551236	GEAR 5TH DRIVEN	Bajaj spare parts
JY551237	GEAR 6TH DRIVEN	Bajaj spare parts
JY551240	SPROCKET DRIVE	Bajaj spare parts
JY551401	BUSH COLLARED	Bajaj spare parts
JY551402	CLUTCH ONE WAY ASSLY	Bajaj spare parts
JY551403	CLUTCH WASHER	Bajaj spare parts
JY551404	ROD PULL	Bajaj spare parts
JY551408	HOUSING CLUTCH ASSY CPL	Bajaj spare parts
JY551413	BOLT(M6*25)	Bajaj spare parts
JY551417	PLATE CLUTCH	Bajaj spare parts
JY551418	DISC FRICTION- A	Bajaj spare parts
JY551420	DISC FRICTION - C	Bajaj spare parts
JY551421	PLATE CLUTCH PRESSURE	Bajaj spare parts
JY551426	SEAT JUDDER SPRING	Bajaj spare parts
JY551427	SPRING JUDDER	Bajaj spare parts
JY551432	SPRING A CLUTCH DAMPER	Bajaj spare parts
JY551434	CLUTCH CENTER ASSY	Bajaj spare parts
JY551435	CLUTCH CENTER	Bajaj spare parts
JY551436	PLATE A CLUTCH	Bajaj spare parts
JY551437	PLATE B CLUTCH	Bajaj spare parts
JY551438	PLATE CLUTCH PRESSURE	Bajaj spare parts
JY551439	SPRING CLUTCH	Bajaj spare parts
JY551440	SEAT SPRING	Bajaj spare parts
JY551441	SPRING JUDDER	Bajaj spare parts
JY551442	SPRING SEAT JUDDER	Bajaj spare parts
JY551443	PLATE STOPPER	Bajaj spare parts
JY551447	SPRING CLUTCH	Bajaj spare parts
JY551448	BRACKET CLUTCH CABLE	Bajaj spare parts
JY551450	SHAFT CLUTCH RELEASE ASSLY	Bajaj spare parts
JY551455	BRACKET CABLE CLUTCH	Bajaj spare parts
JY561001	DRUM GEAR SHIFT	Bajaj spare parts
JY561002	FORK GEAR SHIFT INPUT	Bajaj spare parts
JY561004	SHAFT INPUT GEAR SHIFT FORK	Bajaj spare parts
JY561007	SHAFT OUTPUT FORK SHIFT	Bajaj spare parts
JY561008	FORKSHIFT OUTPUT	Bajaj spare parts
JY561013	DRUM GEAR SHIFT	Bajaj spare parts
JY561204	LEVER COMP CHANGE SHAFT	Bajaj spare parts

JY561205	LEVER GEAR SHIFT ASSLY CPL	Bajaj spare parts
JY561211	LEVER ASSEMBLY CHANGE	Bajaj spare parts
JY561213	ROD ASSEMBLY TIE	Bajaj spare parts
JY571008	STRAINER EVACAUTION	Bajaj spare parts
JY571009	CAP STRAINER EVACUATION	Bajaj spare parts
JY571012	OIL PUMP ASSLY COMP	Bajaj spare parts
JY571015	PUMP EVACUATION ASSLY	Bajaj spare parts
JY571023	GEAR OIL PUMP DRIVE	Bajaj spare parts
JY571024	SHAFT OIL PUMP	Bajaj spare parts
JY571027	STRAINER EVACUATION ASSLY	Bajaj spare parts
JY571029	OIL RAIL	Bajaj spare parts
JY571030	MESH STRAINER ASSLY	Bajaj spare parts
JY571033	CAP OIL FILTER	Bajaj spare parts
JY581003	TUBE BREATHER	Bajaj spare parts
JY581011	ASSLY AIR FILTER CPL	Bajaj spare parts
JY581014	ENTRY DUCT	Bajaj spare parts
JY581016	CLAMP	Bajaj spare parts
JY581018	ASSLY TOP COVER	Bajaj spare parts
JY581019	GARTER SPRING	Bajaj spare parts
JY581024	ASSLY AIR FILTER	Bajaj spare parts
JY581026	TUBE OIL RETURN	Bajaj spare parts
JY581028	CLAMP	Bajaj spare parts
JY581044	TUBE DRAIN	Bajaj spare parts
JY581052	BREATHER TUBE	Bajaj spare parts
JY581054	TUBE DRAIN	Bajaj spare parts
JY581056	OIL RETURN TUBE	Bajaj spare parts
JY581065	PLUG DRAIN	Bajaj spare parts
JY581068	ASSLY TOP BOTTOM COVERS	Bajaj spare parts
JY581069	AIR FILTER ASSLY INJECTION MOULDING	Bajaj spare parts
JY581071	ASSLY AIR FILTER	Bajaj spare parts
JY581072	BREATHER TUBE	Bajaj spare parts
JY581075	COVER ASSLY TOP	Bajaj spare parts
JY581079	ASSLY AIR FILTER COMPLETE	Bajaj spare parts
JY581096	TUBE CONNECTING	Bajaj spare parts
JY581097	DUCT INTAKE	Bajaj spare parts
JY581101	FILTER ASSEMBLY AIR	Bajaj spare parts
JY581102	TUBE CONNECTING	Bajaj spare parts
JY581104	FILTER ASSEMBLY AIR	Bajaj spare parts
JY581105	TUBE CONNECTING	Bajaj spare parts
JY581106	COVER SENSOR	Bajaj spare parts
JY581200	PIPE INTAKE	Bajaj spare parts
JY581201	CAP INJECTOR	Bajaj spare parts
JY581404	O RING INTAKE PIPE	Bajaj spare parts
JY581405	CLAMP INTAKE PIPE	Bajaj spare parts
JY591009	MUFFLER SUB ASSLY	Bajaj spare parts

JY591014	GASKET MUFFLER PIPE A	Bajaj spare parts
JY591015	BAND CLIP	Bajaj spare parts
JY591032	PIPE A EXHAUST ASSLY	Bajaj spare parts
JY591047	ASSLY END CAP	Bajaj spare parts
JY591050	BRACKET BELLY PAN MOUNTING	Bajaj spare parts
JY591074	SILENCER SUB ASSEMBLY	Bajaj spare parts
JY591114	SILENCER SUB ASSLY	Bajaj spare parts
JY591151	SILENCER SUB ASSLY	Bajaj spare parts
JY591226	BRACKET MUFFLER	Bajaj spare parts
JY591245	BUSH MUFFLER	Bajaj spare parts
JY591246	DAMPER MUFFLER	Bajaj spare parts
JY591247	END CAP	Bajaj spare parts
JY591250	SILENCER SUB ASSLY	Bajaj spare parts
JY591251	SILENCER SUB ASSLY	Bajaj spare parts
JY591253	SILENCER SUB ASSLY	Bajaj spare parts
JY591258	BRACKET END CAP	Bajaj spare parts
JY591275	ASSLY EXHAUST PIPE A	Bajaj spare parts
JY591278	GASKET PIPE B	Bajaj spare parts
JY591279	CLAMP DIA 54	Bajaj spare parts
JY591280	ASSLY CAT	Bajaj spare parts
JY591286	GASKET PIPE C	Bajaj spare parts
JY591287	CLAMP DIA 60	Bajaj spare parts
JY591297	ASSLY SHIELD MUFFLER	Bajaj spare parts
JY591299	ASSLY PRE MUFFLER	Bajaj spare parts
JY591303	GROMMET SHIELD MUFFLER	Bajaj spare parts
JY591308	SHIELD STARTER MOTOR	Bajaj spare parts
JY591336	SILENCER SUB ASSEMBLY	Bajaj spare parts
JY591350	ASSEMBLY MUFFLER	Bajaj spare parts
JY591379	MUFFLER SUB ASSLY	Bajaj spare parts
JY591387	ASSEMBLY MUFFLER	Bajaj spare parts
JY591404	SHIELD ASSEMBLY MUFFLER	Bajaj spare parts
JY591424	ASSEMBLY MUFFLER PRIMARY	Bajaj spare parts
JY591431	MUFFLER ASSEMBLY SECONDARY	Bajaj spare parts
JY591434	PIPE ASSEMBLY A	Bajaj spare parts
JY591458	MUFFLER ASSEMBLY SECONDARY	Bajaj spare parts
JY601201	RADIATOR ASSEMBLY	Bajaj spare parts
JY601204	HOSE COOLANT	Bajaj spare parts
JY601208	RADIATOR	Bajaj spare parts
JY601214	PIPE COOLANT	Bajaj spare parts
JY601215	HOSE COOLANT	Bajaj spare parts
JY601217	ASSLY EXPANSION TANK	Bajaj spare parts
JY601224	COWL RADIATOR	Bajaj spare parts
JY601225	HOSE COOLANT-THERM TO RAD	Bajaj spare parts
JY601226	HOSE COOLANT-RAD TO T PIPE	Bajaj spare parts
JY601227	BUSH SILENT_RAD MTG	Bajaj spare parts

JY601228	HOSE THERMOSTAT TO RADIATOR	Bajaj spare parts
JY601229	HOSE RAD. TO COOLANT PIPE-T	Bajaj spare parts
JY601232	HOSE RADIATOR TO THERMOSTAT	Bajaj spare parts
JY601233	HOSE RADIATOR TO PIPE-T	Bajaj spare parts
JY601234	RADIATOR	Bajaj spare parts
JY601237	TUBE DRAIN	Bajaj spare parts
JY601238	BRACKET FAN ASSLY A	Bajaj spare parts
JY601239	BRACKET FAN ASSLY B	Bajaj spare parts
JY601240	BRACKET FAN ASSLY C	Bajaj spare parts
JY601241	FLANGE NUT	Bajaj spare parts
JY601244	ASSLY RADIATOR WITH COOLING	Bajaj spare parts
JY601245	ASSLY RADIATOR	Bajaj spare parts
JY601246	RADIATOR CORE	Bajaj spare parts
JY601248	BRACKET FAN MOUNTING A	Bajaj spare parts
JY601249	BRACKET FAN MOUNTING B	Bajaj spare parts
JY601250	BRACKET FAN MOUNTING	Bajaj spare parts
JY601257	RADIATOR FAN ASSLY	Bajaj spare parts
JY601261	RADIATOR FAN ASSLY	Bajaj spare parts
JY601264	RADIATOR	Bajaj spare parts
JY601266	PIPE THERMOSTAT-CONNECTOR	Bajaj spare parts
JY601267	PIPE THERMOSTAT-JOINT T	Bajaj spare parts
JY601270	TANK ASSEMBLY EXPANSION	Bajaj spare parts
JY601271	PIPE TANK EXPANSION-RADIATOR	Bajaj spare parts
JY601274	PIPE TANK EXPANSION-CONNECTOR	Bajaj spare parts
JY601277	PIPE	Bajaj spare parts
JY601280	TANK EXPANSION	Bajaj spare parts
JY601403	COVER FAN LH	Bajaj spare parts
JY611000	FUEL INJECTOR	Bajaj spare parts
JY611003	FUEL INJECTOR	Bajaj spare parts
JY611202	THROTTLE BODY ASSLY	Bajaj spare parts
JY611209	ASSLY THROTTLE BODY EVAP	Bajaj spare parts
JY611210	NOZZLE	Bajaj spare parts
JY611215	ASSLY THROTTLE BODY ELECT	Bajaj spare parts
JY611216	ASSLY INJ CAP WITH QC	Bajaj spare parts
JY611219	ASSEMBLY THROTTLE BODY	Bajaj spare parts
JY611223	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JY611224	ASSLY INJECTOR CAP WITH QC	Bajaj spare parts
JY611229	BODY THROTTLE ASSLY	Bajaj spare parts
JY611231	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JY611232	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JY611233	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JY611234	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
JY611235	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JY611236	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JY611238	PIPE RADIATOR-CONNECTOR	Bajaj spare parts



JY611239	BODY THROTTLE ASSEMBLY	Bajaj spare parts
JY621411	ASSLY GEAR STARTER CLUTCH	Bajaj spare parts
JY990400	UNIT ABS WET	Bajaj spare parts
JY990401	CABLE LAMP HEAD	Bajaj spare parts
JZ111029	FRAME ASSEMBLY	Bajaj spare parts
JZ111038	FRAME ASSEMBLY	Bajaj spare parts
JZ111231	FRAME ASSY COMP-D106 A	Bajaj spare parts
JZ111278	FRAME ASSLY COMPLETE	Bajaj spare parts
JZ111292	TAPE FRAME HEAD PIPE	Bajaj spare parts
JZ111295	FRAME ASSLY HF	Bajaj spare parts
JZ111296	FRAME ASSLY BF	Bajaj spare parts
JZ111298	FRAME ASSLY D125ST DOMESTIC	Bajaj spare parts
JZ111310	FRAME ASSLY	Bajaj spare parts
JZ111374	FRAME ASSLY	Bajaj spare parts
JZ111392	FRAME ASSEMBLY	Bajaj spare parts
JZ113001	STAY LH MAIN STEP	Bajaj spare parts
JZ113003	STAY RH MAIN STEP	Bajaj spare parts
JZ113005	HOLDER ASSY RH STEP	Bajaj spare parts
JZ113006	HOLDER LH STEP	Bajaj spare parts
JZ113007	HOLDER RH STEP	Bajaj spare parts
JZ113011	STAY RH MAIN STEPSTAY RH	Bajaj spare parts
JZ113013	HOLDER LH STEP	Bajaj spare parts
JZ113015	HOLDER LH STEP	Bajaj spare parts
JZ113017	HOLDER RH STEP	Bajaj spare parts
JZ113020	STAY LH MAIN STEP	Bajaj spare parts
JZ113021	STAY RH MAIN STEP	Bajaj spare parts
JZ113023	HOLDER STEP LH	Bajaj spare parts
JZ113026	HOLDER STEP RH	Bajaj spare parts
JZ113027	STEP MAIN LH	Bajaj spare parts
JZ113028	STEP MAIN RH	Bajaj spare parts
JZ113031	ASSLY PILLION STEP LH	Bajaj spare parts
JZ113032	ASSLY PILLION STEP RH	Bajaj spare parts
JZ113035	RUBBER FOOTREST	Bajaj spare parts
JZ113036	PIN MAIN STEP	Bajaj spare parts
JZ113039	SPRING TORSION	Bajaj spare parts
JZ113042	DAMPER SILENCER	Bajaj spare parts
JZ113045	GROMMET	Bajaj spare parts
JZ113047	STEP HOLDER LH	Bajaj spare parts
JZ113048	HOLDER LH STEP	Bajaj spare parts
JZ113049	ASSLY PILLION STEP LH	Bajaj spare parts
JZ113051	STEP HOLDER RH	Bajaj spare parts
JZ113052	HOLDER RH STEP	Bajaj spare parts
JZ113053	ASSLY PILLION STEP RH	Bajaj spare parts
JZ113055	STEP MAIN LH	Bajaj spare parts
JZ113056	ASSLY MAIN STEP LH	Bajaj spare parts

JZ113058	STEP MAIN RH	Bajaj spare parts
JZ113059	ASSLY MAIN STEP RH	Bajaj spare parts
JZ113061	RUBBER PAD STEP	Bajaj spare parts
JZ113062	ASSEMBLY PILLION STEP LH C	Bajaj spare parts
JZ113068	ASSLY PILLION STEP RH COMPLETE	Bajaj spare parts
JZ113087	HOLDER STEP PILLION LH	Bajaj spare parts
JZ113093	COLLAR	Bajaj spare parts
JZ113114	HOLDER STEP PILLION RH	Bajaj spare parts
JZ113203	STAND CENTER	Bajaj spare parts
JZ113204	STAND SIDE	Bajaj spare parts
JZ113205	SPRING CENTER STAND	Bajaj spare parts
JZ113206	DAMPER STAND CENTER	Bajaj spare parts
JZ113207	SHAFT STAND CENTER	Bajaj spare parts
JZ113209	SPRING STAND MAIN WITH	Bajaj spare parts
JZ113210	SPRING STAND SIDE WITH	Bajaj spare parts
JZ113211	COVER SPRING STAND SID	Bajaj spare parts
JZ113212	COVER STAND CENTER	Bajaj spare parts
JZ113214	SHAFT CENTER STAND	Bajaj spare parts
JZ113400	BKT COMP LH ENG FRON	Bajaj spare parts
JZ113402	ENGINE MTG BKT REAR	Bajaj spare parts
JZ113403	BKT COMP RH ENG FRON	Bajaj spare parts
JZ113405	BKT COMP ENG MTG TOP LH	Bajaj spare parts
JZ113410	BRKT ENG MTG REAR TOP	Bajaj spare parts
JZ113411	BRKT ENG MTG TOP LH	Bajaj spare parts
JZ113426	BRKT ENG MTG FRONT	Bajaj spare parts
JZ113435	ASSLY ENGINE MTG FRONT LH	Bajaj spare parts
JZ113436	ASSLY ENGINE MTG FRONT RH	Bajaj spare parts
JZ113800	TAPE CHASSIS GUS	Bajaj spare parts
JZ113802	HOOK CLUTCH CABLE	Bajaj spare parts
JZ113805	CAP FOR PIPE	Bajaj spare parts
JZ113806	CAP FOR SWING ARM PIVO	Bajaj spare parts
JZ113808	BRACKET MTG RELAY STAR	Bajaj spare parts
JZ113810	HOOK CLUTCH CABLE	Bajaj spare parts
JZ113813	COVER FOR SWITCH SIDE STAND	Bajaj spare parts
JZ113817	CAP FRAME END	Bajaj spare parts
JZ121013	CAP OIL LOCK	Bajaj spare parts
JZ121015	BRACKET UNDER COMP	Bajaj spare parts
JZ121019	ASSLY LEG LH	Bajaj spare parts
JZ121020	TUBE OUTER LH	Bajaj spare parts
JZ121021	ASSLY LEG RH	Bajaj spare parts
JZ121022	TUBE OUTER RH	Bajaj spare parts
JZ121027	FORK ASSY DIS 102	Bajaj spare parts
JZ121030	TUBE OUTER LH	Bajaj spare parts
JZ121031	TUBE OUTER RH	Bajaj spare parts
JZ121040	EN: FORK PIPE SPINNING	Bajaj spare parts

JZ121041	SEAT PIPE	Bajaj spare parts
JZ121042	CLAMP BRAKE HOSE	Bajaj spare parts
JZ121043	ASSLY FRONT FORK	Bajaj spare parts
JZ121046	FORK PIPE SPINNING	Bajaj spare parts
JZ121047	FORK ASSLY DRUM	Bajaj spare parts
JZ121055	ASSLY FRONT FORK - DISC	Bajaj spare parts
JZ121056	ASSLY FRONT FORK - DRUM	Bajaj spare parts
JZ121057	LEG ASSLY LH	Bajaj spare parts
JZ121058	LEG ASSLY RH	Bajaj spare parts
JZ121059	LEG OUTER LH	Bajaj spare parts
JZ121060	LEG OUTER RH	Bajaj spare parts
JZ121061	LEG ASSLY LH	Bajaj spare parts
JZ121062	LEG ASSLY RH	Bajaj spare parts
JZ121063	LEG OUTER LH	Bajaj spare parts
JZ121064	LEG OUTER RH	Bajaj spare parts
JZ121068	FORK ASSLY FRONT-DISC	Bajaj spare parts
JZ121069	FORK ASSLY FRONT-DRUM	Bajaj spare parts
JZ121070	FORK ASSLY LEG LH	Bajaj spare parts
JZ121071	FORK ASSLY LEG RH	Bajaj spare parts
JZ121072	FORK ASSLY LEG LH	Bajaj spare parts
JZ121073	FORK ASSLY LEG RH	Bajaj spare parts
JZ121090	FORK FRONT	Bajaj spare parts
JZ121092	FORK FRONT	Bajaj spare parts
JZ122001	ARM SWING ASSY	Bajaj spare parts
JZ122003	SHOCK ABSORBER MONO	Bajaj spare parts
JZ122005	SLIDER CHAIN	Bajaj spare parts
JZ122008	ADJUSTER CHAIN RH	Bajaj spare parts
JZ122010	SPACER SWING ARM	Bajaj spare parts
JZ122011	SHAFT SWING ARM	Bajaj spare parts
JZ122012	PLATE CHAIN ADJUSTER	Bajaj spare parts
JZ122041	ASSLY SWING ARM	Bajaj spare parts
JZ122042	CHAIN SLIDER	Bajaj spare parts
JZ122043	ADJUSTER CHAIN LH	Bajaj spare parts
JZ122044	ADJUSTER CHAIN RH	Bajaj spare parts
JZ122050	SHOCKABSORBER MONO	Bajaj spare parts
JZ122058	SHAFT SWING ARM	Bajaj spare parts
JZ122071	ARM ASSLY SWING	Bajaj spare parts
JZ122093	ARM ASSEMBLY SWING	Bajaj spare parts
JZ122109	ROD TORQUE	Bajaj spare parts
JZ131005	WHEEL FRONT MT 1.40X17	Bajaj spare parts
JZ131011	WHEEL FRONT 1.4X17 DRUM	Bajaj spare parts
JZ131012	WHEEL ALLOY 1.4X17-DISC-134PCD	Bajaj spare parts
JZ131014	WHEEL FRONT 1.4X17 DISC	Bajaj spare parts
JZ131026	WHEEL FRONT 1.4X17(DR)	Bajaj spare parts
JZ131028	WHEEL FRONT 1.4X17(DI)	Bajaj spare parts

JZ131037	WHEEL FRONT 1.85X17 TUBELESS	Bajaj spare parts
JZ131039	WHEEL FRONT DR-1.85X17	Bajaj spare parts
JZ131041	WHEEL FRONT-1.4X17-SILVER	Bajaj spare parts
JZ131042	WHEEL FRONT DRUM-1.4X17-SILVER	Bajaj spare parts
JZ131206	WHEEL BLACK (2.15X17-130 DR 5 SP)	Bajaj spare parts
JZ131213	WHEEL 1.6X17 DRUM BLACK	Bajaj spare parts
JZ131217	AXLE REAR	Bajaj spare parts
JZ131224	WHEEL REAR 1.6X17(DR)	Bajaj spare parts
JZ131244	COLLAR ASSY	Bajaj spare parts
JZ131245	AXLE REAR	Bajaj spare parts
JZ131261	WHEEL REAR 2.15X17-TUBELESS	Bajaj spare parts
JZ131265	WHEEL REAR 1.6X17-SILVER	Bajaj spare parts
JZ131286	WHEEL REAR 2.15X17	Bajaj spare parts
JZ131291	SPACER	Bajaj spare parts
JZ131601	CASE METER ASSY GEAR	Bajaj spare parts
JZ131605	CASE ASSY- METER GEAR	Bajaj spare parts
JZ131611	CASE METER ASSLY	Bajaj spare parts
JZ131615	PANEL BRAKE FRONT	Bajaj spare parts
JZ131803	LEVER CAM BRAKE FAB	Bajaj spare parts
JZ131807	PANEL ASSY REAR COMP	Bajaj spare parts
JZ131810	ROD BRAKE	Bajaj spare parts
JZ131811	SLEEVE	Bajaj spare parts
JZ131813	PANEL BRAKE REAR	Bajaj spare parts
JZ131817	DISC BRAKE-240 MM	Bajaj spare parts
JZ131818	DISC BRAKE - 200 MM	Bajaj spare parts
JZ131875	PIN ROD BRAKE	Bajaj spare parts
JZ131880	CLAMP BRAKE HOSE	Bajaj spare parts
JZ131884	BRAKE PANEL ASSLY FRONT	Bajaj spare parts
JZ131891	LEVER CAM BRAKE REAR	Bajaj spare parts
JZ131915	CAM ASSEMBLY BRAKE FRONT	Bajaj spare parts
JZ131916	LEVER CAM BRAKE FRONT	Bajaj spare parts
JZ131924	CALIPER ASSLY FRONT	Bajaj spare parts
JZ131926	PANEL BRAKE REAR	Bajaj spare parts
JZ131927	CAM ASSEMBLY BRAKE	Bajaj spare parts
JZ131949	DISC BRAKE DIA 240	Bajaj spare parts
JZ151000	FORK ASSY COMP DISC	Bajaj spare parts
JZ151004	TUBE OUTER LH	Bajaj spare parts
JZ151006	TUBE OUTER RH	Bajaj spare parts
JZ151011	HOLDER FORK UPPER	Bajaj spare parts
JZ151013	BRACKET UNDER ASSY	Bajaj spare parts
JZ151016	HANDLEBAR	Bajaj spare parts
JZ151018	GRIP HAND LH	Bajaj spare parts
JZ151019	HAND GRIP RH	Bajaj spare parts
JZ151023	HOLDER FORK UPPER	Bajaj spare parts
JZ151024	BLINKER MTG BKT	Bajaj spare parts

JZ151036	BRACKET UNDER ASSY	Bajaj spare parts
JZ151043	FORK DRUM DIS 125	Bajaj spare parts
JZ151044	ASSLY UPPER BRACKET	Bajaj spare parts
JZ151045	HOLDER FORK UPPER	Bajaj spare parts
JZ151059	TBE OUTER RH	Bajaj spare parts
JZ151061	TBE OUTER LH	Bajaj spare parts
JZ151064	GRIPHAND LH	Bajaj spare parts
JZ151065	GRIPHAND RH	Bajaj spare parts
JZ151069	WIGHT HANDLE BAR	Bajaj spare parts
JZ151070	HANDLE BAR	Bajaj spare parts
JZ151078	DAMPER HANDLE UPPER	Bajaj spare parts
JZ151079	DAMPER HANDLE LOWER	Bajaj spare parts
JZ151081	WASHER HEADPIPE BOTTOM	Bajaj spare parts
JZ151083	CAP STEERING	Bajaj spare parts
JZ151084	NUT STEERING	Bajaj spare parts
JZ151091	SEAL DUST	Bajaj spare parts
JZ161002	BRAKE PEDAL ASSY	Bajaj spare parts
JZ161004	ROD BRAKE	Bajaj spare parts
JZ161006	SLEEVE BRAKE RETURN SPRIN	Bajaj spare parts
JZ161009	PEDAL BRAKE	Bajaj spare parts
JZ161011	SHAFT LEVER BRAKE	Bajaj spare parts
JZ161019	PAD BRAKE PEDAL	Bajaj spare parts
JZ161023	HOLDER ASSY LEVER LH	Bajaj spare parts
JZ161024	DAMPER BRAKE LEVER	Bajaj spare parts
JZ161025	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
JZ161028	LEVER PIVOT BOLT	Bajaj spare parts
JZ161030	LEVER HOLDER ASSY LH	Bajaj spare parts
JZ161034	BRAKE PEDAL	Bajaj spare parts
JZ161042	COVER BOX DISTRIBUTION	Bajaj spare parts
JZ161043	PEDAL ASSEMBLY BRAKE	Bajaj spare parts
JZ161045	ROD BRAKE	Bajaj spare parts
JZ161051	SLEEVE	Bajaj spare parts
JZ161054	CAP	Bajaj spare parts
JZ161200	CLUTCH CABLE	Bajaj spare parts
JZ161201	CABLE ACCELERATOR	Bajaj spare parts
JZ161202	CABLE ACCELERATOR	Bajaj spare parts
JZ161203	CLUTCH CABLE	Bajaj spare parts
JZ161204	CABLE SPEEDOMETER	Bajaj spare parts
JZ161207	CABLE ACCELERATOR	Bajaj spare parts
JZ161208	CABLE CLUTCH	Bajaj spare parts
JZ161210	CABLE SPEEDOMETER	Bajaj spare parts
JZ161217	CABLE SEAT LOCK	Bajaj spare parts
JZ161221	CABLE ACCELERATOR	Bajaj spare parts
JZ161222	CABLE ACCELERATOR	Bajaj spare parts
JZ161224	CABLE CLUTCH	Bajaj spare parts

JZ161232	CABLE PEDAL-UNIT DISTRIBUTOR	Bajaj spare parts
JZ161233	CABLE UNIT DISTRIBUTOR-PANEL FR	Bajaj spare parts
JZ161236	CABLE THROTTLE	Bajaj spare parts
JZ161237	CABLE PEDAL-CYLINDER MASTER	Bajaj spare parts
JZ171004	CAP TANK FUEL	Bajaj spare parts
JZ171017	TAPE SEAT	Bajaj spare parts
JZ171020	BUSH VAPOUR	Bajaj spare parts
JZ171021	WASHER VAPOUR SEALING	Bajaj spare parts
JZ171055	STRAP CANISTER	Bajaj spare parts
JZ171124	GROMMET	Bajaj spare parts
JZ171807	ASSLY FUEL TAP	Bajaj spare parts
JZ171809	FUEL COCK ASSLY - IRAN	Bajaj spare parts
JZ171817	KNOB TANK FUEL	Bajaj spare parts
JZ171818	FILTER PAPER ELEMENT	Bajaj spare parts
JZ171822	PIPE FUEL - DOMESTIC	Bajaj spare parts
JZ171829	TUBE FUEL	Bajaj spare parts
JZ181001	DAMPER	Bajaj spare parts
JZ181003	WELL NUT M5 X 0.8P	Bajaj spare parts
JZ181004	FOAM STRIP	Bajaj spare parts
JZ181005	FOAM STRIP HEADLAMP KS	Bajaj spare parts
JZ181006	DAMPER FAIRING	Bajaj spare parts
JZ181007	HOLDER HANDLE	Bajaj spare parts
JZ181009	TUBE MTG REAR HUGGER	Bajaj spare parts
JZ181011	BRACKET HOSE CLAMP UPPER	Bajaj spare parts
JZ181012	HOLDER HANDLE LOWER RH	Bajaj spare parts
JZ181013	HOLDER HANDLE LOWER LH	Bajaj spare parts
JZ181016	HOLDER HANDLE LOWER LH	Bajaj spare parts
JZ181017	HOLDER HANDLE LOWER RH	Bajaj spare parts
JZ181018	HOLDER HANDLE	Bajaj spare parts
JZ181200	FLAP COWLING	Bajaj spare parts
JZ181201	COWLING	Bajaj spare parts
JZ181202	SEAT COWL ASSY	Bajaj spare parts
JZ181206	SCREW M5 X 21L	Bajaj spare parts
JZ181208	BKT COWLING LOWER	Bajaj spare parts
JZ181214	COVER ASSY CHAIN	Bajaj spare parts
JZ181233	ASSLY SEAT COWL	Bajaj spare parts
JZ181237	WINDSHIELD	Bajaj spare parts
JZ181238	COWLING ASSEMBLY	Bajaj spare parts
JZ181260	BRKT BLINKER MTG LH	Bajaj spare parts
JZ181261	BRKT BLINKER MTG RH	Bajaj spare parts
JZ181269	FLAP SEAT COWL LH	Bajaj spare parts
JZ181270	FLAP SEAT COWL RH	Bajaj spare parts
JZ181271	DAMPER COVER SIDE	Bajaj spare parts
JZ181273	FAIRING MOUNTING STRUCTURE	Bajaj spare parts
JZ181276	BRACKET HEADLAMP MTG UPPER	Bajaj spare parts

JZ181277	BRACKET HEADLAMP MTG LOWER	Bajaj spare parts
JZ181278	FAIRING ASSY FRONT - HF	Bajaj spare parts
JZ181281	FAIRING REAR LH - HF	Bajaj spare parts
JZ181282	FAIRING REAR RH - HF	Bajaj spare parts
JZ181283	BEZEL HF	Bajaj spare parts
JZ181284	BRACKET MTG FR NUMBER PLATE	Bajaj spare parts
JZ181290	BOLT SOCKET HEAD M5X.8X27L	Bajaj spare parts
JZ181292	SLEEVE FAIRING MTG HF	Bajaj spare parts
JZ181293	COWLING MTG BRACKET LH	Bajaj spare parts
JZ181294	COWLING MTG BRACKET RH	Bajaj spare parts
JZ181299	BRACKET NO. PLATE MTG	Bajaj spare parts
JZ181300	CASE CHAIN UPPER	Bajaj spare parts
JZ181301	CASE CHAIN LOWER	Bajaj spare parts
JZ181320	FOAM NUMBER PLATE FRONT	Bajaj spare parts
JZ181322	GROMMET SIDE COVER	Bajaj spare parts
JZ181323	BEADING SPEEDO FLAP	Bajaj spare parts
JZ181324	COLLAR LH VISOR MTG HF	Bajaj spare parts
JZ181325	COLLAR RH VISOR MTG HF	Bajaj spare parts
JZ181326	WELL NUT M5 X 0.8 P	Bajaj spare parts
JZ181338	BEADING CHAIN CASE	Bajaj spare parts
JZ181343	ASSLY CHAIN COVER	Bajaj spare parts
JZ181345	DAMPER RUBBER	Bajaj spare parts
JZ181346	DAMPER FAIRING	Bajaj spare parts
JZ181347	COVER SIDE LH	Bajaj spare parts
JZ181354	SLEEVE FAIRING MTG BOTTOM	Bajaj spare parts
JZ181355	FOAM STRIP 70X10X5	Bajaj spare parts
JZ181356	GROMMET FAIRING MTG	Bajaj spare parts
JZ181360	ASSLY WINDSHIELD	Bajaj spare parts
JZ181361	ASSLY SPEEDO FLAP	Bajaj spare parts
JZ181365	GROMMET	Bajaj spare parts
JZ181366	GROMMET FAIRING	Bajaj spare parts
JZ181401	REAR FENDER REAR	Bajaj spare parts
JZ181402	REAR FENDER FRONT	Bajaj spare parts
JZ181406	GROMMET SAREE GUARD	Bajaj spare parts
JZ181415	BRACE FENDER	Bajaj spare parts
JZ181416	FLAP FENDER FR	Bajaj spare parts
JZ181419	FENDER REAR RR	Bajaj spare parts
JZ181420	COVER MUD REAR	Bajaj spare parts
JZ181421	FLAP MUD COVER	Bajaj spare parts
JZ181442	FENDER REAR	Bajaj spare parts
JZ181443	HUGGER FRONT	Bajaj spare parts
JZ181460	RUBBER GROMMET	Bajaj spare parts
JZ181483	TAPE	Bajaj spare parts
JZ181703	COVER LINK CBS	Bajaj spare parts
JZ191000	SEAT ASSLY COMP	Bajaj spare parts

JZ191006	SEAT ASSEMBLY	Bajaj spare parts
JZ191010	DAMPER FOR SEAT	Bajaj spare parts
JZ191011	DAMPER SEAT REAR	Bajaj spare parts
JZ191030	SEAT ASSLY COMPLETE	Bajaj spare parts
JZ191032	DAMPER SEAT I	Bajaj spare parts
JZ231201	LEG GUARD	Bajaj spare parts
JZ231202	GUARD SARI	Bajaj spare parts
JZ231204	SMALL SAREE GUARD	Bajaj spare parts
JZ231211	GUARD LEG	Bajaj spare parts
JZ231212	GUARD SAREE	Bajaj spare parts
JZ231225	LEG GUARD	Bajaj spare parts
JZ231227	GUARD SAREE - D106	Bajaj spare parts
JZ231403	GRAB HANDLE	Bajaj spare parts
JZ231409	ASSEMBLY GRAB HANDLE	Bajaj spare parts
JZ231410	FOAM LH GRAB HANDLE	Bajaj spare parts
JZ231411	FOAM RH GRAB HANDLE	Bajaj spare parts
JZ231600	MIRROR ASSLY LH	Bajaj spare parts
JZ231601	MIRROR ASSLY RH	Bajaj spare parts
JZ232600	LOCK SET 3 IN 1	Bajaj spare parts
JZ232601	SET LOCK	Bajaj spare parts
JZ232800	BKT NUMBER PLATE	Bajaj spare parts
JZ232805	FOAM REAR NUMBER PLATE	Bajaj spare parts
JZ232810	FOAM NUMBER PLATE REAR	Bajaj spare parts
JZ232814	PAD RUBBER NUMBER PLATE BKT	Bajaj spare parts
JZ233000	KIT TANK DECAL DISCO H BL	Bajaj spare parts
JZ233005	KIT DECAL DISCO H BLACK B	Bajaj spare parts
JZ233012	KIT TANK DEC DIS B RED	Bajaj spare parts
JZ233017	KIT DECAL DISCO H BLACK R	Bajaj spare parts
JZ233024	DECAL TANKDIS H BL+BLU2	Bajaj spare parts
JZ233029	KIT DECAL DISCO H BL+BLUE	Bajaj spare parts
JZ233036	DECAL TANKDIS H BL+RED2	Bajaj spare parts
JZ233041	KIT DECAL DISCO H BL+RED2	Bajaj spare parts
JZ233070	DECAL TANK KIT BLACK2 GOL	Bajaj spare parts
JZ233075	DECAL KIT BLACK2 GOLD MCM	Bajaj spare parts
JZ233086	DECAL TANK KIT BL2 MGNTA	Bajaj spare parts
JZ233091	DECAL KIT BL2 MAGENTA RED	Bajaj spare parts
JZ233100	KIT DECAL BL GOLD DIS 125	Bajaj spare parts
JZ233145	KIT TANK DECAL D102 BLACK-BLUE	Bajaj spare parts
JZ233153	KIT TANK DECAL 102 BLACK-RED	Bajaj spare parts
JZ233161	KIT KIT TANK DECAL D102 BLUE	Bajaj spare parts
JZ233169	KIT TANK DECAL D102 RED	Bajaj spare parts
JZ233177	FAIRING DECAL B-LOGO	Bajaj spare parts
JZ233178	4 VALVE DECAL D102 SIDE COVER	Bajaj spare parts
JZ233200	ASSLY MADE IN INDIA PLATE	Bajaj spare parts
JZ233201	DECAL KIT TANK	Bajaj spare parts



JZ233213	DECAL KIT TANK	Bajaj spare parts
JZ233225	KIT TANK DECAL BL- RED	Bajaj spare parts
JZ233239	KIT TANK DECAL BLUE BLUE	Bajaj spare parts
JZ233251	KIT TANK DECAL GR-GREEN	Bajaj spare parts
JZ233263	KIT TANK DECAL-RED-RED	Bajaj spare parts
JZ233275	TANK 3D DECAL	Bajaj spare parts
JZ233300	DECAL KIT TANK BLACK RED	Bajaj spare parts
JZ233308	DECAL TANK KIT BLUE	Bajaj spare parts
JZ233314	DECAL TANK KIT GREEN	Bajaj spare parts
JZ233320	DECAL TANK KIT RED	Bajaj spare parts
JZ233326	DECAL 4 VALVE BLACK	Bajaj spare parts
JZ233327	DECAL 4 VALVE BLUE	Bajaj spare parts
JZ233328	DECAL 4 VALVE GREEN	Bajaj spare parts
JZ233329	DECAL 4 VALVE RED	Bajaj spare parts
JZ233362	DECAL KIT TANK-GOLD	Bajaj spare parts
JZ233370	KIT TANK DECAL	Bajaj spare parts
JZ233495	DECAL TANK 3D	Bajaj spare parts
JZ233532	DECAL COVER SIDE LH RED	Bajaj spare parts
JZ233533	DECAL COVER SIDE RH RED	Bajaj spare parts
JZ233564	DECAL COVER SIDE LH BLUE	Bajaj spare parts
JZ233565	DECAL COVER SIDE RH BLUE	Bajaj spare parts
JZ233570	DECAL 125	Bajaj spare parts
JZ351000	MAGNETO ASSLY DIS 125	Bajaj spare parts
JZ351001	ROTOR ASSLY D125	Bajaj spare parts
JZ351005	ROTOR ASSLY	Bajaj spare parts
JZ351006	ROTOR-CLUTCH ASSLY	Bajaj spare parts
JZ351029	ROTOR ASSEMBLY	Bajaj spare parts
JZ351205	DC CDI UNIT	Bajaj spare parts
JZ351206	CDI DIS 125	Bajaj spare parts
JZ351208	CDI DC UNIT D102A	Bajaj spare parts
JZ351211	COIL HT LH D102A	Bajaj spare parts
JZ351212	COIL HT WITH CAP RH D102A	Bajaj spare parts
JZ351213	COIL HT RH D102A	Bajaj spare parts
JZ351214	CDI D101B	Bajaj spare parts
JZ351215	CDI	Bajaj spare parts
JZ351801	SENSOR POSITION THROTTLE	Bajaj spare parts
JZ401000	BLINKER ASSLY FR LH	Bajaj spare parts
JZ401001	BLINKER FRONT RH	Bajaj spare parts
JZ401002	LAMP HEAD ASSEMBLY	Bajaj spare parts
JZ401006	LAMP TAIL ASSEMBLY	Bajaj spare parts
JZ401012	LAMP HEAD ASSEMBLY	Bajaj spare parts
JZ401013	HEAD LAMP CONTROL MODULE	Bajaj spare parts
JZ401015	HEADLAMPASS W/O BULB	Bajaj spare parts
JZ401026	ASSLY HEADLAMP	Bajaj spare parts
JZ401029	HARNESS WIRING HEADLAM	Bajaj spare parts

JZ401038	INDICATOR REAR LH	Bajaj spare parts
JZ401039	INDICATOR REAR RH	Bajaj spare parts
JZ401042	SPACER LAMP ILLUMINATI	Bajaj spare parts
JZ401043	HEAD LAMP W/O BULB	Bajaj spare parts
JZ401045	TAIL LAMP W/O BULB	Bajaj spare parts
JZ401046	BULB HOLDER WITH INLINE CABLES	Bajaj spare parts
JZ401071	INDICATOR FRONT LH	Bajaj spare parts
JZ401072	INDICATOR FRONT RH	Bajaj spare parts
JZ401073	INDICATOR REAR LH	Bajaj spare parts
JZ401074	INDICATOR REAR RH	Bajaj spare parts
JZ401077	REFLECTOR REFLEX	Bajaj spare parts
JZ401400	SWITCH IGN 2PT MTG	Bajaj spare parts
JZ401403	SWITCH CLUTCH (VB)	Bajaj spare parts
JZ401408	SWITCH CONTROL RH	Bajaj spare parts
JZ401410	SWITCH CONTROL LH	Bajaj spare parts
JZ401413	SWITCH CONTROL RH	Bajaj spare parts
JZ401600	HORN DC	Bajaj spare parts
JZ401801	BAND BATTERY 7AH	Bajaj spare parts
JZ401803	CASE BATTERY	Bajaj spare parts
JZ401804	BAND BATTERY	Bajaj spare parts
JZ401809	FOAM BATTERY 5 AH	Bajaj spare parts
JZ402000	REGULATOR DC WITH CAPA	Bajaj spare parts
JZ402002	REGULATOR ASSLY	Bajaj spare parts
JZ402200	HARNESS WIRING	Bajaj spare parts
JZ402202	EARTHING CABLE	Bajaj spare parts
JZ402204	HARNESS WIRING(SS)	Bajaj spare parts
JZ402209	HARNESS WIRING	Bajaj spare parts
JZ402213	HARNESS WIRING - KS	Bajaj spare parts
JZ402214	HARNESS WIRING	Bajaj spare parts
JZ402216	CAP (STARTER MOTOR)	Bajaj spare parts
JZ402217	CABLE STARTER RELAY TO MOTOR	Bajaj spare parts
JZ402218	CABLE TIE (WHITE COLOR L200)	Bajaj spare parts
JZ402227	HARNESS WIRING SS (DIG SPEEDO)	Bajaj spare parts
JZ402239	HARNESS WIRING D106 BF	Bajaj spare parts
JZ402240	HARNESS WIRING-SS	Bajaj spare parts
JZ402241	HARNESS WIRING WVTA	Bajaj spare parts
JZ402242	HARNESS WIRING	Bajaj spare parts
JZ402246	HARNESS WIRING -ARGENTINA	Bajaj spare parts
JZ402247	HARNESS WIRING -ARGENTINA	Bajaj spare parts
JZ402248	HARNESS WIRING	Bajaj spare parts
JZ402249	HARNESS WIRING	Bajaj spare parts
JZ402260	HARNESS WIRING	Bajaj spare parts
JZ402263	HARNESS WIRING BS-IV	Bajaj spare parts
JZ402264	HARNESS WIRING	Bajaj spare parts
JZ402403	INSTRUMENT CLUSTER	Bajaj spare parts

JZ402406	SPEEDOMETER	Bajaj spare parts
JZ402407	FUEL GAUGE MACHINE WITH DIAL	Bajaj spare parts
JZ402410	SPEEDOMETER ASSEMBLY	Bajaj spare parts
JZ402411	ASSLY SPEEDOMETER	Bajaj spare parts
JZ402413	SENSOR SPEED	Bajaj spare parts
JZ402414	SENSOR SPEED WITH CABLE	Bajaj spare parts
JZ402416	SENSOR SPEED ASSLY	Bajaj spare parts
JZ402422	SPEEDOMETER	Bajaj spare parts
JZ402600	GAUGE TANK FUEL	Bajaj spare parts
JZ402602	GAUGE FUEL TANK	Bajaj spare parts
JZ403601	MAGNET HOLDER (SIDE STAND SW)	Bajaj spare parts
JZ501009	ENGINE ASSLY D125 2V SILVER	Bajaj spare parts
JZ501024	ENGINE ASSEMBLY	Bajaj spare parts
JZ511004	CAM SHAFT COMP	Bajaj spare parts
JZ511016	GASKET CYLINDER HEAD	Bajaj spare parts
JZ511021	CYLINDER HEAD COVER COMP	Bajaj spare parts
JZ511029	ASSLY CYLINDER HEAD COVER D125 2V	Bajaj spare parts
JZ511202	SPRING VALVE	Bajaj spare parts
JZ511203	ARM ROCKER	Bajaj spare parts
JZ511222	SEAT SPRING VALVE	Bajaj spare parts
JZ521200	PISTON ASSY	Bajaj spare parts
JZ531006	GEAR PRIMARY DRIVE	Bajaj spare parts
JZ531007	CRANKSHAFT ASSY DIS 125	Bajaj spare parts
JZ541005	NOZZLE OIL JET	Bajaj spare parts
JZ541008	SCREW M6X1 OIL JET	Bajaj spare parts
JZ541021	CRANKCASE LH EXC DIS-H	Bajaj spare parts
JZ541202	COVER RR ES	Bajaj spare parts
JZ541209	COVER COMP MAG ASSY	Bajaj spare parts
JZ541214	CAP FILTER	Bajaj spare parts
JZ541226	COVER RR	Bajaj spare parts
JZ541235	ASSLY COVER LH RR D125 2V	Bajaj spare parts
JZ541237	LABEL GEAR SHIFT D125 2V	Bajaj spare parts
JZ541255	COVER ASSLY REAR	Bajaj spare parts
JZ541268	WINDOW GAUGE OIL	Bajaj spare parts
JZ541269	CIRCLIP	Bajaj spare parts
JZ551001	SHAFT INPUT T/M	Bajaj spare parts
JZ551003	SHAFT OUTPUT T/M	Bajaj spare parts
JZ551008	SHAFT OUTPUT FORG ROUTE	Bajaj spare parts
JZ551010	SHAFT INPUT W/O GUN HOLE	Bajaj spare parts
JZ551201	GEAR 3RD DRIVE	Bajaj spare parts
JZ551202	GEAR 4TH DRIVE	Bajaj spare parts
JZ551204	GEAR 1ST DRIVEN	Bajaj spare parts
JZ551205	BUSH 1ST DRIVEN	Bajaj spare parts
JZ551208	GEAR 4TH DRIVEN	Bajaj spare parts
JZ551211	GEAR 5TH DRIVEN FORG ROUT	Bajaj spare parts

JZ551212	GEAR 3RD DRIVEN FORG	Bajaj spare parts
JZ551213	GEAR 5TH DRIVE FORG ROUTE	Bajaj spare parts
JZ551403	CLUTCH HSG ASSLY HTTS DISCO-H	Bajaj spare parts
JZ551409	CLUTCH ASSLY COMP	Bajaj spare parts
JZ551412	SPRING CLUTCH FCC	Bajaj spare parts
JZ551413	CLUTCH ASSLY DIS 125	Bajaj spare parts
JZ551414	PLATE CLUTCH ASSLY DIS 1	Bajaj spare parts
JZ551415	SPRING CLUTCH DIS 125	Bajaj spare parts
JZ551417	PLATE FRICTION REDUCED HTTS	Bajaj spare parts
JZ561000	DRUM GEAR SHIFT COMP	Bajaj spare parts
JZ561002	FORK INPUT DISCO H	Bajaj spare parts
JZ561201	LEVER CHANGE ARM	Bajaj spare parts
JZ561402	LEVER CHANGE COMP	Bajaj spare parts
JZ561404	ROD TIE	Bajaj spare parts
JZ561405	BOOT LEVER CHANGE	Bajaj spare parts
JZ561407	BOOT ARM CHANGE	Bajaj spare parts
JZ561415	ASSLY GEAR SHIFT LEVER D125	Bajaj spare parts
JZ571000	PUMP OIL	Bajaj spare parts
JZ571001	GEAR DRIVEN + SHAFT OIL P	Bajaj spare parts
JZ581004	HOSE BREATHER	Bajaj spare parts
JZ581006	CONNECTING TUBE	Bajaj spare parts
JZ581007	FILTER AIR ASSY	Bajaj spare parts
JZ581009	FILTER AIR COVER.	Bajaj spare parts
JZ581010	. CATRIDGE AIR FI	Bajaj spare parts
JZ581011	FILTER AIR ELEMENT	Bajaj spare parts
JZ581012	HOSE DRAIN DISCO H	Bajaj spare parts
JZ581020	FILTER ASSY AIR DIS 10	Bajaj spare parts
JZ581021	COVER DIRTY SIDE	Bajaj spare parts
JZ581025	TUBE DRAIN	Bajaj spare parts
JZ581026	HOSE BREATHER AIR FILT	Bajaj spare parts
JZ581029	SEAL RING O	Bajaj spare parts
JZ581032	ELEMENT AIR FITLER DIS	Bajaj spare parts
JZ581040	ASSLY AIR FILTER D102C TX	Bajaj spare parts
JZ581050	DUCT INTAKE	Bajaj spare parts
JZ581056	ASSLY AIR FILTER D101B SAI	Bajaj spare parts
JZ581059	FILTER ASSEMBLY AIR	Bajaj spare parts
JZ581204	SLEEVE PTE 16 DISCO XCD	Bajaj spare parts
JZ581209	CARBURETTOR VM22	Bajaj spare parts
JZ581210	SLEEVE CARBURETOR	Bajaj spare parts
JZ581216	SPRING PV VM22 DISCO H	Bajaj spare parts
JZ581220	HOSE AV DRAIN DISCO H	Bajaj spare parts
JZ581222	JET NEEDLE VM22 DISCO H	Bajaj spare parts
JZ581227	CARBURETTOR DIS 125	Bajaj spare parts
JZ581228	ASSLY CARB BS26 DISCO-11	Bajaj spare parts
JZ581229	SLEEVE CARB	Bajaj spare parts

JZ581238	SLEEVE CARB D102C TX	Bajaj spare parts
JZ581240	ASSLY CARB D101B MANUAL CHOKE	Bajaj spare parts
JZ581241	ASSLY CARB D101B WITH EVAP	Bajaj spare parts
JZ581242	CARBURETTOR ASSLY	Bajaj spare parts
JZ581246	CARBURETTOR	Bajaj spare parts
JZ581248	CARBURETTOR	Bajaj spare parts
JZ581405	MANIFOLD CARB	Bajaj spare parts
JZ581407	ASSLY INTAKE MANIFOLD SAI D101B	Bajaj spare parts
JZ582400	HOSE INTAKE SAI D101B	Bajaj spare parts
JZ582401	HOSE MANIFOLD SAI D101B	Bajaj spare parts
JZ582404	HOSE CONNECTOR SAI D101B	Bajaj spare parts
JZ582405	TUBE METALLIC SAI D101B	Bajaj spare parts
JZ591043	SHIELD SILENCER	Bajaj spare parts
JZ591095	SHIELD MUFFLER	Bajaj spare parts
JZ591108	ASSEMBLY SILENCER WOUT CAT D125	Bajaj spare parts
JZ611000	INJECTOR	Bajaj spare parts
JZ621000	GEAR SPUR KICK START	Bajaj spare parts
JZ621002	SHAFT ASSY KICK	Bajaj spare parts
JZ621008	SPRING TORSION	Bajaj spare parts
JZ621200	KICK LEVER	Bajaj spare parts
JZ621405	GEAR STARTER D101B	Bajaj spare parts
JZ72051R	SIDE PANEL LH MATT SILVER	Bajaj spare parts
JZ72061R	SIDE PANEL RH MATT SILVER	Bajaj spare parts
JZ73033B	SEAT COWL BLK/BLUE DECAL	Bajaj spare parts
JZ73033C	SEAT COWL BLK/RED DECAL	Bajaj spare parts
JZ73035A	COWL SEAT BL+BLUE2 DIS 15	Bajaj spare parts
JZ73043B	FENDER FR PNTD BLACK	Bajaj spare parts
JZ73045A	SEAT COWL ASSLY BLK b	Bajaj spare parts
JZ73045B	SEAT COWL ASSLY PNTD D125 BLK RED DKL	Bajaj spare parts
JZ73053B	SEAT COWL MID BLACK BLUE	Bajaj spare parts
JZ73053C	SEAT COWL MID BLACK RED DIS 102	Bajaj spare parts
JZ73053F	SEAT COWL FL RED DIS 102	Bajaj spare parts
JZ73055R	SEAT COWL ASSLY PNTD BRILLIANT BLUE DECA	Bajaj spare parts
JZ73063F	FENDER FR FL RED DIS 102	Bajaj spare parts
JZ73065J	FENDER FR MID BLACK DIS 102	Bajaj spare parts
JZ73065R	FR FENDER PNTD BRILLIANT BLUE	Bajaj spare parts
JZ74033B	COWLING MID BLK BLUE DIS 102	Bajaj spare parts
JZ74033C	COWLING MID BLK RED DIS 102	Bajaj spare parts
JZ74033F	COWLING FL RED DIS 102	Bajaj spare parts
JZ74035R	COWLING (ASSLY)PNTD	Bajaj spare parts
KAAA0514	BOLT-KAA ST-A DIA-05 L-14	Bajaj spare parts
KAAA0516	BOLT-KAA ST-A DIA-05 L-16	Bajaj spare parts
KAAA0518	BOLT	Bajaj spare parts
KAAA0525	BOLT-KAA ST-A DIA-05 L-25	Bajaj spare parts
KAAA0610	BOLT-KAA ST-A DIA-06 L-10	Bajaj spare parts

KAAA0612	BOLT-KAA ST-A DIA-06 L-12	Bajaj spare parts
KAAA0614	BOLT-KAA ST-A DIA-06 L-14	Bajaj spare parts
KAAA0620	BOLT-KAA ST-A DIA-06 L-20	Bajaj spare parts
KAAA0625	BOLT-KAA ST-A DIA-06 L-25	Bajaj spare parts
KAAA0818	BOLT-KAA ST-A DIA-08 L-18	Bajaj spare parts
KAAA0825	BOLT-KAA ST-A DIA-08 L-25	Bajaj spare parts
KAAA0830	BOLT-KAA ST-A DIA-08 L-30	Bajaj spare parts
KAAA0860	BOLT-KAA ST-A DIA-08 L-60	Bajaj spare parts
KAAB0820	BOLT - HEXAGON SOCKET HEAD	Bajaj spare parts
KAAC0630	BOLT HEXAGON HEAD M6X1	Bajaj spare parts
KAAC0825	BOLT-KAA ST-C DIA-08 L-25	Bajaj spare parts
KAAD0520	BOLT-KAA ST-D DIA-05 L-20	Bajaj spare parts
KAAD0525	BOLT-KAA ST-D DIA-05 L-25	Bajaj spare parts
KAAD0610	BOLT-KAA ST-D DIA-06 L-10	Bajaj spare parts
KAAD0612	BOLT-KAA ST-D DIA-06 L-12	Bajaj spare parts
KAAD0614	BOLT-KAA ST-D DIA-06 L-14	Bajaj spare parts
KAAD0618	BOLT-KAA ST-D DIA-06 L-18	Bajaj spare parts
KAAD0620	BOLT	Bajaj spare parts
KAAD0625	BOLT-KAA ST-D DIA-06 L-25	Bajaj spare parts
KAAD0818	pt11-KAA ST-D DIA-08 L-18	Bajaj spare parts
KAAD0822	BOLT-KAA ST-D DIA-08 L-22	Bajaj spare parts
KAAD0855	BOLT-KAA ST-D DIA-08 L-55	Bajaj spare parts
KAAD0860	BOLT-KAA ST-D DIA-08 L-60	Bajaj spare parts
KAAD0865	BOLT	Bajaj spare parts
KAAD1030	BOLT	Bajaj spare parts
KAAD1035	BOLT	Bajaj spare parts
KAAD1045	BOLT	Bajaj spare parts
KAAD1050	BOLT	Bajaj spare parts
KAAE1030	BOLT-KAA ST-E DIA-10 L-30	Bajaj spare parts
KA AF0614	BOLT-KAA ST-F DIA-06 L-14	Bajaj spare parts
KAAG0625	BOLT	Bajaj spare parts
KAAG0870	BOLT	Bajaj spare parts
KAAG0875	BOLT-KAA ST-G DIA-08 L-75	Bajaj spare parts
KAAG0885	BOLT-KAA ST-G DIA-08 L-85	Bajaj spare parts
KACA0508	BOLT MASTER KAC	Bajaj spare parts
KACA0510	BOLT MASTER KAC	Bajaj spare parts
KACA0512	BOLT MASTER KAC	Bajaj spare parts
KACA0516	BOLT-SOCKET-KAC ST-A DIA-05 L-16	Bajaj spare parts
KACA0520	BOLT MASTER KAC	Bajaj spare parts
KACA0610	BOLT-SOCKET-KAC ST-A DIA-06 L-10	Bajaj spare parts
KACA0612	BOLT-SOCKET-KAC ST-A DIA-06 L-12	Bajaj spare parts
KACA0614	BOLT MASTER KAC	Bajaj spare parts
KACA0616	BOLT SOCKET HEAD M6X1	Bajaj spare parts
KACA0618	BOLT MASTER KAC	Bajaj spare parts
KACA0620	BOLT-SOCKET-KAC ST-A DIA-06 L-20	Bajaj spare parts

KACA0622	BOLT MASTER KAC	Bajaj spare parts
KACA0625	BOLT MASTER KAC	Bajaj spare parts
KACA0630	BOLT MASTER KAC	Bajaj spare parts
KACA0635	BOLT SOCKET	Bajaj spare parts
KACA0645	BOLT MASTER KAC	Bajaj spare parts
KACA0650	BOLT MASTER KAC	Bajaj spare parts
KACA0812	BOLT MASTER KAC	Bajaj spare parts
KACA0818	BOLT MASTER KAC	Bajaj spare parts
KACA0820	BOLT-SOCKET-KAC ST-A DIA-08 L-20	Bajaj spare parts
KACA0822	BOLT MASTER KAC	Bajaj spare parts
KACA0825	BOLT MASTER KAC	Bajaj spare parts
KACA0830	BOLT-SOCKET-DIA-08 L-30	Bajaj spare parts
KACA0840	BOLT MASTER KAC	Bajaj spare parts
KACA0845	BOLT MASTER KAC	Bajaj spare parts
KACA0850	BOLT MASTER KAC	Bajaj spare parts
KACA1040	BOLT MASTER KAC	Bajaj spare parts
KACB0514	BOLT-SOCKET-KAC ST-B DIA-05 L-14	Bajaj spare parts
KACB0616	BOLT-SOCKET-KAC ST-B DIA-06 L-16	Bajaj spare parts
KACB0618	BOLT-SOCKET-KAC ST-B DIA-06 L-18	Bajaj spare parts
KACB0622	BOLT-SOCKET-KAC ST-B	Bajaj spare parts
KACC0520	BOLT-SOCKET-KAC ST-C DIA-05 L-20	Bajaj spare parts
KACC0618	BOLT-SOCKET-KAC ST-C DIA-06 L-18	Bajaj spare parts
KACC0620	BOLT SOCKET M6X1	Bajaj spare parts
KACC0625	BOLT-SOCKET-KAC ST-C DIA-06 L-25	Bajaj spare parts
KACC0630	BOLT-SOCKET-KAC ST-C DIA-06 L-30	Bajaj spare parts
KACC0650	BOLT SOCKET-M6X1XL50XCL10.9XBLK	Bajaj spare parts
KACC0814	BOLT-SOCKET-KAC ST-C DIA-08 L-14	Bajaj spare parts
KACC0820	BOLT-SOCKET-KAC ST-C DIA-08 L-20	Bajaj spare parts
KACC0835	BOLT SOCKET- 08 L-35	Bajaj spare parts
KACC1030	BOLT SOCKET M10X1.5	Bajaj spare parts
KACC1040	Bolt-Socket-KAC ST-C Dia-10 L-40	Bajaj spare parts
KACD0510	BOLT MASTER KAC	Bajaj spare parts
KACD0516	BOLT MASTER KAC	Bajaj spare parts
KACD0530	BOLT MASTER KAC	Bajaj spare parts
KACD0830	BOLT MASTER KAC	Bajaj spare parts
KACD0845	BOLT MASTER KAC	Bajaj spare parts
KACF0508	BOLT SOCKET-M5X0.8XL 8XCL8.8XBRT	Bajaj spare parts
KACF0512	BOLT SOCKET-M5X0.8XL12XCL8.8XBRT	Bajaj spare parts
KACF0516	BOLT SOCKET-M5X0.8XL16XCL8.8XBRT	Bajaj spare parts
KACF0530	BOLT SOCKET-M5X0.8XL30XCL8.8XBRT	Bajaj spare parts
KACF0610	BOLT SOCKET M6X1	Bajaj spare parts
KACF0612	BOLT SOCKET-M6X1XL12XCL 8.8X	Bajaj spare parts
KACF0616	BOLT SOCKET-M6X1XL 16XCL 8.8XBRT	Bajaj spare parts
KACF0618	BOLT SOCKET-M6X1XL18XCL 8.8XBRT	Bajaj spare parts
KACF0650	BOLT SOCKET-M6X1XL 50XCL 8.8XBRT	Bajaj spare parts

KACF0655	BOLT SOCKET-M6X1XL 55XCL 8.8XBRT	Bajaj spare parts
KACF0816	BOLT SOKET-M8X1.25XL16XCL8.8XBRT	Bajaj spare parts
KACF0818	BOLT SOKET-M8X1.25XL18XCL8.8XBRT	Bajaj spare parts
KACF0825	BOLT SOKET-M8X1.25XL25XCL8.8XBRT	Bajaj spare parts
KACF0830	BOLT SOKET-M8X1.25XL30XCL8.8XBRT	Bajaj spare parts
KACF0835	BOLT SOKET-M8X1.25XL35XCL8.8XBRT	Bajaj spare parts
KACF0845	BOLT SOCKET M8X1.25	Bajaj spare parts
KACF1030	BOLT SOKET-M10X1.5XL30XCL8.8XBRT	Bajaj spare parts
KACF1050	BOLT SOKET-M10X1.5XL50XCL8.8XBRT	Bajaj spare parts
KACG0610	BOLT SOCKET M6X1	Bajaj spare parts
KACG0645	BOLT SOCKET M6X1	Bajaj spare parts
KACG0650	BOLT SOCKET M6X1	Bajaj spare parts
KACH0510	BOLT SOKET-M5X0.8XL10XCL10.9XBL	Bajaj spare parts
KACH0514	BOLT SOCKET	Bajaj spare parts
KACH0516	BOLT SOCKET-M5X0.8XL16XCL10.9XBL	Bajaj spare parts
KACH0610	BOLT SOCKET-M6X1XL10XCL 10.9XBLK	Bajaj spare parts
KACH0614	BOLT SOCKET-M6X1XL14XCL 10.9XBLK	Bajaj spare parts
KACH0616	BOLT SOCKET	Bajaj spare parts
KACH0622	BOLT SOCKET-M6X1XL 22XCL10.9XBLK	Bajaj spare parts
KACH0625	BOLT SOCKET-M6X1XL25XCL 10.9XBLK	Bajaj spare parts
KACH0640	BOLT SOCKET M6X1	Bajaj spare parts
KACH0645	BOLT SOCKET-M6X1XL45XCL 10.9XBLK	Bajaj spare parts
KACH0650	BOLT SOCKET M6X1	Bajaj spare parts
KACH0660	BOLT SOCKET-M6X1XL60XCL	Bajaj spare parts
KACH0830	BOLT SOKET-M8X1.25XL30XCL10.9XBL	Bajaj spare parts
KACH0835	BOLT SOCKET	Bajaj spare parts
KACJ0655	BOLT SOCKET-M6X1XL55XCL8.8	Bajaj spare parts
KACM0645	BOLT SOCKET-M6X1XL45XCL 10.9XBRT	Bajaj spare parts
KACM0650	BOLT SOCKET-M6X1XL50XCL 10.9XBRT	Bajaj spare parts
KADA0508	FLANGE BOLT M5 X 0.8	Bajaj spare parts
KADA0510	BOLT-FLANGE-KAD ST-A DIA-05	Bajaj spare parts
KADA0512	BOLT FLANGED M5 L12	Bajaj spare parts
KADA0514	BOLT-FLANGE-KAD ST-A DIA-05 L-14	Bajaj spare parts
KADA0516	BOLT-FLANGE-KAD ST-A DIA-05 L-16	Bajaj spare parts
KADA0518	BOLT-FLANGE-KAD ST-A DIA-05 L-18	Bajaj spare parts
KADA0530	BOLT FLANGED	Bajaj spare parts
KADA0608	BOLT-HEXAGON SOCKET HEAD	Bajaj spare parts
KADA0610	BOLT-FLANGE-KAD ST-A DIA-06	Bajaj spare parts
KADA0612	BOLT-FLANGE-KAD ST-A DIA-06 L-12	Bajaj spare parts
KADA0614	BOLT-FLANGE D06 L-14	Bajaj spare parts
KADA0616	BOLT-FLANGE-KAD ST-A	Bajaj spare parts
KADA0618	BOLT-FLANGE-KAD ST-A DIA-06 L-18	Bajaj spare parts
KADA0620	BOLT-FLANGE-KAD ST-A DIA-06 L-20	Bajaj spare parts
KADA0622	BOLT-FLANGE-KAD ST-A DIA-06 L-22	Bajaj spare parts
KADA0625	BOLT-FLANGE-KAD ST-A DIA-06 L-25	Bajaj spare parts



KADA0630	BOLT FLANGE	Bajaj spare parts
KADA0635	BOLT-FLANGE-KAD ST-A DIA-06 L-35	Bajaj spare parts
KADA0812	BOLT-FLANGE-KAD ST-A DIA-08 L-12	Bajaj spare parts
KADA0814	BOLT-FLANGE-KAD ST-A DIA-08 L-14	Bajaj spare parts
KADA0816	BOLT-FLANGE-KAD ST-A DIA-08 L-16	Bajaj spare parts
KADA0818	BOLT FLANGED	Bajaj spare parts
KADA0820	BOLT-FLANGE-KAD ST-A DIA-08 L-20	Bajaj spare parts
KADA0822	BOLT FLANGED	Bajaj spare parts
KADA0825	BOLT FLANGED	Bajaj spare parts
KADA0830	BOLT-FLANGE-KAD ST-A DIA-08 L-30	Bajaj spare parts
KADA0845	BOLT FLANGED	Bajaj spare parts
KADB0510	BOLT-FLANGE-KAD ST-B DIA-05 L-10	Bajaj spare parts
KADB0514	BOLT-FLANGE-KAD ST-B DIA-05 L-14	Bajaj spare parts
KADB0610	BOLT FLANGED	Bajaj spare parts
KADB0855	BOLT FLANGED	Bajaj spare parts
KADC0510	BOLT-FLANGE-KAD ST-C DIA-05 L-10	Bajaj spare parts
KADC0516	BOLT-FLANGE-KAD ST-C DIA-05 L-16	Bajaj spare parts
KADC0518	BOLT FLANGED	Bajaj spare parts
KADC0525	BOLT FLANGED	Bajaj spare parts
KADC0610	BOLT-FLANGE-KAD ST-C DIA-06 L-10	Bajaj spare parts
KADC0612	BOLT FLANGED	Bajaj spare parts
KADC0614	BOLT FLANGED	Bajaj spare parts
KADC0616	BOLT FLANGED	Bajaj spare parts
KADC0618	BOLT FLANGED	Bajaj spare parts
KADC0620	BOLT FLANGED	Bajaj spare parts
KADC0625	BOLT FLANGED	Bajaj spare parts
KADC0845	BOLT FLANGED	Bajaj spare parts
KADD0508	BOLT FLANGED	Bajaj spare parts
KADD0510	BOLT FLANGED	Bajaj spare parts
KADD0512	BOLT FLANGED	Bajaj spare parts
KADD0514	BOLT-FLANGE-KAD ST-D DIA-05 L-14	Bajaj spare parts
KADD0516	BOLT-FLANGE-KAD	Bajaj spare parts
KADD0520	BOLT FLANGED	Bajaj spare parts
KADD0525	BOLT-FLANGE-KAD ST-D DIA-05 L-25	Bajaj spare parts
KADD0530	BOLT FLANGED	Bajaj spare parts
KADD0608	BOLT FLANGED	Bajaj spare parts
KADD0610	BOLT-FLANGE I-06	Bajaj spare parts
KADD0612	BOLT FLANGED	Bajaj spare parts
KADD0614	BOLT-FLANGE-KAD ST-D DIA-06 L-14	Bajaj spare parts
KADD0616	BOLT-FLANGE-KAD ST-D DIA-06 L-16	Bajaj spare parts
KADD0618	BOLT FLANGED	Bajaj spare parts
KADD0620	BOLT-FLANGE-KAD ST-D DIA-06	Bajaj spare parts
KADD0622	BOLT-FLANGE-KAD ST-D DIA-06 L-22	Bajaj spare parts
KADD0625	BOLT-FLANGE-DIA-06 L-25	Bajaj spare parts
KADD0630	BOLT-FLANGE-KAD ST-D DIA-06 L-30	Bajaj spare parts

KADD0635	BOLT FLANGED	Bajaj spare parts
KADD0640	BOLT-FLANGE-KAD ST-D DIA-06 L-40	Bajaj spare parts
KADD0645	BOLT FLANGED	Bajaj spare parts
KADD0660	BOLT FLANGED	Bajaj spare parts
KADD0670	BOLT-FLANGE-DIA-06L-70	Bajaj spare parts
KADD0812	BOLT-FLANGE-KAD ST-D DIA-08 L-12	Bajaj spare parts
KADD0814	BOLT-FLANGE-KAD ST-D DIA-08 L-14	Bajaj spare parts
KADD0816	BOLT-FLANGE-KAD ST-D DIA-08 L-16	Bajaj spare parts
KADD0818	Flange bolt(spares)	Bajaj spare parts
KADD0820	BOLT FLANGED	Bajaj spare parts
KADD0822	BOLT-FLANGE-KAD ST-D DIA-08 L-22	Bajaj spare parts
KADD0825	BOLT-FLANGE-KAD ST-D DIA-08	Bajaj spare parts
KADD0830	BOLT-FLANGE-KAD ST-D DIA-08 L-30	Bajaj spare parts
KADD0835	BOLT-FLANGE-KAD ST-D DIA-08 L-35	Bajaj spare parts
KADD0840	BOLT FLANGED	Bajaj spare parts
KADD0845	BOLT FLANGED	Bajaj spare parts
KADD0850	BOLT-FLANGE-KAD ST-D DIA-08 L-50	Bajaj spare parts
KADD0855	BOLT-FLANGE-KAD ST-D DIA-08 L-55	Bajaj spare parts
KADD0860	BOLT-FLANGE L-60	Bajaj spare parts
KADD0865	BOLT-FLANGE-KAD ST-D DIA-08 L-65	Bajaj spare parts
KADD0870	BOLT FLANGED	Bajaj spare parts
KADD0880	BOLT-FLANGE-KAD ST-D DIA-08 L-80	Bajaj spare parts
KADD0885	BOLT FLANGED	Bajaj spare parts
KADD08A0	BOLT FLANGED-M8X1.25XL100XBRIGHT	Bajaj spare parts
KADD08A5	BOLT FLANGED-M8X1.25XL105XBRIGHT	Bajaj spare parts
KADD08B0	BOLT FLANGED-M8X1.25XL110XBRIGHT	Bajaj spare parts
KADD08E5	BOLT FLANGED-M8X1.25XL145XBRIGHT	Bajaj spare parts
KADD1016	BOLT FLANGED	Bajaj spare parts
KADD1020	BOLT FLANGED	Bajaj spare parts
KADD1030	BOLT-FLANGE-KAD ST-D DIA-10 L-30	Bajaj spare parts
KADD1040	BOLT FLANGED	Bajaj spare parts
KADD1050	BOLT FLANGED	Bajaj spare parts
KADD1055	BOLT-FLANGE-KAD ST-D DIA-10 L-55	Bajaj spare parts
KADD1060	BOLT-FLANGE-KAD	Bajaj spare parts
KADD1080	BOLT-FLANGE-KAD ST-D DIA-10 L-80	Bajaj spare parts
KADD10A0	BOLT-FLANGED	Bajaj spare parts
KADD10B0	BOLT FLANGE-M10X1.25XL110XBRIGHT	Bajaj spare parts
KADD10B5	BOLT FLANGE-M10X1.25XL115XBRIGHT	Bajaj spare parts
KADD10F0	BOLT FLANGE-M10X1.25XL150XBRIGHT	Bajaj spare parts
KADE0850	BOLT-FLANGE-KAD ST-E DIA-08 L-50	Bajaj spare parts
KADF0510	BOLT FLANGED	Bajaj spare parts
KADF0516	BOLT-FLANGE-DIA-05 L-16	Bajaj spare parts
KADF0520	BOLT-FLANGE-KAD ST-F DIA-05 L-20	Bajaj spare parts
KADF0525	BOLT FLANGED M5X0.8	Bajaj spare parts
KADF0608	BOLT-FLANGE-KAD ST-F DIA-06 L-08	Bajaj spare parts

KADF0610	BOLT FLANGED	Bajaj spare parts
KADF0612	BOLT-FLANGE-KAD ST-F DIA-06 L-12	Bajaj spare parts
KADF0614	BOLT-FLANGE-KAD ST-F DIA-06 L-14	Bajaj spare parts
KADF0616	BOLT-FLANGE-KAD ST-F DIA-06 L-16	Bajaj spare parts
KADF0618	BOLT FLANGED	Bajaj spare parts
KADF0620	BOLT-FLANGE-KAD ST-F	Bajaj spare parts
KADF0622	BOLT FLANGED	Bajaj spare parts
KADF0625	BOLT-FLANGE-KAD ST-F DIA-06 L-25	Bajaj spare parts
KADF0630	BOLT-FLANGE-KAD ST-F DIA-06 L-30	Bajaj spare parts
KADF0635	BOLT FLANGED	Bajaj spare parts
KADF0680	BOLT FLANGED	Bajaj spare parts
KADF0812	BOLT-FLANGE-KAD ST-F DIA-08 L-12	Bajaj spare parts
KADF0814	BOLT FLANGED	Bajaj spare parts
KADF0816	BOLT FLANGED	Bajaj spare parts
KADF0820	BOLT FLANGED	Bajaj spare parts
KADF0822	BOLT-FLANGE-KAD	Bajaj spare parts
KADF0825	BOLT FLANGED	Bajaj spare parts
KADF0835	BOLT HEXAGON HEAD FLANGE M8	Bajaj spare parts
KADF0840	BOLT-FLANGE-KAD ST-F DIA-08 L-40	Bajaj spare parts
KADF0850	BOLT FLANGED	Bajaj spare parts
KADF0855	BOLT FLANGED	Bajaj spare parts
KADF0870	BOLT FLANGED	Bajaj spare parts
KADF0875	BOLT FLANGED	Bajaj spare parts
KADF0880	BOLT FLANGED	Bajaj spare parts
KADF0885	BOLT FLANG-M8X1.25XL85XCL8	Bajaj spare parts
KADF0890	BOLT FLANGED	Bajaj spare parts
KADF08A0	BOLT FLANGE-M8X1.25XL100XOLV GRN	Bajaj spare parts
KADF08C5	BOLT FLANGED-M8X1.25XL 125XBLACK	Bajaj spare parts
KADF08D0	BOLT FLANGE-M8X1.25XL130XOLV GRN	Bajaj spare parts
KADF1030	BOLT HEX FLANGE M10X1.25X30	Bajaj spare parts
KADF1050	BOLT-FLANGE-KAD ST-F DIA-10 L-50	Bajaj spare parts
KADF1080	BOLT-FLANGE-KAD ST-F DIA-10 L-80	Bajaj spare parts
KADF1260	BOLT-FLANGE-KAD ST-F DIA-12 L-60	Bajaj spare parts
KADG0520	BOLT FLANGED	Bajaj spare parts
KADG0825	BOLT FLANGED	Bajaj spare parts
KADG0855	BOLT-FLANGE-KAD ST-G DIA-08 L-55	Bajaj spare parts
KADG08B5	BOLT FLANGED M8X1.25	Bajaj spare parts
KADG08C0	BOLT FLANGED M8X1.25	Bajaj spare parts
KADG1085	BOLT FLANGED	Bajaj spare parts
KADH0870	BOLT-FLANGE-KAD ST-H DIA-08 L-70	Bajaj spare parts
KADJ0860	BOLT FLANGED M8X1.25	Bajaj spare parts
KADJ0890	BOLT-FLANGE-KAD ST-J DIA-08 L-90	Bajaj spare parts
KADJ10D5	BOLT FLANGED M10X1.25	Bajaj spare parts
KADM0508	BOLT FLANGED	Bajaj spare parts
KADP0516	HEXAGONAL FLANGE BOLT	Bajaj spare parts

KADP0608	HEX BOLT FLANGE	Bajaj spare parts
KADQ0606	HEXAGONAL BOLT WITH FLANGE	Bajaj spare parts
KADQ0614	FLANGED BOLT	Bajaj spare parts
KADQ0620	BOLT HEXAGONAL	Bajaj spare parts
KADQ0625	BOLT M6	Bajaj spare parts
KADQ0630	BOLT FLANGED	Bajaj spare parts
KADQ0635	BOLT FLANGED	Bajaj spare parts
KADQ0640	BOLT FLANGED	Bajaj spare parts
KADQ0645	HEX HEADED BOLT FLANGE	Bajaj spare parts
KADQ0835	BOLT FLANGE M8*1.25*35L	Bajaj spare parts
KADR0520	BOLT FLANGED-M5X0.8	Bajaj spare parts
KADS0510	BOLT FLANGE-M5X0.8XL10XCL4.8XBLK	Bajaj spare parts
KADS0516	BOLT FLANGE-M5X0.8XL16XCL4.8XBLK	Bajaj spare parts
KADS0616	BOLT FLANGED-M6X1XL16XCL4.8XBLAK	Bajaj spare parts
KADT0610	BOLT FLANGED	Bajaj spare parts
KADT0612	BOLT FLANGED-M6X1XL12XCL8.8XBLAK	Bajaj spare parts
KADT0614	BOLT FLANGED-M6X1XL14XCL8.8XBLAK	Bajaj spare parts
KADT0616	BOLT FLANGED-M6X1XL16XCL8.8XBLAK	Bajaj spare parts
KADT0620	BOLT FLANGED-M6X1XL20XCL8.8XBLAK	Bajaj spare parts
KADT0625	BOLT FLANGED-M6X1XL25XCL8.8XBLAK	Bajaj spare parts
KADT0814	BOLT FLANG-M8X1.25XL14XCL8.8XBLK	Bajaj spare parts
KADT0820	BOLT FLANG-M8X1.25XL20XCL8.8XBLK	Bajaj spare parts
KADU0840	BOLT FLANGED-M8X1.25XL 40XBLACK	Bajaj spare parts
KADU0855	BOLT FLANGED-M8X1.25XL 55XBLACK	Bajaj spare parts
KADW0820	BOLT FLANG-M8X1.25XL20XCL8.8XBRT	Bajaj spare parts
KADW0830	BOLT FLANG-M8X1.25XL30XCL8.8XBRT	Bajaj spare parts
KADW0835	BOLT FLANG-M8X1.25XL35XCL8.8XBRT	Bajaj spare parts
KADW1050	BOLT FLANGED-M10X1.25XL50XBRIGHT	Bajaj spare parts
KADW10B0	BOLT FLANGE-M10X1.25XL110XBRIGHT	Bajaj spare parts
KADY0870	BOLT FLANGED-M8X1.25XL 70XBRIGHT	Bajaj spare parts
KAEA0510	Bolt-Flange-KAE ST-A Dia-05 L-10	Bajaj spare parts
KAEA0610	BOLT-FLANGE-KAE ST-A DIA-06 L-10	Bajaj spare parts
KAEA0612	BOLT-FLANGE-KAE ST-A DIA-06 L-12	Bajaj spare parts
KAEA0620	BOLT-FLANGE-KAE ST-A DIA-06 L-20	Bajaj spare parts
KAEA0622	BOLT FLANGED	Bajaj spare parts
KAEA0812	BOLT-FLANGED-SMALL	Bajaj spare parts
KAEB0612	BOLT-FLANGE-KAE ST-B DIA-06	Bajaj spare parts
KAEB0830	BOLT-FLANGE-KAE ST-B DIA-08 L-30	Bajaj spare parts
KAED0510	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0516	BOLT-FLANGE-KAE ST-D DIA-05 L-16	Bajaj spare parts
KAED0608	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0610	BOLT-FLANGE-KAE ST-D DIA-06 L-10	Bajaj spare parts
KAED0612	BOLT-FLANGE-KAE ST-D DIA-06 L-12	Bajaj spare parts
KAED0614	BOLT FLANGE KAE STD DIA06 L14	Bajaj spare parts
KAED0616	BOLT-FLANGE-KAE ST-D DIA-06 L-16	Bajaj spare parts

KAED0618	BOLT-FLANGE-KAE ST-D DIA-06 L-18	Bajaj spare parts
KAED0620	BOLT-FLANGE-KAE ST-D DIA-06	Bajaj spare parts
KAED0622	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0625	BOLT-FLANGE-KAE ST-D DIA-06 L-25	Bajaj spare parts
KAED0630	BOLT-FLANGE-KAE ST-D DIA-06 L-30	Bajaj spare parts
KAED0635	BOLT-FLANGE-KAE ST-D DIA-06 L-35	Bajaj spare parts
KAED0640	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0645	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0650	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0655	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0665	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0670	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0675	BOLT-FLANGE-KAE ST-D DIA-06 L-75	Bajaj spare parts
KAED0685	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0690	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED06A5	BOLT FLANG SMAL-M6X1XL105XBRIGHT	Bajaj spare parts
KAED06B5	BOLT FLANG SMAL-M6X1XL115XBRIGHT	Bajaj spare parts
KAED0812	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0814	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0816	BOLT-FLANGE-KAE ST-D DIA-08 L-16	Bajaj spare parts
KAED0820	BOLT-FLANGE-KAE ST-D DIA-08 L-20	Bajaj spare parts
KAED0830	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0835	BOLT-FLANGED-SMALL	Bajaj spare parts
KAED0840	BOLT-FLANGE-KAE ST-D DIA-08 L-40	Bajaj spare parts
KAEF0608	BOLT-FLANGE-KAE ST-F DIA-06 L-08	Bajaj spare parts
KAEF0610	BOLT-FLANGE-KAE ST-F DIA-06 L-10	Bajaj spare parts
KAEF0612	BOLT-FLANGE-KAE ST-F DIA-06 L-12	Bajaj spare parts
KAEF0616	BOLT-FLANGE-KAE ST-F DIA-06 L-16	Bajaj spare parts
KAEF0622	BOLT-FLANGE-KAE ST-F DIA-06 L-22	Bajaj spare parts
KAEF0630	BOLT-FLANGE-	Bajaj spare parts
KAEF0640	BOLT-FLANGE-KAE ST-F DIA-06 L-40	Bajaj spare parts
KAEF0645	BOLT-FLANGE-KAE ST-F DIA-06 L-45	Bajaj spare parts
KAEF0650	BOLT-FLANGE-KAE ST-F DIA-06 L-50	Bajaj spare parts
KAEF0655	BOLT-FLANGE-KAE ST-F DIA-06 L-55	Bajaj spare parts
KAEG0614	BOLT-FLANGED-SMALL	Bajaj spare parts
KAEG0620	BOLT-FLANGED-SMALL	Bajaj spare parts
KAEG0635	BOLT-FLANGE-KAE ST-G DIA-06 L-35	Bajaj spare parts
KAEG0645	BOLT-FLANGED-SMALL	Bajaj spare parts
KAEG0685	BOLT-FLANGED-SMALL	Bajaj spare parts
KAEG0830	BOLT-FLANGED-SMALL	Bajaj spare parts
KAEM0614	BOLT FLANGED SMALL	Bajaj spare parts
KAEM0620	BOLT MASTER KAE	Bajaj spare parts
KAEQ0616	BOLT FLANGE SMALL-M6X1XL16XDACRO	Bajaj spare parts
KAEQ0620	BOLT FL. SMALL-M6X1XL20XDACRO	Bajaj spare parts
KAEQ0630	BOLT FL. SMALL-M6X1XL30XDACRO	Bajaj spare parts

KAEQ0635	BOLT FLANGE SMALL	Bajaj spare parts
KAEQ0640	BOLT FLANGE SMALL	Bajaj spare parts
KAEQ0645	BOLT FL.-M6X1XL45XDACRO	Bajaj spare parts
KAEQ0650	BOLT FLANGE SMALL-M6X1	Bajaj spare parts
KAEQ0670	BOLT FLANGED M6X1	Bajaj spare parts
KAER06C0	BOLT FLANGE SMAL-M6X1XL120XDACRO	Bajaj spare parts
KAET0610	BOLT - FLANGED :- SMALL	Bajaj spare parts
KAET0835	BOLT FLANG SMALL-M8X1.25XL35XBLK	Bajaj spare parts
KAET0850	BOLT FLANG SMALL-M8X1.25XL50XBLK	Bajaj spare parts
KAEW0616	BOLT FLANGE SMAL-M6X1XL16XBRIGHT	Bajaj spare parts
KAEW0620	BOLT FLANGE SMAL-M6X1XL20XBRIGHT	Bajaj spare parts
KAEW0622	BOLT FLANGE SMAL-M6X1XL22XBRIGHT	Bajaj spare parts
KAEW0625	BOLT FLANGE SMAL-M6X1XL25XBRIGHT	Bajaj spare parts
KAEW0635	BOLT FLANGE SMAL-M6X1XL35XBRIGHT	Bajaj spare parts
KAEW0650	BOLT FLANGE SMAL-M6X1XL50XBRIGHT	Bajaj spare parts
KAEW0655	BOLT FLANGE SMAL-M6X1XL55XBRIGHT	Bajaj spare parts
KAEW0670	BOLT FLANGED M6X1	Bajaj spare parts
KAEW0835	BOLT FLANG SMALL-M8X1.25XL35XBRT	Bajaj spare parts
KAHB0818	BOLT WSP	Bajaj spare parts
KAJA0518	BOLT STUD	Bajaj spare parts
KAJA0845	BOLT STUD	Bajaj spare parts
KAMB0818	BOLT UPSET WSP	Bajaj spare parts
KANA0616	BOLT WELD-M6X1XL 16	Bajaj spare parts
KBAA0410	SCREW-PAN+-	Bajaj spare parts
KBAA0412	SCREW-PAN+-	Bajaj spare parts
KBAA0420	SCREW-PAN+-	Bajaj spare parts
KBAA0510	SCREW-PAN+-	Bajaj spare parts
KBAA0520	SCREW-PAN	Bajaj spare parts
KBAC0508	SCREW PAN+- M5X0.8XL 8XOLV GREEN	Bajaj spare parts
KBAC0614	SCREW-PAN	Bajaj spare parts
KBBA0406	SCREW PAN CROSS	Bajaj spare parts
KBBA0408	SCREW PAN CROSS	Bajaj spare parts
KBBA0410	SCREW PAN CROSS	Bajaj spare parts
KBBA0412	SCREW PAN CROSS	Bajaj spare parts
KBBA0414	SCREW PAN CROSS	Bajaj spare parts
KBBA0416	SCREW PAN CROSS	Bajaj spare parts
KBBA0420	SCREW PAN CROSS	Bajaj spare parts
KBBA0425	SCREW PAN CROSS	Bajaj spare parts
KBBA0508	SCREW PAN CROSS	Bajaj spare parts
KBBA0510	SCREW PAN CROSS	Bajaj spare parts
KBBA0512	SCREW PAN CROSS	Bajaj spare parts
KBBA0514	SCREW-M5	Bajaj spare parts
KBBA0516	SCREW PAN CROSS	Bajaj spare parts
KBBA0520	SCREW PAN CROSS	Bajaj spare parts
KBBA0525	SCREW PAN CROSS	Bajaj spare parts

KBBA0530	SCREW PAN CROSS	Bajaj spare parts
KBBA0610	SCREW TRUSS M6	Bajaj spare parts
KBBA0616	SCREW PAN CROSS	Bajaj spare parts
KBBA0625	SCREW PAN CROSS	Bajaj spare parts
KBBA0635	SCREW PAN CROSS	Bajaj spare parts
KBBA0650	SCREW PAN CROSS	Bajaj spare parts
KBBB0630	SCREW PAN CROSS	Bajaj spare parts
KBBC0512	SCREW PAN CROSS	Bajaj spare parts
KBBC0514	SCREW PAN CROSS	Bajaj spare parts
KBBC0516	SCREW PAN CROSS	Bajaj spare parts
KBBC0520	SCREW PAN CROSS	Bajaj spare parts
KBBC0608	SCREW PAN CROSS-M6X1XL 8XOLV GRN	Bajaj spare parts
KBBC0614	SCREW PAN CROSS	Bajaj spare parts
KBBC0616	SCREW PAN CROSS	Bajaj spare parts
KBBC0620	SCREW PAN CROSS	Bajaj spare parts
KBBE0408	SCREW PAN CROSS	Bajaj spare parts
KBBE0550	SCREW PAN CROSS	Bajaj spare parts
KBBF0408	SCREW PAN CROSS	Bajaj spare parts
KBBG0612	PAN HEAD SCREW	Bajaj spare parts
KBBJ0512	SCREW PAN CROSS-M5X0.8XL12XBLACK	Bajaj spare parts
KBBJ0514	SCREW PAN CROSS-M5X0.8XL14XBLACK	Bajaj spare parts
KBBJ0616	SCREW PAN CROSS-M6X1XL 16XBLACK	Bajaj spare parts
KBBK0510	SCREW PAN CROS-M5X0.8XL	Bajaj spare parts
KBBK0512	SCREW PAN CROS-M5X0.8XL12XBLACK	Bajaj spare parts
KBBP0514	SCREW PAN CROS-M5X0.8XL14XBRIGHT	Bajaj spare parts
KBBP0530	SCREW PAN CROS-M5X0.8XL30XBRIGHT	Bajaj spare parts
KBCA0410	SCREW CSK CROSS	Bajaj spare parts
KBCA0414	SCREW CSK CROSS	Bajaj spare parts
KBCA0416	SCREW CSK CROSS	Bajaj spare parts
KBCA0420	SCREW CSK CROSS	Bajaj spare parts
KBCA0614	SCREW CSK CROSS	Bajaj spare parts
KBCA0616	SCREW CSK CROSS	Bajaj spare parts
KBCA0620	SCREW CSK CROS-M6X1XL20XCL4.8XBR	Bajaj spare parts
KBCA0816	SCREW CSK - CROSS	Bajaj spare parts
KBCC0430	SCREW CSK CROSS	Bajaj spare parts
KBCC0514	SCREW CSK CROSS	Bajaj spare parts
KBCC0616	SCREW CSK CROSS M6X1	Bajaj spare parts
KBCD0430	SCREW CSK CROSS	Bajaj spare parts
KBDC0425	SCREW CSK RD CROS-M4X0.7XL25XGRN	Bajaj spare parts
KBFA0516	SCREW PAN WP CROSS	Bajaj spare parts
KBNA0510	SCREW SET SOCKET	Bajaj spare parts
KBQA3506	SCREW TAPPING PAN SLOTTED	Bajaj spare parts
KBQA3513	SCREW TAPPING PAN SLOTTED	Bajaj spare parts
KBRA3510	SCREW TAPPING PAN CROSS	Bajaj spare parts
KBRA4213	SCREW TAPPING PAN CROSS	Bajaj spare parts

KBRA4216	SCREW TAPPING PAN CROSS	Bajaj spare parts
KBRA4219	SCREW TAPPING PAN SLOTTED	Bajaj spare parts
KBRA4225	SCREW TAPPING PAN CROSS	Bajaj spare parts
KBRA4813	SCREW TAPPING PAN CROSS	Bajaj spare parts
KBRA4816	SCREW TAPPING PAN SLOTTED	Bajaj spare parts
KBRA4819	SCREW TAPPING PAN SLOTTED	Bajaj spare parts
KBRB3525	SCREW TAPPING PAN SLOTTED	Bajaj spare parts
KBRC3513	SCREW TAPPING PAN CROS-ST3.5XL13	Bajaj spare parts
KBRC3516	SCREW TAPPING PAN CROS-ST3.5XL16	Bajaj spare parts
KBRC4213	SCREW TAPPING PAN CROSS ST4.2	Bajaj spare parts
KBRC4816	SCREW TAPPING PAN CROS-ST4.8XL16	Bajaj spare parts
KBRC4822	SCREW TAPPING PAN CROS-ST4.8XL22	Bajaj spare parts
KBRD3510	SCREW TAPPING PAN CROSS-ST3.5XL10	Bajaj spare parts
KBRD3513	SCREW TAPPING PAN CROS-ST3.5XL13	Bajaj spare parts
KBRD4213	SCREW TAPPING PAN CROS-ST4	Bajaj spare parts
KBRD4219	SCREW TAPPING PAN CROS-ST4.2XL19	Bajaj spare parts
KBRD4813	SCREW TAPPING PAN CROS	Bajaj spare parts
KBRF3510	SCREW TAPPING PAN CROS-ST3.5XL10	Bajaj spare parts
KBUA0408	SCREW TRUSS	Bajaj spare parts
KBUA0510	SCREW TRUSS	Bajaj spare parts
KBUA0512	SCREW TRUSS	Bajaj spare parts
KBUA0514	SCREW TRUSS	Bajaj spare parts
KBUA0516	SCREW TRUSS	Bajaj spare parts
KBUA0530	SCREW TRUS	Bajaj spare parts
KBUA0545	SCREW TRUSS	Bajaj spare parts
KBUA0608	SCREW TRUSS	Bajaj spare parts
KBUA0612	MUSHROOM HEAD SCREW	Bajaj spare parts
KBUA0614	SCREW TRUSS	Bajaj spare parts
KBUA0616	SCREW TRUS	Bajaj spare parts
KBUA0620	SCREW TRUSS	Bajaj spare parts
KBUA0625	SCREW TRUSS	Bajaj spare parts
KBUA0630	SCREW TRUSS	Bajaj spare parts
KBUA0825	SCREW TRUSS	Bajaj spare parts
KBUB0410	SCREW TRUS	Bajaj spare parts
KBUB0508	SCREW TRUSS	Bajaj spare parts
KBUB0512	SCREW TRUS	Bajaj spare parts
KBUB0516	SCREW TRUS	Bajaj spare parts
KBUC0410	SCREW TRUSS M4 X 0.7P	Bajaj spare parts
KBUC0416	SCREW TRUSS-M4X0.7XL16XOLIVE GRN	Bajaj spare parts
KBUC0510	SCREW TRUSS	Bajaj spare parts
KBUC0514	SCREW TRUSS-M5X0.8XL14XOLIVE GRN	Bajaj spare parts
KBUC0516	SCREW-TRUSS-M5X16L,4.8	Bajaj spare parts
KBUC0520	SCREW TRUSS-M5X0.8XL20XOLIVE	Bajaj spare parts
KBUC0525	SCREW TRUSS-M5X0.8XL25XOLIVE GRN	Bajaj spare parts
KBUC0614	SCREW TRUS	Bajaj spare parts



KBUC0620	SCREW TRUSS-M6X1XL 20XOLIVE GRN	Bajaj spare parts
KBUC0625	SCREW TRUSS-M6X1XL 25XOLIVE	Bajaj spare parts
KBUE0520	SCREW TRUSS	Bajaj spare parts
KBUF0408	SCREW TRUSS-M4X0.7XL 8XBLACK	Bajaj spare parts
KBUF0410	SCREW TRUSS-M4X0.7XL 10XBLACK	Bajaj spare parts
KBUF0412	SCREW TRUSS-M4X0.7XL 12XBLACK	Bajaj spare parts
KBUF0508	SCREW TRUSS-M5X0.8XL 8XBLACK	Bajaj spare parts
KBUF0510	SCREW TRUSS-M5X0.8XL 10XBLACK	Bajaj spare parts
KBUF0512	SCREW TRUSS-M5X0.8XL 12XBLACK	Bajaj spare parts
KBUF0514	SCREW TRUSS-M5X0.8XL 14XBLACK	Bajaj spare parts
KBUF0516	SCREW TRUSS-M5X0.8XL 16XBLACK	Bajaj spare parts
KBUF0530	SCREW TRUSS M5X0.8	Bajaj spare parts
KBUF0612	SCREW TRUSS-M6X1XL 12XBLACK	Bajaj spare parts
KBUF0614	SCREW TRUSS-M6X1XL 14XBLACK	Bajaj spare parts
KBUF0616	SCREW TRUSS-M6X1XL 16XBLACK	Bajaj spare parts
KBUF0620	SCREW TRUSS M6X1	Bajaj spare parts
KBUH0514	SCREW TRUSS-M5X0.8XL 14XBRIGHT	Bajaj spare parts
KBUH0612	SCREW TRUSS-M6X1XL 12XBRIGHT	Bajaj spare parts
KCAA0403	NUT HEX THICK	Bajaj spare parts
KCAA0504	NUT HEX THICK	Bajaj spare parts
KCAA0605	NUT HEX THICK	Bajaj spare parts
KCAA0806	NUT HEX THICK	Bajaj spare parts
KCAA1008	NUT MASTER	Bajaj spare parts
KCAA1210	NUT HEX THICK	Bajaj spare parts
KCAC0504	NUT HEX THICK-M5X0.8XHT. 4XGREEN	Bajaj spare parts
KCAD0504	NUT HEX THICK	Bajaj spare parts
KCAD0605	NUT HEX THICK	Bajaj spare parts
KCAD0806	NUT HEX THICK	Bajaj spare parts
KCAD1008	NUT HEX THICK	Bajaj spare parts
KCAD1411	NUT HEX THICK	Bajaj spare parts
KCAJ0605	NUT INHIBITOR	Bajaj spare parts
KCAK0605	NUT HEX THICK-M6X1XHT 5XBLACK	Bajaj spare parts
KCAM0605	NUT HEX THICK-M6X1XHT 5XDACRO	Bajaj spare parts
KCAM0806	NUT HEX THK-M8X1.25XHT.6.5XDACRO	Bajaj spare parts
KCBA0503	NUT HEX THIN-M5X0.8XHT3.2XBRIGHT	Bajaj spare parts
KCBA0604	NUT HEX THIN-M6X1XHT. 3.6XBRIGHT	Bajaj spare parts
KCBA0605	NUT HEX THIN NUT HEX THIN	Bajaj spare parts
KCBA0805	NUT HEX THIN-M8X1.25XHT.5XBRIGHT	Bajaj spare parts
KCBA1006	NUT HEX THIN-M10X1.25XHT. 6XBRT	Bajaj spare parts
KCBA1811	NUT HEX THIN-M18X1.5XHT. 11XBRT	Bajaj spare parts
KCBC0805	NUT HEX THIN-M8X1.25XHT. 5XGREEN	Bajaj spare parts
KCBD0604	NUT HEX THIN-M6X1XHT. 3.6XBRIGHT	Bajaj spare parts
KCBD1006	NUT HEX THIN-M10X1.25XHT. 6XBRT	Bajaj spare parts
KCBK1006	NUT HEX THIN-M10X1.25XHT. 6XBLK	Bajaj spare parts
KCEA0504	NUT DOMED CAP SINGLE PIECE	Bajaj spare parts

KCEA0605	NUT DOMED CAP SINGLE PIECE	Bajaj spare parts
KCEC0504	NUT DOMED CAP SINGLE PIECE	Bajaj spare parts
KCEE0504	NUT DOME CAP SINGLE PIECE	Bajaj spare parts
KCEE0605	NUT DOME CAP SINGLE PIECE-M6 X 1	Bajaj spare parts
KCGA0505	NUT HEX FLANGED	Bajaj spare parts
KCGA0606	NUT HEX FLANGED	Bajaj spare parts
KCGA0808	NUT HEX FLANGED	Bajaj spare parts
KCGA1010	NUT-HEX-FLANGED	Bajaj spare parts
KCGC0505	NUT HEX FLANGED	Bajaj spare parts
KCGC0606	NUT HEX FLANGED	Bajaj spare parts
KCGC0808	NUT HEX FLANGED-M8X1.25XCL 4XGRN	Bajaj spare parts
KCGD0505	NUT HEX FLANGED	Bajaj spare parts
KCGD0606	NUT HEX FLANGED	Bajaj spare parts
KCGD0808	NUT HEX FLANGED	Bajaj spare parts
KCGD1010	NUT HEX FLANGED	Bajaj spare parts
KCGF0505	NUT HEX FLANGED-M5X0.8XCL8XGREEN	Bajaj spare parts
KCGF0606	NUT HEX FLANGED-M6X1XCL 8XGREEN	Bajaj spare parts
KCGF0808	NUT HEX FLANGED-M8X1.25	Bajaj spare parts
KCGF1010	NUT HEX FLANGED	Bajaj spare parts
KCGK0606	NUT HEX FLANGED-M6X1XCL 4XBLACK	Bajaj spare parts
KCGK0808	NUT HEX FLANGED-M8X1.25XCL 4XBLK	Bajaj spare parts
KCGN0808	NUT HEX FLANGE-M8X1.25XCL8XDACRO	Bajaj spare parts
KCHA0507	NUT NYLOC	Bajaj spare parts
KCHA0608	NUT NYLOC	Bajaj spare parts
KCHA0809	NUT NYLOC	Bajaj spare parts
KCHA1012	NUT NYLOC	Bajaj spare parts
KCHA1417	NUT - NYLOC :- M14 X 1.5	Bajaj spare parts
KCHC0608	NUT NYLOC-M6X1XHT.8XA/F 10XGREEN	Bajaj spare parts
KCHC1417	NUT NYLOC-M14X1.5XHT. 17XGREEN	Bajaj spare parts
KCJA0606	NUT U	Bajaj spare parts
KCJD1212	NUT U-M12X1.25XHT.12XBLACK	Bajaj spare parts
KCKA0609	NUT NYLOC FLANGED	Bajaj spare parts
KCKA0811	NUT NYLOC FLANGED	Bajaj spare parts
KCKA1013	NUT NYLOC FLANGED	Bajaj spare parts
KCKA1216	NUT NYLOC FLANGED	Bajaj spare parts
KCKC0609	NUT NYLOC FLANGED	Bajaj spare parts
KCKC0811	NUT NYLOC FLANGE	Bajaj spare parts
KCKC1013	NUT NYLOC FLANGE	Bajaj spare parts
KCKC1216	NUT NYLOC FLANGE M12X1.25	Bajaj spare parts
KCKD0507	NYLOC NUT	Bajaj spare parts
KCKD0609	NUT NYLOC FLANGED-M6X1XHT. 9.1	Bajaj spare parts
KCKE0507	NUT NYLOC FL-M5X0.8XHT. 7.1XBLK	Bajaj spare parts
KCKE0609	NUT NYLOC FL-M6X1XHT. 9.1XBLK	Bajaj spare parts
KDAA0408	WASHER PLAIN SMALL	Bajaj spare parts
KDAA0510	WASHER PLAIN SMALL	Bajaj spare parts

KDAA0611	WASHER PLAIN SMALL	Bajaj spare parts
KDAA0816	WASHER-KDA-OD/ID	Bajaj spare parts
KDAA1018	WASHER_PLAIN_SMALL	Bajaj spare parts
KDAA1222	WASHER PLAIN SMALL	Bajaj spare parts
KDAB0510	WASHER PLAIN	Bajaj spare parts
KDAB0611	WASHER PLAIN SMALL-6.5X11.5XT0.8	Bajaj spare parts
KDAB0816	WASHER PLAN SMALL 8.5X16X1.2	Bajaj spare parts
KDAB1018	WASHER PLAIN SMALL	Bajaj spare parts
KDAB1222	WASHER_PLAIN_SMALL	Bajaj spare parts
KDAC0816	WASHER PLAIN SMALL	Bajaj spare parts
KDAD0510	WASHER_PLAIN_SMALL	Bajaj spare parts
KDAD0611	WASHER_PLAIN_SMALL	Bajaj spare parts
KDAE0408	WASHER PLAIN SMALL-4.5X8X0.5XBLK	Bajaj spare parts
KDAE0510	WASHER PLAIN SMAL-5.5	Bajaj spare parts
KDBA0512	WASHER PLAIN	Bajaj spare parts
KDBA0613	WASHER PLAIN	Bajaj spare parts
KDBA0818	WASHER PLAIN	Bajaj spare parts
KDBA1022	WASHER PLAIN	Bajaj spare parts
KDBA1226	WASHER_PLAIN 39071411	Bajaj spare parts
KDBA1632	WASHER PLAIN	Bajaj spare parts
KDBB0512	WASHER PLAIN	Bajaj spare parts
KDBB0613	WASHER PLAIN	Bajaj spare parts
KDBB0818	WASHER PLAIN	Bajaj spare parts
KDBB1022	WASHER_PLAIN	Bajaj spare parts
KDBB1226	WASHER PLAIN-ID12.5XOD26XT2.3XGR	Bajaj spare parts
KDBC0512	WASHER PLAIN	Bajaj spare parts
KDBC0818	WASHER PLAIN	Bajaj spare parts
KDBE0613	WASHER PLAIN	Bajaj spare parts
KDBF0512	WASHER PLAIN-ID5.5XOD12XT0.8X	Bajaj spare parts
KDBF0613	WASHER PLAIN-ID6.5XOD13XT1XBLACK	Bajaj spare parts
KDCA0816	WASHER SPRING	Bajaj spare parts
KDCB0816	WASHER SPRING	Bajaj spare parts
KDDA0408	WASHER SPRING THIN	Bajaj spare parts
KDDA0509	WASHER SP THN-ID5.1XOD9.2XT1.2	Bajaj spare parts
KDDA0612	WASHER SPRING THIN	Bajaj spare parts
KDDA0815	WASHER SPRING THIN	Bajaj spare parts
KDDB0408	WASHER SPRING THIN	Bajaj spare parts
KDDB0509	WASHER SPRING THIN	Bajaj spare parts
KDDB0612	WASHER SPRING THIN	Bajaj spare parts
KDDB0815	WASHER SP THN-ID8.1XOD14.8XT2	Bajaj spare parts
KDDB1018	WASHER SPRING THIN	Bajaj spare parts
KDDB1221	WASHER SPRING THIN	Bajaj spare parts
KDDC0815	WASHER SPRING THIN	Bajaj spare parts
KDDD0815	WASHER SPRNG THN-ID8.2XOD15.4XT2	Bajaj spare parts
KDDD1221	WASHER SPRING THIN	Bajaj spare parts

KDDE0509	WASHER SPRING THN-ID4.1XOD7.6XT1	Bajaj spare parts
KDDF0815	WASHER SPRING-ID8.1XOD14.8XT2XBL	Bajaj spare parts
KDFB0815	Toothed washer(spares)	Bajaj spare parts
KDFB1018	WASHER TOOTHED INTERNAL	Bajaj spare parts
KDGB0611	WASHER TOOTHED EXTERNAL	Bajaj spare parts
KEAA1010	CIRCLIP EXTERNAL	Bajaj spare parts
KEAA1110	CIRCLIP	Bajaj spare parts
KEAA1210	CIRCLIP-EXTERNAL	Bajaj spare parts
KEAA1610	CIRCLIP EXTERNAL	Bajaj spare parts
KEAA1710	CIRCLIP	Bajaj spare parts
KEAA2012	CIRCLIP EXTERNAL	Bajaj spare parts
KEAA2212	CIRCLIP EXTERNAL	Bajaj spare parts
KEAA3215	CIRCLIP EXTERNAL	Bajaj spare parts
KEAB1010	CIRCLIP EXTERNAL	Bajaj spare parts
KEAB1210	CIRCLIP EXTERNAL	Bajaj spare parts
KEAB1310	CIRCLIP EXTERNAL	Bajaj spare parts
KEAB1610	CIRCLIP EXTERNAL	Bajaj spare parts
KEAB2412	CIRCLIP EXTERNAL	Bajaj spare parts
KEAB3015	CIRCLIP EXTERNAL	Bajaj spare parts
KEBA3012	CIRCLIP INTERNAL-OD 32.1XTHK 1.2	Bajaj spare parts
KEBA3212	CIRCLIP INTERNAL	Bajaj spare parts
KEBA3615	CIRCLIP INTERNAL	Bajaj spare parts
KEBA3715	CIRCLIP INTERNAL	Bajaj spare parts
KEBB3515	CIRCLIP INTERNAL	Bajaj spare parts
KEBB3715	CIRCLIP INTERNAL	Bajaj spare parts
KEBB4217	CIRCLIP INTERNAL	Bajaj spare parts
KEBB4717	CIRCLIP 47X17	Bajaj spare parts
KEBB5520	INTERNAL CIRCLIP	Bajaj spare parts
KEBB5620	CIRCLIP INTERNAL	Bajaj spare parts
KEBB6020	CIRCLIP-INTERNAL	Bajaj spare parts
KEBB6825	CIRCLIP INTERNAL	Bajaj spare parts
KECA0415	CIRCLIP-TYPE-E-ID	Bajaj spare parts
KECA2004	CIRCLIP TYPE E	Bajaj spare parts
KECA3006	CIRCLIP TYPE E	Bajaj spare parts
KECA4006	CIRCLIP TYPE E	Bajaj spare parts
KECA5006	CIRCLIP TYPE E	Bajaj spare parts
KECA6008	CIRCLIP TYPE - E	Bajaj spare parts
KECA7008	CIRCLIP TYPE E	Bajaj spare parts
KECB4006	CIRCLIP TYPE E	Bajaj spare parts
KECC0110	CIRCLIP TYPE E-ID10XOD20XT 1XBRT	Bajaj spare parts
KECE6008	CIRCLIP TYPE E-ID6XOD12	Bajaj spare parts
KFAB4050	KEY WOODRUFF	Bajaj spare parts
KFBA0412	KEY SUNK	Bajaj spare parts
KHAA1612	PIN COTTER	Bajaj spare parts
KHAA2012	PIN COTTER	Bajaj spare parts

KHAA2015	PIN SNAP	Bajaj spare parts
KHAA2018	PIN COTTER	Bajaj spare parts
KHAA2020	PIN COTTER	Bajaj spare parts
KHAA2025	PIN COTTER	Bajaj spare parts
KHAA2520	PIN COTTER	Bajaj spare parts
KHAA3225	PIN COTTER	Bajaj spare parts
KHAA3228	PIN COTTER	Bajaj spare parts
KHAA3230	PIN COTTER	Bajaj spare parts
KHAA3235	PIN COTTER	Bajaj spare parts
KHAC2518	PIN COTTER-DIA. 2.5XL 18	Bajaj spare parts
KHAE2012	PIN COTTER-DIA. 1.8 XL12 X GREEN	Bajaj spare parts
KHAE2518	PIN COTTER DIA 2.3	Bajaj spare parts
KHAE3220	PIN COTTER-DIA. 2.9 XL20 X GREEN	Bajaj spare parts
KHBA0828	PIN SNAP	Bajaj spare parts
KHBA1033	PIN SNAP	Bajaj spare parts
KHCA0418	PIN SPRING	Bajaj spare parts
KHCA0422	PIN SPRING	Bajaj spare parts
KHCA0432	PIN SPRING-DIA. 4.4XL 32	Bajaj spare parts
KHDA0306	PIN DOWEL	Bajaj spare parts
KHDA0312	PIN DOWEL	Bajaj spare parts
KHDA0314	PIN DOWEL	Bajaj spare parts
KHDA0408	PIN DOWEL	Bajaj spare parts
KHDA0425	PIN DOWEL	Bajaj spare parts
KHDA1014	PIN DOWEL	Bajaj spare parts
KHDD1014	PIN DOWEL-ID 6.5XOD 10XL 14	Bajaj spare parts
KHEA0845	PIN CLEVS WITH HOLE	Bajaj spare parts
KHEC0820	PIN CLEVIS WITH HOLE	Bajaj spare parts
KJAA1424	O RING	Bajaj spare parts
KJAA2024	O RING	Bajaj spare parts
KJAA3035	RING O HUB	Bajaj spare parts
KJAB1019	O RING	Bajaj spare parts
KJAB1424	O RING	Bajaj spare parts
KJAB4535	O RING	Bajaj spare parts
KJAC1824	O RING	Bajaj spare parts
KJAC3535	O RING	Bajaj spare parts
KMAA0800	BALL STEEL	Bajaj spare parts
KMAA1000	BALL STEEL	Bajaj spare parts
KPAA6001	BEARING BALL ORDINARY CLEARANCE	Bajaj spare parts
KPAA6200	BEARING BALL ORDINARY CLEARANCE	Bajaj spare parts
KPAA6202	BEARING BALL ORDINARY CLEARANCE	Bajaj spare parts
KPAC6000	BEARING BALL ORDINARY CLEARANCE	Bajaj spare parts
KPAC6005	BEARING BALL ORDINARY CLEAR	Bajaj spare parts
KPAC6205	BEARING BALL ORD. CL	Bajaj spare parts
KPAF6004	BEARING BALL-ORD CLEARANCE & HN3	Bajaj spare parts
KPBA6003	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts

KPBA6006	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBA6007	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBB6002	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBB6007	BEARING BALL C3	Bajaj spare parts
KPBB6200	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBB6201	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBB6202	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBB6300	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBB6301	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBB6302	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBC6004	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBC6202	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBC6204	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBC6301	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBC6302	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBF6201	BEARING BALL C3 CLEARANCES	Bajaj spare parts
KPBF6203	BEARING-BALL-C3 CLEARANCE-HN3	Bajaj spare parts
KPBF6304	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBF6305	BEARING-BALL-C3 CLEARANCE	Bajaj spare parts
KPBG6201	BEARING BALL C3 CLEARANCES	Bajaj spare parts
KPBG6202	BEARING BALL C3 CLEARANCES	Bajaj spare parts
LAA00007	BOLT HEX M10 X 1.25 X 50	Bajaj spare parts
LAA00008	BOLT -M7X1XL16XCL4.	Bajaj spare parts
LAA00009	BOLT -M6X1XL10XCL6.8XBLKXDOME HD	Bajaj spare parts
LAA00010	BOLT M4X0.7XL 13XS10CXBLACK	Bajaj spare parts
LAA00014	BOLT-M8X1.25XL 16	Bajaj spare parts
LAA00019	BOLT D # M8X1.25 L50	Bajaj spare parts
LAA00022	BOLT -M7X1XL23XCL12.9XPHOSPH	Bajaj spare parts
LAA00023	BOLT -M6X1XL 8.5XBLACKXSTEPPED	Bajaj spare parts
LAA00029	BOLT -M5 X L 22 X 2.5CH	Bajaj spare parts
LAA00030	BOLT -M6X1XL30XCL8.8XBLXSHEAR HD	Bajaj spare parts
LAA00032	BOLT -M8X1.25XL35XCL 12.9XBRIGHT	Bajaj spare parts
LAA00033	BOLT -M8X1.25XL57XOLV GRNXSTEPPED	Bajaj spare parts
LAA00034	BOLT D-M10X1.25XL36XCL8.8XBRIGHT	Bajaj spare parts
LAA00045	BOLT D-M8X1.25XL 26XBLACK	Bajaj spare parts
LAA00046	BOLT-M8X1.25XL 22XCL 8.8XBRIGHT	Bajaj spare parts
LAA00047	BOLT -M10X1.25XL 18XBRTXPRECOAT	Bajaj spare parts
LAA00048	BOLT-M5X0.8XL 80XCL 8.8XBRIGHTXSTEPPED	Bajaj spare parts
LAA00049	BOLT -M6X1XL 30XCL 8.8XBRIGHT	Bajaj spare parts
LAA00050	BOLT -M8X1.25XL 16XCL 8.8XBRIGHT	Bajaj spare parts
LAA00051	BOLT -M8X1.25XL 14XCL 8.8XBLACK	Bajaj spare parts
LAA00052	BOLT M8X1.25	Bajaj spare parts
LAA00054	BOLT -M6X1XL 9XCL 8.8XBRIGHT	Bajaj spare parts
LAA00056	BOLT -M10X1.25XL 23.5XBLKXSTEPED	Bajaj spare parts
LAA00063	ADAPTER	Bajaj spare parts

LAA00068	BOLT M8X1.25	Bajaj spare parts
LAA00073	BOLT STEP M6X1	Bajaj spare parts
LAA00078	BOLT M8X1.25	Bajaj spare parts
LAA00091	BOLT STEP M10X1.25	Bajaj spare parts
LAA00095	BOLT M10X1.25	Bajaj spare parts
LAA00098	BOLT D M8X1.25	Bajaj spare parts
LAC00001	BOLT SOCKET	Bajaj spare parts
LAC00002	BOLT SOCKET M6 X 25L	Bajaj spare parts
LAC00003	BOLT - SOCKET M5 X 0.8X L40	Bajaj spare parts
LAC00004	BOLT SOCKET M10X1.5PX60L	Bajaj spare parts
LAC00005	BOLT SOCKET M8 X 1.25 X 27	Bajaj spare parts
LAC00006	BOLT SOCKET M10 X 1.25 X 80	Bajaj spare parts
LAC00007	BOLT SOCKET M10 X 1.25 X 53	Bajaj spare parts
LAC00008	SCREW HEAD-BLACK	Bajaj spare parts
LAC00009	BOLT UPPER BRACKET	Bajaj spare parts
LAC00010	BOLT SOCKET	Bajaj spare parts
LAC00011	BOLT SOCKET M5 X 28L	Bajaj spare parts
LAC00013	BOLT SOCKET HEADED M8X1.25X30L	Bajaj spare parts
LAC00014	BOLT SPROCKET COVER MTG	Bajaj spare parts
LAC00016	BOLT SOCKET M8X35	Bajaj spare parts
LAC00017	BOLT SOCKET M8 X 1.25	Bajaj spare parts
LAC00019	BOLT SOCKET M10 X 1.25 X 55	Bajaj spare parts
LAC00020	BOLT SOCKET M8	Bajaj spare parts
LAC00021	BOLT SOCKET HEAD-M6	Bajaj spare parts
LAC00022	BOLT SOCKET-SPECIAL HEAD	Bajaj spare parts
LAC00023	BOLT SOCKET	Bajaj spare parts
LAC00024	BOLT M6X1X20L-PRECOATED	Bajaj spare parts
LAC00025	BOLT SOCKET M5X0.8X12	Bajaj spare parts
LAC00026	BOLT SOCKET-M6X1XL 20XCL 12.9	Bajaj spare parts
LAC00027	BOLT SOCKET HEAD	Bajaj spare parts
LAC00029	BOLT SOCKET HEAD	Bajaj spare parts
LAC00030	BOLT SOKET-M8X1.25XL30XCL10.9XBR	Bajaj spare parts
LAC00031	BOLT SCOKET HEAD M6 X	Bajaj spare parts
LAC00032	BOLT SOCKET HEAD M10	Bajaj spare parts
LAC00033	BOLT M6 X 10	Bajaj spare parts
LAC00034	BOLT M6 X 20	Bajaj spare parts
LAC00035	BOLT-SOCKET	Bajaj spare parts
LAC00036	BOLT SPECL SOCKET	Bajaj spare parts
LAC00037	BOLT SOC-SPECIAL HEAD	Bajaj spare parts
LAC00038	BOLT SOCKET HEAD M5 X 10	Bajaj spare parts
LAC00040	SCREW NUMBER PLT MTG	Bajaj spare parts
LAC00041	BOLT M6x16	Bajaj spare parts
LAC00042	BOLT SOCKET HEAD M6	Bajaj spare parts
LAC00044	BOLT SOCK-M10X1.5XL	Bajaj spare parts
LAC00045	BOLT SOCKET-M8X1.25	Bajaj spare parts

LAC00046	BOLT SOCKET-M8X1.25XL35XBRIGHT	Bajaj spare parts
LAC00048	BOLT SOCKET-M6X1XL35COAT	Bajaj spare parts
LAC00049	BOLT SOCKET-M6X1XL10XPRES-COAT	Bajaj spare parts
LAC00050	BOLT SOCKET-M8X1.25XL40XTAPR END	Bajaj spare parts
LAC00051	BOLT SOCKET-M5X0.8XL 14XPRES-COAT	Bajaj spare parts
LAC00052	BOLT SOCKET-M6X1XL 28	Bajaj spare parts
LAC00053	BOLT SOCKET-M8X1	Bajaj spare parts
LAC00054	BOLT SOCKET M6x1xL16x	Bajaj spare parts
LAC00055	BOLT SOCKET-M5X0.8XL 13XSTEPPED	Bajaj spare parts
LAC00057	BOLT SOCKET-M6X1XL 16XCL 8.8XBLK	Bajaj spare parts
LAC00058	BOLT SOCKET-M8X1.25XL 25XPRES-COAT	Bajaj spare parts
LAC00059	BOLT SOCKET-M8X1.25XL 25XPRES-COAT	Bajaj spare parts
LAC00060	BOLT SOCKET-M10X1.5XL 113XBRIGHT	Bajaj spare parts
LAC00061	BOLT SOCKET-M10X1.5XL 135XBRGT	Bajaj spare parts
LAC00062	BOLT SOCKET-M5X0.8XL33	Bajaj spare parts
LAC00063	BOLT SOCKET-M6	Bajaj spare parts
LAC00065	BOLT SOKET-M8X1.25XL33XCL10.9XBR	Bajaj spare parts
LAC00067	BOLT SOCKET-M8X1.25XL 27XPRES.	Bajaj spare parts
LAC00068	BOLT SOCKET-M6X1XL 14XS.S.XDACRO	Bajaj spare parts
LAC00069	BOLT SOCKET-M5X0.8XL 10XPRES	Bajaj spare parts
LAC00071	BOLT SOCKET-M6X1XL20XHD	Bajaj spare parts
LAC00072	BOLT SOCKET-M5X0.8XL 14	Bajaj spare parts
LAC00073	BOLT SOCKET-M6X1XL 14XPRES	Bajaj spare parts
LAC00074	BOLT SOCKET-M8X1.25XL 42XPRES-COAT	Bajaj spare parts
LAC00075	BOLT SOKET-M6X1XL189XDACROTIZING	Bajaj spare parts
LAC00076	BOLT SOCKET-M10X1XL 32XSTEPDXBRT	Bajaj spare parts
LAC00077	BOLT SOCKET-M8X1XL 32XSTEPDXGRN	Bajaj spare parts
LAC00078	BOLT SOCKET-M8X1.25XL20XPRES-COAT	Bajaj spare parts
LAC00079	BOLT SOCKET-M8X1.25XL35XPRES-COAT	Bajaj spare parts
LAC00082	BOLT SOCKET-M6X1XL20XHD HT.4XBLK	Bajaj spare parts
LAC00084	BOLT SOCKET-M6X1XL 14XPRES-COAT	Bajaj spare parts
LAC00085	BOLT SOCKET-M10X1.25XL62XPRES-COAT	Bajaj spare parts
LAC00086	BOLT SOCKET-M8X1XL40	Bajaj spare parts
LAC00087	BOLT SOCKET-M8X1XL40XPHOSPHATISE	Bajaj spare parts
LAC00089	BOLT SOCKET-M8 X 1.25	Bajaj spare parts
LAC00090	BOLT SOCKET-M8X1.25XL 28XSTEPPED	Bajaj spare parts
LAC00091	BOLT SOCKET-M10X1.25XL100XBRIGHT	Bajaj spare parts
LAC00092	BOLT SOKET-M10X1.25XL73XCL8.8XBRT	Bajaj spare parts
LAC00093	BOLT SOKET-M8X1.25XL25XBLXPRES-COT	Bajaj spare parts
LAC00094	BOLT SOKET-M6X1XL36.5XBLKXSTEPED	Bajaj spare parts
LAC00095	BOLT SOKET-M8X1.25XL30XBLXPRES-COT	Bajaj spare parts
LAC00096	BOLT SOKET-M8X1.25XL40XBLXPRES-COT	Bajaj spare parts
LAC00098	BOLT SOCKET-M10X1.25XL128XBRIGHT	Bajaj spare parts
LAC00099	BOLT SOKET-M6X1XL13XS.S.XFL.HEAD	Bajaj spare parts
LAC00100	BOLT SOCKET-M8X1.25XL 31XBLACK	Bajaj spare parts



LAC00101	BOLT SOCKET-M6X1XL 24.5XBLKXSTEP	Bajaj spare parts
LAC00102	BOLT SOCKET-M6X1XL 8XCL 8.8XGRN	Bajaj spare parts
LAC00103	BOLT SOCKET-M8X1.25XL 29XBRIGHT	Bajaj spare parts
LAC00104	BOLT SOKET-M8X1.25XL39.3XPRECOAT	Bajaj spare parts
LAC00105	BOLT SOCKET-M10X1.25XL55XPRECOAT	Bajaj spare parts
LAC00106	BOLT SOKET-M10X1.25XL143.75XSTEP	Bajaj spare parts
LAC00107	BOLT SOCKET-M6X1XL102XBRTXSTEPED	Bajaj spare parts
LAC00108	BOLT SOCKET-M6X1XL20XHD HT.4XBRT	Bajaj spare parts
LAC00109	BOLT SOCKET-M6X1XL10XBRTXPRECOAT	Bajaj spare parts
LAC00110	BOLT SOCKET-M6X1XL35XBRTXPRECOAT	Bajaj spare parts
LAC00111	BOLT SOCKET-M8X1.25XL 29XBLACK	Bajaj spare parts
LAC00112	BOLT SOCKET-M6X1XL40XCL10.9XBLAK	Bajaj spare parts
LAC00113	BOLT SOCKET-M8X1.25XL25XCL8.8XBL	Bajaj spare parts
LAC00114	BOLT SOCKET-M6X1XL14XCL8.8XBLACK	Bajaj spare parts
LAC00115	BOLT SOCKET-M6X1XL18XCL8.8XBLACK	Bajaj spare parts
LAC00116	BOLT SOCKET-M6X1XL55XCL8.8XBLACK	Bajaj spare parts
LAC00118	BOLT SOCKET-M8X1.25XL18XCL8.8XBL	Bajaj spare parts
LAC00119	BOLT SOCKET-M8X1.25XL22XCL8.8XBL	Bajaj spare parts
LAC00120	BOLT SOCKET-M6X1XL 35XCL 8.8XBLK	Bajaj spare parts
LAC00121	BOLT SOCKET-M8X1.25XL 35XPRECOAT	Bajaj spare parts
LAC00122	BOLT SOCKET-M6X1XL 24XPRECOAT	Bajaj spare parts
LAC00124	BOLT SOCKET-M10X1.5XL 35XBLACK	Bajaj spare parts
LAC00125	BOLT SOCKET-M6X1XL45XCL 10.9XBLK	Bajaj spare parts
LAC00126	BOLT SOCKET-M10X1.5XL 25XBRIGHT	Bajaj spare parts
LAC00127	BOLT SOCKET-M8 X 1.25 X L35 X SS	Bajaj spare parts
LAC00128	BOLT SOCKET-M8X1.25XL25XBRTXSTEP	Bajaj spare parts
LAC00130	BOLT SOCKET-M10X1.25XL 55XBRIGHT	Bajaj spare parts
LAC00131	BOLT SOCKET-M10X1.5XL 25XPRECOAT	Bajaj spare parts
LAC00132	BOLT SOCKET-M12X1.5XL 27.5XBRT	Bajaj spare parts
LAC00133	BOLT SOCKET-M6	Bajaj spare parts
LAC00135	BOLT SOKET-M10X1.5XL70XCL10.9XBR	Bajaj spare parts
LAC00136	BOLT SOKET-M8X1.25XL25XBLXPRECOT	Bajaj spare parts
LAC00139	BOLT SOCKET M10X1.5	Bajaj spare parts
LAC00141	BOLT SOCKET-M8X1.25XL 25XBLACK	Bajaj spare parts
LAC00142	BOLT SOCKET-M10X1.5XL 80XPRECOAT	Bajaj spare parts
LAC00144	BOLT SOCKET-M10X1XL32XBLXPRECOAT	Bajaj spare parts
LAC00148	BOLT SOCKET-M10X1.25XL 95XBRIGHT	Bajaj spare parts
LAC00149	BOLT SOCKET-M6X1XL15XCL 10.9XBLK	Bajaj spare parts
LAC00150	BOLT SOCKET-M8X1.25XL10XBLKXSTEP	Bajaj spare parts
LAC00151	BOLT SOCKET-M5X0.8XL 28XPRECOAT	Bajaj spare parts
LAC00152	BOLT SOCKET-M6X1XL25XBLKXPRECOAT	Bajaj spare parts
LAC00153	BOLT SOCKET-M8X1.25XL 18XPRECOAT	Bajaj spare parts
LAC00154	BOLT SOCKET-M8X1.25XL 60XPRECOAT	Bajaj spare parts
LAC00155	BOLT SOCKET-M10X1.5XL 30XPRECOAT	Bajaj spare parts
LAC00156	BOLT SOCKET-M10X1.5XL50XBRIGHT	Bajaj spare parts

LAC00157	BOLT FLANGED M10X1.25	Bajaj spare parts
LAC00158	BOLT SOCKET-M5X0.8XL 30XPRECOAT	Bajaj spare parts
LAC00161	BOLT SOCKET M6X1	Bajaj spare parts
LAC00162	BOLT SOCKET M10X1.25	Bajaj spare parts
LAC00163	BOLT SOCKET M12X1.25	Bajaj spare parts
LAC00164	BOLT SOCKET M8X1.25	Bajaj spare parts
LAC00165	BOLT SOCKET M8X1.25	Bajaj spare parts
LAC00166	BOLT SOCKET STEP M8X1.25	Bajaj spare parts
LAC00179	BOLT SOCKET M8X1.25	Bajaj spare parts
LAC00181	BOLT SOCKET M6X1	Bajaj spare parts
LAC00183	BOLT SOCKET M5X0.8	Bajaj spare parts
LAC00184	BOLT SOCKET M6X1	Bajaj spare parts
LAC00185	BOLT SOCKET M8X1.25	Bajaj spare parts
LAC00187	BOLT SOCKET M6X1	Bajaj spare parts
LAC00191	BOLT SOCKET STEP M6X1	Bajaj spare parts
LAC00194	BOLT SOCKET M6X1	Bajaj spare parts
LAC00195	BOLT SOCKET M6X1	Bajaj spare parts
LAC00196	BOLT SOCKET M6X1	Bajaj spare parts
LAC00197	BOLT SOCKET STEP M10X1.5	Bajaj spare parts
LAC00198	BOLT SOCKET M6X1	Bajaj spare parts
LAC00202	BOLT SOCKET M8X1.25	Bajaj spare parts
LAC00204	BOLT SOCKET M10X1.25	Bajaj spare parts
LAC00205	BOLT SOCKET M8X1.25	Bajaj spare parts
LAC00208	BOLT SOCKET STEP M6X1	Bajaj spare parts
LAC00213	BOLT SOCKET STEP M10X1.25	Bajaj spare parts
LAC00216	BOLT SOCKET M8X1.25	Bajaj spare parts
LAC00217	BOLT SOCKET M8X1.25	Bajaj spare parts
LAD00001	BOLT FLANGED	Bajaj spare parts
LAD00002	BOLT FL-M8X1.25XL 75XCL 12.9	Bajaj spare parts
LAD00003	BOLT FL-M6X1XL 112XCL 9.8XDACRO	Bajaj spare parts
LAD00006	BOLT FL-M10X1.25XL110XCL10.9XBRIGHT	Bajaj spare parts
LAD00010	BOLT HEX FLANGE M8 X	Bajaj spare parts
LAD00011	BOLT FLANGED M6X1X20	Bajaj spare parts
LAD00017	BOLT FLANGED M5X0.8X16	Bajaj spare parts
LAD00018	BOLT FLANGED M5X0.8X10	Bajaj spare parts
LAD00034	BOLT FLANGED-M12X1.25XL94XBRIGHT	Bajaj spare parts
LAD00035	BOLT FLANGE M6X1-40L PRE COATE	Bajaj spare parts
LAD00036	BOLT FLANGED M8X1.25X37	Bajaj spare parts
LAD00037	BOLT FLANGED M8X1X50	Bajaj spare parts
LAD00038	BOLT FLANGED-M10 X 1.25P X 265L	Bajaj spare parts
LAD00039	BOLT FLANGED-M10 X 1.25P X 92L	Bajaj spare parts
LAD00040	BOLT FOR DH161421	Bajaj spare parts
LAD00041	BOLT FLANGED M8 X 1.25P X	Bajaj spare parts
LAD00042	BOLT FLANGED BOLT M8X1.25PX30L	Bajaj spare parts
LAD00043	BOLT FLANGED - STEPPED - M6	Bajaj spare parts

LAD00044	BOLT FL M10 X 1.25PX25L	Bajaj spare parts
LAD00045	HEXAGON BOLT WITH FLANGE	Bajaj spare parts
LAD00046	BOLT PIVOT - MASK CARRIER	Bajaj spare parts
LAD00048	BOLT FLANGED M8 X 1.25P X	Bajaj spare parts
LAD00049	BOLT HEX M8X1.25	Bajaj spare parts
LAD00050	BOLT M8X1.25	Bajaj spare parts
LAD00051	BOLT HEX WITH FLANGE M8X1	Bajaj spare parts
LAD00052	BOLT FFLANGED M8	Bajaj spare parts
LAD00053	BOLT FLANGE M6X1-L10	Bajaj spare parts
LAD00061	BOLT FLANGED M8*1.25*110L	Bajaj spare parts
LAD00062	BOLT FLANGED M6X1X105L	Bajaj spare parts
LAD00063	BOLT FLANGED	Bajaj spare parts
LAD00064	BOLT FLANGED-M6X1XL 20XPRES-COAT	Bajaj spare parts
LAD00065	BOLT FLANGED-M8X1.25XL 40	Bajaj spare parts
LAD00066	BOLT FLANGED-M5X0	Bajaj spare parts
LAD00067	BOLT FLANGED-M5X0.8XL	Bajaj spare parts
LAD00068	BOLT FLANGED-M10X1.25XL88XCL10.9	Bajaj spare parts
LAD00069	BOLT FLANGED-M8X1.	Bajaj spare parts
LAD00070	BOLT FLANGE-M6X1XL20	Bajaj spare parts
LAD00071	BOLT FLANGE-M10X1.25XL136XCL	Bajaj spare parts
LAD00072	BOLT FLANGED-M6X1XL9XSTEPPEDXBLK	Bajaj spare parts
LAD00073	BOLT FLANGED-M8X1.25XL16	Bajaj spare parts
LAD00074	BOLT M5	Bajaj spare parts
LAD00075	BOLT HEX HD BOLT/FLANG-M8	Bajaj spare parts
LAD00076	BOLT FLANGE M 5 X 50	Bajaj spare parts
LAD00077	BOLT FLANGED M6X16	Bajaj spare parts
LAD00079	BOLT FLANGED	Bajaj spare parts
LAD00080	BOLT FLANGED	Bajaj spare parts
LAD00081	BOLT FLANGED M6X1X60L-PRECOATED	Bajaj spare parts
LAD00082	HH COLLAR SCREW M6X12	Bajaj spare parts
LAD00084	BOLT FLANGED	Bajaj spare parts
LAD00085	BOLT M6X1	Bajaj spare parts
LAD00087	BOLT FLANGE M14X1.5XL95	Bajaj spare parts
LAD00091	BOLT FLANGED - M6X1	Bajaj spare parts
LAD00093	BOLT M6 (ABS SENSOR MTG)	Bajaj spare parts
LAD00094	BOLT ABS CLAMP	Bajaj spare parts
LAD00095	BOLT FLANGED-M5X0.8XL	Bajaj spare parts
LAD00097	BOLT CAMSHAFT	Bajaj spare parts
LAD00099	BOLT FLANGED M8X1.25X40L	Bajaj spare parts
LAD00100	BOLT FLANGED M10X1.25X95	Bajaj spare parts
LAD00102	BOLT STEP M6	Bajaj spare parts
LAD00104	BOLT FLANGED	Bajaj spare parts
LAD00105	BOLT FLANGED-M10X1.5XL 25XA/F 12	Bajaj spare parts
LAD00106	BOLT FLANGED-M6X1XL	Bajaj spare parts
LAD00107	BOLT FLANGED-M16 X 1	Bajaj spare parts

LAD00108	AXLE -M14X1.5XL274XCL10.9XBRIGHT	Bajaj spare parts
LAD00109	BOLT FLANGED-M6X1XL 20XPRECOAT	Bajaj spare parts
LAD00110	BOLT FLANG-M12X1.25XL25XTAPR END	Bajaj spare parts
LAD00111	BOLT FLANG-M12X1.25XL60XTAPR END	Bajaj spare parts
LAD00112	BOLT FLANGED-M5X0.8XL 55XPRE.	Bajaj spare parts
LAD00113	BOLT FLANGED-M6X1XL 30XTAPER	Bajaj spare parts
LAD00114	BOLT FLANGE-M10X1.25XL175XBRIGHT	Bajaj spare parts
LAD00116	BOLT FLANG-M10X1.25XL40XTAPR END	Bajaj spare parts
LAD00117	BOLT FLANGED-M8X1XL70XPRECOAT	Bajaj spare parts
LAD00118	BOLT FLANG-M10X1.25XL125XPR	Bajaj spare parts
LAD00119	BOLT FLANGE-M8X1.25XL45XTAPR	Bajaj spare parts
LAD00120	BOLT FLANGED-M8X1.25XL75XPRECOAT	Bajaj spare parts
LAD00121	BOLT FLANGED-M8X1.25XL130XCL12.9	Bajaj spare parts
LAD00122	BOLT FLANGED-M8X1.25XL80XCL 12.9	Bajaj spare parts
LAD00124	BOLT FLANGE-M10X1.25XL 55XBR	Bajaj spare parts
LAD00126	BOLT FLANGED-M8X1.25XL20XSTEP	Bajaj spare parts
LAD00127	BOLT FLANGED-M6X1XL9XSTEPPED	Bajaj spare parts
LAD00128	BOLT FLANGE-M10X1XL30XCL10.9XGRN	Bajaj spare parts
LAD00129	BOLT FLANGE-M6X1XL18.5-TL11XSTEP	Bajaj spare parts
LAD00131	BOLT FLANGED-M10X1.5XL47XOLV GRN	Bajaj spare parts
LAD00133	BOLT FLANGE-M10X1.25XL25XSTEPPED	Bajaj spare parts
LAD00134	BOLT FLANGE-M8X1.25XL60XCL12	Bajaj spare parts
LAD00135	BOLT FLANGE-M8X1.25XL70XCL12	Bajaj spare parts
LAD00136	BOLT FLANGED M10X1.25XL87.3XCL10.9	Bajaj spare parts
LAD00137	BOLT FLANGED-M10X1.5XL55XOLV GRN	Bajaj spare parts
LAD00138	BOLT FLANGED-M8X1.25XL 219XDACRO	Bajaj spare parts
LAD00140	BOLT FLANGE-M6X1XL30XGRNXPRECOAT	Bajaj spare parts
LAD00141	BOLT FLANGED-M6X1XL 46XSTEPPED	Bajaj spare parts
LAD00142	BOLT FLANGED-M6X1XL 73XSTEPPED	Bajaj spare parts
LAD00143	BOLT FLANGED-M10X1.5XL60XBRIGHT	Bajaj spare parts
LAD00145	BOLT FLANGE-M8X1.25XL26XBRTXSTEP	Bajaj spare parts
LAD00148	BOLT FLANG-M8X1.25XL35XCL10.9XBR	Bajaj spare parts
LAD00149	BOLT FLANGE-M8X1.25XL25XCL8.8XBR	Bajaj spare parts
LAD00150	BOLT FLANGED-M6X1XL140XCL8.8XBRT	Bajaj spare parts
LAD00151	BOLT FLANGE-M8X1.25XL 21.5XGREEN	Bajaj spare parts
LAD00153	BOLT FL-M10X1.25XL158XCL12.9XBRT	Bajaj spare parts
LAD00154	BOLT FLANGE-M6X1XL 12.8XBRTXSTEP	Bajaj spare parts
LAD00155	BOLT FL-M10X1.25XL174XCL12.9XDAC	Bajaj spare parts
LAD00157	BOLT FL-M10X1.25XL280XCL10.9XBLK	Bajaj spare parts
LAD00158	BOLT FL-M10X1.25XL105XCL10.9XBLK	Bajaj spare parts
LAD00159	BOLT FLANGE-M6X1XL12XCL 10.9XBRT	Bajaj spare parts
LAD00160	BOLT FLANGE-M6X1XL20XCL 10.9XBLK	Bajaj spare parts
LAD00162	BOLT FLANG-M8X1.25XL25XCL10.9XBL	Bajaj spare parts
LAD00163	BOLT FLANGE-M12X1.25XL10XPRECOAT	Bajaj spare parts
LAD00164	BOLT FL-M10X1.5XL78.5XCL12.9XDCR	Bajaj spare parts

LAD00165	BOLT FLANGE-M5X0.8XL14XCL4.8XGRN	Bajaj spare parts
LAD00166	BOLT FLANGED-M6X1XL35XCL 8.8XBRT	Bajaj spare parts
LAD00167	BOLT FLANGED-M8X1.25XL 215XDACRO	Bajaj spare parts
LAD00168	BOLT FLANGE-M10X1.25XL 18XBRTXPRECOAT	Bajaj spare parts
LAD00169	BOLT FLANGED-M6X1XL26XCL 10.9XBRT	Bajaj spare parts
LAD00170	BOLT FL-M10X1.25XL50XBRTXPRECOAT	Bajaj spare parts
LAD00171	BOLT FL-M10X1.25XL 130XBRXTAPING	Bajaj spare parts
LAD00174	BOLT FLANG-M10X1.25XL35XBRTXSTEP	Bajaj spare parts
LAD00176	BOLT SHIFT CHANGE M8X1.25	Bajaj spare parts
LAD00178	BOLT FLANGE-M10X1.25XL131XBRIGHT	Bajaj spare parts
LAD00179	BOLT FLANG-M8X1.25XL35XCL9.8XBRT	Bajaj spare parts
LAD00180	BOLT FLANGE-M8X1.25XL 20XPRECOAT	Bajaj spare parts
LAD00183	BOLT FLANGE-M6X1XL16XCL 10.9XBLK	Bajaj spare parts
LAD00184	BOLT FLANGED-M8X1.25XL16XPRECOAT	Bajaj spare parts
LAD00186	BOLT FLANGE-M6X1XL 16XCL 8.8XBLK	Bajaj spare parts
LAD00188	BOLT FLANGE-M10X1.25XL196XBRIGHT	Bajaj spare parts
LAD00189	BOLT FLANGE-M6X1XL 22XCL 8.8XBLK	Bajaj spare parts
LAD00190	BOLT FLANGED-M10X1.25XL55XBLACK	Bajaj spare parts
LAD00191	BOLT FLANGED-M8X1.25XL 20XBRIGHT	Bajaj spare parts
LAD00192	BOLT FLANGE-M12X1.25XL40XCL8.8BR	Bajaj spare parts
LAD00193	BOLT FLANGED-M16X1.5XL30XPRECOAT	Bajaj spare parts
LAD00194	BOLT FLANGE-M6X1XL 12.5XSTEPXBLK	Bajaj spare parts
LAD00195	BOLT FLANGE-M6X1XL 12XSTEPXBLACK	Bajaj spare parts
LAD00196	BOLT FLANGE-M6X1XL12XCL8.8XBLACK	Bajaj spare parts
LAD00197	BOLT FLANGE-M8X1.25XL14XCL8.8XBL	Bajaj spare parts
LAD00198	BOLT FLANGE-M8X1.25XL30XCL8.8XBL	Bajaj spare parts
LAD00199	BOLT FLANGE-M8X1.25XL50XCL8.8XBL	Bajaj spare parts
LAD00200	BOLT FLANGE-M8X1.25XL70XCL9.8XBL	Bajaj spare parts
LAD00201	BOLT FBOLT FLANGED-M10X1.25XL115XBLXSTEP	Bajaj spare parts
LAD00202	BOLT FLANGE-M6X1XL10XCL8.8XBLACK	Bajaj spare parts
LAD00205	BOLT FLANGE-M6X1XL85XCL 8.8 X GREEN	Bajaj spare parts
LAD00206	BOLT FLANGE-M6X1XL20XCL 10.9XBLK	Bajaj spare parts
LAD00207	BOLT M6X1XL9XGRNXSTEPPEDEXPRECOAT	Bajaj spare parts
LAD00208	BOLT FLANGE-M6X1XL20XCL 10.9XBRT	Bajaj spare parts
LAD00211	BOLT FLANGE-M10X1.5XL9XCL8.8XBRT	Bajaj spare parts
LAD00212	BOLT FL-M8X1.25XL 39.3XBRIGHTXPRECOAT	Bajaj spare parts
LAD00216	BOLT FLANGED-M10 X 1.5P X L85	Bajaj spare parts
LAD00217	BOLT FLANGED-M6X1XL20XBRIGHT	Bajaj spare parts
LAD00218	BOLT FL-M8X1.25XL 40XBLKXPRECOAT	Bajaj spare parts
LAD00219	BOLT FLANG-M6X1XL19XCL4.6XBRXSTP	Bajaj spare parts
LAD00220	BOLT FLANG-M6X1XL12XCL4.6XBLXSTP	Bajaj spare parts
LAD00222	BOLT FLANGED M12X1.5	Bajaj spare parts
LAD00228	BOLT FLANGE-M6X1XL19XBRIGHTXSTEP	Bajaj spare parts
LAD00229	BOLT FLANG-M8X1.25XL22XBLXPRECOT	Bajaj spare parts
LAD00230	BOLT FLANGED M8X1	Bajaj spare parts

LAD00231	BOLT FLANGE-M10X1.25XL39XBLXSTEP	Bajaj spare parts
LAD00232	BOLT FL-M5X0.8XL14XDACROXPRECOAT	Bajaj spare parts
LAD00233	BOLT FLANGED STEP M6X1	Bajaj spare parts
LAD00236	BOLT FLANGED-M8X1.25XL50	Bajaj spare parts
LAD00244	BOLT FLANGED-M6X1XL22XBRXPRECOAT	Bajaj spare parts
LAD00246	BOLT FLANGE-M10X1.25XL170XBRIGHT	Bajaj spare parts
LAD00253	AXLE -M14X1.5XL290XCL 8.8XBRIGHT	Bajaj spare parts
LAD00261	BOLT FLANGED M8X1.25	Bajaj spare parts
LAD00262	BOLT FLANGED STEP M5X0.8	Bajaj spare parts
LAD00263	BOLT FLANGED M8.5X0.75	Bajaj spare parts
LAD00264	BOLT FLANGED M10X1.25	Bajaj spare parts
LAD00266	BOLT FLANGED STEP M5X0.8	Bajaj spare parts
LAD00267	BOLT FLANGED M8X1.25	Bajaj spare parts
LAD00269	BOLT FLANGED STEP M6X1	Bajaj spare parts
LAD00270	BOLT FLANGED STEP M6X1	Bajaj spare parts
LAD00272	BOLT FLANGED STEP M6X1	Bajaj spare parts
LAD00273	BOLT FLANGED M8X1.25	Bajaj spare parts
LAD00274	BOLT FLANGED M8X1.25	Bajaj spare parts
LAD00275	BOLT FLANGED M8X1.25	Bajaj spare parts
LAD00278	BOLT FLANGED M6X1	Bajaj spare parts
LAD00284	BOLT FLANGED M10X1.25	Bajaj spare parts
LAD00290	BOLT FLANGED STEP M6X1	Bajaj spare parts
LAD00297	BOLT FLANGED M8X1.25	Bajaj spare parts
LAD00300	BOLT FLANGED STEP M6X1	Bajaj spare parts
LAD00301	BOLT FLANGED STEP M6X1	Bajaj spare parts
LAD00311	BOLT FLANGED STEP M6X1	Bajaj spare parts
LAD00313	BOLT FLANGED M12X1.25	Bajaj spare parts
LAD00315	BOLT FLANGED M8X1.25	Bajaj spare parts
LAD00318	BOLT FLANGED M6X1	Bajaj spare parts
LAD00319	BOLT FLANGED M8X1.25	Bajaj spare parts
LAE00001	BOLT FLANGED - M8 X 1.25P X 30L	Bajaj spare parts
LAE00002	BOLT FLANGED M6 X 1 X 75	Bajaj spare parts
LAE00005	BOLT FLANGED-M6X1XL 20XPRECOAT	Bajaj spare parts
LAE00006	BOLT FLANGED SMALL	Bajaj spare parts
LAE00010	BOLT FLANGE M5 X 13L	Bajaj spare parts
LAE00011	BOLT FLANGE M8 X 16L	Bajaj spare parts
LAE00014	BOLT FLANGED M5X10	Bajaj spare parts
LAE00015	BOLT FLANGED M6X14	Bajaj spare parts
LAE00016	BOLT FL M5X0.8X6L-PRECOAT.	Bajaj spare parts
LAE00017	BOLT M6X1X10L-PRECOATED	Bajaj spare parts
LAE00018	BOLT FLANGED M6X1X30L-PRECOATED	Bajaj spare parts
LAE00019	BOLT FLANGED M5X0.8PX8L	Bajaj spare parts
LAE00020	BOLT FLANGED M6X14 PRE	Bajaj spare parts
LAE00021	BOLT FLANGED M6X12	Bajaj spare parts
LAE00022	BOLT FLANGED M6X10 PRE	Bajaj spare parts

LAE00023	BOLT FLANG SMAL-M6	Bajaj spare parts
LAE00024	BOLT FLANG SMAL-M6X1XL55XPR	Bajaj spare parts
LAE00025	BOLT FLANGED SMALL-M6X1XL 85	Bajaj spare parts
LAE00026	BOLT FLANG SMAL-M6X1XL 8XPRES	Bajaj spare parts
LAE00033	BOLT FL-M6X1XL32.5XCL8.8XBRXSTEP	Bajaj spare parts
LAE00034	BOLT FL-M8X1.25XL23.5XBLKXSTEPED	Bajaj spare parts
LAE00035	BOLT FLANGE SMAL-M6X1XL16XBRIGHT	Bajaj spare parts
LAE00037	BOLT FL-M8X1.25XL 45XCL 10.9XBRT	Bajaj spare parts
LAE00040	BOLT FLANGE SMALL-M6X1XL25XSTEPPED	Bajaj spare parts
LAE00041	BOLT FLNG-M6X1XL14XDACROXPRES	Bajaj spare parts
LAE00042	BOLT FLANGE-M6X1XL16XGRNXPRES	Bajaj spare parts
LAE00043	BOLT FLANGED STEP M6X1	Bajaj spare parts
LAE00045	BOLT FLANG-M8X1.25XL27XCL10.9XBR	Bajaj spare parts
LAE00046	BOLT FLANG SMAL-M8X1.25XL19XS.S.	Bajaj spare parts
LAE00048	BOLT FLANGE-M6X1XL10XBRTXPRES	Bajaj spare parts
LAE00049	BOLT FLANGE-M6X1XL14XBRTXPRES	Bajaj spare parts
LAE00050	BOLT FLANGED SMALL-M6X1XL8XBLACK	Bajaj spare parts
LAE00051	BOLT FLANGE SMALL-M6X1XL18XBLACK	Bajaj spare parts
LAE00052	BOLT FLANGED SMALL-M6X1XL14XSS	Bajaj spare parts
LAE00053	BOLT FLANGE SMALL-M5X0.8XL10XBLK	Bajaj spare parts
LAE00054	BOLT FLANGE-M6X1XL8XSTEPEDXBLACK	Bajaj spare parts
LAE00055	BOLT FLANGE-M6X1XL16XCL8.8XBLACK	Bajaj spare parts
LAE00056	BOLT FLANGE-M6X1XL20XCL8.8XBLACK	Bajaj spare parts
LAE00057	BOLT FLANGE-M6X1XL25XCL8.8XBLACK	Bajaj spare parts
LAE00059	BOLT -M8X1.25XL 35XCL 10.9XBRT	Bajaj spare parts
LAE00060	BOLT FLANGE-M8X1.25XL23XCL8.8XBR	Bajaj spare parts
LAE00061	BOLT FLANGE-M6X1XL12XCL 10.9XBLK	Bajaj spare parts
LAE00062	BOLT FLANGE-M6X1XL35XCL 10.9XBLK	Bajaj spare parts
LAE00063	BOLT FLANGE-M5X0.8XL20XCL10.9XBR	Bajaj spare parts
LAE00067	BOLT FLANGED M6X1	Bajaj spare parts
LAE00071	BOLT FLANGED M8X1.25	Bajaj spare parts
LAE00075	BOLT FLANGED M8X1.25	Bajaj spare parts
LAE00077	BOLT FLANGED M6X1	Bajaj spare parts
LAE00082	BOLT FLANGED M6X1	Bajaj spare parts
LAG00001	BOLT WP-M6X1XL 12XCL 8.8XBRIGHT	Bajaj spare parts
LAG00002	BOLT WP-M6X1XL16XCL8.8XGREEN	Bajaj spare parts
LAG00003	BOLT WP-M6X1XL20XCL4.8XBRXPRES	Bajaj spare parts
LAG00004	BOLT WP-M8X1.25XL 75XCL 10.9XBRT	Bajaj spare parts
LAG00006	BOLT WP-M10X1.5XL45XCL8.8XBRIGHT	Bajaj spare parts
LAG00007	BOLT WP-M6X1XL14XCL8.8XBRIGHT	Bajaj spare parts
LAG00008	BOLT WP-M8X1.25XL 40XCL 8.8XBRT	Bajaj spare parts
LAG00010	BOLT WP-M6X1XL 14XCL 8.8XGREEN	Bajaj spare parts
LAG00011	BOLT WP-M8X1.25XL 45XCL 8.8XBRT	Bajaj spare parts
LAH00001	BOLT WSP-M6X1XL47XCL 8.8XOLV GRN	Bajaj spare parts
LAJ00001	BOLTSTUD M6 PR COATE	Bajaj spare parts

LAJ00002	BOLT STUD-M8X1.25XL41XS45CXGREEN	Bajaj spare parts
LAJ00003	BOLT STUD-M8X1.25XL20.5XS45CXBRT	Bajaj spare parts
LAJ00013	BOLT STUD-M10X1.25XL 224XBRIGHT	Bajaj spare parts
LAJ00014	BOLT STUD-M10X1.25XL 153XBRIGHT	Bajaj spare parts
LAJ00015	BOLT STUD-M10X1.25XL 147XBRIGHT	Bajaj spare parts
LAJ00016	BOLT STUD-M8X1.25XL25XCL 10.9	Bajaj spare parts
LAJ00018	BOLT STUD-M10X1.25XL 144XBRIGHT	Bajaj spare parts
LAJ00019	BOLT STUD-M10X1.25XL20XBRXPRECOAT	Bajaj spare parts
LAJ00020	BOLT STUD-M10X1.25XL 153XBRIGHT	Bajaj spare parts
LAJ00021	BOLT STUD-M10X1.25XL 161XBRIGHT	Bajaj spare parts
LAJ00022	BOLT STUD M10X1.25	Bajaj spare parts
LAJ00027	BOLT STUD-M10X1.25XL22.5XPRECOAT	Bajaj spare parts
LAJ00028	BOLT STUD-M10X1.25XL 25XPRECOAT	Bajaj spare parts
LAM00001	BOLT WSP-M6X1XL 45XCL 8.8XBRIGHT	Bajaj spare parts
LAM00002	BOLT SOCKET WSP M6X1	Bajaj spare parts
LBA00001	SCREW PAN+-M6X1XL35-TL25XPRECOAT	Bajaj spare parts
LBA00002	SCREW PAN-M5X0.8XL28.4XGRNXSTEPED	Bajaj spare parts
LBB00001	SCREW PAN CROSS M5X0.8X12	Bajaj spare parts
LBB00005	BOLT SCREW PAN CROS	Bajaj spare parts
LBB00006	SCREW PAN HEAD M5X0	Bajaj spare parts
LBB00007	SCREW -M6X1XL12XPR	Bajaj spare parts
LBB00008	SCREW PAN CROSS-M6X1XL25XPRECOAT	Bajaj spare parts
LBB00010	SCREW PAN CROS-M5	Bajaj spare parts
LBB00011	SCREW PAN CROS-M5X0.8XL12XPRECOT	Bajaj spare parts
LBB00012	SCREW PAN CROSS-M6X1XL10XPRECOAT	Bajaj spare parts
LBB00013	SCREW PAN CROS-M5X0.8XL16.5XSTEP	Bajaj spare parts
LBB00014	SCREW PAN CROS-M5X0.8XL12XBRIGHT	Bajaj spare parts
LBB00015	SCREW PAN CROSS-M5X0.8XL14XBLACK	Bajaj spare parts
LBB00017	SCREW PAN CROS-M4X0.7XL6XPRECOAT	Bajaj spare parts
LBB00020	SCREW PAN CROSS M6X1	Bajaj spare parts
LBB00021	SCREW PAN CROSS M6X1	Bajaj spare parts
LBC00002	FLAT HEAD SCREW M6X20	Bajaj spare parts
LBC00003	SCREW CSK CROSS-M6X1XL	Bajaj spare parts
LBC00004	SCREW CSK CROSS-M6X1XL12XPRECOAT	Bajaj spare parts
LBC00006	SCREW CSK CROSS-M6X1XL20XCL 10.9	Bajaj spare parts
LBC00007	SCREW CSK CROS-M6X1XL26XSHEAR HD	Bajaj spare parts
LBC00009	SCREW CSK CROS-M5X0.8XL12XBRIGHT	Bajaj spare parts
LBC00010	SCREW CSK SOCKET M5X0.8	Bajaj spare parts
LBD00001	SCREW CSK RD CROSS M5	Bajaj spare parts
LBN00003	SCREW SET SOCKET M22X1.25	Bajaj spare parts
LBN00005	SCREW SET SOCKET M6X1	Bajaj spare parts
LBR00001	SCREW TAPING PAN CROS-ST3.5XL6.5	Bajaj spare parts
LBR00002	SELF TAPPING SCREW - DIA 5	Bajaj spare parts
LBR00003	SCREW CR PAN HEAD TAP 4X1.59	Bajaj spare parts
LBR00007	SCREW TAPPING PAN CROS-6XL30XBLK	Bajaj spare parts



LBR00008	SCREW TAPING SOKET-DIA.5XL12XBLK	Bajaj spare parts
LBR00010	SCREW TPNG PAN CRS-DIA3.5XL10XBL	Bajaj spare parts
LBR00013	SCREW TAPPING CSK-DIA 3.5XL12XBL	Bajaj spare parts
LBR00014	SCREW TAPPING-DIA. 4.5XL 12XBRT	Bajaj spare parts
LBR00016	SCREW TAPPING PAN DIA 4.8	Bajaj spare parts
LBS00001	SCREW CSK-SOC RECESS	Bajaj spare parts
LBS00002	SCREW CSK-SOCKET HD	Bajaj spare parts
LBS00003	SCREW CSK-SOCKET HD-M4XL 10XBRT	Bajaj spare parts
LBU00002	SCREW TRUSS M6X1X20	Bajaj spare parts
LBU00004	BOLT STEP M6 X 12L - 4	Bajaj spare parts
LBU00005	SCREW TRUSS M6 X 35 L,4"	Bajaj spare parts
LBU00007	SCREW TRUSS M5 X 15L	Bajaj spare parts
LBU00008	MUSHROOM HEAD SCREW	Bajaj spare parts
LBU00009	SCREW MUSHROOM HEAD	Bajaj spare parts
LBU00010	SCREW TRUSS M5 X 15L	Bajaj spare parts
LBU00012	SCREW	Bajaj spare parts
LBU00015	SCREW -TRUSS-M5X0.8XL30XTAPEREND	Bajaj spare parts
LBU00018	SCREW TRUSS-M5X0.8XL 16	Bajaj spare parts
LBU00020	SCREW TRUSS-M6X1XL37XGRNXTPR END	Bajaj spare parts
LBU00021	SCREW TRUSS-M5X0.8XL16XBLKXTAPER	Bajaj spare parts
LBU00022	SCREW TRUSS-M6X1XL 16XCL 8.8XBLK	Bajaj spare parts
LBU00023	SCREW TRUSS-M5X0	Bajaj spare parts
LBU00024	SCREW TRUSS-M6X1XL16XBLACKXTAPER	Bajaj spare parts
LBU00025	SCREW TRUSS-M5X0.8XL21XGRN	Bajaj spare parts
LBU00026	SCREW TRUSS-M5X0.8XL 16XSTE	Bajaj spare parts
LBU00027	SCREW TRUSS-M6 X 1 XL	Bajaj spare parts
LBU00028	SCREW TRUSS-M5X0.8XL 8.5XGREEN	Bajaj spare parts
LBU00029	SCREW TRUSS-M5X0.8XL 10.5XBRIGHT	Bajaj spare parts
LBU00030	SCREW TRUSS-M5X0.8XL 22XBLACK	Bajaj spare parts
LBU00031	SCREW -M8 X 1.25 X L 12 X BRIGHT	Bajaj spare parts
LBU00032	SCREW TRUSS-M5X 0.8X L14X OLIVE GREEN	Bajaj spare parts
LBU00033	SCREW TRUSS-M6X1XL 23 PRECOAT	Bajaj spare parts
LBU00036	SCREW -M4X0.7XL 13XCL 8.8XBL	Bajaj spare parts
LBU00038	SCREW BUTON HD-M5X0.8XL16	Bajaj spare parts
LBU00039	SCREW TRUSS-M6X1XL 14XCL 4.8XBRT	Bajaj spare parts
LBU00041	SCREW BUTTON HEAD-M5X0.8XL 8XBLK	Bajaj spare parts
LBU00042	SCREW BUTTON HEAD-M6X1XL10XBLACK	Bajaj spare parts
LBU00043	SCREW TRUS-M5X0.8XL14XGRNXPRECOT	Bajaj spare parts
LBU00044	SCREW TRUSS-M5X0.8XL20XGRNXTAPER	Bajaj spare parts
LBU00045	SCREW BUTTON HD-M6X1XL10XPRECOAT	Bajaj spare parts
LBU00046	SCREW TRUS-M6X1XL16XTAPRXPRECOAT	Bajaj spare parts
LBU00047	SCREW TRUSS-M5X0.8XL30XGRNXTAPER	Bajaj spare parts
LBU00048	SCREW BUTTON HD-M6X1XL13XSTEPPED	Bajaj spare parts
LBU00049	SCREW BUTTON HD-M6X1XL25XSTEPPED	Bajaj spare parts
LBU00050	SCREW BUTTON HEAD-M6X1XL9XPRECOAT	Bajaj spare parts

LBU00051	SCREW TRUSS WP-M5X1XL 16XBRIGHT	Bajaj spare parts
LBU00052	SCREW TRUS-M5X0.8XL55XBLXPRECOAT	Bajaj spare parts
LBU00053	SCREW BUTTON HEAD-M6X1XL 14XBRT	Bajaj spare parts
LBU00054	SCREW BUTTON HEAD-M6X1XL 25XBLK	Bajaj spare parts
LBU00055	SCREW BUTTON HEAD-M6X1XL 15XBRT	Bajaj spare parts
LBU00056	SCREW BUTTON HEAD-M6X1XL 10XBRT	Bajaj spare parts
LBU00057	SCREW BUTTON HEAD-M6X1XL 20XBRT	Bajaj spare parts
LBU00058	SCREW BUTTON HEAD-M6X1XL 16XBRT	Bajaj spare parts
LBU00059	SCREW BUTTON HD-M6X1XL13	Bajaj spare parts
LBU00060	SCREW BUTTON HD-M5X0.8XL18XBLACK	Bajaj spare parts
LBU00061	SCREW TRUSS-M5X0.8XL 14XBLACK	Bajaj spare parts
LBU00062	SCREW TRUSS M5X0.8XL10XBLKXPRECOAT	Bajaj spare parts
LBU00063	SCREW TRUS-M4X0.7XL12XGRNXSTEPED	Bajaj spare parts
LBU00064	SCREW BUTN HD-M5X0.8XL10XPRECOAT	Bajaj spare parts
LBU00065	SCREW TRUSS-M5X0.8XL14XCL4.8XBLK	Bajaj spare parts
LBU00066	SCREW TRUSS-M5X0.8XL30XCL4.8XBLK	Bajaj spare parts
LBU00067	SCREW TRUSS-M6X1XL 14XCL 4.8XBLK	Bajaj spare parts
LBU00068	SCREW TRUSS-M5X0.8XL12XCL4.8XBLK	Bajaj spare parts
LBU00069	SCREW TRUSS-M6X1XL 12XCL 4.8XBLK	Bajaj spare parts
LBU00072	SCREW BUTTON HEAD-M6X1XL 16XBRT	Bajaj spare parts
LBU00073	SCREW TRUSS-M5X0.8XL12XBLKXSTEPPED	Bajaj spare parts
LBU00075	SCREW BUTON HEAD-M6X1XL10XSTEPED	Bajaj spare parts
LBU00076	SCREW TRUS-M5X0.8XL14XBRTXPRECOT	Bajaj spare parts
LBU00077	SCREW TRUSS-M6X1XL 20XCL 4.8XBRT	Bajaj spare parts
LBU00078	SCREW BUTTON HEAD-M6X1XL 17XBLK	Bajaj spare parts
LBU00079	SCREW TRUSS-M6X1XL14XPRECOAT	Bajaj spare parts
LBU00080	SCREW BUTN HD-M8X1.25XL20XPRECOT	Bajaj spare parts
LBU00081	SCREW BUTTON HEAD-M5X0.8XL 9XBRT	Bajaj spare parts
LBU00082	SCREW BUTN HD-M5X0.8XL12XBLXSTEP	Bajaj spare parts
LBU00083	SCREW -M6X1XL 15XBLACKXSTEPPED	Bajaj spare parts
LBU00084	SCREW BUTTON HD-M6X1XL14XBLXSTEP	Bajaj spare parts
LBU00085	SCREW BUTN HD-M6X1XL30XCL10.9XBR	Bajaj spare parts
LBU00086	SCREW BUTTON HD-M10X1.25XL20XBLK	Bajaj spare parts
LBU00088	SCREW BUTN HEAD-M8X1.25XL42XDACR	Bajaj spare parts
LBU00089	SCREW BUTTON HEAD-M5X0.8XL18XBLK	Bajaj spare parts
LBU00091	SCREW BUTN HD-M5X0.8XL10XBLKXSTEP	Bajaj spare parts
LBU00092	SCREW BUTN HD-M5X0.8XL13XBLKXSTEP	Bajaj spare parts
LBU00093	SCREW BUTN HD-M6X1XL10XBLKXSTEP	Bajaj spare parts
LBU00094	SCREW BUTTON HEAD-M8X1.25XL14XBL	Bajaj spare parts
LBU00095	SCREW BUTN HEAD-M6X1XL16XBRXSTEP	Bajaj spare parts
LBU00098	SCREW BTN HEAD-M6X1XL12.8XBRXSTP	Bajaj spare parts
LBU00099	SCREW BUTTON HEAD-M6X1XL 16XSTEP	Bajaj spare parts
LBU00100	SCREW BUTTON HEAD-M8X1.25XL27.5	Bajaj spare parts
LBU00101	SCREW BUTTON HEAD-M5X0.8XL10XBLK	Bajaj spare parts
LBU00102	SCREW BUTTON HEAD-M5X0.8XL10XSTP	Bajaj spare parts

LBU00103	SCREW BUTTON HEAD-M6X1XL 16XSTEP	Bajaj spare parts
LBU00104	SCREW BUTTON HEAD-M6X1XL14XBLACK	Bajaj spare parts
LBU00105	SCREW BUTTON HEAD-M6X1XL 12XSTEP	Bajaj spare parts
LBU00106	SCREW BUTTON HEAD-M6X1XL32XBLACK	Bajaj spare parts
LBU00108	SCREW BUTTON HEAD M6X1	Bajaj spare parts
LBU00109	SCREW BUTTON HEAD M5X0.8	Bajaj spare parts
LBU00110	SCREW TRUSS M4X0.7	Bajaj spare parts
LBU00111	SCREW BUTTON HEAD M5X0.8	Bajaj spare parts
LBU00112	SCREW BUTTON HEAD STEP M6X1	Bajaj spare parts
LBU00113	SCREW BUTTON HEAD STEP M5X0.8	Bajaj spare parts
LBU00114	SCREW M6X1	Bajaj spare parts
LBU00116	SCREW BUTTON HEAD STEP M6X1	Bajaj spare parts
LBU00117	SCREW BUTTON HEAD M6X1	Bajaj spare parts
LBU00119	SCREW BUTTON HEAD STEP M6X1	Bajaj spare parts
LBU00123	SCREW BUTTON HEAD M5X0.8	Bajaj spare parts
LBU00129	SCREW BUTTON HEAD M8X1.25	Bajaj spare parts
LBU00131	SCREW BUTTON HEAD M6X1	Bajaj spare parts
LBU00132	SCREW BUTTON HEAD M6X1	Bajaj spare parts
LBU00134	SCREW BUTTON HEAD M6X1	Bajaj spare parts
LBU00135	SCREW BUTTON HEAD M6X1	Bajaj spare parts
LBU00140	SCREW BUTTON HEAD STEP M6X1	Bajaj spare parts
LBU00142	SCREW BUTTON HEAD STEP M6X1	Bajaj spare parts
LBU00144	SCREW BUTTON HEAD STEP M6X1	Bajaj spare parts
LBU00145	SCREW BUTTON HEAD M6X1	Bajaj spare parts
LBU00146	SCREW BUTTON HEAD M8X1.25	Bajaj spare parts
LBU00155	SCREW BUTTON HEAD STEP M6X1	Bajaj spare parts
LBU00168	SCREW SOCKET STEP M6X1	Bajaj spare parts
LBU00172	SCREW BUTTON HEAD M5X0.8	Bajaj spare parts
LBU00174	SCREW TRUSS FLANGED M6X1	Bajaj spare parts
LBU00210	SCREW BUTTON HEAD STEP M6X1	Bajaj spare parts
LCA00002	NUT HEX THIN M10X1.25X6	Bajaj spare parts
LCA00003	NUT HEX.THICK M10X1.25P	Bajaj spare parts
LCA00004	NUT HEX. THICK-M10X1.5XCL	Bajaj spare parts
LCA00005	NUT HEX M10X1.25	Bajaj spare parts
LCA00008	NUT	Bajaj spare parts
LCA00009	NUT	Bajaj spare parts
LCA00010	NUT HEX THIK-M10X1.5XHT.8XBRIGHT	Bajaj spare parts
LCA00011	NUT HEX THIK-M6X1XHT 6.5XOLV GRN	Bajaj spare parts
LCA00014	NUT HEX-M10X1.25XHT.25XCL8XBLACK	Bajaj spare parts
LCA00016	NUT HEX THICK-M6X1XHT. 5XBRASS	Bajaj spare parts
LCA00018	NUT HEX M10X1.5P	Bajaj spare parts
LCA00019	NUT HEX-M16X1.5XHT 15XCL8XBRIGHT	Bajaj spare parts
LCA00025	NUT HEX M12X1.25 LH	Bajaj spare parts
LCA00026	NUT HEX M6X1 LH	Bajaj spare parts
LCA00027	NUT M12X1.25	Bajaj spare parts

LCB00003	NUT (LM6X1)	Bajaj spare parts
LCB00004	NUT HEXAGON -M10X1.25	Bajaj spare parts
LCB00005	NUT HEX A/F 17 M10X1.2	Bajaj spare parts
LCD00001	NUT SPROCKET DRIVE LOCK	Bajaj spare parts
LCD00002	NUT NUT -M39X1.5XHEIGHT 25	Bajaj spare parts
LCF00001	NUT CAP M8	Bajaj spare parts
LCF00003	NUT DOMED FLANGED M6X1	Bajaj spare parts
LCG00001	NUT HEX. FLANGED-M8X1.25XCL	Bajaj spare parts
LCG00002	NUT - FLANGED - M16X1.5X10L	Bajaj spare parts
LCG00003	NUT FLANGED M10 X 1.25	Bajaj spare parts
LCG00004	NUT FLANGED M14 X 1.5	Bajaj spare parts
LCG00006	NUT HEX FLANGED M8*1.25	Bajaj spare parts
LCG00007	NUT FLANGE M8	Bajaj spare parts
LCG00008	NUT FLANGE	Bajaj spare parts
LCG00009	NUT HEX FLANGED-M16X1.5-LH	Bajaj spare parts
LCG00010	NUT FLANGE	Bajaj spare parts
LCG00014	NUT HEX FLANGED-M10X1.25XHT. 10	Bajaj spare parts
LCG00015	NUT HEX FLANG-M10X1.25XHT.10XGRN	Bajaj spare parts
LCG00016	NUT HEX. FLANGE-M8X1.25	Bajaj spare parts
LCG00017	NUT HEX FLANGE-M10X1.5XHT.11XGRN	Bajaj spare parts
LCG00019	NUT HEX FLANGE-M14X1.5XHT.10	Bajaj spare parts
LCG00020	NUT HEX. FLANGE-M8X1.25XCL 8XBRT	Bajaj spare parts
LCG00022	NUT HEX FL-M16X1.5XHT.10XPRECOAT	Bajaj spare parts
LCG00024	NUT HEX FLANGED-M8X1.25XHT.8XBRT	Bajaj spare parts
LCG00028	NUT HEX FLANGE-M5X0.8XHT5XCL4XBL	Bajaj spare parts
LCG00029	NUT HEX FLANGE-M6X1XHT.6XCL4XBLK	Bajaj spare parts
LCG00030	NUT HEX FLANGE-M6X1XHT.6XCL6XBLK	Bajaj spare parts
LCG00031	NUT HEX FL-M14X1-LHXHT.9XPRECOAT	Bajaj spare parts
LCG00034	NUT HEX FLANGED M5X0.8	Bajaj spare parts
LCG00039	NUT HEX FLANGED M6X1	Bajaj spare parts
LCH00001	NUT - NYLOC- M10	Bajaj spare parts
LCH00002	NUT NYLOC-M8X1.25XHT. 8XCL 6XBRT	Bajaj spare parts
LCH00003	NUT NYLOC-M8X1.25XHT 9.5XCL12XBR	Bajaj spare parts
LCH00004	NUT NYLOC-M8X1.25XHT. 8XCL 6XBLK	Bajaj spare parts
LCH00005	NUT NYLOC-M5X0.8XHT. 4.5XCL6XBLK	Bajaj spare parts
LCJ00002	NUT - U M14NUT - U M14	Bajaj spare parts
LCJ00003	NUT U-M12X1.25XHEIGHT 10.5XBLACK	Bajaj spare parts
LCJ00005	NUT U-M14X1.5XHEIGHT 12.5XBRIGHT	Bajaj spare parts
LCK00001	NUT NYLOC FLANGED-M6X1XHT 9.1XBR	Bajaj spare parts
LCL00001	NUT HEX FLANGE-M10	Bajaj spare parts
LCL00002	NUT FLANGE	Bajaj spare parts
LCL00003	NUT U FLANG-M10X1.25XHT	Bajaj spare parts
LCL00004	NUT U FLANGE-M8X1.25XHT. 8.5XBRT	Bajaj spare parts
LCL00005	NUT U FLANGED-M16X1.5XHT.16XBRT	Bajaj spare parts
LCL00006	NUT U FLANG-M10X1.25XHT. 8.5XBRT	Bajaj spare parts

LCL00007	NUT U FLANGED-M8X1.25XHT 8.5XBLK	Bajaj spare parts
LDA00002	WASHER PLAIN SMALL	Bajaj spare parts
LDA00004	WASHER PLAIN	Bajaj spare parts
LDA00005	WASHER PLAIN SMALL-10X16X2.3XBLK	Bajaj spare parts
LDA00007	WASHER PLAIN SMALL	Bajaj spare parts
LDA00008	WASHER 11.2*20*2T	Bajaj spare parts
LDA00009	WASHER PLAIN	Bajaj spare parts
LDA00010	WASHER -ID 5.2XOD 11XT 1.5XNYL	Bajaj spare parts
LDA00011	WASHER PLAIN SMALL-ID4.5XOD12	Bajaj spare parts
LDA00012	PLAIN WASHER FOR INDICATOR	Bajaj spare parts
LDA00013	WASHER PLAIN DIA 6.4XDIA 12.5X 2	Bajaj spare parts
LDA00014	WASHER PLAIN	Bajaj spare parts
LDA00015	WASHER PLAIN	Bajaj spare parts
LDA00017	WASHER PLAIN	Bajaj spare parts
LDA00018	WASHER 6.2X20X1.5	Bajaj spare parts
LDA00019	WASHER PLAIN SMAL-ID17XOD24XT1.6	Bajaj spare parts
LDA00022	WASHER PLAIN SMALL-12.5X22X2.3XBL	Bajaj spare parts
LDA00023	WASHER PLAIN-7X11X2XCOPPER PLTNG	Bajaj spare parts
LDA00025	WASHER PLAIN-ID 14.5XOD 26XTHK 3	Bajaj spare parts
LDA00026	WASHER PLAIN-ID10XOD18.5XTHK1.35	Bajaj spare parts
LDA00028	WASHER PLAIN-ID 8.5XOD 16XTHK 2	Bajaj spare parts
LDA00030	WASHER SPLINE	Bajaj spare parts
LDA00031	WASHER PLAIN	Bajaj spare parts
LDA00032	WASHER PLAIN-ID 12.2XOD 20XTHK 1	Bajaj spare parts
LDA00033	WASHER PLAIN-ID 5XOD 8.5XT 1XGRN	Bajaj spare parts
LDA00034	WASHER PLAIN-ID8.2XOD 14XT 2XBLK	Bajaj spare parts
LDA00036	WASHER PLAIN-ID 16.2XOD 25XT 2.5	Bajaj spare parts
LDA00037	WASHER PLAIN-ID22.2XOD29.6XT 1.5	Bajaj spare parts
LDA00041	WASHER PLAIN-ID7.5XOD11.5XT1XBLK	Bajaj spare parts
LDA00043	WASHER -ID5.1XOD9XT1XNYLONXBROWN	Bajaj spare parts
LDA00048	WASHER PLAIN-ID12.5XOD18.5XTHK 0.5	Bajaj spare parts
LDA00049	WASHER PLAIN-ID 6.5XOD 16XT0.8	Bajaj spare parts
LDA00051	WASHER PLAIN-ID 12.2XOD 20XTHK 1	Bajaj spare parts
LDA00056	WASHER PLAIN	Bajaj spare parts
LDA00057	WASHER PLAIN-ID 6.2XOD 9.5XTHK 1	Bajaj spare parts
LDA00059	WASHER PLAIN	Bajaj spare parts
LDA00063	WASHER PLAIN-ID 20.2XOD 26.4XT 1	Bajaj spare parts
LDA00069	WASHER -ID 7XOD 12XTHK 1XBRIGHT	Bajaj spare parts
LDA00071	WASHER PLAIN-ID8.2XOD15XT2XBLACK	Bajaj spare parts
LDA00077	WASHER PLAIN	Bajaj spare parts
LDA00078	WASHER PLAIN	Bajaj spare parts
LDA00089	WASHER PLAIN	Bajaj spare parts
LDA00092	WASHER PLAIN	Bajaj spare parts
LDB00001	WASHER PLAIN	Bajaj spare parts
LDB00007	WASHER PLAIN - OD15XID 5.5X1.2T	Bajaj spare parts

LDB00010	WASHER PLAIN-ID 10.3XOD29	Bajaj spare parts
LDB00011	WASHER PLAIN	Bajaj spare parts
LDB00012	WASHER PLAIN-ID 6XOD	Bajaj spare parts
LDB00013	WASHER -PLAIN	Bajaj spare parts
LDB00014	WASHER -PLAIN	Bajaj spare parts
LDB00015	WASHER -PLAIN	Bajaj spare parts
LDB00016	WASHER -PLAIN	Bajaj spare parts
LDB00017	WASHER -PLAIN	Bajaj spare parts
LDB00018	WASHER -PLAIN	Bajaj spare parts
LDB00019	WASHER PLAIN	Bajaj spare parts
LDB00020	WASHER 12.5X24X0.8T	Bajaj spare parts
LDB00021	"WASHER 8,2X16X1,5"	Bajaj spare parts
LDB00022	WASHER PLAIN	Bajaj spare parts
LDB00023	WASHER	Bajaj spare parts
LDB00026	WASHER PLAIN	Bajaj spare parts
LDB00027	WASHER FOR WINDSHIELDWASHER FOR WINDSHIE	Bajaj spare parts
LDB00028	WASHER REAR AXLE LH	Bajaj spare parts
LDB00029	WASHER REAR AXLE RH	Bajaj spare parts
LDB00030	WASHER REAR AXLE RH	Bajaj spare parts
LDB00031	WASHER REAR NO PLATE	Bajaj spare parts
LDB00032	WASHER PLAIN-ID 10.2XOD 26	Bajaj spare parts
LDB00033	WASHER PLAIN-ID28.	Bajaj spare parts
LDB00034	WASHER PLAIN-ID 15.2XOD 30XTHK 3	Bajaj spare parts
LDB00035	WASHER PLAIN-ID10.2XOD 24XTHK1.6	Bajaj spare parts
LDB00036	WASHER PLAIN-ID45XOD	Bajaj spare parts
LDB00037	WASHER PLAIN-ID 5.2XOD 14XT2XGRN	Bajaj spare parts
LDB00039	WASHER PLAIN-ID 5.5XOD16XTHK 1.2	Bajaj spare parts
LDB00040	WASHER PLAIN-ID 17XOD 38XTHK 3	Bajaj spare parts
LDB00041	WASHER PLAIN-ID 10.3XOD 29XT8	Bajaj spare parts
LDB00044	WASHER PLAIN-ID 6XOD 18XTHK 1.5	Bajaj spare parts
LDB00045	WASHER PLAIN-ID12.2XOD30XT1.5XBR	Bajaj spare parts
LDB00047	WASHER PLAIN-ID 10.3XOD 26XTHK 8	Bajaj spare parts
LDB00048	WASHER PLAIN	Bajaj spare parts
LDB00049	WASHER PLAIN-ID10.5XOD27XTHK 2.5	Bajaj spare parts
LDB00050	WASHER PLAIN-ID 6XOD 14XTHK 1.2	Bajaj spare parts
LDB00051	WASHER PLAIN-ID 8.2XOD 26XTHK 3	Bajaj spare parts
LDB00053	WASHER PLAIN-ID 8.5XOD 18XTHK 2	Bajaj spare parts
LDB00055	WASHER PLAIN-ID 15.5XOD 29XTHK 5	Bajaj spare parts
LDB00056	WASHER PLAIN	Bajaj spare parts
LDB00057	WASHER PLAIN-ID 15.2XOD30XT 3XBR	Bajaj spare parts
LDB00058	WASHER PLAIN-ID 12.5XOD 26XTHK 3	Bajaj spare parts
LDB00061	WASHER PLAIN-ID10.3XOD21XT 1XGRN	Bajaj spare parts
LDB00062	WASHER PLAIN-ID35.5XOD55XT0.6XGR	Bajaj spare parts
LDB00063	WASHER PLAIN-ID5.5XOD14XT0.8XBLK	Bajaj spare parts
LDB00065	WASHER PLAIN-ID8.5XOD 18XTHK 1.6	Bajaj spare parts

LDB00067	WASHER PLAIN-ID 20XOD 42XT4XSTEP	Bajaj spare parts
LDB00068	WASHER PLAIN-ID 6.5XOD 17.5XT 2	Bajaj spare parts
LDB00071	WASHER PLAIN-ID 13XOD 28XTHK 1.5	Bajaj spare parts
LDB00072	WASHER PLAIN-ID6.5XOD16XTHK1XBLK	Bajaj spare parts
LDB00073	WASHER PLAIN-ID8.4XOD25XTHK2XBLK	Bajaj spare parts
LDB00074	WASHER PLAIN-ID5.5XOD14XT0.8XBLK	Bajaj spare parts
LDB00075	WASHER PLAIN-ID6.2XOD16XTHK1XBLK	Bajaj spare parts
LDB00076	WASHER PLAIN-ID6.5XOD13XTHK1XBLK	Bajaj spare parts
LDB00078	WASHER -ID 10.5XOD 28XTHK. 0.65	Bajaj spare parts
LDB00080	WASHER -ID 5.5XOD 17.5XTHK 2XBLK	Bajaj spare parts
LDB00081	WASHER PLAIN-ID 10.5XOD 24XT 1.6	Bajaj spare parts
LDB00083	WASHER -ID 8.5XOD 18XTHK 2XBLACK	Bajaj spare parts
LDB00084	WASHER -ID 6.5XOD22XTHK 1XBLACK	Bajaj spare parts
LDB00091	WASHER PLAIN-ID 10.3XOD 29XTHK 4	Bajaj spare parts
LDB00105	WASHER PLAIN-ID 12.3XOD 31XT 6	Bajaj spare parts
LDB00106	WASHER PLAIN-ID 18XOD 35XTHK 1	Bajaj spare parts
LDB00120	WASHER PLAIN	Bajaj spare parts
LDB00126	WASHER PLAIN	Bajaj spare parts
LDB00128	WASHER PLAIN	Bajaj spare parts
LDB00143	WASHER PLAIN	Bajaj spare parts
LDC00001	WASHER LEG GUARD	Bajaj spare parts
LDC00002	WASHER SPRING-BLACK	Bajaj spare parts
LDF00001	WASHER LOCK TOOTHED	Bajaj spare parts
LDF00002	TOOTHED WASHER	Bajaj spare parts
LDH00002	WASHER CONICAL-	Bajaj spare parts
LDH00008	WASHER CONICAL-8.2X15X1XOLIV GRN	Bajaj spare parts
LDH00012	WASHER CONICAL-ID34XOD 65XTHK3.8	Bajaj spare parts
LDH00013	WASHER CONICAL-ID30.5XOD47.5XT 1	Bajaj spare parts
LDH00016	WASHER CONICAL-ID8.2XOD15XT2XBLK	Bajaj spare parts
LEA00003	CIRCLIP EXTERNAL 6X0.7	Bajaj spare parts
LEB00001	CIRCLIP INTERNAL	Bajaj spare parts
LEB00003	CIRCLIP INTERNAL-ID62XTHK1XPHOSP	Bajaj spare parts
LEC00001	CIRCLIP E TYPE	Bajaj spare parts
LFB00001	KEY SUNK-WD4XHT4XL12XPHOSPHATISE	Bajaj spare parts
LGA00004	RIVET ROUND-DIA. 6 X L 24XBRIGHT	Bajaj spare parts
LGC00005	RIVET FLAT-DIA. 6XL 12X OLV GRN	Bajaj spare parts
LHA00001	PIN	Bajaj spare parts
LHA00002	PIN -SPLIT	Bajaj spare parts
LHB00001	PIN SNAP	Bajaj spare parts
LHC00001	SPRING PIN	Bajaj spare parts
LHD00001	PIN PARALLEL	Bajaj spare parts
LHD00005	PIN DOWEL-DIA. 8XL 15	Bajaj spare parts
LHE00001	PIN CLEVIS WITH HOLE-DIA.10	Bajaj spare parts
LHE00002	PIN CLEVIS WITH HOLE-DIA. 10XL55	Bajaj spare parts
LHE00003	PIN CLEVIS WITH HOLE-DIA.8XL47.2	Bajaj spare parts

LHE00004	PIN CLEVIS WITH HOLE-DIA.12XL250	Bajaj spare parts
LHE00005	PIN -DIA. 8XL 85	Bajaj spare parts
LHE00010	PIN CLEVIS WITH HOLE-DIA7XL20XBR	Bajaj spare parts
LHE00017	PIN CLEVIS DIA 11.5	Bajaj spare parts
LHE00021	PIN CLEVIS DIA 6	Bajaj spare parts
LJA00001	RING O	Bajaj spare parts
LJA00002	O RING FOR E - 20	Bajaj spare parts
LJA00003	RING O (INSULATOR)	Bajaj spare parts
LJA00004	STRAINER O RING	Bajaj spare parts
LJA00005	PIPE COOLANT T O-RING	Bajaj spare parts
LJA00006	RING O - ID 12.5XSECT. DIA. 2	Bajaj spare parts
LJA00007	RING O - ID 24XSECT. DIA. 2.5	Bajaj spare parts
LJA00009	RING O - ID 11.2XSECT. DIA. 1.2	Bajaj spare parts
LJA00010	RING O - ID 33XSECT. DIA. 2	Bajaj spare parts
LJA00011	RING O-ID 28.7 X 1.9	Bajaj spare parts
LJA00014	RING O-ID 27.7 X SECT.DIA. 2.1	Bajaj spare parts
LJA00015	RING O -ID 14 X SECT. DIA	Bajaj spare parts
LJA00016	RING O-ID 11.5 X SECT. DIA. 1.5	Bajaj spare parts
LJA00019	RING O ID 8.44 X SECT. DIA. 1.78	Bajaj spare parts
LJA00020	RING O ID 21 X SECT. DIA. 4	Bajaj spare parts
LJA00022	RING O	Bajaj spare parts
LJA00023	RING O-ID 18.5 X SECT. DIA. 1	Bajaj spare parts
LJA00024	RING O-ID 6.3 X SECT. DIA. 1.9	Bajaj spare parts
LJA00025	RING O-ID 18.72 X SECT. DIA. 3	Bajaj spare parts
LJA00036	RING O-ID 18.5 X SECT. DIA. 1.5	Bajaj spare parts
LJA00037	RING O-ID 15.2XSECT. DIA. 1.2	Bajaj spare parts
LJA00038	RING O-ID 25.7XSECT. DIA. 3.5	Bajaj spare parts
LJB00001	RING O -ID 57.6 X SECT. DIA. 1.5	Bajaj spare parts
LJB00004	RING O	Bajaj spare parts
LLA00001	GROMMET -ID 8X OD 15.5 X HT. 8.1	Bajaj spare parts
LLA00002	GROMMET -ID 6	Bajaj spare parts
LLA00003	GROMMET -ID 9.3 X OD 16 X HT. 4.6	Bajaj spare parts
LLA00005	GROMMET	Bajaj spare parts
LLA00006	GROMMET	Bajaj spare parts
LPA00003	BEARING BALL-6301XORD.XHIGH TEMP	Bajaj spare parts
LPA00004	BEARING BALL-ID 15XOD 28XTHK 7	Bajaj spare parts
LPA00009	BEARING BALL ID25XOD42XT9XWT	Bajaj spare parts
LPB00001	BEARING BALL-22X56X16-C3	Bajaj spare parts
LPB00002	BEARING BALL-15X35X11-C3-IRS-HN3	Bajaj spare parts
LPB00003	BEARING BALL-22X56X16-C3L-IRS-HN3	Bajaj spare parts
LPB00004	BEARING BALL-15X35X11-C3L	Bajaj spare parts
LPB00007	BEARING BALL-12X28X8XC3LXOPNXHN3	Bajaj spare parts
LPB00009	BEARING BALL-17X35X10XC3LXOPEN	Bajaj spare parts
LZA00004	OIL TRANSMISION GEAR 9 FE 75W-80	Bajaj spare parts
LZE00006	SEALANT -LOCTITE SI 5699	Bajaj spare parts



LZE00009	SEALANT -LOCTITE 620	Bajaj spare parts
PA111030	SLEEVE SWING ARM PIVOT	Bajaj spare parts
PA111075	FRAME ASSEMBLY	Bajaj spare parts
PA111132	FRAME ASSLY	Bajaj spare parts
PA111240	FRAME ASSLY	Bajaj spare parts
PA111246	FRAME ASSLY	Bajaj spare parts
PA113008	FOOTREST RUBBER	Bajaj spare parts
PA113014	MAIN STEP RH ASSY COMP	Bajaj spare parts
PA113015	STAY RH MAIN STEP	Bajaj spare parts
PA113022	ASSLY STEP MAIN LH COMP	Bajaj spare parts
PA113024	ASSLY STEP MAIN RH COMP	Bajaj spare parts
PA113035	ASSLY HOLDER STEP LH	Bajaj spare parts
PA113038	ASSLY HOLDER STEP RH	Bajaj spare parts
PA113040	PILLION FOOT PEG ASSLY LH	Bajaj spare parts
PA113041	PILLION FOOT PEG ASSLY RH	Bajaj spare parts
PA113042	LOCK PLATE LH	Bajaj spare parts
PA113043	LOCK PLATE RH	Bajaj spare parts
PA113044	STEP MAIN LH	Bajaj spare parts
PA113045	STEP MAIN RH	Bajaj spare parts
PA113046	STEP PILLION LH	Bajaj spare parts
PA113047	STEP PILLION RH	Bajaj spare parts
PA113058	ASSLY HOLDER STEP RH -SOFT MTG	Bajaj spare parts
PA113061	DAMPER PILLION FOOT REST	Bajaj spare parts
PA113075	STAY STEP MAIN LH	Bajaj spare parts
PA113077	STEP RIDER RH	Bajaj spare parts
PA113079	HOLDER STEP PILLION RH	Bajaj spare parts
PA113204	DAMPER CENTER STAND	Bajaj spare parts
PA113206	STAND CENTER	Bajaj spare parts
PA113207	STAND CENTER	Bajaj spare parts
PA113208	STAND SIDE	Bajaj spare parts
PA113212	STAND CENTER	Bajaj spare parts
PA113402	BRACKET ENG MTG TOP LH	Bajaj spare parts
PA113410	BRACKET ENGINE MTG FRONT	Bajaj spare parts
PA113413	BRACKET ENGINE MTG TOP	Bajaj spare parts
PA113414	BRACKET ENGINE MTG TOP	Bajaj spare parts
PA113416	BRACKET ASSY ENG MTG FRONT LH	Bajaj spare parts
PA113417	BRACKET ASSY ENG MTG FRONT RH	Bajaj spare parts
PA113421	HANGER ENGINE TOP LH	Bajaj spare parts
PA113422	HANGER ENGINE TOP RH	Bajaj spare parts
PA113426	ASSEMBLY BRACKET ENGINE FRONT LH	Bajaj spare parts
PA113429	ASSEMBLY BRACKET ENGINE FRONT RH	Bajaj spare parts
PA113805	CAP FRAME END	Bajaj spare parts
PA113814	CAP ARM SWING	Bajaj spare parts
PA121000	FRONT FORK ASSY	Bajaj spare parts
PA121001	LEG ASSY LH	Bajaj spare parts

PA121003	LEG ASSY RH	Bajaj spare parts
PA121005	TUBE OUTER LH W/H BUSH	Bajaj spare parts
PA121006	TUBE OUTER RH W/H BUSH	Bajaj spare parts
PA121010	TUBE OUTER LH P/C	Bajaj spare parts
PA121011	TUBE OUTER RH P/C	Bajaj spare parts
PA121012	ASSLY FRONT FORK	Bajaj spare parts
PA121015	TUBE OUTER LH	Bajaj spare parts
PA121016	TUBE OUTER RH	Bajaj spare parts
PA121017	SPRING MAIN	Bajaj spare parts
PA121020	ASSEMBLY FRONT FORK	Bajaj spare parts
PA121022	OUTER TUBE LH	Bajaj spare parts
PA121024	OUTER TUBE RH	Bajaj spare parts
PA121025	ASSLY FRONT FORK	Bajaj spare parts
PA121030	ASSLY FRONT FORK	Bajaj spare parts
PA121032	LEG ASSEMBLY LH	Bajaj spare parts
PA121034	TUBE OUTER LH	Bajaj spare parts
PA121035	TUBE OUTER RH	Bajaj spare parts
PA121036	FORK ASSLY COMP DISC	Bajaj spare parts
PA121039	TUBE OUTER LH	Bajaj spare parts
PA121040	TUBE OUTER RH	Bajaj spare parts
PA121041	SEAT PIPE	Bajaj spare parts
PA121042	FORK PIPE SPINNING	Bajaj spare parts
PA121046	ASLY UNDER BKT COMP	Bajaj spare parts
PA121065	SPRING MAIN	Bajaj spare parts
PA122001	ARM SWING	Bajaj spare parts
PA122009	SHOCKABSORBER REAR	Bajaj spare parts
PA122013	ASSLY SWING ARM	Bajaj spare parts
PA122014	CHAIN SLIDER	Bajaj spare parts
PA122015	SHAFT SWING ARM	Bajaj spare parts
PA122016	RUBBER BEADING SWING ARM	Bajaj spare parts
PA122021	CHAIN ADJUSTER PLATE	Bajaj spare parts
PA122022	CHAIN ADJUSTER RH	Bajaj spare parts
PA122023	CHAIN ADJUSTER LH	Bajaj spare parts
PA122026	SHOCKABSORBER REAR	Bajaj spare parts
PA122028	SWING ARM ASSY	Bajaj spare parts
PA122029	CHAIN SLIDER	Bajaj spare parts
PA122034	ASSLY SWING ARM	Bajaj spare parts
PA122061	SHOCKABSORBER REAR	Bajaj spare parts
PA122064	ARM ASSLY SWING	Bajaj spare parts
PA131002	FRONT AXLE DIA 10	Bajaj spare parts
PA131003	SEAL OIL	Bajaj spare parts
PA131010	WHEEL FRONT DRUM	Bajaj spare parts
PA131019	WHEEL FRONT WHEEL 1.4X17 DRUM	Bajaj spare parts
PA131021	WHEEL FRONT 1.4X17-DI	Bajaj spare parts
PA131046	WHEEL FRONT - 1.4X17	Bajaj spare parts

PA131048	WHEEL FRONT - 1.85X17	Bajaj spare parts
PA131052	WHEEL FRONT MT 1.85X17 DRUM	Bajaj spare parts
PA131204	WHEEL 1.6X17-110 DR BLACK	Bajaj spare parts
PA131207	COUPLING ASSEMBLY	Bajaj spare parts
PA131208	COUPLING	Bajaj spare parts
PA131215	WHEEL REAR 1.6X17 (DR)	Bajaj spare parts
PA131217	ASSEMBLY COLLAR	Bajaj spare parts
PA131221	COLLAR ASSLY	Bajaj spare parts
PA131222	COLLAR	Bajaj spare parts
PA131223	AXLE REAR	Bajaj spare parts
PA131234	COLLAR RH	Bajaj spare parts
PA131238	WHEEL 1.6X17 DRUM BLACK	Bajaj spare parts
PA131239	AXLE REAR	Bajaj spare parts
PA131241	WHEEL 1.6X17 130 DRUM	Bajaj spare parts
PA131261	BOLT D	Bajaj spare parts
PA131263	Damper Coupling	Bajaj spare parts
PA131274	WHEEL REAR 2.15X17	Bajaj spare parts
PA131276	COLLAR	Bajaj spare parts
PA131600	COLLAR BEARING	Bajaj spare parts
PA131602	COLLAR ASSY	Bajaj spare parts
PA131605	SLEEVE	Bajaj spare parts
PA131610	SLEEVE	Bajaj spare parts
PA131801	PANEL BRAKE FRONT	Bajaj spare parts
PA131807	ROD BRAKE	Bajaj spare parts
PA131809	LEVER CAM BRAKE	Bajaj spare parts
PA131825	BRAKE ROD	Bajaj spare parts
PA131828	ROD BRAKE	Bajaj spare parts
PA131830	PANEL BRAKE FRONT	Bajaj spare parts
PA131832	CLAMP SPEEDO CABLE	Bajaj spare parts
PA131834	ASSLY PANEL REAR COMP	Bajaj spare parts
PA131835	LEVER CAM BRAKE -FABRICATED	Bajaj spare parts
PA131844	HOSE ASSLY	Bajaj spare parts
PA131850	BRAKE ROD D105C	Bajaj spare parts
PA131865	LEVER CAM BRAKE REAR	Bajaj spare parts
PA131866	BRACKET HOSE BRAKE	Bajaj spare parts
PA131867	CLIP SEPARATOR	Bajaj spare parts
PA131868	HOOK	Bajaj spare parts
PA131869	HOOK	Bajaj spare parts
PA141002	CHAIN 126 LINKS 428 SERIES	Bajaj spare parts
PA141011	CHAIN 120 LINK - 420 SERIES	Bajaj spare parts
PA151004	ASSEMBLY UPPER BKT	Bajaj spare parts
PA151005	LAMP SHADE ASSEMBLY	Bajaj spare parts
PA151006	ASSLY UPPER BRACKET	Bajaj spare parts
PA151009	HANDLE BAR	Bajaj spare parts
PA151011	HOLDER FORK UPPER	Bajaj spare parts

PA151012	LEVER HOLDER ASSY LH	Bajaj spare parts
PA151013	HAND GRIP LH	Bajaj spare parts
PA151014	HAND GRIP RH	Bajaj spare parts
PA151020	HANDLE BAR	Bajaj spare parts
PA151023	PIPE THROTTLE	Bajaj spare parts
PA161000	BRAKE ROD	Bajaj spare parts
PA161004	SPRING REAR BRAKE SWITCH	Bajaj spare parts
PA161005	SPRING	Bajaj spare parts
PA161006	ASSLY BRAKE PEDAL	Bajaj spare parts
PA161012	BRAKE LEVER	Bajaj spare parts
PA161014	PEDAL BRAKE	Bajaj spare parts
PA161016	ROD BRAKE	Bajaj spare parts
PA161200	CABLE ACCELERATOR	Bajaj spare parts
PA161201	CABLE BRAKE FRONT	Bajaj spare parts
PA161202	CABLE ACCELERATOR	Bajaj spare parts
PA161204	CABLE CLUTCH	Bajaj spare parts
PA161205	CABLE SEAT LOCK ASSEMBLY	Bajaj spare parts
PA161206	CABLE SEAT LOCK	Bajaj spare parts
PA161207	CABLE SEAT LOCK	Bajaj spare parts
PA161208	BRAKE CABLE FRONT	Bajaj spare parts
PA161209	CABLE CLUTCH	Bajaj spare parts
PA161211	ASSLY SEAT LOCK WITH CABLE	Bajaj spare parts
PA161217	CABLE SPEEDOMETER	Bajaj spare parts
PA161221	CABLE BRAKE FRONT	Bajaj spare parts
PA161222	CABLE THROTTLE	Bajaj spare parts
PA171017	TAPE SEAT	Bajaj spare parts
PA171605	TUBE Y CONNECTOR TO CANISTER	Bajaj spare parts
PA171607	TUBE PURGE VALVE TO CARB	Bajaj spare parts
PA171609	TUBE CANISTER DRAIN	Bajaj spare parts
PA171610	TUBE INLINE CONNECTOR TO PURGE	Bajaj spare parts
PA171611	TUBE BREATHER CANISTER	Bajaj spare parts
PA171808	TUBE T TO Y CONNECTOR	Bajaj spare parts
PA171810	TUBE TANK TO Y CONN	Bajaj spare parts
PA181003	WINDSHIELD	Bajaj spare parts
PA181217	ASSLY SEAT COWL	Bajaj spare parts
PA181226	FLAP SPEEDOMETER	Bajaj spare parts
PA181227	STRUCTURE MTG FAIRING	Bajaj spare parts
PA181232	GROMMET-1 SEAT COWL LH	Bajaj spare parts
PA181233	GROMMET-2 SEAT COWL LH	Bajaj spare parts
PA181234	GROMMET-1 SEAT COWL RH	Bajaj spare parts
PA181235	GROMMET-2 SEAT COWL RH	Bajaj spare parts
PA181246	NUT WELL M5X.8	Bajaj spare parts
PA181249	FOAM SPEEDO FLAP	Bajaj spare parts
PA181263	COVER LH SIDE	Bajaj spare parts
PA181264	COVER RH SIDE	Bajaj spare parts

PA181265	ASSEMBLY SEAT COWL	Bajaj spare parts
PA181276	FAIRING STRUCTURE LH	Bajaj spare parts
PA181277	FAIRING STRUCTURE RH	Bajaj spare parts
PA181278	BRACKET LOWER HINGE MTG	Bajaj spare parts
PA181279	BRACKET NUMBER PLATE MTG	Bajaj spare parts
PA181280	FLAP SPEEDO	Bajaj spare parts
PA181281	WINDSHIELD	Bajaj spare parts
PA181282	FAIRING	Bajaj spare parts
PA181283	BRACKET UPPER PIVOT MTG	Bajaj spare parts
PA181284	ASSLY SPEEDOFLAP	Bajaj spare parts
PA181287	WIND SHIELD ASSLY	Bajaj spare parts
PA181292	GROMMET FAIRING MTG	Bajaj spare parts
PA181293	COLLAR FAIRING MTG	Bajaj spare parts
PA181295	FOAM SEAT COWL LH	Bajaj spare parts
PA181296	FOAM SEAT COWL RH	Bajaj spare parts
PA181300	BRACKET NO PLATE MTG BKT	Bajaj spare parts
PA181301	DAMPER FAIRING	Bajaj spare parts
PA181305	WASHER SPECIAL	Bajaj spare parts
PA181310	CHAIN CASE LOWER ASSLY	Bajaj spare parts
PA181313	SLEEVE FAIRING MOUNTING	Bajaj spare parts
PA181341	COVER SIDE LH	Bajaj spare parts
PA181342	COVER SIDE RH	Bajaj spare parts
PA181344	COWL ASSLY SEAT	Bajaj spare parts
PA181347	STRUCTURE FAIRING CENTRAL	Bajaj spare parts
PA181348	STRUCTURE FAIRING LH	Bajaj spare parts
PA181349	STRUCTURE FAIRING RH	Bajaj spare parts
PA181350	BRACKET HEADLAMP PIVOT	Bajaj spare parts
PA181351	GROMMET	Bajaj spare parts
PA181352	SLEEVE	Bajaj spare parts
PA181353	SLEEVE	Bajaj spare parts
PA181354	GROMMET	Bajaj spare parts
PA181355	BRACKET HARNESS	Bajaj spare parts
PA181356	GROMMET	Bajaj spare parts
PA181403	HUGGER FRONT	Bajaj spare parts
PA181405	FENDER BRACE DRUM	Bajaj spare parts
PA181408	FENDER REAR RR	Bajaj spare parts
PA181409	GROMMET SAREE GUARD	Bajaj spare parts
PA181426	FENDER REAR EVAP D104	Bajaj spare parts
PA181440	FENDER REAR	Bajaj spare parts
PA181442	PLUG	Bajaj spare parts
PA181443	PLUG	Bajaj spare parts
PA182200	DAMPER RUBBER FAIRING RH	Bajaj spare parts
PA182201	DAMPER RUBBER FAIRING LH	Bajaj spare parts
PA191000	SEAT ASSEMBLY	Bajaj spare parts
PA191001	SEAT BASE	Bajaj spare parts

PA191006	SEAT BASE	Bajaj spare parts
PA191010	DAMPER FRONT	Bajaj spare parts
PA191016	DAMPER SEAT REAR	Bajaj spare parts
PA191021	ASSLY SEAT COMP	Bajaj spare parts
PA191026	SEAT ASSEMBLY	Bajaj spare parts
PA231002	TOOL KIT	Bajaj spare parts
PA231202	SAREE GUARD	Bajaj spare parts
PA231206	LEG GUARD	Bajaj spare parts
PA231207	GUARD SAREE	Bajaj spare parts
PA231211	LEG GUARD	Bajaj spare parts
PA231216	GUARD SAREE	Bajaj spare parts
PA231217	GUARD LEG LH	Bajaj spare parts
PA231218	GUARD LEG RH	Bajaj spare parts
PA231403	ASSLY GRAB HANDLE	Bajaj spare parts
PA231404	GRAB HANDLE	Bajaj spare parts
PA231600	MIRROR ASSLY LH	Bajaj spare parts
PA231601	MIRROR ASSLY RH	Bajaj spare parts
PA232802	BRACKET FAIRING LOWER	Bajaj spare parts
PA232803	BRACKET PLATE NUMBER	Bajaj spare parts
PA232806	BRACKET PLATE NUMBER REAR	Bajaj spare parts
PA233072	KIT DECAL BL GOLD	Bajaj spare parts
PA233073	KIT TANK DECAL BL GOLD MA	Bajaj spare parts
PA233084	KIT DECAL BL RED MAGENTA	Bajaj spare parts
PA233085	KIT TANK DECAL BL RED MAG	Bajaj spare parts
PA233094	KIT TANK DCL DISCO T BLACK-BLUE	Bajaj spare parts
PA233101	KIT TANK DCL DISCO T BLACK-RED	Bajaj spare parts
PA233109	KIT TANK DCL DISCO D102 BLUE	Bajaj spare parts
PA233117	KIT TANK DCL DISCO D102 RED	Bajaj spare parts
PA233126	DECAL TANK KIT BLACK RED	Bajaj spare parts
PA233138	DECAL KIT TANK BLACK BLUE	Bajaj spare parts
PA233139	DECAL TANK KIT BLUE	Bajaj spare parts
PA233142	DECAL TANK KIT RED	Bajaj spare parts
PA233226	DECAL SIDE COVER - 4 VALVE	Bajaj spare parts
PA233227	KIT TANK DECAL	Bajaj spare parts
PA233247	KIT TANK DECAL D125M	Bajaj spare parts
PA233259	KIT TANK DECAL	Bajaj spare parts
PA233271	DECAL KIT TANK	Bajaj spare parts
PA233283	DECAL TANK KIT	Bajaj spare parts
PA233451	DECAL SPEEDOMETER	Bajaj spare parts
PA233482	DECAL COVER SIDE LH EBONY BLACK	Bajaj spare parts
PA233483	DECAL COVER SIDE RH EBONY BLACK	Bajaj spare parts
PA233509	DECAL ANTI SKID	Bajaj spare parts
PA351000	MAGNETO ASSLY 12 POLE D102B	Bajaj spare parts
PA351003	STATOR ASSLY	Bajaj spare parts
PA351018	ROTOR ASSLY WITHOUT CLUTCH ASSLY	Bajaj spare parts

PA351025	ASSLY ROTOR WITH CLUTCH D105D	Bajaj spare parts
PA351027	ASSLY ROTOR WO CLUTCH D105D	Bajaj spare parts
PA351200	DC CDI UNIT	Bajaj spare parts
PA351201	H T COIL WITH CABLE - LH	Bajaj spare parts
PA351202	H T COIL WITH CABLE - RH	Bajaj spare parts
PA351206	CDI UNIT D102B	Bajaj spare parts
PA351210	COIL HT -1- D105	Bajaj spare parts
PA351212	COIL HT-2 -D105	Bajaj spare parts
PA351213	CDI D105A	Bajaj spare parts
PA351214	CDI D105C	Bajaj spare parts
PA351215	CDI DC D105A	Bajaj spare parts
PA351217	CDI DC MANUAL CHOKE D105A	Bajaj spare parts
PA401000	SIDE REFLEX REFLECTO	Bajaj spare parts
PA401007	ASSEMBLY HEADLAMP	Bajaj spare parts
PA401008	TAIL LAMP ASSEMBLY	Bajaj spare parts
PA401009	TAIL LAMP ASSLY W/O LAMP	Bajaj spare parts
PA401018	BULB LED BAJAJ LOGO	Bajaj spare parts
PA401019	LAMP ASEMBLY HEAD	Bajaj spare parts
PA401401	CLUTCH SWITCH	Bajaj spare parts
PA401405	SWITCH CONTROL RH	Bajaj spare parts
PA401407	SWITCH CONTROL RH	Bajaj spare parts
PA401410	CLUTCH SWITCH WITH VERTICAL	Bajaj spare parts
PA401600	EN: HORN - 82 DIA	Bajaj spare parts
PA401804	BAND BATTERY 5AH	Bajaj spare parts
PA401805	BASE BATTERY 5AH	Bajaj spare parts
PA401809	FOAM BATTERY	Bajaj spare parts
PA402200	HARNESS WIRING(SS)	Bajaj spare parts
PA402201	HARNESS WIRING DIS M	Bajaj spare parts
PA402202	CABLE BATTERY	Bajaj spare parts
PA402203	CABLE ASSY START	Bajaj spare parts
PA402204	BAND(LENGTH 110MM)	Bajaj spare parts
PA402205	HARNESS WIRING(KS)	Bajaj spare parts
PA402207	CABLE RELAY TO MOTOR-IRAN	Bajaj spare parts
PA402211	HARNESS WIRING (SS)	Bajaj spare parts
PA402216	HARNESS WIRING	Bajaj spare parts
PA402218	HARNESS HARNESS WIRING (SS)	Bajaj spare parts
PA402220	HARNESS WIRING	Bajaj spare parts
PA402222	HARNESS WIRING	Bajaj spare parts
PA402224	RELAY TO MOTOR CABLE	Bajaj spare parts
PA402225	CABLE ASSY BATTERY TO EARTH	Bajaj spare parts
PA402226	CABLE RELAY TO BATTERY	Bajaj spare parts
PA402227	CABLE STARTER RELAY TO MOTOR	Bajaj spare parts
PA402228	HARNESS WIRING	Bajaj spare parts
PA402237	HARNESS WIRING DC	Bajaj spare parts
PA402238	HARNESS WIRING	Bajaj spare parts

PA402248	CABLE RELAY TO MOTOR	Bajaj spare parts
PA402250	HARNESS WIRING-AHO	Bajaj spare parts
PA402252	HARNESS WIRING - IRAN	Bajaj spare parts
PA402253	CABLE BATTERY TO EARTH IRAN	Bajaj spare parts
PA402254	CABLE RELAY TO MOTOR IRAN	Bajaj spare parts
PA402255	HARNESS WIRING	Bajaj spare parts
PA402256	CABLE ASSLY BATTERY TO EARTH	Bajaj spare parts
PA402400	INSTRUMENT CLUSTER	Bajaj spare parts
PA402401	SPEEDOMETER WITH DIAL	Bajaj spare parts
PA402402	GAUGE FUEL MACHINE DIAL	Bajaj spare parts
PA402403	COVER TOP SPEEDOMETER	Bajaj spare parts
PA402405	MOUNTING BRACKET SPEED	Bajaj spare parts
PA402406	SPEEDOMETER ASSLY	Bajaj spare parts
PA402407	MACHINE SPPEDOMETER	Bajaj spare parts
PA402408	FG M/C WITH DIAL (DISCO M	Bajaj spare parts
PA402410	COVER SPEEDO BACK (PRICOL	Bajaj spare parts
PA402411	SPEEDO CASE	Bajaj spare parts
PA402412	KNOB TRIPMETER	Bajaj spare parts
PA402413	SCREW TRIPMETER	Bajaj spare parts
PA402414	COVER SPEEDO BACK (MINDA)	Bajaj spare parts
PA402415	SPEEDO CASE (MINDA)	Bajaj spare parts
PA402416	KNOB TRIPMETER (MINDA)	Bajaj spare parts
PA402417	SCREW TRIPMETER (MINDA)	Bajaj spare parts
PA402418	GAUGE FUEL DIAL & M/C MIN	Bajaj spare parts
PA402419	COVER TOP SPEEDOMETER MIN	Bajaj spare parts
PA402420	HARNESS SPEEDOMETER MIND	Bajaj spare parts
PA402421	SPEEDO DIAL & M/C MINDA	Bajaj spare parts
PA402422	SPEEDOMETER ASSEMBLY	Bajaj spare parts
PA402423	SPEEDOMETER ASSLY	Bajaj spare parts
PA402424	SPEEDOMETER & TRIP WITH DIAL	Bajaj spare parts
PA402425	GAUGE FUEL ASSLY WITH DIAL	Bajaj spare parts
PA402426	COVER TOP ASSLY	Bajaj spare parts
PA402427	HOUSING	Bajaj spare parts
PA402428	RING SEALING	Bajaj spare parts
PA402429	KNOB TRIP GROMMET	Bajaj spare parts
PA402431	HARNESS ASSLY WIRING	Bajaj spare parts
PA402432	LAMP 12 V,2W-T5 CAPLESS	Bajaj spare parts
PA402436	SPEEDOMETER ASSLY DIGITAL	Bajaj spare parts
PA402440	SPEEDOMETER ASSLY	Bajaj spare parts
PA402444	SPEEDOMETER	Bajaj spare parts
PA402601	GAUGE FUEL TANK (JNS)	Bajaj spare parts
PA501019	ENGINE ASSLY D105 A	Bajaj spare parts
PA511039	PLATE CYLINDER HEAD D102B(44)	Bajaj spare parts
PA511054	WASHER WAVE CYL HEAD D102B	Bajaj spare parts
PA511055	WASHER PLAIN CYL HEAD D102B	Bajaj spare parts



PA511098	GASKET CYLINDER HEAD D105D	Bajaj spare parts
PA511210	RETAINER VALVE SPRING	Bajaj spare parts
PA511215	CAMSHAFT ASSLY	Bajaj spare parts
PA511224	SEAT VALVE SPRING D102B	Bajaj spare parts
PA511228	VALVE INTAKE - D102B (M)	Bajaj spare parts
PA511229	VALVE EXHAUST - D102B (M)	Bajaj spare parts
PA511232	ASSLY ROCKER ARM IN	Bajaj spare parts
PA511234	ASSLY ROCKER ARM EX	Bajaj spare parts
PA511246	ASSLY CAM SHAFT D105C	Bajaj spare parts
PA511251	ASSLY CAMSHAFT D105D	Bajaj spare parts
PA511254	ASSLY ROCKER ARM D105D	Bajaj spare parts
PA511256	VALVE INTAKE D105D	Bajaj spare parts
PA511257	VALVE EXHAUST D105D	Bajaj spare parts
PA511258	SPRING VALVE D105D	Bajaj spare parts
PA521214	CIRCLIP PISTON D102B	Bajaj spare parts
PA521216	PISTON ASSLY D102 B (M)	Bajaj spare parts
PA521229	CIRCLIP PISTON D105D	Bajaj spare parts
PA531029	ASSLY CRANKSHAFT D105C	Bajaj spare parts
PA541011	ASSLY CRANKCASE RH (D102B)	Bajaj spare parts
PA541208	COVER CLUTCH DIS 100 T	Bajaj spare parts
PA541209	ASSLY COVER RR D102B (M)	Bajaj spare parts
PA541210	LABEL GEAR SHIFT D102B (M)	Bajaj spare parts
PA541213	LABEL GEAR SHIFT ALL UP-4	Bajaj spare parts
PA541217	ASSLY COVER LH RR D105	Bajaj spare parts
PA541224	BRACKET CLUTCH CABLE D105	Bajaj spare parts
PA551002	SHAFT INPUT D105	Bajaj spare parts
PA551205	GEAR 1ST DRIVEN D105	Bajaj spare parts
PA551206	GEAR 4TH DRIVEN D105	Bajaj spare parts
PA551207	GEAR 4TH DRIVE D105	Bajaj spare parts
PA551404	ASSLY CLUTCH D102B TX	Bajaj spare parts
PA551405	ROD PUSH D102B	Bajaj spare parts
PA561000	DRUM COMP. GEAR SHIFT (D102B)	Bajaj spare parts
PA561002	ASSLY DRUM GEARSHIFT	Bajaj spare parts
PA561005	ASSLY DRUM GEAR SHIFT	Bajaj spare parts
PA561209	INHIBITOR COMP D105A UG	Bajaj spare parts
PA561401	GEAR SHIFT LEVER COMP	Bajaj spare parts
PA561402	GEAR SHIFT LEVER	Bajaj spare parts
PA581029	FILTER ELEMENT D105	Bajaj spare parts
PA581034	TUBE BREATHER - D105	Bajaj spare parts
PA581038	UNIT SAI	Bajaj spare parts
PA581053	TOP COVER MTG SCREW M6X18	Bajaj spare parts
PA581205	INSULATOR PTE 20 (D102 B)	Bajaj spare parts
PA581207	INSULATOR CARB PTE 18 - D105	Bajaj spare parts
PA581208	CARBURETTOR PTE 20 AUTO CHOKE	Bajaj spare parts
PA581220	GASKET FLOAT CHAMBER	Bajaj spare parts

PA581222	AUTOCHOKE	Bajaj spare parts
PA581224	INSULATOR CARB PTE-16	Bajaj spare parts
PA581225	SLEEVE CARB D100 C	Bajaj spare parts
PA581226	ASSLY CARBURETOR BS26 D105C	Bajaj spare parts
PA581227	TPS REED SWITCH D105C	Bajaj spare parts
PA581228	CARB.PTE19D AUTO CHOKE D105 A	Bajaj spare parts
PA581229	ASLY CARB MANUAL CHOKE D105A	Bajaj spare parts
PA581406	INSULATOR MANIFOLD D105	Bajaj spare parts
PA581407	MANIFOLD INTAKE D105A (4V)	Bajaj spare parts
PA581409	MANIFOLD INTAKE D105C BS26	Bajaj spare parts
PA621005	ASSEMBLY GEAR KICK PINION D105	Bajaj spare parts
PA621006	ASSLY KICKSHAFT D105A UG	Bajaj spare parts
PA621007	SHAFT KICK D105A UG	Bajaj spare parts
PA621008	GEAR KICK PINION D105A UG	Bajaj spare parts
PA621203	ASSLY KICK LEVER D100M UG	Bajaj spare parts
PA71013B	FUELTANK BLK/BLUE DECAL	Bajaj spare parts
PA71015E	FUELTANK DISCO M 94 RED MCM DECAL	Bajaj spare parts
PA72013B	FENDER FR EBONEY BLK	Bajaj spare parts
PA72013F	FENDER FR FL RED DIS M	Bajaj spare parts
PA72043B	FRONT FENDER PAINTED BLACK D105A	Bajaj spare parts
PA74043F	SIDE PANEL RH RED DECAL	Bajaj spare parts
PA74045R	SIDE PANEL RH D105A BR.BLUE DECAL	Bajaj spare parts
PA74053F	COWLING FLAME RED DECAL	Bajaj spare parts
PA74055R	COWLING BR.BLUE RED DEC	Bajaj spare parts
PA75013B	SEAT COWL E BLK/BLUE DECA	Bajaj spare parts
PA75013C	SEAT COWL E BLK/MAGN	Bajaj spare parts
PA75013F	COWL SEAT RED RED DIS M	Bajaj spare parts
PA75014N	SEAT COWL E BLK/GREEN DCL	Bajaj spare parts
PA75015D	SEAT COWL ASSLY PNTD E BLK GOLD	Bajaj spare parts
PA75015E	SEAT COWL ASSLY PNTD E BLK RED	Bajaj spare parts
PA75043F	SEAT COWL ASSLY PNTD D105A F RED DECAL	Bajaj spare parts
PD111009	FRAME ASSY AV 220	Bajaj spare parts
PD111035	FRAME ASSLY	Bajaj spare parts
PD111036	FRAME ASSLY COMP	Bajaj spare parts
PD111041	FRAME ASSLY AVENGER BS IV	Bajaj spare parts
PD111063	FRAME ASSEMBLY	Bajaj spare parts
PD111120	FRAME ASSEMBLY	Bajaj spare parts
PD113000	FOOTREST RIDER LH - AVENGER	Bajaj spare parts
PD113001	FOOTREST RIDER RH - AVENGER	Bajaj spare parts
PD113002	FOOTREST PILLION - AVENGER	Bajaj spare parts
PD113003	RUBBER RIDER STEP	Bajaj spare parts
PD113004	RUBBER PILLION STEP	Bajaj spare parts
PD113010	BRACKET PILLION STEP HOLDER	Bajaj spare parts
PD113028	HOLDER STEP RH	Bajaj spare parts
PD113203	BRACKET SIDE STAND SWITCH (LOOSE)	Bajaj spare parts

PD113204	BRACKET HOLDER MAGNET	Bajaj spare parts
PD113206	STAND SIDE	Bajaj spare parts
PD113207	STAND CENTER	Bajaj spare parts
PD113208	STAND CENTER	Bajaj spare parts
PD113400	"BRACKET, ENGINE TOP LH"	Bajaj spare parts
PD113401	"BRACKET, ENGINE TOP RH"	Bajaj spare parts
PD113410	BRACKET ENGINE MTG LH	Bajaj spare parts
PD113411	BRACKET ENG MTG TOP RH	Bajaj spare parts
PD113413	BKT ASSY ENG MTG REAR (EVAP)	Bajaj spare parts
PD113800	BRACKET FUSE	Bajaj spare parts
PD113803	BRACKET SPEEDOMETER CABLE	Bajaj spare parts
PD113805	BRACKET ABS	Bajaj spare parts
PD113806	BRACKET FUSE	Bajaj spare parts
PD113807	COVER REGULATOR ASSLY	Bajaj spare parts
PD113808	STRIP CLAMP	Bajaj spare parts
PD113809	BRACKET IGNITION LOCK MTG LOOSE	Bajaj spare parts
PD113810	BKT HT COIL MTG CARB LOOSE LH	Bajaj spare parts
PD113811	BKT HT COIL MTG CARB LOOSE RH	Bajaj spare parts
PD113814	BRACKET THROTTLE CABLE ROUTING	Bajaj spare parts
PD113815	COVER REGULATOR	Bajaj spare parts
PD113822	PLUG	Bajaj spare parts
PD113823	BRACKET ABS	Bajaj spare parts
PD113836	BRACKET RELAY STARTER	Bajaj spare parts
PD113837	BAND BATTERY	Bajaj spare parts
PD113838	BRACKET VALVE PURGE-RELAY	Bajaj spare parts
PD113839	BRACKET COIL IGNITION LH	Bajaj spare parts
PD113840	BRACKET COIL IGNITION RH	Bajaj spare parts
PD113841	BRACKET SWITCH IGNITION	Bajaj spare parts
PD113843	BRACKET	Bajaj spare parts
PD113845	HOOK	Bajaj spare parts
PD113847	BRACKET COVER SIDE RH	Bajaj spare parts
PD113854	BRACKET ABS	Bajaj spare parts
PD113855	HOLDER ECU	Bajaj spare parts
PD113856	FOAM	Bajaj spare parts
PD113857	BRACKET HARNESS	Bajaj spare parts
PD121000	TUBE OUTER LH	Bajaj spare parts
PD121001	TUBE OUTER RH	Bajaj spare parts
PD121002	ASSLY LEG LH	Bajaj spare parts
PD121006	BELLOW FRONT FORK A102	Bajaj spare parts
PD121007	FORK ASSLY FRONT - A102	Bajaj spare parts
PD121009	TUBE OUTER LH - FRONT FORK A102	Bajaj spare parts
PD121010	TUBE OUTER RH - FRONT FORK A102	Bajaj spare parts
PD121011	LEG ASSLY LH - FRONT FORK A102	Bajaj spare parts
PD121012	LEG ASSLY RH - FRONT FORK -A102	Bajaj spare parts
PD121014	CLAMP BELLOW TOP - A102	Bajaj spare parts

PD121015	ASSLY UNDER BKT(BLK)	Bajaj spare parts
PD121016	UNDER BRACKET(Silver)	Bajaj spare parts
PD121017	FORK ASSLY -A101	Bajaj spare parts
PD122000	SWING ARM	Bajaj spare parts
PD122003	ROD -TORQUE (52PD0021)	Bajaj spare parts
PD122004	BOLT -TORQUE ROD	Bajaj spare parts
PD122005	SHOCKABSORBER - A102	Bajaj spare parts
PD122011	SHOCKABSORBER REAR	Bajaj spare parts
PD122013	ARM ASSLY SWING	Bajaj spare parts
PD122016	SHOCKABSORBER REAR	Bajaj spare parts
PD122017	SHOCKABSORBER REAR	Bajaj spare parts
PD131007	WHEEL FRONT - A102 (TUBE LESS TYRE)	Bajaj spare parts
PD131212	COUPLING REAR - A102	Bajaj spare parts
PD131213	ASSLY COUPLING REAR - A102	Bajaj spare parts
PD131218	WHEEL REAR - A102 (TUBELESS TYRE)	Bajaj spare parts
PD131222	REAR DRUM	Bajaj spare parts
PD131224	WHEEL REAR-TL	Bajaj spare parts
PD131802	BRAKE SHOE ASSY-NON ASB	Bajaj spare parts
PD131803	DISC MTG BOLT	Bajaj spare parts
PD131804	DISC FRONT BRAKE - AVENGER 150	Bajaj spare parts
PD131805	ASSLY DISC BRAKE SYSTEM FRONT	Bajaj spare parts
PD131806	ASSLY CALIPER FRONT - A102	Bajaj spare parts
PD131807	ASSLY MC FRONT BRAKE - A102	Bajaj spare parts
PD131808	HOSE FRONT BRAKE - A102	Bajaj spare parts
PD131809	BRAKE PANEL REAR - A102	Bajaj spare parts
PD131810	ASSLY BRAKE PANEL REAR - A102	Bajaj spare parts
PD131812	DISC BRAKE KIT ASSY FRONT	Bajaj spare parts
PD131813	ASSLY CALIPER - A102B	Bajaj spare parts
PD131814	DISC BRAKE KIT FRONT - A102B	Bajaj spare parts
PD131815	DISC BRAKE FRONT - A102B	Bajaj spare parts
PD131816	ASSLY MASTER CYLINDER - A101	Bajaj spare parts
PD131817	ASSLY BRAKE PANEL - NON ASBESTOS	Bajaj spare parts
PD131819	BRAKE PANEL REAR	Bajaj spare parts
PD131823	CALIPER ASSLY FRONT ABS	Bajaj spare parts
PD131824	CALIPER ASSLY FRONT ABS	Bajaj spare parts
PD131833	DISC BRAKE DIA 280	Bajaj spare parts
PD131834	DISC BRAKE DIA 280	Bajaj spare parts
PD131835	DISC SENSOR SPEED FRONT	Bajaj spare parts
PD131836	DISC SENSOR SPEED REAR	Bajaj spare parts
PD131851	CLAMP HOSE BRAKE FRONT	Bajaj spare parts
PD131852	BRAKE SYSTEM FRONT	Bajaj spare parts
PD131853	CALIPER ASSLY FRONT	Bajaj spare parts
PD131876	UNIT ABS WET	Bajaj spare parts
PD131887	CYLINDER ASSEMBLY MASTER FRONT	Bajaj spare parts
PD131888	CYLINDER ASSEMBLY MASTER FRONT	Bajaj spare parts

PD131892	PEDAL BRAKE	Bajaj spare parts
PD131894	BUSH SPRING TORSION	Bajaj spare parts
PD141001	SPROCKET OUTPUT	Bajaj spare parts
PD141007	CHAIN	Bajaj spare parts
PD151000	HANDLE BAR	Bajaj spare parts
PD151001	HOLDER HANDLE UPPER	Bajaj spare parts
PD151003	UPPER BRACKET - A102	Bajaj spare parts
PD151004	HOLDER LH HANDLE TUBE - A102	Bajaj spare parts
PD151005	HOLDER RH HANDLE TUBE - A102	Bajaj spare parts
PD151006	CAP STEERING - AVENGER	Bajaj spare parts
PD151007	HANDLE BAR - A101	Bajaj spare parts
PD151009	WEIGHT HANDLE BAR - A101	Bajaj spare parts
PD151020	HOLDER FORK UPPER	Bajaj spare parts
PD161001	GRIP LH - A102	Bajaj spare parts
PD161004	GRIP ASSLY RH - A102	Bajaj spare parts
PD161005	LEVER AND SUPPORT HOLDER ASSY-A101	Bajaj spare parts
PD161203	CLUTCH CABLE -A101	Bajaj spare parts
PD161204	CABLE THROTTLE - A102 & A102B	Bajaj spare parts
PD161207	CABLE CLUTCH	Bajaj spare parts
PD161208	CABLE THROTTLE	Bajaj spare parts
PD161209	CABLE CLUTCH	Bajaj spare parts
PD161210	CABLE THROTTLE	Bajaj spare parts
PD161213	CABLE THROTTLE	Bajaj spare parts
PD161214	CABLE THROTTLE	Bajaj spare parts
PD161217	PLUG	Bajaj spare parts
PD171000	COVER ASLY. FUEL TANK	Bajaj spare parts
PD171003	COLLAR -TANK MTG	Bajaj spare parts
PD171008	COVER TANK - SATIN BLACK - A102	Bajaj spare parts
PD171012	ASSLY FUEL TANK - AVENGER ABS	Bajaj spare parts
PD171023	DAMPER TANK RESTING CENTRAL	Bajaj spare parts
PD171029	TUBE CANISTER DRAIN	Bajaj spare parts
PD171047	BRACKET COVER TANK	Bajaj spare parts
PD171048	BRACKET COVER TANK	Bajaj spare parts
PD171049	DAMPER	Bajaj spare parts
PD171601	CAP TANK - A102	Bajaj spare parts
PD171602	TUBE TANK TO T CONNECTOR	Bajaj spare parts
PD171603	TUBE INLINE CONNECTOR TO Y CONNECTOR	Bajaj spare parts
PD171604	TUBE Y CONNECTOR TO CANISTER	Bajaj spare parts
PD171605	TUBE CANISTER TO PURGE VALVE	Bajaj spare parts
PD171606	TUBE PURGE VALVE TO CARBURETTOR	Bajaj spare parts
PD171607	CAP FUEL TANK -EVAP	Bajaj spare parts
PD171609	TUBE CANISTER BREATHER	Bajaj spare parts
PD171611	TUBE Y TO DRAIN	Bajaj spare parts
PD171612	CAP FUEL TANK-A102 SATIN CHROME	Bajaj spare parts
PD171616	VALVE PURGE	Bajaj spare parts

PD171619	TUBE Y-CONNECTOR BREATHER CANISTER	Bajaj spare parts
PD171627	PIPE CANISTER-CONNECTOR	Bajaj spare parts
PD171628	PIPE CONNECTOR-VALVE PURGE	Bajaj spare parts
PD171629	PIPE VALVE PURGE-BODY THROTTLE	Bajaj spare parts
PD171807	PIPE PUMP FUEL-CONNECTOR	Bajaj spare parts
PD181000	BATTERY BOX ASSLY 2 - A102	Bajaj spare parts
PD181202	BEADING	Bajaj spare parts
PD181204	COVER GRAB REAR LH - A101	Bajaj spare parts
PD181205	COVER GRAB REAR RH - A101	Bajaj spare parts
PD181207	FOAM BATTERY CASE - A102	Bajaj spare parts
PD181212	COVER GRAB REAR LH - A102	Bajaj spare parts
PD181213	COVER GRAB REAR RH - A102	Bajaj spare parts
PD181214	PLATE COVER GRAB REAR LH - A102	Bajaj spare parts
PD181215	PLATE COVER GRAB REAR RH - A102	Bajaj spare parts
PD181216	BRACKET FORK COVER - A102-A102B	Bajaj spare parts
PD181221	BRACKET COVER FORK	Bajaj spare parts
PD181222	VISOR	Bajaj spare parts
PD181223	BRACKET COVER FORK	Bajaj spare parts
PD181227	COVER TANK	Bajaj spare parts
PD181228	COVER TANK	Bajaj spare parts
PD181230	BRACKET SPEEDO MTG	Bajaj spare parts
PD181234	BRACKET SPEEDOMETER	Bajaj spare parts
PD181235	BRACKET HEAD LAMP MOUNTING UPPER	Bajaj spare parts
PD181239	PIN	Bajaj spare parts
PD181241	BRACKET LAMP HEAD UPPER	Bajaj spare parts
PD181243	COLLAR	Bajaj spare parts
PD181245	NUT SPECIAL	Bajaj spare parts
PD181281	FOAM	Bajaj spare parts
PD181400	GROMMET REAR FENDER	Bajaj spare parts
PD181401	DAMPER REAR FENDER	Bajaj spare parts
PD181408	BRACE FENDER FRONT	Bajaj spare parts
PD181411	FENDER REAR	Bajaj spare parts
PD181412	FLAP FENDER-REAR	Bajaj spare parts
PD181413	BRACKET STRUCTURE REAR FENDER MTG	Bajaj spare parts
PD181421	FOAM FLAP FENDER REAR	Bajaj spare parts
PD191000	SEAT ASSLYL-A101	Bajaj spare parts
PD191001	WASHER SPECIAL NONMETALIC - A102	Bajaj spare parts
PD191002	ASSLY SEAT - A102	Bajaj spare parts
PD191009	SEAT ASSLY	Bajaj spare parts
PD191010	SEAT ASSLY	Bajaj spare parts
PD191020	SEAT ASSEMBLY	Bajaj spare parts
PD191024	SEAT ASSEMBLY	Bajaj spare parts
PD231201	GUARD SAREE - A102	Bajaj spare parts
PD231202	GUARD LEG - A102	Bajaj spare parts
PD231204	GUARD MUFFLER-A102	Bajaj spare parts

PD231205	GUARD BRAKE PEDAL-A102	Bajaj spare parts
PD231206	GUARD STEP LH-A102	Bajaj spare parts
PD231400	GRAB REAR - A101	Bajaj spare parts
PD231401	GRAB REAR - A102	Bajaj spare parts
PD231402	BRACKET GRAB STRUCTURE LH - A102	Bajaj spare parts
PD231403	BRACKET GRAB STRUCTURE RH - A102	Bajaj spare parts
PD231404	CAP GRAB RAIL LH	Bajaj spare parts
PD231407	COVER PAD SEAT - A101	Bajaj spare parts
PD231408	SIDE PLATE LH COVER REAR	Bajaj spare parts
PD231409	SIDE PLATE RH COVER GRAB REAR - A101	Bajaj spare parts
PD231410	EMBLEM BACKREST AVENGER	Bajaj spare parts
PD231411	CAP GRAB RAIL RH	Bajaj spare parts
PD231412	NAIL GRAB ASSLY REAR - A101	Bajaj spare parts
PD231420	GRAB HANDLE REAR	Bajaj spare parts
PD231602	MIRROR ASSLY LH - A101	Bajaj spare parts
PD231603	MIRROR ASSLY RH - A101	Bajaj spare parts
PD231604	MIRROR ASSLY LH	Bajaj spare parts
PD231605	MIRROR ASSLY RH	Bajaj spare parts
PD232001	COVER WIND SHIELD MOUNTING	Bajaj spare parts
PD232003	FRAME WINDSHIELD MOUNTING	Bajaj spare parts
PD232004	BRACKET WINDSHIELD FRAME MTG	Bajaj spare parts
PD232005	PLATE WINDSHIELD	Bajaj spare parts
PD232602	LOCK SET ASSEMBLY - AVENGER	Bajaj spare parts
PD232603	STEERING LOCK - AVENGER	Bajaj spare parts
PD232604	SET LOCK	Bajaj spare parts
PD232817	BRACKET ASSY PLATE NUMBER FRONT	Bajaj spare parts
PD232819	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
PD233001	AVENGER BRANDING	Bajaj spare parts
PD233002	3D TANK DECAL LH	Bajaj spare parts
PD233003	3D TANK DECAL RH	Bajaj spare parts
PD233020	DECAL FRONT FENDER CENTER	Bajaj spare parts
PD233022	DECAL RR FENDER CENTER	Bajaj spare parts
PD233030	DECAL WHEEL RIM FR	Bajaj spare parts
PD233031	DECAL WHEEL RIM REAR (DARK SILVER)	Bajaj spare parts
PD233037	DECAL 3D LH - TANK	Bajaj spare parts
PD233038	DECAL 3D RH - TANK	Bajaj spare parts
PD233042	SIDE COVER DECAL LH (PASSION RED)	Bajaj spare parts
PD233043	SIDE COVER DECAL RH (PASSION RED)	Bajaj spare parts
PD233048	SIDE COVER DECAL LH (GOLDEN BEIGE)	Bajaj spare parts
PD233049	SIDE COVER DECAL RH (GOLDEN BEIGE)	Bajaj spare parts
PD233053	DECAL COVER SIDE LH VIBRANT RED	Bajaj spare parts
PD233054	DECAL COVER SIDE RH VIBRANT RED	Bajaj spare parts
PD233057	DECAL COVER SIDE LH MATTE GREEN	Bajaj spare parts
PD233058	DECAL COVER SIDE RH MATTE GREEN	Bajaj spare parts
PD233063	DECAL 3D LH	Bajaj spare parts

PD233064	DECAL 3D RH	Bajaj spare parts
PD233065	DECAL 3D LH	Bajaj spare parts
PD233066	DECAL 3D RH	Bajaj spare parts
PD233072	DECAL COVER SIDE LH MATTE BLACK	Bajaj spare parts
PD233073	DECAL COVER SIDE RH MATTE BLACK	Bajaj spare parts
PD233077	DECAL COVER SIDE LH KHI E BLACK	Bajaj spare parts
PD233078	DECAL COVER SIDE RH KHI E BLACK	Bajaj spare parts
PD233082	DECAL TANK UPPER LH T NIGHT	Bajaj spare parts
PD233083	DECAL TANK UPPER RH T NIGHT	Bajaj spare parts
PD233084	DECAL COVER SIDE LH T NIGHT	Bajaj spare parts
PD233085	DECAL COVER SIDE RH T NIGHT	Bajaj spare parts
PD233088	DECAL COVER SIDE LH C WHITE	Bajaj spare parts
PD233089	DECAL COVER SIDE RH C WHITE	Bajaj spare parts
PD233090	DECAL TANK LH SPICY RED	Bajaj spare parts
PD233092	DECAL COVER SIDE LH SPICY RED	Bajaj spare parts
PD233093	DECAL COVER SIDE RH SPICY RED	Bajaj spare parts
PD233098	DECAL COVER SIDE LH MATT C WHITE	Bajaj spare parts
PD233099	DECAL COVER SIDE RH MATT C WHITE	Bajaj spare parts
PD233118	DECAL COVER SIDE LH SPICY RED	Bajaj spare parts
PD233119	DECAL COVER SIDE RH SPICY RED	Bajaj spare parts
PD233120	DECAL COVER SIDE LH KHI E BLACK	Bajaj spare parts
PD233121	DECAL COVER SIDE RH KHI E BLACK	Bajaj spare parts
PD233122	LABEL GEAR SHIFT	Bajaj spare parts
PD351001	STATOR ASSY 12 POLE 1PH	Bajaj spare parts
PD351002	STATOR ASSEMBLY	Bajaj spare parts
PD351007	ROTOR ASSEMBLY	Bajaj spare parts
PD351012	STATOR ASSEMBLY	Bajaj spare parts
PD351016	NEUTRAL SWITCH K17A	Bajaj spare parts
PD351022	STATOR ASSEMBLY	Bajaj spare parts
PD351026	ROTOR ASSEMBLY	Bajaj spare parts
PD351028	SENSOR ASSEMBLY PICK UP	Bajaj spare parts
PD351034	ROTOR ASSEMBLY	Bajaj spare parts
PD351057	ROTOR ASSEMBLY	Bajaj spare parts
PD351200	C.D.I ASLY. / DAMPER	Bajaj spare parts
PD351205	COIL H.T. KIT	Bajaj spare parts
PD351213	CDI ASSLY WITH DAMPER (101)	Bajaj spare parts
PD351215	CDI ASSLY WITH DAMPER (102)	Bajaj spare parts
PD351220	H.T. COIL 1	Bajaj spare parts
PD351221	H.T. COIL 2 WITH CAP	Bajaj spare parts
PD351222	H.T. COIL 2	Bajaj spare parts
PD351235	H.T. COIL 1	Bajaj spare parts
PD351237	H.T. COIL 2	Bajaj spare parts
PD351248	CDI	Bajaj spare parts
PD351249	COIL ASSEMBLY IGNITION LH	Bajaj spare parts
PD351250	COIL ASSEMBLY IGNITION RH	Bajaj spare parts



PD351252	CDI	Bajaj spare parts
PD351255	COIL ASSEMBLY IGNITION LH	Bajaj spare parts
PD351256	COIL ASSEMBLY IGNITION RH	Bajaj spare parts
PD351262	COIL ASSEMBLY IGNITION LH	Bajaj spare parts
PD351425	ECU EMS	Bajaj spare parts
PD351608	MOTOR STARTER	Bajaj spare parts
PD351611	MOTOR STARTER	Bajaj spare parts
PD351808	SENSOR TEMPERATURE	Bajaj spare parts
PD401000	TAIL LAMP ASSY / LAMP	Bajaj spare parts
PD401001	LAMP TAIL ASSEMBLY	Bajaj spare parts
PD401004	INDICATOR FRONT LH - A102	Bajaj spare parts
PD401005	INDICATOR FRONT RH - A102	Bajaj spare parts
PD401006	INDICATOR REAR LH - A102	Bajaj spare parts
PD401007	INDICATOR REAR RH - A102	Bajaj spare parts
PD401008	INDICATOR FRONT LH - A101	Bajaj spare parts
PD401009	INDICATOR FRONT RH - A101	Bajaj spare parts
PD401010	INDICATOR REAR LH - A101	Bajaj spare parts
PD401011	INDICATOR REAR RH - A101	Bajaj spare parts
PD401012	HEAD LAMP - A102	Bajaj spare parts
PD401013	HEAD LAMP - A101	Bajaj spare parts
PD401014	BULB H4 BLUE TINGE -12V55/60W	Bajaj spare parts
PD401016	INDICATOR ASSY FR LH-A101	Bajaj spare parts
PD401017	INDICATOR ASSY FR RH-A101	Bajaj spare parts
PD401018	INDICATOR ASSY RR LH-A101	Bajaj spare parts
PD401019	INDICATOR ASSY RR RH-A101	Bajaj spare parts
PD401028	LAMP ASSLY-TAIL	Bajaj spare parts
PD401029	LAMP HEAD ASSLY BULB	Bajaj spare parts
PD401030	INDICATOR LH FRONT	Bajaj spare parts
PD401031	INDICATOR RH FRONT	Bajaj spare parts
PD401032	INDICATOR LH REAR	Bajaj spare parts
PD401033	INDICATOR RH REAR	Bajaj spare parts
PD401034	LAMP HEAD ASSLY	Bajaj spare parts
PD401038	LAMP NUMBER PLATE ILLUMINATION	Bajaj spare parts
PD401045	INDICATOR FRONT LH	Bajaj spare parts
PD401046	INDICATOR FRONT RH	Bajaj spare parts
PD401048	INDICATOR FRONT LH	Bajaj spare parts
PD401049	INDICATOR FRONT RH	Bajaj spare parts
PD401400	SWITCH ASSLY. IGNITION	Bajaj spare parts
PD401401	Control Switch RH	Bajaj spare parts
PD401402	LOCK SET (5 IN 1)	Bajaj spare parts
PD401404	HOUSING ASLY.CONT LH	Bajaj spare parts
PD401408	LOCK SET (4 IN 1) AV 220	Bajaj spare parts
PD401409	CONTROL SWITCH RH	Bajaj spare parts
PD401410	CONTROL SWITCH LH - A101	Bajaj spare parts
PD401411	CONTROL SWITCH RH - A101	Bajaj spare parts

PD401413	SIDE STAND SWITCH-A102 (WVTA)	Bajaj spare parts
PD401414	SWITCH CONTROL AHO RH-A101	Bajaj spare parts
PD401424	SWITCH CONTROL RH	Bajaj spare parts
PD401425	SWITCH CONTROL RH	Bajaj spare parts
PD401435	SWITCH CONTROL LH	Bajaj spare parts
PD401437	SWITCH CONTROL LH	Bajaj spare parts
PD401440	SWITCH CONTROL RH	Bajaj spare parts
PD401601	HORN - A102	Bajaj spare parts
PD401602	HORN - A101	Bajaj spare parts
PD401807	CASE BATTERY	Bajaj spare parts
PD402001	RELAY TURN SIGNAL	Bajaj spare parts
PD402002	CAPACITOR WITH BRACKET	Bajaj spare parts
PD402003	REGULATOR VOLTAGE	Bajaj spare parts
PD402004	REGULATOR ASSLY	Bajaj spare parts
PD402005	REGULATOR DC 3 PHASE	Bajaj spare parts
PD402006	REGULATOR	Bajaj spare parts
PD402007	REGULATOR	Bajaj spare parts
PD402200	HARNESS WIRING	Bajaj spare parts
PD402202	HARNESS WIRING AV 220	Bajaj spare parts
PD402207	SPEEDOMETER CABLE	Bajaj spare parts
PD402208	MAIN WIRING HARNESS	Bajaj spare parts
PD402209	WIRING HARNESS	Bajaj spare parts
PD402210	WIRING HARNESS EXPORT	Bajaj spare parts
PD402212	HARNESS	Bajaj spare parts
PD402213	CABLE BATTERY EARTH A102	Bajaj spare parts
PD402214	CABLE STARTER RELAY TO MOTOR	Bajaj spare parts
PD402215	HARNESS - A101	Bajaj spare parts
PD402216	WIRING HARNESS -A102 (WVTA)	Bajaj spare parts
PD402219	WIRING HARNESS-AHO-(A101)	Bajaj spare parts
PD402226	HARNESS-A102 BS IV	Bajaj spare parts
PD402227	HARNESS-A101 BS IV	Bajaj spare parts
PD402228	HARNESS WIRING	Bajaj spare parts
PD402233	HARNESS WIRING	Bajaj spare parts
PD402234	HARNESS WIRING	Bajaj spare parts
PD402235	HARNESS WIRING BS IV AHO	Bajaj spare parts
PD402236	HARNESS WIRING BS IV AHO	Bajaj spare parts
PD402237	HARNESS WIRING	Bajaj spare parts
PD402249	HARNESS WIRING	Bajaj spare parts
PD402250	HARNESS WIRING	Bajaj spare parts
PD402266	HARNESS WIRING ABS	Bajaj spare parts
PD402271	CABLE BATTERY NEGATIVE	Bajaj spare parts
PD402274	CABLE EARTH	Bajaj spare parts
PD402275	HARNESS WIRING	Bajaj spare parts
PD402284	HARNESS WIRING	Bajaj spare parts
PD402285	HARNESS WIRING	Bajaj spare parts

PD402400	SPEEDOMETER ASSLY A102	Bajaj spare parts
PD402401	SPEEDOMETER A101	Bajaj spare parts
PD402402	SPEEDOMETER	Bajaj spare parts
PD402405	SPEEDOMETER A102	Bajaj spare parts
PD402406	SPEEDOMETER	Bajaj spare parts
PD402407	SPEEDOMETER	Bajaj spare parts
PD402412	SPEEDOMETER	Bajaj spare parts
PD402413	SPEEDOMETER	Bajaj spare parts
PD402418	SPEEDOMETER	Bajaj spare parts
PD402424	SPEEDOMETER	Bajaj spare parts
PD402426	SPEEDOMETER	Bajaj spare parts
PD402428	SPEEDOMETER	Bajaj spare parts
PD402600	GAUGE FUEL (METER)	Bajaj spare parts
PD402602	FUEL GAUGE ASSY	Bajaj spare parts
PD402604	GAUGE TANK UNIT	Bajaj spare parts
PD402606	GAUGE FUEL LEVEL - AVENGER	Bajaj spare parts
PD402607	FUEL LEVEL SENSOR	Bajaj spare parts
PD402608	CONSOLE TELL TALE	Bajaj spare parts
PD402610	CONSOLE TELL TALE	Bajaj spare parts
PD402611	CONSOLE TELL TALE	Bajaj spare parts
PD402617	CONSOLE TELL TALE	Bajaj spare parts
PD403602	SENSOR SPEED WHEEL	Bajaj spare parts
PD501030	ENGINE ASSEMBLY	Bajaj spare parts
PD501033	ENGINE ASSEMBLY	Bajaj spare parts
PD501049	KIT DCL LH SIDE CVR R BLUE	Bajaj spare parts
PD501063	ENGINE ASSEMBLY	Bajaj spare parts
PD501066	ENGINE ASSEMBLY	Bajaj spare parts
PD501072	ENGINE ASSEMBLY	Bajaj spare parts
PD501114	ENGINE ASSEMBLY	Bajaj spare parts
PD509000	MANIFOLD FOR RPT (BS29)	Bajaj spare parts
PD509001	CONNECTING TUBE	Bajaj spare parts
PD511021	CYLINDER HEAD	Bajaj spare parts
PD511025	TAPPET COVER	Bajaj spare parts
PD511053	COVER CYLINDER HEAD	Bajaj spare parts
PD511054	COVER CYLINDER HEAD	Bajaj spare parts
PD511084	CHAIN	Bajaj spare parts
PD511085	PLUG SHAFT ROCKER	Bajaj spare parts
PD511086	BELLEVILLE WASHER	Bajaj spare parts
PD511096	GASKET COVER HEAD CYLINDER	Bajaj spare parts
PD511129	BRACKET HT CABLE	Bajaj spare parts
PD511131	HEAD CYLINDER	Bajaj spare parts
PD511134	GASKET HEAD CYLINDER	Bajaj spare parts
PD511172	GASKET HEAD CYLINDER	Bajaj spare parts
PD511178	GASKET COVER HEAD CYLINDER	Bajaj spare parts
PD511193	SPACER	Bajaj spare parts

PD511195	HEAD CYLINDER	Bajaj spare parts
PD511205	SLEEVE PLUG SPARK	Bajaj spare parts
PD511216	CAMSHAFT ASSEMBLY	Bajaj spare parts
PD511218	ROCKER ARM ASSEMBLY	Bajaj spare parts
PD511221	SPROCKET CRANKSHAFT	Bajaj spare parts
PD511224	ASSLY CAMSHAFT	Bajaj spare parts
PD511229	SPROCKET CAMSHAFT	Bajaj spare parts
PD511231	SEAT SPRING VALVE	Bajaj spare parts
PD511233	VALVE INTAKE	Bajaj spare parts
PD511234	VALVE EXHAUST	Bajaj spare parts
PD511235	CAMSHAFT ASSEMBLY	Bajaj spare parts
PD511237	ROCKER ARM ASSEMBLY	Bajaj spare parts
PD511241	SHAFT ROCKER ARM	Bajaj spare parts
PD511243	CHAIN	Bajaj spare parts
PD511246	SPRING VALVE	Bajaj spare parts
PD511253	SPACER	Bajaj spare parts
PD511256	CAMSHAFT ASSEMBLY	Bajaj spare parts
PD511268	SEAL STEM VALVE	Bajaj spare parts
PD511309	SHAFT ROCKER ARM	Bajaj spare parts
PD511317	SHAFT ROCKER ARM	Bajaj spare parts
PD511326	CAMSHAFT ASSEMBLY	Bajaj spare parts
PD511502	GASKET HEAD CYLINDER	Bajaj spare parts
PD511516	HEAD CYLINDER-COVER ASSEMBLY	Bajaj spare parts
PD511573	GASKET COVER HEAD CYLINDER	Bajaj spare parts
PD511576	COVER ASSEMBLY HEAD CYLINDER	Bajaj spare parts
PD511625	GASKET HEAD CYLINDER	Bajaj spare parts
PD521005	GASKET BLOCK CYLINDER	Bajaj spare parts
PD521014	GASKET BLOCK CYLINDER	Bajaj spare parts
PD521200	PISTON ASSLY K17 A	Bajaj spare parts
PD531015	CRANKSHAFT ASSEMBLY	Bajaj spare parts
PD531022	CRANKSHAFT ASSEMBLY	Bajaj spare parts
PD531028	SPROCKET CRANKSHAFT	Bajaj spare parts
PD531029	SPROCKET CRANKSHAFT	Bajaj spare parts
PD531037	CRANKSHAFT ASSEMBLY	Bajaj spare parts
PD531046	SPROCKET CRANKSHAFT	Bajaj spare parts
PD531052	BOLT ASSEMBLY	Bajaj spare parts
PD531053	NOZZLE	Bajaj spare parts
PD531204	BALANCER ASSEMBLY	Bajaj spare parts
PD531213	BALANCER ASSEMBLY	Bajaj spare parts
PD531227	BALANCER ASSEMBLY	Bajaj spare parts
PD531229	ASSEMBLY GEAR BALANCER IDLER	Bajaj spare parts
PD531232	BALANCER ASSEMBLY	Bajaj spare parts
PD531239	BALANCER ASSEMBLY	Bajaj spare parts
PD541018	CRANKCASE RH	Bajaj spare parts
PD541020	ASSLY CRANKCASE RH	Bajaj spare parts

PD541028	GASKET CRANKCASE	Bajaj spare parts
PD541048	GUARD CHAIN	Bajaj spare parts
PD541049	GASKET CRANKCASE	Bajaj spare parts
PD541050	RETAINER GEAR STARTER	Bajaj spare parts
PD541091	STOPPER BEARING	Bajaj spare parts
PD541120	GASKET CRANKCASE	Bajaj spare parts
PD541225	ASSLY COVER MAGNETO	Bajaj spare parts
PD541231	COVER REAR LH	Bajaj spare parts
PD541239	GASKET COVER CLUTCH	Bajaj spare parts
PD541261	SHAFT ASSEMBLY CLUTCH	Bajaj spare parts
PD541264	SPRING	Bajaj spare parts
PD541265	ROD PUSH G2	Bajaj spare parts
PD541267	GASKET COVER CLUTCH	Bajaj spare parts
PD541268	BRACKET CABLE CLUTCH	Bajaj spare parts
PD541271	BRACKET CABLE STATOR	Bajaj spare parts
PD541272	GASKET COVER MAGNETO	Bajaj spare parts
PD541274	PLATE STOPPER	Bajaj spare parts
PD541279	LEVER ASSEMBLY CLUTCH	Bajaj spare parts
PD541280	BRACKET CABLE CLUTCH	Bajaj spare parts
PD541291	GASKET COVER MAGNETO	Bajaj spare parts
PD541292	BRACKET HARNESS STATOR	Bajaj spare parts
PD541314	COVER REAR LH	Bajaj spare parts
PD541316	PLUG	Bajaj spare parts
PD541317	PLUG	Bajaj spare parts
PD551001	LEVER COMP GEAR SHIFT	Bajaj spare parts
PD551018	SHAFT OUTPUT-PLUG	Bajaj spare parts
PD551028	SHAFT I/P TRANSMISSION SUB ASSLY	Bajaj spare parts
PD551061	SHAFT OUTPUT-PLUG	Bajaj spare parts
PD551071	SEAL OIL	Bajaj spare parts
PD551073	SPROCKET DRIVE	Bajaj spare parts
PD551204	GEAR 5TH DRIVEN	Bajaj spare parts
PD551257	PLAIN WASHER 1ST GEAR	Bajaj spare parts
PD551260	BUSH COLLAR	Bajaj spare parts
PD551261	BUSH	Bajaj spare parts
PD551305	GEAR STARTER COUNTER I	Bajaj spare parts
PD551306	GEAR STARTER COUNTER II	Bajaj spare parts
PD551400	CLUTCH ASSLY COMPLETE	Bajaj spare parts
PD551404	CLUTCH ASSEMBLY	Bajaj spare parts
PD551418	CLUTCH ASSLY	Bajaj spare parts
PD551419	DISK C FRICTION CLUTCH	Bajaj spare parts
PD551420	SPRING CLUTCH	Bajaj spare parts
PD551421	CLUTCH CENTER	Bajaj spare parts
PD551427	SPRING CLUTCH	Bajaj spare parts
PD551433	CLUTCH PLATE	Bajaj spare parts
PD551438	ASSEMBLY CLUTCH	Bajaj spare parts

PD551439	PLATE CLUTCH PRESSURE PLANISHED	Bajaj spare parts
PD551453	CLUTCH ONE WAY	Bajaj spare parts
PD561011	DRUM GEAR SHIFT	Bajaj spare parts
PD561013	FORK GEAR SHIFT INPUT	Bajaj spare parts
PD561014	FORK GEAR SHIFT OUTPUT I	Bajaj spare parts
PD561015	FORK GEAR SHIFT OUTPUT 2	Bajaj spare parts
PD561215	TORSION SPRING_K17B	Bajaj spare parts
PD561229	LEVER GEAR SHIFT ASSLY COMP	Bajaj spare parts
PD561233	SPRING PAWL	Bajaj spare parts
PD561236	BUSH SPRING TORSION	Bajaj spare parts
PD561237	STOPPER ASSEMBLY DRUM	Bajaj spare parts
PD571012	PUMP OIL	Bajaj spare parts
PD571016	PUMP ASSLY OIL	Bajaj spare parts
PD571200	COOLER OIL ASSLY	Bajaj spare parts
PD571201	PIPE INLET OIL COOLER	Bajaj spare parts
PD571203	PIPE OUTLET OIL COOLER	Bajaj spare parts
PD571205	SHROUD OIL COOLER	Bajaj spare parts
PD571208	ASSLY OIL COOLER A101	Bajaj spare parts
PD571209	OIL COOLER ASSLY	Bajaj spare parts
PD571210	SHROUD OIL COOLER	Bajaj spare parts
PD571211	OIL COOLER SHROUD WITH MESH	Bajaj spare parts
PD571212	WASHER SHROUD OIL COOLER	Bajaj spare parts
PD571227	ASSEMBLY VALVE PRESSURE RELIEF	Bajaj spare parts
PD571239	COOLER OIL	Bajaj spare parts
PD571241	PIPE ASSEMBLY INLET	Bajaj spare parts
PD571243	PIPE ASSEMBLY OUTLET	Bajaj spare parts
PD581001	TUBE CONNECTING	Bajaj spare parts
PD581003	ASSLY AIR FILTER	Bajaj spare parts
PD581009	BREATHER TUBE	Bajaj spare parts
PD581011	BOOT	Bajaj spare parts
PD581012	TUBE DRAIN	Bajaj spare parts
PD581013	ASSEMBLY AIR FILTER	Bajaj spare parts
PD581017	BRACKET AIR FILTER	Bajaj spare parts
PD581021	FILTER ASSEMBLY AIR	Bajaj spare parts
PD581029	PIPE ASSEMBLY BREATHER	Bajaj spare parts
PD581030	ASSLY AIR FILTER A101_SAI	Bajaj spare parts
PD581033	ASSLY AIR FILTER A102_SAI	Bajaj spare parts
PD581035	PIPE BREATHER	Bajaj spare parts
PD581037	SEAL FILTER AIR	Bajaj spare parts
PD581042	FILTER ASSEMBLY AIR	Bajaj spare parts
PD581047	ELEMENT FILTER	Bajaj spare parts
PD581052	COVER TOP	Bajaj spare parts
PD581061	TUBE DRAIN	Bajaj spare parts
PD581071	FILTER ASSEMBLY AIR	Bajaj spare parts
PD581080	FILTER ASSLY AIR	Bajaj spare parts

PD581098	PIPE ASSEMBLY BREATHER	Bajaj spare parts
PD581100	FILTER ASSEMBLY AIR	Bajaj spare parts
PD581108	FILTER ASSEMBLY AIR	Bajaj spare parts
PD581112	BRACKET FILTER AIR	Bajaj spare parts
PD581135	BOX RESONATOR	Bajaj spare parts
PD581137	FILTER ASSEMBLY AIR	Bajaj spare parts
PD581143	FILTER ASSEMBLY AIR	Bajaj spare parts
PD581200	CARBURETTOR ASSLY.	Bajaj spare parts
PD581202	VACUUM PISTON KIT	Bajaj spare parts
PD581203	IDLING SCREW KIT	Bajaj spare parts
PD581204	FLOAT BOWL O RING	Bajaj spare parts
PD581205	JET NEEDLE(JN)	Bajaj spare parts
PD581206	FLOAT BOWL SCREW	Bajaj spare parts
PD581207	FLOAT ASSLY.	Bajaj spare parts
PD581211	NEEDLE ASSLY.	Bajaj spare parts
PD581212	SET ADJUSTER (PS)	Bajaj spare parts
PD581214	CARBURETTOR ASSLY	Bajaj spare parts
PD581215	CARBURETTOR ASSLY	Bajaj spare parts
PD581216	ASSLY CARBURETTOR A101_EVAP	Bajaj spare parts
PD581217	ASSLY CARBURETTOR A102_EVAP	Bajaj spare parts
PD581220	SLEEVE CARBURETTOR	Bajaj spare parts
PD581221	CARBURETTOR	Bajaj spare parts
PD581226	CARBURETTOR	Bajaj spare parts
PD581300	CARBURETTOR	Bajaj spare parts
PD581401	CARBURETTOR INSULATOR	Bajaj spare parts
PD581402	CARB INSULATOR WITH CLAMPS	Bajaj spare parts
PD581403	INTAKE MANIFOLD	Bajaj spare parts
PD581404	PIPE INTAKE	Bajaj spare parts
PD581409	ASSLY INTAKE MANIFOLD A101_SAI	Bajaj spare parts
PD581410	ASSLY INTAKE MANIFOLD A102_SAI	Bajaj spare parts
PD581413	PIPE INTAKE	Bajaj spare parts
PD581432	PIPE INTAKE	Bajaj spare parts
PD581434	SLEEVE MANIFOLD	Bajaj spare parts
PD581444	INSULATOR	Bajaj spare parts
PD582200	UNIT SAI	Bajaj spare parts
PD582400	HOSE SAI UNIT TO INTAKE MANIFOLD	Bajaj spare parts
PD582401	HOSE SAI UNIT TO AIR FILTER	Bajaj spare parts
PD582402	HOSE SAI UNIT TO SAI PIPE	Bajaj spare parts
PD582407	HOSE UNIT SAI-MANIFOLD	Bajaj spare parts
PD591023	SHIELD CAT	Bajaj spare parts
PD591035	SHIELD EXHAUST FRONT	Bajaj spare parts
PD591036	SHIELD EXHAUST RIDER	Bajaj spare parts
PD591037	SHIELD EXHAUST REAR	Bajaj spare parts
PD591079	ASSLY SILENCER W/O CAT_A102	Bajaj spare parts
PD591087	MUFFLER ASSEMBLY PRIMARY	Bajaj spare parts

PD591100	WASHER SHIELD	Bajaj spare parts
PD591101	TRUSS SCREW	Bajaj spare parts
PD591158	GASKET	Bajaj spare parts
PD591159	SHIELD MUFFLER	Bajaj spare parts
PD591185	SHIELD MUFFLER	Bajaj spare parts
PD591233	SHIELD	Bajaj spare parts
PD591276	SHIELD CATALYST	Bajaj spare parts
PD591280	ASSEMBLY PIPE A	Bajaj spare parts
PD591325	GASKET	Bajaj spare parts
PD591350	ASSEMBLY PIPE A	Bajaj spare parts
PD591364	MUFFLER ASSEMBLY SECONDARY	Bajaj spare parts
PD591383	SILENCER ASSEMBLY	Bajaj spare parts
PD591406	SHIELD CATALYST	Bajaj spare parts
PD591418	SILENCER ASSEMBLY	Bajaj spare parts
PD591430	SHIELD CATALYST	Bajaj spare parts
PD591432	SILENCER ASSEMBLY	Bajaj spare parts
PD591464	ASSEMBLY PIPE A	Bajaj spare parts
PD591492	MUFFLER ASSEMBLY	Bajaj spare parts
PD591494	GROMMET	Bajaj spare parts
PD591509	SILENCER ASSEMBLY	Bajaj spare parts
PD591525	SHIELD	Bajaj spare parts
PD591536	PIPE ASSEMBLY A	Bajaj spare parts
PD591553	MUFFLER ASSEMBLY SECONDARY	Bajaj spare parts
PD591608	SHIELD	Bajaj spare parts
PD591625	SILENCER ASSEMBLY	Bajaj spare parts
PD591630	SHIELD MUFFLER	Bajaj spare parts
PD591652	SILENCER ASSEMBLY	Bajaj spare parts
PD611002	INJECTOR	Bajaj spare parts
PD611006	CAP INJECTOR	Bajaj spare parts
PD611007	INJECTOR	Bajaj spare parts
PD611200	BODY THROTTLE ASSEMBLY	Bajaj spare parts
PD611201	BODY THROTTLE ASSEMBLY	Bajaj spare parts
PD611205	BODY THROTTLE ASSEMBLY	Bajaj spare parts
PD611207	BODY THROTTLE ASSEMBLY	Bajaj spare parts
PD611208	BODY THROTTLE ASSEMBLY	Bajaj spare parts
PD611209	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
PD611210	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
PD611211	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
PD611212	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
PD611219	MOTOR STEPPER	Bajaj spare parts
PD611220	BODY THROTTLE ASSEMBLY	Bajaj spare parts
PD611222	CAP INJECTOR-CONNECTOR QUICK	Bajaj spare parts
PD611224	BODY THROTTLE ASSEMBLY	Bajaj spare parts
PD621003	GUIDE KICK	Bajaj spare parts
PD621008	SHAFT KICK	Bajaj spare parts



PD621009	GEAR ASSEMBLY PINION KICK	Bajaj spare parts
PD621012	RATCHET KICK STARTER	Bajaj spare parts
PD621020	SLEEVE	Bajaj spare parts
PD621200	LEVER ASSEMBLY KICK	Bajaj spare parts
PD621202	BOSS LEVER KICK	Bajaj spare parts
PD621203	GEAR ASSEMBLY CLUTCH STARTER	Bajaj spare parts
PD621412	BUSH	Bajaj spare parts
PD621417	GEAR ASSEMBLY STARTER CLUTCH	Bajaj spare parts
PD621420	SHAFT GEAR STARTER COUNTER-2	Bajaj spare parts
PD621422	SHAFT STARTER COUNTER 1	Bajaj spare parts
PD621425	COLLAR STARTER COUNTER	Bajaj spare parts
PD710123	TNAK FUEL PRIMERED AV	Bajaj spare parts
PF111000	FRAME ASSEMBLY	Bajaj spare parts
PF111060	FRAME ASSY B104-D	Bajaj spare parts
PF111069	STARTER RELAY MTG BRACKET	Bajaj spare parts
PF111092	CAP FOR TUBE END	Bajaj spare parts
PF111096	CAP FOR TUBE END	Bajaj spare parts
PF111101	FRAME ASSLY	Bajaj spare parts
PF111103	FRAME ASSLY	Bajaj spare parts
PF111114	FOAM 20X20X4	Bajaj spare parts
PF111115	FRAME ASSEMBLY	Bajaj spare parts
PF111163	PAD ECU	Bajaj spare parts
PF111165	FRAME ASSEMBLY	Bajaj spare parts
PF113000	STAY - MAIN STEP LH	Bajaj spare parts
PF113001	STAY - MAIN STEP RH	Bajaj spare parts
PF113002	STAY LH	Bajaj spare parts
PF113003	STAY RH	Bajaj spare parts
PF113005	STAY -MAIN STEP ASSY RH	Bajaj spare parts
PF113006	STAY ASSY LH	Bajaj spare parts
PF113008	FOOTREST THIRD LH	Bajaj spare parts
PF113009	FOOTREST THIRD RH	Bajaj spare parts
PF113010	STAY MAIN STEP RH	Bajaj spare parts
PF113012	STAY MAIN STEP ASSY LH	Bajaj spare parts
PF113013	STAY-MAIN STEP ASSY RH	Bajaj spare parts
PF113014	STAY ASSY PILLION LH	Bajaj spare parts
PF113016	STAY ASSY PILLION RH	Bajaj spare parts
PF113022	COVER FOR SIDE STAND SWITCH	Bajaj spare parts
PF113023	FOOTREST PILLION ASSY LH	Bajaj spare parts
PF113024	FOOTREST PILLION ASSY RH	Bajaj spare parts
PF113028	DAMPER RIDER FOOTREST	Bajaj spare parts
PF113032	FOOTREST PILLION LH	Bajaj spare parts
PF113033	FOOTREST PILLION RH	Bajaj spare parts
PF113036	PIN PILLION FOOTREST	Bajaj spare parts
PF113037	STAY PILLION LH	Bajaj spare parts
PF113038	STAY PILLION RH	Bajaj spare parts

PF113046	DAMPER HINGE 1	Bajaj spare parts
PF113047	DAMPER HINGE 2	Bajaj spare parts
PF113058	HOLDER STEP PILLION LH	Bajaj spare parts
PF113059	HOLDER STEP PILLION RH	Bajaj spare parts
PF113060	STEP PILLION LH	Bajaj spare parts
PF113061	STEP PILLION RH	Bajaj spare parts
PF113063	HOLDER ASSEMBLY STEP PILLION RH	Bajaj spare parts
PF113064	ASSEMBLY STEP RIDER RH	Bajaj spare parts
PF113065	STEP ASSEMBLY RIDER RH	Bajaj spare parts
PF113066	HOLDER STEP PILLION LH	Bajaj spare parts
PF113068	HOLDER STEP PILLION RH	Bajaj spare parts
PF113200	STAND CENTER	Bajaj spare parts
PF113203	STAND CENTER	Bajaj spare parts
PF113205	SIDE STAND	Bajaj spare parts
PF113206	STAND CENTER	Bajaj spare parts
PF113224	STAND CENTER	Bajaj spare parts
PF113225	STAND CENTER	Bajaj spare parts
PF113400	BRACKET ENG HANGER LH	Bajaj spare parts
PF113401	BRACKET ENG HANGER RH	Bajaj spare parts
PF113402	BRACKET ENGINE HANGER	Bajaj spare parts
PF113403	BRACKET ENGINE HANGER	Bajaj spare parts
PF113801	COLLAR	Bajaj spare parts
PF113803	BRACKET BOX FUSE	Bajaj spare parts
PF121001	FORK ASSY (FOR 100)	Bajaj spare parts
PF121002	LAMP SHADE LH	Bajaj spare parts
PF121003	LAMP SHADE RH	Bajaj spare parts
PF121010	FORK PIPE SPINNING	Bajaj spare parts
PF121015	COVER FORK LH	Bajaj spare parts
PF121016	COVER FORK RH	Bajaj spare parts
PF121017	PIPE FORK INNER	Bajaj spare parts
PF121018	PIPE LEFT FORK OUTER	Bajaj spare parts
PF121019	PIPE RIGHT FORK OUTER	Bajaj spare parts
PF121024	LAMP SHADE ASSY	Bajaj spare parts
PF121025	STRUCTURE FAIRING	Bajaj spare parts
PF121026	FORK FRONT	Bajaj spare parts
PF121028	DAMPER COVER FORK	Bajaj spare parts
PF121035	FORK FRONT (FOR DISC BRAKE)	Bajaj spare parts
PF121043	ASSLY FORK FRONT	Bajaj spare parts
PF121054	CLAMP FOR BELLOW	Bajaj spare parts
PF121057	OUTER PIPE LH	Bajaj spare parts
PF121064	OUTER PIPE RH	Bajaj spare parts
PF121073	SEAL OIL	Bajaj spare parts
PF121074	SPRING INNER	Bajaj spare parts
PF121075	FRONT FORK ASSY	Bajaj spare parts
PF121076	ASSLY UNDER BRACKET COMP	Bajaj spare parts

PF121078	ASSLY HOLDER FORK UPPER	Bajaj spare parts
PF121079	BRACKET HOLDER FORK UPPER	Bajaj spare parts
PF121080	FORK ASSY	Bajaj spare parts
PF121082	SEAT PIPE	Bajaj spare parts
PF121083	BELLOW FRONT FORK	Bajaj spare parts
PF121085	HOLDER ASSY FORK	Bajaj spare parts
PF121086	OUTER TUBE LH	Bajaj spare parts
PF121088	FORK ASSY- 130 DRUM B104E	Bajaj spare parts
PF121089	ASSLY HOLDER FORK UPPER	Bajaj spare parts
PF121090	OUTER TUBE RH	Bajaj spare parts
PF121097	SPRING MAIN	Bajaj spare parts
PF121099	ASSEMBLY LEG ASSY LH	Bajaj spare parts
PF121100	ASSEMBLY LEG ASSY RH	Bajaj spare parts
PF121101	TUBE INNER	Bajaj spare parts
PF121102	ASSLY HOLDER FORK UPPER	Bajaj spare parts
PF121115	FORK FRONT	Bajaj spare parts
PF121118	FORK FRONT	Bajaj spare parts
PF121119	FORK FRONT	Bajaj spare parts
PF121133	BRACKET ASSEMBLY-CLAMP HOSE	Bajaj spare parts
PF122004	SHOCKABSORBER REAR-SNS	Bajaj spare parts
PF122005	SHOCKABSORBER REAR	Bajaj spare parts
PF122006	ARM SWING W/O BKTS BM 150	Bajaj spare parts
PF122012	SHOCKABSORBER REAR	Bajaj spare parts
PF122014	ARM SWING	Bajaj spare parts
PF122016	ADJUSTER CHAIN RH	Bajaj spare parts
PF122019	ROD TORQUE	Bajaj spare parts
PF122025	SHOCKABSORBER REAR	Bajaj spare parts
PF122027	ARM SWING	Bajaj spare parts
PF122028	SHOCKABSORBER REAR	Bajaj spare parts
PF122030	ARM ASSLY-SWING	Bajaj spare parts
PF122033	SHOCKABSORBER REAR SNS	Bajaj spare parts
PF131012	WHEEL FRONT	Bajaj spare parts
PF131208	AXLE REAR (DIA.15)	Bajaj spare parts
PF131213	COUPLING ASSY	Bajaj spare parts
PF131220	WASHER LOCK FOR NUT A/	Bajaj spare parts
PF131222	WHEEL RE	Bajaj spare parts
PF131225	SLEEVE	Bajaj spare parts
PF131227	SPACER PANEL SIDE	Bajaj spare parts
PF131228	COLLAR ASSY	Bajaj spare parts
PF131235	AXLE REAR DIA 12	Bajaj spare parts
PF131236	SLEEVE COUPLING	Bajaj spare parts
PF131237	SPACER PANEL	Bajaj spare parts
PF131239	COUPLING 4 LUG	Bajaj spare parts
PF131245	AXLE REAR-DIA 15	Bajaj spare parts
PF131612	CASE ASSEMBLY - METER GEAR	Bajaj spare parts

PF131616	PANEL BRAKE FRONT	Bajaj spare parts
PF131823	BRAKE SYSTEM FRONT	Bajaj spare parts
PF131825	BRAKE SYSTEM FRONT	Bajaj spare parts
PF131826	LEVER CAM BRAKE REAR	Bajaj spare parts
PF151000	HANDLE BAR BOXER 150	Bajaj spare parts
PF151015	HANDLE BAR	Bajaj spare parts
PF151032	GRIP ASSEMBLY RH	Bajaj spare parts
PF161001	ROD BRAKE	Bajaj spare parts
PF161002	PEADL BRAKE	Bajaj spare parts
PF161005	HAND GRIP LH	Bajaj spare parts
PF161006	BRAKE ROD	Bajaj spare parts
PF161007	GRIP ASSY RH	Bajaj spare parts
PF161009	ASSLY LEVER HOLDER LH	Bajaj spare parts
PF161010	HOLDER LEVER LH	Bajaj spare parts
PF161011	ASSEMBLY LEVER HOLDER RH	Bajaj spare parts
PF161012	HOLDER LEVER RH	Bajaj spare parts
PF161014	ASSLY LEVER HOLDER LH WITH ADJUT	Bajaj spare parts
PF161015	LEVER CLUTCH	Bajaj spare parts
PF161016	ASSLY LEVER HOLDER LH - KS	Bajaj spare parts
PF161018	ASSLY LEVER HOLDER LH - KS	Bajaj spare parts
PF161019	ROD BRAKE	Bajaj spare parts
PF161020	ASSEMBLY PEDAL BRAKE	Bajaj spare parts
PF161029	LEVER DISTRIBUTOR LH	Bajaj spare parts
PF161030	LEVER DISTRIBUTOR RH	Bajaj spare parts
PF161031	COVER UNIT DISTRIBUTOR LH	Bajaj spare parts
PF161032	COVER UNIT DISTRIBUTOR RH	Bajaj spare parts
PF161033	GROMMET	Bajaj spare parts
PF161036	ASSEMBLY LEVER-HOLDER LH	Bajaj spare parts
PF161201	CABLE THROTTLE	Bajaj spare parts
PF161202	CABLE BRAKE	Bajaj spare parts
PF161208	CABLE - SPEEDO METER	Bajaj spare parts
PF161209	CABLE -SPEEDO INNER	Bajaj spare parts
PF161211	CABLE THROTTLE	Bajaj spare parts
PF161212	CABLE CLUTCH	Bajaj spare parts
PF161213	CABLE BRAKE	Bajaj spare parts
PF161217	CABLE THROTTLE	Bajaj spare parts
PF161218	CABLE THROTTLE	Bajaj spare parts
PF161219	CABLE CLUTCH	Bajaj spare parts
PF161220	CABLE BRAKE	Bajaj spare parts
PF161226	CABLE CLUTCH	Bajaj spare parts
PF161227	CABLE BRAKE	Bajaj spare parts
PF161228	CABLE BRAKE - WITHOUT ADJUSTER	Bajaj spare parts
PF161231	CABLE THROTTLE	Bajaj spare parts
PF161232	CABLE PEDAL-UNIT DISTRIBUTOR	Bajaj spare parts
PF161233	CABLE UNIT DISTRIBUTOR-PANEL FR	Bajaj spare parts

PF161234	CABLE BRAKE FRONT	Bajaj spare parts
PF161236	CABLE THROTTLE	Bajaj spare parts
PF161237	CABLE THROTTLE	Bajaj spare parts
PF171005	SEAT LAB	Bajaj spare parts
PF171006	SEATLAB DOWN	Bajaj spare parts
PF171030	CANISTER SENTEC 309016	Bajaj spare parts
PF171032	TUBE TANK TO INLINE CONNECTOR	Bajaj spare parts
PF171033	TUBE INLINE TO T CONNECTOR	Bajaj spare parts
PF171034	TUBE T CONNECTOR TO CANISTER	Bajaj spare parts
PF171035	TUNE INLINE TO PURGE VALVE	Bajaj spare parts
PF171036	TUBE PURGE VALVE TO CARBUERATTOR	Bajaj spare parts
PF171037	TUBE DRAIN	Bajaj spare parts
PF171053	TUBE T TO DRAIN	Bajaj spare parts
PF171062	TUBE BREATHER CANISTER CONNECTOR	Bajaj spare parts
PF171063	TUBE BREATHER CANISTER	Bajaj spare parts
PF171075	PIPE FUEL	Bajaj spare parts
PF171076	PIPE FUEL	Bajaj spare parts
PF171601	CAP FUEL TANK BS4	Bajaj spare parts
PF171800	TAP FUEL	Bajaj spare parts
PF171802	TAP FUEL	Bajaj spare parts
PF171803	PIPE FUEL- E10 (L185)	Bajaj spare parts
PF181200	CASE CHAIN LOWER ASSY	Bajaj spare parts
PF181202	CASE CHAIN UPPER ASSY	Bajaj spare parts
PF181208	COWLING	Bajaj spare parts
PF181209	WINDSHIELD	Bajaj spare parts
PF181211	GROMMET COWLING MTG	Bajaj spare parts
PF181214	FLAP SPEEDOMETER	Bajaj spare parts
PF181217	CASE CHAIN UPPER	Bajaj spare parts
PF181218	CHAIN CASE LOWER	Bajaj spare parts
PF181219	RUBBER CAP	Bajaj spare parts
PF181221	ASSY CASE BATTERY	Bajaj spare parts
PF181222	FOAM SEAT COWL	Bajaj spare parts
PF181228	FAIRING	Bajaj spare parts
PF181230	COVER SIDE LHCOVER SIDE LH	Bajaj spare parts
PF181231	COVER SIDE RH	Bajaj spare parts
PF181232	ASSLY COWL SEAT	Bajaj spare parts
PF181236	BKT.FAIRING STRUCTURE LH	Bajaj spare parts
PF181237	FAIRING/INDIC MTG STRUC	Bajaj spare parts
PF181238	BKT. FAIRING LOWER PIVOT	Bajaj spare parts
PF181239	BRACKET FORK SIDE	Bajaj spare parts
PF181246	FOAM TAPE	Bajaj spare parts
PF181248	FOAM TAPE	Bajaj spare parts
PF181259	COVER LINK CBS	Bajaj spare parts
PF181261	CASE ASSEMBLY BATTERY	Bajaj spare parts
PF181264	BRACKET FAIRING LOWER	Bajaj spare parts

PF181404	FENDER ASSY FRONT	Bajaj spare parts
PF181408	MUDFLAP FRONT	Bajaj spare parts
PF181415	FLAP FENDER REAR	Bajaj spare parts
PF181416	COLLAR	Bajaj spare parts
PF181420	FENDER FRONT	Bajaj spare parts
PF181422	FENDER REAR REAR	Bajaj spare parts
PF181423	BRACE FENDER FRONT	Bajaj spare parts
PF181424	FENDER REAR FRONT	Bajaj spare parts
PF181429	FENDER REAR FRONT- CANISTER	Bajaj spare parts
PF181430	FRONT FENDER FRONT	Bajaj spare parts
PF181432	FRONT FENDER REAR	Bajaj spare parts
PF181433	BRACE FRONT FENDER REAR	Bajaj spare parts
PF181435	FENDER REAR	Bajaj spare parts
PF181440	PLUG	Bajaj spare parts
PF181442	FENDER REAR	Bajaj spare parts
PF181443	BRACKET ECU	Bajaj spare parts
PF191000	SEAT ASSY COMP.	Bajaj spare parts
PF191011	ASSLY SEAT	Bajaj spare parts
PF231200	GUARD SARI	Bajaj spare parts
PF231201	GUARD LEG	Bajaj spare parts
PF231204	GUARD SARI	Bajaj spare parts
PF231205	PAD SARI GUARD	Bajaj spare parts
PF231208	GUARD SARI	Bajaj spare parts
PF231401	BRACKET TAIL LAMP	Bajaj spare parts
PF231405	GRIP FRAME (EXPORT)	Bajaj spare parts
PF231410	BRACKET TAIL LAMP	Bajaj spare parts
PF231413	GRAB (DIE CAST)	Bajaj spare parts
PF231600	MIRROR ASSY LH	Bajaj spare parts
PF231601	MIRROR ASSY RH	Bajaj spare parts
PF232601	LOCK KIT (3 IN 1)	Bajaj spare parts
PF232603	LOCK KIT	Bajaj spare parts
PF232604	LOCK KIT	Bajaj spare parts
PF232605	LOCK KIT	Bajaj spare parts
PF232606	LOCK SET	Bajaj spare parts
PF232809	BRACKET PLATE NUMBER FRONT	Bajaj spare parts
PF233027	FAIRING DECAL LH CANDY RED	Bajaj spare parts
PF233028	FAIRING DECAL RH CANDY RED	Bajaj spare parts
PF233029	FAIRING DECAL LH EL BLUE	Bajaj spare parts
PF233030	FAIRING DECAL RH EL BLUE	Bajaj spare parts
PF233031	FAIRING DECAL LH EBONY BLACK	Bajaj spare parts
PF233032	FAIRING DECAL RH EBONY BLACK	Bajaj spare parts
PF233033	TANK DECAL LH CANDY RED	Bajaj spare parts
PF233034	TANK DECAL RH CANDY RED	Bajaj spare parts
PF233035	TANK DECAL LH EL BLUE	Bajaj spare parts
PF233036	TANK DECAL RH EL BLUE	Bajaj spare parts

PF233037	TANK DECAL LH EBONY BLACK	Bajaj spare parts
PF233038	TANK DECAL RH EBONY BLACK	Bajaj spare parts
PF233039	COVER SIDE DECAL LH CANDY RED	Bajaj spare parts
PF233042	COVER SIDE DECAL RH EL BLUE	Bajaj spare parts
PF233043	COVER SIDE DECAL LH EBONY BLACK	Bajaj spare parts
PF233045	COWL SEAT UP DECAL LH CANDY RED	Bajaj spare parts
PF233046	COWL SEAT UP DECAL RH CANDY RED	Bajaj spare parts
PF233047	COWL SEAT LR DECAL LH CANDY RED	Bajaj spare parts
PF233048	COWL SEAT LR DECAL RH CANDY RED	Bajaj spare parts
PF233049	COWL SEAT UP DECAL LH EL BLUE	Bajaj spare parts
PF233050	COWL SEAT UP DECAL RH EL BLUE	Bajaj spare parts
PF233051	COWL SEAT LR DECAL LH EL BLUE	Bajaj spare parts
PF233052	COWL SEAT LR DECAL RH EL BLUE	Bajaj spare parts
PF233053	COWL SEAT UP DECAL LH EBN BLACK	Bajaj spare parts
PF233054	COWL SEAT UP DECAL RH EBN BLACK	Bajaj spare parts
PF233055	COWL SEAT LR DECAL LH EBN BLACK	Bajaj spare parts
PF233056	COWL SEAT LR DECAL RH EBN BLACK	Bajaj spare parts
PF233109	LABEL B MONOGRAM - CANDY RED	Bajaj spare parts
PF233110	LABEL B MONOGRAM - ELECTRON BLUE	Bajaj spare parts
PF233111	LABEL B MONOGRAM - EBONY BLACK	Bajaj spare parts
PF233127	LABEL B MONOGRAM - FLAME RED	Bajaj spare parts
PF233144	PLATE OTTC NO	Bajaj spare parts
PF233145	LABEL EAC	Bajaj spare parts
PF233176	DECAL FRONT FORK	Bajaj spare parts
PF233212	DECAL COVER LH ELETRON BLUE	Bajaj spare parts
PF233213	DECAL COVER RH ELETRON BLUE	Bajaj spare parts
PF233214	DECAL COVER LH EBONY BLACK	Bajaj spare parts
PF233215	DECAL COVER RH EBONY BLACK	Bajaj spare parts
PF233216	DECAL COVER LH COCKTAIL W RED	Bajaj spare parts
PF233217	DECAL COVER RH COCKTAIL W RED	Bajaj spare parts
PF233239	DECAL COVER SIDE LH EBONY BLACK	Bajaj spare parts
PF233240	DECAL COVER SIDE RH EBONY BLACK	Bajaj spare parts
PF233252	DECAL COVER MAGNETO	Bajaj spare parts
PF233253	DECAL COVER CLUTCH	Bajaj spare parts
PF233283	DECAL COVER SIDE LH ARTIC WHITE	Bajaj spare parts
PF233284	DECAL COVER SIDE RH ARTIC WHITE	Bajaj spare parts
PF233338	DECAL COVER LH EBONY BLACK M RED	Bajaj spare parts
PF233339	DECAL COVER RH EBONY BLACK M RED	Bajaj spare parts
PF233348	DECAL COVER EBONY BLACK BRASS LH	Bajaj spare parts
PF233349	DECAL COVER EBONY BLACK BRASS RH	Bajaj spare parts
PF233358	DECAL COVER EBONY BLACK BLUE LH	Bajaj spare parts
PF233359	DECAL COVER EBONY BLACK BLUE RH	Bajaj spare parts
PF233364	DECAL COVER CLUTCH	Bajaj spare parts
PF233365	DECAL COVER MAGNETO	Bajaj spare parts
PF351001	MAGNETO ASSLY(BM150)	Bajaj spare parts

PF351003	ROTOR ASSLY	Bajaj spare parts
PF351004	STATOR ASSLY	Bajaj spare parts
PF351006	STATOR ASSLY BM100	Bajaj spare parts
PF351007	ROTOR ASSLY BM100 KS	Bajaj spare parts
PF351012	ASSLY ROTOR WITH CLUTCH B104D	Bajaj spare parts
PF351013	ASSLY ROTOR WO CLUTCH B104D	Bajaj spare parts
PF351015	ASSLY ROTOR B104D KS	Bajaj spare parts
PF351017	ASSLY STATOR B104D	Bajaj spare parts
PF351024	ASSLY STATOR B104E	Bajaj spare parts
PF351025	ASSLY ROTOR WO CLUTCH B104E	Bajaj spare parts
PF351028	Assly Rotor	Bajaj spare parts
PF351033	ASSEMBLY STATOR B104E KS	Bajaj spare parts
PF351038	ASSLY ROTOR WO CLUTCH B103A	Bajaj spare parts
PF351042	ROTOR ASSLY WITHOUT CLUTCH	Bajaj spare parts
PF351046	ROTOR ASSLY	Bajaj spare parts
PF351054	STATOR ASSEMBLY	Bajaj spare parts
PF351056	STATOR ASSEMBLY	Bajaj spare parts
PF351059	ROTOR ASSEMBLY	Bajaj spare parts
PF351069	STATOR ASSEMBLY	Bajaj spare parts
PF351085	ROTOR ASSEMBLY	Bajaj spare parts
PF351087	STATOR ASSEMBLY	Bajaj spare parts
PF351200	CDI AC STEP UP BM100	Bajaj spare parts
PF351201	CDI SEALED COUPLER	Bajaj spare parts
PF351206	CDI B104D	Bajaj spare parts
PF351217	COIL H T 1 B104D	Bajaj spare parts
PF351219	COIL H T 2 B104D	Bajaj spare parts
PF351220	CDI B104E	Bajaj spare parts
PF351224	CDI B108B	Bajaj spare parts
PF351231	CDI	Bajaj spare parts
PF351238	CDI	Bajaj spare parts
PF351240	CDI	Bajaj spare parts
PF351242	CDI	Bajaj spare parts
PF351243	CDI	Bajaj spare parts
PF351244	CDI	Bajaj spare parts
PF351246	CDI	Bajaj spare parts
PF351247	COIL ASSEMBLY IGNITION RH	Bajaj spare parts
PF351248	CDI	Bajaj spare parts
PF351253	CDI	Bajaj spare parts
PF351410	ECU EMS ASSEMBLY	Bajaj spare parts
PF351413	ECU EMS ASSEMBLY	Bajaj spare parts
PF351420	ECU EMS ASSEMBLY	Bajaj spare parts
PF351423	ECU EMS ASSEMBLY	Bajaj spare parts
PF351426	ECU EMS ASSEMBLY	Bajaj spare parts
PF351430	ECU EMS ASSEMBLY	Bajaj spare parts
PF351438	ECU EMS ASSEMBLY	Bajaj spare parts



PF351441	ECU EMS ASSEMBLY	Bajaj spare parts
PF351478	ECU EMS ASSEMBLY	Bajaj spare parts
PF351486	ECU EMS ASSEMBLY	Bajaj spare parts
PF351496	ECU EMS ASSEMBLY	Bajaj spare parts
PF351500	ECU EMS ASSEMBLY	Bajaj spare parts
PF351504	ECU EMS ASSEMBLY	Bajaj spare parts
PF351512	ECU EMS ASSEMBLY	Bajaj spare parts
PF351525	ECU EMS ASSEMBLY	Bajaj spare parts
PF351529	ECU EMS ASSEMBLY	Bajaj spare parts
PF351533	ECU EMS ASSEMBLY	Bajaj spare parts
PF351539	ECU EMS ASSEMBLY	Bajaj spare parts
PF351547	ECU EMS ASSEMBLY	Bajaj spare parts
PF351554	ECU EMS ASSEMBLY	Bajaj spare parts
PF351562	ECU EMS ASSEMBLY	Bajaj spare parts
PF351567	ECU EMS ASSEMBLY	Bajaj spare parts
PF351579	ECU EMS ASSEMBLY	Bajaj spare parts
PF351600	MOTOR STARTER	Bajaj spare parts
PF351601	STARTER MOTOR B104D	Bajaj spare parts
PF351602	MOTOR ASSLY STARTER	Bajaj spare parts
PF351800	SENSOR INDICATOR GEAR	Bajaj spare parts
PF401000	HEAD LIGHT ASSY/ LMP	Bajaj spare parts
PF401001	ASSLY DIR IND FR-L/LMP	Bajaj spare parts
PF401002	ASSLY DIR IND FR-R/LMP	Bajaj spare parts
PF401003	ASSLY DIR IND RR-L/LMP	Bajaj spare parts
PF401004	ASSLY DIR IND RR-R/LMP	Bajaj spare parts
PF401005	TAIL LIGHT ASSY	Bajaj spare parts
PF401007	HEAD LIGHT ASSY W/O BULB	Bajaj spare parts
PF401016	HEAD LIGHT ASSY	Bajaj spare parts
PF401018	HEAD LAMP ASSLY	Bajaj spare parts
PF401402	SWITCH CONTROL ASSY RH	Bajaj spare parts
PF401403	SPRING BRAKE SWITCH	Bajaj spare parts
PF401404	BRAKE SWITCH ASSY RR	Bajaj spare parts
PF401417	SWITCH CONTROL RH (SS)	Bajaj spare parts
PF401418	SWITCH SIDE STAND	Bajaj spare parts
PF401419	CONTROL UNIT FOR SIDE STAND	Bajaj spare parts
PF401420	CONTROL UNIT FOR SIDE STAND SWITCH	Bajaj spare parts
PF401426	SWITCH SIDE STAND	Bajaj spare parts
PF401801	CLAMP BATTERY CABLE	Bajaj spare parts
PF401805	3AH VRLA DRY BATTERY WITH ACID BOTTLE	Bajaj spare parts
PF401806	3AH VRLA DRY BATTERY ( WITHOUT ACID BOTT	Bajaj spare parts
PF401810	FOAM BATTERY	Bajaj spare parts
PF401811	FOAM BATTERY	Bajaj spare parts
PF401812	BAND BATTERY	Bajaj spare parts
PF401813	ACID BOTTLE FOR 3AH VRLA DRY BATTERY	Bajaj spare parts
PF401814	PIPE DRAIN FOR BATTERY	Bajaj spare parts

PF401819	ASSLY CASE BATTERY	Bajaj spare parts
PF401820	FOAM BATTERY	Bajaj spare parts
PF402000	REGULATOR RECTIFIER UNIT	Bajaj spare parts
PF402001	REGULATOR - DC	Bajaj spare parts
PF402200	HARNESS WIRING	Bajaj spare parts
PF402201	HARNESS WIRING	Bajaj spare parts
PF402204	HARNESS WIRING (BM100 KS)	Bajaj spare parts
PF402207	CABLE STARTER RELAY TO MOTOR	Bajaj spare parts
PF402208	CABLE BATTERY TO EARTH	Bajaj spare parts
PF402209	HARNESS WIRING FOR IRAN EXPORT	Bajaj spare parts
PF402210	BOOT	Bajaj spare parts
PF402213	HARNESS WIRING BM150 SS	Bajaj spare parts
PF402217	HARNESS WIRING	Bajaj spare parts
PF402218	HARNESS WIRING (KS)	Bajaj spare parts
PF402220	HARNESS WIRING	Bajaj spare parts
PF402223	CABLE EARTH	Bajaj spare parts
PF402224	CABLE RELAY TO MOTOR	Bajaj spare parts
PF402226	HARNESS WIRING-SS	Bajaj spare parts
PF402228	HARNESS WIRING -SS	Bajaj spare parts
PF402229	HARNESS WIRING ES	Bajaj spare parts
PF402230	HARNESS WIRING	Bajaj spare parts
PF402231	HARNESS WIRING KS	Bajaj spare parts
PF402236	HARNESS WIRING - EURO III	Bajaj spare parts
PF402237	HARNESS WIRING - B104E AHO	Bajaj spare parts
PF402238	CABLE ASSY ST RELAY TO MOTOR	Bajaj spare parts
PF402239	CABLE ASSY BATTERY TO EARTH	Bajaj spare parts
PF402244	HARNESS WIRING	Bajaj spare parts
PF402247	CAP BATTERY POSITIVE	Bajaj spare parts
PF402254	HARNESS WIRING	Bajaj spare parts
PF402256	HARNESS WIRING	Bajaj spare parts
PF402257	HARNESS WIRING	Bajaj spare parts
PF402260	HARNESS WIRING	Bajaj spare parts
PF402263	HARNESS WIRING	Bajaj spare parts
PF402265	HARNESS WIRING	Bajaj spare parts
PF402267	HARNESS WIRING	Bajaj spare parts
PF402276	HARNESS WIRING	Bajaj spare parts
PF402283	HARNESS WIRING	Bajaj spare parts
PF402400	INSTRU CLUSTER BOXER150	Bajaj spare parts
PF402401	MACHINE SPEEDOMETER WITH DIAL	Bajaj spare parts
PF402402	COVER TOP SPEEDOMETER	Bajaj spare parts
PF402403	HARNESS WIRING SPEEDOMETER	Bajaj spare parts
PF402404	BKT MTG SPEEDOMETER	Bajaj spare parts
PF402406	SPEEDOMETER BOTTOM COVER	Bajaj spare parts
PF402412	SPEEDOMETER ASSY	Bajaj spare parts
PF402413	SPEEDOMETER ASSLY	Bajaj spare parts

PF402416	SPEEDOMETER	Bajaj spare parts
PF402417	SPEEDOMETER	Bajaj spare parts
PF402600	SENSOR - FUEL LEVEL	Bajaj spare parts
PF403400	CHARGER MOBILE	Bajaj spare parts
PF501004	ENGINE ASSEMBLY SS BOXER150	Bajaj spare parts
PF501037	ENGINE ASSLY B104D	Bajaj spare parts
PF501045	ASSLY ENGINE B104E ES SAI	Bajaj spare parts
PF501056	ASSEMBLY ENGINE B104E KS SAI	Bajaj spare parts
PF501066	ASSLY ENGINE B108B	Bajaj spare parts
PF501071	ASSLY ENGINE B104E KS PLATINUM SILVER	Bajaj spare parts
PF501074	ENGINE ASSLY	Bajaj spare parts
PF501076	ENGINE ASSLY	Bajaj spare parts
PF501080	ENGINE ASSLY	Bajaj spare parts
PF501089	ENGINE ASSLY	Bajaj spare parts
PF501096	ENGINE ASSEMBLY	Bajaj spare parts
PF501118	ENGINE ASSEMBLY	Bajaj spare parts
PF501124	ENGINE ASSEMBLY	Bajaj spare parts
PF501128	ENGINE ASSEMBLY	Bajaj spare parts
PF501132	ENGINE ASSEMBLY	Bajaj spare parts
PF501139	ENGINE ASSEMBLY	Bajaj spare parts
PF501141	ENGINE ASSEMBLY	Bajaj spare parts
PF501144	ENGINE ASSEMBLY	Bajaj spare parts
PF501147	ENGINE ASSEMBLY	Bajaj spare parts
PF501150	ENGINE ASSEMBLY	Bajaj spare parts
PF501152	ENGINE ASSEMBLY	Bajaj spare parts
PF501251	ENGINE ASSEMBLY	Bajaj spare parts
PF501254	ENGINE ASSEMBLY	Bajaj spare parts
PF511021	BOLT HEAD M8*144.5	Bajaj spare parts
PF511061	SLEEVE SPARK PLUG B104D	Bajaj spare parts
PF511111	GASKET HEAD CYLINDER	Bajaj spare parts
PF511114	HEAD CYLINDER MACHINED	Bajaj spare parts
PF511133	HEAD CYLINDER	Bajaj spare parts
PF511135	HEAD CYLINDER	Bajaj spare parts
PF511170	HEAD CYLINDER	Bajaj spare parts
PF511191	HEAD CYLINDER	Bajaj spare parts
PF511200	ASSLY CAM SHAFT	Bajaj spare parts
PF511203	SPROCKET CAM B104D	Bajaj spare parts
PF511209	ASSLY CAMSHAFT B104D	Bajaj spare parts
PF511210	ASSEMBLY CAMSHAFT B104E	Bajaj spare parts
PF511212	VALVE INTAKE	Bajaj spare parts
PF511213	VALVE EXHAUST	Bajaj spare parts
PF511222	CAMSHAFT ASSEMBLY	Bajaj spare parts
PF511255	CAMSHAFT ASSEMBLY	Bajaj spare parts
PF511257	CHAIN	Bajaj spare parts
PF511258	SPROCKET CAMSHAFT	Bajaj spare parts

PF511266	CAMSHAFT ASSEMBLY	Bajaj spare parts
PF511521	HEAD CYLINDER	Bajaj spare parts
PF511524	HEAD CYLINDER	Bajaj spare parts
PF521007	ASSLY CYLINDER BLOCK	Bajaj spare parts
PF521014	GASKET CYLINDER BLOCK	Bajaj spare parts
PF521029	BLOCK CYLINDER	Bajaj spare parts
PF521030	GASKET BLOCK CYLINDER	Bajaj spare parts
PF521200	ASSEMBLY PISTON	Bajaj spare parts
PF521205	PISTON ASSLY (BM150)	Bajaj spare parts
PF521210	ASSLY PISTON B104D	Bajaj spare parts
PF521235	CIRCLIP PISTON	Bajaj spare parts
PF531000	CRANKSHAFT ASSY BOXER150	Bajaj spare parts
PF531002	ASSLY CRANKSHAFT BM100 4 SPD	Bajaj spare parts
PF531011	ASSLY CRANKSHAFT B104D	Bajaj spare parts
PF531023	CRANKSHAFT ASSLY	Bajaj spare parts
PF531027	SPROCKET CRANKSHAFT	Bajaj spare parts
PF531031	CRANKSHAFT ASSEMBLY	Bajaj spare parts
PF531033	CRANKSHAFT ASSEMBLY	Bajaj spare parts
PF531039	CRANKSHAFT ASSEMBLY	Bajaj spare parts
PF531044	BEARING NEEDLE	Bajaj spare parts
PF531057	SPROCKET CRANKSHAFT	Bajaj spare parts
PF531061	CRANKSHAFT ASSEMBLY	Bajaj spare parts
PF531063	CRANKSHAFT ASSEMBLY	Bajaj spare parts
PF531066	CRANKSHAFT ASSEMBLY	Bajaj spare parts
PF531068	CRANKSHAFT ASSEMBLY	Bajaj spare parts
PF541018	BUSHING DRUM	Bajaj spare parts
PF541029	ASSLY CRANKCASE LH B104D	Bajaj spare parts
PF541042	ASSLY CRANKCASE LH KS B104D	Bajaj spare parts
PF541043	DAMPER CRANKSHAFT	Bajaj spare parts
PF541071	CRANKCASE ASSLY LH	Bajaj spare parts
PF541073	CRANKCASE ASSLY RH	Bajaj spare parts
PF541083	CRANKCASE ASSLY LH	Bajaj spare parts
PF541084	CRANKCASE LH	Bajaj spare parts
PF541109	CRANKCASE LH	Bajaj spare parts
PF541115	CRANKCASE ASSEMBLY LH	Bajaj spare parts
PF541208	COVER CLUTCH COVER BOXER150	Bajaj spare parts
PF541211	MAGNETO COVER BM100 KS	Bajaj spare parts
PF541217	LABEL COVER BOXER	Bajaj spare parts
PF541218	ASSLY CLUCTH COVER B104D	Bajaj spare parts
PF541237	ASSLY MAGNETO COVER B104D	Bajaj spare parts
PF541242	BRACKET STATOR HARNESS B104D	Bajaj spare parts
PF541244	ASSLY COVER LH RR B104D	Bajaj spare parts
PF541246	ASSLY MAGNETO COVER KS B104D	Bajaj spare parts
PF541248	ASSLY COVER LH RR B104D KS	Bajaj spare parts
PF541249	LABEL MAGNETO COVER B104D	Bajaj spare parts

PF541250	LABEL CLUTCH COVER B104D	Bajaj spare parts
PF541251	LABEL GEAR SHIFT ALL DOWN 4 SPEED	Bajaj spare parts
PF541253	ASSLY COVER LH RR B104E ES	Bajaj spare parts
PF541254	CAP FILTER B104E	Bajaj spare parts
PF541255	BRACKET CLUTCH CABLE B104E	Bajaj spare parts
PF541263	ASSLY COVER LH RR B108B	Bajaj spare parts
PF541267	COVER ASSEMBLY-REAR-LH	Bajaj spare parts
PF541268	COVER ASSLY REAR LH	Bajaj spare parts
PF541270	ASSLY COVER REAR LH	Bajaj spare parts
PF541272	BRACKET HARNESS STATOR	Bajaj spare parts
PF541286	GASKET COVER MAGNETO	Bajaj spare parts
PF541287	COVER ASSEMBLY LH REAR	Bajaj spare parts
PF541308	COVER ASSEMBLY REAR LH	Bajaj spare parts
PF541310	LABEL GEAR SHIFT	Bajaj spare parts
PF541311	COVER ASSEMBLY REAR LH	Bajaj spare parts
PF551000	ASSLY INPUT SHAFT BM150 4 SPD	Bajaj spare parts
PF551002	SHAFT INPUT BOXER150	Bajaj spare parts
PF551003	SHAFT OUTPUT BOXER150	Bajaj spare parts
PF551013	SHAFT INPUT	Bajaj spare parts
PF551200	GEAR 2ND DRIVE BOXER150	Bajaj spare parts
PF551201	GEAR 3RD DRIVE BOXER150	Bajaj spare parts
PF551202	GEAR 4TH DRIVE BOXER150	Bajaj spare parts
PF551203	GEAR 2ND DRIVEN BOXER150	Bajaj spare parts
PF551204	GEAR 3RD DRIVEN BOXER150	Bajaj spare parts
PF551205	GEAR 4TH DRIVEN BOXER150	Bajaj spare parts
PF551206	WASHER GEAR 2ND DRIVEN	Bajaj spare parts
PF551213	GEAR SECOND DRIVE	Bajaj spare parts
PF551214	GEAR FIFTH DRIVE	Bajaj spare parts
PF551215	GEAR SECOND DRIVEN	Bajaj spare parts
PF551230	BUSH	Bajaj spare parts
PF551401	CLUTCH HSG ASSLY COMP (BM100)	Bajaj spare parts
PF551403	CLUTCH ASSLY	Bajaj spare parts
PF551405	SPRING COMPRESSION	Bajaj spare parts
PF551406	HOLDER CLUTCH	Bajaj spare parts
PF551407	ROD PUSH B104D	Bajaj spare parts
PF551411	HUB CLUTCH B104D	Bajaj spare parts
PF551412	ASSLY CLUTCH B104D	Bajaj spare parts
PF551413	ASSLY CLUTCH B104D MAKINO	Bajaj spare parts
PF551422	BOLT FLANGE SPECIAL B104D	Bajaj spare parts
PF551423	SPRING COMPRESSION B104D	Bajaj spare parts
PF551426	HUB CLUTCH B104D	Bajaj spare parts
PF551427	CLUTCH LIFTER B104D	Bajaj spare parts
PF551428	PLATE PRESSURE B104D	Bajaj spare parts
PF551430	CLUTCH ASSEMBLY	Bajaj spare parts
PF551432	PLATE ASSEMBLY CLUTCH	Bajaj spare parts

PF551433	HUB CLUTCH	Bajaj spare parts
PF551436	WHEEL CLUTCH	Bajaj spare parts
PF551437	SPRING COMPRESSION	Bajaj spare parts
PF551438	HOLDER CLUTCH	Bajaj spare parts
PF551439	CLUTCH ASSEMBLY	Bajaj spare parts
PF551440	PLATE ASSEMBLY CLUTCH	Bajaj spare parts
PF551452	CLUTCH ASSEMBLY	Bajaj spare parts
PF561000	DRUM COMP BOXER 150	Bajaj spare parts
PF561002	SHAFT FORK SHIFT BOXER 150	Bajaj spare parts
PF561005	CAM DRUM B104E	Bajaj spare parts
PF561010	DRUM ASSEMBLY GEAR SHIFT	Bajaj spare parts
PF561200	LEVER GEAR SHIFT	Bajaj spare parts
PF561203	SPRING INHIBITOR B104D	Bajaj spare parts
PF561400	LEVER GEAR SHIFT COMP B104D	Bajaj spare parts
PF571000	PUMP OIL PUMP BOXER 150	Bajaj spare parts
PF571001	GEAR PUMP OIL BOXER	Bajaj spare parts
PF581000	ASSLY AIR FILTER BM100	Bajaj spare parts
PF581003	FILTER AIR ASSLY	Bajaj spare parts
PF581011	ELEMENT ASSEMBLY FILTER AIR	Bajaj spare parts
PF581012	ELEMENT AIRFILTER NEW BM150	Bajaj spare parts
PF581019	CARTRIDGE COVER ASSLY BM150	Bajaj spare parts
PF581038	ASSLY AIR FILTER B104D	Bajaj spare parts
PF581040	COVER SIDE AIR FILTER B1104D	Bajaj spare parts
PF581044	FOAM ELEMENT B104D	Bajaj spare parts
PF581045	ELEMENT ASSEMBLY FILTER AIR	Bajaj spare parts
PF581046	ARRESTER FLAME B104D	Bajaj spare parts
PF581047	TUBE BREATHER B104D	Bajaj spare parts
PF581048	TUBE DRAIN B104D	Bajaj spare parts
PF581049	RING SEAL AIR FILTER B104D	Bajaj spare parts
PF581051	DUCT INTAKE B104D	Bajaj spare parts
PF581052	TUBE CONNECTING B104D_26X100	Bajaj spare parts
PF581055	ASSLY AIR FILTER B104D WITH SAI	Bajaj spare parts
PF581057	AIR FILTER ASSEMBLY	Bajaj spare parts
PF581058	TUBE CONNECTING	Bajaj spare parts
PF581062	FILTER ASSLY AIR	Bajaj spare parts
PF581063	TUBE CONNECTING	Bajaj spare parts
PF581087	FILTER ASSLY AIR	Bajaj spare parts
PF581089	FILTER ASSLY AIR	Bajaj spare parts
PF581135	ELEMENT ASSEMBLY FILTER AIR	Bajaj spare parts
PF581136	ELEMENT FILTER AIR	Bajaj spare parts
PF581139	ARRESTER FLAME	Bajaj spare parts
PF581142	FILTER ASSEMBLY AIR	Bajaj spare parts
PF581146	FILTER ASSEMBLY AIR	Bajaj spare parts
PF581150	FILTER ASSEMBLY AIR	Bajaj spare parts
PF581164	FILTER ASSEMBLY AIR	Bajaj spare parts

PF581198	PIPE BREATHER	Bajaj spare parts
PF581200	CARBURETTOR BOXER 150	Bajaj spare parts
PF581215	ASSLY CARBURATOR B104D	Bajaj spare parts
PF581226	CARBURATOR ASSEMBLY	Bajaj spare parts
PF581227	ASSLY CARB B104E WITH EVAP	Bajaj spare parts
PF581228	CARBURETTOR ASSLY	Bajaj spare parts
PF581237	TUBE AIR VENT	Bajaj spare parts
PF581243	CARBURETTOR ASSLY	Bajaj spare parts
PF581244	CARBURETTOR	Bajaj spare parts
PF581264	CARBURETTOR	Bajaj spare parts
PF581266	SLEEVE CARBURETTOR	Bajaj spare parts
PF581268	CARBURETTOR	Bajaj spare parts
PF581271	CARBURETTOR	Bajaj spare parts
PF581272	CARBURETTOR	Bajaj spare parts
PF581273	CARBURETTOR	Bajaj spare parts
PF581282	CAP ASSEMBLY MIXING	Bajaj spare parts
PF581286	BODY ASSEMBLY FLOAT CHAMBER	Bajaj spare parts
PF581293	SCREW DRAIN	Bajaj spare parts
PF581296	FLOAT ASSEMBLY	Bajaj spare parts
PF581297	CARBURETTOR	Bajaj spare parts
PF581298	CARBURETTOR	Bajaj spare parts
PF581300	CARBURETTOR PTE	Bajaj spare parts
PF581329	CAP	Bajaj spare parts
PF581330	RING O	Bajaj spare parts
PF581361	CARBURETTOR	Bajaj spare parts
PF581400	MANIFOLD PTE16	Bajaj spare parts
PF581401	MANIFOLD CARBURETTOR	Bajaj spare parts
PF581402	SLEEVE VM21.5	Bajaj spare parts
PF581403	INSULATOR MANIFOLD BM100	Bajaj spare parts
PF581410	MANIFOLD INTAKE B104D PTE16	Bajaj spare parts
PF581411	ASSLY MANIFOLD B104D SAI	Bajaj spare parts
PF581423	INSULATOR MANIFOLD	Bajaj spare parts
PF581438	MANIFOLD ASSEMBLY INTAKE	Bajaj spare parts
PF581442	PIPE INTAKE	Bajaj spare parts
PF582400	HOSE INTAKE SAI B104D	Bajaj spare parts
PF582401	TUBE OUTLET SAI B104D ES	Bajaj spare parts
PF582402	HOSE CONNECTOR SAI B104D	Bajaj spare parts
PF582403	HOSE MANIFOLD B104D SAI	Bajaj spare parts
PF582404	TUBE OUTLET SAI B104E KS	Bajaj spare parts
PF582409	TUBE SAI OUTLET	Bajaj spare parts
PF582413	PIPE SAI	Bajaj spare parts
PF582414	PIPE SAI	Bajaj spare parts
PF582415	TUBE SAI OUTLET	Bajaj spare parts
PF582600	COVER SAI FILTER B104D	Bajaj spare parts
PF582601	FOAM ELEMENT SAI B104D	Bajaj spare parts

PF582602	RING O SAI B104D	Bajaj spare parts
PF582905	PIPE BREATHER	Bajaj spare parts
PF582982	FILTER ASSEMBLY AIR	Bajaj spare parts
PF591000	ASSLY SILENCER	Bajaj spare parts
PF591043	WIRE SHIELD BM150	Bajaj spare parts
PF591045	SHIELD MUFFLER (BM150)	Bajaj spare parts
PF591146	SHIELD SILENCER B104D	Bajaj spare parts
PF591327	SHIELD MUFFLER	Bajaj spare parts
PF591360	SILENCER ASSEMBLY	Bajaj spare parts
PF591378	SHIELD CAT	Bajaj spare parts
PF591455	SILENCER ASSEMBLY	Bajaj spare parts
PF591465	SHIELD MUFFLER	Bajaj spare parts
PF591474	SHIELD CATALYST	Bajaj spare parts
PF591486	SILENCER ASSEMBLY	Bajaj spare parts
PF591507	SHIELD CATALYST	Bajaj spare parts
PF591515	SILENCER ASSEMBLY	Bajaj spare parts
PF591599	SILENCER ASSEMBLY	Bajaj spare parts
PF611200	ASSLY THROTTLE BODY B103A	Bajaj spare parts
PF611213	BODY THROTTLE ASSEMBLY	Bajaj spare parts
PF621002	ASSLY KICK SHAFT B104D	Bajaj spare parts
PF621003	KICK SHAFT B104D	Bajaj spare parts
PF621005	SHAFT ASSLY KICK	Bajaj spare parts
PF621400	STARTER DRIVE ASSLY B104D	Bajaj spare parts
PF621402	BRACKET STOPPER GEAR B104D	Bajaj spare parts
PF621411	GEAR ASSLY STARTER CLUTCH	Bajaj spare parts
PF621413	GEAR ASSEMBLY CLUTCH STARTER	Bajaj spare parts
PF621416	STOPPER GEAR STARTER	Bajaj spare parts
PF71013E	P.TANK BM 150 ELE. BLUE DECAL	Bajaj spare parts
PF71013F	P.TANK BM 150 FL RED DECAL	Bajaj spare parts
PF7101X3	TANK FUEL EB BLACKBOXER 150	Bajaj spare parts
PF72013E	FR FENDER El. Blue	Bajaj spare parts
PF72013F	FR FENDER 150FLAME RED	Bajaj spare parts
PF7201X3	FR FENDER PAINTED BL	Bajaj spare parts
PF73013E	SIDE CVR LH BLU DEC	Bajaj spare parts
PF73013F	SIDE CVR L BM 150 Red	Bajaj spare parts
PF7301X3	SIDE COVER LH	Bajaj spare parts
PF73023E	SIDE CVR RH BLU DEC	Bajaj spare parts
PF73023F	SIDE CVR RH BM 150 FL RED DECAL	Bajaj spare parts
PF7302X3	SIDE CVR RH EBY BLK	Bajaj spare parts
PF73033E	SIDE COVER LH BM100	Bajaj spare parts
PF73033F	SIDE COVER LH RED DECAL	Bajaj spare parts
PF7303X3	COVER SIDE LH EBONY BLACK DECAL	Bajaj spare parts
PF73043E	COVER SIDE RH ELECTRON BLUE DECAL	Bajaj spare parts
PF73043F	COVER SIDE RH FLAME RED DECAL	Bajaj spare parts
PF7304X3	COVER SIDE RH EBONY BLACK DECAL	Bajaj spare parts



PF74013E	COWLING ELECTRON BLUE	Bajaj spare parts
PF74013F	COWLING FLAME RED	Bajaj spare parts
PF7401X3	COW BM 150 EBONY BLACK	Bajaj spare parts
RA171800	ASSLY HOSE MFV TO FILLING UG	Bajaj spare parts
RA172007	SPRING	Bajaj spare parts
RA172014	ASSEMBLY LPG REGULATOR	Bajaj spare parts
RA172018	REGULATOR LPG TWO STAGE	Bajaj spare parts
RA172020	HOSE LPR TO MIXER	Bajaj spare parts
RA172022	ASSLY HOSE MFV TO LPR UG	Bajaj spare parts
RA172031	ASSEMBLY BKT FILLING UNIT MTG UG	Bajaj spare parts
RA172032	ASSEMBLY FILLING VALVE UG	Bajaj spare parts
RA172041	BUSH RUBBER LPG HOSE UG	Bajaj spare parts
RA172042	REINFORCEMENT LPG MOUNTING	Bajaj spare parts
RA172044	REGULATOR LPG TWO STAGE	Bajaj spare parts
RA172047	ASSLY BRACKET HOSE MTG UG	Bajaj spare parts
RA172050	BRACKET CYLINDER MTG-LPG-LH	Bajaj spare parts
RA172051	BRACKET CYLINDER MTG-LPG-RH	Bajaj spare parts
RA172052	CYLINDER ASSEMBLY-LPG	Bajaj spare parts
RA172056	CYLINDER ASSLY-LPG	Bajaj spare parts
RA172057	ASSLY VALVE MULTIFUNCTION	Bajaj spare parts
RA172058	ASSLY SENDER UNIT	Bajaj spare parts
RA172059	VALVE SOLENOID	Bajaj spare parts
RA172063	HOSE VENT	Bajaj spare parts
RA172075	REGULATOR LPG	Bajaj spare parts
RA172076	HOSE MFV-SOLENOID	Bajaj spare parts
RA172078	REGULATOR LPG	Bajaj spare parts
RA172079	BRACKET SOLENOID	Bajaj spare parts
RA172092	SCREW FLOW CONTROL	Bajaj spare parts
RA172107	HOSE MFV-VAPORIZER	Bajaj spare parts
RA172108	HOSE SOLENOID-REGULATOR	Bajaj spare parts
RA172112	HOSE REGULATOR-FILTER	Bajaj spare parts
RA172113	HOSE FILTER-RAIL	Bajaj spare parts
RA181200	COVER ASSEMBLY CYLINDER	Bajaj spare parts
RA191003	ASSEMBLY SEAT DRIVER	Bajaj spare parts
RA351202	CDI	Bajaj spare parts
RA351203	ASSEMBLY CDI - LPG FL	Bajaj spare parts
RA351207	CDI ASSLY	Bajaj spare parts
RA401400	SWITCH G O P LPG VERTICAL FL	Bajaj spare parts
RA402003	REGULATOR ASSEMBLY	Bajaj spare parts
RA402205	HARNESS WIRING RR 205M LPGHARNESS WIRING	Bajaj spare parts
RA402207	HARNESS WIRING FR 205X LPGHARNESS WIRING	Bajaj spare parts
RA402209	HARNESS WIRING FR INT DB FL	Bajaj spare parts
RA402210	PIGTAIL WITH TRANSIL DIODE	Bajaj spare parts
RA402212	HARNESS WIRING FRONT UG	Bajaj spare parts
RA402214	HARNESS WIRING REAR	Bajaj spare parts

RA402216	HARNESS WIRING FRONT INT DB	Bajaj spare parts
RA402217	HARNESS WIRING-REAR	Bajaj spare parts
RA402218	HARNESS WIRING FRONT LPG	Bajaj spare parts
RA402220	HARNESS WIRING-REAR LPG	Bajaj spare parts
RA402221	HARNESS WIRING FRONT LPG	Bajaj spare parts
RA402222	HARNESS WIRING REAR	Bajaj spare parts
RA402230	HARNESS WIRING REAR	Bajaj spare parts
RA402241	HARNESS WIRING FRONT	Bajaj spare parts
RA402242	HARNESS WIRING REAR	Bajaj spare parts
RA402246	HARNESS WIRING FRONT	Bajaj spare parts
RA402247	HARNESS WIRING REAR	Bajaj spare parts
RA402252	HARNESS WIRING FRONT	Bajaj spare parts
RA402253	HARNESS WIRING REAR	Bajaj spare parts
RA402269	HARNESS WIRING REAR	Bajaj spare parts
RA402270	HARNESS WIRING FRONT	Bajaj spare parts
RA402272	HARNESS WIRING FRONT	Bajaj spare parts
RA402273	HARNESS WIRING REAR	Bajaj spare parts
RA402410	INSTRUMENT CLUSTER	Bajaj spare parts
RA402412	INSTRUMENT CLUSTER	Bajaj spare parts
RA402601	SOLENOID PETR	Bajaj spare parts
RA402602	INDICATOR ASSLY RH POD	Bajaj spare parts
RA402603	GAUGE LPG	Bajaj spare parts
RA402605	INDICATOR POD RH	Bajaj spare parts
RA402607	INDICATOR POD RH	Bajaj spare parts
RA501004	ENGINE ASSY. COMPLETE	Bajaj spare parts
RA501006	ENGINE ASSY- COMPACT LPG UG	Bajaj spare parts
RA501013	ENGINE ASSEMBLY	Bajaj spare parts
RA501021	ENGINE ASSEMBLY	Bajaj spare parts
RA501025	ENGINE ASSEMBLY	Bajaj spare parts
RA511001	GUIDE CHAIN SLACK SIDE	Bajaj spare parts
RA511002	GUIDE CHAIN TIGHT SIDE	Bajaj spare parts
RA511003	ASSLY HEAD CYLINDER	Bajaj spare parts
RA511005	HEAD CYLINDER	Bajaj spare parts
RA511200	CAMSHAFT ASSEMBLY	Bajaj spare parts
RA511201	CAMSHAFT	Bajaj spare parts
RA511202	CHAIN	Bajaj spare parts
RA511204	VALVE INTAKE	Bajaj spare parts
RA521200	ASSLY PISTON- UG LPG	Bajaj spare parts
RA531000	CRANKSHAFT ASSEMBLY	Bajaj spare parts
RA531001	SPROCKET CRANKSHAFT	Bajaj spare parts
RA541001	CRANKCASE MAGNETO SIDE	Bajaj spare parts
RA581004	ASSLY COMPLETE INTEGRAL DUCT	Bajaj spare parts
RA581012	ASSLY COMPLETE INTEGRAL DUCT	Bajaj spare parts
RA581015	DUCT ASSLY COMPLETE-INTEGRAL	Bajaj spare parts
RA581100	PIPE BREATHER	Bajaj spare parts

RA581205	CARBURETTOR ASSY.	Bajaj spare parts
RA581207	CARBURETTOR ASSY- FLANGE TYPE	Bajaj spare parts
RA581401	MANIFOLD INTAKE optima LPG	Bajaj spare parts
RA591000	SILENCER ASSY. COMPLETE	Bajaj spare parts
RA591001	MUFFLER ASSY. COMPLETE	Bajaj spare parts
RA591005	ASSLY - EXHAUST TUBE	Bajaj spare parts
RA591011	SILENCER ASSLY. COMPLETE	Bajaj spare parts
RA591012	MUFFLER ASSLY. COMPLETE	Bajaj spare parts
RA611200	BODY THROTTLE ASSEMBLY	Bajaj spare parts
RC113801	ASSLY BKT AIR FILTER MTG	Bajaj spare parts
RC581002	DUCT A/F INLET	Bajaj spare parts
RC581003	PIPE A/F INLET	Bajaj spare parts
RC581007	ASSLY AIR FILTER	Bajaj spare parts
RC581009	COVER AIR FILTER ASSY.	Bajaj spare parts
RC581400	ASSLY AIR INTAKE CARGO CNG	Bajaj spare parts
TA131845	DISC SENSOR SPEED REAR	Bajaj spare parts
YAF18022	INNER CABLE SPEEDO-AA191134	Bajaj spare parts
YAU02001	STRAINER PUMP FUEL FOR AA201375	Bajaj spare parts
YAZ08001	CAP RESERVOIR BOTTLE AA151112	Bajaj spare parts
YAZ08012	WHEEL CYL ASSY FR. Z BS6	Bajaj spare parts
YAZ08019	PROTECTION PLUG FR RE BS6	Bajaj spare parts
YAZ08027	SNAP CLIP-PASSENGER DOOR LATCH	Bajaj spare parts
YAZ08028	SNAP CLIP- DOOR LATCH LH(YELLOW)	Bajaj spare parts
YBF37005	UBJ(BF121133) REPAIR KIT-UCA	Bajaj spare parts
YBF37006	LBJ(BF121068) REPAIR KIT-LCA	Bajaj spare parts
YDH13001	HEADLAMP WIRING HARNESSRINDER-	Bajaj spare parts
YDH19001	HEADLIGHT ASSLY WO BULB	Bajaj spare parts
YDH19002	TOP COVER WITH SEALING RING	Bajaj spare parts
YDH19003	SILENCER WO SHIELDS	Bajaj spare parts
YDH19004	TOP COVER & O RING-PRICOL	Bajaj spare parts
YDH23001	TOP COVER & O RING ABS PRICOL	Bajaj spare parts
YDH31001	LH OUTER TUBE ENDURANCE	Bajaj spare parts
YDH31002	RH OUTER TUBE ENDURANCE	Bajaj spare parts
YDH31003	GROMMET-P125	Bajaj spare parts
YDH31004	SPRING-P125	Bajaj spare parts
YDH31005	FORK INNER PIPE	Bajaj spare parts
YDH31006	SLIDE BUSH	Bajaj spare parts
YDH32001	TOP COVER & O RING VARROC	Bajaj spare parts
YDH32002	TOP COVER & O RING PRICOL	Bajaj spare parts
YDH32003	LH OUTER TUBE-ENDURANCE	Bajaj spare parts
YDH32004	RH OUTER TUBE-ENDURANCE	Bajaj spare parts
YDH32005	HUB CLUTCH P125	Bajaj spare parts
YDJ08001	SILENCER WO SHIELD MUFFLER & WIRE SHIELD	Bajaj spare parts
YDK06002	SILENCER WO SHIELDS -P220 BS IV	Bajaj spare parts
YDK08001	TOP COVER & O RING ABS	Bajaj spare parts

YDM07001	SILENCER ASSLY WO SHIELDS-LAKSHMI	Bajaj spare parts
YDM07002	CONTROL SWITCH RH	Bajaj spare parts
YDM07004	CONTROL SWITCH LH	Bajaj spare parts
YDM11001	HOUSING HEADLIGHT-RINDER	Bajaj spare parts
YDM11002	LENSE REFLECTOR-RINDER	Bajaj spare parts
YDM11003	RIM-RINDER	Bajaj spare parts
YDM11004	HARNESS-RINDER	Bajaj spare parts
YDM11005	HOUSING HEADLIGHT-LUMAX	Bajaj spare parts
YDM11006	LENSE REFLECTOR-LUMAX	Bajaj spare parts
YDM11007	RIM-LUMAX	Bajaj spare parts
YDM11008	HARNESS-LUMAX	Bajaj spare parts
YDT02001	HIGH BEAM BULB-RINDER-RS200	Bajaj spare parts
YDT02002	PROJECTOR LOW BEAM ASSY WO BULB	Bajaj spare parts
YDT02003	PROJECTOR HIGH BEAM	Bajaj spare parts
YDT02004	SPD MTR TOP COVER WITH SEALING RING	Bajaj spare parts
YDT02005	GROMMET PROJECTOR -RINDER-RS 200	Bajaj spare parts
YDU10001	SILENCER ASSLY WITHOUT SHIELD-LAKSHMI	Bajaj spare parts
YDU10002	SPEEDOMETER TOP COV WITH S/R	Bajaj spare parts
YDU10003	SPEEDOMETER BACK COVER-MINDA	Bajaj spare parts
YDU10004	SPEEDOMETER HOUSING-MINDA	Bajaj spare parts
YDU10005	SPEEDOMETER WIRING HARNESS-MINDA	Bajaj spare parts
YDU10006	SPEEDOMETER WITH DIAL ONLY-MINDA	Bajaj spare parts
YDU10007	SPEEDOMETER TOP COVER	Bajaj spare parts
YDU10010	SPEEDOMETER WIRING HARNESS-PRICOL	Bajaj spare parts
YDU10013	CONTROL SWITCH RH	Bajaj spare parts
YDU12001	SILENCER ASSY WO SHIELDS	Bajaj spare parts
YDU16004	SPEEDO MACHINE-MINDA	Bajaj spare parts
YDU16006	WIRING HARNESS - PRICOL	Bajaj spare parts
YDU16008	SPEEDO MACHINE-PRICOL	Bajaj spare parts
YDU16009	SILENCER ASSY WO SHIELDS-CT100ES	Bajaj spare parts
YDU17001	STATOR PLATE WO EXCITOR COIL	Bajaj spare parts
YDU17002	EXCITOR COIL	Bajaj spare parts
YDU17003	SPEEDO MACHINE JNS	Bajaj spare parts
YDU17004	TOP COVER & O RING JNS	Bajaj spare parts
YDU17005	BACK COVER JNS	Bajaj spare parts
YDU17006	HOUSING JNS	Bajaj spare parts
YDU17007	WIRING HARNESS JNS	Bajaj spare parts
YDU18001	LH OUTER TUBE-GABRIEL	Bajaj spare parts
YDU18002	RH OUTER TUBE-GABRIEL	Bajaj spare parts
YDU19001	LH OUTER TUBE ENDURANCE	Bajaj spare parts
YDU19002	RH OUTER TUBE ENDURANCE	Bajaj spare parts
YDU19003	LH OUTER TUBE GABRIEL	Bajaj spare parts
YDU19004	RH OUTER TUBE GABRIEL	Bajaj spare parts
YDU22001	LH OUTER TUBE ENDURANCE	Bajaj spare parts
YDU22002	RH OUTER TUBE ENDURANCE	Bajaj spare parts

YDU22003	ADJUSTER NUT-LONG	Bajaj spare parts
YDU22004	ROD END	Bajaj spare parts
YDU22005	GROMMET	Bajaj spare parts
YDU22006	SPRING	Bajaj spare parts
YDU25002	WIRING HARNESS - MINDA	Bajaj spare parts
YDU25004	DIAL-MINDA	Bajaj spare parts
YDU25006	WIRING HARNESS - PRICOL	Bajaj spare parts
YDU25008	DIAL-PRICOL	Bajaj spare parts
YDU27002	DIAL-PRICOL	Bajaj spare parts
YDU27003	HARNESS-PRICOL	Bajaj spare parts
YDU27005	DIAL-MINDA	Bajaj spare parts
YDU27006	HARNESS-MINDA	Bajaj spare parts
YDY02001	REFLECTOR WITH RIM MINDA	Bajaj spare parts
YDY02002	HOUSING MINDA	Bajaj spare parts
YDY02003	HARNESS	Bajaj spare parts
YDY02007	HOUSING MINDA	Bajaj spare parts
YDY02008	WIRE HOLDER MINDA	Bajaj spare parts
YDY02009	REFLECTOR MINDA	Bajaj spare parts
YDY02011	LENSE & GASKET MINDA	Bajaj spare parts
YDY02018	SPEEDO HARNESS - PRICOL	Bajaj spare parts
YDY02021	FORK INNER PIPE	Bajaj spare parts
YDY02022	SPACER TUBE ENDURANCE	Bajaj spare parts
YDY04001	COMPRESSION SPRING MAKINO	Bajaj spare parts
YDY04003	HUB CLUTCH MAKINO	Bajaj spare parts
YDY04004	LIFTER MAKINO	Bajaj spare parts
YDY04005	PRESSURE PLATE MAKINO	Bajaj spare parts
YDY07001	SPACER TUBE CT 125X	Bajaj spare parts
YDY07002	LH OUTER TUBE CT 125X	Bajaj spare parts
YDY07003	RH OUTER TUBE CT 125X	Bajaj spare parts
YDY07004	O RING CUP FUEL TAP PAVNA	Bajaj spare parts
YDY07005	4 HOLE GASKET PAVNA CT125X	Bajaj spare parts
YDZ05005	TAIL LAMP WO BULB-VARROCRINDER-	Bajaj spare parts
YDZ05006	TAIL LAMP WIRING HARNESSVARROC-	Bajaj spare parts
YGL12046	MOV PCB-BOX SOCKET MAINS	Bajaj spare parts
YGL14001	MOV WITH COVER AND SCREW	Bajaj spare parts
YGL14002	GASKET MOV COVER	Bajaj spare parts
YGL14003	SCREW MOV COVER	Bajaj spare parts
YGL14004	BATTERY TELEMATIC	Bajaj spare parts
YGL14006	WASHER TELEMATIC	Bajaj spare parts
YGL14007	SCREW TELEMATIC	Bajaj spare parts
YGL14008	DAMPER TELEMATIC	Bajaj spare parts
YJD07003	HEADLAMP ASSY WO BULB	Bajaj spare parts
YJF04001	TOP COVER WITH SEALING RING	Bajaj spare parts
YJF04003	END CHAMBER WITHOUT SHIELD-VS400	Bajaj spare parts
YJF19001	TOP COVER & RING -TANK SPEEDO	Bajaj spare parts

YJF19002	TOP COVER & RING-MAIN SPEEDO	Bajaj spare parts
YJF19003	LH PIPE INNER & AXLE CLAMP	Bajaj spare parts
YJF19004	RH PIPE INNER & AXLE CLAMP	Bajaj spare parts
YJF19005	PISTON ROD ASSEMBLY	Bajaj spare parts
YJF19006	SCREW CAP INNER PIPE	Bajaj spare parts
YJF19007	SPRING & SPACER ASSEMBLY	Bajaj spare parts
YJF19008	RUBBER DAMPER	Bajaj spare parts
YJF19009	LOCK NUT	Bajaj spare parts
YJF19011	OUTER PIPE WITH BUSH	Bajaj spare parts
YJF22001	CAP RESERVOIR	Bajaj spare parts
YJF22002	RESERVOIR WITH CAP	Bajaj spare parts
YJF22004	HOSE RESERVOIR WITH CLAMPS	Bajaj spare parts
YJF22006	MASTER CYLINDER	Bajaj spare parts
YJF22009	CALIPER ASSEMBLY	Bajaj spare parts
YJF25001	H/L ASSEMBLY WO BULBS RINDER	Bajaj spare parts
YJF26001	LH PIPE INNER & AXLE CLAMP	Bajaj spare parts
YJF26002	RH PIPE INNER & AXLE CLAMP	Bajaj spare parts
YJF26003	PISTON ROD ASSEMBLY	Bajaj spare parts
YJF26004	SCREW CAP INNER PIPE	Bajaj spare parts
YJF26005	SPRING & SPACER ASSEMBLY	Bajaj spare parts
YJF26006	RUBBER DAMPER	Bajaj spare parts
YJF26007	LOCK NUT	Bajaj spare parts
YJF26008	OUTER PIPE ONLY	Bajaj spare parts
YJF26009	FORK TOP BOLT	Bajaj spare parts
YJF26011	FRICITION PLATE SET D250	Bajaj spare parts
YJF28007	HUB CLUTCH MAKINO NS125	Bajaj spare parts
YJF28008	LIFTER MAKINO NS125	Bajaj spare parts
YJF28009	PRESSURE PLATE MAKINO NS125	Bajaj spare parts
YJF29001	BOLT HANDLE LEVER KIT D400	Bajaj spare parts
YJG45001	SCREW CAP	Bajaj spare parts
YJG45002	OUTER TUBE	Bajaj spare parts
YJG45003	WP STICKER LH	Bajaj spare parts
YJG45004	WP STICKER RH	Bajaj spare parts
YJG45005	AXLE CLAMP<(>&<)>FORK PIPE ASSY LH	Bajaj spare parts
YJG45006	AXLE CLAMP&FORK PIPE ASSY RH	Bajaj spare parts
YJG45008	PIGTAIL - KTM DIAGNOSTIC TOOL	Bajaj spare parts
YJG45009	FR BRAKE PAD KIT SINT CHAMFER	Bajaj spare parts
YJG45011	PISTON ROD ASSEMBLY	Bajaj spare parts
YJG45012	MAIN SPRING	Bajaj spare parts
YJG48001	AXLE CLAMP&FORK PIPE LH	Bajaj spare parts
YJG48002	AXLE CLAMP &FORK PIPE RH	Bajaj spare parts
YJG48003	PISTON ROD ASSY	Bajaj spare parts
YJG48004	WP APEX BP STICKER IND LH	Bajaj spare parts
YJG48005	WP APEX BP STICKER IND RH	Bajaj spare parts
YJG48006	OUTER TUBE ASSY	Bajaj spare parts

YJG48007	FORK BOLT	Bajaj spare parts
YJG48008	MAIN SPRING & WASHER ASSY	Bajaj spare parts
YJH01001	WIRING HARNESS HEADLIGHT	Bajaj spare parts
YJH01002	SILENCER ASSY WO SHIELD	Bajaj spare parts
YJH01004	HOUSING W/HARNESS <(>&<)> INDICATION	Bajaj spare parts
YJH01006	SPEEDOMETER WITH DIAL	Bajaj spare parts
YJH01007	HEADLIGHT ASSY WO BULB	Bajaj spare parts
YJH01008	TAIL LAMP WO BEZEL-V15	Bajaj spare parts
YJH01009	BEZEL TAIL LAMP-V15	Bajaj spare parts
YJH01010	SILENCER ASSLY WO MUFFLER SHIELD & WI	Bajaj spare parts
YJH05001	HEADLIGHT ASSY WO BULB -V12	Bajaj spare parts
YJH05002	WIRING HARNESS HEADLIGHT-V12	Bajaj spare parts
YJH05003	SILENCER ASSY WO SHIELDS-V12	Bajaj spare parts
YJH05004	HOUSING WITH PANEL-V12	Bajaj spare parts
YJH05005	WIRING HARNESS SPEEDO-V12	Bajaj spare parts
YJH05006	FUEL GAUGE WITH DIAL-V12	Bajaj spare parts
YJK10003	SPEEDO MACHINE-PRICOL	Bajaj spare parts
YJK11001	TOP COVER WITH SEALING RING	Bajaj spare parts
YJK11002	ADJUSTER NUT-SMALL	Bajaj spare parts
YJK17001	H/L WO BULB LUMAX	Bajaj spare parts
YJK17002	HARNESS HEADLAMP-LUMAX	Bajaj spare parts
YJK17003	H/L WO BULB-RINDER	Bajaj spare parts
YJK17004	HARNESS HEADLAMP-RINDER	Bajaj spare parts
YJK17005	H/L WO BULB-VARROC	Bajaj spare parts
YJK17006	HARNESS HEADLAMP-VARROC	Bajaj spare parts
YJK17007	BEZEL WITH TAPE & HARDWARE	Bajaj spare parts
YJK17008	BULB HOLDER - VARROC	Bajaj spare parts
YJK17009	BULB HOLDER - LUMAX	Bajaj spare parts
YJK17011	TAIL-LAMP WO BULB	Bajaj spare parts
YJK19001	OUTER TUBE LH-ENDURANCE	Bajaj spare parts
YJK19002	HOUSING WITH HARNESS-MINDA	Bajaj spare parts
YJL02003	SPD MTR TOP COVER-JCPPL	Bajaj spare parts
YJL02004	SEALING RING TOP COVER-JCPPL	Bajaj spare parts
YJL02005	HEADLAMP WO BULB - RINDER -	Bajaj spare parts
YJL02006	HEADLAMP WIRING HARNESSRINDER-	Bajaj spare parts
YJL04004	MINOR KIT CALIPER FRONT	Bajaj spare parts
YJL04005	MAJOR KIT CALIPER ASSLY REAR	Bajaj spare parts
YJL04006	MINOR KIT CALIPER ASSLY REAR	Bajaj spare parts
YJL06001	RH POSITION LAMP-RINDER-AS150-AS200	Bajaj spare parts
YJL06002	LH POSITION LAMP-RINDER-AS150-AS200	Bajaj spare parts
YJL06003	HEADLAMP WIRING HARNESS-RINDER	Bajaj spare parts
YJL06004	HEADLAMP ASSY WO BULB-RINDER	Bajaj spare parts
YJL22011	LH FORK INNER PIPE	Bajaj spare parts
YJL22012	RH FORK INNER PIPE	Bajaj spare parts
YJL22013	OUTER TUBE ASSEMBLY	Bajaj spare parts

YJL22014	OIL SEAL STOPPER	Bajaj spare parts
YJL22015	OIL SEAL	Bajaj spare parts
YJL22016	LOCK NUT	Bajaj spare parts
YJL22017	FORK TOP BOLT WITH O RING	Bajaj spare parts
YJL22018	MAIN SPRING-SPACER ASSEMBLY	Bajaj spare parts
YJL22019	SEAT PIPE ASSEMBLY	Bajaj spare parts
YJP08001	LEVER LOCK PBT-GF20 (BLACK)	Bajaj spare parts
YJP40001	CARTRIDGE SPLIT COMP. CPL.	Bajaj spare parts
YJP40002	CARTRIDGE SPLIT REB. CPL.	Bajaj spare parts
YJP40003	KIT FORK OIL SEAL SKF RED	Bajaj spare parts
YJP41001	CARTRIDGE SPLIT COMP CPL	Bajaj spare parts
YJP41002	CARTRIDGE SPLIT REB CPL	Bajaj spare parts
YJP41003	AXLE CLAMP&FORK PIPE ASSY LH	Bajaj spare parts
YJP41004	AXLE CLAMP&FORK PIPE ASSEMBLY RH	Bajaj spare parts
YJP42001	AXLE CLAMP&FORK PIPE RH JP121070	Bajaj spare parts
YJP42002	AXLE CLAMP&FORK PIPE LH JP121070	Bajaj spare parts
YJP42003	PISTON ROD ASSEMBLY (JP121070)	Bajaj spare parts
YJP42004	OUTER TUBE ASSEMBLY (JP121070)	Bajaj spare parts
YJP62001	FUEL PUMP REPAIR KIT	Bajaj spare parts
YJP68001	AXLE CLAMP&FORK PIPE RH	Bajaj spare parts
YJP68002	OUTER TUBE ASSEMBLY	Bajaj spare parts
YJR02001	O RING MIKUNI THROTTLE BODY	Bajaj spare parts
YJR02002	LH OUTER TUBE P150	Bajaj spare parts
YJR02003	RH OUTER TUBE P150	Bajaj spare parts
YJR02004	FORK INNER PIPE P150	Bajaj spare parts
YJR02005	MAIN SPRING P150	Bajaj spare parts
YJR03001	BUSH HEADLAMP NS250	Bajaj spare parts
YJR05001	BEZEL HEADLAMP	Bajaj spare parts
YJR05002	SPACER TUBE	Bajaj spare parts
YJR05003	MAIN SPRING	Bajaj spare parts
YJR05004	SEAT PIPE	Bajaj spare parts
YJR05005	CAP OIL LOCK	Bajaj spare parts
YJR05006	FORK PIPE SPINNING	Bajaj spare parts
YJR05007	SOCKET HEADED BOLT	Bajaj spare parts
YJR05008	OUTER TUBE LH	Bajaj spare parts
YJR05009	OUTER TUBE RH	Bajaj spare parts
YJR05011	CENTER CLUTCH	Bajaj spare parts
YJR05012	PLATE CLUTCH	Bajaj spare parts
YJR05015	PLATE CLUTCH PRESSURE	Bajaj spare parts
YJR05016	SPRING CLUTCH	Bajaj spare parts
YJR05017	SEAT JUDDER SPRING	Bajaj spare parts
YJR05018	SPRING JUDDER	Bajaj spare parts
YJR05019	PLATE CLUTCH LIFTER	Bajaj spare parts
YJR05021	BOLT FLANGE	Bajaj spare parts
YJR06001	FORK BOLT PULSAR N160	Bajaj spare parts



YJR06002	MAIN SPRING PULSAR N160	Bajaj spare parts
YJR06003	SEAT PIPE PULSAR N160	Bajaj spare parts
YJR06004	FORK PIPE SPINNING PULSAR N160	Bajaj spare parts
YJR06005	OUTER TUBE LH PULSAR N160	Bajaj spare parts
YJR06006	OUTER TUBE RH PULSAR N160	Bajaj spare parts
YJR06007	CENTER CLUTCH PULSAR N160	Bajaj spare parts
YJR06012	PLATE CLUTCH PRESSURE N160	Bajaj spare parts
YJR06013	SPRING CLUTCH PULSAR N160	Bajaj spare parts
YJR06014	PLATE CLUTCH LIFTER PULSAR N160	Bajaj spare parts
YJR06015	BOLT FLANGE PULSAR N160	Bajaj spare parts
YJU34001	OUTER TUBE ASSY (JU121123)	Bajaj spare parts
YJU34002	KIT FORK OIL SEAL SKF BLK	Bajaj spare parts
YJY0E001	AXLE CLAMP & FORK PIPE LH	Bajaj spare parts
YJY0E002	AXLE CLAMP & FORK PIPE RH	Bajaj spare parts
YJY0E003	PISTON ROD ASSEMBLY	Bajaj spare parts
YJY0E004	MAIN SPRING & WASHER ASSY	Bajaj spare parts
YJY10003	FR MCYL PUSH ROD Ø 13	Bajaj spare parts
YJY10004	MASTER CYL KIT MINOR FR DIA 13	Bajaj spare parts
YJY10005	FUEL PUMP REPAIR KIT	Bajaj spare parts
YJY95001	AXLE CLAMP & FORK PIPE LH	Bajaj spare parts
YJY96001	AXLE CLAMP & FORK PIPE LH	Bajaj spare parts
YJY96002	AXLE CLAMP & FORK PIPE RH	Bajaj spare parts
YJY96005	SPECIAL BOLT M8	Bajaj spare parts
YJY96006	BELLEVILLE SPRING	Bajaj spare parts
YJY96007	SOCKET HEADED BOLT M8X1.25X20	Bajaj spare parts
YJZ08003	SPD MTR TOP COVER-D125	Bajaj spare parts
YJZ08006	SEALING RING TOP COVER-PRICOL	Bajaj spare parts
YJZ08008	SEAL.RING MTR-D125ST	Bajaj spare parts
YJZ08009	SPD MTR BACK COVER-	Bajaj spare parts
YJZ08010	KNOB TRIP GROMMET-JCPL	Bajaj spare parts
YJZ14004	SILENCER ASSLY W/O SHIELDS	Bajaj spare parts
YJZ16001	SPD MTR TOP COVER WITH SEALING RING	Bajaj spare parts
YJZ28001	SILENCER WO SHIELDS D125 BS4	Bajaj spare parts
YJZ45001	LH OUTER TUBE ENDURANCE	Bajaj spare parts
YJZ45002	RH OUTER TUBE ENDURANCE	Bajaj spare parts
YPA08002	HEADLAMP WIRING HARNESSRINDER	Bajaj spare parts
YPA13001	LOCK SET-D100M	Bajaj spare parts
YPA13002	HEADLAMP W/O BULB-D100M	Bajaj spare parts
YPA13003	TAIL LAMP W/O BULB-D100M	Bajaj spare parts
YPA13004	SPD MTR WITH DAIL	Bajaj spare parts
YPA13005	FUEL GAGUE WITH DAIL-MINDA-D100	Bajaj spare parts
YPA13006	SPD MTR TOP COVER-MINDA-D100M	Bajaj spare parts
YPA13007	SPD MTR HARNESS-MINDA-D100M	Bajaj spare parts
YPA13008	SEALING RING METER-MINDA-D100M	Bajaj spare parts
YPA13009	SEALING RING TOP COVER-MINDA	Bajaj spare parts

YPA13010	SPD MTR BACK COVER-MINDA	Bajaj spare parts
YPA13014	LOCK SET-DISCO 100M DC	Bajaj spare parts
YPA13017	SPD MTR TOP COVER-JNS -D100M	Bajaj spare parts
YPA13019	SEALING RING TOP COVER-JNS	Bajaj spare parts
YPA13021	SPD HOUSING-MINDA-D100M	Bajaj spare parts
YPA13023	TAIL LAMP WIR HAR BULB HOLD	Bajaj spare parts
YPA15002	SPD MTR WITH DAILMINDA D125M	Bajaj spare parts
YPA15003	SPD MTR HARNESS MINDA D125M	Bajaj spare parts
YPA26006	HEADLAMP WO BULB & WITH DRL	Bajaj spare parts
YPA26007	WIRING HARNESS HEADLAMP	Bajaj spare parts
YPA26008	TOP COVER WITH SEALING RING	Bajaj spare parts
YPA26009	SILENCER ASSY WITHOUT SHIELD	Bajaj spare parts
YPD01001	TAIL LAMP WO BULB-LUMAX	Bajaj spare parts
YPD01002	TAIL LAMP WIRING HARNESSLUMAX	Bajaj spare parts
YPD01003	HEADLAMP WIRING HARNESS -	Bajaj spare parts
YPD01004	HEADLAMP WO BULB-LUMAX	Bajaj spare parts
YPD01005	HEADLAMP HOUSING	Bajaj spare parts
YPD01007	HEADLAMP ASSY WO BULB	Bajaj spare parts
YPD01008	HEADLAMP HARNESS-AVENGER	Bajaj spare parts
YPD01009	RUBBER CAP HEADLAMP-AVENGER	Bajaj spare parts
YPD01010	INDICATOR LENS-AVENGER	Bajaj spare parts
YPD01011	SILENCER ASSY WO SHIELD-AVENGER 220	Bajaj spare parts
YPD02001	SILENCER ASSY WO SHIELD -AVENGER 150	Bajaj spare parts
YPD02002	HEADLAMP ASSY WO BULB	Bajaj spare parts
YPD02003	RIM HEADLIGHT - AVENGER	Bajaj spare parts
YPD02004	LENS TO REFLECTOR ASSY -AVENGER	Bajaj spare parts
YPD03001	HEADLAMP HOUSING - AVENGER 220-150	Bajaj spare parts
YPD03002	SILENCER SHIELD-AVEN 220	Bajaj spare parts
YPD14001	H/L WITH DRL-STREET	Bajaj spare parts
YPD14002	BACK COVER-STREET	Bajaj spare parts
YPD14003	H/L MTG BRACKET -STREET	Bajaj spare parts
YPD14004	WIRING HARNESS-STREET	Bajaj spare parts
YPD15001	TAIL LAMP WITHOUT BULB	Bajaj spare parts
YPD15002	WIRE HOLDER ASSLY	Bajaj spare parts
YPD15003	H/L WITH DRL-CRUISE	Bajaj spare parts
YPD15004	BEZEL HEADLAMP-CRUISE	Bajaj spare parts
YPD15005	BACK COVER-CRUISE	Bajaj spare parts
YPD15006	H/L MTG BRACKET -CRUISE	Bajaj spare parts
YPD15007	WIRING HARNESS-CRUISE	Bajaj spare parts
YPD25001	SILENCER WO SHIELDS-180 STREET	Bajaj spare parts
YPD28001	SILENCER ASSEMBLY WO SHIELDS	Bajaj spare parts
YPD30001	SILENCER ASSY WO SHIELDS	Bajaj spare parts
YPD31001	SILENCER ASSY WO SHIELDS	Bajaj spare parts
YPD34001	SILENCER ASSY WO SHIELDS AV 160	Bajaj spare parts
YPF08001	SILENCER ASSLY WO SHIELD	Bajaj spare parts

YPF08006	SEALING RING METER MINDA	Bajaj spare parts
YPF08007	SPEEDOMETER WIRING HARNESS MINDA	Bajaj spare parts
YPF08008	COVER TOP SPEEDOMETER MINDA	Bajaj spare parts
YPF08009	FUEL GAUGE WITH DIAL MINDA	Bajaj spare parts
YPF08010	SPEEDOMETER WITH DIAL ONLY-PLATINA	Bajaj spare parts
YPF08011	FUEL GAUGE WITH DIAL PRICOL	Bajaj spare parts
YPF08015	COVER TOP SPEEDOMETER PRICOL	Bajaj spare parts
YPF08016	SPEEDOMETER WIRING HARNESS PRICOL	Bajaj spare parts
YPF08017	SPEEDOMETER WITH DIAL PRICOL	Bajaj spare parts
YPF12001	SILENCER WO SHIELD PLATINAUG	Bajaj spare parts
YPF19004	WIRING HARNESS-MINDA	Bajaj spare parts
YPF19006	SPEEDO MACHINE-MINDA	Bajaj spare parts
YPF19011	WIRING HARNESS-PRICOL	Bajaj spare parts
YPF19013	SPEEDO MACHINE-PRICOL	Bajaj spare parts
YPF19014	BRACKET SPEEDO-MINDA	Bajaj spare parts
YPF19015	BRACKET SPEEDO-PRICOL	Bajaj spare parts
YPF21001	HL ASSY WO BULB	Bajaj spare parts
YPF21002	DUST CAP H/L	Bajaj spare parts
YPF27002	WIRING HARNESS-MINDA	Bajaj spare parts
YPF27003	SPEEDO MACHINE-MINDA	Bajaj spare parts
YPF27005	WIRING HARNESS-PRICOL	Bajaj spare parts
YPF27006	SPEEDO MACHINE-PRICOL	Bajaj spare parts
YPF27007	BEZEL H/L RINDER	Bajaj spare parts